

## N O T I C E

THIS DOCUMENT HAS BEEN REPRODUCED FROM  
MICROFICHE. ALTHOUGH IT IS RECOGNIZED THAT  
CERTAIN PORTIONS ARE ILLEGIBLE, IT IS BEING RELEASED  
IN THE INTEREST OF MAKING AVAILABLE AS MUCH  
INFORMATION AS POSSIBLE

DOE/NASA CONTRACTOR  
REPORT

DOE/NASA CR-161480

INSTALLATION GUIDELINES FOR SOLAR HEATING SYSTEM,  
SINGLE-FAMILY RESIDENCE AT WILLIAM O'BRIEN STATE PARK,  
STILLWATER, MINNESOTA

Prepared from documents furnished by

Honeywell, Inc.  
Energy Resources Center  
2600 Ridgway Parkway, N.E.  
Minneapolis, Minnesota 55413

Under Contract NAS8-32093 with

National Aeronautics and Space Administration  
George C. Marshall Space Flight Center, 35812

For the U. S. Department of Energy




(NASA-CR-161480) INSTALLATION GUIDELINES  
FOR SOLAR HEATING SYSTEM, SINGLE-FAMILY  
RESIDENCE AT WILLIAM OBRIEN STATE PARK,  
STILLWATER, MINNESOTA (Honeywell, Inc.)  
187 p HC A09/MF A01


N80-28861

Unclas  
CSCL 10B G3/44 28169

**U.S. Department of Energy**



**Solar Energy**

1. REPORT NO. DOE/NASA CR-161480	2. GOVERNMENT ACCESSION NO.	3. RECIPIENT'S CATALOG NO.	
4. TITLE AND SUBTITLE Installation Guidelines for Solar Heating System, Single-Family Residence at William O'Brien State Park, Stillwater, Minnesota		5. REPORT DATE May, 1980	6. PERFORMING ORGANIZATION CODE
		8. PERFORMING ORGANIZATION REPORT #	
7. AUTHOR(S)		10. WORK UNIT NO.	11. CONTRACT OR GRANT NO. NAS8-32093
9. PERFORMING ORGANIZATION NAME AND ADDRESS Honeywell, Inc., Energy Resources Center 2600 Ridgway Parkway, N.E. Minneapolis, Minnesota 55413		13. TYPE OF REPORT & PERIOD COVERED Contractor Report	
		14. SPONSORING AGENCY CODE	
12. SPONSORING AGENCY NAME AND ADDRESS National Aeronautics and Space Administration Washington, DC 20546			
15. SUPPLEMENTARY NOTES  This work was done under the technical management of Mr. John Parker, George C. Marshall Space Flight Center, Alabama.			
16. ABSTRACT  This document provides the Solar Heating System installer guidelines for each subsystem and includes testing and filling the system. This single-family residential heating system is a solar-assisted, hydronic-to-warm-air system with solar-assisted domestic water heating. It is composed of the following major components:  <ul style="list-style-type: none"> <li>o Liquid cooled flat plate collectors</li> <li>o Water storage tank</li> <li>o Passive solar-fired domestic water preheater</li> <li>o Electric hot water heater</li> <li>o Heat pump with electric backup</li> <li>o Solar hot water coil unit</li> <li>o Tube-and-shell heat exchanger, three pumps, and associated pipes and valving in an energy transport module</li> <li>o Control system</li> <li>o Air-cooled heat purge unit</li> </ul> This document also provides information on the operating procedures, controls, caution requirements, and routine and schedule maintenance. Information consists of written procedures, schematics, detail drawings, pictures and manufacturer's component data.			
17. KEY WORDS		18. DISTRIBUTION STATEMENT Unclassified-Unlimited UC-59c   WILLIAM A. BROOKSBANK, JR. Mgr. Solar Energy Applications Projects	
19. SECURITY CLASSIF. (of this report) Unclassified	20. SECURITY CLASSIF. (of this page) Unclassified	21. NO. OF PAGES 179	22. PRICE NTIS

## TABLE OF CONTENTS

	Page
SECTION I INTRODUCTION.....	I-1
A) SCOPE.....	I-1
B) SINGLE-FAMILY RESIDENTIAL HEATING SYSTEM DESCRIPTION.....	I-1
C) SYSTEM OPERATION.....	I-3
D) LIMITATIONS.....	I-4
SECTION II SOLAR HEATING SUBSYSTEMS AND COMPONENTS....	II-1
A) COLLECTOR SUBSYSTEM.....	II-1
A-1. Solar Collectors.....	II-1
A-2. Purge Coil Unit.....	II-2
A-3. Diverting Valve.....	II-2
B) STORAGE SUBSYSTEM.....	II-2
C) AUXILIARY ENERGY AND SPACE HEATING SUB- SYSTEM.....	II-2
D) HOT WATER SUBSYSTEM.....	II-3
E) ENERGY TRANSPORT SUBSYSTEM.....	II-3
F) CONTROL SUBSYSTEM.....	II-6
Direct Heating from Collectors.....	II-7
Heating from Storage.....	II-7
Storage Charging.....	II-7
Heat Rejector Control.....	II-7
Auxiliary Heating.....	II-7
G) SITE DATA ACQUISITION SUBSYSTEM (SDAS)....	II-8
Data Collection.....	II-8
Data System Overview.....	II-8
Operation and Maintenance.....	II-9



SECTION III	SUBSYSTEM INSTALLATION GUIDELINES.....	III-1
A)	COLLECTOR SUBSYSTEM.....	III-1
B)	STORAGE SUBSYSTEM.....	III-4
C)	AUXILIARY ENERGY AND SPACE HEATING SUB- SYSTEM.....	III-4
D)	DOMESTIC HOT WATER SUBSYSTEM.....	III-13
E)	ENERGY TRANSPORT SUBSYSTEM.....	III-13
F)	CONTROL SUBSYSTEM.....	III-20
G)	SITE DATA ACQUISITION SUBSYSTEM (SDAS).....	III-26
SECTION IV	SYSTEM TEST AND FILLING.....	IV-1
A)	TESTING.....	IV-1
B)	FLUSHING AND CLEANING.....	IV-1
C)	BALANCING.....	IV-7
D)	START-UP.....	IV-8
E)	SYSTEM CHECK-OUT.....	IV-8
SECTION V	OPERATION.....	V-1
SECTION VI	MAINTENANCE.....	VI-1
A)	COLLECTOR SUBSYSTEM.....	VI-2
B)	STORAGE SUBSYSTEM.....	VI-2
C)	AUXILIARY ENERGY AND SPACE HEAT SUBSYSTEM..	VI-3
D)	HOT WATER SUBSYSTEM.....	VI-3
E)	ENERGY TRANSPORT SUBSYSTEM.....	VI-3
F)	CONTROL SUBSYSTEM.....	VI-4
SECTION VII	MAINTENANCE SCHEDULE.....	VII-1

#### APPENDIX

A.	COLLECTOR SUBSYSTEM.....	A-1
B.	STORAGE SUBSYSTEM.....	B-1
C.	AUXILIARY ENERGY & SPACE HEATING SUBSYSTEMS.....	C-1

D.	INSTALLATION OF DOMESTIC HOT WATER SUBSYSTEM.....	D-1
E.	ENERGY TRANSPORT SUBSYSTEM.....	E-1
F.	CONTROL SUBSYSTEM.....	F-1
G.	GENERAL SDAS INSTALLATION.....	G-1

## LIST OF FIGURES

<u>FIGURE</u>		<u>PAGE</u>
	Sheet 2 of SK 142057 SFR System Information.....	I-2
2-1	Solar Heating System Control Schematic.....	II-6
2-2	Site Instrumentation Interface Hardware.....	II-10
2-3	Honeywell Stillwater Solar Energy System Schematic.....	II-11
	Sheet 2 of SK 142049 SFR Collector Subsystem.....	III-2
	Sheet 4 of SK 142049 SFR Collector Subsystem.....	III-5
	Sheet 2 of SK 142050 SFR Storage Subsystem.....	III-6
	Sheet 1 of SK 142051 SFR Auxiliary Energy & Space Heating.....	III-7
C-1	G11 Series Furnace Installation.....	III-8
C-2	G11 Series Furnace Installation.....	III-9
C-3	G11 Series Furnace Installation.....	III-10
	Sheet 3 of SK 142051 SFR Auxiliary Energy & Space Heating.....	III-11
C-4	Installation Instructions CW3-45.....	III-12
	Sheet 1 of SK 142052 SFR Hot Water Subsystem.....	III-14
D-2	Installation and Operating Instructions, DHW.....	III-15
D-1	Instructions for Installing - Tempering Valve....	III-16
	Sheet 1 of SK 142053 SFR Energy Transport System.	III-17
	Sheet 2 of SK 142053 SFR Energy Transport System.	III-18

	Sheet 3 of SK 142057 SFR System Integration.....	III-19
	Sheet 3 of SK 142054 SFR Control Subsystem.....	III-21
	Sheet 4 of SK 142055 SFR Data Acquisition Sub- system.....	III-22
	Sheet 1 of SK 142054 SFR Control Subsystem.....	III-23
	Sheet 2 of SK 142054 SFR Control Subsystem.....	III-24
F-2	Removing Cover Frame.....	III-25
F-3	Dissassembling Cover Frame.....	III-25
F-1	Control Panel Potentiometer Set.....	III-26
	Sheet 1 of SK 142055 SFR - SDAS.....	III-28
G-1	SDAS Module & J-Box Installation.....	III-29
G-2	Auxiliary Heat SDAS Sensor Installation.....	III-30
	Sheet 2 of SK 142055 SFR-SDAS.....	III-31
	Sheet 3 of SK 142055 SFR-SDAS.....	III-32
	Sheet 4 of SK 142055 SFR-SDAS.....	III-33
4-1	ETM Front View.....	IV-2
4-2	ETM Top View.....	IV-3
4-3	ETM End View (Left).....	IV-4
4-4	System Checkout.....	IV-9
6-E-1	Quantities of Inhibitor.....	VI-4
7-1	Routine Maintenance.....	VII-1

## SECTION I

### INTRODUCTION

#### A) SCOPE

This document provides the Solar Heating System installer guidelines for the installation of each subsystem as well as the testing and filling of the system, operation and maintenance instructions.


#### B) SINGLE-FAMILY RESIDENTIAL HEATING SYSTEM DESCRIPTION

The single-family residential heating system is a single-loop, solar-assisted, hydronic-to-warm air heating system with solar-assisted domestic water heating. The system is composed of the following major components:

- Liquid cooled flat plate collectors
- A water storage tank
- A passive solar-fired domestic water preheater
- A gas-fired hot water heater
- A gas-fired warm air furnace with hot-water coil unit
- A tube-and-shell heat exchanger, three pumps, and associated pipes and valving in an energy transport module.
- A control system
- An air-cooled heat purge unit

The arrangements of components within the system is as shown on Sheet 2 of SK 142057. The system consists of a glycol/water collector loop which interfaces with a water storage loop, through a tube-and-shell heat exchanger. A domestic hot water preheat coil is located in the storage tank.

The glycol/water collector loop consists of the solar collectors, the shell side of the heat exchanger, the purge coil and pump  $P_1$ , and a control valve as required for the different modes of operation.



**WOLFE**

PROJECT LOCATION		SHEET 2 OF 3	
CONTACT		SCALE 1" = 10'	
SHEET 1 OF 1		DATE 12/1/81	
PROJECT NAME		SINGLE FAMILY RESIDENCE	
OWNER		HONEYWELL INC.	
DESIGNER		SINGLE FAMILY RESIDENCE	
DATE		SYSTEM INTEGRATION	
PROJECT NO.		55513	
SHEET NO.		5K-142057	
SHEET 1 OF 1		SHEET 2 OF 3	

The water side of the heat exchanger is a direct heating/storage loop consisting of the storage tank, control valve, pumps  $P_2$  and  $P_3$ , the tube side of the heat exchanger and the solar heating coil.

The system provides six modes of operation:

- Direct heating from collectors
- Direct heating from storage
- Auxiliary heating (insufficient solar)
- Storage charging
- Continuous domestic hot water preheating
- Purging excess energy

### C) SYSTEM OPERATION

When space heating is required and solar energy from the collectors is available, the collectors supply heat to the furnace. Energy transfer is through the heat exchanger then via the solar hot water coil in the return air duct. Pumps  $P_1$  in the solar collector loop and  $P_2$  in the water loop provide movement of the heat transport through valve  $V_2$  to the heating coil. The blower moves the building air across this heating coil. When the heating demand is satisfied, valve  $V_2$  diverts the water fluid to the top of the storage tank. Pumps  $P_1$  and  $P_2$  provide movement of the heat transport fluids to charge the storage tank. Storage charging occurs by circulating water from the tank bottom through the heat exchanger and returning the heated water to the top of the storage tank, thus taking advantage of stratification. During high solar insolation and low heating and storage demands, if surplus energy is collected, then valve  $V_1$  diverts collector loop flow to the purge coil. The purge coil operates to maintain the system fluid temperatures below preselected values.

When space heating is required and direct solar energy is not available, thermal storage supplies heat to the furnace. Pump  $P_3$  circulates the water from the top of the tank through the solar hot

water coil and returns the cooler water to the bottom of the storage tank, again taking advantage of tank stratification. If the storage tank temperature is not high enough to provide space heating, the second stage thermostat activates the auxiliary furnace to maintain a comfortable building temperature.

**D) LIMITATIONS**

These installation guidelines are intended as a general guide and do not supersede local codes in any way. Authorities having jurisdiction should be consulted before installation to comply with all applicable building codes.

## SECTION II

### SOLAR HEATING SUBSYSTEMS AND COMPONENTS

The Solar Heating system consists of the following subsystems:

- Collector
- Storage
- Auxiliary Energy and Space Heating
- Hot water
- Energy transport
- Control

A description of each subsystem is given in the following sections. Information on the major components within each subsystem is provided in the Appendices under the same alphabetical tab.

#### A. Collector Subsystem

The collector subsystem consists of 33 Lennox LSC 18-1 solar collectors, a purge coil unit Lennox HRW-1-30, a diverting valve (V2), Honeywell Part Y534A, headers, supply/returns lines and isolation and balancing valves.

The solar collectors should operate without any special attention. However, excessive temperatures can be achieved if pumps  $P_1$  and  $P_2$  are in the off position and direct solar energy is available. Pump  $P_2$  can be turned off and pump  $P_1$  can be operated during daylight hours if flow is directed through the purge unit. Caution should be taken if pump  $P_1$  is left running at night during below freezing conditions as the water in the tube side of the heat exchanger can be frozen and rupture the unit.

##### A-1. Solar Collectors

The LSC 18-1 is double glass cover, flat plate collector. The tempered, low-iron glass has an acid etched surface to reduce reflection. The steel absorber plate has a special black chrome coating for high solar absorptivity. The absorber plate is formed around the copper fluid tubes and is all incased in an insulated, formed, galvanized steel box.



## **A-2. Purge Coil Unit**

The purge coil unit is a fin and tube coil and blower unit that is mounted outside the dwelling. It is used to get rid of excess heat energy the collectors may be collecting.

## **A-2. Diverting Valve**

The diverting valve is a dual unit consisting of two valve bodies which are plumbed together. These are controlled by two powerheads which move each valve separately. This valve is used to divert the liquid coming from the solar collectors to the purge coil unit as required.

See Appendix A for details on these components.

## **B. Storage Subsystem**

The storage subsystem consists of a 1000 gallon lined steel tank. The tank is designed to operate at ambient pressure and is vented to the space enclosing it. The water in the tank is neutralized with an inhibitor to reduce corrosion of system components.

The storage tank is filled to a level which is 6 inches from the top of the tank. Initial fill level is marked with a red band on the sight glass. If the water level is more than 3 inches below this level additional water should be added to the storage tank. This is accomplished by removing manhole cover, using hose connected to domestic water, fill system until level in sight glass is up to red band on sight glass.

Components in the storage subsystem are standard "off-the-shelf" plumbing components. See Appendix B for parts list.

## **C. Auxiliary Energy and Space Heating Subsystem**

This subsystem consists of a Lennox G11Q3-82V gas fired furnace and a Lennox CW3-45 solar heat coil. The furnace is a standard up flow unit with an output rating of 65,600 Btu/hr. The heat coil is a fin and tube unit designed to be inserted in the return air flow.

The furnace functions as an air handling unit when the solar heated water is above 90°F and there is a call for heat in the dwelling. If the solar heated water is not hot enough the furnace gas burner will turn on and provide heat until demand is satisfied.

**C. (continued)**

Various blower speeds are available on the furnace. However, a new speed which is lower than the initial speed set by the installer should not be used as this can result in less solar energy utilized and consequently higher fossil fuel consumption rates.

The G11Q3 furnace and CW3-45 heat coil maintenance and repair instructions are in Appendix C.

**D. Hot Water Subsystem**

The domestic hot water subsystem consists of a preheat coil submerged in the 1000 gallon storage tank, a 40 gallon gas fired water heater and a mixing valve. When hot water is utilized, make-up cold water from the domestic water supply flows through the preheat coil and undergoes an increase in temperature. If the storage tank temperature is below 150°-160°F the preheated water will be below 140°. The gas fired water heater will maintain water temperature at 140°. If the storage tank temperature is greater than 160°F then the preheated DH water may be over 140°F. In this case the mixing valve then adds cold water to bring the water temperature down to 140°F before entering the domestic hot water heater.

The temping valve setting should be kept at 140°F.

The hot water subsystem components are shown in Appendix D.

**E. Energy Transport Subsystem**

This subsystem contains most of the active components of the solar heating system, i.e., the Energy Transport Module (ETM). The pumps to move the fluid, the valve that diverts from storage to the heating coil, the heat exchanger, an expansion tank, the control panel, circuit setters and fill and drain valves are all in the ETM.

ETM Components and Functions (Appendix E)

Pumps 1, 2, and 3, located in the bottom section of the ETM, provides the required flow rates in the collector, heating, and storage loops. DO NOT RUN PUMPS WITHOUT FLUID IN SYSTEM.

The heat exchanger separates the freeze-protected collector loop from and transfers energy to the heating/storage water loop. Integrally plumbed and mounted into the top section of the ETM, it has no moving parts but is equipped with a manual air bleed and drain valve. Cleaning and flushing of the exchanger shell is possible without contaminating the entire collector loop.

**E. (continued)**

The diaphragm expansion tank absorbs the expansion of the transfer fluid from fill temperature (50-60°F) to purge temperature (210°F). It is mounted in the center of the ETM, with the charging air valve accessible on its bottom (relief pan removal provides additional access to the valve). Tank air pressure should not drop below its initial 20 psi charge; it will increase as the system pressure increases. Removal of expansion tank is through the top panel, after removing the air separator and strainer.

Located in the upper section in the collector line is an air separator. With no moving parts, it separates entrapped air from the collector fluid as it circulates.

The automatic, float-type air vent, attached to the air separator, eliminates the purged air only. Then, fluid fills the chamber and the float closes the vent port. During system start-up, this process may be expedited by removing the protective vent cap and manually depressing the vent system. During operation, leave vent cap 2-1/2 turns open.

Two air bleeds, located in the top section, allow for the manual venting of air from the ETM piping and heat exchanger during system start-up. A catch basin should be used when venting the air/fluid mixture from plumbing.

Located in the top section of the ETM is a pressure relief valve, used to protect the collector loop from overpressure during a system pump failure. When system pressure reaches 45 psig, the valve will begin to open. The discharge is directed through the pressure relief line into the holding pan. **DO NOT REMOVE ETM PANELS WHILE RELIEF VALVE IS FUNCTIONING.** Fluid (water/ethylene glycol mixture) may be at 210°F.

The dual diverting control valve, located in the lower section, directs the water flow into various storage and heating modes. This electrically driven valve is controlled by the Solar Control Panel, but does have manual override levers, one per powerhead. These levers should be in the unlocked position.

Located in the lower section are three circuit setters, used to reduce flow rates to the correct level in the collector, charge storage, and heat from storage loops (there is no setter in the Direct Heating loop). The reduction is made by turning the large nut, thus adjusting the internal valve body. ETM is shipped with the setters in the "open" position, adjustments should be made during initial system start-up. **TURN PUMPS OFF AND SHIELD THEM AND THE ETM BASE FROM FLUID LEAKAGE WHEN CONNECTING OR DISCONNECTING PRESSURE METER FROM SETTER.**

**E. (continued)**

The lift check valve, located in the collector supply line in the top section, is used to prevent thermosyphoning (backward gravity flow) of cold collector fluid into the heat exchanger during cold, cloudy days. It is designed to prevent freezing of the heat exchanger water loop. During operation, the system pump ( $P_1$ ) pushes liquid through the check valve, lifting the mechanism off the seat. When flow stops (the protect mode), the valve mechanism drops by gravity onto the seat, thus not allowing flow in the reverse direction. DURING OPERATION, THE VALVE MUST BE FIRMLY SCREWED DOWN ONTO THE SEAT.

Located in the bottom section are two swing check valves which, like hinged doors, allow flow in only one direction. Reversed flow causes the valve to seat more firmly. Check valves are a part of the overall flow control in the heating and storage loops.

There are four drain/fill valves, located in the ETM. These are used to flush, clean, and fill the system. These valves are similar to the drain on a residential hot water heater and have a standard garden hose threaded outlet. ANY SPILLED GLYCOL SOLUTION SHOULD BE IMMEDIATELY WIPED UP.

Located in the top section of the ETM (in the collector return line) is a ball valve, used during flushing of collector loop. The valve must be open (handle in-line) during system operation, thus allowing full flow through it. By opening and closing (handle perpendicular to supply line) the valve as stated in the operational instructions, the collector loop and heat exchanger shell can be independently flushed and cleaned.

Located in the top section of the ETM (in the collector loop) is a strainer which removes most of the foreign matter from the fluid as it passes through the metal screen. Foreign material should be occasionally removed from the strainer. STRAINER SHOULD NOT BE OPENED PRIOR TO DRAINING OR ISOLATING THE COLLECTOR LOOP.

The low level indicator consists of an indicator lamp (mounted on the ETM) and the pressure gauge mounted in the top section of ETM. After charging the system to 20 psig, the gauge contact pointer should be adjusted to the proper setting (17 psig). When collector loop loses fluid the pressure will drop from the nominal operating 20-36 psig, to the 17 psig, the lamp will light. This indicates a possible system pressure leak, i. e., loss of fluid.

The lamp may also light if all collector fluid becomes very cold and contracts sufficiently to cause a drop in system pressure. If lamp remains lit when the system pump ( $P_1$ ) is automatically turned on, check for a leak.

NOTE: The indicator actually detects a pressure loss, and not a liquid level.

2. (continued)

The Solar Control Panel located in the right side of the ETM, senses conditions throughout the system and requirements of the household (thermostat setting) and provides ETM operational control. When opening the Control Panel, care should be taken to avoid damage to the door or cabinet finish. Switches should remain in the "AUTO" position. Secure the door after closing it with the screw provided.

The holding pan, located on rails under the ETM, is provided to catch and hold the overflow from the relief valve. To remove pan, first disengage the relief line by pushing in at its mid-length and pulling the bottom out of the pan. Then grasp the pan handles and pull from under the ETM.


### 3. Control Subsystem

The control subsystem is composed of the collector plate temperature sensor, the upper and lower storage tank temperature sensors, the collector outlet temperature sensor and the central panel.

Operation of the control subsystem is as follows: (Refer to Figure 2-1)

Space heating is controlled by the two stage heating thermostat. First stage heating is set to utilize solar energy if available while second stage heating will supply the auxiliary energy if solar is not adequate. The system control logic is as follows:

- Collector solar energy when available
  - store energy under no load conditions
  - provide energy directly to load on demand
- Use direct solar energy before stored energy
- Use stored energy when direct solar energy is not available
- Use direct or stored solar energy before auxiliary energy



SOLAR HEATING SYSTEM CONTROL SCHEMATIC

### Direct Heating from Collectors

Whenever plate temperature  $T_p$  is greater than  $105^{\circ}\text{F}$  (adjustable) and there is a call for heating from the space thermostat pumps  $P_1$  and  $P_2$  are activated. Valve  $V_2$  is positioned to direct flow to the heating coil. The furnace fan is activated to provide warm air to the space. A heating coil leaving-air high-limit controller will cause valve  $V_2$  to direct flow to the storage tank if the heating coil leaving-air temperature exceeds  $140^{\circ}\text{F}$  (adjustable). Direct heating operation will continue until the space thermostat is satisfied or until the collector plate temperature has dropped to  $90^{\circ}\text{F}$ .

### Heating from Storage

Whenever  $T_p$  is less than  $105^{\circ}\text{F}$  (adjustable),  $T_{ST}$  is greater than  $90^{\circ}\text{F}$  (adjustable), and there is a call for space heat, pump  $P_3$  is activated to discharge the storage tank for space heating. Valve  $V_2$  is positioned to direct flow to the heating coil. The furnace fan is activated to provide warm air to the space. Pumps  $P_1$  and  $P_2$  are not allowed to operate during this mode. The heating coil leaving-air high-limit controller functions as described above.

### Storage Charging

Storage charging is accomplished whenever  $T_p$  is greater than  $T_{SB}$  by  $18^{\circ}\text{F}$  (adjustable). Pumps  $P_1$  and  $P_2$  are activated and valve  $V_2$  is positioned to direct flow to the storage tank. If the above temperature difference falls to less than  $3^{\circ}\text{F}$  (adjustable), the storage charge mode is terminated.

### Heat Rejector Control

Whenever the collector discharge temperature exceeds  $210^{\circ}\text{F}$  (adjustable) as sensed to  $T_{CP}$ . Valve  $V_1$  is positioned to direct collector loop flow through the heat rejector, and the heat rejector fan is activated.

### Auxiliary Heating

Whenever solar heating is being utilized, either direct or stored, auxiliary gas-fired heating will be available as controlled by the second heating stage of the space thermostat. When solar heating is not available, auxiliary gas-fired heating will be available as first stage heating. Auxiliary heating is provided by a conventional gas furnace utilizing conventional controls.

## G. Site Data Acquisition Subsystem (SDAS)

To meet the data collection, performance evaluation, and data dissemination goals of the National Program for Solar Heating and Cooling, the solar heating system will include a comprehensive instrumentation subsystem.

### Data Collection

The goal of ERDA's data collection activity is to provide the information necessary for evaluation of the performance and operation of solar systems and subsystems under different climatic conditions. The information generated as a result of this data collection activity will be utilized to stimulate industrial and commercial capability, including that of small business, to produce and distribute solar heating and cooling systems, and through widespread applications, to reduce the demand on conventional fuel supplies. This information will also be used to improve the general knowledge and understanding of solar energy systems, to develop definitive solar energy system performance criteria, to provide the basis for component system improvement and to estimate the economics of solar energy systems in reducing the consumption of conventional fuels. Results will be available for use by property owners, the building industry and related sections of the economy to compare costs and benefits of solar heating and cooling systems. This information will also provide the data base for design of new applications in the private sector. ERDA's Technical Information Center at Oak Ridge, Tennessee, will be the National Solar Heating and Cooling Data Bank and will be the focal point for distribution of this information.

### Data System Overview

The Data System depicted in Figure 2-2 provides for the automatic gathering, conversion, transfer, reduction, and analysis of demonstration site data. This system is made up of three basic elements: installed sensors, a Site Data Acquisition Subsystem (SDAS), and a Central Data Processing System (CDPS).


The data will be gathered at each operational site at predetermined intervals of time and will be stored for transfer to the Central Processor. The collected data will be transferred via telephone communications upon request from the Central Data Processing Facility. At the Central Data Processing Facility, the collected data will be processed, analyzed, evaluated, and documented as Performance Evaluation Reports.

Locations of all SDAS sensors are shown in Figure 2-3.

### Operation and Maintenance

All operation and maintenance work for the Site Data Acquisition Subsystem will be the responsibility of ERDA or its appointed representative.





*Figure 2-2 Site Instrumentation Interface Hardware*




Figure 2-3 HONEYWELL-STILLWATER SOLAR ENERGY SYSTEM SCHEMATIC

## SECTION III

### SUBSYSTEM INSTALLATION GUIDELINES

#### A) COLLECTOR SUBSYSTEM

The solar collectors, Lennox LSC18-1, are arranged in typical arrays as shown on sheet 2 of drawing SK 142049. The collectors and headers are interconnected as shown in the lower left of the drawing. Prior to collector placement on the support structure remove inlet and outlet plugs from the collector ends. Do not remove the "red" plastic plugs at each end of the collector. Install straight fittings at the collector inlet of lower-most collectors and collector outlet of upper-most collectors in the collector array (Detail A). Install elbow fittings facing inward at all other collector inlets and outlets (Detail B). Use pipe compounds on all threaded fittings suitable for aqueous ethylene glycol solutions, Rectorseal No. 7 or equivalent.

Collector mounting to the support structure is done chronologically by collector stacks one at a time proceeding from one end of the collector array. The lateral spacing between collectors should be approximately 1/8 inch. The mounting procedure is as follows:

- 1) Place the upper collector(s) of a collector stack approximately 6 inches above its (their) final position and retain by bracing against the support structure. The upper collector(s) may be offset laterally for easier interconnecting to the adjacent lower collector.
- 2) Place the first row collector on the support structure and bolt both lower-end mounting brackets to the structure allowing space for the supply header and its interconnecting hose.
- 3) At the upper end of the collector attach the tie-down clip to the mounting bracket and bolt to the support structure.



- 4) Connect adjacent ends of collectors by installing the 23-inch interconnecting hose using two clamps per end as shown on sheet 2 of drawing SK 142049 (Detail B).
- 5) Bring the upper collector into place by sliding its lower mounting bracket under the tie-down clip attached to the lower collector and support structure.
- 6) For a three-high collector stack repeat steps 3 through 5.
- 7) Bolt both upper-end mounting brackets of the highest collector to the support structure.
- 8) Repeat steps 1 through 7 for all remaining collector stacks in the array.

Header sections are placed into position and connected to the bottom and top collectors' fittings by the 6-inch long interconnecting hose using two clamps per end as shown on sheet 2 of drawing SK 142049 (Detail A). Header sections are connected to each other by means of a copper coupling. After all such interconnections have been made, the header sections are soldered together. During soldering the support structure should be shielded from the flame used to heat the copper headers and coupling. Also, it may be necessary to provide a heat block between the soldering flame and the insulated portion of the headers. Headers should be anchored securely only at ends where connected to supply and return lines. At other locations the headers should be supported or strapped but done in such a manner as to allow expansion and contraction movement.

Air bleed valves must be installed at both ends of the return header in each collector array as shown in drawing SK 142049 (Detail X and Y). Also air bleed valves are needed at the high points in the supply and

return lines, if such locations exist. All collector subsystem piping should be insulated with 3/4 inch thick armafex insulation or equivalent and outdoor piping weatherproofed. A flow balancing valve should be installed in the return line for each collector array and a shut-off valve in the supply line to each array.

The purge unit, Lennox HRW-1-30, is located outside the dwelling on a concrete slab as shown on sheet 4 of drawing SK142049. Check sections E and F for control valve installation guidelines.

#### **B) STORAGE SUBSYSTEM**

The storage tank depicted on SK142050 Sheet 2 is to be installed above ground (i.e., not buried) and enclosed within a partition which allows the tank to be engulfed in blown fiberglass insulation. The tank should rest evenly on four 1-inch redwood boards. The tank should be leveled with a bubble level. All plumbing connections, control and SDAS sensors should be installed prior to engulfing Tank in insulation. See sections F and G for sensor information. Inlet and outlet lines should be insulated with 3/4" thick armafex insulation or equivalent.

#### **C) AUXILIARY ENERGY AND SPACE HEATING SUBSYSTEMS**

The auxiliary energy unit is a Lennox gas fired furnace type G11Q3-82V. It is to be combined with a space heating coil Lennox type CW3-45. The installation of the furnace is outlined in Figures C-1 and C-2. Do not connect return air plenum or filter to furnace.

CAUTION: See SK 142054 Sheet 3 (Pg. III-21) for changes to furnace wiring.

The general dimensional information on the furnace is shown on drawing SK 142051 sheet 1. The installation information for the CW3-45 is shown on drawing SK 142051 sheet 3. This information is supplemented with detail cut out information shown in Figure C-3.

PART NO.
----------

ORIGINAL PAGE IS  
OF POOR QUALITY

# PURGE COIL DESCRIPTION

## Heat Capacity and Pressure Drop

- Length of the coil • 25"
- Length of the coil • 30"
- No. of rows • 2
- No. of fins/tube • 15
- Center dia. of tubes • 1/8"
- No. of circuits • 10
- Air flow rate • 2000 CFM
- TP of fin motor • 1/5

Assumed air temp. at the entrance side of the fan • 60-120°F

Calculated heat dissipated by  
• 101,000-144,000  
Btu/hr. (heat  
input)  
• 330°F 50% 20-  
cal collection





Pressure drop (calculated) in the Purge  
coil

$$\begin{aligned} & \approx 2.0 \text{ R.} \\ & \approx 3.9 \text{ F.S.} \end{aligned}$$

## INSTALLATION NOTES


PLUMBING: Connect the inlet and outlet  
connections (1 1/8" O.D. copper tube) of  
the purge coil to the desired pipes in the  
collector loop.

ELECTRICAL: Connect the motor of the  
purge coil fan to the collector panel.



PURGE COIL UNIT (HEAT REJECTOR)

HONEYWELL		ENERGY RESOURCES CENTER	
LOG		HONEYWELL, INC.	
HUGLE FAMILY RESIDENCE		COLLECTOR SUBSYSTEM	
WILLIAM O'BOEN	DATE 12-11-67	SIZE C 5-5-13	SK-142049
REVISION	DATE	BY	NO.
1	12-11-67	W.O.	1
2			
3			
4			
5			
6			
7			
8			
9			
10			
11			
12			
13			
14			
15			
16			
17			
18			
19			
20			
21			
22			
23			
24			
25			
26			
27			
28			
29			
30			
31			
32			
33			
34			
35			
36			
37			
38			
39			
40			
41			
42			
43			
44			
45			
46			
47			
48			
49			
50			
51			
52			
53			
54			
55			
56			
57			
58			
59			
60			
61			
62			
63			
64			
65			
66			
67			
68			
69			
70			
71			
72			
73			
74			
75			
76			
77			
78			
79			
80			
81			
82			
83			
84			
85			
86			
87			
88			
89			
90			
91			
92			
93			
94			
95			
96			
97			
98			
99			
100			




100-443887-100


control



The "new" gas field will likely be developed in a relatively short period of time, and will be a significant addition to the gas supply of the region.



the company's research and development efforts. The company's research and development efforts are focused on the development of new products and services. The company's research and development efforts are focused on the development of new products and services. The company's research and development efforts are focused on the development of new products and services.

[illegible]

1944

[illegible][illegible][illegible]

	1970	1971	1972	1973	1974	1975	1976	1977	1978	1979	1980	1981	1982	1983	1984	1985	1986	1987	1988	1989	1990	1991	1992	1993	1994	1995	1996	1997	1998	1999	2000	2001	2002	2003	2004	2005	2006	2007	2008	2009	2010	2011	2012	2013	2014	2015	2016	2017	2018	2019	2020	2021	2022	2023	2024	2025	2026	2027	2028	2029	2030	2031	2032	2033	2034	2035	2036	2037	2038	2039	2040	2041	2042	2043	2044	2045	2046	2047	2048	2049	2050	2051	2052	2053	2054	2055	2056	2057	2058	2059	2060	2061	2062	2063	2064	2065	2066	2067	2068	2069	2070	2071	2072	2073	2074	2075	2076	2077	2078	2079	2080	2081	2082	2083	2084	2085	2086	2087	2088	2089	2090	2091	2092	2093	2094	2095	2096	2097	2098	2099	2100	2101	2102	2103	2104	2105	2106	2107	2108	2109	2110	2111	2112	2113	2114	2115	2116	2117	2118	2119	2120	2121	2122	2123	2124	2125	2126	2127	2128	2129	2130	2131	2132	2133	2134	2135	2136	2137	2138	2139	2140	2141	2142	2143	2144	2145	2146	2147	2148	2149	2150	2151	2152	2153	2154	2155	2156	2157	2158	2159	2160	2161	2162	2163	2164	2165	2166	2167	2168	2169	2170	2171	2172	2173	2174	2175	2176	2177	2178	2179	2180	2181	2182	2183	2184	2185	2186	2187	2188	2189	2190	2191	2192	2193	2194	2195	2196	2197	2198	2199	2200	2201	2202	2203	2204	2205	2206	2207	2208	2209	2210	2211	2212	2213	2214	2215	2216	2217	2218	2219	2220	2221	2222	2223	2224	2225	2226	2227	2228	2229	2230	2231	2232	2233	2234	2235	2236	2237	2238	2239	2240	2241	2242	2243	2244	2245	2246	2247	2248	2249	2250	2251	2252	2253	2254	2255	2256	2257	2258	2259	2260	2261	2262	2263	2264	2265	2266	2267	2268	2269	2270	2271	2272	2273	2274	2275	2276	2277	2278	2279	2280	2281	2282	2283	2284	2285	2286	2287	2288	2289	2290	2291	2292	2293	2294	2295	2296	2297	2298	2299	2300	2301	2302	2303	2304	2305	2306	2307	2308	2309	2310	2311	2312	2313	2314	2315	2316	2317	2318	2319	2320	2321	2322	2323	2324	2325	2326	2327	2328	2329	2330	2331	2332	2333	2334	2335	2336	2337	2338	2339	2340	2341	2342	2343	2344	2345	2346	2347	2348	2349	2350	2351	2352	2353	2354	2355	2356	2357	2358	2359	2360	2361	2362	2363	2364	2365	2366	2367	2368	2369	2370	2371	2372	2373	2374	2375	2376	2377	2378	2379	2380	2381	2382	2383	2384	2385	2386	2387	2388	2389	2390	2391	2392	2393	2394	2395	2396	2397	2398	2399	2400	2401	2402	2403	2404	2405	2406	2407	2408	2409	2410	2411	2412	2413	2414	2415	2416	2417	2418	2419	2420	2421	2422	2
--	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	---

ITEM #	ITEM	MANUFACTURER	TYPE / PART NO	QUANTITY
①	FURNACE	LEUNOX IND.	GIQ3-52V	1
②	HEAT COIL	LEUNOX IND.	CW3-45	1

WITH CUB-45 SPACE HEAT CUB-  
51123-82V SLOWLY PERFORMANCE

STATION	AIR VOLUME (CFM)		AIR VOLUME (CFM)		AIR VOLUME (CFM)	
	HIGH	LOW	HIGH	LOW	HIGH	LOW
0.00	1281	1185	975	889		
0.05	1270	1166	971	880		
0.10	1265	1144	960	871		
0.15	1219	1121	940	857		
0.20	1190	1096	920	844		
0.25	1160	1070	898	820		
0.30	1130	1043	875	795		
0.40	1080	984	827	721		
0.50	953	915	770	666		
0.60	773	833	725	597		
0.70	813	750	640	525		
0.80	740	686	515	440		

NOTE - ALL COM VEHICLES EXTENDED TO THE UNITS w/ THE AIR PETER IN PLACE

HONEYWELL INC.		HONEYWELL 88258813 CENTRA COMMERCIAL GROUP, 0810	
SPE. AUXILIARY ENERGY AND SPACE HEATING SUBSYSTEMS		SIZE DATE HEAT NO. EXECUTING NO. C 55513 5K-142051	
SCALE 1/8"=1'-0"		SHEET 1 OF 3	

# **REQUIREMENTS — APPLICATION — INSTALLATION**

## **I - SHIPPING AND PACKING LIST**

### **A - Units with Direct Drive Blowers**

Package 1 of 1 Contains

- 1 - Leveling bolt package
- 1 - Thermostat (if ordered)
- 1 - Rubber grommet (for electrical make-up)

### **B - Units with Belt Drive Blowers**

Package 1 of 1 Contains

- 1 - Leveling bolt package
- 1 - Thermostat (if ordered)
- 1 - Rubber grommet (for electrical make-up)

Package 1 of 1 Contains

- 1 - Blower Motor
- 1 - Motor Pulley
- 1 - Belt

Motor mounting clamps

## **II - SHIPPING DAMAGE**

Check unit for shipping damage. The receiving party should contact the last carrier immediately if any shipping damage is found.

## **III - GENERAL**

These instructions are only intended as a general guide, and do not supersede local codes in any way. Authorities having jurisdiction should be consulted before installation.

## **IV - REQUIREMENTS**

Installation of Lennox gas central furnaces must conform with American National Standard (ANSI-Z223. 1-1974) National Fuel Gas Code, manufacturers installation instructions and local municipal codes. Authorities having jurisdiction should be consulted before installation. Air for combustion and ventilation must conform to the methods outlined in ANSI-Z223. 1-1974.

Unit design, certified by American Gas Association (AGA) and Canadian Gas Association (CGA).

Central furnace is certified for installation clearances to combustible material as listed on A.G.A. rating plate.

Accessibility and service clearances must take precedence over fire protection clearances.

Unit must be adjusted to obtain a temperature rise within the range specified on A.G.A. rating plate.

When this furnace is used in conjunction with cooling units, it shall be installed in parallel with or on the upstream side of cooling units to avoid condensation in the heating element. With a parallel flow arrangement, the damper (or other means to control the flow of air) shall be adequate to prevent chilled air from entering the furnace and, if manually operated, must be equipped with means to prevent operation of either unit, unless damper is in the full "heat" or "cool" position.

All electrical wiring and grounding for unit must be in accordance with the regulations of the National Electrical Code (NFPA No. 70-1975/ANSI C1-1975).

## **V - CUT OUT RETURN AIR OPENINGS**


- 1 - The return air can be brought in either side or at the bottom of the unit. Scribe lines are provided on each side and bottom showing the outline for the return air opening. Remove blower access door and cut out desired opening.

## **VI - INSTALL RETURN AIR PLENUM**

Install return air plenum and secure to return air opening with sheet metal screws. (Do not screw into filter.)

If a return air cabinet is used, install according to the installation instructions furnished with the return air cabinet.

Install leveling bolts provided in leveling bolt package as shown in Figure 1. After unit is level, tighten this nut. Level unit with this nut. Install plastic nuts with flat side toward base. LEVELING BOLT.



**FIGURE 1**

## **VII - INSTALL RETURN AIR PLENUM**


Install return air plenum and secure to return air opening with sheet metal screws. (Do not screw into filter.)

If a return air cabinet is used, install according to the installation instructions furnished with the return air cabinet.

## **VIII - INSTALL WARM AIR PLENUM**

**NOTE - The following are suggested procedures that should be followed when installing the warm air plenum.**

- 1 - Sealing strips of asbestos or fiberglass may be used.
- 2 - In all cases, the plenum should be secured to the furnace or evaporator cabinet with sheet metal screws. In closet installations, it may be impossible to install sheet metal screws from the outside. If this is the case, install screws from the inside. Cut an access panel in plenum if necessary.
- 3 - Install conventional plenum as illustrated in Figure 2. Secure to furnace top with sheet metal screws.
- 4 - Install cooling plenum according to the instruction furnished with the C4 Evaporator Coil or the C4-00 Empty Cabinet.



**FIGURE 2**

## **IX - CONNECT DUCT WORK**

Install supply and return ductwork as desired.

## **X - CONNECT FLUE**

- 1 - Install flue pipe over the collar on the cabinet top and connect to the chimney using least number of elbows and angles possible. See Figure 3.
- 2 - The flue pipe should have a slight upward slope toward the chimney on all horizontal runs. Approximately 1/4 inch for each 1 foot of horizontal run. The flue pipe or vent connector must be

inserted into, but not beyond, the outside wall of the chimney flue. Where two or more appliances vent into a common flue, the area of the common flue should be at least equal to the area of the largest flue or vent connector plus 50% of the combined area of the additional flues or vent connectors.

#### XI - HIGH ALTITUDE

Unit may be fired at full input up to 2000 feet above sea level. If unit is installed at an altitude higher than 2000 feet, unit must be de-rated 4% for each 1000 feet above sea level.




FIGURE 3

#### XII - CONNECT GAS SUPPLY

- 1 - This unit is shipped standard for the piping to be installed through the left side of the unit. See Figure 4. All that is necessary for the installer to do is connect gas supply to the piping assembly.
- 2 - If it is necessary to bring piping through the right side of the unit, a piping hole is furnished on the right side. See Figure 4 for connection.
- 3 - When connecting the gas supply, the length of run from the meter must be considered in determining the pipe size so as to avoid excessive pressure drop. For correct sizing of gas delivering piping consult booklet "Specifications for Installations of Gas Piping and Gas Appliances" issued by the utility having jurisdiction. A drip leg should be installed in the vertical pipe run to the unit. See Figure 4.

In some localities, codes may require a manual main shut off valve and union (furnished by installer) be installed external to unit. Union must be of the ground joint type.

**NOTE** - Compounds used on threaded joints of gas piping must be resistant to the actions of liquefied petroleum gases.

#### XIII - LEAK CHECK PIPING

After gas piping is completed, carefully check all piping connections (factory and field) for gas leaks. Use a soap solution or other preferred means.

**CAUTION: DO NOT USE MATCHES, CANDLES, FLAME OR OTHER SOURCES OF IGNITION TO CHECK FOR GAS LEAKS.**

#### XIV - INSTALL BLOWER MOTOR AND DRIVES (BELT DRIVE MODELS ONLY)

- 1 - Mount motor on motor frame and secure with motor clamps, machine bolts and nuts provided. Be sure motor is rotated so oiling holes are accessible.
- 2 - Install the motor pulley making sure it is aligned with the blower pulley.
- 3 - Install blower belt. Refer to page 2 for correct motor pulley adjustment and belt tension.

- 4 - Use wiring strain relief at motor and connect wiring leads at motor according to wiring make-up diagram on motor cover.
- 5 - Connect the loose end of the green ground provided on blower housing to motor.




FIGURE 4

#### XV - COMPLETE WIRING - Caution - See SK 14 2054 SK3

The unit is equipped with terminal strips where all field wiring connections are made. Line voltage connects at terminals L1 and N. Thermostat connections are made at R and W (heating only) or at R, Y, W and G for additive cooling. For cooling, condensing unit low voltage connections are made at terminals T and Y. An indoor blower relay is mounted standard in the unit. Blower motor speed connections are made at terminals 2 (red) and 6 (black) of indoor blower relay.

- 6 - Cooling Blower Speed
- 2 - Heating Blower Speed

Unused motor leads must be taped separately. Refer closely to unit diagram for correct terminal connections.

- 1 - Refer to blower motor nameplate to select proper fuse and wire size.
- 2 - Snaphole plugs are provided on both sides of cabinet to facilitate wiring.
- 3 - Install room thermostat (avoid installing on an outside wall or where radiant heat will effect thermostat) and wire to unit terminal board. Set adjustable heat anticipator on thermostat accord-

Figure C-2


- ing to the setting stamped on the unit gas valve.
- 4 - Install a separate fused disconnect switch near the unit so power supply can be turned off for servicing.
  - 5 - Complete line voltage from disconnect switch to unit terminal strip in make-up box.
  - 6 - Multi-tap direct drive motors are wired for different heating and cooling speeds. Speed may be changed by simply interchanging motor connections at indoor blower relay. Refer to speed selection chart on unit wiring diagram.

**CAUTION** - To prevent motor burnout, never connect more than (1) motor lead to any one connection. Tape unused motor leads separately.

#### XVI - CLEAN-UP

After unit is operating properly:

- 1 - Set room thermostat at desired setting.
- 2 - Leave this instruction with the unit.
- 3 - Pick up all shipping cartons, metal scraps, extra insulation and generally clean-up the installation.



NOTE: IF ANY WIRE IN THIS APPLIANCE IS REPLACED, IT MUST BE REPLACED WITH WIRE OF LIKE SIZE, RATING AND INSULATION THICKNESS. IF RATING AND INSULATION IS UNKNOWN, USE SAME SIZE THERMO-PLASTIC 105°C WIRE WITH 4/64" INSULATION THICKNESS.

**Caution**  
See SK142054 sheet 3 for changes to furnace wiring.

#### BELT DRIVE MOTOR WIRING SHOWN

#### MULTI-SPEED MOTOR TAPS

**IMPORTANT**—To prevent motor burnout, never connect more than one motor lead to any one connection. Tape unused motor leads separately.

SPEED	BLOWER MOTOR LEAD		
	D2 and Q4	Q3	Q5
LOW	RED	RED	RED
MEDIUM I	YELLOW	YELLOW	YELLOW
MEDIUM II	—	—	BLUE
HIGH	BROWN	BROWN	BROWN
—	BLACK	BLACK	BLACK

To obtain single speed blower operation is desired, wire nut leads from terminal 3 of indoor blower relay and lead from fan control together with desired motor lead.

— LINE VOLTAGE INSTALLED AT FACTORY  
— LINE VOLTAGE TO BE INSTALLED  
— LOW VOLTAGE TO BE INSTALLED  
NEC CLASS 2

#### G11 FIELD WIRING DIAGRAM

Figure C-3



# INSTALLATION INSTRUCTION

## I. SHIPPING AND PACKING LIST

Package 1 of 1 contains:

- 1 - Indoor coil in cabinet with slab filter
- 1 - Roll gasket material
- Screws

## II. SHIPPING DAMAGE

Check unit for shipping damage. If damage is found, receiving party should contact last carrier immediately.

## III. GENERAL

These instructions are intended as a general guide only and do not supersede local codes. Authorities having jurisdiction should be consulted before installation.

## IV. APPLICATION

CW3-45 indoor water coils provide a field installed space heating/cooling subsystem. Used in conjunction with an auxiliary gas or electric furnace unit, the CW3-45 coil will provide solar space heating. When connected with a water chiller, space cooling is available.

## V. INSTALLATION (G11 or G12 Series Auxiliary Unit Installed)

### A. Cabinet Installation

1. Remove return air plenum or cabinet. (If installed.)
2. Remove filter hammock and media from G11 or G12 blower compartment. The air filter will now be in the CW3-45 cabinet, upstream from the water coil.
3. Cut out return air opening on desired side of G11 or G12 cabinet. See Figure 3.




FIGURE 3

4. Remove bottom (4) screws from base of G11 or G12 unit on the return air cutout side. See Figure 4.
5. Install gasket material around cutout opening.
6. Align CW3-45 unit with return air opening.
7. From inside blower compartment drill and fasten CW3-45 cabinet to G11 or G12 cabinet with (4) sheet metal screws (use existing holes in G11 or G12 cabinet). Drill and screw the two cabinets together at (1) other accessible location.
8. Drill and fasten with (2) screws at tabs on top of CW3-45 cabinet. See Figure 5.
9. Attach return air plenum to CW3-45 coil cabinet being careful not to screw into filter.

### B. Electrical

Two leads from CW3-45 high limit switch are to be connected into the total system controls. Refer to total system control wiring instructions.




FIGURE 4




FIGURE 5

### C. Plumbing Connection

Refer to the total system instructions for proper plumbing requirements and procedures.

### D. Auxiliary Energy Components

Refer to the particular Operation, Maintenance, and Installation Instructions that apply to mating components.

Insulate piping with 3/4" thick armaflex insulation or equivalent. Connect temperature limit control wiring to control panel on ETM unit as shown on SK142054 Sheet 3 in Section F.

**D) DOMESTIC HOT WATER SUBSYSTEM**


The domestic hot water subsystem installation consists of installing a conventional hot water heater (either gas or electric) connecting its outlet (hot) to the dwelling hot water line, connecting the inlet (cold) to the preheat coil in the storage tank. This line should have installed in it a tempering valve, see Figure D-1 for installation guidelines. The supply water (cold) is run to the preheat coil and to the mixing valve. The DHW piping is shown on SK 142052.

The hot water heater should be installed as shown in Figure D-2. Install pressure and temperature relief valve in water heater and discharge line to within 2-feet of floor.

**CAUTION:** Be sure to remove thermostatic assembly from tempering valve before sweating connections. Otherwise it will become damaged. Tempering valve should be set at 140°F.

**E) ENERGY TRANSPORT SUBSYSTEM**

The Energy Transport Subsystem consists of the Energy Transport Module (ETM) and the piping between it and the collectors, storage and heating subsystems. The ETM should be installed as outlined on SK 142053 Sheets 1 and 2. The piping installation should conform the Section 15.050 Basic Materials and Methods and Section 15.100 Valves on SK 142057 Sheet 3. Check Section F for control valve installation. It should be located in collector outlet piping where purge unit is to be piped in.

PART 363.

# SCHEMATIC H.W. SUBSYSTEM

## INSTALLATION INFORMATION

- 1) DHW preheat coil will be previously installed in storage tank and has ends protruding from top of tank.
- 2) Tighpen adapter on compression fitting.
- 3) Solid-r coil ends to copper tubing using coupling.

## CONSULTATION INFORMATION

- 11) Insulate copper tubing from storage tank outlet to hot water mixing valve.





FIGURE 1. HEAVY AND LIGHT



FOR THE YEAR 1991

**DOMESTIC HOT WATER (DHW)**

The DWT substation consists of two hot water heaters in series. The first heater is the coil immersed in the storage tank, and the 2nd heater is a conventional domestic hot water heater. The storage tank is heated with the surplus solar energy not required for space heating. The stored heat is transferred to city water via a coil which preheats the water before it goes to the conventional hot water heater. When the storage tank is at its maximum temperature 200°F, an additional heat will be required from the conventional heater at flow rates of 7 gpm or less. The capacity of preheat coil is shown in Figure 1 and 2. To limit the output of the heaters to 120° a coil contained 3 way mixing valve tempers the hot water to the near with the water.

MATERIAL SCHEDULE				
ITEM#	ITEM	MANUFACTURER	TYPE / PART NO	QUANT
1	HOT WATER HEATER	LOCHINVAR	52 KP-10	1
2	3-WAY MIXING VALVE	WATTS REGULATOR CO.	70A-3/4"	1
3	BALL VALVE	NIROD	9-500-3/4"	1
4	COPPER TEE NOM. 3/8" x 1/2"	GOULD-IMPERIAL EASTMAN	111-7/8	1
5	COPPER COUPLING w/ STOP NOM. 3/8"	GOULD-IMPERIAL EASTMAN	100-1/8	2
6	COPPER ELBOW NOM. 3/8" x 1/2"	GOULD-I.E.	107-C-7/8	40 ELBOWS
7	INSULATION (3/4" THICK)	ARMSTRONG CORK CO.	ARMSTRONG INSULATION	40 ELBOWS
8	INSULATION ADHESIVE	ARMSTRONG	520	40 ELBOWS
9	COPPER PIPE 3/4" NOM	EVERETT	1A	4 ELBOWS
10	RELIEF & TEMP RELIEF VALVE	WATTS PLUMBING SPEC.	40 XL	1

MINI ITEMS LISTES OR EQUIVALENT

RELAT. ORIGINATED		DATE OF ORIGIN		RELAT. ORIGINATED		DATE OF ORIGIN		RELAT. ORIGINATED		DATE OF ORIGIN	
1	2	3	4	5	6	7	8	9	10	11	12
13	14	15	16	17	18	19	20	21	22	23	24
25	26	27	28	29	30	31	32	33	34	35	36
37	38	39	40	41	42	43	44	45	46	47	48
49	50	51	52	53	54	55	56	57	58	59	60
61	62	63	64	65	66	67	68	69	70	71	72
73	74	75	76	77	78	79	80	81	82	83	84
85	86	87	88	89	90	91	92	93	94	95	96
97	98	99	100	101	102	103	104	105	106	107	108
109	110	111	112	113	114	115	116	117	118	119	120
121	122	123	124	125	126	127	128	129	130	131	132
133	134	135	136	137	138	139	140	141	142	143	144
145	146	147	148	149	150	151	152	153	154	155	156
157	158	159	160	161	162	163	164	165	166	167	168
169	170	171	172	173	174	175	176	177	178	179	180
181	182	183	184	185	186	187	188	189	190	191	192
193	194	195	196	197	198	199	200	201	202	203	204
205	206	207	208	209	210	211	212	213	214	215	216
217	218	219	220	221	222	223	224	225	226	227	228
229	230	231	232	233	234	235	236	237	238	239	240
241	242	243	244	245	246	247	248	249	250	251	252
253	254	255	256	257	258	259	260	261	262	263	264
265	266	267	268	269	270	271	272	273	274	275	276
277	278	279	280	281	282	283	284	285	286	287	288
289	290	291	292	293	294	295	296	297	298	299	300
301	302	303	304	305	306	307	308	309	310	311	312
313	314	315	316	317	318	319	320	321	322	323	324
325	326	327	328	329	330	331	332	333	334	335	336
337	338	339	340	341	342	343	344	345	346	347	348
349	350	351	352	353	354	355	356	357	358	359	360
361	362	363	364	365	366	367	368	369	370	371	372
373	374	375	376	377	378	379	380	381	382	383	384
385	386	387	388	389	390	391	392	393	394	395	396
397	398	399	400	401	402	403	404	405	406	407	408
409	410	411	412	413	414	415	416	417	418	419	420
421	422	423	424	425	426	427	428	429	430	431	432
433	434	435	436	437	438	439	440	441	442	443	444
445	446	447	448	449	450	451	452	453	454	455	456
457	458	459	460	461	462	463	464	465	466	467	468
469	470	471	472	473	474	475	476	477	478	479	480
481	482	483	484	485	486	487	488	489	490	491	492
493	494	495	496	497	498	499	500	501	502	503	504
505	506	507	508	509	510	511	512	513	514	515	516
517	518	519	520	521	522	523	524	525	526	527	528
529	530	531	532	533	534	535	536	537	538	539	540
541	542	543	544	545	546	547	548	549	550	551	552
553	554	555	556	557	558	559	560	561	562	563	564
565	566	567	568	569	570	571	572	573	574	575	576
577	578	579	580	581	582	583	584	585	586	587	588
589	590	591	592	593	594	595	596	597	598	599	600
601	602	603	604	605	606	607	608	609	610	611	612
613	614	615	616	617	618	619	620	621	622	623	624
625	626	627	628	629	630	631	632	633	634	635	636
637	638	639	640	641	642	643	644	645	646	647	648
649	650	651	652	653	654	655	656	657	658	659	660
661	662	663	664	665	666	667	668	669	670	671	672
673	674	675	676	677	678	679	680	681	682	683	684
685	686	687	688	689	690	691	692	693	694	695	696
697	698	699	700	701	702	703	704	705	706	707	708
709	710	711	712	713	714	715	716	717	718	719	720
721	722	723	724	725	726	727	728	729	730	731	732
733	734	735	736	737	738	739	740	741	742	743	744
745	746	747	748	749	750	751	752	753	754	755	756
757	758	759	760	761	762	763	764	765	766	767	768
769	770	771	772	773	774	775	776	777	778	779	780
781	782	783	784	785	786	787	788	789	790	791	792
793	794	795	796	797	798	799	800	801	802	803	804
805	806	807	808	809	810	811	812	813	814	815	816
817	818	819	820	821	822	823	824	825	826	827	828
829	830	831	832	833	834	835	836	837	838	839	840
841	842	843	844	845	846	847	848	849	850	851	852
853	854	855	856	857	858	859	860	861	862	863	864
865	866	867	868	869	870	871	872	873	874	875	876
877	878	879	880	881	882	883	884	885	886	887	888
889	890	891	892	893	894	895	896	897	898	899	900
901	902	903	904	905	906	907	908	909	910	911	912
913	914	915	916	917	918	919	920	921	922	923	924
925	926	927	928	929	930	931	932	933	934	935	936
937	938	939	940	941	942	943	944	945	946	947	948
949	950	951	952	953	954	955	956	957	958	959	960
961	962	963	964	965	966	967	968	969	970	971	972
973	974	975	976	977	978	979	980	981	982	983	984
985	986	987	988	989	990	991	992	993	994	995	996
997	998	999	1000	1001	1002	1003	1004	1005	1006	1007	1008
1009	1010	1011	1012	1013	1014	1015	1016	1017	1018	1019	1020
1021	1022	1023	1024	1025	1026	1027	1028	1029	1030	1031	1032
1033	1034	1035	1036	1037	1038	1039	1040	1041	1042	1043	1044
1045	1046	1047	1048	1049	1050	1051	1052	1053	1054	1055	1056
1057	1058	1059	1060	1061	1062	1063	1064	1065	1066	1067	1068
1069	1070	1071	1072	1073	1074	1075	1076	1077	1078	1079	1080
1081	1082	1083	1084	1085	1086	1087	1088	1089	1090	1091	1092
1093	1094	1095	1096	1097	1098	1099	1100	1101	1102	1103	1104
1105	1106	1107	1108	1109	1110	1111	1112	1113	1114	1115	1116
1117	1118	1119	1120	1121	1122	1123	1124	1125	1126	1127	1128
1129	1130	1131	1132	1133	1134	1135	1136	1137	1138	1139	1140
1141	1142	1143	1144	1145	1146	1147	1148	1149	1150	1151	1152
1153	1154	1155	1156	1157	1158	1159	1160	1161	1162	1163	1164
1165	1166	1167	1168	1169	1170	1171	1172	1173	1174	1175	1176
1177	1178	1179	1180	1181	1182	1183	1184	1185	1186	1187	1188
1189	1190	1191	1192	1193	1194	1195	1196	1197	1198	1199	1200
1201	1202	1203	1204	1205	1206	1207	1208	1209	1210	1211	1212
1213	1214	1215	1216	1217	1218	1219	1220	1221	1222	1223	1224
1225	1226	1227	1228	1229	1230	1231	1232	1233	1234	1235	1236
1237	1238	1239	1240	1241	1242	1243	1244	1245	1246	1247	1248
1249	1250	1251	1252	1253	1254	1255	1256	1257	1258	1259	1260
1261	1262	1263	1264	1265	1266	1267	1268	1269	1270	1271	1272
1273	1274	1275	1276	1277	1278	1279	1280	1281	1282	1283	1284
1285	1286	1287	1288	1289	1290	1291	1292	1293	1294	1295	1296
1297	1298	1299	1300	1301	1302	1303	1304	1305	1306	1307	1308
1309	1310	1311	1312	1313	1314	1315	1316	1317	1318	1319	1320
1321	1322	1323	1324	1325	1326	1327	1328	1329	1330	1331	1332
1333	1334	1335	1336	1337	1338	1339	1340	1341	1342	1343	1344
1345	1346	1347	1348	1349	1350	1351	1352	1353	1354	1355	1356
1357	1358	1359	1360	1361	1362	1363	1364	1365	1366	1367	1368
1369	1370	1371	1372	1373	1374	1375	1376	1377	1378	1379	1380
1381	1382	1383	1384	1385	1386	1387	1388	1389	1390	1391	1392
1393	1394	1395	1396	1397	1398	1399	1400	1401	1402	1403	1404
1405	1406	1407	1408	1409	1410	1411	1412	1413	1414	1415	1416
1417	1418	1419	1420	1421	1422	1423	1424	1425	1426	1427	1428
1429	1430	1431	1432	1433	1434	1435	1436	143			

44-2

CONTROL	A
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
10	10
11	11
12	12
13	13
14	14
15	15
16	16
17	17
18	18
19	19
20	20
21	21
22	22
23	23
24	24
25	25
26	26
27	27
28	28
29	29
30	30
31	31
32	32
33	33
34	34
35	35
36	36
37	37
38	38
39	39
40	40
41	41
42	42
43	43
44	44
45	45
46	46
47	47
48	48
49	49
50	50
51	51
52	52
53	53
54	54
55	55
56	56
57	57
58	58
59	59
60	60
61	61
62	62
63	63
64	64
65	65
66	66
67	67
68	68
69	69
70	70
71	71
72	72
73	73
74	74
75	75
76	76
77	77
78	78
79	79
80	80
81	81
82	82
83	83
84	84
85	85
86	86
87	87
88	88
89	89
90	90
91	91
92	92
93	93
94	94
95	95
96	96
97	97
98	98
99	99
100	100



# INSTALLATION AND OPERATING INSTRUCTIONS

## INSTALLATION

**WARNING:** The water heater must not be installed in small enclosure unless amply ventilated. In tightly constructed homes or basements, openings must be cut based on 1 sq. inch per 1,000 BTU/HR input. The heater must not be installed in bathroom, bedroom or any other occupied rooms normally kept closed. The water heater must be vented to the proper flue. Be sure your water heater is equipped to burn the particular type of gas you intended to use.

**LOCAL CODES:** Water heater installation must be in accordance with these instructions and all applicable local codes and gas utility requirements.

**SAFETY:** This heater is equipped with an automatic gas shutoff system actuated by high water temperature. A listed temperature and pressure relief valve shall be installed at the time of the installation of the heater. Local codes shall govern installation of relief devices.

A  $\frac{3}{4}$ " tapping has been provided in the top of the heater for installing the relief valve. The pressure setting of the relief valve must not exceed the working pressure shown on the rating plate.

Pipe discharge outlet of relief valve to a suitable drain using pipe full size of relief valve outlet (see typical installation). Failure to install a properly rated ASME and A.G.A. certified temperature and pressure relief valve at the time of installation of this heater will release the manufacturer from any claim due to damages caused by excessive pressure or high temperature.

## LOCATION

Install the water heater as close as possible to existing flues. On long horizontal runs use at least  $\frac{1}{4}$ " rise per foot of length.

Locate the heater in such a manner that should the tank or any connections leak, water damage would not result to adjoining areas. Under no circumstances is the manufacturer to be held liable for any water damages in connection with this heater.

Make certain the draft hood, packaged with this heater, is installed properly on top of the heater. The diameter of the flue pipe must match the diameter of the draft hood. Connect the  $\frac{3}{4}$ " water lines. Cold water inlet connects to right hand nipple at top of heater (facing heater), and hot water connects to left hand nipple.

Connect  $\frac{1}{2}$ " gas piping to gas thermostat. The installation should conform with American National Standard Installation of Gas Appliances and Gas Piping, Z 21.30 — 1964, or with the requirements of the authority having jurisdiction. Use a pipe joint compound that is resistant to the action of liquified petroleum (LP) gases. Check for gas leaks with soap suds, not a flame.

## MAINTENANCE

To assure long life and efficiency, the water heater tank must have a small amount of water drained periodically. Once a month the drain valve should be opened and the water allowed to run until it flows clean. This will help prevent sediment buildup in the tank bottom.

## OPERATION

**CONDENSATION:** When the heater is first lit or during periods of heavy draw-offs, water vapor may condense on the cold tank and drop down on the burner causing a sizzling sound. THIS IS NOT A LEAK and will disappear when the tank warms.

**TEMPERATURE REGULATION:** For general household usage, the normal setting will be satisfactory. However, the knob may be set to any position which satisfies temperature requirements.

## LIGHTING


Under no circumstances should the heater be operated unless it is filled with water. Lighting and operating instructions are located on the front of the heater.

## TEMPERATURE LIMITING SWITCH

Your heater has a nonadjustable limit switch built into the thermostat that guards against excessive temperatures.

If the limit switch operates, the pilot can not be relit until the water temperature drops to approximately 120° F. To relight, follow instructions on rating plate. If heater shuts down frequently contact your serviceman or local gas utility.

## TYPICAL INSTALLATION




(7A60439)

Figure D-2 III-15

# WATTS No. 70A SERIES Adjustable Water Tempering Valves

## IMPORTANT

**BE SURE TO REMOVE THERMOSTATIC ASSEMBLY from valve before sweating connections. Otherwise it will become damaged.**



## INSTALLATION

1. Remove thermostatic assembly (which is handtite) from body and install valve body as illustrated in diagram.

**NOTE:** Be sure piston and Teflon disc do not drop out of thermostat, when removing thermostatic assembly.

2. Re-insert thermostatic assembly in body and tighten securely.

## ADJUSTMENT

The No. 70A features a new adjustment means which permits you to "dial" a desired temperature, quickly and conveniently. To increase or decrease the water temperature, simply turn the adjusting cap as indicated by the arrow. The adjustment temperature range is 120° to 160°F.

## REPLACEMENT PARTS

### RENEWABLE THERMOSTAT AND SPRING

FOR 70A-70A-T  
Part No. SAN70A3

FOR L70A-L70A-T  
Part No. SAN70A3-LT



**DISCARD PLASTIC PROTECTOR**

**NOTE:** Replacement thermostats are furnished with a plastic protector which serves to hold the piston and Teflon disc. Be sure to discard this plastic protector when installing assembly. See note under installation.

## L70A SERIES

**NOTE:** For lower tempered water requirements at or below 130°F., use low temperature Model L70A Series which provides adjustment temperature range between 100° - 130°F.

# WATTS

*The name  
that protects  
your name*

WATTS REGULATOR COMPANY

LAWRENCE, MASS., U.S.A.

PRINTED IN U.S.A.

Figure D-1

III-16







The piping should be leak tested prior to connecting to the collectors or the ETM unit as specified in Section 15.042 Testing on the same drawing.

Electrical connections to ETM are described on Drawing SK 142054 Sheet 3 and the SDAS connections on SK 142055 Sheet 4.

The Site Data Acquisition System (SDAS) temperature sensor that are located in the ETM are brought up to the top of the insulation under the top cover. These are to be connected to the SDAS J Box as shown on SK 142055 Sheet 1.

The watt transducers for the 3 motors in the ETM and the purge unit fan motor are to be connected to the ETM control panel as shown on SK 142055 Sheet 4.

#### F) CONTROL SUBSYSTEM

The installation of the control subsystem consists of installing 2 aquastat controllers, the thermostat, a motorized valve, 2 temperature sensors and wells, a shield over the temperature sensor on the collector and connecting these units with the control panel on the ETM unit. The overall control system schematic and sequence of operation is shown on Drawing SK 142054 Sheet 1.

The temperature sensor and shield installed on the collector should be positioned as shown in detail (upper right) on SK 142054 Sheet 2. This requires removal and reinstallation of the collector glass which is shown in Figure F-2 and F-3.

The two aquastats should be installed as shown on SK 142054 Sheet 2 detail for  $T_{st}$  and  $T_{cd}$ .

PART NO.
----------

# SOLAR HEATING SYSTEM - SINGLE FAMILY RESIDENCE CONTROL SUBSYSTEM


## 1.0 GENERAL CONDITIONS

- 1.1 Scope: The Control Subsystem will include all controls necessary for operation of the solar heating system.
- 1.2 Required Work: The Mechanical Contractor will install and wire all controls as shown on control subsystem wiring schematic. This will include all line voltage wiring required.
- 1.3 Procurement of Control Devices: Control devices listed in Material List, (i.e., Solar Control Panel, Aquastat, Thermostat, etc.) will be provided by Honeywell EHC. This will include the control devices only. All materials necessary for a complete installation will be provided by the Mechanical Contractor.

## 2.0 BASIC MATERIALS AND METHODS

- 2.1 Basic Materials:
  - 2.1.1 Control sensor wiring (T<sub>1</sub> and T<sub>2</sub>); Wiring from solar control panel to control sensors T<sub>1</sub> and T<sub>2</sub> shall be run in conduit to outdoor areas and shall be Belden #8742 or equal.
  - 2.1.2 Power and control wiring: All line and low voltage wiring shall be of size and type required by applicable codes, and supplied by Mechanical Contractor.
  - 2.1.3 Other Materials: All other materials required for a complete installation of the Control Subsystem shall be supplied by the Mechanical Contractor.
- 2.2 Basic Methods:
  - 2.2.1 Control device installation methods: As per applicable details and/or instructions included with equipment.
  - 2.2.2 Electrical wiring: As per all applicable codes.

INSTALLATION  
BY  
E.A. CONTRACTORS



NOREYELL INC.		CREDIT RESOURCES CENTER	
SOLAR HEATING SYSTEM		SINGLE FAMILY RESIDENCE	
CONTROL SUBSYSTEM		CONTROL SUBSYSTEM	
SHEET NO. 55513		SHEET NO. 55513	
SCALE 1/8" = 1'-0"		SCALE 1/8" = 1'-0"	
CONTROL A		CONTROL A	





## Solar Meeting System - Single Family Businesses

### SEQUENCE OF OPERATION

**GENERAL**

Space heating is controlled by the two stage heating thermostat. First stage heating is not to utilize solar energy if available while second stage heating will supply the auxiliary energy if solar is not adequate. The system control logic is as follows:

- Collect solar energy when available
  - Store energy when no load conditions
  - Provide energy directly to load on demand
- Use direct solar energy before stored energy
- Use stored energy when direct solar energy is not available
- Use direct or stored solar energy before auxiliary energy

## DIRECT HEATING FROM COLLECTORS

Whenever plate temperature  $T_p$  is greater than  $105^\circ F$  (adjustable) and there is a call for heating from the space thermostat pumps  $P_1$  and  $P_2$  are actuated. Valve  $V_3$  is positioned to direct flow to the heating coil. The furnace fan is actuated to provide warm air to the space. A heating coil having air high-limit controller will close valve  $V_2$  to direct flow to the storage tank if the heating coil leaving-air temperature exceeds  $140^\circ F$  independent. Direct heating operation will continue until the space thermostat is satisfied or until the collector plate temperature has dropped to  $90^\circ F$ .

### HEATING FROM STORAGE

Whereas  $t$  is less than  $105^{\circ}\text{F}$  (adjustable),  $T_{37}$  is greater than  $30^{\circ}\text{F}$  (adjustable), and there is a call for space heat, pump  $P_3$  is actuated to discharge the storage tank for space heating. Valve  $V_2$  is positioned to direct flow to the heating coil. The furnace fan is actuated to provide warm air to the space. Pumps  $P_1$  and  $P_2$  are not allowed to operate during this mode. The heating coil has a high-limit controller function as described above.

### STORAGE CHARGING

**Storage Charging.** Storage charging is accomplished whenever  $T_p$  is greater than  $T_{SG}$  by 10°F (adjustable). Pumps  $P_1$  and  $P_2$  are activated and valve  $V_2$  is positioned to direct flow to the storage tank. If the above temperature difference falls to less than 3°F (adjustable), the storage charge mode is terminated.

### HEAT REJECTOR CONTROL

Whenever the collector discharge temperature exceeds  $210^{\circ}\text{F}$  (adjustable) as sensed by  $T_{CD}$ , since  $V_1$  is positioned to direct collector loop flow through the heat rejector, and the heat rejector fan is activated.


## AUXILIARY HEATING

Wherever solar heating is being utilized, either direct or stored, auxiliary gas-fired heating will be available as a controlled by the second heating stage of the space instrument. When solar heating is not available, auxiliary gas-fired heating will be available as first stage heating. Auxiliary heating is provided by a conventional gas furnace utilizing conventional controls.

## **DOMESTIC HOT WATER HEATING**

**PRELIMINARY WATER HEATING**

Thermostatic hot water is drawn from the water heater. It is reheated by preheated water from a coil in the sludge tank. A thermostatic mixing valve is used to regulate the hot water supply temperature to 140°F.




SOLAR HEATING SYSTEM CONTROL SCHEMATIC  
NO SCALE

MATERIAL LIST			MONSIEUR WELL MODEL 30.
ITEM	QUANTITY	DESCRIPTION	
	1	SOLAR CONTROL VALVE	91831A009
T <sub>5</sub>	1	AQUASTAT CONTROLLER	L5008C1265
T <sub>6</sub>	1	AQUASTAT CONTROLLER	L4008B1003
	1	MULTI-PASS THERMOSTAT	T07211004
	1	THERMOSTAT SUBBASE	Q6281004
V <sub>1</sub>	1	MOTORIZED VALVE	V4531A1003
V <sub>2</sub>	1	MOTORIZED VALVE	V4531A1003
	2	IMMERSION WELL	122555B
	1	CAS ASSEMBLY	112942F
T <sub>4</sub> & T <sub>5</sub>	2	SENSOR	CT7351005
	1	COLLECTOR SENSOR WELD	9K-142067

ES0241-KC-770001  
 1000000-5K-142053  
 FOR REFERENCE ONLY  
 NOT TO BE USED ON TENDRPORT

FOR REFERENCE ONLY  
PREMOUNTED IN TEMPORARY  
MODULE 54-142053

[illegible]



HONEYWELL INC.		HONEYWELL RESOURCES CENTER	
1000 WEST 10TH AVENUE		MINNEAPOLIS, MINN. 55404	
C 55513		K-14254	
SHEET 2 OF 2		DATE: 10/1/78	
BY: [Signature]		CHECKED: [Signature]	
DATE: 10/1/78		DATE: 10/1/78	

## COLLECTOR COVER REMOVAL & REPLACEMENT

**NOTE** - The collector surface temperature can burn. Handle solar collector with caution.

- 1 - Use rubber gloves when handling solar collector to avoid finger prints on glass.
- 2 - To replace the glass, remove the collector as shown in Figure 19 and disassemble according to Figure 20. To re-assemble frame, insert the glass sheets and new gaskets into side pieces making sure the glass is centered and the ends are even. Next insert the glass into the end pieces and secure with existing screws. Use sealer compound on corner joints.
- 3 - If the glass cover becomes dirty, clean the glass using a soft clean cloth, mild soap or detergent and clean rinse water. Alkalies can stain the glass if allowed to remain in contact too long.




Figure F-2




Figure F-3

The Control Valve  $V_1$  should be installed in the collector outlet piping where the purge unit is to be piped in.

The aquastats should be set as follows:

$T_{cd}$  (on collector outlet piping) set at  $210^{\circ}\text{F}$

$T_{st}$  (top of storage tank) set at  $100^{\circ}\text{F}$

The collector setpoint potentiometer in Control Panel should be set at  $105^{\circ}\text{F}$ . See Figure F-1.




Figure F-1.

#### G) SITE DATA ACQUISITION SUBSYSTEM (SDAS)

The installation of the SDAS involves the installation of 16 temperature sensors; a total radiation sensor, a watt transducer for the furnace blower and 7 flow rate meters. The list of sensors and system schematic showing their location is shown on SK 142055 Sheet 1. As noted on the list of sensors, some items are already installed but need to be connected to the SDAS Junction Box. The SDAS JB should be installed as shown in Figure G-1.

The return air flow sensor and Temp sensors T600 and TD601 should be installed as shown in Figure G-2 and the terminals wired as shown in detail 6 and 7 on SK 142055.

The storage tank temp sensors should be installed with T203 as the top sensor, T204 as the middle sensor and T205 as the bottom sensor. Sensor T401 is mounted in the inlet line at the bottom of the tank and TD401 is installed in the outlet line at the top of the tank -- opposite end to sight glass. These inline sensors should be installed as depicted in detail #9 and 10 on SK 142055 Sheet 2.


The total Radiation sensor I001 (Pyramoneter) should be installed on the collector support structure as shown in detail on SK 142055 Sheet 3.

The ambient temperature sensor, T001, should be mounted under the eaves on the north side of the residence. See detail 3 on SK 142055 Sheet 3 for mounting instructions.

Three types of flow meters are to be installed. The gas flow meters are the most conventional looking. They are to be installed in the gas line to the furnace and to the hot water heater. The return air flow rate is to be installed in the return air duct as shown in Figure G-2. The liquid flow sensors are to be installed in the hydronic lines as depicted in detail 5 on SK 142055 Sheet 3. Flow sensor W100 can be installed in the collector supply line near where it connects to the ETM. The storage flow sensor W200 should be installed in the outlet line from the storage tank (bottom). The heating coil flow rate sensor should be installed in the return line from the space heating coil attached to the furnace. The DHW flow sensor should be installed where the hydrant line is tapped to provide the feed to the preheat coil in the storage tank.

The wiring connections for each sensor is shown on SK 142055. The sensor wiring is to be brought to the SDAS J Box. The types of wire connection and conduit requirements are called out on Sheet 1 of SK 142055.





SDA5 MODULE AND J-BOX INSTALLATION  
NO SCALE

Figure G-1






Figure G-2. Aux. Heat SDAS Sensor Installations





1. **NAME** \_\_\_\_\_  
 2. **ADDRESS** \_\_\_\_\_  
 3. **CITY** \_\_\_\_\_  
 4. **STATE** \_\_\_\_\_  
 5. **ZIP** \_\_\_\_\_  
 6. **PHONE** \_\_\_\_\_  
 7. **TELETYPE** \_\_\_\_\_  
 8. **FAX** \_\_\_\_\_  
 9. **E-MAIL** \_\_\_\_\_  
 10. **DATE** \_\_\_\_\_  
 11. **SIGNATURE** \_\_\_\_\_  
 12. **PRINTED NAME** \_\_\_\_\_  
 13. **POSITION** \_\_\_\_\_  
 14. **COMPANY** \_\_\_\_\_  
 15. **INDUSTRY** \_\_\_\_\_  
 16. **TELEPHONE** \_\_\_\_\_  
 17. **TELETYPE** \_\_\_\_\_  
 18. **FAX** \_\_\_\_\_  
 19. **E-MAIL** \_\_\_\_\_  
 20. **DATE** \_\_\_\_\_  
 21. **SIGNATURE** \_\_\_\_\_  
 22. **PRINTED NAME** \_\_\_\_\_  
 23. **POSITION** \_\_\_\_\_  
 24. **COMPANY** \_\_\_\_\_  
 25. **INDUSTRY** \_\_\_\_\_  
 26. **TELEPHONE** \_\_\_\_\_  
 27. **TELETYPE** \_\_\_\_\_  
 28. **FAX** \_\_\_\_\_  
 29. **E-MAIL** \_\_\_\_\_  
 30. **DATE** \_\_\_\_\_  
 31. **SIGNATURE** \_\_\_\_\_  
 32. **PRINTED NAME** \_\_\_\_\_  
 33. **POSITION** \_\_\_\_\_  
 34. **COMPANY** \_\_\_\_\_  
 35. **INDUSTRY** \_\_\_\_\_  
 36. **TELEPHONE** \_\_\_\_\_  
 37. **TELETYPE** \_\_\_\_\_  
 38. **FAX** \_\_\_\_\_  
 39. **E-MAIL** \_\_\_\_\_  
 40. **DATE** \_\_\_\_\_  
 41. **SIGNATURE** \_\_\_\_\_  
 42. **PRINTED NAME** \_\_\_\_\_  
 43. **POSITION** \_\_\_\_\_  
 44. **COMPANY** \_\_\_\_\_  
 45. **INDUSTRY** \_\_\_\_\_  
 46. **TELEPHONE** \_\_\_\_\_  
 47. **TELETYPE** \_\_\_\_\_  
 48. **FAX** \_\_\_\_\_  
 49. **E-MAIL** \_\_\_\_\_  
 50. **DATE** \_\_\_\_\_  
 51. **SIGNATURE** \_\_\_\_\_  
 52. **PRINTED NAME** \_\_\_\_\_  
 53. **POSITION** \_\_\_\_\_  
 54. **COMPANY** \_\_\_\_\_  
 55. **INDUSTRY** \_\_\_\_\_  
 56. **TELEPHONE** \_\_\_\_\_  
 57. **TELETYPE** \_\_\_\_\_  
 58. **FAX** \_\_\_\_\_  
 59. **E-MAIL** \_\_\_\_\_  
 60. **DATE** \_\_\_\_\_  
 61. **SIGNATURE** \_\_\_\_\_  
 62. **PRINTED NAME** \_\_\_\_\_  
 63. **POSITION** \_\_\_\_\_  
 64. **COMPANY** \_\_\_\_\_  
 65. **INDUSTRY** \_\_\_\_\_  
 66. **TELEPHONE** \_\_\_\_\_  
 67. **TELETYPE** \_\_\_\_\_  
 68. **FAX** \_\_\_\_\_  
 69. **E-MAIL** \_\_\_\_\_  
 70. **DATE** \_\_\_\_\_  
 71. **SIGNATURE** \_\_\_\_\_  
 72. **PRINTED NAME** \_\_\_\_\_  
 73. **POSITION** \_\_\_\_\_  
 74. **COMPANY** \_\_\_\_\_  
 75. **INDUSTRY** \_\_\_\_\_  
 76. **TELEPHONE** \_\_\_\_\_  
 77. **TELETYPE** \_\_\_\_\_  
 78. **FAX** \_\_\_\_\_  
 79. **E-MAIL** \_\_\_\_\_  
 80. **DATE** \_\_\_\_\_  
 81. **SIGNATURE** \_\_\_\_\_  
 82. **PRINTED NAME** \_\_\_\_\_  
 83. **POSITION** \_\_\_\_\_  
 84. **COMPANY** \_\_\_\_\_  
 85. **INDUSTRY** \_\_\_\_\_  
 86. **TELEPHONE** \_\_\_\_\_  
 87. **TELETYPE** \_\_\_\_\_  
 88. **FAX** \_\_\_\_\_  
 89. **E-MAIL** \_\_\_\_\_  
 90. **DATE** \_\_\_\_\_  
 91. **SIGNATURE** \_\_\_\_\_  
 92. **PRINTED NAME** \_\_\_\_\_  
 93. **POSITION** \_\_\_\_\_  
 94. **COMPANY** \_\_\_\_\_  
 95. **INDUSTRY** \_\_\_\_\_  
 96. **TELEPHONE** \_\_\_\_\_  
 97. **TELETYPE** \_\_\_\_\_  
 98. **FAX** \_\_\_\_\_  
 99. **E-MAIL** \_\_\_\_\_  
 100. **DATE** \_\_\_\_\_  
 101. **SIGNATURE** \_\_\_\_\_  
 102. **PRINTED NAME** \_\_\_\_\_  
 103. **POSITION** \_\_\_\_\_  
 104. **COMPANY** \_\_\_\_\_  
 105. **INDUSTRY** \_\_\_\_\_  
 106. **TELEPHONE** \_\_\_\_\_  
 107. **TELETYPE** \_\_\_\_\_  
 108. **FAX** \_\_\_\_\_  
 109. **E-MAIL** \_\_\_\_\_  
 110. **DATE** \_\_\_\_\_  
 111. **SIGNATURE** \_\_\_\_\_  
 112. **PRINTED NAME** \_\_\_\_\_  
 113. **POSITION** \_\_\_\_\_  
 114. **COMPANY** \_\_\_\_\_  
 115. **INDUSTRY** \_\_\_\_\_  
 116. **TELEPHONE** \_\_\_\_\_  
 117. **TELETYPE** \_\_\_\_\_  
 118. **FAX** \_\_\_\_\_  
 119. **E-MAIL** \_\_\_\_\_  
 120. **DATE** \_\_\_\_\_  
 121. **SIGNATURE** \_\_\_\_\_  
 122. **PRINTED NAME** \_\_\_\_\_  
 123. **POSITION** \_\_\_\_\_  
 124. **COMPANY** \_\_\_\_\_  
 125. **INDUSTRY** \_\_\_\_\_  
 126. **TELEPHONE** \_\_\_\_\_  
 127. **TELETYPE** \_\_\_\_\_  
 128. **FAX** \_\_\_\_\_  
 129. **E-MAIL** \_\_\_\_\_  
 130. **DATE** \_\_\_\_\_  
 131. **SIGNATURE** \_\_\_\_\_  
 132. **PRINTED NAME** \_\_\_\_\_  
 133. **POSITION** \_\_\_\_\_  
 134. **COMPANY** \_\_\_\_\_  
 135. **INDUSTRY** \_\_\_\_\_  
 136. **TELEPHONE** \_\_\_\_\_  
 137. **TELETYPE** \_\_\_\_\_  
 138. **FAX** \_\_\_\_\_  
 139. **E-MAIL** \_\_\_\_\_  
 140. **DATE** \_\_\_\_\_  
 141. **SIGNATURE** \_\_\_\_\_  
 142. **PRINTED NAME** \_\_\_\_\_  
 143. **POSITION** \_\_\_\_\_  
 144. **COMPANY** \_\_\_\_\_  
 145. **INDUSTRY** \_\_\_\_\_  
 146. **TELEPHONE** \_\_\_\_\_  
 147. **TELETYPE** \_\_\_\_\_  
 148. **FAX** \_\_\_\_\_  
 149. **E-MAIL** \_\_\_\_\_  
 150. **DATE** \_\_\_\_\_  
 151. **SIGNATURE** \_\_\_\_\_  
 152. **PRINTED NAME** \_\_\_\_\_  
 153. **POSITION** \_\_\_\_\_  
 154. **COMPANY** \_\_\_\_\_  
 155. **INDUSTRY** \_\_\_\_\_  
 156. **TELEPHONE** \_\_\_\_\_  
 157. **TELETYPE** \_\_\_\_\_  
 158. **FAX** \_\_\_\_\_  
 159. **E-MAIL** \_\_\_\_\_  
 160. **DATE** \_\_\_\_\_  
 161. **SIGNATURE** \_\_\_\_\_  
 162. **PRINTED NAME** \_\_\_\_\_  
 163. **POSITION** \_\_\_\_\_  
 164. **COMPANY** \_\_\_\_\_  
 165. **INDUSTRY** \_\_\_\_\_  
 166. **TELEPHONE** \_\_\_\_\_  
 167. **TELETYPE** \_\_\_\_\_  
 168. **FAX** \_\_\_\_\_  
 169. **E-MAIL** \_\_\_\_\_  
 170. **DATE** \_\_\_\_\_  
 171. **SIGNATURE** \_\_\_\_\_  
 172. **PRINTED NAME** \_\_\_\_\_  
 173. **POSITION** \_\_\_\_\_  
 174. **COMPANY** \_\_\_\_\_  
 175. **INDUSTRY** \_\_\_\_\_  
 176. **TELEPHONE** \_\_\_\_\_  
 177. **TELETYPE** \_\_\_\_\_  
 178. **FAX** \_\_\_\_\_  
 179. **E-MAIL** \_\_\_\_\_  
 180. **DATE** \_\_\_\_\_  
 181. **SIGNATURE** \_\_\_\_\_  
 182. **PRINTED NAME** \_\_\_\_\_  
 183. **POSITION** \_\_\_\_\_  
 184. **COMPANY** \_\_\_\_\_  
 185. **INDUSTRY** \_\_\_\_\_  
 186. **TELEPHONE** \_\_\_\_\_  
 187. **TELETYPE** \_\_\_\_\_  
 188. **FAX** \_\_\_\_\_  
 189. **E-MAIL** \_\_\_\_\_  
 190. **DATE** \_\_\_\_\_  
 191. **SIGNATURE** \_\_\_\_\_  
 192. **PRINTED NAME** \_\_\_\_\_  
 193. **POSITION** \_\_\_\_\_  
 194. **COMPANY** \_\_\_\_\_  
 195. **INDUSTRY** \_\_\_\_\_  
 196. **TELEPHONE** \_\_\_\_\_  
 197. **TELETYPE** \_\_\_\_\_  
 198. **FAX** \_\_\_\_\_  
 199. **E-MAIL** \_\_\_\_\_  
 200. **DATE** \_\_\_\_\_  
 201. **SIGNATURE** \_\_\_\_\_  
 202. **PRINTED NAME** \_\_\_\_\_  
 203. **POSITION** \_\_\_\_\_  
 204. **COMPANY** \_\_\_\_\_  
 205. **INDUSTRY** \_\_\_\_\_  
 206. **TELEPHONE** \_\_\_\_\_  
 207. **TELETYPE** \_\_\_\_\_  
 208. **FAX** \_\_\_\_\_  
 209. **E-MAIL** \_\_\_\_\_  
 210. **DATE** \_\_\_\_\_  
 211. **SIGNATURE** \_\_\_\_\_  
 212. **PRINTED NAME** \_\_\_\_\_  
 213. **POSITION** \_\_\_\_\_  
 214. **COMPANY** \_\_\_\_\_  
 215. **INDUSTRY** \_\_\_\_\_  
 216. **TELEPHONE** \_\_\_\_\_  
 217. **TELETYPE** \_\_\_\_\_  
 218. **FAX** \_\_\_\_\_  
 219. **E-MAIL** \_\_\_\_\_  
 22

THE CHARTERED UNIONS NATIONAL ORGANIZATION		CHARTERED UNIONS OFFICE 1000 N. 10TH ST. SEATTLE, WA 98108		1000 N. 10TH ST. SEATTLE, WA 98108		HOMETWELL INC.		HOMETWELL ASSOCIATES CENTER 1000 N. 10TH ST. SEATTLE, WA 98108	
A : B : C : D : E : F : G : H : I : J : K : L : M : N : O : P : Q : R : S : T : U : V : W : X : Y : Z : AA : AB : AC : AD : AE : AF : AG : AH : AI : AJ : AK : AL : AM : AN : AO : AP : AQ : AR : AS : AT : AU : AV : AW : AX : AY : AZ : BA : BB : BC : BD : BE : BF : BG : BH : BI : BJ : BK : BL : BM : BN : BO : BP : BQ : BR : BS : BT : BU : BV : BW : BX : BY : BZ : CA : CB : CC : CD : CE : CF : CG : CH : CI : CJ : CK : CL : CM : CN : CO : CP : CQ : CR : CS : CT : CU : CV : CW : CX : CY : CZ : DA : DB : DC : DD : DE : DF : DG : DH : DI : DJ : DK : DL : DM : DN : DO : DP : DQ : DR : DS : DT : DU : DV : DW : DX : DY : DZ : EA : EB : EC : ED : EE : EF : EG : EH : EI : EJ : EK : EL : EM : EN : EO : EP : EQ : ER : ES : ET : EU : EV : EW : EX : EY : EZ : FA : FB : FC : FD : FE : FF : FG : FH : FI : FJ : FK : FL : FM : FN : FO : FP : FQ : FR : FS : FT : FU : FV : FW : FX : FY : FZ : GA : GB : GC : GD : GE : GF : GG : GH : GI : GJ : GK : GL : GM : GN : GO : GP : GQ : GR : GS : GT : GU : GV : GW : GX : GY : GZ : HA : HB : HC : HD : HE : HF : HG : HH : HI : HJ : HK : HL : HM : HN : HO : HP : HQ : HR : HS : HT : HU : HV : HW : HX : HY : HZ : IA : IB : IC : ID : IE : IF : IG : IH : II : IJ : IK : IL : IM : IN : IO : IP : IQ : IR : IS : IT : IU : IV : IW : IX : IY : IZ : JA : JB : JC : JD : JE : JF : JG : JH : JI : JJ : JK : JL : JM : JN : JO : JP : JQ : JR : JS : JT : JU : JV : JW : JX : JY : JZ : KA : KB : KC : KD : KE : KF : KG : KH : KI : KJ : KK : KL : KM : KN : KO : KP : KQ : KR : KS : KT : KU : KV : KW : KX : KY : KZ : LA : LB : LC : LD : LE : LF : LG : LH : LI : LJ : LK : LL : LM : LN : LO : LP : LQ : LR : LS : LT : LU : LV : LW : LX : LY : LZ : MA : MB : MC : MD : ME : MF : MG : MH : MI : MJ : MK : ML : MM : MN : MO : MP : MQ : MR : MS : MT : MU : MV : MW : MX : MY : MZ : NA : NB : NC : ND : NE : NF : NG : NH : NI : NJ : NK : NL : NM : NN : NO : NP : NQ : NR : NS : NT : NU : NV : NW : NX : NY : NZ : OA : OB : OC : OD : OE : OF : OG : OH : OI : OJ : OK : OL : OM : ON : OO : OP : OQ : OR : OS : OT : OU : OV : OW : OX : OY : OZ : PA : PB : PC : PD : PE : PF : PG : PH : PI : PJ : PK : PL : PM : PN : PO : PP : PQ : PR : PS : PT : PU : PV : PW : PX : PY : PZ : QA : QB : QC : QD : QE : QF : QG : QH : QI : QJ : QK : QL : QM : QN : QO : QP : QQ : QR : QS : QT : QU : QV : QW : QX : QY : QZ : RA : RB : RC : RD : RE : RF : RG : RH : RI : RJ : RK : RL : RM : RN : RO : RP : RQ : RR : RS : RT : RU : RV : RW : RX : RY : RZ : SA : SB : SC : SD : SE : SF : SG : SH : SI : SJ : SK : SL : SM : SN : SO : SP : SQ : SR : SS : ST : SU : SV : SW : SX : SY : SZ : TA : TB : TC : TD : TE : TF : TG : TH : TI : TJ : TK : TL : TM : TN : TO : TP : TQ : TR : TS : TU : TV : TW : TX : TY : TZ :<									



ORIGINAL PAGE IS  
~~OF POOR QUALITY~~

[illegible]



**SECTION IV**  
**SYSTEM TEST AND FILLING**

**A) TESTING**

As the hydronic loops are completed they should be tested to verify their integrity. The System Integration SK 142057 Sheet 3 (Pg. III-19) outlines the testing to be performed under 15.042 Testing.

**B) FLUSHING AND CLEANING**

After the testing of the hydronic loops is completed the following cleaning procedure should be used.

- 1) The collector loop and the space heat/storage loop are controlled by the ETM module. See SK 142053 sheet 2. (Pg. III-18)

Access to the various components in the ETM can be gained as described below. These items are shown in Figure 4-1, 4-2 and 4-3.

- |  |  |
|--|--|
| a) drain/fill valve #4   | - remove side panel (opposite control box)   |
| b) ball valve, flush valve #3, and lift check valve                              | - remove top panel and insulation in front of coll. return inlet                   |
| c) HX drain  | - remove side panel (opp. control box); then remove galvanized insulation retainer |
| d) Pressure gauge (part of low level/pressure indicator system) and HX air bleed | - remove top panel and insulation between the Control Panel and HX                 |

Flushing and draining of the collector loop must be done thru flush drain/fill valve #4 and flush valve #3. To clean collector loop:

- a) set all switches on control panel to stop
- b) close ball valve adjacent to flush valve #3 and open balancing valves in collector supply lines and air vents at collectors




Figure 4-1. ETM Front View






Figure 4-2. ETM Top View




Figure 4-3. ETM End View (Left)

- c) Connect fill line from drum with 50 gal. of water mixed with 1/2 gal. trisodium phosphate to drain/fill valve #4
- d) open valve #4 and using external pump
- e) pump liquid into system.

**CAUTION:** Pressure should not exceed 40 psig

- f) As liquid starts flowing open flush valve #3;
- g) a drain hose should be connected to flush valve #3 and run to a large container (55 gal. drum) to catch to flushing fluid;
- h) start pump by moving switch marked P1 to P1 "ON".

**CAUTION:** Do not run pump when no liquid is present

- i) Continue feeding flushing fluid until it flows freely from drain hose;
- j) close air vents at collector when air ceases to flow;
- k) energize valve V1 (turn to ON position) and continue to feed fluid until it flows freely from drain hose.
- l) open ball valve adjacent to flush valve #3 and close flush valve #3
- m) continue to supply fluid until pressure gauge reads 20 psig
- n) bleed air from HX bleed valve, then
- o) close drain and fill valve #4. Shut external fluid supply and run system for 4 hours.

Monitor pressure gauge periodically to be sure it remains within 20-35 psi operating range.

When cleaning is completed drain total collector loop - HX fluid and measure volume so that correct amount of ethylene glycol can be mixed.



To completely drain collector loop, the Lift Check Valve (rear Circuit Setter (3) must be opened (turn knob counter-clockwise till it stops). \*After draining, insure knob is returned to the fully closed position.

After system is totally drained, remove drain plug from HX to empty shell side.

The strainer should be cleaned while system is drained.

The collector loop should now be flushed with clean water for two hours. This may be accomplished using the water system. Caution:- assure supply pressure does not exceed 40 psi. It should be connected to the drain/fill valve No. 4. Pump  $P_1$  need not be energized but ball valve must be closed. A drain hose should be connected to flush valve No. 3 and run outside to an appropriate area.

The HX portion of the system should be flushed and it may be performed as follows:

- a) Close ball valve and drain/flush valve 3
  - b) Open HX drain and connect drain hose to it
  - c) Pump fluid into drain/fill valve #4 and out of HX drain
- 2) The storage and heating system loop should be flushed and cleaned prior to filling
- a) The storage tank should be flushed first. Connect hose to drain valve on bottom of tank and open valve. Drain hose should be run to appropriate floor drain. Remove manhole cover and using hose connected to household water supply

\*NOTE: Without isolation valves outside ETM, system must be drained before maintenance can be performed.

flush interior of tank.

**CAUTION:** Do not enter tank with shoes as interior lining could be damaged.

To flush heat coil loop, connect a drain hose to drain valve #1 in ETM, open valve, and connect to drain valve #2 in ETM a hose from household water supply. Close both isolation valves on inlet and outlet of storage tank. Turn water on and let water flow for 30 minutes.

- b) When system is thoroughly flushed shut-off drain valve and fill tank to 6" below top of tank. Add inhibitor (1200 mg/l) which is 5 gallons of nitrate base made by Norman Chemical product no. 284, 1630 Carroll Ave, St. Paul, MN.

#### C) BALANCING

Connect Bell and Gossett Delta Pressure readout kit or equivalent to Bell and Gossett Circuit setter balance valve #1 in ETM (heat from storage loop). Proceed as per instructions included with readout kit. Manually start P3. Adjust flow to 8 GPM.

Repeat procedure with circuit setter balance valve #2 in ETM (storage charge loop). Run P.2. Adjust flow to 8 GPM.

Repeat procedure with circuit setter balance valve #3 in ETM (total solar collector loop) run P1. Adjust flow to 12 GPM.

Repeat procedure with circuit setter flow balance valve in supply line to 3 high collector array. (Not in ETM) with P-1 operating. Adjust flow to 5.5 GPM.

Repeat procedure with circuit setter flow balance value in supply line to 2 high collector array (not in ETM) with P-1 running. Adjust flow to 6.5 GPM.

## **D) START-UP**

### **1) Collector Loop**

Fill the collector loop with a 50/50 solution of water and Dowtherm SR1 ethylene glycol. Mix the glycol and water in a 55 gallon drum. Connect fill hose to drain/fill valve #4. Connect inlet of external pump to 55 gal. drum, open fill valve #4 and start pump. Open all air bleeds in the system and fill slowly. It is imperative not to fill the system too rapidly. Close air bleeds as they begin to leak. Precautions should be taken to prevent the glycol mixture from spilling onto the building or collector array.

### **2) System Pressurization**

Once the system is full and purged of air, it may be pressurized to 20 psig as shown on low water/pressure gauge using external pump and 50/50 mixed solution. Energize the collector system pump  $P_1$  manually. Air that is trapped will tend to be separated by the air separator as the fluid circulates. This will cause a decrease in the fluid level within the collector loop. It is important to watch this pressure level to see that it does not get too low as the low fluid warning light will come on. If the pressure gets low, then add more fluid to the collector loop to maintain the same charge pressure. Low water/pressure gauge should be set to 15 psig.

## **E) SYSTEM CHECK-OUT**

To verify system operation have both loops of system filled and electrical power to ETM. Position all Auto-Stop-On switches in Auto position. This allows the indicator lights to function correctly. Using system check-out matrix on Figure 4-4 verify each mode operates as shown.

OPERATING MODE	DISCONNECT	ADJUST	ENERGIZE	PUMP 1	PUMP 2	PUMP 3	VALVE 1	VALVE 2	GAS VALVE	FAN	CONTROL PANEL LIGHTS
Collector Heat Heating House	LOW Temperature Sensor on Differential Temperature Terminal C Controller		1st Stage Heat (W <sub>1</sub> energized)	E	E	DE	DE	DE	DE	E Med-Hi	Collector Heat Heating House
Collector Heat Heating House and Auxiliary Heat Heating House	LOW Temperature Sensor on Differential Temperature Terminal C Controller		2nd Stage Heat (W <sub>1</sub> and W <sub>2</sub> energized)	E	E	DE	DE	DE	E	E Med-Hi	Collector Heat Heating House, Auxiliary Heat Heating House
Storage Heat Heating House	HIGH Temperature Sensor on Differential Temperature Terminal A Controller	Aquastat Tank Sensor Set Point at Minimum (T <sub>1st</sub> )	1st Stage Heat (W <sub>1</sub> energized)	DE	DE	E	DE	DE	DE	E Med-Hi	Storage Heat Heating House
Storage Heat Heating House and Auxiliary Heat Heating House	HIGH Temperature Sensor on Differential Temperature Terminal A Controller	Aquastat Tank Sensor Set Point at Minimum	2nd Stage Heat (W <sub>1</sub> and W <sub>2</sub> energized)	DE	DE	E	DE	DE	E	E Med-Hi	Storage Heat Heating House, Auxiliary Heat Heating House
Auxiliary Heat Heating House	HIGH Temperature Sensor on Differential Temperature Terminal A Controller	Aquastat Tank Sensor Set Point at Maximum	1st Stage Heat (W <sub>1</sub> energized)	DE	DE	DE	DE	DE	E	E Med-Hi	Auxiliary Heat Heating House
Collector Heat to Storage Tank	LOW Temperature Sensor on Differential Temperature Terminal C Controller		Set Thermostat Down	E	E	DE	DE	E	DE	DE	Collector Heat to Storage Tank
Cooling			G on Space Thermostat	DE	DE	DE	DE	DE	DE	E Hi	
Ventilates			G on Space Thermostat	DE	DE	DE	DE	DE	DE	E Hi	
Port	LOW Temperature Sensor on Differential Temperature Terminal C Controller	Aquastat Collector Pipe Sensor Set Point at Minimum	Set Thermostat Down	E	E	DE	E	E	DE	DE	

Figure 4-4. System Checkout

## **SECTION V**

### **OPERATION**

**This section outlines the operation of the single family residence Solar Heating System. The system is automatically controlled by the space thermostat to provide energy to satisfy heating requirements. When no heat is required in the dwelling the system will automatically store the collector solar energy or will dissipate it if the storage is fully charged.**

**The following sections describe in detail how the system and subsystems operate.**

## System Operation

### General (Refer to Pg. I-2)

Once the solar system has been installed, fluids added to collector and storage loops and system checked out by the installer, the complete system will operate automatically. Lights on the control panel will indicate in which mode the system is operating. For normal operation, set all switches in the control panel to the "Auto" position. The On and Stop positions should only be used for manually controlling the system such as during maintenance or system checkout.

The space thermostat can call for heat in two stages. The first stage will utilize solar energy if it is available. If this is not sufficient to heat the building the thermostat will switch automatically to second stage heating which energizes the gas furnace. Solar heated water is available from the collector if sufficient solar energy is available or from energy stored in the solar storage tank.

When heating directly from the collectors to the heating coil located in the return air section of the furnace, the collectors must be at least 105°F. The energy will continue to be supplied from the collectors as long as there is a call for heat and the collectors are greater than 90°F. In this mode pumps P<sub>1</sub> and P<sub>2</sub> are energized and water is heated by the heat exchanger and circulated around the storage tank to the furnace coil through valve V<sub>2</sub>.

If sufficient energy is not available from the collectors and the storage tank is greater than 90°F, then pumps P<sub>1</sub> and P<sub>2</sub> are off, pump P<sub>3</sub> is energized and hot water is supplied to the furnace coil from the top of the storage tank and is returned to the bottom of the tank.

When there is no call for heating and solar energy is available from the collectors the system will charge storage as long as the collectors are greater than 3°F above the storage tank after initial start.

When the storage is fully charged the system will operate the purge coil whenever the collector outlet is greater than 220°F. The purge will control the collector outlet temperature to prevent over heating of the system.

## **SECTION VI**

### **MAINTENANCE**

**This section outlines the maintenance of the single family residence Solar Heating System. The maintenance required is outline in two sections - Section I Routine Maintenance covering ordinary and preventive maintenance; - Section II Maintenance Schedule which provides a chart of maintenance activities for the system and the subsystems.**

**Repair and parts replacement for the components are provided in the appendices A thru F.**

## ROUTINE MAINTENANCE

The Solar Heating System requires only a small amount of routine maintenance. The elements requiring maintenance are broken down by subsystems and described below.

### A. Collector Subsystem

The components requiring routine maintenance are the:

- Solar Collectors (LSC 18-1)  
Normal rainfall will usually suffice for cleaning however, inspect spring and fall for dirty cover glass. Clean glass using a soft clean cloth, mild soap or detergent and clean rinse water. Alkalines can stain the glass if allowed to remain in contact too long.
- Purge Unit (HRW-1-30)  
Inspect spring and fall for debris on coil. Clear debris from coil with brush - unit may be flushed with water hose if necessary. Lubricate motor in accordance with guide on motor.

### B. Storage Subsystem

The water in the storage tank should have the inhibitor checked and water condition checked annually. If the tank water has a pungent odor, or dark discolorization, drain tank and refill with clean water adding inhibitor as called out in Section V under Start-Up part 2 Storage Loop.

The inhibitor pH level should be between 7.0 and 9.0 Draw a small amount of water from the storage tank drain valve. Using a pH test kit dip a short piece of test paper in the fluid drain off. Observe the color of the moistened portion and compare to color chart with kit. The desired pH is 8.0 or higher. If the pH is less than 8.0 add 5 gallons of Product No. 284 made by Norman Chemical Co., 1630 Carroll Ave., St. Paul, or equivalent to reach a value of 1200 mg/l. (1200 ppm) of nitrite base.

Adding of inhibitor and filling tank may be done thru manhole in top of tank. Tank may be drained by connecting drain hose to tank drain on bottom of tank.



### C. Auxiliary Energy and Space Heat Subsystem

- The furnace should have the following checked annually:
  - check and clean blower wheel
  - lubricate blower motor
  - \*- replace filter media
  - check furnace operation

### D. Hot Water Subsystem

To assure long life and efficiency, the water heater tank should have a small amount of water drained periodically. Once every month or two the drain valve should be opened and the water allowed to run until it flows clean. This will help prevent sediment buildup on the bottom of the tank.

### E. Energy Transport Subsystem

- The Energy Transport Module (ETM-1) has three pumps that should be lubricated every three months. Proper lubrication is the most important single factor in obtaining long life and trouble free operation. Each oil cup, two on motor and one on the pump should be filled with #20 non-detergent motor oil.
- Transfer Fluid (SR-1) - The ethylene glycol and water mixture contains corrosion inhibitors. An annual test of the fluid is necessary to avoid plumbing decay. "Do not add chromate inhibitors to system". Using a standard pH test kit, dip a short piece of test paper in a small amount of fluid drawn from drain and fill valve #4 in ETM. Observe the color of the moistened portion and compare to color chart with kit. The desired transfer fluid pH is 8 or higher. If the pH is less than 8 acids are forming in the fluid. The dwelling owner should call the solar system service man to add inhibitor to system. Use Figure 6-E-1 to determine the correct quantity of inhibitor to be added. After system operation for 30 minutes recheck pH level for proper value.
- Replenishing Inhibitor - If the pH is less than 8, the inhibitor is becoming depleted, and adding inhibitor to protect the system is recommended. Such inhibitor is readily available from the Dow Chemical Company in five gallon lots. Since the inhibitors are specially designed for Dowtherm SR-1 heat transfer medium, other type inhibitors should never be mixed with this material.

\* Filter should be checked monthly during heavy operation and replaced as needed.

**-Quantities of Inhibitor for DOWTHERM  
to Recharge Systems Containing DOWTHERM**




Figure 6-E-1.

**F. Control Subsystem**

The control subsystem does not require any periodic maintenance. This subsystem can be used to check system operation as shown in Section IV System Test and Filling.

# SECTION VII

## MAINTENANCE SCHEDULE

Figure 7-1 outlines the routine maintenance required on the single family Solar Heating System.

Frequency	Activity	Reference	
		Section	Appendix
Quarterly every 3 months	Check furnace air filter	3C	C
	Hot Water heater sediment drain	3D	D
	ETM Pump lubrication	3E	E
Semi-Annual or seasonal	Clean Collector Glass	3A	A
	Clean Purge unit	3A	A
Annual	Storage tank fluid check	3B	B
	Service furnace	3C	C
	Solar collector fluid check	3E	

Figure 7-1. Routine Maintenance

## APPENDIX A

### COLLECTOR SUBSYSTEM


LSC18-1	Solar Collectors
HRW-1-30	Purge Unit
Y534A	Diverting Valve (page E-10)

operation  
maintenance  
and  
installation  
instructions


# LSC18-1 and LSC18-1S Solar Collectors

SOLAR  
501,249M  
676

# PARTS ARRANGEMENT



## SOLAR COLLECTOR DIMENSIONS



# FRAMING - FLASHING - COLLECTOR MOUNTING

## I - SHIPPING AND PACKING LIST

Package 1 of 1 Contains

1 - Assembled solar collector

## II - SHIPPING DAMAGE

Check unit for shipping damage. Contact the last carrier immediately if any damage is found.

## III - GENERAL

These instructions are intended as a general guide and do not supersede local codes. Authorities having jurisdiction should be consulted before installation.

## IV - APPLICATION

The consulting engineer, architect or dealer must determine the solar collector application including number required, placement,

mounting angle and piping sequence. This instruction outlines one typical method of framing and installing the solar collectors. Other designs can be substituted if the basic guidelines within the instruction are followed.

Figure 1 illustrates a typical residential application.

## V - SOLAR COLLECTOR

The collectors must mount on a watertight roof. Roof construction must be adequate to support the collectors and mounting frame. Solar collectors must be installed with the flow tubes in the vertical




FIGURE 1




FIGURE 3




FIGURE 2

position. Figure 2 illustrates details for a typical mounting frame. Install the frame and solar collectors as follows:

1 - Center sleepers over trusses and secure to roof. Figure 3 shows the sleeper flashed into the roof.

a - Length of sleepers required for a single row of collectors is 86-1/2 inches.

b - Length of sleepers required for two rows of collectors is 162-5/8 inches.

2 - Figure 4 illustrates typical framing construction for one row of collectors. Figure 5 illustrates construction for two rows of collectors. 2" x 8" dimensional lumber is utilized.




FIGURE 4




FIGURE 5



- 3 - Position first collector 4-7/8 inches from end of frame and then maintain 1/8 inch between remainder of collectors. Refer to Figure 6. Secure collectors to frame with lag bolts (4 per collector). If desired the inside spacing could enclose the supply and return header runs where they penetrate through roof.

*NOTE - Solar collectors can be piped individually as they are set or if working area permits, piped after all collectors are set.*

- 4 - The temperature control system has a sensor which secures

directly to one absorber plate. Remove the collector frame from desired collector and install the sensor in the center of absorber plate. Refer to manufacturer's installation instructions. Drill a hole through collector cabinet and route wiring to sensor.

- 5 - After the system has been leak tested and the insulation has been installed on outdoor piping, flash the frame and solar collectors as illustrated in Figure 7. This flashing prevents air flow around collectors minimizing convection losses. This trim can bolt directly to the collector frame.




FIGURE 6




FIGURE 7


# PIPING

## VI - PIPING FOR SOLAR COLLECTORS

### A - Basic Piping Fundamentals

#### 1 - Flared Connections


- a - Cut pipe to size with a roller type tubing cutter. See Figure 8.



CUT TUBING WITH A ROLLER-TYPE TUBING CUTTER

FIGURE 8


- b - Remove any burrs with knife or reaming tool as shown in Figure 9.



REMOVE BURR WITH KNIFE OR REAMING TOOL

FIGURE 9

- c - Flare tubing with a flaring tool as illustrated in Figure 10.



INSERT TUBING TO DEPTH GAUGE AND TIGHTEN THE FLARING CONE

FIGURE 10

- d - Align parts as shown in Figure 11 and tighten using two wrenches to prevent twisting lines. Figure 12 shows cutaway of flared connections.




FIGURE 11




FIGURE 12

#### 2 - Soldered Connections

- a - Cut the pipe to size.  
b - Remove burr.  
c - Fit tubing into coupling maintaining a tight and proper clearance. See Figure 13.  
d - Use *minimum* 95-5 rated solder.  
e - Make joint using proper amount of heat to draw solder in joint.  
f - Cool and clean the joint with wet cloth.




FIGURE 13

#### B - General Guidelines

- 1 - The solar collectors can be assembled in parallel, series or series-parallel combinations. Figure 14 illustrates various sequencing arrangements. **The supply header is always positioned at the bottom side of collectors while the return header is on the top.**

**NOTE -** For residential applications, no more than two collectors should be connected in series.

TABLE 1

APPLICATION	SIZE
Single family heating and heating/cooling	1-1/4" (38 mm)
Multi-family heating and heating/cooling	3" (76 mm)
Commercial heating and heating/cooling	4" (102 mm)

2 - Table 1 lists information for sizing headers.

3 - Avoid dissimilar metals. Where copper piping connects to different piping materials, dielectric insulating couplers should be used to prevent corrosion.

ferent piping materials, dielectric insulating couplers should be used to prevent corrosion.

## TYPICAL PIPING ARRANGEMENTS










FIGURE 14

### C. Installation of Piping

1. Remove the plug from each end of solar collector.
2. The collector either pipes to another collector or into a header. The 1/2 inch copper tubing must be field provided.
  - a. Figure 15 illustrates two solar collectors piped in series. Install a flare male elbow at the bottom collector and a flare male straight connection at the top collector.
  - b. A 1/2 inch sweat to 1/2 flare fitting must be soldered into each header at 36 inch intervals. Install a flare male elbow at the collector and connect piping as shown in Figure 16. In a two row parallel application, the return and supply headers can be piped according to Figure 17 to minimize collector spacing.
3. Route the supply and return headers into the interior of building and then flash completely to waterproof the opening.




FIGURE 15




FIGURE 16




FIGURE 17

- 4 - An air bleed valve must be installed at each end of the return header for the top row of collector cells. Solder a sweat to flare fitting into the ends of return header. Connect a short length of 3/8 inch tubing to flared connection and then secure to a "B" valve with a nut and ferrule. Refer to Figure 18.




FIGURE 18

- 5 - Leak test the installation thoroughly and make any needed repairs. Insulate all outdoor piping with 3/4 inch thick foamed plastic insulation. Waterproof outdoor pipe insulation with two coats of plastic finish reinforced with glass mesh. Install per manufacturer's recommendations.

# MAINTENANCE

## VII - MAINTENANCE

1 - If the glass cover becomes dirty, clean the glass using a soft clean cloth, mild soap or detergent and clean rinse water. Alkalies can stain the glass if allowed to remain in contact too long.

**NOTE** - The collector surface temperature can burn. Handle solar collector with caution.

2 - Use rubber gloves when handling solar collector to avoid finger prints on glass.

3 - To replace the glass, remove the collector as shown in Figure 19 and dismantle according to Figure 20. To re-assemble frame, insert the glass sheets and new gaskets into side pieces making sure the glass is centered and the ends are even. Next insert the glass into the end pieces and secure with existing screws. Use

sealer compound on corner joints.

4 - To replace an absorber plate refer to following sequence and Figure 21.

a - Drain collector.

b - Remove collector frame.

c - Remove plate seal and gasket on each end of collector.


d - Disconnect flare fitting on each end of collector.

e - Remove 6 screws securing absorber and left plate from cabinet. Avoid touching coating on plate.

f - When re-assembling absorber plate, tighten screws between 10 lbs and 15 lbs torque.

5 - The ethylene glycol/water mixture should be checked once a year by your Lennox service organization for proper freeze protection and inhibitor level.

REMOVE (1) SCREWS SECURING  
FRAME TO COVER TUB




REMOVING COVER FRAME

FIGURE 19

INSERT GLASS SHEET(S)  
INTO SIDE PIECES

SEAL COMPOUND  
ON CORNER JOINTS

INSTALL SEALER STRIP AROUND  
PERIMETER OF NEW GLASS



REMOVE (1) SCREW PER END  
TO DISASSEMBLE COVER FRAME

NOTE LSC18-15 SOLAR COLLECTORS  
HAVE ONLY THE OUTER GLASS SHEET

DISASSEMBLING COVER FRAME

FIGURE 20




FIGURE 21

## PURGE UNIT    HRW-1-30

The HRW-1-30 is an air to water heat exchanger. The finned tube coil and the blower are mounted in a cabinet designed for outdoor installation. The air is drawn in through the bottom and exhausted out the top of the unit. When connected to the collector outlet line, the purge unit will lower the fluid temperature. The unit is rated at 2000 CFM and should dissipate 100,000 Btu's per hour.

### Maintenance

At the beginning of each heating or cooling season the system should be cleaned as follows:

#### A. HRW-1-30 Unit

1. Clean and inspect both sides of coil. Coil may be flushed with water hose if necessary.
2. Oil outdoor fan motor: always relubricate motor according to manufacturers lubrication instructions on each motor. If no instructions are provided, use the following as a guide.
  - a. Motors With Oiling Ports - Prelubricated for an extended period of operation. For extended bearing life, relubricate with a few drops of SAE No. 10 non-detergent oil once every two years.
  - b. Motors Without Oiling Ports - Prelubricated and sealed. No further lubrication required.
3. Visually inspect all connecting lines, joints and coils for evidence of fluid leaks.
4. Check all wiring for loose connections.
5. Check for correct voltage at unit (unit operating).

APPENDIX B

STORAGE SUBSYSTEM

SK-142050    Storage Tank Installation Drawing  
(sheet 2)





APPENDIX C

AUXILIARY ENERGY AND SPACE  
HEATING SUBSYSTEM

G11            Series Furnaces

CW3-45        Series Coils

**operation  
maintenance  
and  
installation  
instructions**

**GAS UNITS**


501,172M

12/76

Supersedes 476

**LENNOX** Industries Inc.


## PARTS ARRANGEMENT



### MODELS

G11 (Belt Drive), G11D2, G11Q3, G11Q4 AND  
G11Q5 (Multi-Speed Direct Drive) SERIES UNITS

## DIMENSIONS



TOP VIEW

### DIMENSIONS

Model No.	A	B	C	D	E
G11-82	49 in. (1245 mm)	16-1/4 in. (413 mm)	14-1/8 in. (359 mm)	14 in. (356 mm)	11 in. (279 mm)
G11-110	49 in. (1245 mm)	21-1/4 in. (540 mm)	19-1/8 in. (486 mm)	14 in. (356 mm)	16 in. (406 mm)
G11-137	53 in. (1346 mm)	26-1/4 in. (667 mm)	24-1/8 in. (613 mm)	18 in. (457 mm)	21 in. (533 mm)
G11-165	53 in. (1346 mm)	31-1/4 in. (794 mm)	29-1/8 in. (740 mm)	18 in. (457 mm)	26 in. (660 mm)
G11-200	53 in. (1346 mm)	31-1/4 in. (794 mm)	29-1/8 in. (740 mm)	18 in. (457 mm)	26 in. (660 mm)



SIDE VIEW



FRONT VIEW

\*OUTLINE OF RETURN AIR OPENING

## TABLE OF CONTENTS

START-UP - OPERATION - ADJUSTMENT	PAGE 1
ANNUAL MAINTENANCE	PAGE 2
REQUIREMENTS - APPLICATION - INSTALLATION	PAGE 4
INSTALLING BELT DRIVE BLOWER MOTOR - WIRING	PAGE 5

# START-UP AND PERFORMANCE CHECK LIST

Job Name \_\_\_\_\_ Job No. \_\_\_\_\_ Date \_\_\_\_\_  
 Job Location \_\_\_\_\_ City \_\_\_\_\_ State \_\_\_\_\_  
 Installer \_\_\_\_\_ City \_\_\_\_\_ State \_\_\_\_\_  
 Unit Model No. \_\_\_\_\_ Serial No. \_\_\_\_\_ Serviceman \_\_\_\_\_

## HEATING SECTION

Electrical Connections Tight? ☐  
 Supply Voltage \_\_\_\_\_ Blower Motor Amps \_\_\_\_\_  
 Blower Motor H.P. \_\_\_\_\_  
 Blower Motor Lubrication O.K.? ☐  
 Gas Piping Connections Tight & Leak-Tested ☐  
 Fuel Type: Natural? ☐ Propane? ☐  
 Furnace BTU Input \_\_\_\_\_

Regulator Pressure (3.5 Factory Setting, Nat. Only) \_\_\_\_\_  
 Air Shutters Properly Adjusted (Propane Only)? ☐  
 Flue Connections Tight? ☐ Proper Draft? ☐  
 Fan Control Setting (90° Factory Setting) \_\_\_\_\_  
 Limit Control Cutout \_\_\_\_\_ Temperature Rise \_\_\_\_\_  
 Filters Clean & Secure? ☐

## THERMOSTAT

## START UP - OPERATION - ADJUSTMENTS - MAINTENANCE

### I - START-UP AND OPERATION

**CAUTION:** Before proceeding with lighting instructions, make sure that the main gas valve and pilot valve at unit have been closed for at least five minutes and that room thermostat is at lowest setting.

#### A - To Light Unit

Refer to lighting instructions on A.G.A. rating plate.

#### B - Burner Operation

- 1 - After pilot is lighted, set thermostat at desired temperature.
- 2 - If during normal operation pilot goes out relight according to instructions on A.G.A. rating plate.

### II - FAILURE TO OPERATE

If unit fails to operate check the following:

- 1 - Is thermostat calling for heat?
- 2 - Is main disconnect switch closed?
- 3 - Is there a blown fuse?
- 4 - Is filter dirty or plugged? Dirty or plugged filters will cause unit to go off on limit control.
- 5 - Is gas turned on at meter?
- 6 - Is pilot lit?
- 7 - Is manual main shut off valve open?

### III - ADJUSTMENTS

#### A - Fan and Limit Control Settings

- 1 - **Limit Control** - Do not adjust from factory settings.
- 2 - **Fan Control** - Refer to Figure 1 to determine the type of control used on this unit and the correct setting.

#### B - Air Shutters (If Used)

The G11 is not factory equipped with air shutters. If air shutters are desired, the optional G11 Propane Changeover Kit must be ordered. Minor adjustments for flame lifting, burner noise, etc., may be necessary. Refer to Figure 2.

#### C - Proper Gas Flow

To check for proper gas flow to combustion chamber, determine btu input from the A.G.A. rating plate. Divide this input rating by the btu per cubic foot of available gas. Result is the number of cubic feet per hour required. Determine the flow of gas through gas meter for 2 minutes and multiply by 30 to get the hourly flow of gas to burner.




FIGURE 1




FIGURE 2

Regulator Pressure: 3.5 w/c propane (3.0 w/c natural gas)  
 Adjustment  
 Adjust belt tension so that belt is as loose as possible without allowing slippage. See Figure 3.

## F - Temperature Rise

Adjust blower speed for proper air temperature rise listed on A.G.A. rating plate. To measure this temperature rise, place plenum thermometers in warm air and return air plenums. See Figure 4. Locate thermometer in warm air plenum where thermometer will not "see" heat exchanger, thus picking up radiant heat. Turn up thermostat as high as possible to start unit. After plenum thermometers have reached their highest and steadiest readings, subtract the readings. The difference should be in the range listed on A.G.A. rating plate. If this temperature is low, decrease blower speed; if temperature is high, increase blower speed. Refer to the following for adjustment of belt or direct drive units.

1 - *Belt Drive (G11 units)* - Loosen nut on the blower motor housing and push motor up to relieve belt tension. See Figure 5. Remove belt as shown in Figure 3. Then loosen motor pulley with Allen wrench as illustrated in Figure 7 and open adjustable pulley to decrease blower speed or close to increase speed. Refer to Figure 8.

**CAUTION** - Be sure that Allen screw is lined up with flat side of motor shaft before retightening. Adjust belt tension as outlined in "E - Belt Adjustment."




FIGURE 3




FIGURE 4




FIGURE 5




FIGURE 6

2 - *Multi-Speed Direct Drive (G11D2, G11Q3, G11Q4 and G11Q5 units)* - Wire motor to higher or lower speed according to unit wiring diagram.

Repeat either of these procedures until desired setting in this range is obtained.

## IV - ANNUAL MAINTENANCE

At the beginning of each heating season, the system should be checked as follows:

### A - Blower

- 1 - Check and clean blower wheel
- 2 - Lubricate blower motor

Always relubricate motor according to the manufacturer's lubrication instructions on each motor. If no instructions are provided, use the following as a guide.

- a - *Motors Without Oiling Ports* - Prelubricated and sealed. No further lubrication required.




FIGURE 7




FIGURE 8

- b - *Belt Drive Motors With Oiling Ports* - Add a few drops of SAE No. 10 non-detergent oil yearly. Refer to Figure 9.
- c - *Direct Drive Motors With Oiling Ports* - Prelubricated for an extended period of operation. For extended bearing life, relubricate with a few drops of SAE No. 10 non-detergent oil once every two years. It may be necessary to remove blower assembly for access to oiling ports.
- 3 - Lubricate Blower Bearings (Belt Drive Models)
  - a - *Bearings With No Fittings* - These bearings are prelubricated and sealed. No further lubrication required.
  - b - *Bearings With Grease Cups* - Grease cups are packed with lubricant. Turn grease cups down about one turn yearly to relubricate bearings. Use only special lubricant for refilling grease cups, such as Gulf E or Lennox P-8-2638 (available through Lennox dealers).
- 4 - Belt Drive Blowers - Check belt for wear and proper tensions.
- 5 - If blower speed has been altered during the cooling season, the unit should be adjusted for the proper air temperature rise at the beginning of the heating season. Refer to "Temperature Rise" section in this manual.

NOTE: See page III-8 for additional information.

#### B - Filter

- 1 - Replace media in hammock type filter with 1 inch thick fiberglass of the same size. Refer to Figure 10.

#### C - Fan And Limit Control

Check fan and limit controls for proper operation and settings. For settings, refer to the "Fan and Limit" section in this manual.




FIGURE 9




FIGURE 10

#### D - Burner

- 1 - Check gas pressure (both inlet and manifold).
- 2 - Inspect burners and clean, if necessary.
- 3 - Check gas valve for proper operation.
- 4 - Adjust pilot and main burner flame.

#### E - Electrical


- 1 - Check all wiring for loose connections.
  - 2 - Check for correct voltage at unit (unit operating).
  - 3 - Check amp-draw on blower motor.
- Motor Nameplate \_\_\_\_\_ Actual \_\_\_\_\_

#### F - Flue And Chimney

- 1 - Check flue pipe, chimney and all connections for tightness and to make sure there is no blockage.
- 2 - Check unit for proper draft.



## DIMENSIONS (G11/G12 Cabinet shown with CW3-45 Coil)



## OPERATION/MAINTENANCE

### I. OPERATION

#### A. Water Coil and Auxiliary Energy Subsystem

The CW3-45 coil can be used as either a heating or cooling coil depending on application. In a heating application, solar heated water in the coil serves as the first stage heat source. When the room thermostat demands heat, solar heated water is circulated through the CW3-45 and the blower circulates air. If solar water heat is sufficient the thermostat requirement will be met. If sufficient heat is not available from the coil the thermostat will activate the second stage heat source, the auxiliary gas heat, to meet the heating demand.

The CW3-45 coil is usable alternatively with a chiller system to provide space cooling. Chilled water circulated through the coil cools the system air being drawn through the coil by the blower.

#### B. High Limit Switch

A high limit switch, located on the downstream side of the coil provides overheating protection for the subsystem blower motor. If the temperature of air discharged from the coil reaches 140°F (60°C) the switch stops the water flow through the coil. No additional heat will be available from the coil and the blower motor will not be subjected to excessive air temperature.

#### C. Condensate Drain

The condensate run-off drain (3/4 npt) needs to be connected only if the CW3-45 is used for cooling purposes. A condensate line should be run from the stub at CW3-45 coil to an open

drain. (Never connect the condensate drain line directly to a waste line.)

#### D. Drain Plugs

Two drain plugs are provided on the side of the CW3-45 coil for draining of the coil. One plug connects to the inlet water line and the other — the outlet water line.

### II. ADJUSTMENTS

#### A. Air Flow Capacities

Refer to Tables 1 and 2 for flow capacities relating external static pressure and blower air volumes for specific applications.

#### B. Fluid Pressure Drop

Table 3 is four related tables which provide information to adjust actual pressure drops involved based on temperature and % glycol solution.

#### C. Heating and Cooling Capacity

Figure 1 provides performance standards which can be traced from supply fluid temperature to air volume to cooling capacity for cooling determination. Figure 2, for heating monitoring, shows resultant Btuh heating capacity based on water flow rate, inlet water temperature, entering air temperature and blower air volume.



Table 1

BLOWER PERFORMANCE G12Q4-110V FURNACE, CW3-45 COIL AND SLAB FILTER						
External Static Pressure (In. H <sub>2</sub> O)	Air Volume @ Various Speeds					
	High		Medium		Low	
	CFM	M <sup>3</sup> /SEC	CFM	M <sup>3</sup> /SEC	CFM	M <sup>3</sup> /SEC
0.00	1446	.682	1276	.602	1089	.514
0.05	1424	.672	1261	.595	1081	.510
0.10	1396	.659	1243	.587	1070	.505
0.15	1367	.645	1222	.577	1056	.498
0.20	1337	.631	1200	.566	1040	.491
0.25	1305	.616	1175	.554	1022	.482
0.30	1271	.600	1150	.543	1002	.473
0.40	1201	.567	1095	.517	958	.452
0.50	1130	.533	1033	.487	905	.427
0.60	1055	.498	965	.455	846	.399

Table 2

BLOWER PERFORMANCE G11Q3-82V FURNACE, CW3-45 COIL AND SLAB FILTER							
External Static Pressure (In. H <sub>2</sub> O)	Air Volume (CFM) @ Various Speeds						
	High		Medium High		Medium Low		Low
	CFM	M <sup>3</sup> /SEC	CFM	M <sup>3</sup> /SEC	CFM	M <sup>3</sup> /SEC	CFM
0.00	1291	.609	1188	.559	995	.470	838
0.05	1270	.599	1166	.550	977	.461	830
0.10	1245	.588	1144	.540	960	.453	819
0.15	1219	.575	1121	.529	940	.444	807
0.20	1190	.562	1096	.517	920	.434	794
0.25	1160	.547	1070	.505	898	.424	780
0.30	1128	.532	1043	.492	875	.413	763
0.40	1060	.500	984	.464	827	.390	721
0.50	985	.465	915	.432	770	.363	666
0.60	905	.427	835	.394	705	.333	597
0.70	825	.389	750	.354	640	.302	523
0.80	740	.349	668	.315	573	.270	440

Table 3

Table A: Temperature Correction Factor to be Multiplied with Fluid Pressure Drop at 100°F (38.7°C)

Fluid: Water

Temp.		Correction Factor
°F	°C	
100	37.8	1.000
120	48.9	0.966
140	60.0	0.931
160	71.1	0.897
180	82.2	0.862
200	93.3	0.862

Table C: Correction Factor to be Multiplied With the Water Pressure Drop at 100°F (38.7°C) to get Pressure Drop for Ethylene Glycol Solution (25% by Weight)

Temp.		Correction Factor
°F	°C	
40	4.4	1.352
50	10.0	1.296
60	15.6	1.259
70	21.1	1.204
80	26.7	1.167
90	32.2	1.148
100	37.8	1.111
120	48.9	1.067
140	60.0	1.037
160	71.1	1.000
180	82.2	0.981
200	93.3	0.967

Table B: Calculated Pressure Drop Across the Residential Solar Coil (20" x 15") (508 mm x 381 mm)

Water Temp. = 100°F (38.7°C)

GPM	L/SEC	Head Loss	
		FT. H <sub>2</sub> O	mm H <sub>2</sub> O
5.0	315	3.41	1039
7.5	473	6.00	1829
10.0	631	10.27	3130
15.0	946	21.27	6483

Table D: Correction Factors to be Multiplied With the Water Pressure Drop at 100°F (38.7°C) to get Pressure Drop for Ethylene Glycol Solution (50% by weight)

Temp.		Correction Factor
°F	°C	
40	4.4	2.019
50	10.0	1.926
60	15.6	1.828
80	26.7	1.621
100	37.8	1.414
120	48.9	1.310
140	60.0	1.207
160	71.1	1.138
180	82.2	1.069
200	93.3	1.034

## III. MAINTENANCE

## A. CW3-45 Unit

1. The CW3-45 slab filter, 18" x 25" x 1" (457 x 635 x 25 mm), is a disposable type which should be replaced semi-annually or more frequently if circumstances require. Remove screw from top of filter bracket and lift filter assembly from cabinet. New filter installs with fibrous side away from auxiliary furnace unit.
2. Inspect unit for evidence of coil leaks.

3. Inspect condensate drain to insure free flow. (If used.)

4. Inspect coil. The coil must be clean and free of any obstructions.

## B. Auxiliary Energy Unit

Refer to the Operation and Maintenance book accompanying the auxiliary energy unit for its proper maintenance requirements.

**Chilled Water Capacity Correction Chart (To Be Multiplied with the Capacity of 50% Glycol Solution)**

% Glycol	Correction Factor
0	1.190
10	1.179
20	1.155
30	1.107
40	1.060
50	1.000

**Coil for residential units:**

Outer diameter of tubes = 1/2" (12.7 mm)


Size of coil = 20" x 15" (508 mm x 381 mm)

Number of fins/inch = 13

Number of rows = 3

Face area = 2.083 ft.<sup>2</sup> (1935 cm<sup>2</sup>)


Circulated fluid: 50% glycol



**COOLING CAPACITY CHART**  
Solar Coil of Residential Unit  
50% Glycol Solution Circulating Fluid

FIGURE 1

# HEATING CAPACITY CHART Solar Coil of Residential Units Water Circulating Fluid



Coil for residential units:  
 Outer diameter of tubes = 1/2" (12.7 mm)  
 Size of coil = 20" x 15" (503 mm x 381 mm)  
 Number of fins/in = 13  
 Number of rows = 3  
 Face area = 2.033 ft.<sup>2</sup> (1935 cm<sup>2</sup>)  
 Circulated fluid: water

FIGURE 2

## APPENDIX D

### INSTALLATION OF DOMESTIC HOT WATER SUBSYSTEM

40 Gal.	Water Heater (page III-15)
SK142047	Preheat Coil
70A	Tempering Valve (page III-15)

PART NO.

LTR	DESCRIPTION	DATE	APPROVED
A	STRAIGHTENED ENDS OF COIL	8/3/77	

# NOTES

- 1) The seller will inspect each coil to the requirements of this specification and for evidence of poor workmanship.
- 2) The heat coils shall be packaged in suitable protective containers that prevent damage to coil when shipped by United Parcel Service.


## Approved Source

Vender/PN  
Wolverine Tube Division  
17200 Southfield Rd.  
Allen Park, Michigan 48101  
Truffin Type W/H  
Catalog No. 66-116038-01  
With type 1 ends

## Specifications

Material - copper alloy-ASTM-B359-B111  
length - approx. 33 feet  
No. of Coils - 17  
Coil I.D. - 5 3/4" (5 1/8")  
Tubing Diam. - nom. 5/4"

ORIGINAL PAGE IS  
OF POOR QUALITY



PROVIDE PLASTIC  
CAPS TO PROTECT  
ENDS OF COIL.

TOTAL COIL LENGTH  
APPROX. 33 FT.

COIL ID APPROX. 5 3/4"

HONEYWELL INC.		ENERGY RESOURCES CENTER MINNEAPOLIS, MINN. 55413	
HOT WATER COIL		SIZE CODE IDENT NO. DRAWING NO. A 55513 5K-142047	
SOURCE CONTROL		SCALE NONE SHEET 1 OF 1	
FINISH-SEE NOTE		CONTROL A	
NEXT ASSY		USED ON	
APPLICATION			
TOLERANCES UNLESS NOTED OTHERWISE		DRAFTSMAN Donahue 8/3/77	
X + 50° FORMED ANGLES +20 -16		CHECKER	
.XX +		DEV ENGR	
.XXX +		ENGRG MGT	
MATERIAL		CONTRACT NO.	

APPENDIX E

ENERGY TRANSPORT SUBSYSTEM

Energy Transport Module ETM-1

The Energy Transport Module is a fully-assembled, pre-wired unit which provides the pumping means, control logic, and interface between sub-systems in a residential hydrolic solar heating system. It has a sturdy, rolled steel cabinet with an attractive, durable finish for installation within a building. Large, removable vented access panels are provided for system checkout and component servicing.

The main system pump is capable of 12 gpm flow of water/ethylene glycol (mixture percentage is site specific) through collector arrays of 200-550 ft<sup>2</sup>. Two smaller pumps move water through the heating and storage subsystems. Separating the freeze-protected collector loop from the heating/storage water loop is a high efficiency, water-to-water solar heat exchanger. Other hydronic components are included in the ETM, resulting in an efficient, quietly running system which requires minimal maintenance. An integrally mounted Honeywell Solar Control Panel which senses conditions throughout the system and requirements of the household (thermostat setting), provides ETM operational control.

Application

The basic ETM design (for gas furnace auxiliary heating solar systems) can be adapted for use with heat pump auxiliary by replacing the W962A Control Panel with the SCP 421111 controls. See table below.

Consult manufacturer for other application assistance.

Pressure drop within ETJ (can be increased by adjusting circuit setting):

Collector Loop (50% ethylene glycol) = 1.3 psig

Direct Heating (water) = 4.0 psig

Charge Storage (water) = 4.0 psig

Heat from Storage (water) = 1.0 psig

**Conditions:**

Pressure (pump inlet)	Operating	Maximum	Minimum
Collector Loop Storage/Heating	20-35 psig atmospheric	45 psig	--- ---
Temperature (liquid)			
Collector Loop Storage/Heating	50-210°F 50-200°F	210°F 210°F	outside ambient inside ambient

[illegible]

1

11

1

1

1

100

1

1


[illegible]

1


•

11

PLANT NO.
-----------



ETM INTERNAL WIRING SCHEMATIC  
NO SCALE



ETM INTERNAL WIRING SCHEMATIC  
NO SCALE

NOTE: ALL WIRING MUST BE DONE BY A LICENSED ELECTRICIAN. (SEE NOTE 1)


Specifications

Electrical: Power Supply ... 115 VAC, 60 Hz, 1 phase  
Minimum supply circuit conductor ... 25 amperes  
Maximum circuit overcurrent protection ... 25 amperes

Pumps: 1750 rpm, centrifugal impeller, open drip-proof motor,  
built in thermal overload protection.

Subsystem	Motor	Capacity (flow @ head)	Full Load Current	Starting Current
Collector (P <sub>1</sub> )	1/4 Hp	12 gpm @ 24 ft.	4.8 amp	12 amp
Heating (P <sub>2</sub> )	1/8 Hp	8 gpm @ 17 ft.	3.2 amp	8 amp
Storage (P <sub>3</sub> )	1/8 Hp	8 gpm @ 17 ft.	3.2 amp	8 amp

NOTE: A 1/8 Hp fan, located outside the cabinet is the Purge Unit,  
is controlled and powered by the ETM Control Panel.



Installation

- ETM may be fort-lined as indicated on shipping crate. Before moving unit when uncrated, the two small lower panels and pressure relief holding pan should be removed. Holding pan will slide from under the ETM after the pressure relief line is removed from pan. ETM can be carefully fort-lined after interference between lift and cabinet underside is checked out. IMPORTANT: Removable panels and Control Panel will be damaged if uncrated unit is hand-trucked on its side or top.
- ETM size is 26" x 32" x 45" and weighs 550 lbs. (excluding weight is 600 lbs). Position on level surface (adjustable legs provided) near storage and space heating subsystems. Consult manufacturer when ETM is to be located above the electric array or storage tank.
- Orient ETM with its back towards wall. Heat ventilation clearance is required around the unit, two feet minimum in front and at the sides. Adequate clearance for service access through front, top and side panels shall be provided. Panels are removed with a sharp upward pull on the recessed tabs.

Plumbing Connections

- Five 1 1/4 inch sweat copper unions are provided for system piping connections (see drawing). DO NOT APPLY HEAT to ETM piping inlets. Sweat solder tubing to the removable union pieces BEFORE connecting to ETM inlets.
- External plumbing shall conform to applicable codes. Isolation/Shutdown valves and air bleeds shall be installed, as necessary.

Electrical Connections

- ETM is internally pre-wired.
- External wiring must conform to National Electrical Code and local codes. Line voltage supply to ETM shall be from properly sized branch circuit and overcurrent protection device. Use wire suitable for at least 90°C (194°F). Wiring diagrams are shown on this drawing and on SK-142054, Rev. A (Control Subsystem).
- Three 1/2 inch flexible conduits are provided to the Control Panel terminals for 115 VAC electrical service and the line voltage control wiring. Low voltage sensor wires may be run from the upper right side of the Control Panel through the end hole provided in cabinet top. (Additional openings are provided for the SDAS, with wiring diagrams shown on SK-142055, Rev. B.)

UNRELEASED DRAWING  
NOT SUBJECT TO  
E.C.O. CONTROL

TOLERANCES UNLESS NOTED OTHERWISE		CONTRACT NO.		HONEYWELL INC.		ENERGY RESOURCES CENTER MINNEAPOLIS, MINN. 55413	
±	0.001	±	0.001	NAME: FAMILY RESIDENCE		DATE: JAN 1970	
±	0.002	±	0.002	PROJECT: ENERGY TRANSPORT SUBSYSTEM		SHEET 2 OF 2	
±	0.005	±	0.005	SITE: CODE 1001 NO. 1		C 55513	
±	0.010	±	0.010	DRAWN BY: J. J. J.		-42053	
±	0.020	±	0.020	CHECKED BY: J. J. J.		SCALE: 1" = 1'-0"	
±	0.050	±	0.050	APPROVED BY: J. J. J.		CONTROL	
±	0.100	±	0.100	TEST ASST: J. J. J.		APPLICATION: J. J. J.	
±	0.200	±	0.200	FINISH-SEE NOTE		USE ON: J. J. J.	





# ETM-1. Energy Transport Replacement Parts

<u>No.</u>	<u>Item</u>	<u>Manufacturer</u>	<u>Type/Part</u>	<u>Quantity</u>
1	Pump 1	Bell & Gossett	60-11S, 1 1/4AA, 1/4hp	1
2	Pump 2 & 3	Bell & Gossett	PR-1 1/4, 1/6 hp	2
3	Heat Exchanger	Honeywell	SK-140184	1
4	Expansion Tank	Amtrol	30, Diaphragm	1
5	Air Separator	Amtrol	444-1 1/4	1
6	Air Vent	Amtrol	690	1
7	Air Bleed	Hammond	1/8 Radiator	2
8	Relief Valve	Bell & Gossett	480-45 psi	1
9	Control Valve, Dual Diverting	Honeywell	V4331-A1003, (115 VAC)	1
10	Circuit Setter Balancing Valve	Bell & Gossett	CB-1 1/4	3
11	SDA Sensor Wells	Mueller	Bronze, 1 1/4	4
12	Lift Check Valve	Bell & Gossett	BA- 1 1/4	1
13	Swing Check Valve	Stockham	B-309-1 1/4	2
14	Drain/Fill Valve	Hammond	710-3/4	1
15	Ball Valve	Hammond	Sweat-1 1/4	1
16	Strainer	Strong	S-1 1/4	1
17	Low Level Indicator w/Lamp	F.W. Murphy	20-PC, 50 psi, 24 VAC	1
18	Solar Control Panel	Honeywell	W968A	1

NOTE: See page IV-2, IV-3 and IV-4 for photograph on ETM system

**This page has been removed because of copyright information. For information on the PD Boosters and Series "60" In-Line Centrifugal Pumps, contact Bell and Gossett, 8200 N. Austin Ave., Morton Grove, Ill. 60053.**



ITEM#	ITEM	MANUFACTURER	TYPE / PART NO	QTY
1	SHELL	GEORGE BIRD, INC.	SK-14217B	1
2	HEAT EXCHANGE COIL	HONEYWELL BIC	SK-14217A	1
3	WELDED 90° ELBOW 1/2\"	SEE DATA SUPPLY CO.	407-5-1/2	2
4	WELDED 90° ELBOW 3/8\"	SEE DATA SUPPLY CO.	407-5-3/8	2
5	WELDED 90° ELBOW 1/2\"	SEE DATA SUPPLY CO.	407-5-1/2	2

TOLERANCES UNLESS NOTED OTHERWISE		DRAFTSMAN'S SYMBOLS		HONEYWELL INC.		ENERGY RESOURCES CENTER MINNEAPOLIS, MINN 55413	
±	±	±	±	CHECKER	DATE	SIZE	CODE IDENT NO.
±	±	±	±	DEV ENGR	10-25-77	B	55513
±	±	±	±	ENGR		SCALE	1/4\"
±	±	±	±	CONTRACT NO.			

HEAT EXCHANGER FOR SOLAR HEATING SYSTEM		DRAWING NO. SK-140184	
NEXT ASBY		USED ON	
APPLICATION		FINISH-SEE NOTE	
CONTROL		SHEET 1 OF 3	

# Selection Data

EX-TROL Sizing Table									SYSTEM CONTENT IN GALLONS											
BOILER NET OUTPUT IN 1000's CF BTU/HR	TYPE OF RADIATION								Average System Temp. °F	SYSTEM CONTENT IN GALLONS										
	Finned Tube Baseboard or Radiant Panel		Convectors or Unit Heaters		Radiators—Cast Iron		Baseboard Cast Iron			Extrol Model 15		Extrol Model 30		Extrol Model 60		Extrol Model 90		Extrol Model SX-30		
	SW	CS	SW	CS	SW	CS	SW	CS		SW	CS	SW	CS	SW	CS	SW	CS	SW	CS	
25	15	15	15	15	15	15	15	15	15	100		133		305		500		734		1102
50	15	15	15	15	15	30	15	30	110		101		232		380		557		835	
75	15	30	15	30	30	30	30	60	120		80		193		300		440		660	
100	15	30	15	30	30	60	30	60	130		65		149		244		358		537	
125	15	30	30	60	30	60	30	90	140		54		125		204		298		447	
150	30	30	30	60	30	90	60	90	150	62	47	141	106	230	174	338	256	473	304	
175	30	60	30	60	60	SX-30	60	SX-30	160	58	40	134	92	219	150	321	220	449	330	
200	30	60	60	60	60	SX-30	60	SX-30	170	55	34	127	78	208	128	306	187	428	209	
250	30	60	60	90	60	SX-30	90	SX-40	180	53	30	121	68	198	111	291	163	407	245	
300	60	90	60	SX-30	90	SX-30	90	SX-40	190	51	26	116	60	190	98	278	144	389	216	
350	60	SX-30	60	SX-30	90	SX-40	SX-30	SX-60	200	49	23	111	52	182	86	266	126	372	109	
400	60	SX-30	90	SX-40	SX-30	SX-40	SX-30	SX-60	210	47	21	106	48	174	78	256	114	358	171	
									220	45	19	102	43	167	71	246	103	344	155	
									230	43	17	98	39	161	64	236	94	330	141	
									240	41	16	95	35	155	58	228	86	316	129	

SW indicates Summer—Winter hook up where boiler is used for heating, and supplying domestic hot water. Minimum boiler water temp. of 150 F. is required.  
 CS indicates cold start hook up where boiler is used for heating only. MAXIMUM WORKING PRESSURE 75 PSI — OPERATING TEMP. 40°-240°F  
 #15 EX-TROL = 109 FILL-TROL #30 EX-TROL = 110 FILL-TROL #60 EX-TROL = 111 FILL-TROL #90 EX-TROL = 112 FILL-TROL

## Dimensional Data

### EX-TROL TANKS


Model No.	Diameter Inches	Length Inches	Shipping Wt. Lbs.
15	8	11½	5
30	11	14	9
60	11	23	14
90	15	23	23



### EX-TROL COMBINATION PACKAGES

Model No.	INCLUDES			Shipping Wt. Lbs.
	EXTROL	Purger *	Vent	
1500	15	1"		9
3000	30	or	#700	13
6000	60	1¼"		19

\*Specify type and size required



### EX-TROL WITH FILL-TROL

Model No.	Diameter Inches	Length Inches	Shipping Wt. Lbs.
109	8	14½	6
110	11	17	10
111	11	26	15
112	15	23½	24



### FILL-TROL COMBINATION PACKAGE

Model No.	INCLUDES			Shipping Wt. Lbs.
	FILL-TROL	Purger *	Vent	
109-P	109	1" or 1¼"		11
110-P	110	1" or 1¼"	#700	14
111-P	111	1¼"		18

\*Specify type and size required



DISTRIBUTED BY



AMTROL INC.

1408 DIVISION ROAD • WEST WARWICK, R. I. 02893




Fig. 2 Extrol tank construction

**The EX-TROL Tank is a modern, pressurized diaphragm-type expansion tank for all hot water heating systems.**

It is of welded steel construction; compact and neat in appearance. A rugged, flexible diaphragm of a material specially compounded for long life in hydronic service is the heart of the EX-TROL tank.

This diaphragm separates system water from the (standard 12-lb.) air charge, assuring a permanent air cushion. Because the diaphragm permits the tank to be pressurized, the EX-TROL tank can be smaller than conventional units.

**The EX-TROL Tank may be installed into a tee or any other suitable tapping anywhere on a hot water heating system.**

It may also be remotely located and piped to convenient point on the system.

An ideal EX-TROL installation is to screw it into the bottom of an American Air Purger. A single 1/2" nipple serves as both pipe connection and mounting.




Fig. 3 Extrol tank operation

**The EX-TROL Tank controls expansion of heating system water. See Figure 3**

- A. When the system is first filled to the setting of the automatic fill valve, no water enters the EX-TROL Tank because of the charge pressure behind the diaphragm.
- B. When the system comes up to temperature, the EX TROL tank receives the expanded volume of water.
- C. When the boiler water temperature rises to its maximum, the EX-TROL diaphragm simply flexes against the air cushion.

**The American Air Purger continuously separates air from heating system water.**

It is a one-piece cast iron chamber with two passages through which boiler water flows. Internal contours and baffles are designed for low flow resistance characteristics and efficient separation of the air from the water.

The Air Purger should be installed horizontally on the main as close to the boiler as possible. It must be installed so that water flows through it in the direction indicated by the arrow.




Fig. 4 System view illustrating contin-

All models have tappings for installation of #700 Float Vents to provide complete continuous purging and venting. Spare tappings are also provided for easy mounting of an EX-TROL for expansion control or FILL-TROL for combining automatic fill valve and expansion control.

**EX-TROL system venting**

After initial purging and venting of air from the system more air will be released from the water as it is heated. The American #700 Float Vent is an advanced type valve designed for venting all hydronic heating and cooling systems. It has a unique construction which insures: Fastest Venting — Positive shut off — Venting through the complete pressure range (0-45) — Long continuous operation — Trouble free performance — No spitting or unsightly stains from leaking. No separate air chamber is required.

Even with Air Purger and Float Vent installed on the main or mains, it is recommended the American #700 Float Vent to be installed on each return at the elbow that drops to the circulator.

While seldom required, it is also recommended that manual (key or coin type) air vents be installed at high points on the radiation.

**This page has been removed because of copyright information. For information on the Installation Instructions Ex-Trol Expansion Tanks contact Amtrol, 1400 Division Road, West Warwick, R. I. 02893.**


This page has been removed because of copyright information. For information on the Relief Valves-ASME Valves and Fittings contact Bell and Gossett, 8200 N. Austin Ave., Morton Grove Ill. 60053.

# Honeywell

THE Y534A DUAL DIVERTING VALVE ASSEMBLY CONSISTS OF TWO VALVE BODIES WHICH ARE SWEATED TOGETHER AND TWO POWERHEADS WHICH CONTROL EACH VALVE BODY SEPARATELY. WHEN ASSEMBLED, THE Y534A OFFERS FLOW CHARACTERISTICS WHICH ARE COMPATIBLE WITH SOLAR ENERGY SYSTEMS.

- ☐ Available for line or low voltage applications (specify when ordering).
- ☐ Assembly provides a flow capacity of 14 Cv [12 kv].
- ☐ Sweat copper end connections may be installed without disassembling the valve.
- ☐ Manual opener for valve operation on power failure. Valve returns to automatic position when power is restored.
- ☐ Complete powerhead may be removed without breaking the line connections.
- ☐ Motor actuator may be replaced without removing the valve body or draining the system.

## DUAL DIVERTING VALVES



Y534A

R.L.  
9-77 (.05)



# SPECIFICATIONS

## IMPORTANT

THE SPECIFICATIONS GIVEN IN THIS PUBLICATION DO NOT INCLUDE NORMAL MANUFACTURING TOLERANCES. THEREFORE, THIS UNIT MAY NOT MATCH THE LISTED SPECIFICATIONS EXACTLY. ALSO, THIS PRODUCT IS TESTED AND CALIBRATED UNDER CLOSELY CONTROLLED CONDITIONS, AND SOME MINOR DIFFERENCES IN PERFORMANCE CAN BE EXPECTED IF THOSE CONDITIONS ARE CHANGED.

### MODEL:

Y534A—2-position dual diverting valve. The two powerheads must be assembled to the two valve bodies which are shipped sweated together. Available for line or low voltage applications.

### TEMPERATURE AND FLOW RATINGS:

Capacity Rating—14 Cv [12 kv].  
Maximum Closeoff Pressure—10 psi [69 kPa].  
Static Pressure Rating—125 psi [862 kPa].  
Maximum Fluid Temperature—  
Line voltage model—200 F [93 C].  
Low voltage model—240 F [115 C].  
Maximum Ambient Temperature—125 F [52 C].

### ELECTRICAL RATINGS:

Line voltage models—  
0.16 amps at 120V ac, 60 Hz.  
0.08 amps at 220/240V ac, 50 Hz.  
Low voltage model—  
0.64 amps at 24V ac, 50/60 Hz.

WIRING PROVISIONS: 18 in. [457.2 mm] leadwires and 1/2 in. conduit openings.

LINE FITTINGS: 1-1/4 in. sweat (1-3/8 in. O.D.).

DE-ENERGIZED POSITION: Port A normally closed.

TIMING: Diverts flow in 30 seconds.

MANUAL OPENER: Allows valve to be opened in case of power failure. Valve returns to automatic position when power is restored.

DIMENSIONS: See Fig. 1.

UNDERWRITERS LABORATORIES INC. LISTING APPLIED FOR.

### REPLACEMENT PARTS:

O-ring Part No. 802344.

Powerhead—

Line voltage model—Part No. 130441ARG.

Low voltage model—Part No. 130441ARA.

DETERMINATION OF WATER FLOW CHARACTERISTICS: The pressure drop in psi [kPa], equivalent feet [metres] of pipe, or feet of water [kPa] may be determined by calculating the flow rate, referring to Fig. 2, and using the following procedures.

Pressure drop in psi [kPa]

1. Locate the flow rate at the bottom of the graph in Fig. 2.
2. Draw a line upward from the flow rate until it intersects the curve on the graph.
3. Draw a line from the intersection to the left-hand edge of the graph and read the pressure drop in psi [kPa].

Pressure drop in equivalent feet [metres] of pipe—

1. Locate the flow rate at the bottom of the graph in Fig. 2.
2. Draw a line vertically to the top of the graph. Read the pressure drop in equivalent feet [metres] of pipe on the 3/4 in. pipe scale.

Pressure drop in feet of water [kPa]—

1. Locate the flow rate at the bottom of the graph in Fig. 2.
2. Draw a line upward from the flow rate until it intersects the curve on the graph.
3. Draw a line from the intersection to the right-hand edge of the graph and read the pressure drop in feet of water [kPa].

continued on page 3

## MODERNIZATION

WHEN PURCHASING REPLACEMENT AND MODERNIZATION PRODUCTS FROM YOUR TRADELINE WHOLESALE OR YOUR DISTRIBUTOR, REFER TO THE TRADELINE CATALOG OR PRICE SHEETS FOR COMPLETE ORDERING NUMBER, OR SPECIFY—

1. Order number (specify line voltage or low voltage model).
2. Replacement part, if required.

IF YOU HAVE ADDITIONAL QUESTIONS, NEED FURTHER INFORMATION, OR WOULD LIKE TO COMMENT ON OUR PRODUCTS OR SERVICES, PLEASE WRITE OR PHONE:

1. YOUR LOCAL HONEYWELL RESIDENTIAL DIVISION SALES OFFICE (CHECK WHITE PAGES OF PHONE DIRECTORY).

2. RESIDENTIAL DIVISION CUSTOMER SERVICE

HONEYWELL INC., 1885 DOUGLAS DRIVE NORTH  
MINNEAPOLIS, MINNESOTA 55422 (612) 642-7500

(IN CANADA—HONEYWELL CONTROLS LIMITED, 740 ELLESMERE ROAD, SCARBOROUGH, ONTARIO M1P 2V9)  
INTERNATIONAL SALES AND SERVICE OFFICES IN ALL PRINCIPAL CITIES OF THE WORLD.




FIG. 1-Y534A DIMENSIONS IN INCHES [MILLIMETRES IN BRACKETS].




FIG. 2-FLOW CHARACTERISTICS OF Y534A DUAL DIVERTING VALVES.

# INSTALLATION

## CAUTION

1. Installer must be a trained, experienced service technician.
2. Disconnect power supply before connecting wiring to prevent electrical shock and equipment damage.
3. Always conduct a thorough checkout when installation is complete.

## ASSEMBLY

Each powerhead controls each valve body separately. To assemble a powerhead to a valve body, place an O-ring in the circular slot on the top of the valve body (Fig. 3). Assemble the powerhead to the valve body by placing the manual opening lever on the powerhead in the MAN. OPEN position.

Align the powerhead by fitting the hex head screw on the bottom of the powerhead into the hole on the top of the valve body. The guide pins and the positioning pin in the powerhead should fit the holes in the valve body. Tighten securely and repeat this procedure for the other powerhead and valve body.




FIG. 3—POWERHEAD MUST BE ALIGNED SO THAT THE GUIDE PINS AND THE POSITIONING PIN IN THE POWERHEAD FIT THE HOLES IN THE VALVE BODY.

## MOUNTING




FIG. 4—MOUNTING POSITIONS.

The valve may be mounted in any position on a vertical line. If valve is mounted horizontally, the powerhead must be even with or above the center line of the piping. Make sure that enough room is provided above the powerhead to remove the cover for servicing. See Fig. 4.

The 3 fittings or ports of the dual diverting valves are labeled on the bottom of the valve body castings. Port A is connected to the purge coil piping and is closed when the valve is de-energized. Port B is connected to the system bypass and is open when the valve is de-energized. Port AB is the inlet and is open at all times. See Fig. 4.

#### SWEAT COPPER MODELS

1. Use new, properly reamed pipe, free from dents or corrosion.
2. Place valve onto the pipe. Set the manual opener lever to MAN. OPEN before applying heat. This will protect the plug inside the valve by removing it from the heat.
3. Sweat joints keeping the outer surface free from solder. DO NOT use silver solder because of the high melting temperatures required.

#### TO INSTALL REPLACEMENT POWERHEAD

##### IMPORTANT

Installation of new powerhead does not require the removal of the valve body from the pipe line. It is, however, necessary to drain the water from the system before beginning the installation.

1. Disconnect the valve from the electrical power source and remove the conduit connections if fitted.
2. Place the manual opening lever on the old powerhead in the MAN. OPEN position.
3. With the cover off, remove the 4 screws securing the powerhead to the valve body. Remove the old O-ring from the valve body.

4. Place the new O-ring in the circular slot on the top of the valve body.

5. Install the new powerhead—

—Place the manual opening lever on the new powerhead in the MAN. OPEN position.

—Align the powerhead by fitting the hex head screw on bottom of powerhead into the hole on top of valve body (see Fig. 3).

6. Reconnect electrical connections.

Inspect the powerhead installation and the valve body to insure that all connections and adjustments have been correctly made. Adjust the thermostat or controller connected to the valve so the valve runs through its cycle. Make sure the valve runs smoothly and positively from closed to open to closed again.

#### WIRING

All wiring must agree with local codes and ordinances. See Fig. 5 for a typical wiring hookup.




FIG. 5—TYPICAL WIRING FOR Y534 DUAL DIVERTING VALVES.

## OPERATION AND CHECKOUT

### CAUTION

On 24 volt systems, never jumper the valve coil terminals, even temporarily. This may burn out the heat anticipator in the thermostat.

#### OPERATION

##### AUTOMATIC OPERATION

When the valve is energized, port B, the bypass, closes and port A opens. Port A closes by integral spring return when the valve is de-energized.

## MANUAL OPERATION

The motorized dual diverting valves (two with each assembly) can be opened manually by lifting the manual opener lever over the stop and pushing slowly and firmly to the MAN, OPEN position. The stop permits the valve to be locked in the open position. The valve will return to automatic position when the valve is energized.

## CHECKOUT

1. Lower the set point of the high limit controller below the temperature of the collector fluid.
2. Observe that port A of the valve should be open and port B of the valve should be closed.
3. Raise the set point of the high limit controller above the collector fluid temperature.
4. Observe that port A of the valve should close and port B of the valve should be open.

## SERVICE

This valve should be serviced by a trained, experienced service technician.

1. If the valve is leaking, check to see if the O-rings need to be replaced.
2. If the gear train is damaged or the motor is burned out, it is necessary to replace the entire powerhead assembly. See INSTALLATION.

NOTE: Honeywell zone valves are designed and tested for silent operation in properly designed and installed systems. However, water noises may occur as a result of excessive water velocity or piping noises may occur in high temperature (over 212 F [100 C]) systems with insufficient water pressure.

This page has been removed because of copyright information. For information on the Flo-Control Valves contact Bell and Gossett, 8200 N. Austin Ave, Morton Grove, Ill. 60053.

Additional pages have been removed because of copyright information. For information on the Circuit Setter Balance Valves contact Bell and Gossett, 8200 N. Austin Ave., Morton Grove, Ill. 60053.

**CLASS 125  
BRONZE  
SWING  
CHECK  
VALVES**

**FIGS:  
B-309  
B-319**


**SCREWED CAP**

SEE PAGE 36 FOR PRESSURE-TEMPERATURE RATING.

**SERVICE FEATURES**

Recommended for prevention of backflow in general services. • Solder ends recommended for non-flammable liquids or gases with Types K, L, and M copper tubing.

**BRONZE VALVES**



**B-319**

NO.	DESCRIPTION	MATERIAL	ASTM SPEC.
1	BODY	BRONZE	B-62
2	CAP	BRONZE	B-62
3	PISTON	BRASS (1/4-1/2)	B-16
		BRONZE (1/4-3)	B-62
4	DISC NUT	BRASS	B-16
5	HINGE	BRONZE	B-62
6	HINGE PIN	BRASS	B-16
* 7	SIDE PLUG	BRASS	B-16

\*Not Shown



**†B-309, SOLDER ENDS**

SIZE	WGT.	B	G*	M
3/8	.4	1 13/32	1 1/16	2 1/16
1/2	.5	1 19/32	1 1/16	2 1/16
3/4	.9	1 59/64	1 3/4	3 1/4
1	1.4	2 1/4	2	3 13/16
1 1/4	2.0	2 19/32	2 5/16	4 1/4
1 1/2	3.4	3 1/32	2 11/16	4 7/8
2	4.8	3 1/2	3 1/16	6

†Saturated Steam Pressure for Solder End Valves Should Not Exceed 15 PSI.

\*Piping Make-Up Dimension




**B-319, THREADED**

SIZE	WGT.	B	M
1/4	.5	1 13/32	2 1/16
3/8	.5	1 13/32	2 1/16
1/2	.7	1 19/32	2 1/16
3/4	1.1	1 29/32	2 13/16
1	1.7	2 1/4	3 3/16
1 1/4	2.7	2 19/32	3 3/4
1 1/2	3.9	3 1/32	4 3/16
2	6.1	3 1/2	5 1/8
2 1/2	11	4 3/32	6 3/16
3	17	4 13/16	7 1/8

# STRONG

## Semi-Steel Y-Type Strainers

High Tensile Semi-Steel Body ASTM A126 Class B.



STYLE S



STYLE SG

**SIZES** 1/4" thru 3"

### OPERATING PRESSURES AND TEMPERATURES:

Steam	250 psi at 406°F.
Water, Oil, Gas	400 psi at 150°F.

### STANDARD SCREENS:

Service	Connections & Sizes	Screen Openings	Screen Material
Liquid	Screwed 1/4" thru 2" 2 1/2" thru 3"	20 mesh 045 perf.	Stainless Steel
Steam	Screwed 1/4" thru 2" 2 1/2" thru 3"	20 mesh 045 perf.	Stainless Steel

### BLOW-OFF OUTLETS:

N.P.T. tapped in sizes specified on dimension table. Not normally furnished plugged.

### CONSTRUCTION:

Constructed of high tensile ASTM A126 Class B semi-steel with blow-off connections and easily removable cylindrical screens. A tapered seat allows the screen to be self aligning and assures a perfect fit. 2 1/2" and 3" sizes have a flanged blow off cover. Strainer with gasketed blow off plug and straight thread available in 1/4" thru 2" size. 18-8 stainless steel screens.

### MILITARY SPECIFICATIONS:

Model with gasketed blow off plug conforms to MIL S-16293E, Type 1, Style Y, Class 250 when equipped with a brass plug in the blow off connection. State service when ordering.

### PACKAGING:

Screwed strainers in sizes thru 2" can be packaged in multiple unit cartons for certain industries. Write for specific information.

### DIMENSIONS:

Size	A	B	Size Blowoff NPT	Ship Weight lbs.	Screen Area In <sup>2</sup>
1/4	2 5/8	1 3/4	1/4	1 3/4	3.0
3/8	2 5/8	1 3/4	1/4	1 3/4	3.0
1/2	3 13/32	2 3/8	3/8	1 3/4	5.4
3/4	4	2 3/4	3/8	2 1/2	7.4
1	4 5/8	3 1/4	1/2	4	12.7
1 1/4	5 5/8	3 1/2	3/4	6 1/4	18.1
1 1/2	6 1/16	4	3/4	8 1/4	25.3
2	7 1/2	5	1	14 1/2	39.2
2 1/2	9	6 3/4	1 1/4	22 1/2	49.3
3	10	7 7/8	1 1/4	35 1/4	64.8



## Pressure Monitoring SWICHGAGES®

These rugged, pressure monitoring SWICHGAGES® are designed for any critical pressure control function.

Recommended specifically for safety shutdown on oil field, irrigation and industrial engines or as alarm systems on construction equipment, trucks and marine engines.

### Offers constant visual indication.

These instruments offer a constant visual indication of the condition of your lubrication system, or any other vital pressures on your equipment. Their precision construction meets the specifications of those applications which require a higher degree of accuracy and dependability than is available in most standard 2" diameter instruments.

A SWICHGAGE® performs the job of two ordinary instruments (a gauge and a switch), thus this instrument greatly reduces necessary inventory and installation time.

In addition, each instrument is available with a lockout feature to hold the indicating pointer away from the shut-down contact for start-up. When the oil pressure reaches the normal operating level, the lockout is automatically disengaged.

### Durability

The entire working mechanism of the SWICHGAGE® is assembled completely independent from the case and therefore is not affected by case damage or abuse in normal operation. Also, all moving parts are machined to close tolerance and many parts are interlocking to retard damage from vibration or shock. The unique design of the diaphragm and bearing plate prevent normal overpressures from harming the accuracy of the instrument.

### Model 20-P-7

This model features a "tamperproof" front adjustable contact which can be set with an Allen-Head wrench (also available with standard screwdriver adjustment — specify), and a pushbutton for lockout.

### Model 20-P-27

A side mounted micrometer — adjustment type contact screw and convenient side lockout are features of this model. It also has a stand-off ring which holds the instrument away from the panel to give access to the contact adjustment and lockout pushbutton.

### Warranty

Like all Murphy instruments, Pressure SWICHGAGES® carry a full one year warranty against defective materials and workmanship. Consult the Murphy Service department for product repairs.


**CONTACT RATINGS:** 2 amp. @ 30 v.a.c., 2 amp. @ 30 v.d.c.

**SHIPPING WEIGHTS:** 20-P-7 7.8 Oz.—20-P-27 13 Oz.

Model 20-P  
20-P-27


- An accurate indicating gauge & safety switch
- Features adjustable front/side switch contact

Patent no. 3375718



ORIGINAL PAGE IS  
OF POOR QUALITY

20-P-27




**COMPATIBILITY:** These simple one-wire to ground SWICHGAGES® are compatible with all Murphymatic® Controls and can be used with any Murphy "Nerve Center."

- To interrupt ignition circuit — Section 25
- To start and stop engines — Section 40
- To start and stop elec. tric. motors — Section 45
- For fuel shut-off — Section 55

## SPECIFICATIONS

- A. PORT:** Machined from brass bar stock. It is accurately threaded for connection to the pressure line. Together with the diaphragm, it forms the pressure chamber.
- B. PULSATION DAMPENER:** A restricting orifice designed to minimize hydraulic shock within the pressure transmitting fluid, preventing undesirable pointer chatter. It is accessible for cleaning, or removal.
- C. DIAPHRAGM:** Beryllium copper, procured to very close physical and metallurgical specs. The material is die formed and close control heat treated to insure consistent reliability. Each pressure range is designed to operate well below its maximum capability in order to maintain long life and consistent reliability.
- D. MOUNTING PLATE:** Machined from brass bar stock. The mounting plate performs threefold function. First, together with the port, clamps back diaphragm in position. Second, it provides a strong back stop for the diaphragm, thereby preventing damage should the gauge experience high over pressure. Lastly, it also provides a stable platform upon which to mount the pointer post and the mechanism which amplifies the diaphragm movement into pointer travel.
- E. RECAL SCREW:** Provides a measure of adjustment to compensate for wear or disturbances that may result if gauge is operated in unusually severe environment.
- F. BRIDGE PLATE:** Tempered nickel silver provides corrosion resistance and dimensional stability.
- G. SPRING ANCHOR & POINTER ZERO STOP:** Stainless Steel.
- H. POINTER:** Tempered nickel silver for strength and corrosion resistance. It is mounted on a machined brass post. The return spring is helically wound of spring temper stainless steel.
- J. CRANK ARM:** K-Monel. Senses and amplifies diaphragm movement and transmits it to the pointer.
- K. BEARING PLATE:** Beryllium copper. Provides fulcrum for crank arm. It is free to lift off the bridge plate should the pointer be restrained by stationary contacts, etc. It returns to original position when strain is relieved.
- L. JOINT AND SEAL:** The carefully designed peripheral edges of the diaphragm and port, and the radiused channel in the mounting plate provide consistently accurate parts alignment. The annular solder channel provides optimum conditions for producing a combination structural joint, and seal, with maximum integrity.



DESCRIPTION	MODEL NO.	RANGES
2" Dia. Pressure SWITCHGAGE* Front Contact — No Lockout	20-P	0-30, 0-75, 0-100 p.s.i. 0-150, 0-200, 0-300 p.s.i.
20-P w/Front Lockout	20-P-7	All Ranges
2" Dia. Pressure SWITCHGAGE Side Contact — No Lockout	20-P-75	0-30, 0-75, 0-100 p.s.i. 0-200, 0-300 p.s.i.
20-P-75 w/side Lockout	20-P-27	All Ranges
2" Dia. Vacuum SWITCHGAGE* Hi-Lo Contacts — No Lockout	20-V-2 20-V-3	0-20 inches Vacuum 0-30 inches Vacuum

### OPTIONAL EXTRAS

Additional Contact (except 20-V)	add-HL	All Ranges
"C" Contacts — 2 wire ungrounded (Not avail. w/Lockout)		
Circuit (rated 1 amp @ 125V A.C.)	add-C	All Ranges
Illumination slots. (Front contact only)	add-1	All Ranges

Also available in explosion proof case — see bulletin No. EX-5828. Available on front contact models only.

# **murphy**



"DEVELOPING SOLUTIONS TO YOUR MONITORING & CONTROL PROBLEMS"  
Write us today for a no-obligation recommendation

P.O. BOX 45248 • TULSA, OKLAHOMA • 74145 • 918 (627-3550)

**FRANK W. murphy**  
MFR., INC.

FRANK W. MURPHY MANUFACTURING, INC.  
MURPHY ELECTRONIC DIVISION  
MURPHY SAFETY SWITCH CO. CALIFORNIA  
FRANK W. MURPHY LIMITED


P.O. Box 45248, Tulsa, Oklahoma 74145 918 627-3550  
P.O. Box 36638, Houston, Texas 77036 713 666-4393  
P.O. Box 788, Palmdale, California 93550 805 947-7108  
178 High Street, Teddington, Middlesex, England 01 977-0193



RANGES AVAILABLE	CONTACT SETTING
■ 0-15 PSI	3 PSI
■ 0-30 "	7 "
■ 0-50 "	10 "
■ 0-75 "	15 "
■ 0-100 "	20 "
▲ 0-150 "	30 "
▲ 0-200 "	50 "
▲ 0-300 "	75 "

\*STANDARD

WIRING DIAGRAM



RATING - 1 AMP 120VAC - 2 AMP 30V AC/DC  
 WIRE - (1) RED, (1) WHITE, 12" X 18 GA  
 CONTACT SETTING - SEE ABOVE  
 TYPE ADJUSTMENT - NYLON KNOB  
 DIAL - WHITE ON BLACK  
 CLAMP - LONG P/N 05 05-789  
 MOUNTING HOLE - 2-1/16 DIA  
 MAX PANEL THICKNESS - 1/4  
 PORT - BRASS 1/8-27 NPT  
 MAX PRESSURE - (□=300PSI) (▲=500PSI)  
 PULSATION DAMPENER - BUILT IN (REMOVABLE)  
 BEZEL - STAINLESS STEEL  
 CASE - STEEL, CAD & IRIDITE  
 CRYSTAL - LEXAN  
 STUDS - 10-24 NC

CALIBRATION CONFORMS TO USAS CLASS B - FIRST & LAST 1/3 OF SCALE  
 ±3%, MIDDLE OF SCALE ±2%

NOTE: NO CUSTOMER REPLACABLE PARTS

NO.	REVISION
FRANK W. MURPHY MFR. INC.	
MURPHY SAFETY SWITCH	
TULSA, OKLAHOMA	
DRN BY <i>W. J. R. S.</i>	APPD BY <i>W. J. R. S.</i>
DATE <i>11-1-72</i>	CHKD BY <i>W. J. R. S.</i>
MODEL <b>20PC</b>	
DWG. NO.	SWITCHAGE
<b>05 02-108</b>	



# Honeywell

W968A SOLAR CONTROL PANEL CONTAINS A DIFFERENTIAL TEMPERATURE CONTROLLER, TRANSFORMER, AND SWITCHING RELAYS WHICH CONTROL EITHER A 3-PUMP, 2-VALVE OR A 2-PUMP, 4-VALVE SOLAR HYDRONIC HEATING SYSTEM.

□ Manual AUTO-STOP-ON switches aid in installation and provide emergency control of the heating system.

□ Available with lights that indicate the operating mode of the system when manual switches are in the AUTO position.

□ Plug-in type switching relays are easily replaceable.




□ Ample terminal connections make wiring hookup convenient.

□ Collector set point potentiometer adjustable from 75 to 125 F [24 to 52 C].

□ Complies with the requirements of the HUD Interim Performance Criteria for Solar Heating.

ORIGINAL PAGE IS  
OF POOR QUALITY

R.L.  
10-77 (.07)



# SPECIFICATIONS

## IMPORTANT

THE SPECIFICATIONS GIVEN IN THIS PUBLICATION DO NOT INCLUDE NORMAL MANUFACTURING TOLERANCES. THEREFORE, THIS UNIT MAY NOT MATCH THE LISTED SPECIFICATIONS EXACTLY. ALSO, THIS PRODUCT IS TESTED AND CALIBRATED UNDER CLOSELY CONTROLLED CONDITIONS, AND SOME MINOR DIFFERENCES IN PERFORMANCE CAN BE EXPECTED IF THOSE CONDITIONS ARE CHANGED.

**MODEL:** W968A Solar Control Panel contains a differential temperature controller, transformer, switching relays, manual switches and field wiring terminals for use in controlling either a 3-pump, 2-valve or a 2-pump, 4-valve solar hydronic system.

### ELECTRICAL RATINGS:

Input and Output Voltage and Frequency 120V ac, 60 Hz.

Load Relay Contacts—

1 N.O. Pole—12 AFL/60 ALR at 120V ac.

1 N.C. Pole—125 VA at 120V ac.

Maximum Power Consumption—25 watts.

### DIFFERENTIAL TEMPERATURE CONTROLLER:

Adjustable ON and OFF differentials from minus 10 to plus 40 F [minus 5.6 to plus 22.2 C]. Factory set for 18 F [10 C] temperature difference ON and 3 F [1.7 C] temperature difference OFF. Plug-in resistors vary settings.

### COLLECTOR SET POINT POTENTIOMETER RANGE:

75 to 125 F [24 to 52 C]. Indicates minimum temperature at which energy is used from the collector.

### SHIPPING TEMPERATURE RANGE:

Minus 30 to plus 150 F [minus 34 to plus 56 C].

### AMBIENT TEMPERATURE RANGE:

Plus 30 to plus 115 F [minus 1 to plus 46 C].

**MOUNTING:** 4 holes in back of case.

**WIRING CONNECTIONS:** Pressure-type terminals.

**DIMENSIONS:** See Fig. 1.

**UNDERWRITERS LABORATORIES INC. LISTING**  
APPLIED FOR.

### ADDITIONAL EQUIPMENT REQUIRED:

**L6031B Solar Aquastat Controller.** High limit controller that prevents excessive temperatures in the collector system is combined with tankstat which controls first stage heating from storage.

**Y534A Dual Diverting Valve.** Provides flow characteristics which are compatible with solar energy systems.

**C773 Electronic Temperature Sensor (2).** Used with R7412 Differential Temperature Controller.

C773A is a single sensor for storage tank or solar collector mounting.

C773B contains a double sensor for storage tank or solar collector mounting.

C773C contains a single sensor with a flattened end and mounting hole for solar collectors.

C773D is a double sensor with flattened end and mounting hole for collector installation.

**Immersion Well.** For mounting C773 Electronic Temperature Sensor in storage tank. See Fig. 2 and Table 1.

**T872 Thermostat.** Provides low voltage control of multi-stage heating and cooling systems.

**Q672 Subbase.** Required for operation of T872 Thermostat.

(continued on page 3)

## ORDERING INFORMATION

WHEN PURCHASING REPLACEMENT AND MODERNIZATION PRODUCTS FROM YOUR TRADELINE WHOLESALE OR YOUR DISTRIBUTOR, REFER TO THE TRADELINE CATALOG OR PRICE SHEETS FOR COMPLETE ORDERING NUMBER, OR SPECIFY—

1. Order number.
2. Additional equipment required and optional specifications.
3. Replacement parts, if needed (see back cover).

IF YOU HAVE ADDITIONAL QUESTIONS, NEED FURTHER INFORMATION, OR WOULD LIKE TO COMMENT ON OUR PRODUCTS OR SERVICES, PLEASE WRITE OR PHONE:

1. YOUR LOCAL HONEYWELL RESIDENTIAL DIVISION SALES OFFICE (CHECK WHITE PAGES OF PHONE DIRECTORY).
2. RESIDENTIAL DIVISION CUSTOMER SERVICE  
HONEYWELL INC., 1885 DOUGLAS DRIVE NORTH  
MINNEAPOLIS, MINNESOTA 55422 (612) 542-7500

(IN CANADA—HONEYWELL CONTROLS LIMITED, 740 ELLESMERE ROAD, SCARBOROUGH, ONTARIO M1P 2V9)  
INTERNATIONAL SALES AND SERVICE OFFICES IN ALL PRINCIPAL CITIES OF THE WORLD.




FIG. 1-W968A CASE DIMENSIONS IN INCHES [MILLIMETRES IN BRACKETS].

TABLE 1-IMMERSION WELL TABLE

IMMERSION LENGTH		INSULATION LENGTH		SELECT WELL MATERIAL AND ORDER NUMBER BELOW			
in.	mm	in.	mm	COPPER		STAINLESS STEEL	
				1/2 NPT	3/4 NPT	1/2 NPT	3/4 NPT
3-3/8	85.7	1-1/2	38.1	121731A	121371B	121371E	121371F
3-3/8	85.7	1-1/2	38.1	—	121371K <sup>a</sup>	—	—
3-3/8	85.7	3	76.2	121371L	121371M	—	—
3-3/8	85.7	4	101.6	122554A <sup>a</sup>	122555A <sup>a</sup>	—	—
5-3/8	136.5	4	101.6	122554B <sup>a</sup>	122555B <sup>a</sup>	—	—
0	152.4	1-1/4	31.8	112020BB	—	—	—

<sup>a</sup>Has plastic sleeve on insertion well.




FIG. 2—TANK SENSOR INSERTED INTO IMMERSION WELL.

## OPTIONAL SPECIFICATIONS:

111892F Remote Sensor Wiring Compartment. For wiring C773 Electronic Temperature Sensor to storage tank.

## INSTALLATION

1. Installer must be a trained, experienced service technician.
2. Disconnect power supply before connecting wiring.
3. Conduct thorough checkout when installation is complete.
4. Shield the sensor against possible overtemperature conditions prior to system operation.
5. On unlazed collectors mount the sensor with leadwires down to keep sensor from accumulating water.
6. Wire additions to the leadwires must be capable of withstanding a temperature of 450 F [232 C].

### MOUNTING CONTROL CABINET

The panel should be mounted on a convenient wall. Make certain that the desired location does not exceed the ambient temperature rating of 30 to 115 F [minus 1 to plus 46 C].

Remove the two chassis screws which are located on each side of the cabinet. Allow the chassis to rest at the bottom of the cabinet.

Fasten the cabinet to the wall using the two mounting holes at the top of the cabinet and two mounting screws (not provided). Replace the chassis and chassis screws.

Secure the cabinet to the wall using the two mounting holes at the bottom of the cabinet and two mounting screws (not provided).

### MOUNTING ELECTRONIC TEMPERATURE SENSORS

Follow the system manufacturer's recommendations for the best location of the sensor. Each sensor should be located so that it experiences the most useful temperature for proper system operation.

Mount C773A,B as a storage tank sensor using an immersion well as follows:

1. Drain system fluid to a point below the sensor fitting.
2. Screw the well into the threaded fitting. Use an approved pipe dope or Teflon tape to seal the threads.
3. Refill system and check for leaks.
4. Insert the sensor probe into the immersion well until it bottoms. See Fig. 2.
5. Attach retainer clamp over groove on well spud. Fit wires in clamp groove and lightly tighten screw. Do not overtighten. If a remote sensor wiring compartment is used, secure the sensor with the spring clip instead of the retainer clamp.

Install C773A,B as a collector sensor using the mounting clip provided and No. 8 screw. Mount C773C,D as a collector sensor using the flattened end with mounting hole and a No. 8 or 10 screw. On unlazed collectors mount the sensor with leadwires down to keep sensor from accumulating water.

Temperatures in excess of 450 F [232 C] will damage the sensor. Shield the sensor against possible overtemperature conditions prior to system operation. Do not mount collector sensor to collector fluid channels.

### WIRING

All wiring must comply with applicable codes and ordinances. The panel has four 1/2 inch conduit knockouts and two 3/4 inch conduit knockouts on the bottom of the case. It has one 7/8 inch [22.2 mm] opening for conduit on the right side of the case.

Pressure terminal connections are used for the wiring hookup. Refer to Fig. 3 for a wiring diagram.

If the amount of electronic temperature sensor cable used exceeds 100 feet [30.5 m], use No. 14 wire and grounded metallic conduit or shielded cable. Connect the shield to ground at the panel. Grounded metallic conduit and shielded cable (such as Belden 8762 or equivalent) minimize possible radio frequency signal interference. Wire additions to the leadwires must be capable of withstanding maximum collector stagnation temperatures if installed within the collector.





# ADJUSTMENTS AND CHECKOUT

## ADJUSTMENTS

### AUTO-STOP ON SWITCHES

For normal operation, the panel switches should remain in the AUTO position. The ON and STOP positions of these switches are useful during installation and calibration of the heating system. They may also be used for manually operating the system if the differential temperature controller fails.

### COLLECTOR SET POINT POTENTIOMETER

The collector set point potentiometer establishes the minimum fluid temperature which the heating system will accept from the collector for direct heating of the house. Set the collector set point potentiometer to the desired setting; 90 F [32 C] is the recommended setting. This set point may be readjusted in accordance with individual preferences. Lower settings will generally result in the solar system carrying a higher percentage of the total heating load.

## DIFFERENTIAL TEMPERATURE SELECTION

The control settings may be adjusted by changing the ON and OFF plug-in resistors and sensor connections (Fig. 4). The standard R7412 is factory-set for pull-in at 18 F [10 C] temperature difference with a 4750 ohm ON resistor. Dropout is set for 3 F [1.7 C] temperature difference with a 9760 ohm OFF resistor.

To change the setting refer to Table 3 to select the resistors needed. See Fig. 5 to prepare resistor for installation. Remove the old ON resistor and plug in the replacement. Repeat for the OFF resistor. Be sure the correct resistor is inserted in the proper position. Use 1/8 watt, 1 percent resistors, available locally.

## CHECKOUT

One by one, set the AUTO-STOP-ON switches in the ON position to check that the valves and pumps have been wired correctly and that they are operating properly.

TABLE 2--W968A WIRING CHECKOUT

OPERATING MODE	DIS-CONNECT	ADJUST	ENERGIZE	SYSTEM RESPONSE (E = ENERGIZED, DE = DE-ENERGIZED)							W968A PANEL LIGHTS
				PUMP 1	PUMP 2	PUMP 3*	VALVE 1	VALVE 2	GAS VALVE	FAN	
Collector Heat Heating House	HIGH Temperature Sensor on Differential Temperature Controller		W <sub>1</sub> and B on Space Thermostat	E	E	DE	DE	DE	DE	E	Collector Heat Heating House
Collector Heat Heating House and Auxiliary Heat Heating House	HIGH Temperature Sensor on Differential Temperature Controller		W <sub>1</sub> , W <sub>2</sub> , and B on Space Thermostat	E	E	DE	DE	DE	E	E	Collector Heat Heating House, Auxiliary Heat Heating House
Storage Heat Heating House	LOW Temperature Sensor on Differential Temperature Controller	Dual Aquastat Tank Sensor Set Point at Minimum	W <sub>1</sub> and B on Space Thermostat	DE	DE	E	DE	DE	DE	E	Storage Heat Heating House
Storage Heat Heating House and Auxiliary Heat Heating House	LOW Temperature Sensor on Differential Temperature Controller	Dual Aquastat Tank Sensor Set Point at Minimum	W <sub>1</sub> , W <sub>2</sub> , and B on Space Thermostat	DE	DE	E	DE	DE	E	E	Storage Heat Heating House, Auxiliary Heat Heating House
Auxiliary Heat Heating House	LOW Temperature Sensor on Differential Temperature Controller	Dual Aquastat Tank Sensor Set Point at Maximum	W <sub>1</sub> and B on Space Thermostat	DE	DE	DE	DE	DE	E	E	Auxiliary Heat Heating House
Collector Heat to Storage Tank	HIGH Temperature Sensor on Differential Temperature Controller			E	E	DE	DE	E	DE	DE	Collector Heat to Storage Tank
Cooling			Y and O on Space Thermostat							E	
Ventilation			G on Space Thermostat							E	

\*May be used for valve 3 and 4.

Next, set all W968A AUTO-STOP-ON switches in the AUTO position. The indicator lights function correctly only if the panel switches are in the AUTO position. Check differential temperature controller operation as follows:

1. Disconnect wire to high temperature terminal C (see Fig. 3). Relay should pull in.




FIG. 4—ADJUSTING THE DIFFERENTIAL TEMPERATURE CONTROL.




FIG. 5—PLUG-IN RESISTOR PREPARATION. DIMENSIONS IN INCHES [MILLIMETRES IN BRACKETS].

2. Reconnect sensor wire to high temperature terminal C and disconnect wire to low temperature terminal A. Relay should drop out. Reconnect sensor wire.

Check out the wiring of the W968A to a 3-pump, 2-valve solar heating system according to the procedures in Table 2.

TABLE 3—DIFFERENTIAL TEMPERATURE CONTROL

FOR TEMP. DIFFERENCE OF:		USE RESISTANCES BELOW FOR BOTH ON AND OFF RESISTORS (IN OHMS)
F	C	
0	0	11500
1	.6	11000
2	1.1	10500
3	1.7	9760
4	2.2	9310
5	2.8	8870
6	3.3	8250
7	3.9	7870
8	4.4	7500
9	5.0	7150
10	5.6	6810
12	6.7	6340
14	7.8	5760
16	8.9	5230
18	10.0	4750
20	11	4320
25 <sup>a</sup>	14 <sup>a</sup>	3480
30	17	2430
35	19	1740
40	22	1210
45	25	750
50	28	330

<sup>a</sup>Do not exceed 25 F [14 C] for OFF setting.

## OPERATION

To trace the relay operation of the W968A, refer to the internal wiring of the panel given in Fig. 3. The following information describes how the W968A operates within a 3-pump, 2-valve solar heating system (Fig. 6). Fig. 7 depicts a 2-pump, 4-valve solar heating system.

### COLLECTOR HEAT TO STORAGE TANK

Collector heat begins to be transferred to the storage tank whenever the collector plate temperature is 18 F warmer than the storage tank temperature and there is no call for heat from the space thermostat. Pumps 1 and 2 conduct heated water to the storage tank through valve 2. Pumps 1 and 2 are controlled by the differential temperature controller within the W968A and they will run as long as the collector temperature is at least 3 F [1.7 C] hotter than the storage tank temperature.

### COLLECTOR HEAT HEATING THE HOUSE

On a call for heat from the space thermostat, 2 control relays direct valve 2 to allow flow of heated water to the solar coil.

If the collector plate temperature is greater than 90 F [32 C] (adjustable), then pump 1 will operate through the appropriate relays (Fig. 3). Pump 2 operates only when pump 1 is operating and they are both controlled by the differential temperature controller.

When the call for heat is satisfied, valve 2 diverts flow to the storage tank.

### STORAGE HEAT HEATING HOUSE

Heating from storage is accomplished on a call for heat when sufficient energy is not present on the collector plate, but energy is available from storage.

On a call for heat, pump 3 brings heat from storage if the storage temperature at the top of the tank is greater than 90 F [32 C] (adjustable). Pumps 2 and 3 can not operate at the same time.

#### AUXILIARY HEAT HEATING HOUSE

On a call for heat, if none is available from the collector panels or the storage tank, relay contacts energize the gas furnace.




FIG. 6—3-PUMP, 2-VALVE HYDRONIC SOLAR HEATING SYSTEM WHICH USES THE W968A SOLAR CONTROL PANEL.

Also, if the "collector heat heating the house" or the "storage heat heating the house" cannot satisfy a call for heat from the thermostat, relay contacts will start the gas furnace. Collector or storage heating may continue during auxiliary heating.

If heat is available from the collectors or storage tank, auxiliary heating operates when the thermostat senses a space temperature 2 F [1.1 C] below the set point.




FIG. 7—2-PUMP, 4-VALVE HYDRONIC SOLAR HEATING SYSTEM WHICH USES THE W968A SOLAR CONTROL PANEL.

## TROUBLESHOOTING

When the W968A Solar Control Panel does not appear to be operating properly, the following steps may be taken to troubleshoot system problems:

1. Determine the temperatures at the differential temperature controller and solar aquastat controller sensors. For the differential temperature controller, use a high resistance ohmmeter to measure the resistance across terminals E-F (storage sensor) and F-G (solar panel sensor) located in the W968A panel (Fig. 3). Refer to Fig. 8 to convert the resistance measurement to a temperature reading.

Determine the temperature which the solar aquastat is experiencing by adjusting the set points with a screwdriver and listening for the relays to operate. Aquastat may not cause a relay to operate when the relay in the aquastat changes state. Observe temperature scale for temperature reading.

2. Read the OPERATION section to determine which mode(s) the heating system should be operating in based on the sensor temperatures and the space temperature.

3. Check the location of the sensors for the differential temperature controller and solar aquastat controller. Make certain that each sensor is located so as to measure the most appropriate temperature for proper

system operation. If the sensors are not providing correct temperature readings, change the location and mount properly.

4. Check that the solar aquastat is operating properly by adjusting the control points of the tankstat and high limit controller and listening for the relays to operate. Reset to the proper temperature.

5. Check that the differential temperature controller relay is operating properly by disconnecting the wire to high temperature terminal C (Fig. 3). Relay should pull in. Reconnect sensor wire to high temperature terminal C and disconnect wire to low temperature terminal A. Relay should drop out. Reconnect sensor wire to low temperature terminal A.

6. Check that the four W968A switching relays are operating properly by plugging in a new R8222 dpdt relay in place of the low voltage relays in the panel and a new R4222 dpdt relay in place of the line voltage relay in the panel. If the substituted relay causes the system to change modes, the original panel relay is faulty. Do not install a low voltage relay in a line voltage receptacle.

7. Check system operation on a mode by mode basis using the procedures of Table 2.





FIG. 8—CONVERTING SENSOR RESISTANCE INTO DEGREES F [C].

#### REPLACEMENT PARTS LIST

LOCATION	DESCRIPTION	ORDER NUMBER
1	Differential Temp. Controller	R7412A1012
2	Switching Relay (2)	R8222H1007
3	Switching Relay (1)	R8222S1000
4	Switching Relay (1)	R4222V1044
5	Transformer	AT40A1121
6	Manual AUTO-STOP-ON Switch	113700
7	Indicator Lamp (2)	192061
8	Indicator Lamp (2)	118543A



## APPENDIX F

### CONTROL SUBSYSTEM

#### Parts List

<u>Item</u>	<u>Quantity</u>	<u>Description</u>	<u>Honeywell Model No.</u>	<u>Component Data</u>
	1	Solar Control Panel*	W968A1009	Appendix E
T <sub>st</sub>	1	Aquastat Controller	L6008C1065	Appendix F
T <sub>cd</sub>	1	Aquastat Controller	L4008B1013	Appendix F
	1	Multistage Thermostat	T872C1004	Appendix F
	1	Thermostat Subbase	Q672B1004	Appendix F
V <sub>1</sub>	1	Motorized Valve	V4331A1003	Appendix A & E
V <sub>2</sub>	1	Motorized Valve*	V4331A1003	Appendix A & E
	2	Immersion Well	122555B	
	1	Case Assembly	112892F	
T <sub>p</sub> & T <sub>sb</sub>	2	Sensor	C773B1005	
	1	Collector Sensor Shield	SK-142067	

SK142054 (sheet 3) - Control System Wiring Diagram

\*For reference only, premounted on transport module SK142053.

PART NO.	

# SOLAR HEATING SYSTEM - SINGLE FAMILY RESIDENCE CONTROL SUBSYSTEM


## 1.0 GENERAL CONDITIONS

- 1.1 Scope: The Control Subsystem will include all controls necessary for operation of the solar heating system.
- 1.2 Required Work: The Mechanical Contractor will install and wire all controls as shown on control subsystem wiring schematic. This will include all line voltage wiring required.
- 1.3 Procurement of Control Devices: Control devices listed in Material List, (i.e., Solar Control Panel, Aquastat, Thermostat, etc.) will be provided by Honeywell EMC. This will include the control device only. All materials necessary for a complete installation will be provided by the Mechanical Contractor.

## 2.0 BASIC MATERIALS AND METHODS

- 2.1 Basic Materials:
  - 2.1.1 Control sensor wiring (T<sub>1</sub> and T<sub>2</sub>): Wiring from solar control panel to control sensors T<sub>1</sub> and T<sub>2</sub> shall be run in conduit to outdoor areas and shall be Bolden #8702 or equal.
  - 2.1.2 Power and control wiring: All line and low voltage wiring shall be of size and type required by applicable codes, and supplied by Mechanical Contractor.
  - 2.1.3 Other Materials: All other materials required for a complete installation of the Control Subsystem shall be supplied by the Mechanical Contractor.
- 2.2 Basic Methods:
  - 2.2.1 Control device installation methods: As per applicable details and/or instructions included with equipment.
  - 2.2.2 Electrical wiring: As per all applicable codes.

(INCLUDES WORK BY  
PLUMBING CONTRACTOR  
E.P.A. COMPANY)



TOLERANCES UNLESS NOTED OTHERWISE		DRAFTSMAN		SHEET		ENERGY RESOURCES CENTER	
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE	DATE	DATE	DATE	DATE
AS SHOWN	PER	DATE	DATE				




# Honeywell

THESE THERMOSTATS AND SUBBASES PROVIDE LOW VOLTAGE CONTROL OF MULTISTAGE HEATING AND COOLING SYSTEMS INCLUDING HEAT PUMP SYSTEMS.

- ☐ T872 Thermostat requires a Q672 Subbase.
- ☐ Q672 Subbase provides system and fan switching, wiring terminals, and mounting base for T872 Thermostat.
- ☐ T872 Thermostat has silent dust-free mercury switches operated by coiled bimetal elements.
- ☐ Q672 Subbase mounts on wall or horizontal outlet box.
- ☐ Adapter plate available for mounting Q672 Subbase on vertical outlet box.
- ☐ Heat anticipator(s) are adjustable or fixed; cooling anticipator(s) are fixed.
- ☐ External levers and scale for temperature setting located on top of thermostat case.
- ☐ Cover thermometer on most T872 Thermostat models.
- ☐ Locking cover and locking lever screws available for T872 Thermostats.
- ☐ Plastic thermostat guards available for T872 Thermostats.
- ☐ Key lock cover with tumbler lock available for T872 Thermostats.

N.J.  
REV. 11-76 (.259)

## MULTISTAGE THERMOSTAT AND SUBBASE



T872A-H,  
M.Q.R.T  
Q672A-G.K.L.N

ORIGINAL PAGE IS  
OF POOR QUALITY

# SPECIFICATIONS

## SUPER TRADELINE / TRADELINE MODELS

Super Tradeline controls offer features not available on Tradeline or standard models, and are designed to replace a wide range of Honeywell and competitive controls.

Tradeline models are selected and packaged to provide ease of stocking, ease of handling, and maximum replacement value. Specifications of Super Tradeline and Tradeline controls are the same as those of standard models except as noted below.

### SUPER TRADELINE MODELS

#### T872 THERMOSTAT

T872D1300 Thermostat. Provides 2 stages of heating and 2 stages of cooling.

##### SUPER TRADELINE FEATURES:

- Includes 130821 Adapter Plate Assembly for mounting T872-Q672 on a vertical outlet box.
- Super Tradeline package with cross reference label and special instruction sheet.

- Super Tradeline thermostat is compatible with all Tradeline switching subbases.
- Super Tradeline model supplied with locking lever and locking cover accessories.
- Includes adjustable temperature locking stops.
- Super Tradeline model with 4 switches replaces T872A-F Tradeline or standard models.

### TRADELINE MODELS

#### T872 THERMOSTAT

T872 Thermostat Tradeline models provide 1- or 2-stage heat and/or cool operation as shown in the chart below.

T872	A	B	C	D	E	F
HEATING STAGES	1	1	2	2	—	2
COOLING STAGES	1	2	1	2	2	—

##### TRADELINE FEATURES:

- Tradeline package with cross reference label and special instruction sheet.
- T872A model with adjustable temperature locking stops.
- All Tradeline T872 models are supplied with locking lever and locking cover accessories.
- All Tradeline thermostat models are compatible with all Tradeline switching subbase models.

#### Q672 SUBBASE

Q672 switching subbases provide system and fan switching as listed.

##### TRADELINE FEATURE:

- Tradeline package with cross reference label and special instruction sheet.

Q672	SYSTEM	FAN
A	Heat-Auto-Cool	Auto-On
B	Heat-Off-Cool	Auto-On
E	Off-Heat-Auto-Cool	Auto-On

(continued on page 3)

## ORDERING INFORMATION

WHEN PURCHASING REPLACEMENT AND MODERNIZATION PRODUCTS FROM YOUR TRADELINE WHOLESALER OR YOUR DISTRIBUTOR, REFER TO THE TRADELINE CATALOG OR PRICE SHEETS FOR COMPLETE ORDERING NUMBER, OR SPECIFY—

1. Order number:
  - T872 Thermostat, Tradeline, or Super Tradeline, if desired.
  - Q672 Subbase, Tradeline, if desired.
2. Optional T872 specifications, as required.
3. Optional Q672 specifications, if desired.
4. Accessories, as required.
5. Optional temperature scale range, if desired.

IF YOU HAVE ADDITIONAL QUESTIONS, NEED FURTHER INFORMATION, OR WOULD LIKE TO COMMENT ON OUR PRODUCTS OR SERVICES, PLEASE WRITE OR PHONE:

1. YOUR LOCAL HONEYWELL RESIDENTIAL DIVISION SALES OFFICE (CHECK WHITE PAGES OF PHONE DIRECTORY).
2. RESIDENTIAL DIVISION CUSTOMER SERVICE  
HONEYWELL INC., 1885 DOUGLAS DRIVE NORTH  
MINNEAPOLIS, MINNESOTA 55422 (612) 542-7500  
(IN CANADA—HONEYWELL CONTROLS LIMITED, 740 ELLESMERE ROAD, SCARBOROUGH, ONTARIO M1P 2V9)  
INTERNATIONAL SALES AND SERVICE OFFICES IN ALL PRINCIPAL CITIES OF THE WORLD.



## STANDARD MODELS

### T872 THERMOSTATS

MODELS: See Table 1.

ELECTRICAL RATING: 24 to 30V ac.

SWITCHING: Coiled bimetal elements operate mercury switches.

TEMPERATURE ADJUSTMENT: Heating and cooling setting levers, with common scale located on top of thermostat base. Common lever for heating and cooling on T872R, 1 cooling lever on T872E, and 1 heating lever on T872F.

TEMPERATURE SCALE RANGE: 44 to 86 F [7 to 30 C], standard; optional ranges available.

THERMOMETER RANGE: 52 to 98 F [11 to 36 C].

CHANGEOVER DIFFERENTIAL: 3 F [2 C] minimum between heating and cooling. Levers may be set apart for greater separation.

#### INTERSTAGE DIFFERENTIAL:

Standard Models--mechanical differential is 1 F [0.6 C] between heating or cooling stages; operating differential is approximately 1.9 F [1 C] between stages in heating or cooling.

Special Models--have other differential requirements.

FINISH: Silver bronze.

MOUNTING MEANS: T872 Thermostat mounts on Q672 Subbase. Subbase mounts horizontally on wall or outlet box. Mounts on vertical outlet box with optional 130821A Adapter Plate Assembly.




FIG. 1--DIMENSIONS OF T872 THERMOSTAT MOUNTED ON Q672 SUBBASE.

#### OPTIONAL SPECIFICATIONS (T872 only):

1. Temperature Scale Ranges: 40-75 F [5-24 C] and 75-90 F [24-32 C] with stop; 44-68 F [7-20 C] heating, 80-86 F [27-30 C] cooling; 6-29 C (43-85 F) Celsius scale.

2. Nonadjustable factory added stop. Limits heating set point to 75 F [24 C] maximum, cooling set point to 75 F [24 C] minimum.

3. Celsius scale; 6 to 29 C (43 to 85 F).

4. Customer personalization.

5. Locking cover and locking lever (see Accessories).

6. Thermostat cover less thermometer.

7. Adjustable locking temperature stops.

8. Voltage heat anticipation--first or second stage heat or both (Table I).

9. Fast cycling on heating stage(s) for electric heat applications.

#### ACCESSORIES:

1. Locking cover and locking lever assembly--Part No. 133627AA with thermometer, 133627AC without thermometer. Includes cover, two screws and Allen wrench for locking cover, plus two No. 4 X 1/4 inch (6.4 millimetre) panhead screws to lock set point levers.

2. Universal thermostat guard--

--Part No. 133722A, clear plastic cover and beige plastic mounting base.

--Part No. 133722D, clear plastic cover and clear plastic "ring type" mounting base. Thermostat need not be removed from wall to install guard.

--Part No. 133723A, beige plastic cover and beige plastic mounting base.

--Part No. 133723B, beige plastic cover and clear plastic "ring type" mounting base.

3. Key lock cover with tumbler lock--mounts on T872 base and covers thermostat set levers and subbase switches. Two keys included. Should not be used with 130821A or B adapter plate.

● 190103C blank face, internal thermometer.

● 190903D external thermometer.




FIG. 2--T872 THERMOSTAT ACCESSORIES.

TABLE 1 T872 THERMOSTAT SPECIFICATIONS

MODELS AND OPTIONS	RE- PLACES	APPLICATION	SYSTEM STAGES			ANTICIPATION			
			HEAT	COOL	OTHER	HTG (ADJ)		COOLING (FIXED)	
						STAGE 1	STAGE 2	STAGE 1	STAGE 2
T872A--Standard and Tradeline --75 F scaleplate stop w/locking cover --Adj anticipator set .4 amp --Adjustable locking tem- perature stops (T/L) --75 F scaleplate stop w/locking cover, no thermometer (for DODI).	T870A	STD	1	1	--	0.1-1.2A	--	0-1.5A	--
		STD	1	1	--	0.1-1.2A	--	0-1.5A	--
		STD	1	1	--	0.1-1.2A	--	0-1.5A	--
		STD	1	1	--	0.1-1.2A	--	0-1.5A	--
		STD	1	1	--	0.1-1.2A	--	0-1.5A	--
T872B--Standard and Tradeline --Adj anticipator set .4 amp	T870B	STD	1	2	--	0.1-1.2A	--	0-1.2A	0-1.0A
		STD	1	2	--	0.1-1.2A	--	0-1.2A	0-1.0A
T872C--Standard and Tradeline --75 F scaleplate stop w/locking cover --Fast cycling --75 F scaleplate stop w/locking cover, no thermometer (for DODI). --12 F differential be- tween H1 and H2 stages (T872C1368)	T870C	STD	2	1	--	0.1-1.2A	0.1-1.2A	0-1.5A	--
		STD	2	1	--	0.1-1.2A	0.1-1.2A	0-1.5A	--
		Elec Heat	2	1	--	0.12-0.6A	0.12-0.6A	0-1.5A	--
		STD	2		--	0.1-1.2A	0.1-1.2A	0.1-1.5A	--
		STD	2	1	--	0.1-1.2A	0.1-1.2A	0.1-1.5A	--
T872D--Standard and Tradeline --Adjustable locking tem- perature stops (T/L)	T870D	STD	2	2	--	0.1-1.2A	0.1-1.2A	0-1.2A	0-1.0A
		STD	2	2	--	0.1-1.2A	0.1-1.2A	0-1.2A	0-1.0A
T872E--Standard and Tradeline	T870E	2-Stage Cool	--	2	--	--	--	0-1.2A	0-1.0A
T872F--Standard and Tradeline --Locking cover --Fast cycling	T870F	2-Stage Heat	2	--	--	0.1-1.2A	0.1-1.2A	--	--
		2-Stage Heat	2	--	--	0.1-1.2A	0.1-1.2A	--	--
		Elec Heat	2	--	--	0.12-0.6A	0.12-0.6A	--	--
T872G--Heat pump, cool changeover, with fast cycling	T870G	Ht Pump	2	1	1 <sup>a</sup>	0-1.0A <sup>b</sup>	0.1-1.2A <sup>h</sup>	--	0-1.0A
T872H--Use with Q672C	New	Ht Pump	1	1	1 <sup>a</sup>	0-0.8A <sup>b</sup>	--	--	0-0.8A
T872M--Motel heating-cooling application (requires manual changeover remote switching)	T870M	Remote Panel Switching	1	1	1 <sup>c</sup>	0.1-1.2A	--	0-1.5A	--
T872N--Heat pump, heat changeover	New	Ht Pump	2	1	1 <sup>i</sup>	0.1-1.2A	--	0-1.0A	--
T872Q--Night setback heating	T870Q	STD	1 <sup>f</sup>	--	--	0.1-1.2A	--	--	--
T872R--Standard	T870R	Ht Pump <sup>g</sup>	2	1	--	0-1.5A <sup>b</sup>	--	0-1.5A	--
T872S--Heat pump, heat changeover	New	Ht Pump	2	1	--	0.1-1.2A	0.1-1.2A	0-1.0A	--
T872T--Representative model	New	STD--Vent Stage	1	2	1 <sup>f</sup>	0.1-1.2A	--	0-1.0A	0-1.0A

<sup>a</sup> Changeover stage operates with cooling.<sup>b</sup> Fixed voltage type anticipation.<sup>c</sup> Nonadjustable heating changeover stage set at 60 F (16 C).<sup>d</sup> Manual changeover stage--use Q672B,L subbase.<sup>e</sup> Provides night setback used with standard T872 and timer operated remote switching.<sup>f</sup> Ventilating stage (See Fig. 31.)<sup>g</sup> Second stage. Also available with fast cycle anticipation (0.12-0.6A) with voltage heater, or without anticipation.<sup>h</sup> Changeover stage operates with heating.<sup>i</sup> Department of Defense.

## Q672 SUBBASES

**MODELS:** See table in form 70-6208.

### ELECTRICAL RATING:

Switch contacts—2.5 amp at 30V ac (7.5 amp inrush).

Malfunction light (optional)—24 to 30V ac.

**SWITCHES:** Two snap-acting switches (one switch, Q672G and K, no switches on Q672D), operated by levers. Switch position is shown on scaleplate.

**MOUNTING:** Designed to mount horizontally on an outlet box or wall. Adapter plate assembly available for mounting on a vertical outlet box (see Accessories).

**FINISH:** Silver bronze.

**DIMENSIONS** in inches [millimetres]: 3-9/16 [90] high; 5-5/8 [142] wide; 5/16 [8] deep (Fig. 1).

### OPTIONAL SPECIFICATIONS (Q672 only):

1. Malfunction indicator light with replaceable bulb available on all models. Indicator can show FILTER, CHECK, EM. HT. (emergency heat), or LK. OUT (lockout). Specify indication when ordering.

2. External jumper between R<sub>C</sub>-R<sub>H</sub> for common heating-cooling transformer. Jumper is field removable.

3. System switching marked HEAT-OFF/RESET-COOL for systems requiring impedance relay reset. Available on Q672B only.

4. "G" terminal isolated on heating to provide fan relay operation from external low voltage fan switch (Q672B only).

5. Auto fan operation on both heat and cool (Q672B only).

6. Common R terminal for heating/cooling.

7. External O and B terminal jumper (Q672G only).

8. Jumper between W2-X2 terminals (Q672F only).

9. Jumper between E-X2 terminals (Q672F only).

10. Changeover in cool or heat made for heat pumps.

11. Auto fan in EM. HT. for heat pumps.

### ACCESSORIES:

1. Adapter plate assembly, Part No. 130821A, for mounting on vertical outlet box. Assembly includes adapter ring and cover plate.

2. Adapter plate assembly, Part No. 130821B, for covering old thermostat marks on wall. Cover plate only.

3. Indicator replacement bulb, Part No. 129571.

4. Field addable indicator light assembly, Part No. 135734A. Assembly includes retainer plate, 2 self-tapping screws, light bulb with 2-3/4 inch [70 millimetres] leadwires with spade terminals and lenses. The Q672 lenses indicate FILTER, CHECK or EM. HT.

## INSTALLATION

### CAUTION

1. Installer must be a trained, experienced serviceman.
2. Disconnect power supply to prevent electrical shock and equipment damage.
3. Do NOT short across coil terminals on relay. This may burn out the heat anticipator.
4. Run wires as close to the subbase as possible. To prevent interference with the thermostat linkage, keep wire length to a minimum, and make certain wires do NOT protrude outward beyond standoffs (Fig. 5). Push excess wire back into the hole, and plug hole to prevent drafts from affecting thermostat operation.
5. Do NOT overtighten thermostat captive mounting screws. This may damage the threads in the subbase.
6. Always conduct a thorough checkout when installation is complete.

### IMPORTANT

Thermostats are calibrated at the factory using subbases mounted at true level. Inaccurate subbase leveling will cause thermostat control deviation.

### LOCATION

Locate the thermostat about 5 feet [1.5 metre] above the floor in an area with good air circulation at average temperature.

Do not mount the thermostat where it may be affected by

- drafts, or dead spots behind doors and in corners.
- hot or cold air from ducts.
- radiant heat from the sun or appliances.
- concealed pipes and chimneys.
- unheated (uncooled) areas behind the thermostat.

### SUBBASE MOUNTING

The subbase is designed for mounting on a wall or horizontal outlet box. (Adapter assembly, Part No. 130821B, with cover plate only is available for covering wall marks from old thermostat.) An adapter assembly, Part No. 130821A, with adapter ring and cover plate is available for mounting on a vertical outlet box. To mount subbase, proceed as follows:

1. At the location selected, prepare an opening for the thermostat wires.

2. Run low voltage thermostat wires to the location, and pull about 4 inches [100 millimetres] through the wall opening.

**NOTE:** Use color-coded thermostat cable for proper wiring.

3. If mounting the subbase on a vertical outlet box (Fig. 3), install the adapter ring with the 2 screws provided.




FIG. 3—INSTALLATION OF Q672 SUBBASE ON OUTLET BOX.

4. Pull thermostat cable through cover plate (if used) and subbase opening. Secure the cover plate and subbase with the 2 screws provided, but do not tighten.

Thermostats are calibrated at the factory using subbases mounted at true level. Inaccurate subbase leveling will cause thermostat control deviation.

5. The subbase mounting slots provide for minor out of level adjustments. Level the subbase using a spirit level, as shown in Fig. 4 and tighten subbase mounting screws.




FIG. 4—LEVELING THE SUBBASE.

## WIRING

All wiring must comply with local electrical codes and ordinances.

A letter code is near each terminal for easy identification. Typical terminal designation and wiring connections are listed in Tables 2 and 3.




FIG. 5—BARRIER CONFIGURATION.

TABLE 2 TERMINAL DESIGNATIONS

TERMINAL	TYPICAL CONNECTION
B	Heating damper motor, changeover valve (if used).
E	Emergency heat relay.
G	Fan relay coil.
O	Cooling damper motor, changeover valve (if used).
R	Power connection to transformer (internally connected for cooling and heating).
RC	Power connection to cooling transformer.
RH	Power connection to heating transformer.
W1	Stage 1 heating control.
W2	Stage 2 heating control.
Y1	Stage 1 cooling control.
Y2	Stage 2 cooling control.
X X1 X2 C	Clogged filter switch.

TABLE 3 ALTERNATE CONTROL CIRCUIT TERMINAL DESIGNATIONS

ALTERNATE DESIGNATIONS	STANDARD DESIGNATION	TYPICAL CONNECTION
V	V	24 volt power supply
H1	W1	First stage heating
H2	W2	Second stage heating
C1	Y1	First stage cooling
C2	Y2	Second stage cooling
F	G	Fan
-	B	Heating changeover
-	O	Cooling changeover

The shape of the terminal barrier permits insertion of straight or conventional wrap around (Fig. 5) wiring connections. Either method is acceptable. When making connections, strip wire to the length specified in Fig. 5.

Follow the equipment manufacturer's wiring instructions, if available, when wiring the subbase. If not available, Figs. 15 and up show typical T872-Q672 system hookups.




FIG. 6—INDIVIDUAL SCREW WIRING FOR Q672 SUBBASE.

Run wires as close to the subbase as possible. To prevent interference with the thermostat linkage, keep wire length to a minimum, and make certain wires do NOT protrude outward beyond standoffs, (Fig. 6). Push excess wire back into the hole, and plug hole to prevent drafts from affecting thermostat operation.

### HEAT ANTICIPATOR SETTING

Set the heat anticipator scale to match the primary control rating. When using a T872 Thermostat with 2 stages of heating, set both heat anticipators to match their respective primary control rating. If the primary control nameplate has no rating or if further adjustment is necessary, use the following procedure to determine the current draw of each stage.

The current draw of each heating stage must be measured with the thermostat removed.

1. Connect an ac ammeter of appropriate range between the heating terminals of the subbase—  
Stage 1—between W1 and RH or R;  
Stage 2—between W2 and RH or R.
2. Move the system switch to HEAT or AUTO.
3. After 1 minute, read the ammeter and record the reading.  
Stage 1—                      amp;  
Stage 2—                      amp.
4. After mounting the thermostat (see Thermostat Mounting, next paragraph), set the adjustable heat anticipator to match the respective reading measured in step 3.




FIG. 7—ADJUSTABLE HEAT ANTICIPATOR SCALES.

If equipment cycles too fast, set the anticipator to a higher current rating, not more than 1/2 division at a time, and recheck cycle rate. Most conventional 2-stage heating equipment is designed to operate at 3 cycles per hour, and 1-stage heating equipment at 6 cycles per hour, at 50 percent load conditions. When using a T872 Thermostat in heat pump systems, set the heat anticipator at 140% of the actual primary control current draw to reduce the cycling rate.

Most heat pump systems should cycle 2-1/2 to 3 times per hour.

### THERMOSTAT MOUNTING

1. Remove the thermostat from the polystyrene shipping container.

2. Remove the thermostat cover by pulling the bottom edge of the cover upward until it snaps free of the locking springs.

NOTE: The cover is hinged at the top and must be removed by pulling up at the bottom.

3. Carefully remove and discard the polystyrene packing insert which protects the mercury switches during shipment.

4. Turn the thermostat base over and note the spring fingers which engage the subbase contacts. Make sure the spring fingers are NOT bent preventing proper electrical contact with the subbase.




FIG. 8—RANGE LIMITING AND LEVER LOCKING METHODS.

5. Set the heat anticipator indicator(s), Fig. 7, to the respective current setting of each stage. See Heat Anticipator Setting.

6. If the thermostat provides the optional locking lever assembly, install the 2 self-tapping screws (Fig. 8) in the lever arms, if desired.

7. If the thermostat provides optional locking cover assembly, start the 2 Allen locking screws in the cover with the wrench provided (Fig. 9).

8. Note the tabs along the top inside edge of the thermostat base. The tabs fit the subbase sockets. Hang the thermostat on the subbase and tighten the captive mounting screws (Figs. 3-4) on the thermostat base. Do NOT overtighten thermostat captive mounting screws. This may damage the threads in the subbase.

9. Hang the upper edge of the thermostat cover on the base and swing cover downward until it engages with spring clips on base. Tighten the locking cover screws, if assembly is provided.




FIG. 9—INSTALLATION LOCKING COVER SCREWS ASSEMBLY.

## SETTING AND CHECKOUT

### CAUTION

On systems using a gas valve, never apply a jumper across the valve coil terminals, even temporarily. This may burn out thermostat heat anticipator(s).

### SETTING

#### TEMPERATURE SETTING

Move the H (heating) and C (cooling) levers (see Fig. 10) to the desired positions. On models with 2 stages of heating or cooling, the same lever controls both stages. The minimum differential between heating and cooling set points is 3 F [2 C] at midscale.

If model has optional screws to lock temperature control levers, loosen these screws before making temperature adjustment; tighten when levers are set at desired position.

#### SUBBASE SETTING

SYSTEM SWITCHING positions control thermostat operation as follows (see listing of models for positions applicable to model being installed):

OFF—both the heating and cooling systems are off.

If the fan switch is at AUTO position, the cooling fan is also off.

HEAT—heating system is controlled by the thermostat. Cooling system is off.

AUTO—completely automatic heating or cooling controlled by the thermostat.

COOL—thermostat controls the cooling system. Heating system is off.

EM. HT.—emergency heat relay is energized. Cooling system is off.

FAN SWITCHING positions control fan operation as follows:

ON—fan operates continuously.

AUTO—fan operates with cooling equipment as controlled by the thermostat or with the heating equipment as controlled by the plenum switch.

### CHECKOUT

#### HEATING

Move the system switch on the Q672 Subbase to HEAT or AUTO. Move the H lever on the T872 (Fig.

10) about 10 F [6 C] above room temperature. Both stages of heating system should start and the fan should run after a short delay. Move the H lever about 10 F [6 C] below room temperature. The heating equipment should shut off, and the fan should run for a short time, then shut off.




FIG. 10—INTERNAL VIEW OF T872D (WITH 2 STAGES OF HEATING AND COOLING).

#### COOLING

Move the system switch on the Q672 Subbase to COOL or AUTO. Move the C setting lever on the T872 Thermostat (Fig. 10) about 10 F [6 C] below room temperature. The cooling equipment and fan should start. If the system has 2 stages of cooling, both stages should start. Move the C lever about 10 F [6 C] above room temperature. The cooling equipment and fan should stop.

#### FAN

Move the system switch to COOL, OFF, or AUTO. If necessary, position both temperature setting levers near midscale so that the heating and cooling equipment are off. Move the fan switch to ON. The fan should run continuously. When the fan switch is in the AUTO position, fan operation is controlled by the heating or cooling system.

# SERVICE

## CAUTION

Before servicing, disconnect power supply to prevent electrical shock or equipment damage.

## THERMOSTAT

T872 Thermostats are accurately calibrated at the factory; THEY DO NOT HAVE PROVISION FOR FIELD CALIBRATION.

## THERMOMETER

To calibrate the thermometer:

1. Remove thermostat cover by pulling up from the bottom until it clears the locking springs. If cover has optional locking screws, these must be backed out before cover can be removed.

2. Set the cover on a table near an accurate thermometer.

3. After allowing 5 or 10 minutes for stabilization, compare the readings. If they are the same, replace cover and put system into operation. If they are different, recalibrate the thermostat thermometer, step 4.

4. Insert a small screwdriver in the thermometer shaft (Fig. 11) and turn it until the thermometers read the same. When thermometer is calibrated, replace cover and place system and fan switches for desired operation.

NOTE: Hand heat will offset the thermometer reading.

After making each adjustment, wait 5 or 10 minutes for the thermometer to stabilize before comparing.




FIG. 11—THERMOMETER CALIBRATION.

## BULB REPLACEMENT

Before replacing bulb, shut off the power supply to prevent shorting out the transformer at the bulb terminals, or move subbase system switch to "OFF."

Replace bulb in subbases with optional malfunction light as follows.

1. Remove the thermostat from the subbase.
2. Remove the snap-on shield that covers the light.
3. Disconnect the field wire from the "X" terminal to prevent shorting out the transformer at the bulb terminals.

4. Snap out the old bulb and replace it with a new bulb, Part No. 129571. The bulb contact should seat in the depression in the socket base. The bulb may be screwed in farther, if necessary, for a better electrical connection. When installing bulb, use needlenose pliers.

5. Reconnect the field wire to terminal "X."

6. Replace the shield and mount the thermostat.

## INDICATOR LIGHT ASSEMBLY INSTALLATION

The 135734A Indicator Light Assembly may be field added to most Q672 Subbases. The assembly mounts directly on the subbase and may be installed before or after the subbase is mounted. To install the indicator light assembly, use the following procedure.




FIG. 12—INSTALLATION OF INDICATOR LIGHT ASSEMBLY.

1. If the thermostat is mounted on the Q672 Subbase, remove the thermostat cover. NOTE: If the cover has optional locking screws, these must be backed out before cover can be removed.

2. Loosen 2 captive screws and remove thermostat.

3. Select either FILTER, CHECK, or EM. HT. lens.

4. Place the lens over the recess cavity on the subbase, and place the black retainer plate over the lens.

5. Start 1 self-tapping screw through the left-hand hole of the retainer plate and lens.

6. Pivot lens and plate out of way as shown in Fig. 12. Insert bulb into recessed cavity, and route wires toward left-hand side of subbase.

7. Pivot lens and retainer plate into position, and start second self-tapping screw in right-hand retainer hole.

To wire indicator light assembly, use the following procedure:

1. Route 1 indicator light leadwire to the R or RH subbase terminal, and fasten beneath the terminal screw (Fig. 13).
2. Route second indicator light leadwire to right retainer screw.




FIG. 13—CONNECTING 135734A LEADWIRES.

3. Route wire from indicator light control switch to right retainer screw. Attach both indicator switch wire and indicator light leadwire to right retainer screw.

4. Connect remaining indicator light control switch wire to common secondary leg of heating transformer (Fig. 14).




FIG. 14—WIRING HOOKUP FOR INDICATOR LIGHT AND CONTROL SWITCH.

Remount the thermostat, and restore the power supply. To check indicator light operation, jumper the indicator light control. The indicator lamp should light. After removing the jumper, the lamp should go out.

## THERMOSTAT-SUBBASE APPLICATION

The schematics on the following pages are divided into four groups:

1. Standard circuits with AUTO heat-cool changeover, page 11.
2. Standard circuits with MANUAL heat-cool changeover, page 17.
3. Heat Pump circuits with changeover in cooling--AUTO, page 21.  
MANUAL, page 28.
4. Heat Pump circuits with changeover in heating--AUTO, page 32.

Within groups, schematics are generally arranged alphabetically by subbase model, then thermostat model. For additional information on Q672 Subbase/T872 Thermostat combinations, see form 70-6208.

Circuit descriptions and terminology is defined as follows.

For standard heating-cooling circuits:

**AUTO CHANGEOVER**--refers to the presence of an AUTO position in the system switching (EXAMPLE: Q672E with OFF-HEAT-AUTO-COOL switching); does not require switch movement to change mode.

**MANUAL CHANGEOVER**--requires a system switch movement to change mode. (EXAMPLE: Q672B with HEAT-OFF-COOL switching).

T872D thermostats with 2 heat and 2 cool switches are shown on most standard circuits. Most standard or Tradeline subbases (Q672 A-E, G) can be used with T872A-F standard Tradeline thermostats. The schematics can be field-modified as required.

For heat pump circuits:

**CHANGEVER VALVE**--operates on Cooling. The reversing valve or relay is activated either by moving the system switch to COOL (manual changeover) or by a mercury switch which makes on a temperature rise (auto changeover).

**CHANGEVER VALVE**--operates on heating. The reversing valve or relay is activated either by moving the system switch to HEAT (manual changeover) or by a mercury switch which makes on a temperature fall (auto changeover.)

For all circuit components:

Each mercury switch is identified by function, as follows:

- H1--Stage 1 heating
- H2--Stage 2 heating
- C1--Stage 1 cooling
- C2--Stage 2 cooling
- C/O--Changeover (heat pumps)

Each anticipator is identified as adjustable or fixed, as well as naming which switch it affects. FOR EXAMPLE: H1 adjustable anticipator, C1 fixed anticipator.

All T872 thermostats use mercury switches. Each schematic will indicate switch operation by being drawn in the open position with an arrow indicating operation with a temperature RISE or FALL.



# STANDARD CIRCUITS WITH AUTO HEAT-COOL CHANGEOVER




FIG. 15—INTERNAL SCHEMATIC AND TYPICAL HOOKUP FOR Q672A SUBBASE WITH T872D THERMOSTAT. SUBBASE PROVIDES HEAT-OFF-COOL SYSTEM AND AUTO-ON FAN SWITCHING.






FIG. 16—INTERNAL SCHEMATIC AND TYPICAL HOOKUP FOR Q672C SUBBASE WITH T872D THERMOSTAT. SUBBASE PROVIDES OFF-AUTO SYSTEM AND AUTO-ON FAN SWITCHING.






FIG. 19—INTERNAL SCHEMATIC AND TYPICAL HOOKUP FOR Q672E SUBBASE WITH T872D THERMOSTAT. SUBBASE PROVIDES OFF-HEAT-AUTO-COOL SYSTEM AND AUTO-ON FAN SWITCHING. R TERMINAL FOR COMMON HEATING AND COOLING CIRCUIT.




FIG. 20—INTERNAL SCHEMATIC AND TYPICAL HOOKUP FOR Q672E SUBBASE AND T872D THERMOSTAT. SUBBASE PROVIDES OFF-HEAT-AUTO-COOL SYSTEM AND AUTO-ON FAN SWITCHING. RC-RH TERMINALS FOR SEPARATE HEATING AND COOLING CIRCUITS.




FIG. 21—INTERNAL SCHEMATIC AND TYPICAL HOOKUP FOR Q672E SUBBASE AND T872D THERMOSTAT. SUBBASE PROVIDES OFF-HEAT-AUTO-COOL SYSTEM AND AUTO-ON FAN SWITCHING.




FIG. 22—INTERNAL SCHEMATIC AND TYPICAL HOOKUP FOR Q672F SUBBASE AND T872D THERMOSTAT. SUBBASE PROVIDES OFF-EM. HT-HEAT-AUTO-COOL SYSTEM AND AUTO-ON FAN SWITCHING. EMERGENCY HEAT RELAY AND LIGHT ARE ENERGIZED WHEN SWITCH IS IN EM. HT. POSITION.




FIG. 23—INTERNAL SCHEMATIC AND TYPICAL HOOKUP FOR Q672F SUBBASE AND T872D THERMOSTAT. SUBBASE PROVIDES OFF-EM. HT.-HEAT-AUTO-COOL SYSTEM AND AUTO-ON FAN SWITCHING. EMERGENCY HEAT RELAY IS ENERGIZED WHEN SYSTEM SWITCH IS IN EM. HT. POSITION; LIGHT OPERATES WITH SECOND STAGE OF HEATING.




FIG. 24—INTERNAL SCHEMATIC AND TYPICAL HOOKUP FOR Q672F SUBBASE WITH T872C THERMOSTAT. SUBBASE PROVIDES OFF-EM. HT.-HEAT-AUTO-COOL SYSTEM AND AUTO-ON FAN SWITCHING. EMERGENCY HEAT RELAY ENERGIZED WHEN SWITCH IS IN EM. HT. POSITION; LIGHT OPERATES WITH SECOND STAGE HEATING.




FIG. 25—INTERNAL SCHEMATIC AND TYPICAL HOOKUP FOR Q672F SUBBASE AND T872C THERMOSTAT. SUBBASE PROVIDES OFF-EM. HT-HEAT-AUTO-COOL SYSTEM AND AUTO-ON FAN SWITCHING.




FIG. 26—INTERNAL SCHEMATIC AND TYPICAL HOOKUP FOR Q672G SUBBASE AND T872D THERMOSTAT. SUBBASE PROVIDES OFF-AUTO SYSTEM SWITCHING ONLY.




FIG. 27—INTERNAL SCHEMATIC AND TYPICAL HOOKUP FOR Q672K SUBBASE AND T872D THERMOSTAT. SUBBASE PROVIDES OFF-HEAT-AUTO-COOL SYSTEM SWITCHING ONLY.

### STANDARD CIRCUITS WITH MANUAL HEAT-COOL CHANGEOVER




FIG. 28—INTERNAL SCHEMATIC AND TYPICAL HOOKUP FOR Q672B SUBBASE AND T872D THERMOSTAT. SUBBASE PROVIDES HEAT-OFF-COOL SYSTEM AND AUTO-ON FAN SWITCHING.




FIG. 29—INTERNAL SCHEMATIC AND TYPICAL HOOKUP FOR Q672B SUBBASE AND T872D THERMOSTAT. SUBBASE PROVIDES HEAT-OFF-COOL SYSTEM AND AUTO-ON FAN SWITCHING. G TERMINAL IS ISOLATED ON HEATING TO PROVIDE FAN RELAY OPERATION FROM EXTERNAL LOW VOLTAGE FAN SWITCH.




FIG. 30—INTERNAL SCHEMATIC AND TYPICAL HOOKUP FOR Q672B SUBBASE AND T872D THERMOSTAT. SUBBASE PROVIDES HEAT-OFF-COOL SYSTEM AND AUTO-ON FAN SWITCHING, AND AUTOMATIC FAN OPERATION IN HEATING AND COOLING FOR ELECTRIC FURNACE.






FIG. 31—INTERNAL SCHEMATIC AND TYPICAL HOOKUP FOR Q672B SUBBASE AND T072T THERMOSTAT. THERMOSTAT PROVIDES 1-STAGE HEATING, 1-STAGE VENTILATION, AND 2-STAGE COOLING. SUBBASE PROVIDES HEAT-OFF-COOL SYSTEM AND AUTO-ON FAN SWITCHING.




FIG. 32—INTERNAL SCHEMATIC AND TYPICAL HOOKUP FOR Q672B SUBBASE AND T072C THERMOSTAT. SUBBASE PROVIDES HEAT-OFF-COOL SYSTEM AND AUTO-ON FAN SWITCHING.




FIG. 33—INTERNAL SCHEMATIC AND TYPICAL HOOKUP FOR Q672D SUBBASE AND T872D THERMOSTAT. NO SUBBASE SWITCHING IS PROVIDED.




FIG. 34—INTERNAL SCHEMATIC AND TYPICAL HOOKUP FOR Q672D SUBBASE AND T872M THERMOSTAT. SYSTEM SWITCHING TO BE PROVIDED EXTERNALLY, SECOND-STAGE HEAT IS FIXED TO MAKE AT 60 F [16 C].

# HEAT PUMP CIRCUITS WITH AUTOMATIC CHANGEOVER ON COOLING




FIG. 35—INTERNAL SCHEMATIC AND TYPICAL HOOKUP FOR Q672C/T872H IN HEAT PUMP APPLICATION. THERMOSTAT PROVIDES 1-STAGE HEATING AND 1-STAGE COOLING; CHANGEOVER VALVE OPERATES WITH COOLING. SUB-BASE PROVIDES OFF-AUTO SYSTEM AND AUTO-ON FAN SWITCHING.






FIG. 36—INTERNAL SCHEMATIC AND TYPICAL HOOKUP FOR Q672E/T872G IN HEAT PUMP APPLICATION. THERMOSTAT PROVIDES 2-STAGE HEATING AND 1-STAGE COOLING; CHANGEOVER VALVE OPERATES WITH COOLING. SUB-BASE PROVIDES OFF-HEAT-AUTO-COOL SYSTEM AND AUTO-ON FAN SWITCHING.






FIG. 39—INTERNAL SCHEMATIC AND TYPICAL HOOKUP FOR Q672F/T872G IN HEAT PUMP APPLICATION. THERMOSTAT PROVIDES 2-STAGE HEATING (SECOND-STAGE HEAT IS FAST CYCLING) AND 1-STAGE COOLING; CHANGEOVER VALVE OPERATES WITH COOLING. SUBBASE PROVIDES OFF-COOL-AUTO-HEAT-EM. HT. SYSTEM AND AUTO-ON FAN SWITCHING.








FIG. 40—INTERNAL SCHEMATIC AND TYPICAL HOOKUP FOR Q672F/T872G IN HEAT PUMP APPLICATION. THERMOSTAT PROVIDES 2-STAGE HEATING AND 1-STAGE COOLING; CHANGEOVER VALVE OPERATES WITH COOLING. SUDDASE PROVIDES OFF-COOL-AUTO-HEAT-EM.HT.SYSTEM AND AUTO-ON FAN SWITCHING.










FIG. 45—INTERNAL SCHEMATIC AND TYPICAL HOOKUP FOR Q672J/T872G IN HEAT PUMP APPLICATION. THERMOSTAT PROVIDES 2-STAGE HEATING AND 1-STAGE COOLING; CHANGE-OVER VALVE OPERATES WITH COOLING. SUB-BASE PROVIDES EM.HT-AUTO-OFF SYSTEM AND AUTO-ON FAN SWITCHING.








FIG. 46—INTERNAL SCHEMATIC AND TYPICAL HOOKUP FOR Q672J/T872G IN HEAT PUMP APPLICATION. THERMOSTAT PROVIDES 2-STAGE HEATING AND 1-STAGE COOLING; CHANGE-OVER VALVE OPERATES WITH COOLING. SUB-BASE PROVIDES EM.HT-ON-OFF SYSTEM AND AUTO-ON FAN SWITCHING.

# HEAT PUMP CIRCUITS WITH MANUAL CHANGEOVER ON COOLING





**FIG. 49—INTERNAL SCHEMATIC AND TYPICAL HOOKUP FOR Q672L/T872R IN HEAT PUMP APPLICATION. THERMOSTAT PROVIDES 2-STAGE HEATING AND 1-STAGE COOLING; MANUAL CHANGEOVER OPERATES ON COOLING. FAST CYCLING STAGE 2 HEAT HAS ISOLATED CIRCUIT AND SEPARATE TRANSFORMER. EMERGENCY HEAT RELAY AND LIGHT ARE ENERGIZED IN EM.HT. SWITCH POSITION. SUBBASE PROVIDES EM.HT. HEAT-OFF-COOL SYSTEM AND AUTO-ON FAN SWITCHING.**



**FIG. 50—INTERNAL SCHEMATIC AND TYPICAL HOOKUP FOR Q672L/T872R IN HEAT PUMP APPLICATION. THERMOSTAT PROVIDES 2-STAGE HEATING AND 1-STAGE COOLING; MANUAL CHANGEOVER OPERATES ON COOLING. FAST CYCLING STAGE 2 HEAT HAS ISOLATED CIRCUIT AND SEPARATE TRANSFORMER. EMERGENCY HEAT RELAY AND LIGHT ARE ENERGIZED IN EM.HT. SWITCH POSITION. SUBBASE PROVIDES EM.HT. HEAT-OFF-COOL SYSTEM AND AUTO-ON FAN SWITCHING.**




FIG. 51—INTERNAL SCHEMATIC AND TYPICAL HOOKUP OF Q672L/T872G IN HEAT PUMP APPLICATION. THERMOSTAT PROVIDES 2-STAGE HEATING AND 1-STAGE COOLING; MANUAL CHANGEOVER OPERATES ON COOLING. SUB-BASE PROVIDES EM.HT.-HEAT-OFF-COOL SYSTEM AND AUTO-ON FAN SWITCHING.




FIG. 52—INTERNAL SCHEMATIC AND TYPICAL HOOKUP OF Q672L/T872R IN HEAT PUMP APPLICATION. THERMOSTAT PROVIDES 2-STAGE HEATING AND 1-STAGE COOLING; MANUAL CHANGEOVER OPERATES ON COOLING. SUB-BASE PROVIDES EM.HT.-HEAT-OFF-COOL SYSTEM AND AUTO-ON FAN SWITCHING.




FIG. 53—INTERNAL SCHEMATIC AND TYPICAL HOOKUP OF Q672L/T872R IN HEAT PUMP APPLICATION. THERMOSTAT PROVIDES 2-STAGE HEATING AND 1-STAGE COOLING; MANUAL CHANGEOVER OPERATES ON COOLING. SUBBASE PROVIDES EM. HT.-HEAT-OFF-COOL SYSTEM AND AUTO-ON FAN SWITCHING.




FIG. 54—INTERNAL SCHEMATIC AND TYPICAL HOOKUP OF Q672L/T872G IN HEAT PUMP APPLICATION. THERMOSTAT PROVIDES 2-STAGE HEATING AND 2-STAGE COOLING. SUBBASE PROVIDES EM. HT.-HEAT-OFF-COOL SYSTEM AND AUTO-ON FAN SWITCHING.

# HEAT PUMP CIRCUITS WITH AUTOMATIC CHANGEOVER ON HEATING




FIG. 55—INTERNAL SCHEMATIC AND TYPICAL HOOKUP OF Q672C/T8725 IN HEAT PUMP APPLICATION. THERMOSTAT PROVIDES 2-STAGE HEATING AND 1-STAGE COOLING; CHANGEOVER VALVE OPERATES WITH HEATING. SUB-BASE PROVIDES OFF-AUTO SYSTEM AND AUTO-ON FAN SWITCHING.




FIG. 56—INTERNAL SCHEMATIC AND TYPICAL HOOKUP OF Q672F/T872N IN HEAT PUMP APPLICATION. THERMOSTAT PROVIDES 2-STAGE HEATING AND 1-STAGE COOLING; CHANGEOVER VALVE OPERATES WITH HEATING. SUB-BASE PROVIDES OFF-COOL-AUTO-HEAT-EM.HT. SYSTEM AND AUTO-ON FAN SWITCHING.




FIG. 57—INTERNAL SCHEMATIC AND TYPICAL HOOKUP OF Q672E/T872C IN HEAT PUMP APPLICATION. THERMOSTAT PROVIDES 1-STAGE HEATING AND 1-STAGE COOLING; CHANGEOVER VALVE OPERATES WITH HEATING. SUB-BASE PROVIDES OFF-HEAT-AUTO-COOL SYSTEM AND AUTO-ON FAN SWITCHING.








FIG. 60—INTERNAL SCHEMATIC AND TYPICAL HOOKUP OF Q672J/T872A OR D IN HEAT PUMP APPLICATION. THERMOSTAT PROVIDES 2-STAGE HEATING AND 2-STAGE COOLING; CHANGEOVER VALVE OPERATES WITH HEATING. SUBBASE PROVIDES EM. HT.-AUTO-OFF SYSTEM AND AUTO-ON FAN SWITCHING.

# Honeywell

AQUASTAT CONTROLLERS ARE IMMERSION TYPE DEVICES FOR LIMITING OR REGULATING THE TEMPERATURE OF LIQUIDS IN BOILERS, STORAGE TANKS, AND OTHER APPLICATIONS WHERE TEMPERATURE CONTROL OF LIQUIDS IS REQUIRED. AS THE TEMPERATURE OF THE CONTROLLED MEDIUM RISES TO THE SET POINT, EXPANSION OF THE FLUID IN THE SENSING ELEMENT OPERATES THE INTERNAL SWITCH OR SWITCHES.

☐ The L4006, 7, and 8 provide spst switching for high or low limit control of a burner.

☐ The L4006G model has two spst switches that make and break in sequence to provide boiler sequencing.

☐ The L6006 and 8 provide spdt switching for low limit and circulator control.

☐ Models which break contact on a temperature rise to the set point are calibrated for high limit use. They are also suitable for low limit control if a separate high limit control is used.

☐ Ambient compensated models are available to prevent control-point shift caused by temperature fluctuation at the case.

☐ Visible control point scale and external adjustment screw permit easy setting.

☐ Models are available for either horizontal or vertical insertion of the sensing element. The sensing element may be directly immersed or placed in an immersion well.

☐ Remote bulb models are available if the controller must be mounted at a location away from the sensing element.

☐ Remote bulb models may also be used to sense air temperature in ducts and in outside air sensing applications.


☐ Totally enclosed Micro Switch snap-acting switches are used in all models.

S.K.

7-75

ORIGINAL PAGE IS  
OF POOR QUALITY

## AQUASTAT CONTROLLERS



## L4006,7,8; L6006,8

Residential Div. Form Number

60-2104-1

#

**SPST MODELS CONTINUED:**

MODEL	APPLICATION	RANGE (F)	MIDSCALE DIFFERENTIAL (F)	INSERTION <sup>a</sup>	SWITCHING ON TEMP. RISE	AVAILABLE OPTIONS
L4008D <sup>a</sup>	ambient compensated circulator	0 to 70 or 40 to 180	2 or 5 fixed	remote bulb	makes	Tradeline model available. Centigrade scale markings. Hot tinned 8 ft. capillary. Electrical rating: 2.3 amp at 120-240v ac, full load. Fast response, 10 ft. armored capillary with 3 ft. bulb. External adjustment knob. Factory set scale stops at 120, 220, or 250 F. Plastic shield for covering well in water heater applications.
L4008E <sup>ab</sup>	high limit	40 to 80 or 110 to 290	manual reset	remote bulb	breaks	Factory set scale stop at 250 F. 8 ft. 6 in. capillary.
L4008J <sup>a</sup>	high limit	100 to 240	5 fixed	remote bulb	breaks	All models less case and cover. 18 in. capillary and 1/2 in. well assy. Factory set scale stop at 220 F.
L4008K <sup>a</sup>	circulator	40 to 180	5 fixed	remote bulb	makes	All models less cover.

**SPDT MODELS:**

MODEL	APPLICATION	RANGE (F)	MIDSCALE DIFFERENTIAL (F)	INSERTION <sup>a</sup>	AVAILABLE OPTIONS
L6006A <sup>a</sup>	circulator and low limit or high limit	100 to 240 or 110 to 290	5 fixed or 5 to 30 adj.	horizontal	Tradeline model which includes well adapter and tube of heat conductive compound. 3/4 in. NPT brass spud, 3 in. insulation depth. Horizontal or vertical mount available on same models.
L6006B	circulator and low limit or high limit	100 to 240	5 fixed or 5 to 30 adj.	horizontal	3/4 in. brass bulb compression fitting.
L6008A <sup>a</sup>	circulator and low limit cooling	100 to 240 -30 to 70	5 fixed or 5 or 30 adj.	remote bulb	Tradeline model with 5 ft. capillary. Range of -30 to 70 F. Centigrade scale markings. Without cover.
L6008C <sup>a</sup>	dual fuel changeover	0 to 70 40 to 180	2 or 5 fixed	remote bulb. May be duct mounted.	Tradeline model. 150 va switch rating. Centigrade scale markings. 7 ft. 6 in. armored capillary. External adjustment knob. Lock type cover. 20 ft. element. Averaging element.
L6008E <sup>a</sup>	ambient compensated	40 to 180	5 fixed	remote bulb	All models less enclosure. Front mounted.

<sup>a</sup>Conner well or fitting is supplied with all models except remote bulb type. When ordering, specify boiler tapping size (1/2 or 3/4 inch) and insulation depth.

<sup>b</sup>Manual reset (trip-free)—Switch breaks circuit and locks out when controlled medium reaches set point. Controlled temperature must drop 20 degrees below set point before contacts can be manually reset.

NOTE: The following specifications are standard. Variances, available as options, are noted in the preceding table.

**ELECTRICAL RATING (AMPS):**

Models with 2 F fixed differential—

	120v ac	240v ac
FULL LOAD	2.6	1.3
LOCKED ROTOR	15.6	7.8

Models with 5 F differential—

	120v ac	240v ac
FULL LOAD	8	5.1
LOCKED ROTOR	48	30.6
INDUCTIVE CURRENT	.25 at 1/4 to 12v dc	

**PRESSURE RATING:**

**Capillary bulb (direct immersion)—200 psi.**

**Immersion well—255 psi.**

**SENSING BULB MATERIAL:** Copper.

**SENSING BULB FULL: Liquid. Toluene or Silicone.**

**CAPILLARY LENGTH (including bulb): Remote bulb models—60 inches.**

**SENSING BULB DIMENSIONS (inches): 2-7/8 long,  
3/8 diameter.**

**INSERTION DEPTH: 3-3/8 inches.**

**INSULATION: Brass. 1-1/2 or 3 inches. Specify when ordering.**

**PROVISION FOR WIRING:** Screw terminals.


**MOUNTING:** Horizontal and vertical models mount directly to an immersion well installed in a boiler fitting. Remote bulb models have 3 mounting holes rear of case for screw mounting to a vertical surface.

**FINISH: Gray.**


**INSTALLATION DIMENSIONS:** See Figs. 1 and 2.

**IMMERSION WELL DIMENSIONS:** See Fig. 3.

**BOILER FITTING AND BULB DIMENSIONS: See Fig. 4.**



**FIG. 1—INSTALLATION DIMENSIONS.**



**FIG. 3—IMMERSION WELL DIMENSIONS FOR ALL MODELS EXCEPT L4006C, L4007D, AND L6006B.**

### ACCESSORIES:

**Weatherproof enclosure—Q615.**

### Immersion wells—

Copper, 1/2 NPT, 1-1/2 inch insulation—Part  
No. 121371A.

Copper, 1/2 NPT, 3 inch insulation—Part No.  
121371L.

Copper, 3/4 NPT, 1-1/2 inch insulation—Part  
No. 121371B.

Copper, 3/4 NPT, 3 inch insulation—Part No.  
121371M.

Copper, 3/4 NPT, 1-1/2 inch insulation, plastic sleeve—Part No. 12131K.

Copper, 3/4 NPT, 3 inch insulation, plastic  
 sleeve—Part No. 121371N.

Stainless steel, 1/2 NPT, 1-1/2 inch insulation  
—Part No. 121371E.

—Part No. 121371F.  
Stainless steel, 3/4 NPT, 1-1/2 inch insulation  
—Part No. 121371F.

**Bulb Compression Fittings (see Fig. 6) —**


Brass, 1/2 NPT plug. 1-1/2 inch insulation—  
Part No. 104486B.

Brass, 3/4 NPT plug. 1-1/2 inch insulation—  
Part No. 104486C.

**Capillary Compression Fittings (see Fig. 7) —**

Copper, 1/2 NPT plug. 1-1/2 inch insulation—  
Part No. 104484C.

Copper, 3/4 NPT plug. 1-1/2 inch insulation—  
Part No, 104484B.



**FIG. 2—INSTALLATION DIMENSIONS FOR REMOTE BULB MODELS. OTHER DIMENSIONS SAME AS FIG. 1.**




FIG. 4--BOILER FITTING AND BULB DIMENSIONS FOR L4006C, L4007D, AND L6006B.

# INSTALLATION

The manufacturer usually provides a tapping for insertion of the controller's sensing element. This tapping is located at a point where typical water temperature can be measured. Depending on model, the element is inserted in an immersion well, through a boiler fitting, or directly immersed.

Installation should be made by a qualified serviceman. Follow the instructions furnished by the system manufacturer, if available. Otherwise, refer to appropriate procedure listed below.

## IMPORTANT

Controller may be used with or without immersion well. Well, if used, must fit sensing bulb snugly for good thermal response. Insert bulb until it rests against bottom of well, then hold it there while tightening the tubing clamp.

## MOUNTING REMOTE BULB MODELS

The remote temperature-sensing bulb can either be installed in an immersion well (Fig. 5) that extends into the boiler or tank, or it can be directly immersed in the liquid. For installations not using a well, secure the remote bulb with a bulb compression fitting (Fig. 6), or capillary compression fitting (Fig. 7).

Well, bulb compression fitting or capillary compression fitting must be ordered separately. Sizes available: 1/2 in., 3/4 in. NPT spud. Well, if used, must fit sensing bulb snugly for good thermal response. Insert bulb until it rests against bottom of well, then hold it there while tightening the tubing clamp. (See Fig. 5.)

The boiler manufacturer generally provides a tapping for the insertion of the Aquastat controller's sensing element. This tapping should be located at a point where typical water temperature can be measured. The bulb or protecting immersion well must never be located close to a hot or cold water inlet or a steam coil.

If the system is filled, drain system to a point below the boiler tapping, or wherever the sensing bulb is to be installed.

The bulb can also be installed in the supply line of an indirect water heater, in the direct water heater itself, or in the feed riser, about 6 in. above the boiler. If the riser is valved, the bulb can be installed between the boiler and the valve.

NOTE: Avoid making sharp bends or kinks in the capillary. Bends should be no sharper than 1 inch radius.

After installing, carefully coil excess capillary at the bottom of the controller case.

## IMMERSION WELL MOUNTING

1. Screw the well into the boiler, tank, or pipe tapping.
2. Insert bulb in well, pushing tubing until bulb bottoms in well.

3. Attach retainer clamp to end of well spud. Loosen draw nut and spread jaws of clamp with screwdriver if necessary.

4. With retainer clamp attached to well spud (be sure jaws of clamp hook over ridge at end of spud, as shown at points "A"), adjust tubing to fit through retainer clamp groove, as shown at point "B."

5. Tighten draw nut so that retainer clamp is firmly attached to well spud and tubing is held securely in place.

## CAUTION:

Do not secure draw nut so tightly that retainer clamp could collapse tubing.




FIG. 5—IMMERSION WELL FITTING.

## MOUNTING WITH BULB COMPRESSION FITTING




FIG. 6—BULB COMPRESSION FITTING. USE WITH MODEL L4008A,B,E,J, OR L6008A.

1. Screw the fitting into boiler or pipe tapping.
2. Slide sealing washer onto bulb.
3. Insert bulb into boiler fitting until bulb bottoms.
4. Slide split sleeve into fitting.
5. Place clamps A and B on assembly so that sleeve is drawn into fitting when screws are tightened. Note: make sure that nub on clamp A engages space between sleeve and clamp.
6. Tighten clamp screws evenly.

#### MOUNTING WITH CAPILLARY COMPRESSION FITTING




FIG. 7—CAPILLARY COMPRESSION FITTING. USE WITH MODEL L4000C,D,K, OR L6000C,E.

1. Screw fitting into boiler or pipe tapping.
2. Place packing nut on tubing.
3. Slide bulb completely through fitting.
4. Place composition disc and 4 slotted brass washers on tubing in the order shown in Fig. 7. Turn brass washers so that slots are 180 degrees apart.
5. Slide seal assembly into fitting and tighten packing nut.

#### DUCT MOUNTING




FIG. 8—BULB SUPPORT.

1. Drill a 3/4 inch hole in the duct wall large enough to admit the sensing bulb into the holder.
2. Using the holder as a template, mark and drill holes for bulb holder mounting screws.
3. Break holder to desired length (Fig. 9).

NOTE: Holder must be long enough to hold sensing bulb in freely circulating air away from duct wall. Neatly coil excess capillary at controller case or at bulb holder.




FIG. 9—REMOVING EXCESS BULB SUPPORT.

4. Place capillary in bulb holder channel. Pinch top edges of holder together at each segment (Fig. 10).




FIG. 10—SECURING CAPILLARY IN BULB HOLDER.

5. Insert bulb holder into controlled area through hole prepared in step 1 above.
6. Fasten bulb holder to duct wall with screws furnished.

#### MOUNTING DIRECT IMMERSION MODELS

##### FOR MODELS USING AN IMMERSION WELL

The well of the Aquastat controller must always be exposed to circulation of the medium under control, but must never be located close to a hot or cold inlet or steam coil. Where the tapping is on the side of the boiler, use an Aquastat controller with horizontal well. Where the tapping is on top of the boiler, use a model with a vertical well.

##### INSTALLING THE IMMERSION WELL

On existing installations, shut off the power and remove the old control. If the old immersion well appears suitable, and if the adapter clamp on the Aquastat controller fits the old well spud, the well need not be replaced.

1. If the system is filled, drain system to a point below the boiler tapping.
2. Remove plug (or old well) from boiler tapping.
3. Install the No. 121371 Immersion Well included with the controller. If boiler tapping is greater than 1/2 inch a reduction fitting must be used to adapt the boiler opening to the 1/2 inch threads that are standard with the well or fitting. Fittings with 3/4 inch threads are also available.
4. Fill the system. Make sure that the well is screwed in tightly enough to prevent leakage. Do NOT tighten or apply force to case after controller is secured to well.

## INSTALLATION OF SENSING BULB IN IMMERSION WELL

a. Loosen screw (at top of case, above scale-setting), and remove cover. Loosen two screws that secure adapter clamp. See Fig. 11.

b. Insert the sensing element into the immersion well.

c. Fasten the case of the Aquastat controller to the well with the adapter clamp. Make certain that the clamp is properly positioned over the groove of the well spud. Also be sure the flange at the opening of the well fits snugly into the opening of the case. The sensing element bulb must bottom in the well.




FIG. 11—INTERNAL VIEW OF L6006A.

## MODELS DESIGNED FOR DIRECT IMMERSION (WITHOUT WELL)

Some models, which provide direct immersion of the sensing element into the boiler, include a No. 104486 bulb compression fitting assembly instead of an immersion well. Install fitting in boiler tapping. Be sure sealing washer is in place as shown in Fig. 12. Make sure that spud of bulb compression fitting is screwed in tightly enough to prevent leaking. Insert immersion bulb (sensing element) through bulb compression fitting. Adjust the adapter clamp so that it fits over the groove at the opening of the bulb compression fitting. Tighten adapter clamp screws so that Aquastat controller is firmly attached to bulb compression fitting.

## MOUNTING DUAL FUEL CHANGEOVER MODELS

These models have a five foot capillary. This capillary establishes the maximum distance between the case and the outdoor mounting.




FIG. 12—DIRECT IMMERSION MODEL WITH BULB COMPRESSION FITTING PARTIALLY REMOVED.

The bulb should be installed on the outside of the building in the shield provided (see Fig. 13) where it will be exposed to representative air temperature, but not to direct sunlight. It should be mounted high enough so that accumulated snow, leaves, or other debris cannot obstruct circulation of air around it, and where children cannot reach it. Avoid vents from the building.

Install the case at the indoor location selected, fastening with screws through holes in back of the case. Bring the bulb and tubing out through a 3/4 inch hole in the outside wall. In uncoiling the tubing, carefully avoid sharp bends or kinks. Excess tubing should be left coiled near the case. Do not make sharp bends near the case or bulb.

Slip the bulb through the supports in the shield. Pinch the split supporting clip until it holds the bulb firmly in position. If the seal-off tube protrudes from under the shield, it may be bent under as shown in Fig. 13.

Hold the shield over the mounting position and form a small-radius bend in the tubing. Place the split plug around the tubing and move the shield into mounting location as a unit. Push the split plug into the hole until it is wedged securely in place. Fasten the shield in place on the wall with the screws provided.

NOTE: If the tubing is properly shaped and the split plug installed as directed, the shield will cover the split plug, and the hole in the wall will be hidden from sight.




FIG. 13—MOUNTING BULB IN SHIELD OUTSIDE BUILDING.



## MOUNTING THE L6008A REMOTE BULB COOLING THERMOSTAT

### MOUNTING WITH GUARD BRACKET

Mount the bulb in the guard bracket as shown in Fig. 14. Locate the bulb and bracket combination in freely circulating air in the controlled area. With screws provided, fasten the bracket in place.

### MOUNTING ON SUCTION LINE

1. In cooling units with more than one suction line, sensing bulb should be placed on the common line.
2. Make certain the bulb is at least 2 feet from the point at which the suction line leaves the cooler. This will prevent the outside temperature from being transmitted to the remote bulb through the copper tubing of the suction line.
3. Place the remote sensing bulb on the side of the horizontal suction line between the coil and trap (not on the trap).
4. Attach the sensing bulb to the suction line with clips or straps.
5. Coil the excess length of capillary tubing near the L6008A case.




FIG. 14—SECURING REMOTE BULB IN CLIP.

### WIRING

All wiring must comply with local codes and ordinances regarding wire size, type of insulation, enclosure, etc. Figures 16 through 23 show typical hook-up diagrams.




FIG. 15—ATTACHING REMOTE BULB TO HORIZONTAL SUCTION LINE.




FIG. 16—TYPICAL GAS-FIRED SYSTEM WITH DOMESTIC HOT WATER.




FIG. 17—TYPICAL OIL-FIRED GRAVITY SYSTEM.




FIG. 18—TYPICAL OIL-FIRED HYDRONIC SYSTEM WITH DOMESTIC HOT WATER.




FIG. 19—OIL-FIRED SUMMER-WINTER HYDRONIC SYSTEM WITH DOMESTIC HOT WATER.




FIG. 20—TYPICAL WIRING DIAGRAM FOR L6008C1040 USED TO SWITCH FROM GAS TO OIL ON TEMPERATURE DROP.




FIG. 21—TYPICAL WIRING DIAGRAM FOR L6008C1040 USED TO SWITCH STREET GAS TO LPG ON TEMPERATURE DROP.




FIG. 22—L6008A USED TO CONTROL COOLING EQUIPMENT AND INDICATING LIGHT.




FIG. 23—TYPICAL HOOKUP FOR L4006G BOILER SEQUENCING AQUASTAT.

## FOR PROPER SELECTION OF SETTINGS, FOLLOW THE BOILER MANUFACTURER'S RECOMMENDATIONS.

### HIGH LIMIT CONTROLLER

Shuts off burner if water temperature exceeds high limit setting. Burner restarts when temperature drops to high limit setting, less differential.

NOTE: On manual reset models, the reset button on the front of the case must be pushed in to allow the burner to operate after a high limit shutdown.

### LOW LIMIT CONTROLLER

Maintains minimum boiler temperature for domestic hot water. Turns on boiler at temperature setting, minus differential.

### CIRCULATOR CONTROLLER

Prevents circulation of water that is below the desired heating temperature. Breaks circulator circuit on temperature drop below setting minus differential, remakes on rise to setting.

## ADJUSTING

Set the differential to correspond with the boiler manufacturer's recommendations. To adjust models with adjustable differential, rotate the wheel on the back of the snap switch until the desired reading is aligned with the "V" notch in the frame. The wheel provides an adjustment from 5 to 30 F. Replace the cover on the Aquastat controller.

Adjust the control point to correspond with the boiler manufacturer's recommendations. To adjust, insert a screwdriver in the slotted screw-type head located beneath the window in the cover. Turn the scale to the desired control point.

### L6008A LOCATION DIFFERENTIAL CALIBRATION

The L6008A1093 is calibrated for applications with both the bulb and case located in the room in which the temperature is being controlled. A correction will be necessary if the temperature of the case is different from the desired dial setting.

1. If the case is at a higher temperature than the desired dial setting, raise the desired dial setting by the correction determined from the table at right.

2. If the case is at a lower temperature than the desired dial setting, lower the desired dial setting by the correction determined from the table below.

Temperature difference between desired room temperature and case temperature (F)	Correction (Degrees F)
0	0
5	3/4
10	1-1/2
15	2
20	2-3/4
25	3-1/2
30	4-1/4
35	5
40	5-3/4
45	6-1/2
50	7
55	8
60	8-1/2
70	10
80	11-1/2

## CHECK OUT

Check to make certain that the Aquastat controller has been installed and adjusted properly. Put the system into operation and observe the action of the device through several cycles to make certain that it provides

proper control of the system as described under OPERATION. Further adjustments then can be made to meet more exact comfort requirements.

## APPENDIX G

### GENERAL SDAS INSTALLATION

## INSTRUMENTATION INTERFACE REQUIREMENTS

To transmit data from each sensor to the Central Data Processing System, the hardware components shown in Figure 1 are utilized at each site. A typical layout of the work space required around the SDAS mounting area is shown in Figure 2.

*NOTE: All ERDA responsibilities will be performed by NASA.*

### Hardware Components

1. Sensor wire (supplied and installed by site contractor)
2. Junction box (supplied by ERDA and installed by site contractor)
3. Junction box/SDAS interface cables (supplied and installed by ERDA)
4. Site Data Acquisition Subsystem (SDAS) (supplied by ERDA and installed by site contractor)
5. SDAS telephone interface (supplied by ERDA)
6. SDAS and telephone electrical power interface (supplied by site contractor)

### Sensor to Junction Box Wiring

All wiring from sensors to junction box (J-box) terminal block connections shall be performed by the site contractor in accordance with these guidelines utilizing wire procured by the site contractor and prepared for each sensor according to instructions in Figure 3. The wire size and number of conductors required for each sensor is specified in Table 1. The sensor-to-junction-box wire shall be color-coded, audio and instrumentation grade cable to minimize noise problems. Conduit shall be used only in accordance with local codes.





Figure 1 . Site Instrumentation Interface Hardware



**NOTES:**

- ① J Box (A) is to be located within a cable run of 4 ft. of the SDAS (B)
- ② NEMA type L5 15R receptacle to be within 6 ft. of SDAS (B)
- ③ Telephone Interface (Coupler) is located within 3 ft. of SDAS (B)

Figure 2. Typical SDAS Installation Layout Profile




Figure 3. Sensor Wire Preparation Procedure



Table 1. Sensor Wire Requirements

SENSOR TYPE	CONDUCTORS	AMERICAN WIRE GAUGE
Temperature		
- Single element RTD	3 + shield	#18-3
- Dual element RTD	3 + shield (2)	#18-3
Flow rate (liquid)	4 + shield	#18-4
Air velocity	2 + shield	#18-2
Solar radiation	2 + shield	#18-2
Electric power	2 + shield	#18-2
<p>NOTE: 1. Typical wire part numbers include:</p> <ul style="list-style-type: none"> <li>- Alpha P/N 2422-18 gauge, 2 conductor or equivalent</li> <li>- Alpha P/N 2423-18 gauge, 3 conductor or equivalent</li> <li>- Alpha P/N 2424-18 gauge, 4 conductor or equivalent</li> <li>- Dearborn P/N 971804-18 gauge, 4 conductor or equivalent</li> <li>- Dearborn P/N 971803-18 gauge, 3 conductor or equivalent</li> <li>- Dearborn P/N 971802-18 gauge, 2 conductor or equivalent</li> <li>- Manhattan P/N M3242-18 gauge, 2 conductor or equivalent</li> <li>- Manhattan P/N M3243-18 gauge, 3 conductor or equivalent</li> <li>- Manhattan P/N M3244-18 gauge, 4 conductor or equivalent</li> </ul> <p>2. Two (2) cables required for dual element RTDs.</p> <p>3. Wire exposed to the outdoor environment or buried shall be in conduit.</p> <p>4. Rigid conduit runs to all sensors shall be terminated with flexible conduit. All connections shall be made watertight.</p>		

**CAUTION**

**AC POWER LINES AND OTHER POTENTIAL NOISE INDUCING LINES SHOULD NOT BE PLACED IN THE SENSOR WIRING CONDUIT OR ROUTED NEAR THE INSTRUMENTATION CABLES. ALSO, THE INSTRUMENTATION CABLES SHOULD NOT BE ROUTED NEAR NOISE GENERATING EQUIPMENT.**

**Junction Box**

ERDA will provide a junction box (Figure 4) to the site contractor for installation in a central location with respect to the solar energy system. The installation location shall be selected by the site contractor and shall be specified in the ISPI.

As defined by ERDA, noise suppression may be required at the sensor, J-Box or both to provide acceptable data. Remote signal conditioning may be required to improve the signal-to-noise ratio that would improve data accuracy.

**Junction Box Location** -- The junction box, Figure 4, shall be mounted by the site contractor so that it is accessible for wiring connections from the sensors and is within four feet of the SDAS location on the same side of the wall.

**Junction Box Mounting** -- At the predefined mounting location, the junction box shall be mounted by the site contractor using the four mounting holes located at the back of the unit. Figure 4 provides the dimensional information for mounting. Depending on the characteristics of the mounting surface, Molly bolts, wood screws, or bolt/nut combinations shall be used to mount the unit. The junction box shall be installed in a top-up orientation.

**Junction Box Interfaces** -- ERDA will establish the wire run list which identifies where each sensor wire attaches to the junction box terminal strips. This wire run list will be a part of the AIP which the site contractor will implement. A typical example of a wire run list and the connection of typical measurements




Figure 4. Junction Box/SDAS Interface with typical Sensor connection

ORIGINAL PAGE IS  
OF POOR QUALITY

is shown in Table 2. The junction box will be prewired from the terminal strips to the output connectors of the SDAS prior to delivery to the site. Five conductor terminals will be provided for each sensor input. Either two, three, or four conductor (18 gauge) and shield will be connected between the sensors and the junction box depending on the interface characteristics of the sensors. Figure 5 illustrates the sensor-to-junction-box interconnections for each of the approved sensors.

#### Junction Box/SDAS Interface Cables

ERDA will provide and install the junction box/SDAS interface cables.

#### Site Data Acquisition Subsystem

The Site Data Acquisition Subsystem (SDAS) location at each demonstration project will be selected by the site contractor and shall be specified in the ISPI for approval.

SDAS Location -- The SDAS, Figure 5, shall be mounted by the site contractor in a central position with respect to the solar energy system sensors. It shall be located in an indoor environment having temperature limits between 32°F and 100°F and relative humidity limits of 5-80% without condensation. The SDAS shall be located to minimize contamination by elements such as dust or other pollutants. To the extent possible, the SDAS shall be located in an area that minimizes the variations in temperature, relative humidity, and vibration to the SDAS. The SDAS shall be located in an area easily accessible for installation and maintenance.

SDAS Mounting -- The SDAS shall be mounted in accordance with the installation drawings supplied by ERDA. The mounting space required for the SDAS is dependent on the model as shown in Figure 6. Either unit will weigh approximately 70 pounds. The SDAS shall be wall mounted using dimensions in Figure 6 both top and bottom. Either Molly bolts, wood screws, or bolt/nut combination shall be used.

Table 2. Typical Wire Run List for J-Box Terminal Connection

DATE _____								
SITE <u>IIG</u>			WIRE LIST <u>XXXXXXA</u>			SHEET <u>X</u> OF <u>XX</u>		
SENSOR NUMBER	REF. MEAS. NUMBER	SENSOR CONNECTION	SENSOR/J-BOX WIRE COLOR	TERMINAL STRIP NO.	INTERNAL FROM	JUMPER TO	SDAS CHANNEL	LEVEL
T100	T100	PED	RED	TB1-6			2	LO
		WHITE*	CLEAR	TB1-7			2	HI
		WHITE*	BLACK	TB1-9			2	3RD
			SHIELD	TB1-8S				SHIELD
	TD100L	YELLOW*	BLACK	TB2-4			4	3RD
		YELLOW*	CLEAR	TB2-4			4	3RD
		BLUE	RED	TB2-1			4	LO
			SHIELD	TB2-3S				SHIELD
TD100	TD100H	RED	RED	TB2-2			4	HI
		WHITE*	BLACK	TB2-5			4	3RD
		WHITE*	CLEAR	TB2-5			4	3RD
			SHIELD	TB2-3S				SHIELD
W100	W100	1	RED	TB1-15			3	+5 VDC
		2	CLEAR	TB1-12			3	HI
		3	GREEN	TB1-11			3	LO
		4	BLACK	TB1-14			3	GND
	I001		SHIELD	TBL-13S				SHIELD
		B	RED	TB3-2			7	HI
		A	BLACK	TB3-1			7	LO
			SHIELD	TB3-3S				SHIELD
D001	D001	G	RED	TB11-5			31	+5 VDC
		E	CLEAR	TB11-2			31	HI
		F	BLACK	TB11-1			31	LO/GND
			SHIELD	TB11-3S				SHIELD
EP101	EP101	2	RED	TB13-2			34	HI
		1	BLACK	TB13-1			34	LO
			SHIELD	TB13-3S				SHIELD
			RED	TB2-10			8	+5 VDC
F300	F300	1	RED	TB2-10			8	HI
		2	CLEAR	TB3-7			8	LO/GND
		3	BLACK	TB3-6	TB3-6**	TB2-9**	8	LO/GND
			SHIELD	TB3-8S				
V001	V001	A	RED	TB9-2			25	HI
		B	BLACK	TB9-1			25	LO
			SHIELD	TB9-3S				SHIELD
			RED	TB11-2			31	HI
W400	W400	1	BLACK	TB11-1			31	LO
		2	SHIELD	TB11-3S				SHIELD
			RED	TB14-15			39	+3.6 VDC
			BLACK	TB14-14			39	GND
RH001	RH001	BROWN	CLEAR	TB14-12			39	HI
		PURPLE	GREEN	TB14-11			39	LO
		YELLOW	SHIELD	TB14-13S				SHIELD
		GREEN	RED	TB5-15			15	5 VDC
D101	D101	RED 1	BLACK	TB5-14			15	GND
		BLACK 3	BLACK	TB5-14			15	LO/GND
								HI
		YELLOW 2	CLEAR	TB5-12			15	

\*EITHER WIRE

\*\*JUMPER ADDED PRIOR TO SHIPMENT






Figure 6. Site Data Acquisition Subsystem

to mount the unit depending on the characteristics of the mounting surface. The SDAS shall be mounted between two feet and four feet above floor level measured from the bottom of the SDAS.

#### SDAS Telephone Interface

ERDA will arrange for the telephone installation required for the SDAS. The SDAS shall interface with a standard Bell System CBS Data Access Arrangement (DAA), Series 5 or later, or equivalent. The DAA shall be located within three feet of the SDAS on the same side of wall. The DAA connection with the SDAS shall be performed by ERDA. The site contractor shall provide a standard 120 VAC three (3) wire receptacle for power to the coupler.

#### SDAS Electrical Interface

The SDAS interfaces with 110-125V, 60 Hertz, 1 phase, .3 amp service. A standard 3 wire interface (safety ground, power and return) with a standard power cord and twist lock connector shall be provided on the SDAS. A 120 VAC three pin twist lock outlet (actual receptacle should be NEMA Part Numbers L6-15R, 250V, 15 amps for Mod I and L5-15R, 120V, 15 amps for Mod II) shall be provided by the site contractor and located within six feet of the SDAS.