



Airspace Technology Demonstration II (ATD-2)

American Airlines CLT Ramp Training RTC/RMTC

NEXTGEN


September 8, 2017

Vicki Dulchinos & Savvy Verma

Agenda

Training Topic	Duration
A. Overview of ATD-2 & RTC/RMTC	30 Min
B. Interface Details: Upper Status Bar: (Map Features, Notifications)	30 Min
C. Interface Details: Flight Strip and Flight Menu	30 Min
D. Data Exchange and Integration	30 Min
E. Metering Modes, and Tactical Scheduler Advisories	1 Hour
F. Interactive Exercises on all the above	1 Hour
	Total 4 Hours

Field Demo Partners




Concept Overview – Users




Overview video online at: <http://aviationsystemsdivision.arc.nasa.gov/research/tactical/atd2.shtml>

Nutshell of ATD-2 (Phase 1 of 3)



3T Data Exchange & Integration


- Integrated Arrival/Departure/Surface (IADS)
- Onramp to the overhead stream (TFDM with IDAC)
- New data elements shared between FAA & Industry
- Real-time dashboard for planning and awareness



Surface modeling, scheduling & metering

- Surface modeling uses nodes and heuristics to model surface operations
- Trajectory based model of airport operations that allows predictive capacity estimation and creating a schedule
- Metering is required when there is a demand and capacity imbalance

Data Exchange and Integration




What does ATD-2 bring to AA Ramp Control?

- ATD-2 as a system connects AA Ramp tower with CLT ATC-T, TRACON and ZDC
- Information exchange between AA CLT Ramp and Tower (STBO) in real time will improve shared situational awareness among all users.
- ATD-2 fuses data from 12-13 feeds including TBFM, Flight Stats, Flight Hub, ASDE-X, and different SWIM feeds that has improved the quality of data used to drive the systems
- ATD-2 improves transparency of information
 - e.g. Wheels-up time provided to pilot are now visible to ramp controllers.
 - AA Ramp can see ATC-T displays in observer mode and vice versa
- ATD-2 tools allow automation to suggest gate hold times based on demand and capacity imbalance for the purpose of metering

How to Access ATD-2 system?


Switch to ATD-2 Display

- Pushing the source button will bring up the menu
- Clicking on the second button from right on the menu shown on the screen switches between Aerobahn and ATD2




ATD-2 Desktop

(From this Desktop: Use MFD menu to access My Desktop)



ATD-2 Desktop

(Use MFD menu to access My Desktop)



ATD-2 Desktop

(Select My Desktop from MFD Menu)

Select
→
“My
Desktop”

The screenshot shows a dark green background with the text "ATD2" in large, bold, white and red letters. A white menu box is overlaid on the left side, listing several options. A red arrow points from the text "Select 'My Desktop'" to the "My Desktop" option in the menu. The menu options are:

- My Desktop
- CLT Roof Camera 1
- CLT Roof Camera 2
- OSI Camera 1
- Remote Desktop Tower
- Remote Desktop TMC
- Remote Desktop RM
- Remote Desktop Ramp North
- Remote Desktop Ramp East
- Remote Desktop Ramp South
- Remote Desktop Ramp West

Logos for the Federal Aviation Administration, NATCA, Charlotte-Douglas International Airport, and American Airlines are visible in the background.

My Desktop


(Click on NASA Icon to open My Desktop Menu)



Click
NASA
Icon

My Desktop


(Select RTC)




Ramp Sector Maps

Separate Default View for Each RTC Sector

North



East





South



West




Agenda

Training Topic	Duration
A. Overview of ATD-2 & RTC/RMTC	30 Min
 B. Interface Details: Upper Status Bar: (Map Features, Notifications)	 30 Min
C. Interface Details: Flight Strip and Flight Menu	30 Min
D. Data Exchange and Integration	30 Min
E. Metering Modes, and Tactical Scheduler Advisories	1 Hour
F. Interactive Exercises on all the above	1 Hour
	Total 4 Hours


User Profile

Save as a Unique Username




User Profile

Load an Existing Profile



Map Options


Choose Time to Display on Strip



- P-Time: Airline scheduled departure time (default setting)
- EOBT (Earliest Off Block Time): updated departure time provided by the airline
- TOBT (Target Off Block Time): generated by the Metering Tool

Map Options


Gate Conflict Settings



Open the Gate Conflict Settings Menu to configure when to display gate conflicts on RTC


Gate Conflict Alerting

- Gate conflict Alerting:
The arrival icon as well as gate number are displayed in magenta
- Click on icon or gate number to draw “tether” line between them
- Gate conflict alerting logic: gates blocked by a heavy type aircraft are also shown as gate conflict
- Yellow gate number indicates arrival is On



Map Options



Bloom Icon Upon Hover



Bloom Icon Upon Hover: select this option to enable “bloom” of icon or strip when hovering with mouse cursor

Map Options

Show Near Arrival Count



Select Show Near Arrival Count to display the Near Arrival Count Box next to the departure count boxes on bottom right side of the RTC display.

Flight & Hold Lists

The screenshot displays an airport operations software interface. At the top, there's a 'User Profile' and 'Map Options' section with a time of 16:50:00. Below this is a 'NEW 11 TIME BASED METERING 0015' status bar with various control buttons like 'Set', 'View 1', 'View 2', 'View 3', 'Zoom In', 'Zoom Out', 'Reset View', 'Rotate Left', and 'Rotate Right'. The main area is a map of the airport with various flight call signs and taxi times overlaid on the runways. Three pop-up windows are visible: 'Departures (-)' for runway 18L/36R, 'Departures (-)' for runway 18C/36C, and 'Arrivals (-)'. A 'Holds (-)' window is also present. A yellow callout box points to the 'Departures' windows, stating: 'Eastbound and Westbound Flight Lists and Hold Lists Opened by clicking on Runway Count boxes'. Another yellow callout box points to the 'Arrivals' window, stating: 'Near Arrival List'. A third yellow callout box points to the runway count boxes at the bottom right, stating: 'Runway Count and Near Arrivals Click these to open lists'. The bottom right corner shows a status bar with 'Arrivals 3', 'Eastbound 4/0', and 'Westbound 4/0'.


Seq #	Callsign	Taxi Time	Dest
1	RFA4160	7:00	RIC
2	JJA5119	0:17	MYR
3	EDV3678	15:00	LGA
4	PDT4935	15:30	LYH

Seq #	Callsign	Taxi Time	Dest
1	JJA5123	28:15	DAY
2	AAL1988	6:00	ALB
3	JJA5533	01:17:00	CHO
4	JJA5615	2:00	AVL

Callsign	Gate	Est. ON
JJA5457	E16	16:10
JJA5063	E6	16:12
PDT4876	E35A	16:49

Map Options

Reset-Increase-Decrease Strip Font



- Reset strip font (to default font size)
- Increase strip font size
- Decrease strip font size

Notifications

Notification Window

Click here to acknowledge Yellow alert

Click here to open the Notification Window


The screenshot shows a software interface with a map and a notifications window. The notifications window is open, displaying a list of events. A yellow alert is highlighted in the list. A red arrow points to the 'NEW 11' indicator in the status bar, and another red arrow points to the 'Notifications' window title bar.

Reported	Event Type	Description	Event Start	Event End	Details
8/16/17 1345	TMI	APREQ to DFW	8/16/17 1345	8/16/17 1345	Expired
8/16/17 1300	TMI	APREQ to ORD	8/16/17 1015	8/16/17 1300	Expired
8/16/17 1107	TMI	APREQ to DCA	8/16/17 1100	8/17/17 0130	INCL IET...
8/16/17 1052	TMI	APREQ to FWR	8/16/17 1045	8/17/17 0130	INCL IET...
8/16/17 1037	TMI	APREQ to LGA	8/16/17 1030	8/17/17 0130	INCL IET...
8/16/17 0949	Airport	North	8/16/17 0949		
8/16/17 0949	Airport	N_Normal	8/16/17 0949		
8/16/17 0949	Airport	VMC	8/16/17 0949		
8/16/17 0818	Ramp	RAMP OPENED	8/16/17 0818		
8/16/17 0818	Metering Mode	TIME BASED METERING	8/16/17 0800		
8/16/17 0818	Airport	VMC	8/16/17 0800	8/16/17 0949	
8/16/17 0818	Airport	S_Normal	8/16/17 0800	8/16/17 0949	
8/16/17 0818	Airport	South_Sim	8/16/17 0800	8/16/17 0949	

- Notification Window opened here shows entire list of notifications with the new notifications highlighted in yellow
- Click anywhere in the list to acknowledge yellow alerting
- Same notifications and alerts also shown on STBO Client


RTC Upper Status Bar

Set Views- Zoom/Rotate/Reset View



- Set the zoom level by using the mouse scroll wheel on the map or use the zoom in and zoom out buttons shown above to incrementally zoom
- Use the rotate Left and Right buttons to rotate the map
- Once the view is configured, use the set view buttons to save up to three different views and then toggle between those set views


RTC Upper Status Bar Search



Search for call sign, flight number, destination airport, or departure fix. Search result marked with yellow circle.

RTC Upper Status Bar

Runway Utilization-Ramp Status-Metering Mode





Runway Utilization


Ramp Status

Metering Mode

Agenda


Training Topic	Duration
A. Overview of ATD-2 & RTC/RMTC	30 Min
B. Interface Details: Upper Status Bar: (Map Features, Notifications)	30 Min
 C. Interface Details: Flight Strip and Flight Menu	 30 Min
D. Data Exchange and Integration	30 Min
E. Metering Modes, and Tactical Scheduler Advisories	1 Hour
F. Interactive Exercises on all the above	1 Hour
	Total 4 Hours

RTC Flight Strips



RTC

Solid if Tracked, Hollow if no Track




Flight Strips and Persisted Targets

Select to Drag & Drop and Spin

- Flight strips and persisted targets may be relocated and reoriented on the display, deselect strip to remove any tether lines
- Flight strips or icons, once selected, have a white circle drawn to indicated selectable area.


Click inside circle
to drag/drop

Click outside
circle to "spin"




Click here to
drag/drop

Click here
to "spin"



Right Click Mouse Menu

Next Logical Action



Use right click mouse menu to Open Flight Menu, Handoff, or Hold.
Also use right click menu to select “next logical action”:

- Hold
- Pushback
 - Undo pushback
 - Undo Proceed to Spot
 - Proceed to Spot
 - Return to gate

Right click Menu: Pushback-Proceed or Hold:

After Pilot Calls Ready

After Pilot Calls Ready to Push:

Pushback: A

-Right Click Menu, select Pushback

After Spool Up, Proceed: B

-Click engine icon


-Or Right click menu, select proceed

Aircraft icon displayed: C

-Solid icon if track, hollow if track is not available


OR

Hold at gate: Use right click menu to hold, count up timer appears




Departure Flight Data

AAL1477
8738 W
ESTRR-IAH
1705
816 13536C



- Current sector ownership is automatically transferred.
- Use Handoff feature on right click menu to deliberately handoff sector ownership.
- For example, in the case of handing off (taking back) control of a flight from ground back to ramp sector

Arrival Flight Data




Mouse over or select target to view arrival time and time since On

- Arrivals are green
- Arrivals become grey discs after they become inactive at the gate, click on the grey disc to view flight data.
- Once there is an In time, the arrival may be relocated on the map

Flight Menu

Make Updates to Flight Data


Open the Flight Menu using double click on flight or from right click menu to make updates to flight information.



Flight Menu

Surface Data Updates


Click here to open each option menu to make changes to hardstand, spot, gate or runway, then apply



Flight Menu

Hardstand


Choose West or North hardstand or Clear to remove hardstand assignment, then apply.



Hardstand Assignment

From Flight Menu

Hardstand assignment places yellow box around the flight



Departures: Assign a hold to apply the count up timer in hardstand
Arrivals: A red count up timer automatically provided in hardstand

Flight Menu

Gate Assignment on RTC

- Recommend use for A Concourse Only
- This change is local to RTC/RMTC, the update is not made on ASCENT/ Gate Manager

The screenshot displays the Flight Menu interface for flight AAL848 (A319) departing from KWEEN-NAS. The 'Gate' field is set to B14, which is highlighted with a red box. A 'Select Gate' dialog box is open, showing a grid of gates across five terminals (A, B, C, D, E). A red arrow points from the 'B14' field to the 'B14' gate in the dialog.

Flight Menu Details:

- Flight: AAL848 A319 NA
- SURFACE: Hardstand: Clear, Bypass: Clear, Gate: B14, Spot: 235, Runway: 36R
- DEPARTURE DETAILS: P-Time: 1715, EOBT: 1715, TOBT: 1652, TMAT: 1655, APREQ: EDCT: MIT: Departure fix: KWEEN, Previous fix:
- METERING STA: Exempt from
- FLIGHT STATUS: Priority Flight, Flight Cancelled
- OPERATIONAL: Normal, Inactive

Select Gate Dialog:

Terminal A				
A1	A2	A2A	A3	A4
A5	A6	A7	A8	A9
A10	A11	A12	A13	

Terminal B				
B1	B2	B3	B4	B5
B6	B7	B8	B9	B10
B11	B12	B13	B14	B15
B16				

Terminal C				
C2	C3	C4	C5	C6
C7	C8	C9	C10	C11
C12	C13	C14	C15	C16
C17	C18	C19		

Terminal D				
D1	D2	D3	D4	D5
D6	D7	D8	D9	D10
D11	D12	D13		


Terminal E				
E1	E2	E3	E4	E5
E5A	E6	E7	E8	E9
E10	E11	E12	E13	E14
E14A	E14B	E15	E16	E16A
E17	E18	E19	E20	E21
E22	E23	E24	E25	E26
E27	E28	E29	E30	E31
E32	E33	E34	E35A	E35B
E35C	E36	E38A	E38B	E38C

Buttons: Apply, Cancel

Flight Menu

Spot Assignment


- Click on spot to open the Select Spot menu
- Select new spot, then apply



Flight Menu

Update Runway Assignment


- Click on runway to open Select Runway menu
- Select Operational Necessity checkbox
- Select new runway, then apply



Flight Menu

Update Runway Assignment

- Flight strip updates to new color, with green highlight to indicate the change was made



Flight Menu

Departure Details


- View details for the flight here: EOBT, TOBT, and TMAT
- If applicable then Traffic Management Initiatives (TMI) times will also be shown here: APREQ/CFR, EDCT, and MIT
- The current departure fix is shown here, as well as the previous fix if there was an update to the departure fix



Flight Menu

Status Details

- Select Exempt from Metering to remove this flight from metering
 - GA and Military are exempted automatically
 - Internationals will have to be manually exempted
- Flight Status: Select Priority Flight or Flight Cancelled to update the flight status
- Operational Status: Normal is the default, but Inactive Temporarily may be chosen to temporarily remove flight from metering




Priority and Canceled Flight

Assigned from Flight Menu



Canceled flight
Red X Watermark



Priority flight
Green Border

Flight Menu

Scratch Pad Entry-Return to Gate-Remove Icon

- Type text into the scratchpad field, then apply
- Return to Gate and Remove Icon are greyed out until necessary
 - Return to Gate: will be available if departure flight is already off the gate, select here and apply to move flight back to gate
 - Remove Icon (greyed out), only available if the departure flight has been cancelled or arrival is in inactive state, select here then apply to permanently remove the icon

Flight Menu

AAL1719 A320 FLL

SURFACE
Hardstand: Clear
Bypass: Clear
Gate: C6
Spot: 24S
Runway: 36R

DEPARTURE DETAILS
P-Time: 1724
EOBT: 1717
TOBT: 1720
TMAT:
APREQ:
EDCT:
MIT:
Departure fix: ICONS
Previous fix:

METERING STATUS
 Exempt from metering


FLIGHT STATUS
 Priority Flight
 Flight Cancelled

OPERATIONAL STATUS
 Normal
 Inactive Temporarily

SCRATCH PAD
Scratchpad
Entry goes here

STRIP
 Return To Gate
Remove Icon

Apply Cancel



Arrival Flight Menu


- Move To Gate option is not available (grey) until IN message
- May assign Mike Charlie Bypass (see next slide)





Arrival Flight Menu

Mike Charlie Bypass

- Assign Mike Charlie Bypass on arrival flights
 - Places MC designation on flight to show intent to use Mike Charlie Bypass



Agenda

Training Topic	Duration
A. Overview of ATD-2 & RTC/RMTC	30 Min
B. Interface Details: Upper Status Bar: (Map Features, Notifications)	30 Min
C. Interface Details: Flight Strip and Flight Menu	30 Min
 D. Data Exchange and Integration	 30 Min
E. Metering Modes, and Tactical Scheduler Advisories	1 Hour
F. Interactive Exercises on all the above	1 Hour
	Total 4 Hours

Data Exchange

- Data Exchange and sharing between CLT Tower and AA Ramp is foundational to Scheduling and Metering
- Improves Situational Awareness among decision makers
- Allows automated exchange of information and less reliance on phone calls
- Allows for collaboration between different kind of users
- Twelve ATD2 Shadow sessions at CLT lab have captured more than dozen data exchange items between tower and ramp
- Data exchange generates a notification for the users in their respective system

Data Exchange and Integration

ATC-T to Ramp

- Airport Config & Runway Utilization
- MIT
- EDCTs
- APREQ/Call For Release (CFR)
- Departure Fix Closures
- Ground Stop
- Runway Closures

Ramp to ATC-T



- Taxi for Operational Necessity
- Cancellations
- Ramp Closure
- Metering Information
- Pushback & Surveillance

Gate Conflicts & LOB/ LTD

Data Exchange and Integration

Runway Utilization

Runway Configuration and Utilization



Tower/STBO Client



Ramp RTC/ RMTC


Data Exchange and Integration

MIT

New "ICONS" Fix Miles-in-Trail of 15

NEW 11

15 MIT ICONS 2015-0712




Ramp RTC/ RMTc

Tower/STBO Client


Data Exchange and Integration

EDCT Flights

EDCT Flights



Tower/STBO Client




EDCT aircraft that is currently within time window of ± 5 min

Data Exchange and Integration

APREQ/Call For Release (CFR)Scheduling


APREQ on RTC

- Notification on RTC for the APREQ/CFR



Reported	Event Type	Description	Event Start	Event End
2/8/17 1808	AIRPORT	JFK APREQ	2/8/17 1800	2/9/17 ...
2/8/17 1701	FIX	LGA 15 MIT	2/8/17 1650	2/9/17 ...
2/8/17 1630	FIX	DCA OPEN	2/8/17 1515	2/8/17 ...
2/8/17 1624	AIRPORT	EWR APREQ	2/8/17 1615	2/9/17 ...
2/8/17 1600	FIX	ORD OPEN	2/8/17 1515	2/8/17 ...
2/8/17 1100	FIX	LGA APREQ	2/8/17 1115	2/8/17 ...

- APREQ showing on the strip




Prior to scheduling of CFR



After scheduling of CFR



Scheduled APREQ on STBO Client

- APREQ Time shown on STBO Client Timeline after scheduled



Cancel APREQ or Reschedule

- To cancel or reschedule an APREQ release time
 - Right click on Timeline datablock
 - Click “Cancel APREQ”
 - Begin the APREQ process again
- RTC will show APREQ on the flight strip when the time has been cancelled



Data Exchange and Integration

Departure Fix Closures

Departure Fix Closures

NEW 11 Closure JOJJO 1755-0712

Closed Dep Fix with CDR Fix selected

```

— AAL436 DFW BOBZY->CHOPN D2
— JIA5275 E36
— JIA5066 LGA BARMY E36 APREQ E:2324
— AAL1692 C10
— AAL435 DFW BOBZY->CHOPN B10
20 — PDT4791 LYH GANTS E35A
— JIA5387 ORF BARMY E30
— AAL101 B16
— JIA5221 TYS BOBZY->CHOPN E31
— AAL2006 B3
— AAL1722 SEA BOBZY->CHOPN C10
15 — N606PS VNY KILNS UNK
— JIA5232 E38C
    
```

Tower/STBO Client

Closed Dep Fix with no CDR Fix selected

Data Exchange/Integration

```

JIA5098
CRJ9 E
KILNS-MKE
P1830
E11 24536C
    
```

Ramp RTC/ RMTc

Data Exchange and Integration

Ground Stops

Ground Stop BWI on RTC

with Notification




Reported	Event Type	Description	Event Start	Event End
3/14/17 1736	TMI	GROUND STOP at BWI	3/14/17 1736	
3/14/17 1730	TMI	GROUND STOP REMOVED BWI	3/14/17 1723	
3/14/17 1700	TMI	OPEN LGA	3/14/17 1659	
3/14/17 1700	TMI	OPEN BWI	3/14/17 1659	
3/14/17 1700	TMI	OPEN BOS	3/14/17 1659	
3/14/17 1601	TMI	GROUND STOP REMOVED SNA	3/14/17 1456	3/14/17...

Data Exchange and Integration

Runway Closures

Runway Closure on RTC



Data Exchange and Integration

Runway Change for Operational Necessity

Flight Menu

Update Runway Assignment

- Click on runway to open Select Runway menu
- Select Operational Necessity checkbox
- Select new runway, then apply

Before runway change

After runway change

Flight Menu

AAL848 A319 NAS

SURFACE
Hardstand: Clear
Bypass: Clear
Gate: B14
Spot: 23S
Runway: **36R**

DEPARTURE DETAILS
P-Time: 1715

METERING STATUS
 Exempt from metering

SCRATCH PAD

Select Runway


Runway can only be changed due to operational necessity. Once you click Apply both here AND in the main Flight Menu dialog, the runway cannot be changed again with this tool.

Operational Necessity

18C	18L
18R	23
36C	36L
36R	5

Apply Cancel

Taxi For Operational Necessity (TFON) on STBO Client




Data Exchange and Integration


Cancellations

Cancellations

Initiated from RTC Flight Menu



Ramp RTC/ RMTC



Ramp RTC/ RMTC

All; Results: 841 total. 17:58 GMT

Close [Icons] Search

Flight ID	Dest	Origin	AC Type	Rwy	RwyOpNec	Rwy Time	Flight Status	Gate	Gate Time	Spot	Spd
PDT4955	AVL	CLT	DH3	E36C		E14/18:55	Scheduled_Out	E38B	E14/18:40	S24	E14/
PDT4968	HTS	CLT	DH3	36C		14/17:35	Enroute_Dep	E34	14/17:15	S24	14/1
PDT4968	CLT	HTS	DH8C	E36L			Scheduled_In	E12		S9W	
PDT4972	CLT	ROA	DH3	36R		14/14:21	In	E38B	14/14:27	S29	14/1
PDT4974	TRI	CLT	DH3	36C		14/17:20	Enroute_Dep	E38A	14/16:59	S24	14/1
PDT4974	CLT	TRI	DH8C	E36L		E14/19:26	Scheduled_In	E12	E14/19:36	S9W	E14/
PDT4976	HTS	CLT	DH8C	E36C			Scheduled_Out	E38A		S24	
PDT4982	AVL	CLT	DH8C	E36C			Scheduled_Out	E38B		S24	
PDT4983	CLT	AVL	DH8C	E36L			Scheduled_In	E4		S9W	
RPA3454	IAH	CLT	E170	E36C		E14/18:40	Scheduled_Out	A12	E14/18:25	S12S	E14/
RPA3474	EWR	CLT	E170				Cancelled	A13			
RPA4402	CLT	BNA	E170	36L		14/16:15	In	C5	14/16:23	S9W	14/1


Tower/STBO Client

Data Exchange and Integration

Ramp Closure

Ramp Closure

From RMTC: Update Ramp Status



Ramp RTC/ RMTC

Ramp Open



Ramp Closure Pending



Ramp Closed




Tower/STBO Client
Ramp RTC/ RMTC

Data Exchange and Integration

Metering

Ramp sets the Metering Mode from Tools Menu (RMTC)



Metering Mode Icon

Displayed Top Right of Window

- **No Metering :**



- No time-based advisories are displayed
- Hold lists are available on RTC/RMTC

- **Sequence-based metering:**



- This is provided primarily for legacy backward compatibility
- This is how ATD-2 allows the count-based metering that CLT has previously called “departure sequencing”
- Requires selection of a queue size on RMTC
- Hold lists are available on RTC/RMTC

- **Time-based metering:**





- This is the new tactical surface metering ATD-2 is adding which leverages time-based-metering & ration-by-schedule principles
- The time-based pushback advisory is for individual aircraft using trajectory based predictions & scheduling algorithms
- Both pushback and recommended hold times advisories are available on RTC/RMTC

Data Exchange and Integration

Gate Conflicts

Gate Conflict




Data Exchange/Integration

Data Exchange and Integration

Long On Board /Lengthy Taxi Delay

Long On Board/Lengthy Taxi Delay



Data Exchange and Integration

Review of Data Exchange on Flight Strips

Review of TMI Flight Notification

AAL1864 A319 E
KILNS-DCA
APREQ
D12 27 18L P1916

← APREQ

AAL1864 A319 E
KILNS-DCA
A2100
D12 27 18L P1916

← APREQ
with
Scheduled
Time

- When a flight has a TMI, the TMI detail will be displayed on the flight strip with a blinking yellow text box. ***Click on flight to acknowledge this alert**
- APREQ on strip: this flight is waiting to be scheduled. *try not to release a flight until it has a scheduled time
- Required to acknowledge again after scheduled APREQ
- **APREQ flights will always get a gate hold recommendation, meant to guide the pushback of the flight to meet FAA controlled time (TMI)**

As an alert, these will all blink when they first appear.

*It is important to acknowledge any alerting (blinking yellow or red) alerts so that if the TMI is updated, new alerts can be easily noticed.

EDCT Flight Notification

AAL1864 A319 E
KILNS-DCA
E2230
D12 27 18L P1916



EDCT

- EDCT flights will always get a gate hold recommendation, meant to guide the pushback of the flight to meet FAA controlled time (TMI)

AAL1864 A319 E
KILNS-DCA
E2340Q
D12 27 18L P1916



EDCT & APREQ

- EDCT & APREQ shown together
APREQ will trump EDCT once negotiated

As an alert, these will all blink when they first appear.

*It is important to acknowledge any alerting (blinking yellow or red) alerts so that if the TMI is updated, new alerts can be easily noticed.

MIT, Departure Fix Closure, CDRs and Airport Closures

```
AAL1864 A319 E  
KILNS-DCA  
M20  
D12 27 18L P1916
```

← MIT

```
AAL1864 A319 E  
KILNS-DCA  
D12 27 18L P1916
```

← Departure Fix
Closed

```
AAL1864 A319 E  
KILNS-DCA  
D12 27 18L P1916
```

← Departure Fix
Updated

```
AAL1864 A319 E  
KILNS-DCA  
D12 27 18L P1916
```

← Destination
Airport Closed
(Ground Stop)


As an alert, these will all blink when they first appear.

*It is important to acknowledge any alerting (blinking yellow or red) alerts so that if the TMI is updated, new alerts can be easily noticed.

APREQ and EDCT

Hold Recommendation

APREQ flights with a scheduled Call For Release (CFR) and EDCT flights will always have a recommended gate hold time



TMAT or Spot Time on APREQ and EDCT

If a flight has an APREQ or EDCT, then after pushback the TMAT or Spot Time is displayed in yellow highlighting as an alert that this TMAT is a function of the scheduled APREQ or EDCT. Beyond spot, APREQ displayed



APREQ and EDCT flights

Hardstand Release Advisory

Departures with Metering, APREQ and EDCTs get a TMAT/Spot Time

They have a release timers in the hardstand





Hardstand Assignment

From Flight Menu - Departures



Agenda

Training Topic	Duration
A. Overview of ATD-2 & RTC/RMTC	30 Min
B. Interface Details: Upper Status Bar: (Map Features, Notifications)	30 Min
C. Interface Details: Flight Strip and Flight Menu	30 Min
D. Data Exchange and Integration	30 Min
 E. Metering Modes, and Tactical Scheduler Advisories	 1 Hour
F. Interactive Exercises on all the above	1 Hour
	Total 4 Hours

Metering Modes and Icons

Displayed Top Right of Window



No Metering :

- No time-based advisories are displayed
- Hold lists are available on RTC/RMTC



Departure Sequencing-based metering:

- This is provided primarily for legacy backward compatibility
- This is how ATD-2 allows for the count-based metering that CLT has previously called “departure sequencing”
- Requires selection of a queue size on RMTC
- Hold lists are available on RTC/RMTC



Surface Time Based metering:

- This is the new tactical surface metering ATD-2 is adding which leverages time-based-metering & ration-by-schedule principles
- The time-based pushback advisory is for individual aircraft using trajectory based predictions & scheduling algorithms
- Both pushback and recommended hold times advisories are available on RTC/RMTC

Surface Time Based Metering (STBM)


Flight Grouping and EOBTs

- The metering tool algorithm places flights in Groups based on the quality of their EOBTs, and how far they are from current time, updates to EOBT are received at regular intervals
 - Uncertain Group
 - Planning Group
 - Ready Group
 - Out Group
 - Taxi Group
 - Queue Group
- Each group may have different rules for prediction for scheduling, metering and display
- Taxi-time prediction is included in the algorithm to assess transit times and buffers are included to handle congestion
- Given aircraft groups, the scheduler calculates TTOT, TMAAT and TOBT. Order of consideration is based on operation, aircraft groups, priority and exempt status


Advisories

(After Pilot Calls for Pushback)

- Advisories are present only if Metering is on and there is sufficient demand
- **After** the pilot calls for pushback, the Advisory (in cyan) will recommend: A, B or C
- If a hashtag is displayed, click on hashtag to generate the advisory
- If a “PUSH” advisory is displayed, then pushback recommended by the scheduler, make pushback entry using right click menu
- If a recommended hold time, then use right click menu to hold for n minutes





Uncertain Group

Group	Definition	RTC display
<p>Is Flight Ready?</p> <p>Uncertain</p>	Flights with poor quality EOBT or (EOBT – current time) > 10 min	<p>Click on hashtag to put flight in ready group and reveal advisory</p> 
<p>Click Hashtag</p> <p>Planning</p>	Flights within 10 min of EOBT (i.e., EOBT – current time <= 10 min)	
Ready	Flights that have called in ready for pushback	
Out	Flights that are in pushback state	
Taxi	Flights that are cleared for taxi	
Queue	Flights waiting in the runway queue	





Note: Flights with hashtag can not be put on hold. Must click hashtag to get advisory

Planning Group

Group	Definition	RTC display
Uncertain	Flights with poor quality EOBT or (EOBT – current time) > 10 min	
Planning	Flights with good quality EOBT (and within 10 minutes of EOBT)	 Or 
Ready	Flights that have called in ready for pushback	
Out	Flights that are in pushback state	
Taxi	Flights that are cleared for taxi	
Queue	Flights waiting in the runway queue	






Ready Group

Group	Definition	RTC display
Uncertain	Flights with poor quality EOBT or (EOBT – current time) > 10 min	
Planning	Flights with good quality EOBT (and within 10 minutes of EOBT)	 Or 
Ready	Flights that have called in ready for pushback	
Out	Flights that are in pushback state	
Taxi	Flights that are cleared for taxi	
Queue	Flights waiting in the runway queue	



Out-Taxi-Queue

Group	Definition	RTC display
Uncertain	Flights with poor quality EOBT or $(EOBT - \text{current time}) > 10 \text{ min}$	
Planning	Flights within 10 min of EOBT (i.e., $EOBT - \text{current time} \leq 10 \text{ min}$)	
Ready	Flights that have called in ready for pushback	
Out	Flights that are in pushback state	
Taxi	Flights that are cleared for taxi	
Queue	Flights waiting in the runway queue	


Metering Groups

Group	Definition	RTC display		
Uncertain	Flights with poor quality EOBT or (EOBT – current time) > 10 min			
Planning	Flights within 10 min of EOBT (i.e., EOBT – current time <= 10 min)		Or	
Ready	Flights that have called in ready for pushback		Or	
Out	Flights that are in pushback state			
Taxi	Flights that are cleared for taxi			
Queue	Flights waiting in the runway queue			

Metering Advisories

PUSH Phraseology

- I. IF the flight has a **PUSH** advisory
“AAL705, pushback approved, expect 18C”
Use right click menu to enter pushback.
Engine symbol appears to indicate spool up




Advisories

Hold

- I. IF Flight has a Recommended Hold (**4 min**)
“AAL705, hold 4 minutes for metering”
(Use right click menu to select Pushback)
- II. Red border appears and timer begins to count down to zero **note: the time may jump from the rounded advisory time to a specific count-down time when locked in*

Timer color will change to yellow when two minutes remaining
- III. When timer counts down to zero, if able, contact flight to give pushback approval
“AAL705, pushback and proceed to spot 9”
(Use right click menu to select pushback)
- IV. If count down goes past zero, then an extra 5 minutes count down will be provided with blinking **PUSH** to allow extra time to pushback



Advisories

Add Extra Hold


- If count down goes past zero, then an extra 5 minutes count down will be provided to give additional time
- *If needed, to prevent flight from being placed into the uncertain group (hashtag), time may be added to the hold
- Use the right click mouse menu to add 2, 5, or 10 minutes to the hold time
 - » Five minutes added to hold countdown timer




Target Movement Area Entry Times

Metering v/s APREQ/EDCT Flights

When in Surface Time Based Metering, the TMAT or Spot Time is displayed on flight after Pushback





If a flight has an APREQ or EDCT, then after pushback the TMAT is displayed in yellow highlighting as an alert that this TMAT is a function of the scheduled APREQ or EDCT. Beyond spot, APREQ displayed



Expected Pilot Procedures

- Metering
 - “AAL705, hold 4 minutes for metering”
- APREQ Flights with wheels-up time
 - “AA 235 you have a wheels-up time of 1230 to LGA, hold for 10 min”
 - OR check if the flight got it’s wheels-up time before proceeding to spot
- EDCT Flights
 - “AA 795 you have an EDCT or wheels up time of 1330 to EWR, hold for 40 min” or send to hard stand
- In Hardstand
 - Advisory available
 - “AA 898, you will be released from hardstand in 7 minutes”
 - Advisory not available : use current day procedures
- Dep Fix Closure (at gate when possible)
 - “AA 267, Contact Clearance delivery for new route, call when ready for push”

Agenda

Training Topic	Duration
A. Overview of ATD-2 & RTC/RMTC	30 Min
B. Interface Details: Upper Status Bar: (Map Features, Notifications)	30 Min
C. Interface Details: Flight Strip and Flight Menu	30 Min
D. Data Exchange and Integration	30 Min
E. Metering Modes, and Tactical Scheduler Advisories	1 Hour
 F. Interactive Exercises on all the above	 1 Hour
	Total 4 Hours

Exercises

- How to access RTC
- Pushback, taxi
- Undo pushback, undo taxi
- Flight Menu
 - Surface updates (gate, spot, runway update)
 - Status updates (Exempt, Priority, Cancel, inactive temp)
 - Scratchpad, return to gate (move to gate for arrival)
- Notifications, open panel and acknowledge
- Advisories
 - Push, hold, undo hold
 - add time to hold

Extra Slides

Hashtag Flight

If the flight is in the Uncertain Group, it will have a hashtag in place of the advisory

- Click on the hashtag to get the “instant advisory” (Either PUSH or a recommended hold time)

*If the hashtag is clicked on by mistake, it is important to use the right click mouse menu to put the flight back into the “unready” group. This places a hashtag back on the flight.

- If a hold is recommended, use right click menu to hold, and a countdown timer is displayed showing amount of time remaining for the recommended hold

