




PLM WORLD®

The Voice of Siemens PLM Software Users Worldwide

Parametric Modeling in the CAE Process: Creating a Family of Models




Christopher Brown

NASA

Kennedy Space Center

SIEMENS

<http://plmworld.org/>






Introduction

- This Presentation meant as an example
 - Give ideas of approaches to use
 - The significant benefit of PARAMETRIC geometry based modeling
- The importance of planning before you build
- Showcase some NX capabilities
 - Mesh Controls
 - Associativity
 - Divide Face
 - Offset Surface



Typical Electrical Enclosure






Notice the Back Panel

Back Panel holds components and has coupled vibration response


Back Panel often acts as an "amplifier" when resonant



Top View




Multiple Configurations




Cabinets in the ML are varied in shape and size


PANEL AND DOOR ARE NOT SHOWN IN THIS VIEW



PANEL AND DOOR ARE NOT SHOWN IN THIS VIEW



PANEL AND DOOR ARE NOT SHOWN IN THIS VIEW





Vibe Lab Test Article


Cabinets mounted on wire rope isolators to shaker table






Typical Rack Components

Interested in developing qualification curves for assembled racks AND individual components to test separately





Another Test Setup






3D Solid Geometry From Vendor

- Many vendors provide this data.
- Take advantage of it.
- In this case not used.


Cad geometry can easily be mid-surfaced.

“Dumb” CAD geometry can be parameterized (made “smart”) with Synchronous Modeling in NX






First Sketch and Extrude






Initial Simplified Cabinet



Front




Sketch for
Back Panel

Back




Sketch for Back Panel

Dimension from corners to standoff location



We will use this rectangle to create Back Panel




Cabinet Back

All features are still associative to the master part



Create "Wall" for Mounting

Perform "Offset Surface" to create "wall" that cabinet is mounted too. This is needed to apply base excitation.








Divide Face

Entire face
selectable

Divisions
selectable



Before

Divide through entire box!


After

"Wall"
surface




Create and Section Back Panel

Rectangle created by "Divide Face" is used to create associative "Offset Surface" to create Back Panel




Sketch on face to divide Back Panel at DIN rail locations





Create Standoffs



Associative "curves" from corner to corner used to mesh 1D elements (bar or beam)





Create Isolators to Wall


Associative "curves" from corner to corner
used to mesh 1D elements (bar or beam)



Associative "curve" to
mesh 1D elements
(RBE)




Wall Structure






Back Panel Mesh Controls







Mesh Controls

Keeps each mesh consistent and "tidy"



Number on Edge






Final Cabinet



Front Panel Removed




Multiple Cabinets



36x30x10

48x36x10

Extreme Example



12x10x6



Conclusion


- Reminder
 - This only had to be done once!
 - Can be used for any cabinet in that “family”
- Saves a lot of time if pre-planned
- Allows re-use in the future



PLM WORLD®

The Voice of Siemens PLM Software Users Worldwide

Thank You!



Siemens PLM Connection 2011

Las Vegas, NV

May 2-5

SIEMENS

<http://plmworld.org/>

