

NASA Technical Memorandum 100645

The Computational Structural Mechanics Testbed Data Library Description

**(NASA-TM-100645) THE COMPUTATIONAL
STRUCTURAL MECHANICS TESTBED DATA LIBRARY
DESCRIPTION (NASA) 137 p CSDL 20K**

N89-13810

**G3/39 Unclass
0177648**

Compiled by Caroline B. Stewart

October 1988

NASA

National Aeronautics and
Space Administration

Langley Research Center
Hampton, Virginia 23665-5225

Preface

The purpose of this manual is to document the datasets created and used by the Computational Structural Mechanics (CSM) Testbed software system. A description of each dataset including its form, contents, and organization is presented.

Periodically, updates to this manual will be released which describe new datasets that are created by new Testbed processors or changes to existing datasets.

The contents of this manual were compiled by Caroline B. Stewart of Analytical Services and Materials, Inc. NASA TM-83181 entitled *SPAR Data Set Contents* by Sally Cunningham, October 1981, was the starting point for this manual. Contributors include:

NASA Langley

Sue Bostic
Ronnie E. Gillian
William H. Greene
Norman F. Knight, Jr.
Jonathan Ransom
Olaf O. Storaasli

Planning Research Corporation

Christine G. Lotts
Steven C. Macy
Susan L. McCleary
Sharon S. Paulson

Analytical Services and Materials, Inc.

Mohammad A. Aminpour

Awesome Computing, Inc.

Andrea L. Overman
Eugene L. Poole

Lockheed Palo Alto Research Laboratory

Charles R. Rankin
Marc E. Regelbrugge
Gary M. Stanley
Phillip Underwood
Mary A. Wright

<u>Update Log</u>	<u>Date</u>
TM-100645 initial release	October, 1988

1.0 Description of CSM Testbed Datasets

Descriptions of the datasets created and used by the Testbed processors are given, ordered alphabetically by dataset name (see Table 1-1). Each nominal dataset name involves four components referred to as NAME1, NAME2, NAME3, and NAME4. NAME1 and NAME2 are alphanumeric names with a maximum of four characters each. NAME3 and NAME4 are integers.

Several standard dataset forms are used by nearly all of the Testbed processors. Four such dataset forms are designated TABLE, SYSVEC, ELDATA, and ALPHA. TABLE is a generalized dataset form for the storage of any type of data. Data such as node-point position coordinates and nodal temperatures are stored in TABLE format. SYSVEC is a special case of the TABLE form. SYSVEC is used primarily to represent the displacements and rotations at all points in a structure, and the forces and moments acting on all joints. This form is also used for diagonal mass matrices. ELDATA is a dataset form used to represent certain categories of data bearing a one-to-one relationship with structural elements of a given type, such as element pressure or temperature loads. The ALPHA dataset form is used to store lines of alphanumeric text, such as static load case titles.

The contents of most of the datasets may be viewed logically as two-dimensional tables, where NI is the first dimension, or column-size, and NJ is the second dimension, or row-size. Data are written to the Testbed global database as named records in nominal datasets, with a record length of NI*NJ data items. If the dataset is blocked, each block is written as one nominal record. The NJ parameter (row-size) is stored in a Testbed record as the matrix dimension parameter. The default record name used by the currently installed Testbed processors is "DATA".

Most datasets contain data of only a single type: integer, single precision real, double precision real, or alphanumeric. These are indicated by type codes 0, -1 or 1, -2 or 2, and 4, respectively. Alphanumeric data are packed four characters to a machine word.

THIS PAGE LEFT BLANK INTENTIONALLY.

2.0 Dataset Contents

The content of each Testbed dataset is described in this chapter. The dataset description includes dataset name, content, size, and format. The processor which creates each dataset is also identified.

THIS PAGE LEFT BLANK INTENTIONALLY.

ALTR.BTAB.2.4

Created by the ALTREF subprocessor of processor TAB

NJ = Number of alternate reference frames

NI = 12

Type = single precision real

Contents of each entry:

1. a_{11}	} Components of a coordinate transformation matrix
2. a_{21}	
3. a_{31}	
4. a_{12}	
5. a_{22}	
6. a_{32}	
7. a_{13}	
8. a_{23}	
9. a_{33}	
10. X_o	} Location of origin of alternate reference frame given in global coordinates
11. Y_o	
12. Z_o	

Formula:

$$\begin{pmatrix} X_a \\ Y_a \\ Z_a \end{pmatrix} = \begin{bmatrix} a_{11} & a_{12} & a_{13} \\ a_{21} & a_{22} & a_{23} \\ a_{31} & a_{32} & a_{33} \end{bmatrix} \begin{pmatrix} X_g \\ Y_g \\ Z_g \end{pmatrix} + \begin{pmatrix} X_o \\ Y_o \\ Z_o \end{pmatrix}$$

coordinates in
coordinates in
alternate reference frame
global reference frame

PRECEDING PAGE BLANK NOT FILMED

AMAP..ic2.isize

ic2 = Parameter reflecting the cost of equation solution given a factored system matrix. Computed in processor TOPO.

isize = The maximum number of submatrices involved during the factorization process.

Created in processor TOPO and used by INV to guide factorization of system matrices.

NJ = total number of joints in the model

Type = integer

The purpose of this dataset is to furnish compact information describing the location of each submatrix in the "active" upper triangle of the system matrix as each joint is eliminated. During factorization, the active upper triangle is held in the work array S(JDF, JDF, *isize*). The pointers in AMAP..ic2.isize point to JDF by JDF submatrices in this array. The dataset consists of one or more records with the default record size of 1792 words. A joint group is included for each joint in the model. Each record contains the following:

JOINTS - The number of joint groups contained in this record. A joint group is not allowed to span a record boundary.

Repeated JOINTS times:

JNT - The number of the current joint.

CONRNG - The number of submatrices including the diagonal in the upper triangle for the current joint as it is being eliminated.

CONNECT(CONRNG-1) - A list of column positions for each of the submatrices in the JNT row.

SUBMAP (CONRNG * (CONRNG + 1)/2) - Contains a pointer into the work array, S, for each submatrix in the active upper triangle.

APPL.FORC.iset.1

iset = Load set

Created in processor AUS.

NI = maximum number of active degrees of freedom per joint

NJ = total number of joints in the model

Type = single precision real

SYSVEC-format dataset. A SYSVEC dataset has NJ equal to the number of joints in the model and NI equal to the number of active (unconstrained) degrees of freedom per joint. When these datasets are manipulated by a processor, they are expanded to six degrees of freedom per joint by subroutine PUP. SYSVEC-format datasets frequently have multiple blocks. The meaning of the block number varies depending on the particular dataset. In static analyses the block number indicates the load case. In eigenvalue problems, the block number indicates the eigenvector.

Contents:

Each entry contains applied forces and moments on that joint in each active direction.

APPL.MOTI.iset.1

iset = Load set

Created in processor AUS.

SYSVEC format. See APPL.FORC.iset.1.

Contents:

Each entry contains applied motions on that joint in each active direction.

BA.BTAB.2.9

Created from E21 section properties in processor TAB

NJ = Number of entries

NI = 31

Type = single precision real

Contents of each entry:

For a description of the section property input for the E21 element, see Section 4.1.3.15 of the CSM Testbed User's Manual.

- | | |
|---------------------------|--|
| 1. Element type indicator | 17. Number of points at which stresses
are to be calculated |
| 2. Not used | |
| 3. Not used | 18. y_{11} |
| 4. I_1 | 19. y_{12} |
| 5. α_1 | 20. y_{21} |
| 6. I_2 | 21. y_{22} |
| 7. α_2 | 22. y_{31} |
| 8. a | 23. y_{32} |
| 9. f | 24. y_{41} |
| 10. f_1 | 25. y_{42} |
| 11. z_1 | 26. b_1 |
| 12. z_2 | 27. t_1 |
| 13. θ | 28. b_2 |
| 14. q_1 | 29. t_2 |
| 15. q_2 | 30. b_3 |
| 16. q_3 | 31. t_3 |

BC.BTAB.2.11

Created from E23 section properties in processor TAB

NJ = Number of entries

NI = 6

Type = single precision real

Contents of each entry:

1. Cross-sectional area of axial element
 2. Cross-sectional area of axial element
 3.)
 4.)
 5.)
 6.)
- Not used.

BUCK.EVAL.nset.ncon

nset = Set identifier

ncon = Constraint case

Created in processor EIG

NJ = 1

NI = Number of eigenvalues

Type = single precision real

Contents:

Buckling eigenvalues corresponding to each eigenvector in BUCK.MODE.*nset.ncon*.

BUCK.MODE.*nset.ncon*

nset = Set identifier
ncon = Constraint case

Created in processor EIG.

SYSVEC format. See APPL.FORC.*iset.1*.

Contents:

Each block of data contains an eigenvector (buckling mode shape) corresponding to an eigenvalue stored in BUCK.EVAL.*nset.ncon*.

CASE.TITL.i^{set}.1

i^{set} = Load set

Created in processor AUS.

Number of blocks = Number of load cases in this load set

Type = alphanumeric

Contents:

Each block contains the title for the corresponding load case.

CEM.SPAP.jdf2

jdf2 = square of the number of active degrees of freedom per joint

Created in processor M.

A Testbed sparse matrix format system matrix. See K.SPAP.jdf2.

Contents:

The unconstrained system consistent mass matrix considering only the structural and nonstructural distributed mass associated with the elements.

CON..*ncon**ncon* = Constraint case

Created by CON subprocessor in processor TAB

NJ = Number of joints

NI = 1

Type = integer

Contents:

Each entry contains an integer representing the joint reference frame number and constrained components for that joint. This integer is interpreted as a bit pattern with two bits allocated for each joint degree of freedom and the joint reference frame number stored in the leading bits. For each joint degree of freedom the bit pattern 00 indicates that component is free, the pattern 01 indicates that component is constrained to be zero, and the pattern 10 indicates that a non-zero value of this component will be applied using the APPL.MOTI.*iset.1* dataset.

For example:

A joint with components 1, 2, 3 and 5 constrained to zero and JREF = 7 (0111₂) would have the integer 28949₁₀ stored according to the following binary bit pattern:

JREF number	Joint Motion Components					
	6	5	4	3	2	1
0...0111	00	01	00	01	01	01

Component 1 (constrained)	=	1 ×	1 =	1
Component 2 (constrained)	=	1 ×	4 =	4
Component 3 (constrained)	=	1 ×	16 =	16
Component 4 (unconstrained)	=	0 ×	64 =	0
Component 5 (constrained)	=	1 ×	256 =	256
Component 6 (unconstrained)	=	0 ×	1024 =	0
JREF number = 7	=	7 ×	4096 =	+ 28 672
Integer stored for this joint	=			28 949

CSMP.FOCS.1.1

Contains integer input for Processor CSM1 (see CSM Testbed User's Manual Section 14.1 for a definition of terms).

NI = 33
 NJ = 1
 Type = Integer

Contents of each record:

1. NNPE, Number of nodes per element (3, 4, or 9)
2. IOPT, Element option: 0 for E33 or E43 elements; 1-7 for experimental element options 1-7
3. NRINGS, Number of rings of *elements* (4 or 9 node) around hole
4. NSPOKES, Number of radial spokes of *nodes* normal to hole boundary (must be a multiple of 8)
5. Translational constraints along the $x = 0$ edge of the panel.
6. Rotational constraints along the $x = 0$ edge of the panel.
7. Translational constraints along the $y = 2 * (B_E + B_S)$ edge of the panel.
8. Rotational constraints along the $y = 2 * (B_E + B_S)$ edge of the panel.
9. Translational constraints along the $x = A_l$ edge of the panel.
10. Rotational constraints along the $x = A_l$ edge of the panel.
11. Translational constraints along the $y = 0$ edge of the panel.
12. Rotational constraints along the $y = 0$ edge of the panel.
13. Translational constraints at the corner (0,0)
14. Rotational constraints at the corner (0,0)
15. Translational constraints at the corner $(0, 2 * (B_E + B_S))$
16. Rotational constraints at the corner $(0, 2 * (B_E + B_S))$
17. Translational constraints at the corner $(A_l, 2 * (B_E + B_S))$
18. Rotational constraints at the corner $(A_l, 2 * (B_E + B_S))$
19. Translational constraints at the corner $(A_l, 0)$
20. Rotational constraints at the corner $(A_l, 0)$
21. Translational constraints on stiffeners at $x = 0$
22. Rotational constraints on stiffeners at $x = 0$
23. Translational constraints on stiffness at $x = A_l$

CSMP.FOCS.1.1 (concluded)

24. Rotational constraints on stiffeners at $x = A_I$
25. IWALL, Panel section property flag (NSECT for panel skin)
26. JWALL, Stiffener section property flag (NSECT for stiffeners)
27. IREF, Material reference frame for panel skin
28. JREF, Material reference frame for stiffeners
29. NELX, Number of elements (4 or 9 node) between $0 < x < \frac{(A_I - A)}{2}$
30. NELE, Number of elements (4 or 9 node) from panel edge to outside stiffener; between $0 < y < B_E$
31. NELBS, Number of elements (4 or 9 node) between interior stiffeners; between $B_S < y < [B_E + B_S - \frac{A}{2}]$
32. NELS, Number of elements (4 or 9 node) across height of stiffener; if NELS = 0, there are no stiffeners
33. IFILL, Flag to fill in hole: 0=No fill-in, 1=Fill-in

CSMP.FOCS.1.2

Contains floating point input for processor CSM1 (see CSM Testbed User's Manual Section 14.1 for a definition of terms).

NI = 10

NJ = 1

Type = single precision real

1. A , Length of a side of the central square region; $A < 2B_S$
2. D_{HOLE} , Diameter of hole. $D_{HOLE} < A$
3. Local x coordinate of the center of the hole relative to the Point O
4. Local y coordinate of the center of the hole relative to the Point O
5. Local z coordinate of the center of the hole relative to the Point O
6. RAT, Mesh grading factor. For RAT = 0, element rings will be of nearly equal size. As RAT is increased to a value of one (1), the mesh becomes finer close to the hole and coarser away from the hole. RAT is only effective within the A by A square region around the hole.
7. A_l , Overall length of the panel.
8. B_E , Distance between the panel edge and an outside stiffener.
9. B_S , Distance between an outside stiffener and the inside stiffener.
10. H_S , Height of each stiffener.

DEF.xxxx.itype.nnod

xxxx = element name (e.g., E43, S81, EX97)
itype = element type number
(E21=1 thru E44=12, S41=16, S61=17, S81=18, element
implemented using an independent element processor = 0)
nnod= number of joints per element

Created in processor ELD.

NJ = Number of elements type xxxx
NI varies depending on the number of nodes in the element
Type = integer

The dataset contains NJ nominal records, NI items per record.

Contents:

1. Element number
2. Group number
3. Element number within group
4. Stress reference frame number
5. N3 of corresponding dataset xx.BTAB.N3.N4
6. N4 where xx = BA, BB, SA, . . .
7. Index of MATC entry for element material constants
8. Index of section property dataset entry for element section properties
9. Index of non-structural weight dataset entry (NSW)
10. Index of rigid link offset dataset entry (BRL)
11. Index of beam orientation dataset entry (MREF)
12. Section type code
13. Node #1
14. Node #2
15. Node #3
16. Node #4
- ⋮
- Node n

DEM.DIAG

Created in processor E.

SYSVEC format. See APPL.FORC.*iset.1*

Contents:

System mass matrix in diagonal form.

DIR.xxxx.itype.nnod

xxxx = element name (e.g., E43, S81, EX97)
itype = element type number
(E21=1 thru E44=12, S41=16, S61=17, S81=18, element
implemented using an independent element processor = 0)
nnod = number of joints per element

Created in processor ELD.

NJ = 1
NI = 20
Type = integer

Contents:

1. Number of nodes
2. Element type number
3. Number of elements of this type
4. N4 in name of dataset xx.BTAB.N3.N4 where xx is BA, BB, SA, ...
5. Length of E-file[†] entry for this element
6. Offset of the end of segment 1 from the beginning of E-file entry
7. Offset of the end of segment 2 from the beginning of E-file entry
8. Offset of the end of segment 3 from the beginning of E-file entry
9. Offset of the end of segment 4 from the beginning of E-file entry
10. Offset of the end of segment 5 from the beginning of E-file entry
11. Offset of the end of segment 6 from the beginning of E-file entry
12. Offset of the end of segment 7 from the beginning of E-file entry
13. Offset of the end of segment 8 from the beginning of E-file entry
14. Offset of the end of segment 9 from the beginning of E-file entry
15. Precision of element stiffness in segment 5 of the E-file entry;
1 = single precision, 2 = double precision
16. Number of stresses
17. Number of thermal loads
18. Number of degrees of freedom per node
19. MAJOR (=1 for beams, =2 for plates/shells, =3 for solids)
20. MINOR

[†] The term "E-file" refers to the xxxx.EFIL.itype.nnod dataset.

DISL.xxxx.is_{et}.ic_{ase}

xxxx = element name

is_{et} = load set

ic_{ase} = load case within load set

Created in processor AUS.

NJ = number of elements of this type

Type = single precision real

For 2-node elements:

NI = 6

Contents of each entry:

1. Displacement in direction 1
2. Displacement in direction 2
3. Displacement in direction 3
4. Rotation about axis 1
5. Rotation about axis 2
6. Rotation about axis 3

These displacements and rotations are relative to a reference frame, parallel to the element's reference frame, and embedded in node 2.

For E31 elements:

NI = 3

Contents of each entry:

1. Displacement of joint 2 in direction 1
2. Displacement of joint 3 in direction 1
3. Displacement of joint 3 in direction 2

For E32 elements:

NI = 6

Contents of each entry:

1. Displacement of joint 2 in direction 3
2. Rotation of joint 2 about axis 1
3. Rotation of joint 2 about axis 2
4. Displacement of joint 3 in direction 3
5. Rotation of joint 3 about axis 1
6. Rotation of joint 3 about axis 2

DISL.xxxx.isel.icasel (continued)**For E33 elements**

$$NI = 9$$

Contents of each entry:

1. Displacement of joint 2 in direction 1
2. Displacement of joint 3 in direction 1
3. Displacement of joint 3 in direction 2
4. Displacement of joint 2 in direction 3
5. Rotation of joint 2 about axis 1
6. Rotation of joint 2 about axis 2
7. Displacement of joint 3 in direction 3
8. Rotation of joint 3 about axis 1
9. Rotation of joint 3 about axis 2

For E41 elements:

$$NI = 6$$

Contents of each entry:

1. Displacement of joint 2 in direction 1
2. Displacement of joint 3 in direction 1
3. Displacement of joint 3 in direction 2
4. Displacement of joint 4 in direction 1
5. Displacement of joint 4 in direction 2
6. Displacement of joint 4 in direction 3

For E42 elements:

$$NI = 9$$

Contents of each entry:

1. Displacement of joint 2 in direction 3
2. Rotation of joint 2 about axis 1
3. Rotation of joint 2 about axis 2
4. Displacement of joint 3 in direction 3
5. Rotation of joint 3 about axis 1
6. Rotation of joint 3 about axis 2
7. Displacement of joint 4 in direction 3
8. Rotation of joint 4 about axis 1
9. Rotation of joint 4 about axis 2

DISL.xxxx.iset.icas (concluded)For E43 elements:

$$NI = 14$$

Contents of each entry:

1. Displacement of joint 2 in direction 1
2. Displacement of joint 3 in direction 1
3. Displacement of joint 3 in direction 2
4. Displacement of joint 4 in direction 1
5. Displacement of joint 4 in direction 2
6. Displacement of joint 2 in direction 3
7. Rotation of joint 2 about axis 1
8. Rotation of joint 2 about axis 2
9. Displacement of joint 3 in direction 3
10. Rotation of joint 3 about axis 1
11. Rotation of joint 3 about axis 2
12. Displacement of joint 4 in direction 3.
13. Rotation of joint 4 about axis 1
14. Rotation of joint 4 about axis 2

For E44 elements:

$$NI = 6$$

Contents of each entry:

1. Displacement of joint 2 in direction 1
2. Displacement of joint 3 in direction 1
3. Displacement of joint 3 in direction 2
4. Displacement of joint 4 in direction 1
5. Displacement of joint 4 in direction 2
6. Displacement of joint 4 in direction 3

xxxx.EFIL.itype.nnod

xxxx = element name (e.g., E43, S81, EX97)

itype = element type number

(E21=1 thru E44=12, S41=16, S61=17, S81=18, element implemented using an independent element processor = 0)

nnod = number of joints per element

Created by processor E, modified by processors EKS and GSF and by independent element processors, ESi.

NJ = Number of elements of this type

Type = mixed integer and real

Contents:

This dataset contains NJ entries, written as one entry per nominal record of mixed type data; each entry is made up of segments whose offsets from the beginning of the entry may be determined from the DIR.xxxx.itype.nnod dataset for the corresponding element type. There are two possible structures for records in this dataset: one structure is used for elements implemented in a structural element processor and a different dataset record structure is used for original SPAR elements. The two structures are described on the following pages.

For the remaining discussion of this dataset, the following definitions apply:

nen = the number of nodes

ndof = the number of degrees of freedom per element node

nee = the number of element degrees of freedom (typically $nen * ndof$)

nmt = the number of matrix terms in the upper triangle of the element matrices.

$$nmt = ndof^2 * nen * (nen + 1) / 2$$

nb = the number of stress terms; used for SPAR elements only.

nsrt = the number of matrix terms in the full stress recovery matrix for original SPAR elements.

$$nsrt = nen * ndof * nb$$

xxxx.EFIL.itype.nnod (continued)

For elements implemented using a Structural Element processor (e.g., ES1, ES5), the structure of the dataset is as follows:

Segment	Item	Length	Type	Description
1	Definition		Integ	Same as dataset DEF.<ES_NAME>.
2	Material		Real	(currently unused)
3	Geometry		Real	Element geometric parameters.
	XEO	(3,nen)		Initial element nodal coordinates in element basis.
	TEG	(3,3)		Transf. from global to current element basis.
	TEC	(3,3,nen)		Transf. from computational to element basis at element nodes.
	XGO	(3,nen)		Initial elt. nodal coords in global basis.
	TEGO	(3,3)		Transf. from global to initial element basis.
	DE	(nee)		Deformational displacements (d_e^{def}).
4	Property		Real	(currently unused)
5	Matrix	KM	Real*	Element matrix (stiffness/mass); only upper triangle of nodal blocks.
6	Aux. Storage		Real	Auxiliary storage for element developer.
7	Stress		Real	(currently unused)
8	Therm. Force		Real	(currently unused)
9	Therm. Stress		Real	(currently unused)

*The element stiffness/mass matrix, item KM in Segment 5, may be stored in either single or double precision, as specified in dataset DIR.xxxx.itype.nnod (entry 15). However, all of the other REAL data in the xxxx.EFIL.itype.nnod dataset are stored exclusively in single precision.

xxxx.EFIL.itype.nnod (continued)

For the original SPAR elements the structure of the record is as follows:

Segment	Item	Length	Type	Description
1	Definition		Integ	Same as dataset DEF.xxxx. <i>itype.nnod</i>
2	Material		Real	(currently unused)
3	Geometry		Real	Element dependent geometric parameters.
				Structural 1-D elements:
	z	1		element length
	Dij	3		coordinates of node 2 in element basis
	R	(3,3)		Transf. from global to element basis
	Q	(3,3,2)		Transf. from global to nodal basis
	X _{off}	(3,2)		Rigid link offsets
				Structural 3-node elements:
	Area	1		Element area
	x	(2,3)		Element nodal coordinates in element basis
	TEG	(3,3)		Transf. from global to element basis
	TEC	(3,3,3)		Transf. from computational to element basis at element nodes
				Structural 4-node elements:
	Area	1		Element area
	A ₁₂₃	1		Area of triangle connecting element nodes 1, 2 and 3
	A ₁₂₄	1		Area of triangle connecting element nodes 1, 2 and 4
	X ₃₄	1		Amount of warping
	X	(2,4)		Element nodal coordinates in element basis
	TEG	(3,3)		Transf. from global to element basis
	TEC	(3,3,4)		Transf. from computational to element basis at element nodes

xxxx.EFIL.itype.nnod (concluded)

Segment	Item	Length	Type	Description	
				3-d Solid elements:	
	Vol.	1		Element volume	
	x	(3,nen)		Element nodal coordinates in element basis.	
	TEG	(3,3)		Transf. from global to element basis	
	TEC	(3,3,nen)		Transf. from computational to element basis at element nodes.	
4	Property		Real	Structural 1-D elements: Same as appropriate section properties dataset (e.g., BA.BTAB.**)	
				Structural 2-D elements:	
				Section type (as used in SA.BTAB.2.13 dataset), material i.d., flexibility coefficients in upper triangular form. The flexibility matrix is transformed and rewritten as requested by processor EKS.	
				3-D solid elements:	
				Same as PROP.BTAB.2.21 dataset	
5	Intrinsic Stiffness	Km	nmt	Real	Element intrinsic stiffness matrix; only upper triangle of nodal blocks.
6	Stress	R	nsrt	Real	Full element stress recovery matrix
7	Stress	S	nb	Real	Coefficients of stress terms
8	Thermal force				(currently unused)
9	Thermal Stress Recovery				(currently unused)

ELTS.ISCT

Created in processor ELD.

NJ = Number of element types in the model

NI = 1

Type = integer

Contents:

N4 of xx.BTAB.N3.N4 where xx = BA, BC, SA, ... which contains section property information for an element type.

ELTS.NAME

Created in processor ELD.

NI = 1

NJ = Number of element types in the model

Type = alphanumeric

Contents:

Alphanumeric element name of each element used in the model.

ELTS.NNOD

Created in processor ELD.

NJ = Number of element types in the model

NI = 1

Type = integer

Contents:

The number of nodes in each element type.

ES.SUMMARY

Created by structural element processors, ESi.
Type = mixed integer, real, and character

Contents:

This dataset contains a comprehensive set of parameters which collectively describe each element type/Processor involved in the current model definition. The dataset is useful for both user query during pre/post-processing, as well as for driving the standard ES Procedure which cycles through all pertinent element Processors/types to perform analysis functions.

The following table describes the various record groups stored in dataset ES.SUMMARY.

ES.SUMMARY (concluded)

Record	Type	Length	Description
ES_C.1: <i>nsp</i>	Integ	(1)	Element displacement continuity (e.g., $1 \Rightarrow C^1$).
ES_CLAS.1: <i>nsp</i>	Char	(4)	Element class, e.g., BEAM SHELL SOLID.
ES_CNS.1: <i>nsp</i>	Integ	(1)	Constitutive option.
ES_DIM.1: <i>nsp</i>	Integ	(1)	Number of element intrinsic dimensions (1,2,3).
ES_NAME.1: <i>nsp</i>	Char	(4)	Element type name within Processor. (e.g., EX97).
ES_NDOF.1: <i>nsp</i>	Integ	(1)	Number of freedoms per element node (1:6).
ES_NEE.1: <i>nsp</i>	Integ	(1)	Number of element equations (NDOF*NEN).
ES_NEN.1: <i>nsp</i>	Integ	(1)	Number of element nodes.
ES_NIP.1: <i>nsp</i>	Integ	(1)	Number of element integration (stress) points.
ES_NORO.1: <i>nsp</i>	Integ	(1)	Nodal drilling-rotation parameter.
ES_NSTR.1: <i>nsp</i>	Integ	(1)	Number of stress components per integ. point.
ES_OPT.1: <i>nsp</i>	Integ	(1)	Element developer's option number (internal).
ES_NPAR.1: <i>nsp</i>	Integ	(1)	Number of meaningful research parameters in ES_PARS.
ES_PARS.1: <i>nsp</i>	Real	(NPAR)	Element research parameters.
ES_PROC.1: <i>nsp</i>	Char	(4)	Element Processor name (e.g., ES1, ES2, ...).
ES_PROJ.1: <i>nsp</i>	Integ	(1)	Corotational projection option.
ES_SHAP.1: <i>nsp</i>	Char	(4)	Element planform shape: TRIA QUAD.
ES_STOR.1: <i>nsp</i>	Integ	(1)	Number of entries in Segment 6 of EFIL dataset.

where *nsp* is the number of structural-element (ES) Processors active in the current model. The sequence of element Processors/types represented in this dataset corresponds to the sequence in which the elements were defined, via the DEFINE ELEMENTS command. Note that the *i*th element-Processor and element-type defined in the model would be stored in records ES_PROC.*i* and ES_NAME.*i*, respectively.

EXT.FORC

Created by procedure NL_STATIC.1.
SYSVEC format. See APPL.FORC.iset.1

Contents:

This dataset contains the external forces at any load step. If no, APPL.FORC.iset.1 dataset is defined, EXT.FORC is initialized to zero by NL_STATIC.1.

FAIL.xxxx.i.j

xxxx = element name (e.g., E43, EX97)

$i = \text{Load set (iset)}$
 $j = \text{Constraint case (ncon)}$ } for Linear static analysis

$i = \text{Load step (istep)}$
 $j = 0$ } for Nonlinear static analysis

Created by processor FPF

NJ = 1

NI = 26

Type = single precision real

The dataset is written one record per structural element. Each record contains:

1. Index of element section type
 2. Element group number
 3. Element number within group
 4. Maximum stress, σ_1
 5. Maximum stress, σ_2
 6. Maximum stress, τ_{12}
 7. Maximum strain, ϵ_1
 8. Maximum strain, ϵ_2
 9. Maximum strain, γ_{12}
 10. Tsai-Hill criterion
 11. Azzi-Tsai criterion
 12. Hoffman criterion
 13. Tsai-Wu criterion
 14. Modified Tsai-Wu criterion
 15. Maximum stress, σ_1
 16. Maximum stress, σ_2
 17. Maximum stress, τ_{12}
 18. Maximum strain, ϵ_1
 19. Maximum strain, ϵ_2
 20. Maximum strain, γ_{12}
 21. Tsai-Hill criterion
 22. Azzi-Tsai criterion
 23. Hoffman criterion
 24. Tsai-Wu criterion
 25. Modified Tsai-Wu criterion
 26. Compressive strength ratio (Shuart)
- } Evaluated at z_{min}
- } Evaluated at z_{max}

GD.xxxx.itype.nnod

xxxx = Element name

itype = Type number

(E21=1 thru E44=12, S41=16, S61=17, S81=18, element
implemented using an independent element processor = 0)

nnod = number of joints per element

Created from element definitions in processor ELD.

NJ = Number of groups

NI = 2

Type = integer

Contents of each entry:

1. Total number of elements within group
2. Cumulative total of elements in all previous groups

GSTR.E31.iset.icas

Contains stress resultants transformed to the global reference frame.

iset = Load set
icas = Load case within set

Created in processor GSF.

NJ = Number of E31 elements
NI = 11
Type = single precision real

The dataset contains NJ nominal records, NI items per record.

Contents of each record: (Note - x, y, z are in global reference frame.)

1. Group number
2. Element number within group
3. Joint #1
4. Joint #2
5. Joint #3
6. not used
7. Index of section property dataset entry for element section properties
8. Section type code
9. Tractive force in x -direction, N_x
10. Tractive force in y -direction, N_y
11. Shearing force, N_{xy}

Formulas:

$$S_x = N_x / \text{thickness}$$
$$S_y = N_y / \text{thickness}$$
$$T_{xy} = N_{xy} / \text{thickness}$$

GSTR.E32.iset.icas

Contains stress resultants transformed to the global reference frame.

iset = Load set

icas = Load case within set

Created in processor GSF.

NJ = Number of E32 elements

NI = 28

Type = single precision real

The dataset contains NJ nominal records, NI items per record.

Contents of each record:

1. Group number
2. Element number within group
3. Joint #1
4. Joint #2
5. Joint #3
6. Not used
7. Index of section property dataset entry for element section properties
8. Section type code
9. M_x Bending moment about y -axis at joint 1
10. M_y Bending moment about x -axis at joint 1
11. M_{xy} Twisting moment at joint 1
12. Q_x Transverse shear in x -direction at joint 1
13. Q_y Transverse shear in y -direction at joint 1
14. M_x Bending moment about y -axis at joint 2
15. M_y Bending moment about x -axis at joint 2
16. M_{xy} Twisting moment at joint 2
17. Q_x Transverse shear in x -direction at joint 2
18. Q_y Transverse shear in y -direction at joint 2
19. M_x Bending moment about y -axis at joint 3
20. M_y Bending moment about x -axis at joint 3
21. M_{xy} Twisting moment at joint 3
22. Q_x Transverse shear in x -direction at joint 3
23. Q_y Transverse shear in y -direction at joint 3

GSTR.E32.iset.icas (concluded)

24. M_x Bending moment about y -axis at the center
25. M_y Bending moment about x -axis at the center
26. M_{xy} Twisting moment at the center
27. Q_x Transverse shear in x -direction at the center
28. Q_y Transverse shear in y -direction at the center

Formulas:

$$\begin{aligned} S_x &= f_{4j} M_x & f_{ij} &= 1/\text{thickness for } i \text{ and } j = 1, 2, 3 \\ S_y &= f_{5j} M_y & f_{42} &= f_{52} = -f_{62} = 6/(\text{thickness})^2 \\ T_{xy} &= f_{6j} M_{xy} & f_{43} &= f_{53} = -f_{63} = -6/(\text{thickness})^2 \end{aligned}$$

GSTR.E33.iset.icase

Contains stress resultants transformed to the global reference frame.

iset = Load set

icase = Load case within set

Created in processor GSF.

NJ = Number of E33 elements

NI = 31

Type = single precision real

The dataset contains NJ nominal records, NI items per record.

Contents of each record:

1. Group number
2. Element number within group
3. Joint #1
4. Joint #2
5. Joint #3
6. Not used
7. Index of section property dataset entry for element section properties
8. Section type code
9. N_x Tractive force in x -direction
10. N_y Tractive force in y -direction
11. N_{xy} Shearing force
12. M_x Bending moment about y -axis at joint 1
13. M_y Bending moment about x -axis at joint 1
14. M_{xy} Twisting moment at joint 1
15. Q_x Transverse shear in x -direction at joint 1
16. Q_y Transverse shear in y -direction at joint 1
17. M_x Bending moment about y -axis at joint 2
18. M_y Bending moment about x -axis at joint 2
19. M_{xy} Twisting moment at joint 2
20. Q_x Transverse shear in x -direction at joint 2
21. Q_y Transverse shear in y -direction at joint 2
22. M_x Bending moment about y -axis at joint 3
23. M_y Bending moment about x -axis at joint 3

GSTR.E33.iset.icas (concluded)

24. M_{xy} Twisting moment at joint 3
25. Q_x Transverse shear in x -direction at joint 3
26. Q_y Transverse shear in y -direction at joint 3
27. M_x Bending moment about y -axis at the center
28. M_y Bending moment about x -axis at the center
29. M_{xy} Twisting moment at the center
30. Q_x Transverse shear in x -direction at the center
31. Q_y Transverse shear in y -direction at the center

Formulas:

$$\begin{aligned}
 S_x &= f_{1j}N_x + f_{4j}M_x & f_{ij} &= 1/\text{thickness for } i \text{ and } j = 1, 2, 3 \\
 S_y &= f_{2j}N_y + f_{5j}M_y & f_{42} &= f_{52} = -f_{62} = 6/(\text{thickness})^2 \\
 T_{xy} &= f_{3j}N_{xy} + f_{6j}M_{xy} & f_{43} &= f_{53} = -f_{63} = -6/(\text{thickness})^2
 \end{aligned}$$

GSTR.E41.iset.icas

Contains stress resultants transformed to the global reference frame.

iset = Load set

icas = Load case within set

Created in processor GSF.

NJ = Number of E41 elements

NI = 23

Type = single precision real

The dataset contains NJ nominal records, NI items per record.

Contents of each record:

1. Group number
2. Element number within group
3. Joint #1
4. Joint #2
5. Joint #3
6. Joint #4
7. Index of section property dataset entry for element section properties
8. Section type code
9. N_x Tractive force in x -direction at joint 1
10. N_y Tractive force in y -direction at joint 1
11. N_{xy} Shearing force at joint 1
12. N_x Tractive force in x -direction at joint 2
13. N_y Tractive force in y -direction at joint 2
14. N_{xy} Shearing force at joint 2
15. N_x Tractive force in x -direction at joint 3
16. N_y Tractive force in y -direction at joint 3
17. N_{xy} Shearing force at joint 3
18. N_x Tractive force in x -direction at joint 4
19. N_y Tractive force in y -direction at joint 4
20. N_{xy} Shearing force at joint 4
21. N_x Tractive force in x -direction at the center
22. N_y Tractive force in y -direction at the center
23. N_{xy} Shearing force at the center

GSTR.E41.iset.icas (concluded)

Formulas:

$$S_x = N_x / \text{thickness}$$

$$S_y = N_y / \text{thickness}$$

$$T_{xy} = N_{xy} / \text{thickness}$$

GSTR.E42.iset.icas

Contains stress resultants transformed to the global reference frame.

iset = Load set

icas = Load case within set

Created in processor GSF.

NJ = Number of E42 elements

NI = 33

Type = single precision real

The dataset contains NJ nominal records, NI items per record.

Contents of each record:

1. Group number
2. Element number within group
3. Joint #1
4. Joint #2
5. Joint #3
6. Joint #4
7. Index of section property dataset entry for element section properties
8. Section type code
9. M_x Bending moment about y -axis at joint 1
10. M_y Bending moment about x -axis at joint 1
11. M_{xy} Twisting moment at joint 1
12. Q_x Transverse shear in x -direction at joint 1
13. Q_y Transverse shear in y -direction at joint 1
14. M_x Bending moment about y -axis at joint 2
15. M_y Bending moment about x -axis at joint 2
16. M_{xy} Twisting moment at joint 2
17. Q_x Transverse shear in x -direction at joint 2
18. Q_y Transverse shear in y -direction at joint 2
19. M_x Bending moment about y -axis at joint 3
20. M_y Bending moment about x -axis at joint 3
21. M_{xy} Twisting moment at joint 3
22. Q_x Transverse shear in x -direction at joint 3
23. Q_y Transverse shear in y -direction at joint 3

GSTR.E42.iset.icas (concluded)

24. M_x Bending moment about y -axis at joint 4
25. M_y Bending moment about x -axis at joint 4
26. M_{xy} Twisting moment at joint 4
27. Q_x Transverse shear in x -direction at joint 4
28. Q_y Transverse shear in y -direction at joint 4
29. M_x Bending moment about y -axis at the center
30. M_y Bending moment about x -axis at the center
31. M_{xy} Twisting moment at the center
32. Q_x Transverse shear in x -direction at the center
33. Q_y Transverse shear in y -direction at the center

Formulas:

$$\begin{aligned}S_x &= f_{4j} M_x & f_{42} &= f_{52} = -f_{62} = -6/(\text{thickness})^2 \\S_y &= f_{5j} M_y & f_{43} &= f_{53} = -f_{63} = -6/(\text{thickness})^2 \\T_{xy} &= f_{6j} M_{xy}\end{aligned}$$

GSTR.E43.iset.icas

Contains stress resultants transformed to the global reference frame.

iset = Load set

icas = Load case within set

Created in processor GSF.

NJ = Number of E43 elements

NI = 48

Type = single precision real

The dataset contains NJ nominal records, NI items per record.

Contents of each record:

1. Group number
2. Element number within group
3. Joint #1
4. Joint #2
5. Joint #3
6. Joint #4
7. Index of section property dataset entry for element section properties
8. Section type code
9. N_x Tractive force in x -direction at joint 1
10. N_y Tractive force in y -direction at joint 1
11. N_{xy} Shearing force at joint 1
12. N_x Tractive force in x -direction at joint 2
13. N_y Tractive force in y -direction at joint 2
14. N_{xy} Shearing force at joint 2
15. N_x Tractive force in x -direction at joint 3
16. N_y Tractive force in y -direction at joint 3
17. N_{xy} Shearing force at joint 3
18. N_x Tractive force in x -direction at joint 4
19. N_y Tractive force in y -direction at joint 4
20. N_{xy} Shearing force at joint 4
21. N_x Tractive force in x -direction at the center
22. N_y Tractive force in y -direction at the center
23. N_{xy} Shearing force at the center

GSTR.E43.iset.icas (concluded)

24. M_x Bending moment about y -axis at joint 1
25. M_y Bending moment about x -axis at joint 1
26. M_{xy} Twisting moment at joint 1
27. Q_x Transverse shear in x -direction at joint 1
28. Q_y Transverse shear in y -direction at joint 1
29. M_x Bending moment about y -axis at joint 2
30. M_y Bending moment about x -axis at joint 2
31. M_{xy} Twisting moment at joint 2
32. Q_x Transverse shear in x -direction at joint 2
33. Q_y Transverse shear in y -direction at joint 2
34. M_x Bending moment about y -axis at joint 3
35. M_y Bending moment about x -axis at joint 3
36. M_{xy} Twisting moment at joint 3
37. Q_x Transverse shear in x -direction at joint 3
38. Q_y Transverse shear in y -direction at joint 3
39. M_x Bending moment about y -axis at joint 4
40. M_y Bending moment about x -axis at joint 4
41. M_{xy} Twisting moment at joint 4
42. Q_x Transverse shear in x -direction at joint 4
43. Q_y Transverse shear in y -direction at joint 4
44. M_x Bending moment about y -axis at the center
45. M_y Bending moment about x -axis at the center
46. M_{xy} Twisting moment at the center
47. Q_x Transverse shear in x -direction at the center
48. Q_y Transverse shear in y -direction at the center

Formulas:

$$\begin{aligned}
 S_x &= f_{1j}N_x + f_{4j}M_x & f_{ij} &= 1/\text{thickness for } i \text{ and } j = 1, 2, 3 \\
 S_y &= f_{2j}N_y + f_{5j}M_y & f_{42} &= f_{52} = -f_{62} = 6/(\text{thickness})^2 \\
 T_{xy} &= f_{3j}N_{xy} + f_{6j}M_{xy} & f_{43} &= f_{53} = -f_{63} = 6/(\text{thickness})^2
 \end{aligned}$$

GTIT.xxxx.itype.nnod

xxxx = Element name

itype = Type number

(E21=1 thru E44=12, S41=16, S61=17, S81=18, element
implemented using an independent element processor = 0)

nnod = Number of joints/element

Created from element definitions in processor ELD.

NJ = Number of groups

NI = 15

Type = alphanumeric

Contents of each entry:

15 words of title for each group; default is blanks.

INT.FORC

Created by procedure NL_STATIC_1.
SYSVEC format. See APPL.FORC.iset.1

Contents:

This dataset contains the internal forces at the current load step. At each load step, *istep*, internal forces are computed and saved in this dataset (overwriting the data from the previous load step) which is then copied into the REAC.FORC.*istep* dataset.

INV.name.ncon

name = name of the unfactored sparse format system matrix

ncon = constraint case applied during factorization

Created in processor INV.

NJ = total number of joints in the model

Type = mixed real and integer

Contains the upper triangle of the factored system matrix. For a matrix, **A**, factored into the product LDL^T , INV.A.2 dataset contains the inverse of the diagonal matrix **D** and the triangular matrix L^T stored by row for the system matrix **A** subject to constraint set 2. The dataset consists of one or more records with the default record size of 3584 words. A joint group is included for every joint in the model. Each record contains the following:

- JOINTS - The number of joint groups contained in this record. A joint group is not allowed to span a record boundary.
- INDEX(JMAX) - An array of integers pointing to the beginning of each joint group in the record. JMAX is defaulted to 50 and JOINTS must be \leq JMAX.

Repeated JOINTS times:

JNT - The number of the current joint.

NZERO - the number of active degrees of freedom at the current joint. If NZERO equals zero, the next joint group follows.

MAP(NZERO) - a list of the unconstrained degrees of freedom at the current joint.

CONRNG - the number of joints connected to the current joint at the time of its elimination.

CONNECT(CONRNG-1) - a list of all connected joints in the upper triangle of the factored matrix.

A(JDF, CONRNG, NZERO) - contains the $1/D_{ii}$ and L_{ij}^T components of the factored matrix for this joint. For each active degree of freedom (1 to NZERO), there is a vector $JDF \times CONRNG$ in length which represents a row of the factored matrix.

JDF1.BTAB.1.8

Created by the TAB processor START command.

NJ = 1

NI = 18

Type = integer

Contents:

1. Total number of joints.
2. Number of active (unconstrained) degrees of freedom per joint.
3. Number of joint translational degrees of freedom not constrained.
4.)
5.) A list of unconstrained joint degrees of freedom, filled in
6.) consecutively from position number 4; unused values are zero.
7.) Example of d.o.f. 1, 2, and 6 unconstrained:
8.) 1,2,6,0,0,0
9.)
10.)
11.) A list specifying the order of each unconstrained degree of
12.) freedom; zero if not active.
13.) Example for d.o.f. 1, 2, and 6 unconstrained:
14.) 1,2,0,0,0,3
15.)
16.)
17.) Not used.
18.)

JLOC.BTAB.2.5

Created in subprocessor JLOC of processor TAB.

NJ . . . Number of joints

NI = 3

Type = single precision real

Contents:

		J = 1, 2, . . . Number of joints	
I = 1	x_1 x_2 . . .	Rectangular coordinates	
2	y_1 y_2 . . .	of each joint in the	
3	z_1 z_2 . . .	global reference frame	

JREF.BTAB.2.6

Created by subprocessor JREF of processor TAB.

NJ = Total number of joints

NI = 1

Type = integer

Contents:

Contains the joint reference frame number for each joint, corresponding to the entry in dataset ALTR.BTAB.2.4 containing the definition of each joint reference frame.

JSEQ.BTAB.2.17

Created by subprocessor JSEQ in processor TAB or by automatic joint ordering processors.

NJ = number of joints in the model

NI = 1

Type = integer

Contents:

The j^{th} entry contains the elimination order number for joint j.

K.SPAP.jdf2

jdf2 = square of the number of degrees of freedom in the model, JDF.

Created in processor K.

NJ = total number of joints in the model

Type = single or double precision real

Contents:

Contains the assembled global stiffness matrix in the Testbed sparse matrix format. The Testbed sparse matrix format stores only the nonzero JDF by JDF submatrices in the upper triangle of the symmetric system matrix. Submatrix *i, j* is nonzero if an element connects joints *i* and *j*. A Testbed sparse matrix format dataset consists of one or more fixed length records with a default record size of 2240 words. A joint group is included for every joint in the model starting in record 1 with the first joint to be eliminated in factorization. Integer information is converted to the numeric type of the dataset before being stored in the record. Each record contains the following:

JOINTS - The number of joint groups contained in this record. A joint group is not allowed to span a record boundary.

Repeated JOINTS times:

CONRNG - The number of submatrices including the diagonal in the upper triangle for the current joint.

SUBMAP(CONRNG) - A list of joints connected to the current joint (listed first).

S(JDF, JDF, CONRNG) - The submatrices in the upper triangle of the system matrix connected to the current joint. These correspond to the joints listed in SUBMAP.

KMAP..*nsubs.ksize*

nsubs = the total number of submatrices in a sparse format system matrix
for this model

ksize = the maximum number of joints active at any time during
the assembly of the system matrix

Created in processor TOPO and used by various processors to guide the
assembly of system matrices.

NJ = total number of joints in the model

Type = integer

Contents:

The purpose of this dataset is to furnish compact information about elements connected to each joint in the model. It also defines which upper triangle submatrices will be nonzero for each joint. During assembly of a Testbed system matrix, a work area S(JDF, JDF, KSIZE) is used to hold the active submatrices. Information in the dataset shows where each piece of an elemental matrix fits in the array S. Other information in KMAP..*nsubs.ksize* shows which joint pair i, j is associated with each submatrix in S.

KMAP..*nsubs.ksize* (concluded)

The KMAP..*nsubs.ksize* dataset consists of one or more fixed length records with a default record size of 1792. A joint group is included for each joint in the model. Each joint group contains element groups for elements connected to the joint. Each record contains the following:

JOINTS - Number of joint groups contained in this record. A joint group is not allowed to span a record boundary.

Repeated **JOINTS** times:

- JNT** - The number of the current joint
- LRNG** - Number of elements which connect to JNT and any higher numbered joints. These are elements which will contribute to the upper triangle of the system matrix.

Repeated **LRNG** times:

- NODES** - Number of nodes in the current element type
- LTYPE** - Integer number for this element type
- NSE** - Element number. For each element type, this number begins at one and increments for each element of the particular type.
- ITYPE** - Pointer into dataset NS for this element type
- NSCT** - N4 of the section property dataset name for this element type. See the ELTS.ISCT dataset.
- ISCT** - Index of section property dataset entry for element section properties.
- MAP** ($\text{NODES} * (\text{NODES} + 1) / 2$) - Location in the work area, S, where each submatrix in the elemental submatrix is to be summed. If $\text{MAP}(I) \leq 0$, then the transpose of the elemental submatrix should be summed into S.
- CONRNG** - The number of submatrices, including the diagonal, in the upper triangle for the current joint.
- CONNECT(CONRNG-1)** - A list of joints connected to the current joint.
- SUBMAP(CONRNG)** - A pointer into the work array, S, for each submatrix associated with the current joint.

LAM.OMB.nsect.1

Contains the laminate data for shell section number "nsect".

Created using AUS/TABLE

NI = 3

NJ = Number of layers

Type = single precision real

Contents of each entry:

1. Material number
2. Layer thickness
3. Layer orientation

Repeated NJ times.

LAM.O3D.nsect.1

Contains the laminate data for solid section number "*nsect*".

Created using AUS/TABLE

NI = 3

NJ = Number of layers

Type = single precision real

Contents of each entry:

1. Material number
2. Layer thickness
3. Layer orientation

Repeated NJ times.

MATC.BTAB.2.2

Created by MATC subprocessor of processor TAB.

NJ = Number of material types

NI = 10

Type = single precision real

Contents of each entry:

1. E = Modulus of elasticity
2. ν = Poisson's Ratio
3. G = shear modulus; default is $E/(2(1 + \nu))$
4. ρ = Weight per unit volume
5. α_1 = Thermal expansion coefficient, direction x
6. α_2 = Thermal expansion coefficient, direction y
7. θ = Angle between element reference frame and the
frame used for input of α_1 and α_2 .
8. }
9. } Not used.
10. }

MREF.BTAB.2.7

Created by subprocessor MREF in processor TAB.

NJ = Number of beam orientation entries

NI = 5

Type = single precision real

Contents of each entry:

Format 1 (Default)

1. Beam axis NB
2. Global axis NG
3. 1. (floating point one) if cosine between NB and NG is positive, -1. (floating point negative one) if negative
4. Cosine of angle between NB and NG
5. 1. (floating point one; indicates format = 1)

Format 2

1. X1
2. X2
3. X3
4. I 1 axis orientation
5. -1. (floating point negative one; indicating format = 2)

MSTR.E31.iset.icode

Contains stress resultants transformed to the material reference frame.

iset = Load set

icode = Load case within set

Created in processor GSF.

NJ = Number of E31 elements

NI = 11

Type = single precision real

The dataset contains NJ nominal records, NI items per record.

Contents of each record: (Note - *x, y, z* are in material reference frame.)

1. Group number
2. Element number within group
3. Joint #1
4. Joint #2
5. Joint #3
6. Not used
7. Index of section property dataset entry for element section properties
8. Section type code
9. Tractive force in *x*-direction N_x
10. Tractive force in *y*-direction N_y
11. Shearing force N_{xy}

Formulas:

$$S_x = N_x/\text{thickness}$$

$$S_y = N_y/\text{thickness}$$

$$T_{xy} = N_{xy}/\text{thickness}$$

MSTR.E32.iset.icas

Contains stress resultants transformed to the material reference frame.

iset = Load set
icas = Load case within set

Created in processor GSF.

NJ = Number of E32 elements
NI = 28
Type = single precision real

The dataset contains NJ nominal records, NI items per record.

Contents of each record:

1. Group number
2. Element number within group
3. Joint #1
4. Joint #2
5. Joint #3
6. Not used
7. Index of section property dataset entry for element section properties
8. Section type code
9. M_x Bending moment about y -axis at joint 1
10. M_y Bending moment about x -axis at joint 1
11. M_{xy} Twisting moment at joint 1
12. Q_x Transverse shear in x -direction at joint 1
13. Q_y Transverse shear in y -direction at joint 1
14. M_x Bending moment about y -axis at joint 2
15. M_y Bending moment about x -axis at joint 2
16. M_{xy} Twisting moment at joint 2
17. Q_x Transverse shear in x -direction at joint 2
18. Q_y Transverse shear in y -direction at joint 2
19. M_x Bending moment about y -axis at joint 3
20. M_y Bending moment about x -axis at joint 3
21. M_{xy} Twisting moment at joint 3
22. Q_x Transverse shear in x -direction at joint 3
23. Q_y Transverse shear in y -direction at joint 3

MSTR.E32.iset.icas (concluded)

24. M_x Bending moment about y -axis at the center
25. M_y Bending moment about x -axis at the center
26. M_{xy} Twisting moment at the center
27. Q_x Transverse shear in x -direction at the center
28. Q_y Transverse shear in y -direction at the center

Formulas:

$$\begin{aligned} S_x &= f_{4j} M_x & f_{ij} &= 1/\text{thickness for } i \text{ and } j = 1, 2, 3 \\ S_y &= f_{5j} M_y & f_{42} &= f_{52} = -f_{62} = 6/(\text{thickness})^2 \\ T_{xy} &= f_{6j} M_{xy} & f_{43} &= f_{53} = -f_{63} = -6/(\text{thickness})^2 \end{aligned}$$

MSTR.E33.iset.ibase

Contains stress resultants transformed to the material reference frame.

iset = Load set
ibase = Load case within set

Created in processor GSF.

NJ = Number of E33 elements

NI = 31

Type = single precision real

The dataset contains NJ nominal records, NI items per record.

Contents of each record:

1. Group number
2. Element number within group
3. Joint #1
4. Joint #2
5. Joint #3
6. Not used
7. Index of section property dataset entry for element section properties
8. Section type code
9. N_x Tractive force in x -direction
10. N_y Tractive force in y -direction
11. N_{xy} Shearing force
12. M_x Bending moment about y -axis at joint 1
13. M_y Bending moment about x -axis at joint 1
14. M_{xy} Twisting moment at joint 1
15. Q_x Transverse shear in x -direction at joint 1
16. Q_y Transverse shear in y -direction at joint 1
17. M_x Bending moment about y -axis at joint 2
18. M_y Bending moment about x -axis at joint 2
19. M_{xy} Twisting moment at joint 2
20. Q_x Transverse shear in x -direction at joint 2
21. Q_y Transverse shear in y -direction at joint 2
22. M_x Bending moment about y -axis at joint 3
23. M_y Bending moment about x -axis at joint 3

MSTR.E33.iset.icas (concluded)

24. M_{xy} Twisting moment at joint 3
25. Q_x Transverse shear in x -direction at joint 3
26. Q_y Transverse shear in y -direction at joint 3
27. M_x Bending moment about y -axis at the center
28. M_y Bending moment about x -axis at the center
29. M_{xy} Twisting moment at the center
30. Q_x Transverse shear in x -direction at the center
31. Q_y Transverse shear in y -direction at the center

Formulas:

$$\begin{aligned}
 S_x &= f_{1j}N_x + f_{4j}M_x & f_{ij} &= 1/\text{thickness for } i \text{ and } j = 1, 2, 3 \\
 S_y &= f_{2j}N_y + f_{5j}M_y & f_{42} &= f_{52} = -f_{62} = 6/(\text{thickness})^2 \\
 T_{xy} &= f_{3j}N_{xy} + f_{6j}M_{xy} & f_{43} &= f_{53} = -f_{63} = -6/(\text{thickness})^2
 \end{aligned}$$

MSTR.E41.iset.ibase

Contains stress resultants transformed to the material reference frame.

iset = Load set

ibase = Load case within set

Created in processor GSF.

NJ = Number of E41 elements

NI = 23

Type = single precision real

The dataset contains NJ nominal records, NI items per record.

Contents of each record:

1. Group number
2. Element number within group
3. Joint #1
4. Joint #2
5. Joint #3
6. Joint #4
7. Index of section property dataset entry for element section properties
8. Section type code
9. N_x Tractive force in x -direction at joint 1
10. N_y Tractive force in y -direction at joint 1
11. N_{xy} Shearing force at joint 1
12. N_x Tractive force in x -direction at joint 2
13. N_y Tractive force in y -direction at joint 2
14. N_{xy} Shearing force at joint 2
15. N_x Tractive force in x -direction at joint 3
16. N_y Tractive force in y -direction at joint 3
17. N_{xy} Shearing force at joint 3
18. N_x Tractive force in x -direction at joint 4
19. N_y Tractive force in y -direction at joint 4
20. N_{xy} Shearing force at joint 4
21. N_x Tractive force in x -direction at the center
22. N_y Tractive force in y -direction at the center
23. N_{xy} Shearing force at the center

MSTR.E41.iset.ibase (concluded)

Formulas:

$$S_x = N_x / \text{thickness}$$

$$S_y = N_y / \text{thickness}$$

$$T_{xy} = N_{xy} / \text{thickness}$$

MSTR.E42.iset.icas

Contains stress resultants transformed to the material reference frame.

iset = Load set
icas = Load case within set

Created in processor GSF.

NJ = Number of E42 elements
NI = 33
Type = single precision real

The dataset contains NJ nominal records, NI items per record.

Contents of each record:

1. Group number
2. Element number within group
3. Joint #1
4. Joint #2
5. Joint #3
6. Joint #4
7. Index of section property dataset entry for element section properties
8. Section type code
9. M_x Bending moment about y -axis at joint 1
10. M_y Bending moment about x -axis at joint 1
11. M_{xy} Twisting moment at joint 1
12. Q_x Transverse shear in x -direction at joint 1
13. Q_y Transverse shear in y -direction at joint 1
14. M_x Bending moment about y -axis at joint 2
15. M_y Bending moment about x -axis at joint 2
16. M_{xy} Twisting moment at joint 2
17. Q_x Transverse shear in x -direction at joint 2
18. Q_y Transverse shear in y -direction at joint 2
19. M_x Bending moment about y -axis at joint 3
20. M_y Bending moment about x -axis at joint 3
21. M_{xy} Twisting moment at joint 3
22. Q_x Transverse shear in x -direction at joint 3
23. Q_y Transverse shear in y -direction at joint 3

MSTR.E42.iset.icas (concluded)

24. M_x Bending moment about y -axis at joint 4
25. M_y Bending moment about x -axis at joint 4
26. M_{xy} Twisting moment at joint 4
27. Q_x Transverse shear in x -direction at joint 4
28. Q_y Transverse shear in y -direction at joint 4
29. M_x Bending moment about y -axis at the center
30. M_y Bending moment about x -axis at the center
31. M_{xy} Twisting moment at the center
32. Q_x Transverse shear in x -direction at the center
33. Q_y Transverse shear in y -direction at the center

Formulas:

$$\begin{aligned} S_x &= f_{4j} M_x & f_{42} &= f_{52} = -f_{62} = -6/(\text{thickness})^2 \\ S_y &= f_{5j} M_y & f_{43} &= f_{53} = -f_{63} = -6/(\text{thickness})^2 \\ T_{xy} &= f_{6j} M_{xy} \end{aligned}$$

MSTR.E43.iset.icas

Contains stress resultants transformed to the material reference frame.

iset = Load set
icas = Load case within set
Created in processor GSF.
NJ = Number of E43 elements
NI = 48
Type = single precision real

The dataset contains NJ nominal records, NI items per record.

Contents of each record:

1. Group number
2. Element number within group
3. Joint #1
4. Joint #2
5. Joint #3
6. Joint #4
7. Index of section property dataset entry for element section properties
8. Section type code
9. N_x Tractive force in x -direction at joint 1
10. N_y Tractive force in y -direction at joint 1
11. N_{xy} Shearing force at joint 1
12. N_x Tractive force in x -direction at joint 2
13. N_y Tractive force in y -direction at joint 2
14. N_{xy} Shearing force at joint 2
15. N_x Tractive force in x -direction at joint 3
16. N_y Tractive force in y -direction at joint 3
17. N_{xy} Shearing force at joint 3
18. N_x Tractive force in x -direction at joint 4
19. N_y Tractive force in y -direction at joint 4
20. N_{xy} Shearing force at joint 4
21. N_x Tractive force in x -direction at the center
22. N_y Tractive force in y -direction at the center
23. N_{xy} Shearing force at the center

MSTR.E43.iset.icas (concluded)

24. M_x Bending moment about y -axis at joint 1
25. M_y Bending moment about x -axis at joint 1
26. M_{xy} Twisting moment at joint 1
27. Q_x Transverse shear in x -direction at joint 1
28. Q_y Transverse shear in y -direction at joint 1
29. M_x Bending moment about y -axis at joint 2
30. M_y Bending moment about x -axis at joint 2
31. M_{xy} Twisting moment at joint 2
32. Q_x Transverse shear in x -direction at joint 2
33. Q_y Transverse shear in y -direction at joint 2
34. M_x Bending moment about y -axis at joint 3
35. M_y Bending moment about x -axis at joint 3
36. M_{xy} Twisting moment at joint 3
37. Q_x Transverse shear in x -direction at joint 3
38. Q_y Transverse shear in y -direction at joint 3
39. M_x Bending moment about y -axis at joint 4
40. M_y Bending moment about x -axis at joint 4
41. M_{xy} Twisting moment at joint 4
42. Q_x Transverse shear in x -direction at joint 4
43. Q_y Transverse shear in y -direction at joint 4
44. M_x Bending moment about y -axis at the center
45. M_y Bending moment about x -axis at the center
46. M_{xy} Twisting moment at the center
47. Q_x Transverse shear in x -direction at the center
48. Q_y Transverse shear in y -direction at the center

Formulas:

$$\begin{aligned}
 S_x &= f_{1j} N_x + f_{4j} M_x & f_{ij} &= 1/\text{thickness for } i \text{ and } j = 1, 2, 3 \\
 S_y &= f_{2j} N_y + f_{5j} M_y & f_{42} &= f_{52} = -f_{62} = 6/(\text{thickness})^2 \\
 T_{xy} &= f_{3j} N_{xy} + f_{6j} M_{xy} & f_{43} &= f_{53} = -f_{63} = 6/(\text{thickness})^2
 \end{aligned}$$

NDAL

Created by the TITLE command in processor TAB.

NJ = 1

Type = alphanumeric

Contents:

Library title

NODA.PRES.iset.1

iset = Load set

Created using subprocessor TABLE in processor AUS.

NJ = Number of joints

NI = 1

Number of blocks = Number of load cases in this load set.

Type = single precision real

Contents:

Each block of data contains nodal pressures for every joint in the structure. One block corresponds to one load case.

NODA.TEMP.iset.1

iset = Load set

Created using subprocessor TABLE in processor AUS.

NJ = Number of joints

NI = 1

Number of blocks = Number of load cases in this load set.

Type = single precision real

Contents:

Each block of data contains nodal temperatures for every joint in the structure. One block corresponds to one load case.

xxxx.NODE.i,j

Contains nodal values interpolated from element centroidal values.

xxxx = first word of the element value dataset name from which interpolation occurred (e.g., ESR, ESC)

i,j = the same as used in the element value dataset name

Created in processor NVAL.

NJ = Number of joints

NI is a variable determined by resets used in Processor NVAL. Default = 8

Type = single precision real

Contents:

The dataset contains one nominal record. This record contains "smoothed" nodal values interpolated from 2-D structural element centroidal values (i.e., stress resultants, strain energy, etc.).

NS

Created in processor ELD.

NJ = Number of element types present

NI = 1

Type = integer

Contents of each entry:

1. Offset of the end of segment 1 from the beginning of E-file† entry
2. Offset of the end of segment 2 from the beginning of E-file entry
3. Offset of the end of segment 3 from the beginning of E-file entry
4. Offset of the end of segment 4 from the beginning of E-file entry
5. Offset of the end of segment 5 from the beginning of E-file entry
6. Offset of the end of segment 6 from the beginning of E-file entry
7. Offset of the end of segment 7 from the beginning of E-file entry
8. Offset of the end of segment 8 from the beginning of E-file entry
9. Offset of the end of segment 9 from the beginning of E-file entry
10. Precision of element stiffness in segment 5 of the E-file entry
1 = single precision, 2 = double precision
11. Number of stress resultants per element for elements implemented using an independent structural element processor. For original SPAR elements, this position is used to indicate the number of terms used in the stress approximation. For example, for E31 elements, a three (3) is stored here; for E41 elements a five (5) is stored here. See the CSM Testbed Theory Manual for further information.
12. Number of thermal loads
13. Number of degrees of freedom per node
14. MAJOR
15. MINOR

(The contents of each entry are the same as words 6-20 of the DIR.xxxx.*itype.nnod* dataset for the element type.)

† The term "E-file" refers to the xxxx.EFIL.*itype.nnod* dataset.

OMB.DATA.1.1

Created by AUS/TABLE

Contains the material properties for the 2-D section types.

NI = 16

NJ = Number of materials

Type = Real

Contents of each entry:

1. Young's Modulus, E_1
2. Poisson's Ratio, ν_{12}
3. Young's Modulus, E_2
4. Shear Modulus, G_{12}
5. Shear Modulus, G_{13}
6. Shear Modulus, G_{23}
7. Linear Thermal Expansion Coefficient, α_1
8. Linear Thermal Expansion Coefficient, α_2
9. Weight Density (weight per unit area)
10. Longitudinal Compression Strain Allowable $(\epsilon_1)_{all}^C$
11. Transverse Compression Strain Allowable $(\epsilon_2)_{all}^C$
12. Inplane Shear Compression Strain Allowable $(\gamma_{12})_{all}^C$
13. Longitudinal Tension Strain Allowable $(\epsilon_1)_{all}^T$
14. Transverse Tension Strain Allowable $(\epsilon_2)_{all}^T$
15. Inplane Shear Tension Strain Allowable $(\gamma_{12})_{all}^T$
16. Zero-degree Lamina Compressive Strength, σ_0

Repeated NJ times.

O3D.DATA.1.1

Created using AUS/TABLE

Contains the material properties for the 3-D section types.

NI = 13

NJ = Number of materials

Type = Real

Contents of each entry:

1. Young's Modulus, E_1
2. Young's Modulus, E_2
3. Young's Modulus, E_3
4. Shear Modulus, G_{12}
5. Shear Modulus, G_{23}
6. Shear Modulus, G_{13}
7. Poisson's Ratio, ν_{12}
8. Poisson's Ratio, ν_{23}
9. Poisson's Ratio, ν_{13}
10. Weight Density (weight per unit area)
11. Linear Thermal Expansion Coefficient, α_1
12. Linear Thermal Expansion Coefficient, α_2
13. Linear Thermal Expansion Coefficient, α_3

Repeated NJ times.

PRES.xxxx.iset.icas

xxxx = Element name

iset = Load set

icas = Load case within Load set

Created in processor AUS.

NJ = Number of elements of this type

Type = single precision real

For 2-node elements:

Not Applicable.

For 3-node structural elements:

NI = 3

Contents of each entry:

1. Pressure at joint 1
2. Pressure at joint 2
3. Pressure at joint 3

For 4-node structural elements:

NI = 4

Contents of each entry:

1. Pressure at joint 1
2. Pressure at joint 2
3. Pressure at joint 3
4. Pressure at joint 4

PROP.BTAB.2.21

Created from solid section properties in processor LAU if reset SPAR = -1

NI = 31

NJ = Number of solid sections

Type = single precision real

Contents of each entry:

1. weight density (weight/unit volume)	16. a_{55}
2. a_{11}	17. a_{61}
3. a_{21}	18. a_{62}
4. a_{22}	19. a_{63}
5. a_{31}	20. a_{64}
6. a_{32}	21. a_{65}
7. a_{33}	22. a_{66}
8. a_{41}	23. linear thermal expansion coefficient, α_x
9. a_{42}	24. linear thermal expansion coefficient, α_y
10. a_{43}	25. linear thermal expansion coefficient, α_z
11. a_{44}	26. Y_{xx} , reference stress for use in stress display
12. a_{51}	27. Y_{yy} , reference stress for use in stress display
13. a_{52}	28. Y_{zz} , reference stress for use in stress display
14. a_{53}	29. Y_{xy} , reference stress for use in stress display
15. a_{54}	30. Y_{yz} , reference stress for use in stress display
	31. Y_{xz} , reference stress for use in stress display

The default values of each reference stress is 1.0.

For an orthotropic material with the 1-, 2-, and 3-directions aligned with the x -, y -, and z -directions respectively, the flexibility matrix components in terms of the engineering constants are

$$\begin{Bmatrix} \epsilon_x \\ \epsilon_y \\ \epsilon_z \\ \gamma_{xy} \\ \gamma_{yz} \\ \gamma_{zx} \end{Bmatrix} = \begin{bmatrix} \frac{1}{E_1} & -\frac{\nu_{21}}{E_2} & -\frac{\nu_{31}}{E_3} & 0 & 0 & 0 \\ -\frac{\nu_{12}}{E_1} & \frac{1}{E_2} & -\frac{\nu_{32}}{E_3} & 0 & 0 & 0 \\ -\frac{\nu_{13}}{E_1} & -\frac{\nu_{23}}{E_2} & \frac{1}{E_3} & 0 & 0 & 0 \\ 0 & 0 & 0 & \frac{1}{G_{12}} & 0 & 0 \\ 0 & 0 & 0 & 0 & \frac{1}{G_{23}} & 0 \\ 0 & 0 & 0 & 0 & 0 & \frac{1}{G_{13}} \end{bmatrix} \begin{Bmatrix} \sigma_x \\ \sigma_y \\ \sigma_z \\ \tau_{xy} \\ \tau_{yz} \\ \tau_{zx} \end{Bmatrix}$$

PROP.BTAB.2.21 (concluded)

or

$$\begin{pmatrix} \epsilon_x \\ \epsilon_y \\ \epsilon_z \\ \gamma_{xy} \\ \gamma_{yz} \\ \gamma_{zx} \end{pmatrix} = \begin{bmatrix} a_{11} & & & & & & \\ a_{21} & a_{22} & & & & & \\ a_{31} & a_{32} & a_{33} & & & & \\ a_{41} & a_{42} & a_{43} & a_{44} & & & \\ a_{51} & a_{52} & a_{53} & a_{54} & a_{55} & & \\ a_{61} & a_{62} & a_{63} & a_{64} & a_{65} & a_{66} & \end{bmatrix} \begin{pmatrix} \sigma_x \\ \sigma_y \\ \sigma_z \\ \tau_{xy} \\ \tau_{yz} \\ \tau_{zx} \end{pmatrix}$$

where

$E_1, E_2, E_3 =$ Young's moduli in 1, 2, and 3 directions, respectively.
 $\nu_{ij} =$ Poisson's ratio for transverse strain in the j -direction
 when stressed in the i -direction.

$G_{23}, G_{13}, G_{12} =$ shear moduli in the 2-3, 1-3, and 1-2 planes, respectively.

$$\frac{\nu_{ij}}{E_i} = \frac{\nu_{ji}}{E_j} \quad i, j = 1, 2, 3$$

Thus, there are three reciprocal relations that must be satisfied for an orthotropic material. Moreover, only $\nu_{12}, \nu_{13},$ and ν_{23} need be further considered since $\nu_{21}, \nu_{31},$ and ν_{32} can be expressed in terms of the first-mentioned Poisson's ratios and the Young's moduli.

PROP.BTAB.2.101

Created from shell section properties in processor LAU

NI = 40

NJ = Number of shell sections

Type = single precision real

Contents include the stiffness coefficients for a first-order transverse shear deformation theory.

Contents of each entry:

1. A_{11}	21. B_{16}
2. A_{21}	22. D_{11}
3. A_{16}	23. D_{12}
4. B_{11}	24. D_{16}
5. B_{12}	25. B_{12}
6. B_{16}	26. B_{22}
7. A_{12}	27. B_{26}
8. A_{22}	28. D_{12}
9. A_{26}	29. D_{22}
10. B_{12}	30. D_{26}
11. B_{22}	31. B_{16}
12. B_{26}	32. B_{26}
13. A_{16}	33. B_{66}
14. A_{26}	34. D_{16}
15. A_{66}	35. D_{26}
16. B_{16}	36. D_{66}
17. B_{26}	37. CS_{55}
18. B_{66}	38. CS_{45}
19. B_{11}	39. CS_{45}
20. B_{12}	40. CS_{44}

where A_{ij} are the extensional stiffness coefficients, B_{ij} are the bending-extensional coupling stiffness coefficients, D_{ij} are the bending stiffness coefficients, and CS_{ij} are the transverse shear stiffness coefficients.

PROP.BTAB.2.101 (concluded)

These stiffness coefficients relate the force and moment resultants to the middle surface strains and curvatures. That is,

$$\begin{Bmatrix} N_x \\ N_y \\ N_{xy} \\ \hline M_x \\ M_y \\ M_{xy} \end{Bmatrix} = \begin{bmatrix} A_{11} & A_{12} & A_{16} & | & B_{11} & B_{12} & B_{16} \\ A_{12} & A_{22} & A_{26} & | & B_{12} & B_{22} & B_{26} \\ A_{16} & A_{26} & A_{66} & | & B_{16} & B_{26} & B_{66} \\ \hline B_{11} & B_{12} & B_{16} & | & D_{11} & D_{12} & D_{16} \\ B_{12} & B_{22} & B_{26} & | & D_{12} & D_{22} & D_{26} \\ B_{16} & B_{26} & B_{66} & | & D_{16} & D_{26} & D_{66} \end{bmatrix} \begin{Bmatrix} \epsilon_x^o \\ \epsilon_y^o \\ \gamma_{xy}^o \\ \hline \kappa_x \\ \kappa_y \\ \kappa_{xy} \end{Bmatrix}$$

and

$$\begin{Bmatrix} Q_x \\ Q_y \end{Bmatrix} = \begin{bmatrix} CS_{55} & CS_{45} \\ CS_{45} & CS_{44} \end{bmatrix} \begin{Bmatrix} \gamma_{xz}^o \\ \gamma_{yz}^o \end{Bmatrix}$$

If reset SPAR = -1, then

$$\left. \begin{array}{l} B_{i6} = -B_{i6} \\ D_{i6} = -D_{i6} \\ D_{6i} = -D_{6i} \end{array} \right\} \text{ for } i = 1, 2, 6$$

to agree with the sign convention used by the SPAR elements.

PROP.BTAB.2.102

Created from shell section properties in processor LAU

NI = 64

NJ = Number of shell sections

Type = single precision real

Contents include the stiffness coefficients for a first-order transverse shear deformation theory.

Contents of each entry:

1. A_{11}	22. B_{66}	43. B_{66}
2. A_{21}	23. 0	44. D_{16}
3. A_{16}	24. 0	45. D_{26}
4. B_{11}	25. B_{11}	46. D_{66}
5. B_{12}	26. B_{12}	47. 0
6. B_{16}	27. B_{16}	48. 0
7. 0	28. D_{11}	49. 0
8. 0	29. D_{12}	50. 0
10. A_{22}	30. D_{16}	51. 0
11. A_{26}	31. 0	52. 0
12. B_{12}	32. 0	53. 0
13. B_{22}	33. B_{12}	54. 0
14. B_{26}	34. B_{22}	55. CS_{55}
15. 0	35. B_{26}	56. CS_{45}
16. 0	36. D_{12}	57. 0
17. A_{16}	37. D_{22}	58. 0
18. A_{26}	38. D_{26}	59. 0
19. A_{66}	39. 0	60. 0
20. B_{16}	40. 0	61. 0
21. B_{26}	41. B_{16}	62. 0
	42. B_{26}	63. CS_{45}
		64. CS_{44}

PROP.BTAB.2.102 (concluded)

where A_{ij} are the extensional stiffness coefficients, B_{ij} are the bending-extensional coupling stiffness coefficients, D_{ij} are the bending stiffness coefficients, and CS_{ij} are the transverse shear stiffness coefficients.

These stiffness coefficients relate the force and moment resultants to the middle surface strains and curvatures. That is,

$$\begin{pmatrix} N_x \\ N_y \\ N_{xy} \\ - \\ M_x \\ M_y \\ M_{xy} \\ - \\ Q_x \\ Q_y \end{pmatrix} = \begin{bmatrix} A_{11} & A_{12} & A_{16} & | & B_{11} & B_{12} & B_{16} & | & 0 & 0 \\ A_{12} & A_{22} & A_{26} & | & B_{12} & B_{22} & B_{26} & | & 0 & 0 \\ A_{16} & A_{26} & A_{66} & | & B_{16} & B_{26} & B_{66} & | & 0 & 0 \\ \hline B_{11} & B_{12} & B_{16} & | & D_{11} & D_{12} & D_{16} & | & 0 & 0 \\ B_{12} & B_{22} & B_{26} & | & D_{12} & D_{22} & D_{26} & | & 0 & 0 \\ B_{16} & B_{26} & B_{66} & | & D_{16} & D_{26} & D_{66} & | & 0 & 0 \\ \hline 0 & 0 & 0 & | & 0 & 0 & 0 & | & CS_{55} & CS_{45} \\ 0 & 0 & 0 & | & 0 & 0 & 0 & | & CS_{45} & CS_{44} \end{bmatrix} \begin{pmatrix} \epsilon_x^o \\ \epsilon_y^o \\ \gamma_{xy}^o \\ - \\ \kappa_x \\ \kappa_y \\ \kappa_{xy} \\ - \\ \gamma_{xz}^o \\ \gamma_{yz}^o \end{pmatrix}$$

If reset SPAR = -1, then

$$\left. \begin{aligned} B_{i6} &= -B_{i6} \\ D_{i6} &= -D_{i6} \\ D_{6i} &= -D_{6i} \end{aligned} \right\} \text{ for } i = 1, 2, 6$$

to agree with the sign convention used by the SPAR elements.

PROP.BTAB.2.103

Created from solid section properties in processor LAU

NI = 36

NJ = Number of solid sections

Type = single precision real

Contents include the constitute matrix for 3-D elasticity.

Contents of each entry:

1. C_{11} ,	19. C_{14}
2. C_{12}	20. C_{24}
3. C_{13}	21. C_{34}
4. C_{14}	22. C_{44}
5. C_{15}	23. C_{45}
6. C_{16}	24. C_{46}
7. C_{12}	25. C_{15}
8. C_{22}	26. C_{25}
9. C_{23}	27. C_{35}
10. C_{24}	28. C_{45}
11. C_{25}	29. C_{55}
12. C_{26}	30. C_{56}
13. C_{13}	31. C_{16}
14. C_{23}	32. C_{26}
15. C_{33}	33. C_{36}
16. C_{34}	34. C_{46}
17. C_{16}	35. C_{56}
18. C_{35}	36. C_{66}

For an orthotropic material with the 1-, 2-, and 3-directions aligned with the x -, y -, and z -directions, respectively, the stress-strain relations are:

$$\begin{Bmatrix} \sigma_x \\ \sigma_y \\ \sigma_z \\ \tau_{yz} \\ \tau_{xz} \\ \tau_{xy} \end{Bmatrix} = \begin{bmatrix} C_{11} & C_{12} & C_{13} & 0 & 0 & 0 \\ C_{12} & C_{22} & C_{23} & 0 & 0 & 0 \\ C_{13} & C_{23} & C_{33} & 0 & 0 & 0 \\ 0 & 0 & 0 & C_{44} & 0 & 0 \\ 0 & 0 & 0 & 0 & C_{55} & 0 \\ 0 & 0 & 0 & 0 & 0 & C_{66} \end{bmatrix} \begin{Bmatrix} \epsilon_x \\ \epsilon_y \\ \epsilon_z \\ \gamma_{yz} \\ \gamma_{xz} \\ \gamma_{xy} \end{Bmatrix}$$

PROP.BTAB.2.104

Created from 2-D section properties in processor LAU

NI = 13

NJ = Number of 2-D sections

Type = single precision real

Contents include the stiffness coefficients for 2-D plane elasticity.

Contents of each entry:

- | | |
|-------------|---|
| 1. C_{11} | 8. C_{23} |
| 2. C_{12} | 9. C_{33} |
| 3. C_{13} | 10. Thermal expansion coefficient, x -direction |
| 4. C_{12} | 11. Thermal expansion coefficient, y -direction |
| 5. C_{22} | 12. Weight density |
| 6. C_{23} | 13. Thickness |
| 7. C_{13} | |

For isotropic materials only, the stress-strain relations are:

$$\begin{Bmatrix} \sigma_x \\ \sigma_y \\ \tau_{xy} \end{Bmatrix} = \begin{bmatrix} C_{11} & C_{12} & C_{13} \\ C_{12} & C_{22} & C_{23} \\ C_{13} & C_{23} & C_{33} \end{bmatrix} \begin{Bmatrix} \epsilon_x \\ \epsilon_y \\ \gamma_{xy} \end{Bmatrix}$$

PLANE STRESS

$$\begin{Bmatrix} \sigma_x \\ \sigma_y \\ \tau_{xy} \end{Bmatrix} = \frac{E}{(1-\nu^2)} \begin{bmatrix} 1 & \nu & 0 \\ \nu & 1 & 0 \\ 0 & 0 & \frac{1-\nu}{2} \end{bmatrix} \begin{Bmatrix} \epsilon_x \\ \epsilon_y \\ \gamma_{xy} \end{Bmatrix}$$

PLANE STRAIN

$$\begin{Bmatrix} \sigma_x \\ \sigma_y \\ \tau_{xy} \end{Bmatrix} = \frac{E}{(1+\nu)(1-2\nu)} \begin{bmatrix} 1-\nu & \nu & 0 \\ \nu & 1-\nu & 0 \\ 0 & 0 & \frac{1-2\nu}{2} \end{bmatrix} \begin{Bmatrix} \epsilon_x \\ \epsilon_y \\ \gamma_{xy} \end{Bmatrix}$$

where E = Young's Modulus

ν = Poisson's Ratio

PROP.MASS.2.102

Created from shell section properties by processor LAU.

NI = 3

NJ = Number of shell sections

Type = single precision real

Contents include the mass coefficients.

Contents of each entry:

1. \bar{m}_0
2. \bar{m}_1
3. \bar{m}_2

where \bar{m}_0 is the translational inertia coefficient, \bar{m}_1 is the translational-rotary inertia coupling coefficient, and \bar{m}_2 is the rotary inertia coefficient. The effect of an eccentric middle surface of the shell is included in these coefficients.

PROP.MASS.2.103

Created from solid section properties by processor LAU.

NI = 1

NJ = Number of solid sections

Type = single precision real

Contents include the average mass densities.

Contents of each entry:

1. ρ

where ρ is the average mass density for the solid sections.

QJJT.BTAB.2.9

Created in processor TAB.

NJ = Number of Joints

NI = 9

Type = single precision real

Contents of each entry:

1. a_{11}
2. a_{21}
3. a_{31}
4. a_{12}
5. a_{22}
6. a_{32}
7. a_{13}
8. a_{23}
9. a_{33}

Formula:

Each entry contains a 3×3 matrix to convert global reference frame to alternate reference frame for that joint.

$$\begin{array}{ccc} \left\{ \begin{array}{c} X_a \\ Y_a \\ Z_a \end{array} \right\} & = & \begin{bmatrix} a_{11} & a_{12} & a_{13} \\ a_{21} & a_{22} & a_{23} \\ a_{31} & a_{32} & a_{33} \end{bmatrix} \begin{array}{c} \left\{ \begin{array}{c} X_g \\ Y_g \\ Z_g \end{array} \right\} \\ \\ \end{array} \\ \text{coordinates in} & & \text{coordinates in} \\ \text{alternate reference frame} & & \text{global reference frame} \end{array}$$

REAC.FORC.*istep*

istep = Load step for nonlinear static analysis

Created by procedure NL.STATIC.1.

SYSVEC format. See APPL.FORC.*iset.1*

Contents:

This dataset contains the nodal reaction forces at load step *istep*.

RESPONSE.HISTORY

Created by procedure NL_STATIC_1.

Type = mixed integer and double precision real

Contents:

This dataset contains a nonlinear response history. The user may select the nodes and degrees-of-freedom to be saved. The following table describes the various record groups stored in RESPONSE.HISTORY dataset.

Record	Type	Length	Description
COEF.DET.1:nstep	D	(1)	Coefficient of ten(10) in the stiffness determinant (i.e., $\text{det} = \text{coef_det} * 10^{(\text{exp10_det})}$)
DISP_dofi.i.1:nstep	D	(1)	Displacement <i>dofi</i> for node <i>i</i>
DISP_dofj.j.1:nstep	D	(1)	Displacement <i>dofj</i> for node <i>j</i>
ERROR.1:nstep	D	(1)	Relative energy error
EXP10.DET.1:nstep	I	(1)	Exponent of ten (10) in the stiffness determinant
FORCE_dof.i.1:nstep	D	(1)	Reaction force in <i>dofi</i> direction for node <i>i</i>
FORCE_dof.j.1:nstep	D	(1)	Reaction force in <i>dofj</i> direction for node <i>j</i>
LOAD.1:nstep	D	(1)	Load factor
LOAD_DIR.1:nstep	I	(1)	Direction of load
NEG_ROOTS.1:nstep	D	(1)	Number of negative diagonal terms in stiffness matrix
NUM_CUTS.1:nstep	I	(1)	Number of cuts in step size
NUM_ITERS.1:nstep	I	(1)	Number of iterations for current step size
PATH_INC.1:nstep	D	(1)	Path length increment
REF_ERR.1:nstep	D	(1)	Reference value of error
SIGN_DET.1:nstep	I	(1)	Sign of determinant
TOT_ITERS.1:nstep	I	(1)	Total number of iterations for current step. Will equal NUM_ITERS. <i>i</i> if NUM_CUTS. <i>i</i> = 0

RESPONSE.HISTORY (concluded)

where

nstep is the number of steps in the nonlinear analysis

dofi, dofj are degrees-of-freedom specified in NL.STATIC_1 argument list (SEL_DOFS)

i, j are nodes specified in NL.STATIC_1 argument list (SEL_NODES)

Note that the name of this dataset is an argument to the NL.STATIC_1 procedure. The name, RESPONSE.HISTORY, is the default name.

SA.BTAB.2.13

Created from shell section properties in processor TAB.

NJ = Number of entries
Type = single precision real

Contents vary according to section type:

For MEMBRANE, PLATE, ISOTROPIC or UNCOUPLED section types: NI = 43

Contents of each entry:

1. Number indicating section type		26. f_{11}	} stress coefficients
1 MEMBRANE		27. f_{21}	
2 PLATE		28. f_{31}	
3 ISOTROPIC or UNCOUPLED		29. f_{41}	
2. Pointer to entry IN MATC.BTAB.2.2 containing material constants		30. f_{51}	
3. Structural weight/area		31. f_{61}	
4. d_{11}	} flexibility coefficients	32. f_{12}	
5. d_{12}		33. f_{22}	
6. d_{22}		34. f_{32}	
7. d_{13}		35. f_{42}	
8. d_{23}		36. f_{52}	
9. d_{33}		37. f_{62}	
10. d_{44}		38. f_{13}	
11. d_{45}		39. f_{23}	
12. d_{55}		40. f_{33}	
13. d_{46}		41. f_{43}	
14. d_{56}		42. f_{53}	
15. d_{66}		43. f_{63}	
16. } thru } 25. }		Not used.	

SA.BTAB.2.13 (continued)

For COUPLED section types: NI = 43

Contents of each entry:

1. Number indicating section type	25. Number of layers
4 = COUPLED	26. f_{11}
2. Pointer to entry in MATC.BTAB.2.2	27. f_{21}
containing material constants	28. f_{31}
3. Structural weight/area	29. f_{41}
4. d_{11}	30. f_{51}
5. d_{12}	31. f_{61}
6. d_{22}	32. f_{12}
7. d_{13}	33. f_{22}
8. d_{23}	34. f_{32}
9. d_{33}	35. f_{42}
10. d_{14}	36. f_{52}
11. d_{24}	37. f_{62}
12. d_{34}	38. f_{13}
13. d_{44}	39. f_{23}
14. d_{15}	40. f_{33}
15. d_{25}	41. f_{43}
16. d_{35}	42. f_{53}
17. d_{45}	43. f_{63}
18. d_{55}	
19. d_{16}	
20. d_{26}	
21. d_{36}	
22. d_{46}	
23. d_{56}	
24. d_{66}	

flexibility
coefficientsstress
coefficients

SA.BTAB.2.13 (concluded)

For LAMINATE section types: NI = 25 + (18 times number of layers)

Contents of each entry:

1. Number indicating section type	25. Number of layers	
5 = LAMINATE	26. g_{11}^1	} stress recovery coefficients for first layer
2. Pointer to entry in MATC.BTAB.2.2 containing material constants	.	
3. Structural weight/area	.	
4. d_{11}	43. g_{36}^1	} stress recovery coefficients for second layer
5. d_{12}	44. g_{11}^2	
6. d_{22}	.	
7. d_{13}	.	} flexibility coefficients
8. d_{23}	.	
9. d_{33}	61. g_{36}^2	
10. d_{14}	62. through (25 + 18 * number of layers). Eighteen additional values of g_{ij}^{nlayer} for each successive layer.	
11. d_{24}		
12. d_{34}		
13. d_{44}		
14. d_{15}		
15. d_{25}		
16. d_{35}		
17. d_{45}		
18. d_{55}		
19. d_{16}		
20. d_{26}		
21. d_{36}		
22. d_{46}		
23. d_{56}		
24. d_{66}		

SB.BTAB.2.14

Created by subprocessor SB in processor TAB.

NJ = Number of entries

NI = 4

Type = single precision real

Contents of each entry:

1. Thickness of E44 element
2.)
3.) Not used.
4.)

SED.xxxx.i.j

Contains element strain energy density (SED) components for 2-D elements at **one or more** of the following locations: element centroid, each integration point, and each node.

xxxx = element name (e.g., EX41, EX97)

For **linear** static analysis:

i = Load set (*iset*)

j = Constraint case (*ncon*)

For **nonlinear** static analysis:

i = Load step (*istep*)

j = 0

Created by processor SED

Type = single precision real

The dataset may contain as many as 12 record groups, one record in each record group per structural element. The record name is determined by the location and the reference frame used in calculating the strain energy density. The record names, contents, and sizes are defined as follows:

- CENTROIDS** *_Sdir.ielt* SED components at the centroid of element *ielt* based on stress resultants in reference frame *dir*. Record length is the number of strain energy density components.
- INTEG_PTS** *_Sdir.ielt* SED components at each integration point of element *ielt* based on stress resultants in reference frame *dir*. The record is ordered such that all SED components at the first integration point are followed by all SED components at the second integration point, etc. Record length is equal to the number of SED components times the number of integration points.
- NODES** *_Sdir.ielt* SED components at each node of element *ielt* in reference frame *dir*. The record is ordered such that all SED components at the first node are followed by all SED components at the second node, etc. Record length is equal to the number of SED components times the number of nodes.

where *dir* indicates the stress/strain reference frame. Strain components may be computed in the element stress/strain reference frame (*dir* = 0) or in one of three alternate reference frames. For *dir* = 1, the strain *x* direction is coincident with the global *x* direction. For *dir* = 2, the strain *x* direction is coincident with the global *y* direction. For *dir* = 3 the strain *x* direction is coincident with the global *z* direction. Note that the chosen reference

frame need not be coincident with the material reference frame. For example, a record named

CENTROIDS_S1.15

will contain SED components, at the centroids, computed in the global reference frame for element number 15.

Strain energy density components are ordered: SED due to membrane stress resultants, SED due to out-of-plane bending resultants, SED due to membrane-bending coupling, SED due to transverse shear, and the total SED (the sum of the first four components).

SPLI.GEOM.isurf.nsym

isurf = surface number

$$nsym = \begin{cases} isym & \text{if } isym \geq 0; \\ |isym| + 2 & \text{otherwise.} \end{cases}$$

where *isurf* and *isym* are defined in processor SPLN (see Section 14.2 of the CSM Testbed User's Manual).

Contains minimum and maximum *x* and *y* values for the spline interpolation region within the global model.

Created in processor SPLN.

NJ = 1

NI = 4

Type = single precision real

The dataset contains NJ nominal records, NI items per record.

Contents of each record:

1. Minimum *x* coordinate
2. Maximum *x* coordinate
3. Minimum *y* coordinate
4. Maximum *y* coordinate

SPLI.INPU.isurf.nsym

isurf = surface number

$$nsym = \begin{cases} isym & \text{if } isym \geq 0; \\ |isym| + 2 & \text{otherwise.} \end{cases}$$

where *isurf* and *isym* are defined in processor SPLN (see Section 14.2 of the CSM Testbed User's Manual).

Contains the nodal *x* and *y* coordinates for the spline interpolation region within the global model.

Created in processor SPLN.

NJ = number of joints in interpolation region

NI = 2

Type = single precision real

The dataset contains NJ nominal records, NI items per record.

Contents:

		J = 1, 2, . . . Number of joints
I = 1		$x_1 \ x_2 \ \dots$ Rectangular coordinates of
2		$y_1 \ y_2 \ \dots$ joints in global reference frame

SPLI.NODI.*isurf.nsym**isurf* = surface number

$$nsym = \begin{cases} isym & \text{if } isym \geq 0; \\ |isym| + 2 & \text{otherwise.} \end{cases}$$

where *isurf* and *isym* are defined in processor SPLN (See Section 14.2 of the CSM Testbed User's Manual).

Contains the node numbers of the corresponding *x* and *y* coordinates for the spline interpolation region within the global model.

Created in processor SPLN.

NJ = number of joints in interpolation region

NI = 1

Type = integer

The dataset contains NJ nominal records, NI items per record.

Contents:

	J = 1, 2, . . . Number of joints
I = 1	J ₁ J ₂ . . . Node numbers

SPLI.MATR.isurf.nsym

isurf = surface number

$$nsym = \begin{cases} isym & \text{if } isym \geq 0; \\ |isym| + 2 & \text{otherwise.} \end{cases}$$

where *isurf* and *isym* are defined in processor SPLN (see Section 14.2 of the CSM Testbed User's Manual).

Contains the spline coefficient matrix or its inverse to be used for interpolating the specified field. If the reset parameter INV is equal to one, the dataset contains the inverse of the coefficient matrix. If INV is not equal to one, then the dataset contains the coefficient matrix.

Created in processor SPLN.

NJ = number of joints in interpolation region + *n*

NI = number of joints in interpolation region + *n*

Type = single precision real

where $n = \begin{cases} 3 & \text{if } isym = 0; \\ 2 & \text{otherwise.} \end{cases}$

The dataset contains NJ nominal records, NI items per record.

Contents:

1.	a_{11}	}	Components of a spline coefficient matrix or its inverse
2.	a_{21}		
3.	a_{31}		
⋮			
$nj.$	$a_{nj,1}$		
$nj + 1.$	a_{12}		
$nj + 2.$	a_{22}		
$nj + 3.$	a_{32}		
⋮			
$2 * nj.$	$a_{nj,2}$		
⋮			
$nj * ni.$	$a_{ni,nj}$		

$$A_{ni,nj} = \begin{bmatrix} a_{11} & a_{12} & \dots & a_{1,nj} \\ a_{21} & a_{22} & \dots & a_{2,nj} \\ \vdots & \vdots & \ddots & \vdots \\ a_{ni,1} & a_{ni,2} & \dots & a_{ni,nj} \end{bmatrix}$$

STAT.DISP.i.j

For **linear** static analysis:

i = Load set (*iset*)

j = Constraint case (*ncon*)

For **nonlinear** static analysis:

i = Load step (*istep*)

j = 0

Created in processor SSOL.

SYSVEC format. See APPL.FORC.*iset*.1.

Contents:

Each entry contains static displacements for that joint in each active direction.

STAT.REAC.i,j

For linear static analysis:

i = Load set (*iset*)

j = Constraint case (*ncon*)

For nonlinear static analysis:

i = Load step (*istep*)

j = 0

Created in processor SSOL.

SYSVEC format. See APPL.FORC.*iset*.1.

Contents:

Each entry contains static reactions for the joint constrained degrees of freedom and residual errors for the joint unconstrained degrees of freedom. There are no entries for globally constrained degrees of freedom (i.e., those declared inactive using TAB/START).

STAT.RES.iset.ncon

iset = Load set

ncon = Constraint set

Created in processor ITER.

SYSVEC format

Each entry represents the residual for the associated equation in the linear system $Ku = f$. The residual is computed using the constrained system K which is derived by applying constraint conditions to the unconstrained stiffness matrix (usually K.SPAP). This dataset is useful whenever one wants to examine the error in the computed solution u , particularly when there are fixed displacements in the problem (APPL.MOTI). See documentation for processor ITER in the User's Manual (Section 7.5).

STRN.xxxx.i.j

Contains element strain components at **one or more** of the following locations: element centroid, each integration point, and each node.

xxxx = element name (e.g., EX41, EX97)

For **linear** static analysis:

i = Load set (*iset*)

j = Constraint case (*ncon*)

For **nonlinear** static analysis:

i = Load step (*istep*)

j = 0

Created by processor ES*i* (e.g., ES1, ES2, ES5)

Type = single precision real

The dataset may contain as many as 12 record groups, one record in each record group per structural element. The record name is determined by the location and the reference frame used in calculating the strain components. The record names, contents, and sizes are defined as follows:

- CENTROIDS *_Sdir.ielt* STRAIN components at the centroid of element *ielt* in reference frame *dir*. Record length is the number of STRAIN components.
- INTEG *_PTS _Sdir.ielt* STRAIN components at each integration point of element *ielt* in reference frame *dir*. The record is ordered such that all STRAIN components at the first integration point are followed by all STRAIN components at the second integration point, etc. Record length is equal to the number of STRAIN components times the number of integration points.
- NODES *_Sdir.ielt* STRAIN components at each node of element *ielt* in reference frame *dir*. The record is ordered such that all STRAIN components at first node are followed by all STRAIN components at the second node, etc. Record length is equal to the number of STRAIN components times the number of nodes.

where *dir* indicates the stress/strain reference frame. Strain components may be computed in the element stress/strain reference frame (*dir* = 0) or in one of three alternate reference frames. For *dir* = 1, the strain *x* direction is coincident with the global *x* direction. For *dir* = 2, the strain *x* direction is coincident with the global *y* direction. For *dir* = 3 the strain *x* direction is coincident with the global *z* direction. Note that the chosen reference frame need not be coincident with the material reference frame. For example, a record named

CENTROIDS *_S1.15*

will contain strain components, at the centroids, computed in the global reference frame for element number 15.

For 2-D structural elements, strain components are typically ordered: ϵ_{xx}^o , ϵ_{yy}^o , ϵ_{xy}^o , κ_{xx} , κ_{yy} , κ_{xy} , γ_x , γ_y . Users should consult the specific element processor documentation for the strain components calculated by the specific element processor.

STRS.E21*iset.icase**iset* = Load set*icase* = Load case within set

Created in processor GSF.

NJ = Number of E21 elements

NI = 52

Type = single precision real

The dataset contains NJ nominal records, NI items per record.

Contents of each record:

1. Group number	27. α_2
2. Element number within group	28. Cross-sectional Area
3. Joint #1	29. f_1
4. Joint #2	30. f_2
5. Max. combined P/A + bending (tension)	31. z_1
6. Max. combined P/A + bending (compression)	32. z_2
7. P/A	33. θ
8. Transverse shear stress, S	34. q_1
9. Transverse shear stress, S	35. q_2
10. Twist shear	36. q_3
11. Shear force, end 1, direction 1	37. NY = number of points for stress
12. Shear force, end 1, direction 2	
13. Axial force, end 1, direction 3	38. y_{11}
14. Moment, end 1, direction 4	39. y_{12}
15. Moment, end 1, direction 5	40. y_{21}
16. Moment, end 1, direction 6	41. y_{22}
17. Shear force, end 2, direction 1	42. y_{31}
18. Shear force, end 2, direction 2	43. y_{32}
19. Axial force, end 2, direction 4	44. y_{41}
20. Moment, end 2, direction 4	45. y_{42}
21. Moment, end 2, direction 5	46. b_1
22. Moment, end 2, direction 6	47. t_1
23. Not used	48. b_2
24. I_1	49. t_2
25. α_1	50. b_3
26. I_2	51. t_3

STRS.E22.iset.icas

iset = Load set

icas = Load case within set

Created in processor GSF.

NJ = Number of E22 elements

NI = 16

Type = single precision real

The dataset contains NJ nominal records, NI items per record.

Contents of each record:

- | | |
|------------------------------------|-------------------------------------|
| 1. Group number | 9. Moment about axis 2 at joint 1 |
| 2. Element number within group | 10. Moment about axis 3 at joint 1 |
| 3. Joint #1 | 11. Force in direction 1 at joint 2 |
| 4. Joint #2 | 12. Force in direction 2 at joint 2 |
| 5. Force in direction 1 at joint 1 | 13. Force in direction 3 at joint 2 |
| 6. Force in direction 2 at joint 1 | 14. Moment about axis 1 at joint 2 |
| 7. Force in direction 3 at joint 1 | 15. Moment about axis 2 at joint 2 |
| 8. Moment about axis 1 at joint 1 | 16. Moment about axis 3 at joint 2 |

STRS.E23.iset.icas

iset = Load set

icas = Load case within set

Created in processor GSF.

NJ = Number of E23 elements

NI = 6

Type = single precision real

The dataset contains NJ nominal records, NI items per record.

Contents of each record:

1. Group number
2. Element number within group
3. Joint #1
4. Joint #2
5. Force in element
6. Stress in element

STRS.E24.iset.icas

iset = Load set

icas = Load case within set

Created in processor GSF.

NJ = Number of E24 elements

NI = 18

Type = single precision real

The dataset contains NJ nominal records, NI items per record.

Contents of each record:

1. Group number
2. Element number within group
3. Joint #1
4. Joint #2
5. Axial force at joint 1
6. Transverse shear at joint 1
7. Moment at joint 1
8. Axial force at joint 2
9. Transverse shear at joint 2
10. Moment at joint 2
11. Axial stress at joint 1
12. Shear stress at joint 1
13. Bending stress on upper surface at joint 1
14. Bending stress on lower surface at joint 1
15. Axial stress at joint 2
16. Shear stress at joint 2
17. Bending stress on upper surface at joint 2
18. Bending stress on lower surface at joint 2

STRS.E25.iset.icas

iset = Load set

icas = Load case within set

Created in processor GSF.

NJ = Number of E25 elements

NI = 16

Type = single precision real

The dataset contains NJ nominal records, NI items per record.

Contents of each record:

1. Group number
2. Element number within group
3. Joint #1
4. Joint #2
5. Force in direction 1 at joint 1
6. Force in direction 2 at joint 1
7. Force in direction 3 at joint 1
8. Moment about axis 1 at joint 1
9. Moment about axis 2 at joint 1
10. Moment about axis 3 at joint 1
11. Force in direction 1 at joint 2
12. Force in direction 2 at joint 2
13. Force in direction 3 at joint 2
14. Moment about axis 1 at joint 2
15. Moment about axis 2 at joint 2
16. Moment about axis 3 at joint 2

STRS.E31.iset.icas

Contains stress resultants calculated in the element reference frame.

iset = Load set

icas = Load case within set

Created in processor GSF.

NJ = Number of E31 elements

NI = 11

Type = single precision real

The dataset contains NJ nominal records, NI items per record.

Contents of each record:

1. Group number
2. Element number within group
3. Joint #1
4. Joint #2
5. Joint #3
6. Not used
7. Index of section property dataset entry for element section properties
8. Section type code
9. Tractive force in *x*-direction N_x
10. Tractive force in *y*-direction N_y
11. Shearing force N_{xy}

Formulas:

$$S_x = N_x / \text{thickness}$$

$$S_y = N_y / \text{thickness}$$

$$T_{xy} = N_{xy} / \text{thickness}$$

STRS.E32.*iset.icas*e

Contains stress resultants calculated in the element reference frame.

iset = Load set
*icas*e = Load case within set

Created in processor GSF.

NJ = Number of E32 elements
NI = 28
Type = single precision real

The dataset contains NJ nominal records, NI items per record.

Contents of each record:

1. Group number
2. Element number within group
3. Joint #1
4. Joint #2
5. Joint #3
6. Not used
7. Index of section property dataset entry for element section properties
8. Section type code
9. M_x Bending moment about y -axis at joint 1
10. M_y Bending moment about x -axis at joint 1
11. M_{xy} Twisting moment at joint 1
12. Q_x Transverse shear in x -direction at joint 1
13. Q_y Transverse shear in y -direction at joint 1
14. M_x Bending moment about y -axis at joint 2
15. M_y Bending moment about x -axis at joint 2
16. M_{xy} Twisting moment at joint 2
17. Q_x Transverse shear in x -direction at joint 2
18. Q_y Transverse shear in y -direction at joint 2
19. M_x Bending moment about y -axis at joint 3
20. M_y Bending moment about x -axis at joint 3
21. M_{xy} Twisting moment at joint 3
22. Q_x Transverse shear in x -direction at joint 3
23. Q_y Transverse shear in y -direction at joint 3

STRS.E32.iset.icas (concluded)

24. M_x Bending moment about y -axis at the center
25. M_y Bending moment about x -axis at the center
26. M_{xy} Twisting moment at the center
27. Q_x Transverse shear in x -direction at the center
28. Q_y Transverse shear in y -direction at the center

Formulas:

$$\begin{aligned} S_x &= f_{4j} M_x & f_{ij} &= 1/\text{thickness for } i \text{ and } j = 1, 2, 3 \\ S_y &= f_{5j} M_y & f_{42} &= f_{52} = -f_{62} = 6/(\text{thickness})^2 \\ T_{xy} &= f_{6j} M_{xy} & f_{43} &= f_{53} = -f_{63} = -6/(\text{thickness})^2 \end{aligned}$$

STRS.E33.iset.icas

Contains stress resultants calculated in the element reference frame.

iset = Load set

icas = Load case within set

Created in processor GSF.

NJ = Number of E33 elements

NI = 31

Type = single precision real

The dataset contains NJ nominal records, NI items per record.

Contents of each record:

1. Group number
2. Element number within group
3. Joint #1
4. Joint #2
5. Joint #3
6. Not used
7. Index of section property dataset entry for element section properties
8. Section type code
9. N_x Tractive force in x -direction
10. N_y Tractive force in y -direction
11. N_{xy} Shearing force
12. M_x Bending moment about y -axis at joint 1
13. M_y Bending moment about x -axis at joint 1
14. M_{xy} Twisting moment at joint 1
15. Q_x Transverse shear in x -direction at joint 1
16. Q_y Transverse shear in y -direction at joint 1
17. M_x Bending moment about y -axis at joint 2
18. M_y Bending moment about x -axis at joint 2
19. M_{xy} Twisting moment at joint 2
20. Q_x Transverse shear in x -direction at joint 2
21. Q_y Transverse shear in y -direction at joint 2
22. M_x Bending moment about y -axis at joint 3
23. M_y Bending moment about x -axis at joint 3

STRS.E33.iset.icas (concluded)

24. M_{xy} Twisting moment at joint 3
25. Q_x Transverse shear in x -direction at joint 3
26. Q_y Transverse shear in y -direction at joint 3
27. M_x Bending moment about y -axis at the center
28. M_y Bending moment about x -axis at the center
29. M_{xy} Twisting moment at the center
30. Q_x Transverse shear in x -direction at the center
31. Q_y Transverse shear in y -direction at the center

Formulas:

$$\begin{aligned} S_x &= f_{1j}N_x + f_{4j}M_x & f_{ij} &= 1/\text{thickness for } i \text{ and } j = 1, 2, 3 \\ S_y &= f_{2j}N_y + f_{5j}M_y & f_{42} &= f_{52} = -f_{62} = 6/(\text{thickness})^2 \\ T_{xy} &= f_{3j}N_{xy} + f_{6j}M_{xy} & f_{43} &= f_{53} = -f_{63} = -6/(\text{thickness})^2 \end{aligned}$$

STRS.E41.iset.icas

Contains stress resultants calculated in the element reference frame.

iset = Load set

icas = Load case within set

Created in processor GSF.

NJ = Number of E41 elements

NI = 23

Type = single precision real

The dataset contains NJ nominal records, NI items per record.

Contents of each record:

1. Group number
2. Element number within group
3. Joint #1
4. Joint #2
5. Joint #3
6. Joint #4
7. Index of section property dataset entry for element section properties
8. Section type code
9. N_x Tractive force in x -direction at joint 1
10. N_y Tractive force in y -direction at joint 1
11. N_{xy} Shearing force at joint 1
12. N_x Tractive force in x -direction at joint 2
13. N_y Tractive force in y -direction at joint 2
14. N_{xy} Shearing force at joint 2
15. N_x Tractive force in x -direction at joint 3
16. N_y Tractive force in y -direction at joint 3
17. N_{xy} Shearing force at joint 3
18. N_x Tractive force in x -direction at joint 4
19. N_y Tractive force in y -direction at joint 4
20. N_{xy} Shearing force at joint 4
21. N_x Tractive force in x -direction at the center
22. N_y Tractive force in y -direction at the center
23. N_{xy} Shearing force at the center

STRS.E41.iset.icas (concluded)

Formulas:

$$S_x = N_x/\text{thickness}$$

$$S_y = N_y/\text{thickness}$$

$$T_{xy} = N_{xy}/\text{thickness}$$

STRS.E42.iset.icas

Contains stress resultants calculated in the element reference frame.

iset = Load set

icas = Load case within set

Created in processor GSF.

NJ = Number of E42 elements

NI = 33

Type = single precision real

The dataset contains NJ nominal records, NI items per record.

Contents of each record:

1. Group number
2. Element number within group
3. Joint #1
4. Joint #2
5. Joint #3
6. Joint #4
7. Index of section property dataset entry for element section properties
8. Section type code
9. M_x Bending moment about y -axis at joint 1
10. M_y Bending moment about x -axis at joint 1
11. M_{xy} Twisting moment at joint 1
12. Q_x Transverse shear in x -direction at joint 1
13. Q_y Transverse shear in y -direction at joint 1
14. M_x Bending moment about y -axis at joint 2
15. M_y Bending moment about x -axis at joint 2
16. M_{xy} Twisting moment at joint 2
17. Q_x Transverse shear in x -direction at joint 2
18. Q_y Transverse shear in y -direction at joint 2
19. M_x Bending moment about y -axis at joint 3
20. M_y Bending moment about x -axis at joint 3
21. M_{xy} Twisting moment at joint 3
22. Q_x Transverse shear in x -direction at joint 3
23. Q_y Transverse shear in y -direction at joint 3

STRS.E42.iset.icas (concluded)

24. M_x Bending moment about y -axis at joint 4
25. M_y Bending moment about x -axis at joint 4
26. M_{xy} Twisting moment at joint 4
27. Q_x Transverse shear in x -direction at joint 4
28. Q_y Transverse shear in y -direction at joint 4
29. M_x Bending moment about y -axis at the center
30. M_y Bending moment about x -axis at the center
31. M_{xy} Twisting moment at the center
32. Q_x Transverse shear in x -direction at the center
33. Q_y Transverse shear in y -direction at the center

Formulas:

$$\begin{aligned}S_x &= f_{4j} M_x & f_{42} &= f_{52} = -f_{62} = -6/(\text{thickness})^2 \\S_y &= f_{5j} M_y & f_{43} &= f_{53} = -f_{63} = -6/(\text{thickness})^2 \\T_{xy} &= f_{6j} M_{xy}\end{aligned}$$

STRS.E43.iset.icase

Contains stress resultants calculated in the element reference frame.

iset = Load set

icase = Load case within set

Created in processor GSF.

NJ = Number of E43 elements

NI = 48

Type = single precision real

The dataset contains NJ nominal records, NI items per record.

Contents of each record:

1. Group number
2. Element number within group
3. Joint #1
4. Joint #2
5. Joint #3
6. Joint #4
7. Index of section property dataset entry for element section properties
8. Section type code
9. N_x Tractive force in x -direction at joint 1
10. N_y Tractive force in y -direction at joint 1
11. N_{xy} Shearing force at joint 1
12. N_x Tractive force in x -direction at joint 2
13. N_y Tractive force in y -direction at joint 2
14. N_{xy} Shearing force at joint 2
15. N_x Tractive force in x -direction at joint 3
16. N_y Tractive force in y -direction at joint 3
17. N_{xy} Shearing force at joint 3
18. N_x Tractive force in x -direction at joint 4
19. N_y Tractive force in y -direction at joint 4
20. N_{xy} Shearing force at joint 4
21. N_x Tractive force in x -direction at the center
22. N_y Tractive force in y -direction at the center
23. N_{xy} Shearing force at the center

STRS.E43.iset.icas (concluded)

24. M_x Bending moment about y -axis at joint 1
25. M_y Bending moment about x -axis at joint 1
26. M_{xy} Twisting moment at joint 1
27. Q_x Transverse shear in x -direction at joint 1
28. Q_y Transverse shear in y -direction at joint 1
29. M_x Bending moment about y -axis at joint 2
30. M_y Bending moment about x -axis at joint 2
31. M_{xy} Twisting moment at joint 2
32. Q_x Transverse shear in x -direction at joint 2
33. Q_y Transverse shear in y -direction at joint 2
34. M_x Bending moment about y -axis at joint 3
35. M_y Bending moment about x -axis at joint 3
36. M_{xy} Twisting moment at joint 3
37. Q_x Transverse shear in x -direction at joint 3
38. Q_y Transverse shear in y -direction at joint 3
39. M_x Bending moment about y -axis at joint 4
40. M_y Bending moment about x -axis at joint 4
41. M_{xy} Twisting moment at joint 4
42. Q_x Transverse shear in x -direction at joint 4
43. Q_y Transverse shear in y -direction at joint 4
44. M_x Bending moment about y -axis at the center
45. M_y Bending moment about x -axis at the center
46. M_{xy} Twisting moment at the center
47. Q_x Transverse shear in x -direction at the center
48. Q_y Transverse shear in y -direction at the center

Formulas:

$$\begin{aligned}
 S_x &= f_{1j}N_x + f_{4j}M_x & f_{ij} &= 1/\text{thickness for } i \text{ and } j = 1, 2, 3 \\
 S_y &= f_{2j}N_y + f_{5j}M_y & f_{42} &= f_{52} = -f_{62} = 6/(\text{thickness})^2 \\
 T_{xy} &= f_{3j}N_{xy} + f_{6j}M_{xy} & f_{43} &= f_{53} = -f_{63} = 6/(\text{thickness})^2
 \end{aligned}$$

STRS.E44.iset.icase

iset = Load set

icase = Load case within set

Created in processor GSF.

NJ = Number of E44 elements

NI = 8

Type = single precision real

The dataset contains NJ nominal records, NI items per record.

Contents of each record:

1. Group number
2. Element number within group
3. Joint #1
4. Joint #2
5. Joint #3
6. Joint #4
7. Element thickness
8. Shear stress

STRS.xxxx.i.j

Contains element stress components at **one or more** of the following locations: element centroid, each integration point, and each node.

xxxx = element name (e.g., EX41, EX97)

For **linear** static analysis:

i = Load set (*iset*)

j = Constraint case (*ncon*)

For **nonlinear** static analysis:

i = Load step (*istep*)

j = 0

Created by processor ES_{*i*} (e.g., ES1, ES2, ES5)

Type = single precision real

The dataset may contain as many as 12 record groups, one record in each record group per structural element. The record name is determined by the location and the reference frame used in calculating the stress components. The record names, contents, and sizes are defined as follows:

- CENTROIDS** _S*dir.ielt* Stress components at the centroid of element *ielt* in reference frame *dir*. Record length is the number of stress components.
- INTEG** .PTS _S*dir.ielt* Stress components at each integration point of element *ielt* in reference frame *dir*. The record is ordered such that all stress components at the first integration point are followed by all stress components at the second integration point, etc. Record length is equal to the number of stress components times the number of integration points.
- NODES** _S*dir.ielt* Stress components at each node of element *ielt* in reference frame *dir*. The record is ordered such that all stress components at the first node are followed by all stress components at the second node, etc. Record length is equal to the number of stress components times the number of nodes.

where *dir* indicates the stress/strain reference frame. Stress resultants may be computed in the element stress/strain reference frame (*dir* = 0) or in one of three alternate reference frames. For *dir* = 1, the stress *x* direction is coincident with the global *x* direction. For *dir* = 2, the stress *x* direction is coincident with the global *y* direction. For *dir* = 3 the stress *x* direction is coincident with the global *z* direction. Note that the chosen reference frame need not be coincident with the material reference frame. For example, a record named

CENTROIDS _S1.15

will contain stress components, at the centroids, computed in the global reference frame for element number 15.

For 2-D structural elements, the stress components are stress resultants which are typically ordered: N_x , N_y , N_{xy} , M_x , M_y , M_{xy} , Q_x , Q_y . Users should consult the specific element processor documentation for the stress components calculated by the specific element processor.

TEMP.xxxx.is_{et}.ic_{ase}

xxxx = Element name
is_{et} = Load set
ic_{ase} = Load case within Load set

Created using processor AUS.

NJ = Number of elements of this type.
Type = single precision real

For 2-node elements (Not defined for E25 elements):

NI = 3

Contents of each entry:

1. Average temperature of the element
2. Transverse gradient in direction 1
3. Transverse gradient in direction 2

For 3-node structural elements (Not defined for E32 elements):

NI = 3

Contents of each entry:

1. Temperature at joint 1 of element
2. Temperature at joint 2 of element
3. Temperature at joint 3 of element

For 4-node structural elements (Not defined for E42 elements):

NI = 4

Contents of each entry:

1. Temperature at joint 1 of element
2. Temperature at joint 2 of element
3. Temperature at joint 3 of element
4. Temperature at joint 4 of element

Formula:

Total effective temperature at node n = Element temperature at node n + Nodal temperature from block ic_{ase} of dataset NODA.TEMP. is_{et}.1

TEXT.BTAB.2.1

Created by TEXT subprocessor in processor TAB.
Type = alphanumeric

Contains data in text.

TOT.DISP.*istep*

istep = Load step for nonlinear static analysis

Created by procedure NL_STATIC_1.

SYSVEC format. See APPL.FORC.*iset*.1

Contents:

This dataset contains the total displacement solution at load step *istep*. Procedure NL_STATIC_1 uses processor SSOL to generate a STAT.DISP.1.1 dataset at each load step. This dataset is immediately renamed to TOT.DISP.*istep* by the procedure.

Note that for geometrically (large-rotation) nonlinear analysis, the rotational components of TOT.DISP.*istep* may not be physically meaningful. In that case, the current orientation of the nodal (surface) triads is used to represent the rotational part of the motion. These triads are stored in TOT.ROTN.*istep*.

TOT.ROTN.istep

istep = Load step for nonlinear static analysis

Created by procedure NL.STATIC.1.

NI = 3

NJ = total number of joints in model

Type = single precision real

Contents:

This dataset contains nodal pseudo-vectors representing the rotation of the nodal freedom triad, from the initial configuration to the current configuration. These pseudo-vectors are relevant only for large-rotation geometrically nonlinear analysis in which rotational freedoms are used at some nodes. Otherwise, this dataset should not even appear in the database (note that the rotational components of the TOT.DISP.istep datasets are meaningful for small or moderate rotation analysis).

The pseudo-vector at each node points in the direction of the axis of rotation, and the magnitude is simply the angle of rotation (in radians) - where the rotation is measured from the initial configuration to the current configuration, and the components are expressed in the global coordinate system. Note that there is a unique correspondence between pseudo-vectors and rotation (orthogonal) matrices, so that a full 3×3 triad can be obtained at each node from the 3-component psuedo-vectors.

VIBR.EVAL.nset.ncon

nset = Set identifier

ncon = Constraint case

Created in processor EIG.

NJ = 1

NI = Number of eigenvalues

Type = single precision real

Contains eigenvalues corresponding to each eigenvector in VIBR.MODE.*nset.ncon*.

VIBR.MODE.nset.ncon

nset = Set identifier
ncon = Constraint case

Created in processor EIG.

SYSVEC format. See APPL.FORC.*iset.1*.

Contents:

Each block of data contains one eigenvector (vibration mode shape) corresponding to an eigenvalue stored in VIBR.EVAL.*nset.ncon*. Data is stored for each joint in each active direction.

WALL.PROP.1.1

Created using AUS/TABLE.

Contains shell wall properties for the 2-D section types.

NI = 5

NJ = Number of sections

Type = single precision real

Content of each entry:

1. Shell wall eccentricity, *ecz*
2. (Reserved for future use.)
3. (Reserved for future use.)
4. (Reserved for future use.)
5. (Reserved for future use.)

Repeated NJ times.

THIS PAGE LEFT BLANK INTENTIONALLY.



Report Documentation Page

1. Report No. NASA TM-100645		2. Government Accession No.		3. Recipient's Catalog No.	
4. Title and Subtitle The Computational Structural Mechanics Testbed Data Library Description				5. Report Date October 1988	
				6. Performing Organization Code	
7. Author(s) Caroline B. Stewart, Compiler				8. Performing Organization Report No.	
				10. Work Unit No. 505-63-01-10	
9. Performing Organization Name and Address NASA Langley Research Center Hampton, VA 23665-5225				11. Contract or Grant No.	
				13. Type of Report and Period Covered Technical Memorandum	
12. Sponsoring Agency Name and Address National Aeronautics and Space Administration Washington, DC 20546-0001				14. Sponsoring Agency Code	
				15. Supplementary Notes Caroline B. Stewart: Analytical Services and Materials, Inc., Hampton, VA	
16. Abstract The purpose of this manual is to document the datasets created and used by the Computational Structural Mechanics (CSM) Testbed software system. A description of each dataset including its form, contents, and organization is presented.					
<p>COMPUTATIONAL ANALYSIS</p> <p>DATA BASES</p> <p>ANALYSIS</p> <p>LIBRARY</p> <p>FORMATS</p>					
17. Key Words (Suggested by Authors(s)) Computational Structural Mechanics Structural Analysis			18. Distribution Statement Unclassified—Unlimited Subject Category 39		
19. Security Classif.(of this report) Unclassified		20. Security Classif.(of this page) Unclassified		21. No. of Pages 139	22. Price A07