
Space Shuttle Day-of-Launch Trajectory Design and Verification

Operational Concepts

Brian E. Harrington

Brian.E.Harrington@usa-spaceops.com

281-282-3762

AIAA-Houston Annual Technical Symposium

April 30, 2010

April 30, 2010

Brian_Harrington_ATS2010-DOLILU.ppt

Copyright © 2010 by United Space Alliance, LLC. These materials are sponsored by the National Aeronautics and Space Administration under Contract NNJ06VA01C. The U.S. Government retains a paid-up, nonexclusive, irrevocable worldwide license in such materials to reproduce, prepare, derivative works, distribute copies to the public, and perform publicly and display publicly, by or on behalf of the U.S. Government. All other rights are reserved by the copyright owner.



Objective

- Review Space Shuttle day-of-launch trajectory optimization operational concepts
- Demonstrate how the Day-of-Launch Initialization-Load Update process, or DOLILU, can improve launch probability three-fold
- Offer Shuttle DOLILU methodology for future launch vehicles to build on


Background

- Space Shuttle is not certified to lift-off in all weather conditions
- Vehicle's trajectory is optimized to that day's wind and environmental conditions
- Designed trajectory must be rigorously assessed to ensure crew and vehicle safety, while accomplishing mission objectives
- DOLILU process results in a trajectory that protects vehicle structural margins and maximizes performance given other factors
- Similarity will transition to future launch vehicles



DOLILU Overview

Since the environment (wind) changes, the DOLILU design and assessment process is repeated every hour from about launch minus 6 hours to lift-off



Balloon Systems

- Shuttle makes use of weather balloon data on Day-of-Launch (DOL)
 - Wind speed and direction from 0 to ~58,000 ft.
 - Thermodynamic atmosphere data (temperature, humidity, density) from 0 to 100,000 ft
- Weather Balloons are released about 10 miles from the launch pads by Air Force contractors



Jimsphere

- Radar tracked, no package
- Measures Wind Speed and Direction

High-Res


- GPS tracked, attached to clear Jimsphere
- Measures Wind Speed and Direction



Low-Res

- GPS tracked
- Measures Wind Speed and Direction
- Measures Thermodynamic data

Balloon Timeline




DOLILU Design


- Shuttle first-stage is “Open-loop”; “Closed-loop” second-stage will fly itself to a target
- DOLILU software optimizes the first-stage trajectory in order to minimize vehicle structural loads and maximize abort capability
 - Targets angle of attack (Alpha), angle of sideslip (Beta), and dynamic pressure (Qbar)
 - Targets staging conditions: altitude rate and optimum azimuth
- Design consists of two elements
 - “Shaper” software uses a low pass filtered wind to obtain
 - Initial pitch and yaw steering commands
 - Throttle up and down table
 - On-board wind table
 - “Biaseder” software uses the actual wind to fine-tune the pitch and yaw command by centering the wind-induced Alpha and Beta spikes

Example Wind

In-Plane Wind




Out-of-Plane Wind




Resultant Alpha, Beta, Qbar

In-Plane Wind &
Resultant Alpha




Out-of-Plane Wind &
Resultant Beta




Now with a wind 3 ½ hours later

In-Plane Wind
Resultant Alpha




Out-of-Plane Wind
Resultant Beta




Constraints: Alpha/Beta/Qbar

- “Q-planes” constrain the flight envelope to alleviate structural concerns
- Each trajectory point is dispersed by the Root Sum Square of wind persistence, flight derived system dispersions, and atmosphere persistence (Qbar only)
- Limits are reduced for engine out and gust effects

Alpha-Beta Slice or Plane





Alpha-Beta varies with Mach




Constraints: Structural Loads and Trajectory

- Structural Load Indicators (SLI) protect critical load points on the vehicle
 - Each SLI is dispersed for the Root Sum Square of wind persistence, system dispersions, and gust
- Trajectory System Rules protect staging limits, pitch/yaw/roll rates, Range Safety limits, and throttle limits
- Trajectory Experience Rules assess attitude errors, angular accelerations, SSME and SRB commanded positions, and on-board wind table



Wind Persistence


- Wind will continue to change after the final assessment
- Wind Persistence statistically accounts for the change on a constraint caused by the wind
- Shuttle uses a statistical distribution using a minimum margin method




MSFC Wind-Only Assessments

- Wind Shear Limits protect the Orbiter Tail
- Measurement Reasonableness Assessment ensures the balloon represents the current environment
- Wind Change Redline Assessment ensures that no late-in-the-count large shift in the wind might invalidate the design:

In-Plane Wind Example




Wind Change Redline Assessment




Ascent Performance Margin (APM)

- APM is remaining propellant in excess of that required to reach orbit
- DOL performance uncertainties influence pre-launch payload manifesting
- DOLILU designs tends to normalize APM which reduces in-flight dispersion protection



Launch Probability

- With the DOLILU process, the probability of launch increases over an average monthly wind design
- For example, what if Shuttle did not redesign on launch day, but used the monthly average wind/atmos design?
 - In February, the launch probability would be reduced from 90% to ~30%



Summary

- **Day-of-launch design and assessment is important because it increases the probability of launch**
- **Winds always change and the Space Shuttle must have some means to account for those changes**
 - **Space Shuttle trajectory is redesigned on day-of-launch to minimize loads while maximizing performance**
 - **Many safety improvements and assessment refinements have been made**
- **The Shuttle concepts of operation can serve as a good basis for future NASA vehicles**