

A STUDY PROGRAM ON THE DEVELOPMENT OF MATHEMATICAL

MODEL(S) FOR MICROBIAL BURDEN PREDICTION

JPL Contract 952532

Volume IX


Report On The

Mariner Mars 69-3

Burden Prediction

(Tasks 4, 5 and 6 of Phase VIII)

Prepared by:




Lloyd B. Farabee
Program Manager


For

Jet Propulsion Laboratory
4800 Oak Grove Drive
Pasadena, California 91103

Approved:



George E. Fosdick
Chief
Operations Analysis



J. C. Curlander
Manager
Systems Engineering

Martin Marietta Corporation
P. O. Box 179
Denver, Colorado 80201

CASE FILE
COPY

FOREWORD

This document describes the work performed as Tasks 4, 5, and 6 of Phase VIII of JPL Contract 952532. (This is a follow-on to JPL Contract 952028.) Phase VIII accomplished improvements in the preparation of input data for the computer programs generated in Phase III.

This document reports the results of utilizing the newly developed improvements in predicting the burden on the Mariner Mars 69-3.

This work was performed for the Jet Propulsion Laboratory, California Institute of Technology, sponsored by the National Aeronautics and Space Administration under Contract NAS7-100.

CONTENTS

	<u>Page</u>
Foreword	1
Contents	11
Illustrations	111
I. Introduction	1
II. Input Preparation	2
III. Burden Prediction	9
A. MBPM Output	9
B. Swab Sample Results	9
C. MBPM and Swab Sample Comparison	12
IV. Conclusions and Recommendations	15
References	16
Appendix	A1

ILLUSTRATIONS

<u>Figure</u>	<u>Page</u>
1. Comparison of MBPM and Swab Sample Predictions	14

<u>Table</u>	
1. Daily Activity Report Page	3
2. ITP Standard Data Format -- Card 1	4
3. ITP Standard Data Format -- Card 2	5
4. ITP Standard Data Format -- Card 3	6
5. ITP Standard Data Format -- Sample Page	7
6. MBPM End of Task Typical Printout	10
7. Subzone Surface Burden Typical Printout	11
8. Summary of Swab Sample Data	13

I. INTRODUCTION

During Phases I, II, and III of JPM Contract 952028 the requirements for the Microbial Burden Prediction Model (MBPM) were established, and the model was developed and programmed for computer utilization. During Phases IV, V, and VI, the model was used to estimate the burden on the Mariner V Spacecraft. References 1 through 5 describe this work.

As a result of the above work, a number of changes were identified that would improve the effectiveness of the existing computer programs. These changes were effected during Phase VII of the carry-on contract (JPL Contract 952532). As a result of the experience gained during the preparation of the input data, the desirability of a more manageable method of preparing this data for input to the program was recognized.

The Input Translator Program (ITP) has been developed during Phase VIII of JPL Contract 952532 to meet this latter need. The ITP performs much of the repetitious and time-consuming work involved in preparing input data. In addition, it also performs bookkeeping chores such as maintaining the current status of all parts. The ITP has been programmed so that only minor revisions have been made to the previously developed portions of the program. In most cases, an error of input data to the ITP is printed as an error, but does not stop the production of an input tape for the Tape Alteration Subroutine (TAS). The manual preparation of input data is therefore reduced to coding the JPL Quality Assurance Daily Activity Report log information for key punching, key punching this information, and making corrections to the errors which are flagged by the ITP. (Ref. 7)

Volume VII of this series of reports is a User's Manual which describes the various subroutines comprising the Input Translator Program, the method of data inputs, and the process of transferring the output data to the MBPM.

The principal factor in the development of the ITP that contributed to changes in existing programs was the change from making parts inputs at the Task level to making these inputs at the Subtask level.

Although the changes are minor in nature and small in number, the effect is felt on a number of pages of the User's Manual. The changes to these pages are listed in Volume VIII of this series of reports.

The ITP has been used to prepare input data based on the Mariner Mars 69-3 spacecraft for use on the MBPM. Using this input data, the MBPM has been run on the CDC 6400 at Martin Marietta's Denver facility and on the Univac 1108 at JPL in Pasadena.

This document is concerned with the preparation of the input data, the results of the burden prediction of the MM 69-3, and a comparison with swab sample data taken during the spacecraft preparation.

II. INPUT PREPARATION

During the assembly, testing and preparation of a spacecraft, a daily activity report of all activities and the time involved in each activity is maintained. The first page of the log of MM 69-3 is shown in Table 1.

Using this record as a source of information, JPL prepared data in the format shown in Tables 2, 3, and 4. The first page of data, prepared according to this format, is shown on Table 5 and includes the activity shown on Table 1. 355 pages of data covering the 252 days of activity were prepared. The data were then key punched onto cards for input to the ITP.

PROGRAM MM69
SPACECRAFT M69-3
DATE 6-17-68

Q. A. S/C STATUS LOG

REQUEST NO. _____ PROGRAM LABEL _____ DATE _____

CUSTOMER _____ PHONE EXT. _____

TASK CARD									
1	2	3	4	5	6	7	8	9	10
TASK	XX	DAY	XX	XX	XX	XX	XX	XX	XX
11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30
31	32	33	34	35	36	37	38	39	40
41	42	43	44	45	46	47	48	49	50
51	52	53	54	55	56	57	58	59	60
61	62	63	64	65	66	67	68	69	70
71	72	73	74	75	76	77	78	79	80
81	82	83	84	85	86	87	88	89	90
91	92	93	94	95	96	97	98	99	00

TABLE 2. ITP Standard Data Format - Card 1

REQUEST NO. _____ PROGRAM LABEL _____ DATE _____

CUSTOMER _____ PHONE EXT. _____

5

SUBTASK CARD (ONE PER QA LOG ENTRY)	
SUBTASK NUMBER	DESCRIPTION OF SUBTASK
1	TIME TO PERFORM (MIN.)
2	NUMBER OF MEN REQUIRED
3	ENVIRONMENT
4	CLOTHING
5	TOOLS
6	TOOLS
7	TOOLS
8	TOOLS
9	PREREQUISITE TASK
10	BLANK
11	PREREQUISITE SUBTASK
12	TYPE OF SUBTASK
13	OPERATIONS MAKING UP SUBTASK (ID)
14	TIME REQUIRED
15	OPERATION ID
16	TIME
17	OPERATION ID
18	TIME
19	OPERATION ID
20	TIME
21	OPERATION ID
22	TIME
23	OPERATION ID
24	TIME
25	OPERATION ID
26	TIME
27	OPERATION ID
28	TIME
29	OPERATION ID
30	TIME
31	OPERATION ID
32	TIME
33	OPERATION ID
34	TIME
35	OPERATION ID
36	TIME
37	OPERATION ID
38	TIME
39	OPERATION ID
40	TIME
41	OPERATION ID
42	TIME
43	OPERATION ID
44	TIME
45	OPERATION ID
46	TIME
47	OPERATION ID
48	TIME
49	OPERATION ID
50	TIME
51	OPERATION ID
52	TIME
53	OPERATION ID
54	TIME
55	OPERATION ID
56	TIME
57	OPERATION ID
58	TIME
59	OPERATION ID
60	TIME
61	OPERATION ID
62	TIME
63	OPERATION ID
64	TIME
65	OPERATION ID
66	TIME
67	OPERATION ID
68	TIME
69	OPERATION ID
70	TIME
71	OPERATION ID
72	TIME
73	OPERATION ID
74	TIME
75	OPERATION ID
76	TIME
77	OPERATION ID
78	TIME
79	OPERATION ID
80	TIME

TABLE 3. ITP Standard Data Format - Card 2

REQUEST NO. _____ PROGRAM LABEL _____ DATE _____

CUSTOMER _____ PHONE EXT. _____

6

PARTS AFFECTED IDENTIFICATION (ONE PER SUBTASK CARD)	
1	PART AFFECTED (ID)
2	
3	
4	
5	
6	
7	
8	
9	
10	
11	
12	
13	
14	
15	
16	
17	
18	
19	
20	
21	
22	
23	
24	
25	
26	
27	
28	
29	
30	
31	
32	
33	
34	
35	
36	
37	
38	
39	
40	
41	
42	
43	
44	
45	
46	
47	
48	
49	
50	
51	
52	
53	
54	
55	
56	
57	
58	
59	
60	
61	
62	
63	
64	
65	
66	
67	
68	
69	
70	
71	
72	
73	
74	
75	
76	
77	
78	
79	
80	
81	
82	
83	
84	
85	
86	
87	
88	
89	
90	
91	
92	
93	
94	
95	
96	
97	
98	
99	
100	

TABLE 4. ITP Standard Data Format - Card 3

STAGE 1 S/C ASSEMBLY & CHECKOUT

FORTRAN Coding Form

7

FORTRAN STATEMENT											
TASK		DAY 001		6/17/68		510 2H1		1 2 511		I 1 400 2 4014 70	
1 INST UPPER RING HARN											
01A02 15A01X15A02X											
2 SECURED IN HIGH BAY						930 H1				1 1718 930	
00000											
TASK		DAY 002		6/18/68		195 2H1		112		1 1R 2 95 1 100	
1 REM FASTENERS RING HARN											
01A02 15A01X15A02X											
2 INST CABLE TRAY TO HARN						195 2H1		1 2 5		2 11 1 55 2 7014 70	
01A02 15A01X15A02X15A03X											
3 INST ØCTAGØN						35 4H1		4 5		I 1 20 2 10 9 5	
01A02X 15A01 15A02 15A03											
4 CLEAN ØCTAGØN STRUCTURE						45 2H1				2 3C 1 5 6 15 7 20 9 5	
01A02X											
5 INST BAY 2 SHEAR PLATE						15 1H1		1 3 5		2 4I 1 7 2 8	
01A02X											
6 SECURED IN HIGH BAY						955 H1				2 5718 955	
00000											
TASK		DAY 003		6/19/68		15 2H1				2 5C 1 5 6 5 7 5	
1 CLEAN ØCTAGØN STRUCTURE											
01A02X											
2 SPØTFACE RING CASES						50 2H1		7		3 17 9 1012 40	

TABLE 5. ITP Standard Data - Sample Page

In theory, the manual involvement with the data ends here. If the cards are in the proper sequence, the ITP will run and produce a tape that is acceptable to the MBPM. In practice, however, the printout of the ITP should be examined for errors, as the ITP will take corrective action to prevent termination of the run. These errors may be in any of the following categories: (1) errors of omission in the format, which in fact are not errors (for example, an operation time so short as to be approximately zero), (2) errors that have no effect on the output (for example, two successive installations of the same part; the program ignores the second installation), (3) errors that have a small effect on the output (for example, if no men are specified for an installation operation, the ITP will assume that one man was involved, whereas, there could have been several), and (4) errors that might have considerable effect on the output (for example, a part with a large area (and probably large burden) could have been removed and not re-installed before launch).

In addition to the daily log of activities, a list of parts, with the area of each surface (top exposed, exposed, mated and occluded) is furnished. In MM 69-3 only three surface types have been identified -- no area is assigned to the top exposed surface. The mated surface area is included in the occluded surface area where the part has occluded area shown. The program accepts mated areas even when the occluded area is zero. The surface histograms, a list of constants, the decontamination operations, and a list of the environment letters used are input. All of these data precede the daily log data. A complete listing of the input data to the ITP for the MM 69-3 is given in the Appendix.

When the output print of the ITP was examined and it was determined that no errors remained in the input data that could have appreciable impact on the output, the tape was ready for use as Tape 12 (input) to the TAS subroutine of the MBPM. Even here, the TAS permits correction of the tape as the data is fed into the main program, as it was designed to do with manually generated input data tapes (Ref. 6).

III. BURDEN PREDICTION

A. MBPM Output

The printout options exercised in the MBPM produced the following types of information:

- (1) At the end of each Task (day) the distribution of burden on the total area of each surface type and the distribution of burden on the total area of all surfaces combined was printed out. These histograms give the burdens for cumulative probabilities of .05, .50, .80, .95, and 1.00. The burden for the first day is shown on Table 6.
- (2) At the end of the Task when the swab samples were taken, at the end of the first stage, and at the end of the run, the distribution of burden on each surface of each subzone was printed out. An example of this type of data is given on Table 7.

B. Swab Sample Results

Swab samples were taken on six different days during the spacecraft preparation. On each of these days samples were taken from several areas on the spacecraft. Each sampling area was 4 sq. in. (1/36 sq. ft.). For each of these samples, a record of the colony count was kept.

TASK SUMMARY
RUN 1. STAGE

10

1. TASK 1 DAY 001 6/17/68

TASK START TIME = 0.

TASK FINISH TIME = 2.40000E+01

BURDEN TOTALS BY SURFACE

SURFACE 1. TOTAL AREA = 0. , TOTAL BURDEN = 0.

SURFACE 2. TOTAL AREA = 195.792, TOTAL BURDEN MEAN VALUE = 1.31428E+05
PROBABILITY = .05000 .45000 .30000 .15000 .05000
RANGE = 1.72E+01 1.42E+04 9.06E+04 1.09E+05 3.03E+05 1.03E+06

SURFACE 3. TOTAL AREA = .632, TOTAL BURDEN MEAN VALUE = 6.00918E+02
PROBABILITY = 6.50E+01 4.35E+02 8.30E+02 1.15000 .05000
RANGE = 0. 6.50E+01 4.35E+02 8.30E+02 1.15000 .05000

SURFACE 4. TOTAL AREA = 0. , TOTAL BURDEN = 0.

TOTAL, ALL SURFACES. ARFA = 196.424, BURDEN MEAN VALUE = 1.32029E+05
PROBABILITY = .05000 .45000 .30000 .15000 .05000
RANGE = 1.71E+01 1.46E+04 9.06E+04 1.10E+05 3.04E+05 1.03E+06

TABLE 6. MBPM End of Task Typical Printout

TASK SUMMARY
RUN 1. STAGE

1. TASK 70 DAY 070 08/25/68

11

TASK START TIME = 1.65600E+03

TASK FINISH TIME = 1.68000E+03

BURDEN DISTRIBUTIONS AT END OF TASK

BURDENS BY ZONE AND SURFACE - - - - -

ZONE 1 01A00
SURFACE NUMBER 2, AREA= 55.090, BURDEN MEAN VALUE = 5.40794E+02
PROBABILITY = .43541 .06040 .00265 .00002
RANGE = 1.08E+03 5.08E+02 1.02E+03 1.52E+03 2.03E+03 2.55E+03

SURFACE NUMBER 3, AREA= .806, BURDEN MEAN VALUE = 7.66006E+02
PROBABILITY = .28404 .47857 .17442 .06282
RANGE = 0. 3.87E+01 4.18E+02 8.76E+02 1.47F+03 4.46E+03

ZONE 3 03A00
SURFACE NUMBER 2, AREA= 11.972, BURDEN MEAN VALUE = 2.67256E+02
PROBABILITY = .13761 .50733 .25367 .05615 .04524
RANGE = 5.14E+03 8.54E+01 2.45E+02 4.07E+02 5.93E+02 2.36E+03

SURFACE NUMBER 3, AREA= .618, BURDEN MEAN VALUE = 5.87711E+02
PROBABILITY = .45000 .30000 .15000 .05000
RANGE = 0. 3.65E+01 3.95E+02 8.27E+02 1.39E+03 4.21E+03

SURFACE NUMBER 4, AREA= 1.014, BURDEN MEAN VALUE = 9.41968E+02
PROBABILITY = .45000 .30000 .15000 .05000
RANGE = 1.81E+01 7.13E+01 6.31E+02 1.31E+03 2.24E+03 6.76E+03

ZONE 5 05A00
SURFACE NUMBER 2, AREA= 8.702, BURDEN MEAN VALUE = 8.63650E+01
PROBABILITY = .49212 .44243 .06253 .00289 .00003
RANGE = 3.31E+10 8.01E+01 1.61E+02 2.41E+02 3.22E+02 4.08E+02

ZONE 6 06A00
SURFACE NUMBER 2, AREA= .007, BURDEN MEAN VALUE = 6.01351E-02
PROBABILITY = .43478 .06026 .00264 .00002
RANGE = 6.40E+09 6.41E+02 1.28E+01 1.92E+01 2.56E+01 3.21E+01

SURFACE NUMBER 3, AREA= .007, BURDEN MEAN VALUE = 6.60350E+00
PROBABILITY = .45000 .30000 .15000 .05000
RANGE = 0. 4.10E+01 4.44E+00 9.30E+00 1.56E+01 4.74E+01

TABLE 7. Subzone Surface Burden Typical Printout

ZONE 7 07A00

The total burden was estimated from the swab sample data by using the equation

$$\text{Burden} = \frac{(\text{sample mean})(36)A}{E}$$

where A = the area (in sq. ft.) to which the burden is to be extrapolated.

E = the sampling efficiency

Table 8 summarizes the swab sample data and shows the estimate of total burden for sampling efficiencies of 30% and 70%, extrapolated to the area of the spacecraft at the time of sampling, as determined from the MBPM output. The attribute data were not used in this computation.

C. MBPM and Swab Sample Comparison

The results of the MBPM predictions are shown graphically on Figure 1 for the 5%, mean, and 95% probabilities. As these are the probabilities that the value shown will not be exceeded, there is a 90% probability that the microbial burden will be between the 5% and 95% values. These data are subject to erratic day-to-day variations because contamination and decontamination operations can drastically affect the burden on individual parts and the installation and removal of parts tend to cause abrupt changes in the total surface involved in the calculation.

Plotted on this same figure are the swab sample estimates for sampling efficiencies of 30% and 70%. These two predictions tend to diverge with time, as the mathematical model predictions have an upward trend, while the swab sample predictions have a downward trend. An analysis of the reasons for this disagreement (approximately 40 to 1 just prior to launch) has not been made and was not included in the statement of work to be performed under this contract.

DATE (Day)	10/21/68 (126)	12/9 (127)	12/28 (194)	1/8 (205)	2/5 (233)	2/10/69 (238)
COUNT	FREQUENCY OF OCCURRENCE					
0	171	213	173	225	235	231
1	52	21	12	20	11	15
2	9	3	1	2		4
3	7	2	2		2	
4	3	1				
5	1	2		2	1	
6	2			1	1	
7						
8	2	1				
9						
10	2					
11						
12	1					
Number of Swab Samples	250	243	188	250	250	250
Total Colony Count	168	55	20	46	28	23
Mean Colony Count	0.672	0.226	0.1063	0.184	0.112	0.092
Burden Calculated on 30% Sampling Eff.	98,400	17,400	8,000	12,100	15,500	13,440
Burden Calculated on 70% Sampling Eff.	42,100	7,470	3,440	5,180	6,650	5,760

Table 8. SUMMARY OF SWAB SAMPLE DATA




FIGURE 1. COMPARISON OF MBPM AND SWAB SAMPLE PREDICTIONS

IV. CONCLUSIONS AND RECOMMENDATIONS

For the first time, the ITP has been interfaced with the MBPM on a complete run. This document reports the results of the MBPM prediction for that case (the MM 69-3). These results have been compared with the data obtained by taking swab samples. Although conclusions as to the reasons for the disparities between the burden predictions obtained by the two methods were not included as part of this contract, several points should be noted.

The two methods seem to give results that diverge with time; the MBPM continues to increase whereas the swab sampling continues to decrease with time until the MBPM is approximately forty times as great as the swab sampling just prior to launch. When these results were compared with the results for the Mariner Venus 67-2, it is found that the swab sample data for the MM 69-3 are lower by an order of magnitude than comparable data for the MV 67-2. The MBPM results for the MM 69-3 and the MV 67-2 are in rather close agreement, but it should be pointed out that the same histogram data were used for both (as per Contract specifications).

It is recommended that the input data to the MBPM and the swab sampling be reviewed to gain insight into the reasons for the difference in predictions and particularly into the reasons for the divergence in slope of the curves.

It is also recommended that the necessary action be taken to enable multitape operation on the Univac 1108 with FORTRAN programming so that a complete run may be made from a single start (without requiring restarts).

REFERENCES

The following references, which were issued in December, 1968, and are available through the NASA STAR, form the final report for JPL Contract 952028, A Study Program on the Development of a Mathematical Model(s) for Microbial Burden Prediction:

- (1) Volume I, Technical Report
- (2) Volume II, User's Manual for the Microbial Burden Prediction Model
- (3) Volume III, Appendices
- (4) Volume IV, Addendum: Technical Report
- (5) Volume V, Addendum: Appendices

The following reference, which was issued in October 1969 forms the report for the work performed under the original phase of Contract 952532 prior to the work covered by this report:

- (6) Volume VI, Technical Report, Phase VII, Revised User's Manual for the Microbial Burden Prediction Model

The following two references, which are issued concurrently with this document, when combined with this document comprise the report for the work performed under the extension to JPL Contract 952532:

- (7) Volume VII, User's Manual for the Input Translator Program
- (8) Volume VIII, Addendum to the User's Manual for the Microbial Burden Prediction Model

APPENDIX

ITP INPUT DATA

LISTING FOR MM 69-3

INITIAL				
01A00	SUBZONE STRUCTURE (A)	4030	249	8738
01A01	OCTAGON STRUCTURE ASMBLY			3270
01A02	SUPER STRUCTURE ASMBLY		96	1296
01A03	SUN SENSR PEDST BAY IV		23	109
01A04	SUN SENSR PEDST BAY VIII		18	157
01A05	S/P SUPRT HINGE BAY I	28	2	
01A06	S/P SUPRT HINGE BAY III	28	2	
01A07	S/P SUPRT HINGE BAY V	28	2	
01A08	S/P SUPRT HINGE BAY VII	28	2	
01A09	S/P SUPRT DPLOY BAY I	68	3	
01A10	S/P SUPRT DPLOY BAY III	68	3	
01A11	S/P SUPRT DPLOY BAY V	68	3	
01A12	S/P SUPRT DPLOY BAY VII	68	3	
01A13	PROP BALL ENG MOUNT SIDE		1	6
01A14	PROP RET BALL ENG MOUNT		6	12
01A15	PROP FTG ENG MOUNT SIDE		10	68
01A16	PROP BASE ENG MOUNT SIDE		30	114
01A17	FTG ENG MOUNT UPPER			37
01A18	PROP BASE ENG MOUNT UPPR			37
01A19	LATCH: SUPPORT INBOARD		40	152
01A20	LATCH: SUPPORT OUTBOARD		4	20
01A21	LATCH: INBRD MOTION SWCH			4
01A22	ACCELEROMETER ADAPTER		1	2
01A23	ADAPTER STRUCTURE	3454		3454
01A24	V-BAND ASSEMBLY	192		
01B00	SUBZONE MECH DEVICES (B)	136	100	285
01B01	LATCH ASMBLY SCAN PLATFM		72	224
01B02	LATCH OUTBRD MOTION SWCH		2	4
01B03	REL DEVICE + TENSION MON	16		
01B04	SEPARATION SPRING DEVICE	112	18	
01B05	SEPARATION INITIATE TIMR		3	22
01B06	PYRO ARMING SWITCH ASMBLY		1	8
01B07	ACCELEROMETER IN FLT LEG		4	22
01B08	ACCELEROMETER AMP CHARGE			3
01B09	SCAN PLAT LATCH VENT SQB			2
01B10	V-BAND SOIBS	8		
02A00	SUBZONE LOW GAIN ANT (A)	1546	20	75
02A01	LOW GAIN ANTENNA ASSMBLY	1384	16	75
02A02	LOW GAIN ANTENNA CABLE	31		
02A03	LOW GAIN ANT SHRT DAMPER	53	2	
02A04	LOW GAIN ANT LOWR DAMPER	78	2	
02B00	SUBZONE TCFM (B)	1171	2	
02B01	TCFM SENSR XDUCER ASSMBY	2	1	
02B02	WIRING HARNESS TCFM SENS	1169	1	
02C00	SUBZONE HIGH GAIN ANT (C)	3868	20	
02C01	HIGH GAIN ANTENNA ASSMBY	3613	20	
02C02	PROBE SUB ASSMBLY	2		
02C03	FEED CABLE SUB ASSMBLY	91		
02C04	HIGH GAIN LOW CABLE ASSY	162		
03A00	SUBZONE PLAT + TRANSDUCR	2066	115	235
03A01	SCAN PLAT STRUCTURE ASSY	1724	89	235
03A02	SCAN PLAT HALF LOUVER	342	26	
03B00	SUBZONE SCIENCE INSTRMNT	4588	141	
03B01	MARS GATE ASSY=1 NARROW	24	4	
03B02	MARS GATE ASSY=2 NARROW	24	4	
03B03	FARENCOUNTD PLANET SENS	50	8	
03B04	SCAN ACT ASSY (CLOCK AX)	55	7	
03B05	SCAN ACT ASSY (CONE AX)	55	7	
03B06	IR RADIOMETER ASSEMBLY	204		
03B07	IRR TEMP XDUCER	2	1	
03B08	UV SPECTROMETER ASMBLY	1452		

03B09	UVS TEMP XDUCER	2	1	
03B10	WIDE ANG TV CAMERA ASSY	227		
03B11	TV A TEMP XDUCER	2	1	
03B12	TV NARROW ANG CAMERA B	1094		
03B13	TV B VIDICON TEMP XDUCR	2	1	
03B14	TV B OPTICS TEMP XDUCER	2	1	
03B15	IR SPECTROMETER GAS STOR	239		
03B16	MONOCHROMETER TELESCOPE	1032	99	
03B17	IRS VENT ASSEMBLY	100		
03B18	IRS ELECT TEMP XDUCER	2	1	
03B19	IRS RADIATER TEMP XDUCER	2	1	
03B20	ACCELEROMETER SCAN PLAT	2	1	
03B21	TEMP XDUCR SCAN PLAT YOK	2	1	
03B22	SCAN PLAT LATCH PRESS XD	2	1	
03B23	MANIFOLD ASSEMBLY	8		
03B24	IRS GAS VALVE, SQUIB N2	2	1	
03B25	IRS GAS VALVE, SQUIB H2	2	1	
04A00	SUBZONE SOLAR PANEL ASSY	58288		
04A01	SOLAR PANEL ASSY -X+Y	14572		
04A02	SOLAR PANEL ASSY +Y	14572		
04A03	SOLAR PANEL ASSY -X	14572		
04A04	SOLAR PANEL ASSY -Y	14572		
04B00	SOLAR PANEL MECH DEVICES	420		
04B01	DEPLOY MECHANISM ASSMBLY	28		
04B02	SOLAR PANEL BOOST DAMPRS	48		
04B03	SOLAR PANEL CRUISE DAMPR	28		
04B04	S/P PIN PULLER HARNESS+X	71		
04B05	S/P PIN PULLER HARNESS+Y	71		
04B06	S/P PIN PULLER HARNESS-X	71		
04B07	S/P PIN PULLER HARNESS-Y	71		
04B08	SOLAR PANEL PIN PULLER	8		
04B09	S/P UNLATCH MOTION SENSR	8		
04B10	S/P SQUIB LEFT	8		
04B11	S/P SQUIB RIGHT	8		
05A00	CHASSIS, LOUVERS, TRANSDUC	311	44	1585
05A01	CHASSIS PWR/PYPO/SCAN/TC			1266
05A02	LOUVER BAY I	311	40	311
05A03	CHASSIS TEMP XDUCER		4	8
05B00	SUBZONES MODULES (B)		149	1350
05B01	PYRO CONTROL I+II RIGHT		21	120
05B02	PYRO CONTROL I+II LEFT		2	6
05B03	POWER DISTRIBUTION		9	108
05B04	2400 HZ MAIN INVERTER		15	132
05B05	2400 HZ STANDBY INVERTER		15	132
05B06	400 HZ 10+30 INVERTER		21	156
05B07	HEATER + DC PWR DISTRIBU		9	108
05B08	TEMP CNTRL MONITOR I		9	108
05B09	TEMP CNTRL MONITOR II		9	108
05B10	SCAN LOGIC ELECTRONICS		9	108
05B11	SCAN POWER SUPPLY		9	108
05B12	SERVO AMP+STEPPER MOTOR		21	156
05C00	HARNESSES AND CABLES		45	1894
05C01	POWER HARNESSES		22	626
05C02	TCFM HARNESS		4	242
05C03	TCFM INTER CONN HARNESS		2	40
05C04	SCAN HARNESS		12	434
05C05	PYRO DIR. ACCESS HARNESS		5	552
06A00	CHASSIS, TRANSDUCERS (A)		5	675
06A01	N2 TANK PRESSURE XDUCER		1	2
06A02	N2 TANK TEMP XDUCER		1	2
06A03	PROP TANK PRESS XDUCER		1	2
06A04	PROP TANK TEMP XDUCER		1	2

06A05	THRUST CHAMBR PRES XDUCR		1	2
06A06	PROPULSION CHASSIS			665
06B00	PROP SYSTEM ASSEMBLY (B)	40	47	505
06B01	THRUST VECTOR CONTROL		35	85
06B02	JET VANE ACTUATOR	40		
06B03	PROP VALVE ASSEMBLY		6	40
06B04	PROP TANK ASSEMBLY		6	380
06C00	NITROGEN SYSTEM ASSEMBLY		96	502
06C01	N2 VALVE ASSEMBLY		5	27
06C02	N2 REGULATOR ASSEMBLY		2	37
06C03	N2 TANK ASSEMBLY		6	133
06C04	THRUST PLATE + ENG ASSY		74	196
06C05	ROCKET ENGINE ASSEMBLY		6	84
06C06	INCIDENTAL PLUMBING		3	25
06D00	HARNESSES + SQUIBS	613	19	1529
06D01	WIRING HARN TVCA + SENSR		5	251
06D02	WIRING HARN PROP PYRO		6	748
06D03	PROPELLANT THERML SHIELD	613		514
06D04	PROP PROPEL START SQUIBS		2	4
06D05	PROP NITROG START SQUIBS		2	4
06D06	PROP PROPEL STOP SQUIBS		2	4
06D07	PROP NITROG STOP SQUIBS		2	4
07A00	CHASSIS, LOUVERS, TRANSDUC	240	44	1909
07A01	CHASSIS A/C CC+S			818
07A02	EAGLE SHIELD	240	40	240
07A03	SHEAR PLATE CC+S ATT CON			739
07A04	CHASSIS TEMP XDUCER		4	8
07A05	SUPPORT SUB CHASSIS			104
07B00	SUBZONE MODULES (B)		163	1244
07B01	CC + S POWER SUPPLY		7	119
07B02	CC + S TIMING CONTROL		28	267
07B03	CC + S EVENT CONTROL		28	267
07B04	CC + S MEMORY		19	169
07B05	ATT CONTROL ELECT		35	287
07B06	GYRO CONTROL		46	135
07C00	HARNESSES AND CABLES (C)		57	2113
07C01	WIRING HARNESSES CC + S		30	1577
07C02	WIRING HARN ATT CONTROL		18	519
07C03	FUSED CONNECTOR		9	17
08A00	CHASSIS, LOUVER, TRANSDUC	311	4	1202
08A01	CHASSIS CMD TELEMETRY			883
08A02	LOUVER BAY IV	311		311
08A03	CHASSIS TEMP XDUCER IV		4	8
08B00	SUBZONES MODULES (B)		165	2162
08B01	CMD DETECTOR SUBASSY 1		7	110
08B02	CMD DETECTOR 2+PROG CONT		7	110
08B03	CMD DECODER SUBASSY 1		7	110
08B04	CMD DECODER SUBASSY 2		7	110
08B05	CMD DECODER 3 PWR SUPPLY		7	110
08B06	TIMING GENERATOR SUBASSY		10	123
08B07	DATA PROCESSOR SUBASSY		10	123
08B08	ANALOG/DIGITAL CONVERTER		10	123
08B09	ANALOG/DIGITAL CONVERTER		10	123
08B10	TRANSFER REGISTER SUBASY		10	123
08B11	MODE+RATE CONTROL SUBASY		10	123
08B12	PROGRAMER SUBASSEMBLY		10	123
08B13	DECK 100-110 210-220		10	123
08B14	DECK 200-300-LOW LEV AMP		10	123
08B15	DECK 400-410 SUBASSEMBLY		10	123
08B16	DECK 420-430 SUBASSEMBLY		10	123
08B17	BLOCK CODER SUBASSEMBLY		10	123
08B18	POWER SUPPLY SUBASSEMBLY		10	136

08C00	HARNESSES AND CABLES (C)	54	2105
08C01	WIRING HARN FLIGHT COMND	25	862
08C02	WIRING HARN FLIGHT TELEM	29	1243
09A00	CHASSIS, LOUVERS, TRANSDUC	311 44	1385
09A01	CHASSIS DATA STORAGE		1066
09A02	LOUVER BAY V	311 40	311
09A03	CHASSIS TEMP XDUCER	4	8
09B00	SUBZONE MODULES (B)	193	1351
09B01	ANALOG TAPE TRANSPORT	48	236
09B02	ATR PLAYBACK ELECTRONICS	9	108
09B03	DSS LOGIC SUBASSEMBLY	9	108
09B04	MTR DRIVER AMP SUBASSY	30	123
09B05	2400 HZ POWER SUPPLY	18	150
09B06	DIGITAL TAPE TRANSPORT	35	214
09B07	DTR PLAYBACK ELECTRONICS	21	162
09B08	ATR+DTR RECORD ELECTRONI	11	124
09B09	DSS CONT LOGIC INTERFACE	11	124
09B10	HEATER	1	2
09C00	HARNESSES AND CABLES (C)	19	2596
09C01	WIRING HARN DATA STORAGE	19	2596
10A00	CHASSIS, LOUVERS, TRANSDUC	49	1123
10A01	CHASSIS RADIO SUBASSY	40	1105
10A02	CHASSIS TEMP XDUCER VI	4	8
10A03	VCO TEMP XDUCER	1	2
10A04	AUX OSC TEMP XDUCER	2	4
10A05	TWT BASE TEMP XDUCER	2	4
10B00	SUBZONE MODULES (B)	201	1327
10B01	CONTROL UNIT SUBASSEMBLY	12	127
10B02	DIPLEXER SUBASSEMBLY	21	156
10B03	RECEIVER SUBASSEMBLY	36	216
10B04	RF SWITCH SUBASSEMBLY	12	120
10B05	FILTER/HYBRID SUBASSMBLY	12	88
10B06	OUTPUT FILTER SUBASSMBLY	6	68
10B07	EXCITER SUBASSEMBLY	42	240
10B08	TWTA SUBASSEMBLY	60	312
10C00	HARNESSES AND CABLES (C)	24	792
10C01	WIRING HARN RADIO FREQ	15	627
10C02	RF CABLE FLEXIBLE	3	33
10C03	RF CABLE SEMI-RIGID	3	66
10C04	RF CABLE SEMI-RIGID	3	66
11A00	CHASSIS, LOUVERS, TRANSDUC	311 4	1465
11A01	CHASSIS SCIENCE EQUIP		777
11A02	LOUVER BAY VII	311	311
11A03	SHEAR PLATE SCIENCE EQUI		369
11A04	CHASSIS TEMP XDUCER	4	8
11B00	SUBZONE MODULES (B)	323	2212
11B01	DAS POWER CONVERTER SUBA	11	140
11B02	DAS LOGIC SUBASSEMBLY	24	256
11B03	DAS LOGIC SUBASSEMBLY	24	256
11B04	DAS LOGIC SUBASSEMBLY	24	256
11B05	TV POWER SUPPLY SUBASSY	174	563
11B06	TV DATA CONVERTER SUBASY	22	247
11B07	TV CAMERA DRIVERS SUBASY	22	247
11B08	TV CONTROL SUBASSEMBLY	22	247
11C00	HARNESSES AND CABLES (C)	47	2175
11C01	WIRING HARNESS DAS	11	256
11C02	WIRING HARN DAS INTERCON	19	1299
11C03	WIRING HARN TV ELECTRONI	16	618
11C04	HEATER	1	2
12A00	CHASSIS, LOUVERS, TRANSDUC	311 5	1191
12A01	CHASSIS POWER REGULATOR		870
12A02	LOUVER BAY VIII	311	311

12A03	TEMP XDUCERS		5	10
12B00	SUBZONE MODULES (A)		516	1671
12B01	POWER SOURCE + LOGIC		99	244
12B02	MAIN BOOSTER REGULATOR		34	143
12B03	STANDBY BOOSTER REGULATR		34	143
12B04	POWER CONTROL SUBASSY		93	312
12B05	BATTERY CHARGER		42	172
12B06	BATTERY ASSEMBLY		214	657
12C00	HARNESSES + CABLES (C)		15	6204
12C01	WIRING HARN POWER REGULA		15	6204
13A00	A/C GAS SYSTEM ASSY (A)	1063	66	611
13A01	A/C GAS SYSTEM ASY +X/+Y	177		
13A02	HI PRESS (GAS) SUPP EQUI		18	289
13A03	PITCH JETS ASSY (+Y SOLR	20	4	
13A04	ROLL+YAW JETS ASY(+X SOL	56	6	
13A05	JET VALVES	5	3	
13A06	CABLE ASSY A/C GAS SYSTT	540		20
13A07	GAS VESSEL TEMP XDUCER		2	4
13A08	GAS VESSELL PRESS XDUCER		2	4
13A09	A/C GAS SYSTM ASY(-X/-Y	177		
13A10	HI PRESS(GAS) SUPPRT EQ		18	289
13A11	PITCH JETS ASY (-Y SOLR	20	4	
13A12	ROLL+YAW JETS ASY(-X SO	56	6	
13A13	JET VALVES		3	5
13A14	FLIGHT NOZZLES +X/+Y	6		
13A15	FLIGHT NOZZLES -X/-Y	6		
13B00	SUBZONE SENSORS (B)	274	121	695
13B01	SUN SENSOR PRIMARY ASSY		8	62
13B02	SUN SENSOR PRIM TEMP XD		1	2
13B03	SUN SENSOR SECONDARY		4	21
13B04	SUN SENSOR SECONDARY		4	21
13B05	SUN SENSOR SECONDARY		4	21
13B06	SUN SENSOR SECONDARY		4	21
13B07	SUN GATE DETECTOR ASSY		2	11
13B08	CANOPUS SENSOR ASSY	137	91	530
13B09	CANOPUS SENSOR TEMP XDU		1	2
13B10	CANOPUS SENSOR BAFFLE	137		
13B11	SUN DETECTOR		2	4
14A00	TEMP CONTROL ATTACH ASY	12774	983	12668
14A01	UPPR THERML SHIELD BLNK	3600		3600
14A02	LOWR THERML SHIELD BLNK	2736		2736
14A03	SCAN PLAT T/C SHIELD BLK	2592		2592
14A04	PRI SUN SEN PED L BLK B4	99		99
14A05	PRI SUN SEN PED L BLK B8	99		99
14A06	T/C SHIELD CORNER A	85		85
14A07	T/C SHIELD CORNER B	85		85
14A08	T/C SHIELD CORNER C	85		85
14A09	T/C SHIELD CORNER D	85		85
14A10	T/C SHIELD CORNER E	85		85
14A11	T/C SHIELD CORNER F	85		85
14A12	T/C SHIELD CORNER G	85		85
14A13	T/C SHIELD CORNER H	85		85
14A14	CHANNEL UPPER BAY I	44	44	44
14A15	CHANNEL UPPER BAY III	44	44	44
14A16	CHANNEL UPPER BAY V	44	44	44
14A17	CHANNEL UPPER BAY VII	44	44	44
14A18	CHANNEL UPPER BAY VIII	44	44	44
14A19	CHANNEL LOWER BAY I	44	44	44
14A20	CHANNEL LOWER BAY III	44	44	44
14A21	CHANNEL LOWER BAY IV	44	44	44
14A22	CHANNEL LOWER BAY V	44	44	44
14A23	CHANNEL LOWER BAY VII	44	44	44

14A24	CHANNEL LOWER BAY VIII	44	44	44
14A25	ANGLE ATTACH BAY I	32	32	32
14A26	ANGLE ATTACH BAY III	32	32	32
14A27	ANGLE ATTACH BAY V	32	32	32
14A28	ANGLE ATTACH BAY VII	32	32	32
14A29	ANGLE ATTACH BAY VIII RS	34	34	34
14A30	ANGLE ATTACH BAY VIII LS	34	34	34
14A31	ANGLE ATTACH BAY II	35	35	35
14A32	ANGLE ATTACH BAY VI	35	35	35
14A33	RING CENTR SUPRT LOW T/C	22	22	22
14A34	RING LOWER T/C SHIELD	27	26	26
14A35	SPRING LOWER BLANKET	8	8	8
14A36	CLAMP LOWER RING	8	8	8
14A37	ANGLE ATTACH BAY IV	32	33	33
14A38	SHIELD CORNER H R. STRUT	232		232
14A39	SHIELD CORNER B R. STRUT	169		169
14A40	SHIELD CORNER B L. STRUT	169		169
14A41	SHIELD CORNER E R. STRUT	156		156
14A42	SHIELD CORNER E L. STRUT	272		272
14A43	SHIELD CORNER H L. STRUT	143		143
14A44	SHIELD LONG DAMPER	168		168
14A45	SHIELD FITTING CORNER B	70		70
14A46	SHIELD FITTING CORNER E	70		70
14A47	SHIELD FITTING CORNER H	70		70
14A48	SHIELD CANOPUS BAFFLE	48		48
14A49	SHIELD S/P HINGE A+B	60		60
14A50	SHIELD S/P HINGE C+D	60		60
14A51	SHIELD S/P HINGE E+F	60		60
14A52	SHIELD S/P HINGE G+H	60		60
14A53	SHIELD CANOPUS CAD SUL	3		3
14A54	BRACKET 1/2 LOUVER SUPP	139	27	139
14A55	SHIELD UPPER BAY IV	36	36	36
14A56	ANGLE ATTACH LOWER III	30	30	30
14A57	T/C FEPS	40	16	
14A58	T/C SCAN	66	27	
15A00	STRUCTURAL HARNESSSES		164	48038
15A01	WIRING HARN UPPR RNG POW		11	2480
15A02	WIRING HARN UPPR RNG SIG		80	25805
15A03	UPPER RING HARN TROUGH		20	1584
15A04	LOWER RING WIRING HARN		15	5366
15A05	PYRO DISTR HARNESS		11	203
15A06	PYRO INTERCOMM WIRE HARN		4	201
15A07	PLATFORM HEATER HARNESS		5	589
15A08	ACCELEROMETER HARNESS		1	4
15A09	PYRO HARNESS		3	1246
15A10	SIGNAL HARNESS		11	10536
15A11	SEPERATION COAX CONNECTR		1	8
15A12	SEPERATION CONNECTOR		1	8
15A13	SEPERATION CONNECTOR		1	8
15B00	SUBZONE HARNESSSES (B)		28	15427
15B01	WIRING HARN SCIENCE POWR		6	3086
15B02	WIRING HARN SCIENCE PYRO		6	3086
15B03	WIRING HARN SCIENCE SIGN		6	3085
15B04	WIRING HARN SCAN ACTUATR		5	3085
15B05	PLAT ACCELEROMETER HARN		5	3085

9	.3846	.2846	.1385	.0769	.0692	.0077	.021
.0154							
0.	480.	960.	1440.	1920.	2400.	3360.	4800.
7200.							

						A7	
	.3846	.2846	.1385	.0769	.0692	.0077	.0231
.0154							
0.	480.	960.	1440.	1920.	2400.	3360.	4800.
7200.							
4	1.0	0.8	5	200.0	0.2	0.0	0.
15	0.0	0.5	0.0	0.0			
2	6	7					

T H V S A O F E N P

STAGE 1 SPACECRAFT ASSEMBLY AND CHECKOUT

TASK 1 DAY 001 6/17/68

1INST UPPER RING HARN 510 2H1 1 2 511 I 1 400 2 4014 70

01A02 15A01X15A02X

2SECURED IN HIGH BAY 930 H1 1 1T18 930

00000

TASK 2 DAY 002 6/18/68

1REM FASTENERS RING HARN 195 2H1 112 1 1R 2 95 1 100

01A02 15A01X15A02X

2INST CABLE TRAY TO HARN 195 2H1 1 2 5 2 1I 1 55 2 7014 70

01A02 15A01X15A02X15A03X

3INST OCTAGON 35 4H1 4 5 I 1 20 2 10 9 5

01A02X15A01 15A02 15A03

4CLEAN OCTAGON STRUCTURE 45 2H1 2 3C 1 5 6 15 7 20 9 5

01A02X

5INST BAY 2 SHEAR PLATE 15 1H1 1 3 5 2 4I 1 7 2 8

01A02X

6SECURED IN HIGH BAY 955 H1 2 5T18 955

00000

TASK 3 DAY 003 6/19/68

1CLEAN OCTAGON STRUCTURE 15 2H1 2 5C 1 5 6 5 7 5

01A02X

2SPOTFACE RING CASES 50 2H1 7 3 1T 9 1012 40

01A02X

3MOVE SUPERSTRUCT TO GAS 45 4H2 1 2 5 3 2R 1 30 2 15

00000

4PYRO DIST HARN HIGH BAY 70 3H2 1 2T25 70

15A05X

5PREP LOWER RING HARN 50 3H2 T25 50

15A04X

6INST CABLE CLAMPSLR HARN 50 2H2 1 2 5 3 5I 1 25 2 1514 10

01A02X

7INST SCAN PLAT TUBE 60 5H2 510 3 6I 1 40 2 20

01A02X03B04X03B05X03B000

8INST PYRO DIST HARN 10 3H2 3 4I 1 5 2 214 3

01A02 15A05X

9INST PYRO DIP ACCES HARN 95 2H2 3 8I 1 60 2 1514 20

01A02 15A01 15A02 15A03 05C05X

10ROUT PYRO INTERCONN HARN 7 2H2 1 5 3 9T 1 4 2 3

01A02 15A01 15A02 15A03 15A06X

11INST S/P SUPPORT HINGES 18 2H2 4 5 3 10I 1 6 2 12

01A05X01A06X01A07X01A08X01A02

12INST LOWER RING HARN 15 3H2 1 2 5 3 11I 1 5 2 514 5

01A02 15A04X

13WEIGH WIRE HARN UP RING 60 2H2 1 5 I 1 20 2 40

01A02 15A01X15A02

14TORQUE UPPER RING HARN 50 2H2 1 2 5 1 1T 1 20 2 2014 10

01A02 15A01X15A02

15INST PYRO INTERCONN HARN 50 2H2 1 5 3 10I 1 20 2 30

01A02 15A01 15A02 15A06X

16SECURED IN HIGH BAY 795 H2 3 15T18 795

00000

TASK 4 DAY 004 6/20/68

1ROUTE HARN 70 3H2 1 2 512 3 15I 1 25 2 2514 20

01A02 15A01 15A02 15A06X	80 2H2 1 211	4	1I 1	40 2	40	
2ROUTE RF CABLE						
01A02 15A04 15A11X	20 3H2111213	4	2I 1	7 2	7 8	6
3INST LOW HARN TO OCTAGON						
01A02						
4INSPECT +X +Y GAS SYSTEM	25 2H2		T 1	5 9	1010	10
13A X						
5INST GRND LUGS TO WIRE	95 2H2111213	4	3I 1	40 2	35 8	20
01A02 15A04X						
6INST SCAN ACTUATOR ADAPT	15 4H2 1 2		I 1	12 2	3	
15A02 15A04 03B04X03B05X						
7REM SUN SENSORS FROM GAS	5 1H2		T25	5		
00000						
8INST SEC SS AND TORQUE	10 2H2 1 5	4	7I 1	5 2	5	
13B03X13B04X13B05X13B06X						
9INST ACCEL ON OCTAGON	5 2H2 2 5		I 1	3 2	2	
01A02 15A04 01B07X						
10TORQUE ACCEL TO OCTAGON	7 1H2 2 5	4	9I 1	4 2	3	
01A02 15A04 01B07X						
11RETURN PRIM SS TO GAS.	18 1H2	4	7T26	18		
00000						
12INST DISCONN AND RF CONN	5 2H2 1 2 5		I 1	3 2	2	
01A02 15A01 15A02 15A03 01B05X10C02X						
13INST UP RING AND TROUGH	85 3H2 1 212		I 1	35 2	3014	20
01A02 15A03X15A01X15A02X						
14SOLDER TERM TO SEC SS	60 3H2111213	4	8I 1	20 2	20 8	20
01A02 15A04 13B03X13B04X13B05X13B06X						
15SECURE IN HIGH BAY	940 H2	4	14T18	940		
00000						
TASK 5 DAY 005 6/21/68						
1SECURE IN HIGH BAY	10 H2	4	15T18	10		
00000						
2ROUTE UPPER RING HARN	20 3H2 1 3 5	4	13I 1	10 2	514	5
15A01X15A02X01A02						
3INST WIRING HARN	60 3H2 2 5	4	1I 1	20 2	2014	20
15A06X15A01 15A02 15A03 15A05 01A02						
4RELEASED PARTS FROM GAS	10 1H2		T25	10		
00000						
5CHECKED SUN SENSOR GAP	80 2H210	4	14T 1	3010	50	
13B03X13B04X13B05X13B06X01A02 15A04						
6INST TEMPLATE ROUTE HARN	150 2H2 2 5	5	3I 1	70 2	70 9	10
01A02						
7INST MICROSWITCHS	180 1H2 1 2	5	4I 1	90 2	90	
01B03X01B04X						
8SECURE IN HIGH BAY	930 H2	5	7T18	930		
00000						
TASK 6 DAY 006 6/22/68						
1SECURE IN HIGH BAY	1440 H2	5	8T181440			
00000						
TASK 7 DAY 007 6/23/68						
1SECURE IN HIGH BAY	1440 H2	6	1T181440			
00000						
TASK 8 DAY 008 6/24/68						
1SECURE IN HIGH BAY	10 H2	7	1T18	10		
00000						
2ROUTE HARN	170 2H2 1 2 5	5	6I 1	60 2	6014	50
15A01X15A02X15A03 01A02						
3RELEASED PARTS FROM GAS	30 1H2		T25	30		
00000						
4REM SCAN PLAT GAS VENT	22 2H2 2 6	8	3R 1	8 2	810	6
03B17X01A02 15A04						
5INST GAS VENT TUBE	116 2H2 1 2 510 8	4I 1	50 2	5010	18	

03P17X01A02 15A04	10 2H2 2 5	8 5I 1	5 2	5
6INST SCAN PLAT GAS VENT				
03P17X01A02 15A04				
7RELEASE PRIM SS FROM GAS	30 1H2	T25	30	
00000				
8INST PRIM SS	15 2H2 1 5	8 7I 1	8 2	7
01A03X01A04X01A02				
9INST SCAN PLAT STRUCT	60 4H2 2 6	8 6I 1	30 2	30
03P17X01A02 15A04				
10RELEASED MOTOR MTS	45 1H2	8 3T25	45	
00000				
11INST MOTOR MTS	60 2H2 1 2 5	8 10I 1	30 2	30
01A15X01A17X01A02				
12CLOTHING STUDY IN TENT	40 4T2	8 11T27	40	
00000				
13SECURE IN TENT	830 T2	8 12T17	830	
00000				
TASK 9 DAY 009 6/25/68				
1SECURE IN TENT	10 T2	8 13T17	10	
00000				
2RELEASE SCAN PLAT HARN	15 1T2	T25	15	
00000				
3RELEASE PLAT LATCH MECH	15 1T2	T25	15	
00000				
4INST LATCH LOCKS ON SCAN	10 3T2 1 2 5	9 3I 1	5 2	5
01A19X01A20X01A02 15A04				
5INST INBD LATCH ASS	10 2T2 1 2 5	9 3I 1	5 2	5
01A19X01A02 15A04				
6INST OUTBD LATCH ASS	3 2T2 1 2 5	9 3I 1	1 2	2
01A20X01A19 01A02 15A04				
7SOLDER SENSOR WIRE	3 2T21113	9 3I 1	1 2	1 8 1
01A04X01A03X01A02				
8INST LATCH LOCKS	4 3T2 1 2	9 7I 1	2 2	2
01A19X01A20X01A02 15A04				
9SOLDER MICROSWITCHES	60 1T21113	5 7I 1	20 2	20 8 20
04B09X				
10PEM SUN GATE FROM GAS	20 1T2	T25	20	
00000				
11PRESS POSS LATCH MECH	60 2T2 2 5	9 8T 1	30 2	30
01A19X01A20X01A02 15A04				
12MEASURE PEELABLE SHIM	120 2T2 2 510	9 11T 1	50 2	5010 20
01A19X01A20X01A02 15A04				
13SOLDER LEADS SUN GATE	10 1T21113	9 10I 1	3 2	3 8 4
13B07X01A02				
14REM SHIMS TORQUE B NUT	50 2T2 2 51112	9 12R 1	25 2	25
01A19X01A20X01A02 15A04				
15INST GR LUG	5 2T2 2 5	4 5I 1	3 2	2
15A04X				
16PREP SCAN INSTALL	25 3T2 1 2	8 9T 2	10 1	1010 5
01A19X01A20				
17INST INBD LATCH SCREWS	20 2T2 1 2 5	9 16I 1	10 2	10
01A19X01A20X01A02 15A04				
18INST SCAN PLAT	10 4T2 2 5	9 16I 1	5 2	5
03A01X01A02 15A04 01A19 01A20				
19INST COVER AND TORQUE	65 3T2 2 5	9 18I 1	35 2	30
03A01X01A02 15A04				
20INST SCAN ELECTRONICS	65 3T2 1 2 5	I 1	30 2	30 9 5
05B01X05B02X05B10X05B11X05B12X05A01				
21RELEASED CS 1	15 1T2	T25	15	
00000				
22POWER SOURCE FROM GAS	15 1T2	T25	15	
00000				

23INST POWER DIST. MODS	20 2T2 1 5	9 21I 1	8 2	8 9	4	
05R03X05B D5A01						
24INST POWER SOURCE ON S/C	20 2T2 1 2 6	9 22I 1	10 2	10		
12B01X12A01						
25SECURE IN TENT	790 T2	9 24T17	790			
00000						
TASK 10 DAY 010 6/26/68						
1SECURE IN TENT	10 T2	9 25T17	10			
00000						
2RESOLVE PROB CLOCK PLAT	20 2T2 5	T 2	20			
03A01X15A04 01A02						
3GET BATT ASSY FROM GAS	10 1T2	T25	10			
00000						
4RETURN BATT TO GAS	10 1T2	T26	10			
00000						
5REM BEARING RETAIN CAPS	70 2T2 2 5	9 18R 2	30 1	40		
03A01X15A04 01A02						
6SAND BEARING FLANGE EDGE	60 1T214	10 5T 1	10 4	25 7	15 6	10
03B04X01A02 15A04						
7INST BEARING RETAINERS	30 2T2 2 5	10 6I 1	15 2	15		
03B04X01A02 15A04						
8REM BEARING RETAINERS	35 2T2 2 5	10 7R 2	15 1	20		
03B04X01A02 15A04						
9TAKE TORQUE CHECK	5 1T2 5	10 8T 2	2 9	3		
03B04X01A02 15A04						
10REM RETAINERS	75 2T2 2 5	10 9R 2	25 1	50		
03B04X01A02 15A04						
11INST RETAINER SHIMS	15 1T2 2 5	10 10I 1	5 2	510	5	
03B04X01A02 15A04						
12INST RETAIN AND PLAT	90 3T2 2 5 61010	11I 1	30 2	30 9	1510	15
03A01X15A04 01A02 03A000						
13INST SCAN PLAT HARN ASS	5 3T2 1 2 5	9 2I 1	2 2	214	1	
15B01X15B02X15B03X15B04X03A01X01A02 15A04						
14INST INBD LATCH PRESS LN	25 2T2 5 612	9 5I 1	15 2	10		
01B01X03A01 01A02 15A04						
15ROUTE SCAN PLAT HARN	10 3T2 1 2 5	10 13I 1	4 2	314	3	
15B01X15B02X15B03X15B04X03A01 01A02 15A04						
16INST INBD LATCH MICSWCTH	15 1T2 1 5	9 9I 1	8 2	7		
01B02X01B01 03A01 15A04 01A02						
17INST HARN ON CASE 3	30 2T2 1 2 5	9 23I 1	15 2	1014	5	
07C01X07A01						
18SECURE IN TENT	925 T2	10 17T17	925			
00000						
TASK 11 DAY 011 6/27/68						
1CK TORQUE ON SCAN BRACK	120 1T2 2 5	10 15T1	60 2	60		
01A02 03A01 03B04 15A04						
2INST BENDIX FASTENERS	15 2T2 1 5	11 1I 1	8 2	7		
15A03X01A02 15A01 15A02						
3INST SCAN TUBE CABL SUPP	15 2T2 1 2 5	I 1	8 2	7		
15B01 15B02 15B03 15B04 03A01 15A04						
4SECURE SCAN HARN TO TRAY	60 3T2	11 2I 1	35 2	5 9	511	814
15B04X15A02X15A03X15A01 15B01 15B02 15B03 01A02 03A01						
5TORQUE MICROSWITCHES	100 1T2 2 5	10 16I 1	35 2	3010	35	
04P09X01A05 01A06 01A07 01A08 01A02						
6SEC HAND FRAME TO CASE I	10 2T2 2	T 1	5 2	5		
05A01X						
7REM PYRO MODULES	20 2T2 1 5	11 6R 2	10 1	10		
05B01X05B02X05A01						
8CLOSE CASE EA1	110 1T2 1 2 5	11 7I 1	50 2	60		
05A01X05B03 05B10 05B11 05B12						
9ROUTE AND SEC SCAN HARN	20 3T2 1 2 5	11 4I 1	10 2	3 9	214	5
15B01X15B02X15B03X15B04X01A02 03A01 15A04						

10INST CC+S AT CONT HARNS	20 2T2 1 5	10 17I 1	10 2	514	5
07C01X07C02X07A01					
11INST HARN SCREWS ON PLAT	20 2T2 1 5	11 4I 1	10 2	10	
15B01 15B02 15B03 15B04 03A01					
12SECURE IN TENT	930 T2	11 11T17	930		
00000					
TASK 12 DAY 012 6/28/68					
1SECURE IN TENT	10 T2	11 12T17	10		
00000					
2REL BATT FOR EXT MOUNT	20 1T2	10 4T25	20		
00000					
3REL SIT FROM GAS	15 1T2	T25	15		
00000					
4REL PAS FROM GAS	15 1T2	T25	15		
00000					
5INST SIT TO BATT BRACKET	10 1T2 1 2	12 3I 1	5 2	5	
01B05X12A01					
6INST PAS ON S/C	10 1T2 2 5	12 4I 1	5 2	5	
01B06X					
7INST HARN FAST TO PLAT	40 2T2 1 2 5	9 18I 1	20 2	15 9	5
01B01X01A02 15A04					
8TEST SUBSYS M69-204.02	90 T2	12 7T27	90		
00000					
9SEC AND TORQUE 3 HARNS	100 3T2 1 2 5	10 17I 1	40 2	30 9	1014 20
07C01X07C02X07A01					
10INST CC+S MODULES	20 2T2 1 2 5	12 9I 1	10 2	10	
07B01X07B02X07B03X07B04X07C01	07C02 07A01				
11REL AT CONT MOD FROM GAS	15 1T2	T25	15		
00000					
12REL SUP SUBCHAS FROM GAS	15 1T2	T25	15		
00000					
13INST AT CONT MOD	2 2T2 1 2 5	12 11I 1	1 2	1	
07B05X07B 07A01					
14INST SUP SUBCHAS	3 2T2 1 2 5	12 12I 1	2 2	1	
07A05X07B 07A01					
15INST BATT	15 2T2 2	12 2I 1	8 2	7	
12B06X12A01					
16TORQUE MOD EARS	10 1T2 5	12 10I 2	10		
07B X07A01					
17REM BATT FROM S/C	5 2T2 2	12 15R 2	2 1	3	
12B06X12A01					
18REM PAS FROM S/C	5 1T2 1 2	12 4R 2	2 1	3	
01B06X					
19REM CASE EA 3	5 2H2 1 2	12 16R 1	2 2	226	1
00000					
20SECURE IN TENT	1035 T2	12 19T171035			
00000					
TASK 13 DAY 013 6/29/68					
1SECURE IN TENT	1440 T2	12 20T171440			
00000					
TASK 14 DAY 014 6/30/68					
1SECURE IN TENT	1440 T2	13 1T171440			
00000					
TASK 15 DAY 015 7/01/68					
1SECURE IN TENT	10 T2	14 1T17	10		
00000					
2REL BATT FROM GAS	20 1T2	12 17T25	20		
00000					
3REL CASE EA 3	20 1T2	12 19T25	20		
00000					
4INST CASE EA 3	10 2T2 2 5	15 3I 1	5 2	5	
07A01X07B					

5INST BATT	30 2T2 2	15 2I 1 15 2 15	
12B06X12A01			
6TEST SUBSYS M69-204.02	480 T2	15 5T27 480	
00000			
7INST NUTS	20 1T2 1 2	I 1 10 2 10	
11A01X			
8TORQUE CONN BRACK	30 1T2 1 2 5	15 7I 1 15 2 15	
11A01X			
9REM SCREWS FROM BRACK	38 2T2 1 2	15 8R 2 20 1 18	
11A01X			
10INST SCREWS ON BRACK	38 2T2 1 2	15 9I 1 20 2 18	
11A01X			
11INST CONN SCREWS	59 1T2 1 2	15 8I 1 30 2 29	
11A01X			
12TORQUE CONN ROUT HARN	115 2T2 1 2 5	15 11I 1 50 2 40 9 1014 15	
11C01X11C02X11A01			
13WORK ON CASE VII HARN	60 2T2 1 2 5	15 10I 1 20 2 20 9 1014 10	
11C01X11C02X11A01			
14INST CLAMP ON HARN	5 1T2 1 2 5	15 13I 1 3 2 2	
11C01X11C02X11A01			
15SECURE IN TENT	475 T2	15 14T17 475	
00000			
16INSP FTS MODS IN GAS	30 1T2	T 9 30	
08B X			
TASK 16 DAY 016 7/02/68			
1REL FTS MODS GAS	30 1T2	15 16T25 30	
00000			
2INSP FTS MODS	90 1T2	16 1T 1 45 9 45	
08B X			
3INST FTS MODS IN CASE 4	60 2T2 1 2 5	16 2I 1 30 2 30	
08900W08A01			
4REM SCREWS FROM CHAS EA4	30 2T2 1	16 3I 1 15 2 15	
08A01X			
5INST FLGHT SCRW ON BRACK	75 1T2 1 2 5	15 12I 1 40 2 35	
08A01X08B			
6TEST TORQUE ON SCAN PLAT	15 1T2 5	10 9T 2 710 8	
03A01X01A02 15A04			
7READJUST MICROSWITCH	15 1T2 1 2	16 7T 1 8 2 7	
01B02X03A01 01A02 15A04			
8TORQUE RECTANG CONNS	45 2T2 1 5	15 11I 1 5 2 1511 1514 10	
08C02X08B 08A01			
9INST CASE EA4 INC CMD MD	86 2T2 1 2 5	16 4I 1 43 2 43	
08A01X08B00W08C02			
10TEST SUBSYS INTEGRATION	74 T2	16 9T27 74	
00000			
11TURN OFF POWER	50 T2	16 10T27 50	
00000			
12REL RAD ASSY TO TENT	50 1T2	T26 50	
00000			
13REM SCREWS ON MOD EARS	5 1T2 1 5	12 16R 2 2 1 3	
10B01X			
14INST SCREWS ON MOD EARS	5 1T2 1 5	16 13I 1 3 2 2	
10B01X			
15CARRY CASE TO PIT AREA	5 2P2	16 12T28 5	
00000			
16SECURE IN TENT	805 T2	16 15T17 805	
00000			
TASK 17 DAY 017 7/03/68			
1SECURE IN TENT	30 T2	18 16T17 30	
00000			
2INSP IRR ASSY	16 1T2	T 1 8 9 8	
03B06X			

3TURN POWER ON	14 T2	16 11T27	14
00000			
4REL CANOPUS SEN FROM GAS	10 1T2	T25	10
00000			
5REL FEPS FROM GAS	50 1T2	T25	50
00000			
6REL MARS GATE FROM GAS	15 1T2	T25	15
00000			
7INST FEPS ON S/C	2 2T2 5	17 5I 1	1 2 1
03803X03A01 01A02 15A04			
8INST MARS GATE	73 2T2 1 2 5	17 6I 1	37 2 36
03801X03B02X03B03 03A01 01A02 15A04			
9IRR PRESS PREP	100 3T2 2 6	T 1	70 2 30
03815X03B06X03B01 03B02 03B03 03A01 15A04 01A02			
1CINST PROTO CANOPUS SEN	15 2T2 1 5	17 4I 1	8 2 7
13B08X01A02			
11PREP TO INST GYROS	55 1T2 1 2	T 1	28 2 27
07B06X07B 07A01 07C01 07C02			
12INST GYROS ON S/C	120 2T2 1 2	17 11I 1	60 2 60
07B06X07B 07A01 07C01 07C02			
13REL BATT TO GAS	18 1T2	15 5R26	18
00000			
14TURN POWER OFF	20 T2	17 3T27	20
00000			
15SECURE IN TENT	902 T2	17 14T17	902
00000			
TASK 18 DAY 018 7/04/68			
1SECURE IN TENT	1440 T2	17 15T171440	
00000			
TASK 19 DAY 019 7/05/68			
1SECURE IN TENT	1440 T2	18 1T171440	
00000			
TASK 20 DAY 020 7/06/68			
1SECURE IN TENT	1440 T2	19 1T171440	
00000			
TASK 21 DAY 021 7/07/68			
1SECURE IN TENT	1440 T2	20 1T171440	
00000			
TASK 22 DAY 022 7/08/68			
1SECURE IN TENT	35 T2	21 1T17	35
00000			
2REL PYRO MODS	10 1T2	11 8T25	10
00000			
3REL BATT FROM GAS	5 1T2	17 13T25	5
00000			
4INST PYRO MODS	20 2T2 1 2 5	22 2T 1	10 2 10
05B01X05B02X05A01 05B03 05B10 05B11 05B12			
5TORQUE CASE SCREWS	5 1T2 5	22 4I 2	5
05A01X			
6INST BATT	3 2T2 1 2	22 3I 1	2 2 1
12B06X12A01			
7REL CLOCK AXIS	1 1T2	T25	1
00000			
8REL CONE AXIS	1 1T2	T25	1
00000			
9INST CLOCK AXIS	20 2T2 1 2 5	21 7I 1	10 2 10
03B04X03A01 03B01 03B02 03B03 03B06 01A02 15A04			
10INST CONE AXIS	20 2T2 1 2 5	21 8I 1	10 2 10
03B05X03A01 03B01 03B02 03B03 03B06 01A02 15A04			
11MATE INT CONN	45 2T2 6	I 1	15 2 1511 15
15B01X15B02X15B03X03A01 03B01 03B02 03B03 03B06 C3B15 01A02 15A04			
12INST PS TO HOOD	15 1T2 1 5	9 7I 1	7 2 8

13901X	15	1T2	1	5	9	7I	1	7	2	8				
13INST PS TO HOOD	15	1T2	1	5	9	7I	1	7	2	8				
13801X														
14INST SUN SENSOR TO HOOD	30	2T2	1	5	4	14I	1	15	2	15				
13803X13804X13805X13806X15A04														
15INST CANOPUS SEN TO HOOD	30	2T2	1	5	17	10I	1	15	2	15				
13808X13810X														
16MATE GAS SYSTEM	85	3T2	1	2	3	I	1	45	2	40				
13A00W														
17REL PROP SYSTEM	10	2T2				T25		10						
00000														
18INST PROP SYSTEM TO S/C	74	4T2	12	3	5	22	17I	1	40	2	24	9	511	5
06800WC6C00W01A02														
19TURN POWER ON	56	T2				17	14T	27	56					
00000														
20TURN POWER OFF	5	T2				22	19T	27	5					
00000														
21TURN POWER ON	30	T2				22	20T	27	30					
00000														
22TURN POWER OFF	30	T2				22	21T	27	30					
00000														
23REM CONNECTOR	1	1T2				22	6R	11	1					
12806X														
24TURN POWER ON	2	T2				22	22T	27	2					
00000														
25TURNPOWER OFF	10	T2				22	24T	27	10					
00000														
26SEC IN TENT	882	T2				22	25T	17	882					
00000														
TASK 23 DAY 023 7/09/68														
1PREP TO REMOVE CASE 8	30	1T2	1	5		22	23T	1	15	2	15			
12A01X														
2REM MODS FROM CASE 8	70	2T2	1	2	5	23	1R	1	35	2	35			
12804X12801 12A01														
3REL PIN PULL HARNS	35	2T2					T25		35					
00000														
4LOOSEN CABLE CLAMPS	15	2T2	1	2	5	23	2T	1	7	2	8			
12C01X12801X12804X12A01														
5ROUT HARN	155	2T2	1	2	5	23	4T	1	70	2	7011	15		
07C02X07C01 07B 07A01														
6INST PWR CONT SUBASSY	25	2T2	1	2	5		T	1	5	2	5	9	525	526
12804X12C01 12801 12A01														
7REM GYRO CONT FROM S/C	55	2T2	1	5		17	12R	2	30	1	25			
07806X07B 07C 07A01 07A05														
8INST GYRO ON S/C NFU	45	2T2	1	2	5	23	7I	1	25	2	20			
07806X07B 07C 07A01 07A05														
9REL CHAS SCI EQUIP	5	1T2												

TASK 24 DAY 024 7/10/68

1SECURE IN TENT	15 T2	23 16T17	15
00000			
2REM BAT MT INST EA 8	15 2T2 1 2 5	22 6X 2	7 1 8
12B06X12A01X12C01 12B01 12B04			
3INST CASE EA 7	10 2T2 1 2 5	I 1	4 2 4 5 2
11A01X11B01 11B02 11B03 11B04	11C01 11C02		
4INST BATT MOUNT	5 2T2 1 2	24 2I 1	3 2 2
12B06X12A01			
5REL IRR FROM OAS	25 1T2	17 2T25	25
00000			
6INST IRR ON S/C	63 3T2 1 2 5	24 5I 1	27 2 26 9 10
03B06X03B01 03BC2 03B03 03A01	15A04 01A02		
7TURN ON POWER	5 T2	24 6T27	5
00000			
8TURN ON GYRO	1 T2	23 8T27	1
00000			
9TURN OFF GYRO	1 T2	24 8T27	1
00000			
10TURN ON GYRO	50 T2	24 9T27	50
00000			
11TEST A/C GAS SYS ASSY +X	10 1T2	22 16T27	10
00000			
12TEST A/C GAS SYS ASSY -X	20 1T2	22 16T27	20
00000			
13PRESS1A/ GAS SYS +X	48 1T2	24 11T27	48
00000			
14TURN POWER OFF	22 T2	24 7T27	22
00000			
15COMP PRESS A/C GAS SYS	50 T2	24 13T27	50
00000			
16REM PSS HOOD CABLE	3 1T2 1 5	22 14R 2	4 1 4
13B01X01A02			
17INST PSS CABLE TO S/N 09	7 T2 1 5	24 16I 1	3 2 4
13B01X01A02			
18TURN ON POWER	18 T2	24 17T27	18
00000			
19RUNNING DOWN GYROS	3 T2	24 10T27	3
00000			
20GYROS DOWN	14 T2	24 19T27	14
00000			
21PRESS A/C GAS SYS -X	60 T2	24 12T27	60
00000			
22COMP PRESS A/C GAS SYS	75 T2	24 21T27	75
00000			
23RUNNING DOWN GYROS	5 T2	T27	5
00000			
24GYROS DOWN	5 T2	24 23T27	5
00000			
25TURN OFF POWER	5 T2	24 24T27	5
00000			
26SECURE IN TENT	900 T2	24 25T17	900
00000			

TASK 25 DAY 025 7/11/68

1SECURE IN TENT	10 T2	24 26T17	10
00000			
2PERFORM PYRO CHECKS	55 T2	23 14T27	55
00000			
3REM PSS HOOD	2 1T2 1 5	24 17R 2	1 1 1
13B01X			
4INST PSS HOOD S/N 09	3 1T2 1 5	25 3I 1	2 2 1
13B01X			

5CONN SS TERMINATIONS	15 1T2 1 2	4 14T 1	8 2	7	
13R05X13B06X15A04					
6TORQUE CONNECTORS	15 2T2 1 2 5	I 1	5 2	511	5
05B01X05B02X05B10 05B11 05B12 05A01					
7INST LIGHT SOURCE ON IRR	36 1T2 1 6	24 6I 1	20 2	16	
03B06X03A01 03B01 03B02 03B03 03B15 15A04 01A02					
8TURN ON POWER	34 T2		T27	34	
00000					
9POWER OFF RUN DOWN GYROS	110 T2	25	8T27	110	
00000					
10TURN ON POWER	20 T2	25	9T27	20	
00000					
11REP SQUIB SIM FOR TEST	32 T2		T27	32	
00000					
12REM UV SPEC TO S/C 69-2	3 T2		T27	3	
00000					
13TURN OFF POWER	3 T2	25	10T27	3	
00000					
14REM IRR STIM	57 T2 6	25	7R 2	27 1	30
03B06X03A01 03B01 03B02 03B03 15A04 01A02					
15TORQUE CONNECTORS	5 T2 1 5	25	6I 1	211	1 2 2
05B01X05B02X05B03 05B10 05B11 05B12 05A01					
16SECURE IN TENT	1040 T2	25	15T171040		
00000					
TASK 26 DAY 026 7/12/68					
1SECURE IN TENT	80 T2	25	16T17	80	
00000					
2TURN POWER ON	85 T2	25	13T27	85	
00000					
3TURN POWER OFF	43 T2	26	2T27	43	
00000					
4MATE IRR CONNS	2 1T2 5	25	7R11	2	
03B06X					
5TURN POWER ON	58 T2	26	3T27	58	
00000					
6TURN POWER OFF	1 T2	26	5T27	1	
00000					
7RELEASE CASE EA 5	71 2T2		T25	71	
00000					
8INST CASE 5	45 3T2 1 2 5	26	7I 1	20 2	15 9 10
09300W09A01X09C01X					
9TURN POWER ON	128 T2	26	6T27	128	
00000					
10TURN POWER OFF	2 T2	26	9T27	2	
00000					
11REM BATT	5 2T2 1 2	24	R 1	2 2	3
12B06X12A01					
12SECURE IN TENT	920 T2	26	11T17	920	
00000					
TASK 27 DAY 027 7/13/68					
1SECURE IN TENT	1440 T2	26	12T171440		
00000					
TASK 28 DAY 028 7/14/68					
1SECURE IN TENT	1440 T2	27	1T171440		
00000					
TASK 29 DAY 029 7/15/68					
1SECURE IN TENT	15 T2	28	1T17	15	
00000					
2INST BATT	15 2T2 1 2	26	11I 1	8 2	7
12B06X12A01					
3INTERFACE DSS	35 T2	29	2T27	35	
00000					

4TURN POWER ON	40 T2	26 10T27 40
00000		
5PERFORM PYRO CK	155 T2	25 2T27 155
00000		
6TURN POWER OFF	47 T2	29 4T27 47
00000		
7REM GYRO CONTROL	13 2T2 1 2 5	23 8R 1 7 2 6
07A06X07B 07C01 07C02 07A05 07A01		
8INST GYRO CONTROL	15 T2 1 2 5	26 5I 1 8 2 7
07B06X07B 07C01 07C02 07A05 07A01		
9REL MONO TEL FROM OAS	5 1T2	T25 5
00000		
10REM PYRO MODS	32 2T2 1 2 5	25 2R 1 16 2 16
C5B01X05B02X05B03 C5B10 05B11 C5B12 05A01		
11TURN POWER ON	3 T2	29 6T27 3
00000		
12TURN POWER OFF	40 T2	29 11T27 40
00000		
13REM ANALOG MOD	40 2T2 1 2 5	26 8I 1 20 2 20
09B02X09B 09A01 09C01		
14REM SQUIB SIMULATOR	20 2T2 1 6	25 11R 1 10 2 511 5
09A01 09B 09C01		
15INST SQUIB SIMULATOR	20 2T2 1 6	29 14I 1 10 2 511 5
09A01 09B 09C01		
16CLOSE CASE	15 1T2 1 2 5	29 10T 1 8 2 7
09A01X09B 09C01		
17TIED HARN	5 2T212	T 1 2 2 214 1
15B05X15B C3A01 03B01 03B02 03B03 03B06 15A04 01A02		
18REL FEPS HOOD	5 T2	T25 5
00000		
19INST FEPS HOOD	10 1T2 1 2	29 18I 1 5 2 5
03B03X03A01 03B01 03B02 03B04 03B05 03B06 15A04 01A02		
20SEC IN TENT	910 T2	29 19T17 910
00000		
TASK 3D DAY 03D 7/16/68		
1SEC IN TENT	25 T2	29 20T17 25
00000		
2INST IRS	52 4T2 1 2 5 629	9I 1 20 2 20 9 12
03B15X03B17X03AC1 03B01 03B02 03B03 03B04 03B05 03B06 03B16 15A04 01A02		
3REM IRS	13 4T2 1 2 5 630	2R 1 5 2 4 7 4
03B15X03B17X03AC1 03B01 03B02 03B03 03B04 03B05 03B06 03B16 15A04 01A02		
4INST IRS	15 4T2 1 2 5 630	3I 1 6 2 6 9 3
03B15X03B17X03AC1 03B01 03B02 03B03 03B04 03B05 03B06 03B16 15A04 01A02		
5TURN POWER ON	42 T2	29 12T27 42
00000		
6TURN POWER OFF	42 T2	30 5T27 42
00000		
7TEST SCAN INTERFACE	24 T2	22 17Z7 24
00000		
8TURN POWER ON	148 T2	30 6T27 148
00000		
9TURN POWER OFF	7 T2	30 8T27 7
00000		
10TORQUE DBB NUTS	5 1T2	30 9I 1 3 2 2
13ADOW		
11SEC IN TENT	1067 T2	30 10T171067
00000		
TASK 3I DAY 03I 7/17/68		
1SECURE IN TENT	56 T2	30 11T17 56
00000		
2TURN POWER ON	104 T2	27 104
00000		

3TURN POWER OFF	20	T2	31	2T27	20				
00000									
4REL PYRO CONT FROM GAS	20	1T2		T25	20				
00000									
5INST PYRO MOOS	20	2T2	1	2	5	31	3I	1	10 2 10
05B01X05B02XC5A01									
6INST SCREWS	85	2T2	1	2	5	31	4I	1	45 2 40
05A01XC5B01 05B02									
7TURN ON POWER AND GYROS	10	T2				31	3T27		10
00000									
8RUN DOWN GYROS	35	T2				31	7T27		35
00000									
9TURN OFF POWER	3	T2				31	7T27		3
00000									
10TURN ON POWER	12	T2				31	9T27		12
00000									
11REM MONOCHROMETER TELE	25	1T2	1	5		30	4R	1	10 2 1026 5
03R16X03A01 03B01 03B02 03B03 03B04 03B05 03B06 03B15 03B17 01A02 15A04									
12INST IRR LIGHT HOOD	134	1T2	1	2		31	12I	1	100 2 34
03B06X03B16 03A01 03B01 03B02 03B03 03B04 03B05 03B15 03B17 01A02 15A04									
13TURN OFF POWER	256	T2				31	10T27	255	1 1
00000									
14REWORK RING HARN	30	2T2	1	212		29	17I	1	10 2 1014 10
15A04X03A01 03B01 03B02 03B03 03B04 03B05 03B06 03B15 03B17 01A02									
15SOLDER GROUND LUGS	10	2T2111213				31	14I	1	4 2 4 8 2
15B04X15B 03A01 03B01 03B02 03B03 03B05 03B06 01A02									
16SPICE SCAN XDUCER	20	2T2	11112			30	7I	1	5 2 514 10
03B21X03B 03A01 15A04 01A02									
17INST SWITCHS ON SCAN PLAT	45	3T2	1	2	5	31	16I	1	15 2 15 9 511 10
05B10X05B11X05B12X05B01 05B02 05B03 05A01 03B 03A01 03B01 03B02 01A20 01A21									
18RELOCATE AT CONT HARN	10	2T212				23	5I	1	3 2 314 4
07C01X07C02507C03X07B 07A05 07A01									
19HARDMOUNT GROUND LUGS	45	3T2	1	2	51331	15I	1	15 2 15 8 10 9 5	
15B04X15B 03B 03A01 15A04 01A02									
20REPLACE CENT SCAN PLAT	5	2T2	1	2	4	31	17I	1	3 2 2
03A01X03B 01A02 15A04									
21SECURE IN TENT	495	T2				31	20T17		495
00000									
TASK 32 DAY 032 7/18/68									
1SECURE IN TENT	5	T2				31	21T17		5
00000									
2REL UV SPECT FROM GAS	12	1T2					T25		12
00000									
3REL MONOCHROM TELE	13	1T2				31	11T25		13
00000									
4INST OV SPEC	10	3T2	1	2	5	32	2I	1	4 2 3 9 3
03B08X03B 03A01 15A04 01A02									
5INSP MONOCHROM TELE	20	2T2				32	3T	1	10 9 10
03B08003B 03A01 15A04 01A02									
6INST MONOCHROM TELE	10	3T2	1	2	5	32	5I	1	5 2 5
03B08X03B 03A01 15A04 01A02									
7PURSE MONOCHROM TELE	53	3T2	1	2	6	32	6I	1	20 2 2010 13
03B16X03B15X03B 03A01 15A04 01A02									
8TURN ON POWER AND GYROS	7	T2				31	13T27		7
00000									
9RUNNING DOWN GYROS	40	T2				32	8T27		40
00000									
10REM MONOCH TELE COVER	10	1T2				32	7R	1	10
03B16X03B 03A01									
11INST MONOCH TELE COVER	5	1T2				32	10I	1	5
03B16X03B 03A01									
12REM MONOCH TELE COVER	5	1T2				32	11R	1	5

03B16X03B 03A01							
13INST HOOD ON UV SPECT	15	2T2 1 2	32	4I 1	8 2	7	
03B08X03B 03A01							
14RET CANOPUS SEN TO GAS	46	1T2		T26	26 9	20	
13B08X13B10X							
15PWR OFF IRR IRS CONN	49	2T2	32	8T 1	1011	1027	29
03B06X03B16X03B 03A02							
16REM CANOPUS SENSOR	3	2T2 1 2	32	14R 1	2 2	1	
13B08X13B10X							
17INST CANOPUS SENSOR	2	2T2 1 2	32	16I 1	1 2	1	
13B08X13B10X							
18INST TOP PLATE CANOPUS	5	2T2 1 2	32	17I 1	3 2	2	
13B08X13B10X							
19REM ATR DTR REC ELECT	5	1T2 1 2 5		R 1	3 2	2	
09B08X09B 09CC1 09A01							
20RET ATR DTR MOD TO GAS	26	1T2	32	19I26	26		
00000							
21TURN ON POWER AND GYROS	70	T2	32	15T27	70		
00000							
22RUN DOWN GYROS	14	T2	32	21T27	14		
00000							
23RUN UP GYROS	15	T2	32	22T27	15		
00000							
24RUN DOWN GYROS	81	T2	32	23T27	81		
00000							
25TURN OFF POWER	9	T2	32	21T27	9		
00000							
26PURGE SOLAR PANEL	90	T2		T27	90		
00000							
27SEC SOLAR PANEL FROM OSE	5	T2	32	26T27	5		
00000							
28SECURE IN TENT	815	T2	32	27T17	815		
00000							
TASK 33 DAY 033 7/19/68							
1SEC IN TENT	45	T2	32	28T17	45		
00000							
2SEC SIT FROM GAS	5	1T2		T25	5		
00000							
3TURN POWER AND GYROS ON	5	T2	32	25T27	5		
00000							
4INST SIT ON EXT MOUNT	55	1T2 1 2	33	2I 1	30 2	25	
01B05X01A02							
5REM UV SPECT STIM	55	1T2 1 2	32	13R 1	30 2	25	
03B08X03B 03A01							
6PURGE GAS SYSTEM	15	T2		T27	15		
00000							
7INST SHIP COV ON UV SPEC	60	T2 1 2	33	5I 1	20 2	20 9	20
03B08X							
8TURN OFF POWER	38	T2	33	3T27	38		
00000							
9RUN DOWN GYROS	38	T2	33	3T27	38		
00000							
10TURN POWER ON	104	T2	33	8T27	104		
00000							
11TURN OFF POWER	12	T2	33	10T27	12		
00000							
12TURN ON POWER	12	T2	33	11T27	12		
00000							
13RUN UP GYROS	12	T2	33	9T27	12		
00000							
14TURN OFF POWER	1	T2	33	12T27	1		
00000							

15RUN DOWN GYROS	1 T2	33 13T27	1		
00000					
16RET IR GAS ASSY TO DIV	7 1T2	30 4T26	7		
00000					
17REM INVERTER MOD	25 1T2 1 2 5	31 6R 2	13 1	12	
05B06X05B 05A01					
18REM BATT AND SIT	10 2T2 1 2 6	29 2R 2	5 1	5	
12B06X01B05X12A01					
19SECURE IN TENT	940 T2	33 18T17	940		
00000					
TASK 34 DAY 034 7/20/68					
1SECURE IN TENT	1440 T2	33 19T17	1440		
TASK 35 DAY 035 7/21/68					
1SECURE IN TENT	1440 T2	34 1T17	1440		
TASK 36 DAY 036 7/22/68					
1SECURE IN TENT	15 T2	36 1T17	15		
00000					
2INST BATT	65 2T2 1 2 6	33 18I 1	35 2	30	
12B06X12A01					
3REM CASE 4 FROM S/C	60 2T2 1 2 5	16 5R 1	10 2	10 5	518 527
08B06X08A01X08C00W					
4INST INVERTER MODS	74 1T2 1 2 5	33 17I 1	37 2	37	
05B06X05B 05A01					
5TURN ON POWER	3 T2	33 14T27	3		
00000					
6TURN OFF POWER	136 T2	36 5T27	136		
00000					
7TURN ON POWER	52 T2	36 6T27	52		
00000					
8TURN OFF POWER	75 T2	36 7T27	75		
00000					
9SEC CASE 4 FROM OSE	25 2T2	36 3T25	25		
00000					
10INST CASE 4 ON S/C	35 2T2 1 2 5	36 9T 1	20 2	15	
11SECURE IN TENT	900 T2	36 10T17	900		
00000					
TASK 37 DAY 037 7/23/68					
1SECURE IN TENT	30 T2	36 11T17	30		
00000					
2CABLE S/C FOR TESTS	75 T2	36 9T 1	3827	37	
3TURN ON POWER	5 T2	36 8T27	5		
00000					
4TURN OFF POWER	25 T2	37 1T27	25		
00000					
5TURN ON POWER	35 T2	37 4T27	35		
00000					
6REC CANOPUS SEN IN GAS	22 T2	32 17T26	22		
00000					
7TURN OFF POWER	115 T2	37 5T27	115		
00000					
8TURN ON POWER	42 T2	37 7T27	42		
00000					
9TURN OFF POWER	31 T2	37 8T27	31		
00000					
10TURN ON POWER	15 T2	37 9T27	15		
00000					
11TURN OFF POWER	9 T2	37 10T27	9		
00000					

12TURN ON POWER	24	T2	37	11T27	24		
00000							
13TURN OFF POWER	82	T2	37	12T27	82		
00000							
14REM SCAN PLAT HOOD	15	2T2 1 2 5	29	17R 1	5 2	526	5
03A02X03A01 03B							
15SECURE IN TENT	915	T2	37	14T17	915		
00000							
TASK 38 DAY D38 7/24/69							
1SECURE IN TENT	57	T2	38	15T17	57		
00000							
2TURN ON POWER	19	T2	37	13T27	19		
00000							
3TURN OFF POWER	7	T2	38	2T27	7		
00000							
4TURN ON POWER	24	T2	38	3T27	24		
00000							
5TURN OFF POWER	13	T2	38	4T27	13		
00000							
6TURN ON POWER	15	T2	38	5T27	15		
00000							
7TURN OFF POWER	25	T2	38	6T27	25		
00000							
8TURN ON POWER	25	T2	38	7T27	25		
00000							
14TURN OFF POWER	15	T2	38	13T27	15		
00000							
15REM 9ATT	5	2T2 1 2	36	2R 2	3 1	2	
12B06X12A01							
16REM CASE 7	10	2T2 1 2 5	24	3R 2	4 1	414	2
11B05X11B06X11B07X11B08X11C	11A01 11B01 11B02 11B03 11B04						
17INST 8ATT	15	2T2 1 2	38	15I 1	8 2	7	
12B06X12A01							
18REM LOGIC MOD FROM CASE7	10	1T2 1 2	38	16R 2	5 1	5	
11B02X11B 11C 11A01							
19INST TV ELECT HARN	5	2T2 1 2 12	38	18I 1	2 2	214	1
11C03X11A01X11C01 11C02 11B							
20TURN ON POWER	35	T2	38	14T27	35		
00000							
21TURN OFF POWER	35	T2	38	20T27	35		
00000							
22INST LOGIC MOD	5	T2 1 2	38	18I 1	3 2	2	
11B02X11B 11C 11A01							
23TORO TV MODS	5	1T2 5	38	19I 2	5		
11B08X11B07X11B 11C 11A01							
24TORO TV MODS	7	1T2 5	38	19I 2	7		
11B05X11B 11C 11A01							
25TORO TV DATA CONVERTER	38	1T2 5	38	19I 2	38		
11B06X11B 11C 11A01							
26REM BATT	10	2T2 1 2	38	17R 2	5 1	5	
12B06X12A01							
27REL DATA PROC SUBASSY	5	T2		12S	5		
00000							
28REM SUBASSYS	20	2T2 1 2	36	10R 2	10 1	511	5
C8B10X08B11X08B18X08B 08C02 C8A01							
29SEC CASE 7 HARN	7	2T2 1 2 5 1238	16T 1	2 2	214	3	
11C03X11C01 11C02 11B 11A01							
30INST CASE 4 SUBASSYS	3	2T2 1 2	38	28I 1	1 2	111	1
C8B10X08B11X08B18X08B02X08B C8C02 C8A01							
31INST CASE 7	20	2T2 1 2	38	29I 1	10 2	10	
11A01X11B 11C							
32MATE TV HARN	5	2T2 6	38	19I 1	2 2	2 9	1

11C03X15A01 15A02 15A03									
33REM CASE 7	15	2T2	1	2	38	31R	2	0	1 7
11A01X11B 11C									
34RETRY TO INST CABLE TRAY	65	2T2	1	212	38	32I	1	20	2 20 9 514 20
11C03X11C02 11C01 11B 11A01									
35INST CASE 7	40	2T2	1	2	38	33I	1	20	2 20
11A01X11B 11C									
36MATE CONNECTORS	275	T2			38	34I	1	125	9 2511 125
11C03X15B01X15B02X15B03X15B04X15B05X15A01X15A02X15A03X11C01X11A01 11B 11C02									
37MOUNT LOGIC MOD FOR TEST	5	1T2	1	2	38	22I	1	3	2 2
11B02X11B 11C 11A01									
38SECURE IN TENT	600	T2			38	37I	17	600	
00000									
TASK 39 DAY 039 7/25/68									
1SECURE IN TENT	80	T2			38	38I	17	80	
00000									
2TURN POWER ON	1	T2			38	21I	27	1	
00000									
3REM SP SUPP DEPLOY BAY	89	2T2	1	2		R	1	45	2 44
C1A09XC1A10XC1A11XC1A12XC1A02									
4TURN POWER OFF	25	T2			39	2I	27	25	
00000									
5REM TV CAMER SUB ASSY	5	2T2	1	2	38	24R	2	3	1 2
11B07X11C 11B01 11B02 11B03 11B04 11A01									
6REM TV DATA CONVERTER	5	2T2	1	2	38	25R	2	3	1 2
11B06X11C 11B01 11B02 11B03 11B04 11A01									
7REM TV CONT	5	2T2	1	2	38	23R	2	3	1 2
11B08X11C 11B01 11B02 11B03 11B04 11A01									
8REM TV POWER	5	2T2	1	2	38	24R	2	3	1 2
11B05X11C 11B01 11B02 11B03 11B04 11A01									
9REM DATA STOR CHAS 20SE	10	2T2	1	2	29	16R	2	5	1 5
09AC1X09E 09C									
10INST DAS LOGIC SUB ASSY	5	1T2	1	2 5	38	37I	1	3	2 2
11B02X11B 11C 11A01									
11REM DATA CHAS FROM SAF	15	1T2			39	9R	26	15	
00000									
12REC IR SPEC GAS STOR ASS	10	1T2			33	16I	18	10	
00000									
13INST ATR + DTR REC ELECT	70	1T2	1	2		I	1	35	2 35
09B08X09B 09C01 09A01									
14REL WIDE ANG TV CAM ASSY	1	1T2				T25		1	
00000									
15INST BATT	2	2T2	1	2	38	26I	1	1	2 1
12B06X12A01									
16TURN POWER ON	7	T2			38	21I	27	7	
00000									
17INST WIDE ANG TV CAMERA	5	2T2	1	2 5	39	14I	1	2	2 2 9 1
03B10X03B 03A									
18REL NARR ANG TV CAMERA	6	2T2				T25		6	
00000									
19INST NARP ANG TV CAMERA	54	3T2	1	2 5	39	18I	1	20	2 20 9 14
03B12X03B 03A									
20TURN POWER OFF	2	T2			39	16I	27	2	
00000									
21MATE CABLE TO SCI POW HN	2	2T2				T	1	111	1
15B01X15B02X15B03X15B04X15B05X15A01 11B01X									
22MATE TEST CABLE	3	2T2				T	1	211	1
11C03X11C 11B03X									
23MATE TEST CABLE	5	T2							

DESCRIPTION	QTY	UNIT	QTY	UNIT	QTY	UNIT	QTY	UNIT
25INSP TV MODS IN QAS	5	T2	38	24T 9	326	2		
00000								
26REM BATT	2	2T2 1 2	39	15R 1	1 2	1		
12B06X12A01								
27INST TV POWER SUPPLY	2	1T2 1 2	39	8I 1	1 2	1		
11B05X11B 11C 11A01								
28INST TV DATA CONVERTER	2	1T2 1 2	39	6I 1	1 2	1		
11B06X11B 11C 11A01								
29INST TV CAMERA	2	1T2 1 2	39	5I 1	1 2	1		
11B07X11B 11C 11A01								
30INST TV CONT SUB ASSY	2	1T2 1 2	39	7I 1	1 2	1		
11B08X11B 11C 11A01								
31INST BATT	15	T2 1 2	39	26I 1	8 2	7		
12B06X12A01								
32TURN POWER ON	60	T2	39	20T27	60			
00000								
33TURN POWER OFF	5	T2	39	32T27	5			
00000								
34SEC IN TENT	918	T2	39	33T17	918			
TASK 40 DAY 040 7/26/68								
1SEC IN TENT	60	T2	39	34T17	60			
00000								
2TURN ON POWER	19	T2	39	33T27	19			
00000								
3TURN OFF POWER	24	T2	40	2T27	24			
00000								
4TURN ON POWER	37	T2	40	3T27	37			
00000								
5INST BRACK FOR SCAN PLAT	15	2T2 1 2	32	20I27	15			
00000								
6TEST PIN RETENT BEF ETL	35	T2		T27	35			
00000								
7TURN OFF POWER	2	T2	40	4T27	2			
00000								
8REM SCAN PLAT BRACKS	234	T2	40	5R27	234			
00000								
9REM MODE + RATE MOD	5	1T2 1 2	38	30R 2	3 1	2		
08B11XC8B 08C 08A01								
10REM DATA PROC MOD	5	1T2 1 2	38	30R 2	2 1	3		
08B07XC8B 08C 08A01								
11REM CASE 4 MODS	5	2T2 1 2	38	30R 2	2 1	226	1	
08B07XC8B10XC8B11XC8B18XC8B	08C 08A01							
12INST CASE 4	1	2T2 1 2	40	11I 1	1 2			
08A01X								
13PURG A/C GAS SYS ASSY	14	T2	30	10T 1	710	7		
13A01X13A02 13A03 13A04 13A05	13A06 13A07 13A08							
14REM BATT	15	2T2 1 2	39	31R 2	8 1	7		
12B06X12A01								
15SEC SIT TO BATT	15	2T2 1 2	40	14I 1	8 2	7		
01B05X12B06X12A01								
16REM CLOCK AXIS	12	2T2 1 2 5	22	9R 2	6 1	526	1	
03B04XC03B 03A								
17REM CONE AXIS	13	2T2 1 2 5	22	10R 2	6 1	626	1	
03B05XC03B 03A								
18CHARGE GAS VESSEL	5	1T2	39	12T 1	310	2		

TASK 42 DAY 042	7/28/68										
1SECURE IN TENT		1440	T2			41	1T17	1440			
00000											
TASK 43 DAY 043	7/29/68										
1SECURE IN TENT		10	T2			42	1T17	10			
00000											
2INST BATT		55	2T2	1	2	40	14I	1	30	2	25
12B06X12A01											
3INST DATA PROC SUB ASSY		7	2T2	1	2	40	10I	1	3	2	311 1
08B07X08B C8A01 D8C02											
4INST TRANS REG SUB ASSY		3	2T2	1	2		I	1	1	2	111 1
08B10X08B D8A01 D8C02											
5INST MOD + RATE CONT ASS		5	2T2	1	2	40	9I	1	2	2	211 1
08B11X08B D8AC1 D8C02											
6INST POWER SUPPLY ASSY		15	2T2	1	2		I	1	7	2	711 1
C8R18X08B C8A01 C8C02											
7INST CASE IV MODS		55	2T2	1	2	5	40	11I	1	30	2 25
D8A01X08B C8C02											
8REM CASE I MODS		2	2T2	1	2	5	31	5R	2	1	1 1
05B10X05B11XC5B12 05B03 05B02 05B01 05A01											
9OPEN CASE IV		5	2T2	1	2		43	7T	2	3	1 2
08A01X											
10INST DECK SUB ASSY		10	1T2	1	2			I	1	5	2 5
08B16X08B C8C02 08A01											
11REM SERVO AMP		10	1T2	1	2		43	8R	2	5	1 5
C5B12X05B03 05B02 05B01 05A01 05C04X											
12CLOSE CASE IV		5	2T2	1	2		43	9T	1	3	2 2
08A01X											
13CLOSE CASE I		230	2T2	1	2		43	8T	1	115	2 115
08A01X											
14TURN POWER ON		10	T2				40	7T27	10		
00000											
15TURN POWER OFF		30	T2				43	14T27	30		
00000											
16TURN POWER ON		10	T2				43	15T27	10		
00000											
17TURN POWER OFF		30	T2				43	16T27	30		
00000											
18REM MODS FROM CASE III		15	2T2	1	2		15	4R	2	5	1 526 5
07B01X07B02X07B03X07B04X07B05 07B06 07C 07A05 07A01											
19SECURE IN TENT		933	T2				43	18T17	933		
00000											
TASK 44 DAY 044	7/30/68										
1SECURE IN TENT		197	T2				43	19T17	197		
00000											
2ALIGN TORQUE S/PS		95	3T2	1	5	10	32	27I	1	30	2 30 9 1810 17
01A05X01A06XC1AC7XC1AD8X01A02 01A09X01A10X01A11X01A12X											
3TURN POWER ON		253	T2				43	17T27	253		
00000											
4TURN POWER OFF		5	T2				44	3T27	5		
00000											
5SEC IN TENT		890	T2				44	4T17	890		
00000											
TASK 45 DAY 045	7/31/68										
1SEC IN TENT		50									

5REM WIDE ANG TV CAMERA	2	T2 2	39	29R 2	1	1	1
03B10X03B 03A 15A04							
6REM BATT	7	T2 1 2	43	2R 1	4	2	3
12B06X12A01							
7INST BAT REM CS7 MODS	66	T2 1 2 5	45	6I 1	43	2	43
12B06X12A01 11B05X11B06X11B07X11B08X11C	11B01	11B02	11B03	11B04	11A01		
8TURN POWER ON	120	T2	45	4T27	120		
00000							
9TURN POWER OFF	30	T2	45	5T27	30		
00000							
10REM MONO TEL	30	3T2 1 2	32	5R 2	15	1	15
03B16X03B15X03B17X03B21 03B22 03B12 03B01 03B02 03B03 03B04 03B05 03B06 03A							
11INST ECI ON CONNECTOR	20	2T2	39	23I 1	8	9	411 8
15B01X15B02X15B03X15B04X15B05X15A01 15A02 15A03							
12REM CANOPUS HOOD	85	2T2 1 2	32	17R 2	45	1	40
13A1CX13B11X13B08 13B09 01A02							
13CK ECI	60	1T2	45	11T 1	20	9	2027 20
15B01X15B02X15B03X15B04X15B05X15A01 15A02 15A03							
14SOLDER COAX CONNECTOR	45	2T21113		I 1	10	2	10 8 15 9 10
15B X15A01 15A02 15A03							
15MODIFY MONO TEL	45	2T2 1 2	45	10T 1	25	2	20
15B X15A01 15A02 15A03							
16POT MONO TEL CONNS	15	3T215	45	15T 1	712		8
15B X15A01 15A02 15A03							
17SECURE IN TENT	669	T2	45	16T17	669		
00000							
TASK 46 DAY 046 8/01/68							
1SECURE IN TENT	215	T2	45	17T17	215		
00000							
2INST MONO TEL	25	3T2 1 2 5	45	16I 1	13	2	12
03B16X03B 03A 15A01 01A02							
3REM PROP SYSTEM ASSY	5	5T2 1 2 4		R 2	3	1	2
06A05X06B01X06B02X06B03X06B04X06C01X06C02X06C03X06C04X06C05X06C06X01A02							
4INST PROP SYSTEM ASSY	10	5T2 1 2 4	46	3I 1	5	2	5
06A05X06B01X06B02X06B03X06B04X06C01X06C02X06C03X06C04X06C05X06C06X01A02							
5INST HARN ON ADAP STRUCT	65	2T2 1 2 5		I 1	20	2	15 9 1514 15
15A10X01A23X01A24X							
6REM CANOPUS SENSOR	10	2T2 1 2	45	12R 2	4	1	426 2
13B08X13B09X							
7IDENT UP RING HARN TROUG	80	2T2	4	13T 1	80		
15A03X15A01 15A02 15A10 15A05 15A06							
8INST RIVNUT PROPERLY	40	1T2 1 212		I 1	20	2	20
01A23X01A22X01A24X15A10							
9TORQUE ACCELEROMETER	405	1T2 5	46	8I 1	100	2	10010 10026 105
01A23X01A22X01A24X15A10							
10REM RADIO ASSY PTM	15	3T2 1 2 5	40	6R 2	5	1	527 5
01A02X							
11SECURE IN TENT	570	T2	46	10T17	570		
00000							
TASK 47 DAY 047 8/02/68							
1SECURE IN TENT	30	T2	46	11T17	30		
00000							
2INST ACCELEROMETER	30	T2 1 2	46	9I 1	15	2	15
01A22X01A23X01A24							
3INST W/A TV STIMULUS	10	T2 1 2 5	47	2I 1	5	2	5
01A22X01A23X01A24							
4TORQUE ALL 808 CLAMPS	95	T2 4 5 6	47	3I 1	45	2	45 9 5
01B03X01B04X							
5CK FIT ON IRS GAS STOR	45	T2 4 6	33	16T 1	5	2	5 9 527 30
03B15X03B16							
6COMPLETE ALL TORQUES	650	2T2 5	47	4I 1	200	2	200 9 5010 200
01B03 01B04 01A22 01A23 01A24							

7REM BATT		5 T12 1 2	47	6R 1	3 2	2	
12B06X12A01							
8SEC IN TENT		575 T2	47	7T17	575		
00000							
TASK 48 DAY 048	8/03/68						
1SECURE IN TENT		1440 T2	47	7T17	1440		
00000							
TASK 49 DAY 049	8/04/68						
1SECURE IN TENT		1440 T2	48	1T17	1440		
00000							
TASK 50 DAY 050	8/05/68						
1SECURE IN TENT		195 T2	49	1T17	195		
00000							
2REM MONO TEL		10 3T2 1 2 5	46	2R 1	3 2	3 9	4
03B16X03B15 03B17 03B21 03B22		03B01 03B02 03B03	03B04	03B05	03B06	03A	15A04
3REM UV SPEC		15 T2 1 2	32	4R 2	8 1	7	
03B08X03B09X03B01 03B02 03B03		03B04 03B05 03B06	03A	15A04	01A02	03B21	03B22
4REM NARR ANG TV CAMERA		60 T2 1 2	39	19R 2	30 1	30	
03B12X03B09 03B01 03B02 03B03		03B04 03B05 03B06	03A	15A04	01A02	03B21	03B22
5STARTED CONNECTOR POTT		60 T215		I 1	20 9	1012	30
15A10X01A22 01A23 01A24							
6SOLDER SIGNAL HARNESS		80 T2111213	46	5I 1	15 2	15 8	3014 20
15A10X01A22 01A23 01A24							
7SHORTEN ACCELEROM LEADS		30 T2 112	47	2R 1	10 2	1011	514 5
15A10X15A11X15A12X15A13X01A22		01A23 01A24					
8SECURE IN TENT		990 T2	50	7T17	990		
00000							
TASK 51 DAY 051	8/06/68						
1SECURE IN TENT		540 T2	50	8T17	540		
00000							
2CONDUCT POTTING		15 T215	51	1T12	15		
15A10X15A11 15A12 15A13 01A22		01A23 01A24					
3RAN FEPS TESTS PTM		30 T2	51	2T27	30		
00000							
4CONDUCT POTTING		375 T2	51	2T12	375		
15A10X15A11 15A12 15A13 01A22		01A23 01A24					
5SECURE IN TENT		480 T2	51	4T17	480		
00000							
TASK 52 DAY 052	8/07/68						
1SECURE IN TENT		1440 T2	51	4T17	1440		
00000							
TASK 53 DAY 053	8/08/68						
1SECURE IN TENT		15 T2	51	5T17	15		
00000							
2REL DSS MODS FROM GAS		5 1T2		T27	5		
00000							
3REL DATA STOR HARNESS		5 1T2		T27	5		
00000							
4RELEASE CHAS EAS		5 1T2	53	2T27	5		
00000							
5REL TCFM SEN XDUCER		1 1T2		T25	1		
00000							
6REL TEMP CONT FLUX MON 1		1 1T2		T25	1		
00000							
7REL TEMP CONT FLUX MON 2		1 1T2		T25	1		
00000							
8REL TCFM HARNESS		1 1T2		T25	1		
00000							
9REL TCFM INTR CONN HARN		1 1T2		T25	1		
00000							
10REL CC+S MODS		10 1T2		T25	10		
00000							

11REL SERVO AMP PTM	5	1T2		T27	5		
00000							
12REL SCAN LOGIC ELECT	2	1T2		T25	2		
00000							
13REL SCAN POWER SUPPLY	3	1T2		T25	3		
00000							
14REL SCAN ACTUATOR CLOCK	2	1T2		T25	2		
00000							
15SEC SCAN ACTUATOR CONE	3	1T2		T25	3		
00000							
16INST TCFM	8	2T2 2 5	53	5I 1	4 2	4	
05808X05809X							
17INST CC+S MODS	7	2T2 1 2 5	53	10I 1	4 2	3	
07801X07802X07803X07804X07805			07806 07C	07A01 07A05			
18INST SCAN ACT ASSY CLOCK	8	2T2 1 2	53	14I 1	4 2	4	
03804X03801 03802 03803 03805			03806 01A02				
19INST SCAN ACT ASSY CONE	7	T2 1 2	53	15I 1	4 2	3	
03805X03801 03802 03803 03804			03806 15A04 01A02				
20INST BATT	35	2T2 1 2	47	7T 1	18 2	17	
12906X12A01							
21PEM SCAN POW TO 69/2	2	2T2 1 2	53	13R 2	1 1	1	
05801 05802 05803 05803 05809			05A01 05C04				
23PEM SCAN LOGIC TO 69/2	2	2T2 1 2	53	12R 2	1 1	1	
05801 05802 05803 05808 05809			05A01 05C04				
24INST SCAN LOGIC ELECT	2	2T2	53	23I 1	1 2	1	
05810X05801 05802 05803 05808			05809 05A01 05C04				
25INST SCAN POW SUPPLY	2	2T2	53	21I 1	1 2	1	
05811X05810 05801 05802 05803			05808 05809 05A01 05C04				
26INST CASE V MOD AND HARN	4	2T2 1 2	53	2I 1	2 2	2	
09801X09802X09803X09804X09805X09806X09807X09808X09809X09810X09801X09801X							
27INST CASE V ON S/C	5	2T2 1 2 5	53	26I 1	3 2	2	
09801X09802X09803X09804X09805X09806X09807X09808X09809X09810X09801X09801X							
28INST TEMP CONT FLUX MON1	2	1T2 1 2 5	53	6I 1	1 2	1	
05808X05801 05802 05803 05C04			05A01				
29INST TEMP CONT FLUX MON2	2	1T2 1 2 5	53	7I 1	1 2	1	
05809X05801 05802 05803 05C04			05A01				
30INST TCFM HARN	1	2T2 1 2	53	8I14	1		
05C02X05801 05802 05803 05808			05809 05C04 05A01				
31INST TCFM INTER CON HARN	1	2T2 1 2	53	9I14	1		
05C03X05801 05802 05803 05808			05809 05C02 05C04 05A01				
32INST SCAN ACT CLOCK AXIS	2	2T2 1 2 5	53	14I 1	1 2	1	
03804X01A02							
33INST SCAN ACT CONE AXIS	2	2T2 1 2 5	53	15I 1	1 2	1	
03805X01A02							
34INST CASE 3 CONN	5	2T2	51	17I 1	211	3	
07C01X07C02 07C03 078			07A05 07A01				
35INST SERVO AMP PTM	7	2T2 1 2	51	11I 1	4 2	3	
058 05A01 05C02 05C03 05C04							
36REL TCFM SEN HARN	8	1T2		T25	8		
00000							
37TURN ON POWER	120	T2	45	9T27	120		
00000							
38TURN OFF POWER	60	T2	51	37T27	60		
00000							
39TURN ON POWER	120	T2	51	38T27	120		
00000							
40REM UV SPECT	5	2T2 1 2	50	3R 1	3 2	2	
03808X03809X03801 03802 03803			03804 03805 03806 03821 03822 03A				
41REL INST UV SPECT	50	2T2 1 2	53	40I 1	20 2	2025 10	
03808X03809X03801 03801 03803			03804 03805 03806 03821 03822 03A				
42TORQUE UV SPECT	15	1T2 1 2 5	53	41I 1	8 2	7	
03808X03809X03801 03801 03803			03804 03805 03806 03821 03822 03A				

43TURN OFF POWER	5	T2	53	39T27	5		
00000							
44SEC IN TENT	893	T2	53	43T17	893		
00000							
TASK 54 DAY 054 8/09/68							
1SEC IN TENT	75	T2	53	44T17	75		
00000							
2INST OSE PLAT	10	3T2 2 4 6		I 1	5 2	5	
03A 03B							
3MATE TCFM SEN TO TRANS	5	2T2	53	36I 1	311	2	
02B02X02B01X02B000							
4TURN ON POWER	60	T2	53	43T27	60		
00000							
5TURN OFF POWER	90	T2	54	5T27	90		
00000							
6REM UVS AND REPLACE	30	2T2	50	3R 1	30		
03B08X03B							
7TURN ON POWER	5	T2	54	5T27	5		
00000							
8MISSFIT ON MONO TELE ECR	15	1T2	50	2R 2	5 1	10	
03B16X03B17X03B 03A01 03A02							
9REL IRS STIM FROM GAS	15	1T2	50	3T25	15		
00000							
10INST IRS STIM	65	1T2 2	54	9I 1	33 2	32	
03B16X03B17X03B 03A01 03A02							
11REM PLEXGLASS COVER	40	1T2 1	54	10R 2	20 1	20	
03B16X03B 03A							
12INST PLEXGLASS COVER	30	1T2 1	54	11I 1	15 2	15	
03B16X03B 03A							
13COVER S/C	5	4T2	54	12T29	5		
014 X							
14TURN OFF POWER	15	T2	54	7T27	15		
00000							
15DECABLE A/C GAS ASSY	2	2T2 2 6	47	5T 1	1 2	1	
13A X							
16REM A/C GAS ASSY	3	4T2	54	15R 1	218	1	
13A00W							
17REM BATT TO GAS	5	T2 1 2	47	7R 1	2 2	226	1
12B06X12A01							
18SEC IN TENT	970	T2	54	17T17	970		
00000							
TASK 55 DAY 055 8/10/68							
1SEC IN TENT	1440	T2	54	18T17	1440		
00000							
TASK 56 DAY 056 8/11/68							
1SEC IN TENT	1440	T2	55	1T17	1440		
00000							
TASK 57 DAY 057 8/12/68							
1SEC IN TENT	15	T2	56	1T17	15		
00000							
2SEC BATT	15	T2	54	17T25	15		
00000							
3INST BATT AND CABLE	90	T2 1 2	57	2T 1	45 2	45	
12B06X12A01							
4REL INVERTER	5	T2		T25	5		
00000							
5REL SERVO MECH	5	T2		T25	5		
00000							
6REL ELECT CASE 6	5	T2		T25	5		
00000							
7REL SCAN POWER SUPPLY	5	T2		T25	5		
00000							

8REL SCAN LOGIC ELECT	10	T2		T25	10		
00000							
9REM ELECT CASE VI	2	2T2	1 2	R27	2		
00000							
10REM SCAN LOGIC ELECT	2	1T2	1 2	53 24R	1	1 2	1
05B10X05B01 05B02 05B03 05B08	05B09	05C02	05C03 05C04	05A01			
11REM SCAN POWER SUPPLY	2	1T2	1 2	53 25R	1	111	1
05B11X05B01 05B02 05B03 05B08	05B09	05C02	05C03 05C04	05A01			
12REM SERVO AMP AND STEPPR	2	1T2	1 2	53 11R	1	1 2	1
05B12X05B01 05B02 05B03 05B08	05B09	05C02	05C03 05C04	05A01			
13REL SCAN ACT CLOCK ASSY	2	1T2		T25	2		
00000							
14REL SCAN ACT CONE ASSY	2	1T2		T25	2		
00000							
15INST SCAN LOGIC ELECT	1	1T2	1 2	57 8I	2	1	
05B10X05B01 05B02 05B03 05B08	05B09	05C02	05C03 05C04	05A01			
16INST SCAN POWER SUPPLY	1	1T2	1 2	57 7I	2	1	
05B11X05B01 05B02 05B03 05B08	05B09	05C02	05C03 05C04	05A01			
17INST SERVO MECH	2	1T2	1 2	57 5I	1	1 2	1
05B12X05B01 05B02 05B03 05B08	05B09	05C02	05C03 05C04	05A01			
18REM INVERTER	1	1T2	1 2	R	2	1	
05B06X05B 05A01 05C02 05C03 05C04							
19INST INVERTER	1	1T2	1 2	57 18I	2	1	
05B06X05B 05A01 05C02 05C03 05C04							
20REM SCAN ACT CLOCK ASSY	2	T2	1 2	53 32R	2	1 1	1
03B04X01A02							
21INST SCAN ACT CLOCK ASSY	3	2T2	1 2	57 13I	1	2 2	1
03B04X01A02							
22PEM SCAN ACT CONE ASSY	2	2T2	1 2	53 33R	2	1 1	1
03B05X03B 03A							
23INST SCAN ACT CONE ASSY	3	2T2	1 2	57 14I	1	2 2	1
03B05X03B 03A							
24INST CASE VI ON S/C	10	2T2	1 2 5	57 6I	1	5 2	5
10A01X10B 10C							
25TEST A/C GAS SYS ASSY +X	88	T2	4 6	54 16T	1	40 2	4411 4
13A X							
26TEST A/C GAS SYS ASSY -X	89	T2	4 6	54 16T	1	40 2	4411 5
13A X							
27TURN ON POWER	78	T2		54 14T	27	78	
00000							
28TURN OFF POWER	9	T2		57 27T	27	9	
00000							
29TURN ON POWER	79	T2		57 28T	27	79	
00000							
30TURN OFF POWER	5	T2		57 29T	27	5	
00000							
31SEC IN TENT	904	T2		57 30T	17	904	
00000							
TASK 58 DAY 058 8/13/68							
1SEC IN TENT	30	T2		57 31T	17	30	
00000							
2PREP TO REM RADIO	10	1T2		57 24T	27	10	
00000							
3REM RADIO	30	2T2	1 2 5	58 2R	2	15 1	15
10A00W10B00W10C00W							
4TURN ON POWER	17	T2		57 30T	27	17	
00000							
5TURN OFF POWER	23	T2		58 4T	27	23	
00000							
6TURN ON POWER	57	T2		58 5T	27	57	
00000							
7TURN OFF POWER	63	T2		58 6T	27	63	

000000	BREL CMD SUBASSYS	5 212	125	5		
000000	9REL DATA PROC FROM QAS	35 112	125	35		
000000	10REM TEMP CONT MON I	10 112 1 2	53 28R 1	4 2	411	2
05909X05B	05C02 05C03 05C04 05A01					
11REM TEMP CONT MON II	10 112 1 2	53 29R 1	4 2	411	2	
05909X05B	05C02 05C03 05C04 05A01					
11PEM DATA PROC FROM S/C	10 112 1 2	43 3R 1	4 2	411	2	
08907X08B	08C02 08A01					
12INST DATA PRCC ON S/C	5 112 1 2	58 9I 1	2 2	211	1	
08907X08B	08C02 08A01					
13REM CMD PRCTO MODS	4 212 1 2	43 12R 2	2 1	2		
08901X08B02X09803X08B04X08B05X						
14INST CMD MODS ON S/C	50 212 1 2	58 8I 1	25 2	25		
08901X08B02X09803X08B04X08B05X						
15REM PRCTO WIR HARN COMM	3 212 1 2 5	43 12R 2	1 1	111	1	
08C01X08C02 08B 08A01						
16INST WIR HARN COMM	13 212 1 2 5	58 15I 1	5 2	511	3	
08C01X08C02 08B 08A01						
17MATE WIR HARN COMM PTM	15 212	58 16I 1	5 2	511	5	
08C02 08B 08A01						
18TURN CN POWER	1 12	58 7127	1			
000000						
19REM BREADBD MODS	8 12	43 12R27	8			
000000						
20TURN OFF POWER	43 12	58 18127	43			
000000						
21TURN ON POWER	24 12	58 20127	24			
000000						
22TURN OFF POWER	69 12	58 21127	89			
000000						
23TURN ON POWER	5 12	58 22127	5			
000000						
24TURN OFF POWER	2 12	58 23127	2			
000000						
25TURN ON POWER	3 12	58 24127	3			
000000						
26TURN OFF POWER	5 12	58 25127	5			
000000						
27SEC IN TENT	870 12	58 25127	870			
000000						
TASK 59 DAY 059 8/14/68						
1SEC IN TENT	55 12	58 27127	55			
000000						
2TURN ON POWER	7 12	58 26127	7			
000000						
3RUN DOWN GYROS	40 12	59 2127	40			
000000						
4TURN OFF POWER	38 12	59 2127	38			
000000						
5INST STIM PLAT ON U-RING	5 312 4 6	54 10I 1	3 2	2		
03A 03B						
6INST WIDE ANG TV STIM	5 112 1 2	45 5I 1	3 2	2		
03B10X03B 03A						
7INST MONO TEL STIM	10 12 1 2	1 1	5 2	5		
03B16X03B 03A						
8TURN POWER ON	9 12	59 4127	9			
000000						
9RUN GYROS DOWN	31 12	59 8127	31			
000000						

10TURN POWER OFF	65 T2	59 9T27 65
00000		
11TURN POWER ON	7 T2	59 10T27 7
00000		
12RUN GYROS DOWN	18 T2	59 11T27 18
00000		
13INST NARR ANG TV STIM	7 1T2 1 2	50 4T 1 4 2 3
03B12X03B O3A		
14INST STIMULUS CABLE UVS	58 1T2 1 2	53 42I 1 29 2 29
03B08X03B O3A		
15REM CAMERA COVER	109 1T2	59 13R 1 109
03912X03B O3A		
16INST CAMERA COVER	6 1T2	59 15I 1 6
03912X03B O3A		
17REM STIM SUPP GEAR TV	9 2T2 1 2	59 13R 2 5 1 4
03912X03B O3A		
18REM STIM PLAT ASSY	16 4T2 4 6	59 5 R 2 8 1 8
03B00W03A		
19TURN OFF POWER	10 T2	59 11T27 10
00000		
20REM ATR PLAYBACK ELECT	5 T2 1 2	53 2R 2 2 1 211 1
09B08X09B O9C O9A01		
21SEC IN TENT	930 T2	59 20T17 930
00000		
TASK 60 DAY 060 8/15/68		
1SEC IN TENT	30 T2	59 21T17 30
00000		
2TEST GROUND INTEGRITY	270 T2	T27 270
00000		
3TEST GROUND INT COMM	90 T2	60 2T27 90
00000		
4SEC TEMP CONT FLUX MON 1	30 T2	58 10T26 30
00000		
5SEC TEMP CONT FLUX MON 2	30 T2	58 11T26 30
00000		
6TEST GRND INT A/C	55 T2	57 26T27 55
00000		
7TEST GRND INT CC+S	50 T2	53 17T27 50
00000		
8REM OSE CABLES	15 T2	60 7T27 15
00000		
9SEC IN TENT	870 T2	60 8T17 870
00000		
TASK 61 DAY 061 8/16/68		
1SEC IN TENT	30 T2	60 9T17 30
00000		
2SEC RADIO FROM GAS	10 T2	58 3T25 10
00000		
3SEC TCMF MON 1	10 T2	60 4T25 10
00000		
4SEC TCMF MON 2	10 T2	60 4T25 10
00000		
5INST TCMF MON 1	3 2T2 1 2	61 3I 1 1 2 111 1
05B08X05B 05A01 OSC		
6INST TCMF MON 2	3 2T2 1 2	61 4I 1 1 2 111 1
05B09X09B 05A01 OSC		
7INST TCMF INTCONN HARN	19 2T2 1 2 5	54 30I 1 5 2 511 514 4
05C03X05C 05B 05A01		
8REL PLAT HEAT HARN	5 T2	T26 5
00000		
9INST RADIO ON S/C	60 2T2 1 2 5	61 21 1 30 2 30
10A01X10B01X10C02X10B03X10B04X10B05X10B06X10B07X10B08X10C01X10C02X10C03X10C04X		

10REM MONO TEL	160 3T2 1 2	59 7R 1	80 2	80	
03B16X03B17X03B15X03B 03A					
11REM UV STIM	10 1T2	59 14R 1	10		
03B08X03B 03A					
12REM NARR ANG TV CAMERA	10 2T2 1 2	59 17T 2	4 1	426	2
03B12X03B 03A					
13REM UV SPECT	10 2T2 1 2	61 11R 2	4 1	426	2
03B08X03B 03A					
14REM WIDE ANG TV CAMERA	5 2T2 1 2	59 6R 2	2 1	226	1
03B10X03B 03A					
15REM IRR	45 2T2 1 2	31 12R 2	20 1	2026	5
03B06X03B07X03B 03A					
16REL SCAN PLAT HEATS	60 T2		125 60		
00000					
17REM BATT	10 2T2 1 2	57 3I 1	4 2	426	2
12B06X12A01					
18REM GYRO CONT FROM S/C	10 2T2 1 2	29 8R 2	4 1	426	2
07B06X07B 07C 07A01 07A05					
19REM RADIO	10 2T2 1 2	61 9R 2	4 1	426	2
10A00W10B00W10C00W					
20REM DIPLEXER SUBASSY	5 1T2 1 2	61 19R 2	3 1	2	
10P02X10B 10C 10A					
21REM CASE 3	5 T2 1 2	53 17R 2	2 1	226	1
07A01X07A05X07B01X07B02X07B03X07B04X07B05X07B06X07C01X07C02X07C03X					
22SEC IN TENT	950 T2	61 22T17	950		
00000					
TASK 62 DAY 062 8/17/68					
1 SEC IN TENT	1440 T2	61 22T17	1440		
00000					
TASK 63 DAY 063 8/18/68					
1 SEC IN TENT	1440 T2	62 1T17	1440		
00000					
TASK 64 DAY 064 8/19/68					
1PREP SCAN PLAT OPT ALGN	30 4T2 1 2 4	T 1	1515	1027	5
03A 15A04 01A02 03B01 03B02 03B03					
2SEC PLAT HEAT HARN	55 1T2		125 55		
00000					
3REM TV MODS	5 2T2 1 2	60 2R 1	3 2	2	
11B05X11B06X11B07X11B08X11C	11A01				
4INST PLAT HEAT HARN	90 2T2 1 2 5	64 2I 2	25 1	25 9	1014 30
15A07X03A01 03A02 03B01 03B02 03B03 03B05 15A04 01A02					
5REL SCAN DR MECH	30 1T2	61 12T25	30		
00000					
6REM CONE AXIS/INS DOGS	20 2T2 1 2 5	57 23X 2	10 1	5 9	5
03B05X03A 03B01 03B02 03B03 15A04 01A02					
7INST CONE AXIS/TOR	5 2T2 1 2 5	64 6I 1	2 2	2 9	1
03B05X03A 03B01 03B02 03B03 15A04 01A02					
8REM CLOCK ACTUATOR/TOR	39 2T2 1 2 5	57 21X 2	15 1	15 9	9
03B04X01A02					
9INST CLOCK ACTUATOR/TOR	39 2T2 1 2 5	64 8I 1	15 2	15 5	9
03A01X03A02					
10TURN ON POWER	69 T2	59 19T27	69		
00000					
11TURN OFF POWER	8 T2	64 10T27	8		
00000					
12SEC IN TENT	1050 T2	64 11T17	1050		
00000					
TASK 65 DAY 065 8/20/68					
1SEC IN TENT	20 T2	64 12T17	20		
00000					
2REM CASE 4	25 2T2 1 2 5	58 19R 2	10 1	15	
08A01 08B 08C					

3REM TTS HARN	25	2T2	1	2	51216	8R	2	5	1	1011	514	5
08C02X08B 08A01												
4REM FTS MODS	25	2T2	1	2	5	64	3R	2	15	1	10	
08B01X03B02X08B03X08B04X03B05X08B 08C01 08A01												
5PREP TC INST COMM PROTO	25	2T2	1	2		58	14T	1	15	2	10	
08A01 08B 08C01												
6INST FTS HARN/MODS	30	2T2	1	2	5	65	4I	1	10	2	1014	10
08B0CWO8C02X08A01												
7INST COMM PROTO	30	2T2	1	2		65	5I	1	15	2	15	
08A01 08B 08C												
8INST C+D DETC SUBASSYS	30	2T2	1	2	5	65	2I	1	10	2	1011	10
08B01X03B02X08B03X08B04X08B05X08C 08A01												
9MATE CASE 4 MODS	102	1T2	1	2	5	65	2I	1	40	2	4011	22
08B01X03B02X08B03X08B04X08B05X08C 08A01												
10TURN ON POWER	99	T2				64	11T27		99			
00000												
11TURN OFF POWER	99	T2				65	10T27		99			
00000												
12REM CASE 4 FROM S/C	20	2T2	1	2		65	9I	1	10	2	10	
08B 08C 08A01												
13REM FTS MODS TO GAS	35	1T2				65	4R26		35			
00000												
14SEC IN TENT	875	T2				65	13T17		875			
00000												
TASK 66 DAY 066 8/21/68												
1SEC IN TENT	150	T2				65	14T17		150			
00000												
2SEC IOHN RIS FROM GAS	15	1T2					125		15			
00000												
3SCWFF SIDE OF SCAN PLAT	40	1T2				64	1I	1	40			
03A01X03A02												
4SEC IN TENT	1235	T2				66	3T171235					
00000												
TASK 67 DAY 067 9/22/68												
1INST HEATRS ON SCAN PLAT	120	2T2	1	2		61	16I	1	60	2	60	
11C04X03A 03B01 03B02 03B03 03B04 03B05												
2INST PROTO C+D DET MODS	45	2T2	1	2	5	65	8I	1	23	2	22	
08B01X08B02X08B03X08B04X08B05X08B 08A01 08C												
3INST CASE IV	15	2T2	1	2		67	2I	1	8	2	7	
08A01X08B 08C												
4START SCAN ALIGN	15	3T2				67	1T	9	15			
03A-												
5TURN ON POWER	310	T2				65	11T27		310			
00000												
6TURN OFF POWER	5	T2				67	5T27		5			
00000												
7SECURE IN TENT	930	T2				67	6T17		930			
00000												
TASK 68 DAY 068 8/23/68												
1SECURE IN TENT	30	T2				67	7T17		30			
00000												
2ALIGN SCAN PLAT	240	2T2				67	4T	9	240			
03A												
3REM SCAN PLAT ALIGN	60	2T2	4	6		68	2T	1	20	2	20	9 20
03A												
4SET UP FOR FEPS TEST	60	T2					T	9	60			
03A												
5REM FEPS COVER	10	1T2					R	1	10			
03B03X03B01 03B02 03B04 03B05 03A01 03A02												
6CONT TEST	30	T2				68	4T27		30			
00000												
7INST FLIGHT HOOD	30	1T2	1			29	19I	1	15	2	15	

03803X03B01	03802	03804	03805	03A01	03A02
BREL DIPLEXER ASSY IN QAS	20	T2		61	20T26 20
00000					
9INST DIPLEXER ASSY	30	2T2	1 2 5	68	8T 1 15 2 15
10902X10C02X10B 10A01					
10INST RF CABLE SEMI RIGID	5	2T2		I 1	3 2 2
10C03X10C04X10B 10A01 10C01	10C02				
11MATE DXI AND TORQUE	35	2T2	5	68	9I 1 10 2 1011 15
10R02X10C01X10B 10A01 10C02	10C03 10C04				
12SEC CASE VI TO OSE TESTS	10	T2		68	11T18 527 5
10A01 10B 10C					
13RERUN FEPS TESTS	70	T2		68	6T27 70
00000					
14SECURE IN TENT	20	T2		68	13T17 20
00000					
15REM FLIGHT HOOD	10	1T2	1 2	68	7R 2 5 1 5
03803X03B01 03802 03804 03805	03A01 03A02				
16INST FEPS STIMULUS	20	T2	1 2	68	13T 1 10 2 10
17INST FLIGHT HOOD	10	2T2	1 2	68	15I 1 5 2 5
03803X03B01 03802 03804 03805	03A01 03A02				
18COVER S/C WITH PLASTIC	45	T2		68	17T29 45
01A01					
19REC CASE VI FROM OSE	5	T2		68	12T25 5
00000					
20SECURE IN TENT	700	T2		68	19T17 700
00000					
TASK 69 DAY 069 8/24/68					
1SECURE IN TENT	10	T2		68	20T17 10
00000					
2REWORK UPPER RING HARN	4	3T2	1 2 512	4	13T 1 1 2 111 114 1
15AD2X15AD01X15AD03X15AD05 15AD06					
3REM POTTING SLEEVE	2	3T2	1 2 51269	2R 1	1 2 1
15AD01X15AD02X15AD03X15AD05 15AD06					
4REM CONN FROM RING	14	3T2	1 2 51269	3R 1	5 2 514 4
15AD01X15AD02X15AD03X15AD05 15AD06					
5REM POTTING AROUND PINS	15	3T2		69	4R 1 8 6 7
15AC1X15AD02X15AD03X15AD05 15AD06					
6SOLDER LEADS TO PINS	10	3T2111213		69	5I 1 4 2 4 8 2
15AD01X15AD02X15AD03X15AD05 15AD06					
7LACE NEW LEADS IN HARN	60	3T2		69	6I 1 60
15AD01X15AD02X15AD03X15AD05 15AD06					
8HOOK UP BREAKOUT BOX	30	2T2		69	7I 1 30
15AD01X15AD02X15AD03X15AD05 15AD06					
9REM CONN	5	2T212		69	8R14 5
15AD01X15AD02X15AD03X15AD05 15AD06					
10CUT LEAD FROM CONN	10	2T212		69	9R14 10
15AC1X15AD02X15AD03X15AD05 15AD06					
11COMPLETE SOLDER SPLICE	2	2T21213		69	10I 2 1 8 1
15AD01X15AD02X15AD03X15AD05 15AD06					
12SHRINK SPLICE SLEEVE	2	2T215		69	11I12 2
15AC1X15AD02X15AD03X15AD05 15AD06					
13CUT LEAD FROM CONN	8	2T212		69	10R 1 4 2 4
15AD01X15AD02X15AD03X15AD05 15AD06					
14COMPLETE SOLDER SPLICE	3	2T21113		69	13R 1 1 2 1 8 1
15AC1X15AD02X15AD03X15AD05 15AD06					
15SHRINK SPLICE SLEEVE	40	2T2		69	14I12 40
15AD01X15AD02X15AD03X15AD05 15AD06					
16LACE UP HARN REWORK	5	2T2 1 2 51269		2I 1	2 2 214 1
15AD01X15AD02X15AD03X15AD05 15AD06					
17CK FOR CONTIN BY TECH	20	T2		69	16T27 20
00000					

1 PROTATED S/C BY TECH	20 12	69 17T16	20			
00000						
19 INST SUPP BRACK ON SCAN	30 3T2 2 6	64 1I 1	10 2	1015	10	
03A 03B						
20 POT CONN	25 2T2 15	69 13T12	25			
15A01X15A02X15A03X15A05 15A06						
21 SEC IN TENT	1125 12	69 20T171125				
00000						
TASK 70 DAY 070 8/25/69						
1 SEC IN TENT	1440 12	69 21T171440				
00000						
STAGE 2 SYSTEMS TEST						
TASK 01 DAY 071 8/26/68						
1 SEC IN TENT	30 12	117	30			
00000						
2 TORQUE SCREWS ON UP RING	20 2T2 1 5	1 1	10 2	10		
15A01X15A02X15A03X15A05 15A06						
3 SOLDER SCAN HEATERS	10 2T2 1 1 1 3	1 1	4 2	4 8	2	
15A07X03A 03B						
4 REM CASE 4	15 2T2 1 2 5	R 2	5 1	518	5	
08A 08B 08C						
5 INST PROTO COMM MOD	4 1T2 1 2	1 1	2 2	2		
08B05X08B 08C 08A01						
6 REINST PROTO COMM MOD	1 1T2	1 5I 1	1			
08B0CWC8A01 C8C00						
7 REL CASE 3 FROM QAS	5 1T2	T25	5			
00000						
8 INST CASE 3	2 2T2 1 2 5	1 7I 1	1 2	1		
07A01 07A05 07B 07C						
9 REL TV MODS FROM QAS	2 1T2	T25	2			
00000						
10 REM CLOCK AXIS	2 2T2 1 2	R 2	1 1	1		
03B04X01A02						
11 INST CLOCK AXIS	2 2T2 1 2	1 10I 1	1 2	1		
03B04X01A02						
12 REV SCREWS ON HARN 111	3 2T2 1 2 5	1 1	1 2	111	1	
07C01X07C03 07C02 07B 07A05 07A01 15A01 15A02 15A03						
13 INST TV POWER SUPPLY	4 2T2 1 2	1 9I 1	2 2	2		
11B05X11B01 11B02 11B03 11B04 11A01 11C						
14 INST TV CONT SUB ASSY	5 2T2 1 2	1 9I 1	3 2	2		
11B08X11B01 11B02 11B03 11B04 11B05 11A01 11C						
15 REM CONE AXIS/INST	5 2T2 1 2	X 2	3 1	2		
03B05X03B 03A 15A04						
16 INST TV CAMERA DRIVERS	5 2T2 1 2	1 9I 1	3 2	2		
11B07X11B 11C 11A01						
17 INST TV DATA CONV	2 2T2 1 2	1 1	1 2	1		
11B06X11B 11C 11A01						
18 REV SCREWS ON HARN 111	2 1T2 1 2 5	1 1	1 2	1		
07C02X07C01 07C03 07B 07A05 07A01						
19 REL BATT FROM QAS	4 1T2	T25	4			
00000						
20 INST BATT	2 2T2 1 2	1 19I 1	1 2	1		
12B06X12A01						
21 INST SIT	2 1T2 1	1 1	1 2	1		
01B05X12B06 12A01						
22 PEC ATR PLAYBACK IN QAS	6 2T2	X26	125	1 1	2 2	2
09B02X09B 09A01 09C01						
23 REL GYRO CONT FROM QAS	5 1T2	T25	5			
00000						
24 INST GYRO CONT	13 2T2	1 23I 1	7 2	6		
07B06X07B 07C 07A05 07A01						
25 PREP TO INST A/C GAS SYS	55 4T2 4 6	1 1	15 2	1510	1511	10

13A00X										
26PREP TO INST A/C GAS SYS	55	4T2	4	6	1	25I	1	20	2	2010 15
13A00X										
27INST A/C GAS SYS	45	4T2	2	510	1	26I	1	15	2	1510 15
13A00W										
28REM A/C GAS SYS	45	4T2	4	6	1	27R	2	15	1	15 9 15
13A00W										
29INST CASE V1	30	2T2	1	2		I	1	15	2	15
10A01 10B 10C										
30INST A/C GAS SYS	15	4T2	2	510	1	28I	1	5	2	510 5
13A00W										
31INST A/C GAS SYS	30	4T2	2	510	1	25I	1	10	2	1010 10
13A00W										
32PREP TO INST SCI INSTRU O3A	15	1T2				T	1	15		
33INST IRR	5	2T2	1	2		I	1	3	2	2
O3B06X03B07X03B O3A										
34INST WIDE ANG TV	5	2T2	1	2	1	I	1	3	2	2
O3B10X03B11X03B O3A										
35INST BLOCK CODE	10	2T2				I26		5	2	5
O8B17XC8B O8A O8C										
36INST MT1 + UVS	35	2T2	1	2 5		I	1	18	2	17
O3B16X03B08X03B O3A										
37CK INST GROUND O0000	15	T2			1	36I27		15		
38INST CASE 1V	30	2T2	1	2		3I	1	15	2	15
O7B O7C O7A01 O7A05										
39SECURE IN TENT O0000	899	T2			1	38I17	899			
TASK Q2 DAY D72 8/27/68										
1PURGE IRS O0000	5	1T2			1	36I27		5		
2INST STIM BRACKETS	15	T2	4	6		I	1	8	2	7
O3A O3B 15A04 01A02										
3INST STIMULI	81	T2	1	2		I	1	41	2	40
O3A O3B 15A04 01A02										
4TURN POWER ON O0000	3	T2				T27		3		
5TURN POWER OFF O0000	7	T2			2	4T27		7		
6TURN POWER ON O0000	19	T2			2	5T27		19		
7TURN POWER OFF O0000	25	T2			2	6T27		25		
8TURN POWER ON O0000	18	T2			2	7T27		18		
9RUN DOWN BYROS O0000	27	T2			2	8T27		27		
10TURN POWER OFF O0000	27	T2			2	9T27		27		
11TURN POWER ON O0000	48	T2			2	10T27		48		
12INST WIDE ANG COLUM	5	3T2			1	34I	1	315		2
O3B10X03B O3A 15A04 01A02										
13INST WIDE ANG CCLUM	5	3T2				I	1	315		2
O3B12X03B O3A 15A04										
14REM NARR ANG TV COVER	25	1T2			2	13R	1	25		
O3B12X03B O3A										
15INST NARR ANG TV COVER	27	1T2			2	14I	1	27		
O3B12X03B O3A										
16TURN POWER OFF O0000	48	T2			2	11T27		48		

17SECURE IN TENT	1055 T2	2 16T171055
00000		
TASK 03 DAY 073 8/28/68		
1SEC PYRO SP TO GAS SUPPO	60 3T2 1 2 6	I 1 30 2 30
13A00W15A09X		
2TURN POWER ON	325 T2	2 16T27 325
00000		
3REM LOCKING PIN PAS	2 1T2 111	R 2 1 1 1
01806X		
4INST LOCKING PIN PAS	13 1T2 111	3 3I 1 7 2 6
01806X		
5REM LOCKING PIN SIT	10 T2 111	R 2 5 1 5
01805X12806		
6REM LOCKING PIN PAS	10 1T2 111	3 4R 2 5 1 5
01806X		
7MOUNT CANOPUS SENSOR	170 2T2 1 2	I 1 85 2 85
13B08X13B09X13B10X13B11X01A02		
8TURN POWER OFF	25 T2	3 2T27 25
00000		
9SECURE IN TENT	825 T2	3 8T17 825
00000		
TASK 04 DAY 074 8/29/68		
1SECURE IN TENT	30 T2	3 9T17 30
00000		
2TURN POWER ON	20 T2	3 8T27 20
00000		
3RUN GYROS DOWN	10 T2	4 2T27 10
00000		
4MOUNT MAGNETOMETER	560 2T2 1 2	3 7I 1 280 2 280
13B08X13B09X13B10X13B11X01A02		
5TURN POWER OFF	5 T2	4 2T27 5
00000		
6REM HOOD FROM NAMG 1	2 1T2 1 2	R 2 1 1 1
03B01X03B 03A		
7REM HOOD FROM NAMG 2	2 1T2 1 2	4 6R 2 1 1 1
03B02X03B 03A		
8INST MARS GATE HOOD 1	6 1T2 1 2	4 7I 1 3 2 3
03B01X03B 03A		
9INSTALL MARS GATE HOOD 2	5 1T2 1 2	4 7I 1 2 2 3
03B02X03B 03A		
10SECURE IN TENT	800 T2	4 9T17 800
00000		
TASK 05 DAY 075 8/30/68		
1SECURE IN TENT	19 T2	4 10T17 19
00000		
2TURN POWER ON	26 T2	4 5T27 26
00000		
3RUN GYRO DOWN	105 T2	5 1T27 105
00000		
4REM CAMERA COVER	8 1T2	R 1 8
03B12X03B 03A		
5TURN POWER OFF	397 T2	5 2T27 397
00000		
6REM BATT	5 2T2 1 2	1 20R 2 3 1 2
12B06X12A01 01805		
7SECURE IN TENT	880 T2	5 6T17 880
00000		
TASK 06 DAY 076 8/31/68		
1SECURE IN TENT	1440 T2	5 7T171440
00000		
TASK 07 DAY 077 9/01/68		

1SECURE IN TENT	1440	T2	6	1T171440			
00000							
TASK 08 DAY 078 9/02/68							
1SECURE IN TENT	1440	T2	7	1T171440			
00000							
TASK 09 DAY 079 9/03/68							
1INST BATT	50	2T2 1 2	5	6I 1	25	2	25
12B06X12A01 01B05							
2TURN POWER ON	20	T2	5	5T27	20		
00000							
3REM WIDE ANG TV COVER	25	1T2	2	12R 1	25		
03B10X							
4REM NARR ANG TV COVER	25	1T2	2	15R 1	25		
03B12X03B 03A							
5INST WIDE ANG TV COVER	15	1T2	9	3I 1	15		
03B10X03B 03A							
6INST NARR ANG TV COVER	15	1T2	9	4I 1	15		
03B12X03B 03A							
7REM MONO TEL COVER	45	2T2 1 2 4	1	36R 1	23	2	22
03B15X03B16X03B17X03B 03A							
8INST MONO TEL COVER	25	T2 1 2 4	9	7I 1	13	2	12
03B15X03B16X03B17X03B 03A							
9REM STIM PLATFORM	15	3T2 1 4 6	2	3R 2	5	1	515 5
03B16X03B 03A 15A04 01A02							
10REPLACE METAL COVER	2	1T2 1	9	3I 1	1	2	1
03B12X							
11REL MODE + RATE ASSY GAS	3	T2		T25	3		
00000							
12REM POWER SUPPLY	5	1T2 1 2	1	38R 2	3	1	2
08B18X08B 08C 08A01							
13REM MODE + RATE FROM CS4	10	T2 1 2	9	12X 2	5	1	5
08B11X08B 08C 08A01							
14INST POWER SUPPLY/CONN	75	T2 1 2	9	12I 1	30	2	3011 15
08B18X08B 08C 08A01							
15TURN POWER OFF	35	T2	9	2T27	35		
00000							
16TURN POWER ON	40	T2	9	15T27	40		
00000							
17TURN POWER OFF	5	T2	9	16T27	5		
00000							
18SECURE IN TENT	1030	T2	9	17T171030			
00000							
TASK 10 DAY 080 9/04/68							
1SECURE IN TENT	10	T2	9	18T17	10		
00000							
2DEMATE ATR + DTR ELECT	10	1T2 1		R 1	511		5
09B08X09B 09C 09A01							
3INST ATR +DTR	10	T2	10	2I 1	5	2	5
09B08X09B 09C 09A01							
4CLOSE CASE 5	13	T2 1 2	10	3T 1	7	2	6
09A01X							
5TURN POWER ON	13	T2	9	17T27	13		
00000							
6INST COLLIMATOR	302	4T2	2	12I 1	151	5	151
03B12X03B 03A 15A04 01A02							
7TURN POWER OFF	5	T2	10	5T27	5		
00000							
8MOVE S/C TO 35DEG POSITN	5	1T2 1 2	10	7T 1	111		216 2
09B08X09B 09C 09A01							
9MOVE S/C TO HOR POSITION	5	1T2	10	8T16	5		
00000							
10SECURE IN TENT	1067	T2	10	9T171067			

00000

TASK 11 DAY 081 9/05/68

1SECURE IN TENT	15 T2	10 10T17	15		
00000					
2OPEN CASE 5	5 2T2 1 2	10 4R 2	3 1	2	
09A01X					
3REM ATR + DTR	5 2T2 1 2	10 3R 2	3 1	2	
09B08X09B 09C 09A01					
4TURN ON POWER	3 T2	10 7T27	3		
00000					
5TURN OFF POWER	2 T2	11 4T27	2		
00000					
6INST ATR + DTR	5 2T2 1 2 5	11 3I 1	3 2	2	
09B08X09B 09C 09A01					
7MATE ATR + DTR CONNS	5 1T2 1 2 5	11 6I 1	2 2	211	1
09B08X09B 09C 09A01					
8CLOSE CASE 5	5 2T2 1 2	11 7I 1	3 2	2	
09A01X					
9CHANGE S/C POSITION	35 T2	11 8T16	35		
00000					
10TURN ON POWER	5 T2	11 5T27	5		
00000					
11REM IRR	10 2T2 1 2	1 33R 2	5 1	5	
03B06X03B07X03B 03A01 15A04 01A02					
12INST SCI STIM PLAT	7 3T2 1 4 6	9 9I 1	2 2	215	3
03A 03B					
13REM NARR ANG TV COVER	43 1T2	10 6R 1	43		
03B12X03B13X03914X03B 03A 15A04 01A02					
14REM SCAN ALIGN PLATE	240 1T2 1 2		R27 240		
00000					
15INST IRR	55 2T2 1 2 5	11 11I 1	20 2	2011	15
03B06X03B07X03B 03A 15A04 01A02					
16REM SCI OSE PLAT	30 3T2 1 4 6	11 12R 2	10 1	1015	10
03A 03B					
17SET UP LOS TEST	95 2T2		T27 95		
00000					
18TURN OFF POWER	10 T2	11 10T27	10		
00000					
19SEC IN TENT	865 T2	11 18T17	865		
00000					

TASK 12 DAY 082 9/06/68

1SEC IN TENT	10 T2	11 19T17	10		
00000					
2REM IRR	50 2T2 1 2 5	11 15R 2	20 1	2011	10
03B06X03B07X03B 03A 15A04 01A02					
3INST GAUSS METER	10 1T2 1 2		I 1	5 2	5
13B09X13B10X13B11X13B08X					
4REM CLAMPS FROM SCAN HTS	5 2T21112	1 3R 2	2 1	214	1
03B06X03B07X03B 03A 15A04 01A02					
5MATE IRR AND MOUNT	5 2T2 1 2	12 2I 1	2 2	211	1
03B06X03B07X05C04X03B 03A 15A04 01A02					
6TURN ON POWER	70 T2	11 18T27	70		
00000					
7REM CAMERA COVERS	10 1T2	9 6R 1	10		
03B10X03B12X03B 03A01 15A04 01A02					
8ALIGN SCAN PLAT	70 2T210	11 14I 1	35 9	35	
03A 03B 15A04 01A02					
9REM IRR	15 T2 1 2	11 5R 1	5 2	511	5
03B06X03B07X05C04X03B 03A 15A04 01A02					
10INST IRR	20 2T2 1 2	12 9I 1	7 2	711	6
03B06X03B07X05C04X03B 03A 15A04 01A02					
11TURN OFF POWER	10 T2	12 6T27	10		

00000					
12TURN ON POWER	20	T2	12	11T27	20
00000					
13TEST WIDE ANG TV CAMERA	5	4T2	9	5T 1	315 2
03B12X03B 03A 15A04 01A02					
14REM MONO TEL COVER	5	1T2	9	8R 1	5
03B16X03B17X03B18X					
15REM IRR	50	2T2 1 2	12	10R 2	20 1 2011 10
03B06X03B07X05C04X03B 03A	15A04	01A02			
16INST IRR	50	2T2 1 2	12	15I 1	20 2 2011 10
03B06X03B07X05C04X03B 03A	15A04	01A02			
17REM COVER FROM MONO TEL	15	1T2	9	8R 1	15
03B16X03B17X03B18X					
18INST MONO TEL COVER	52	1T2	12	17I 1	52
03B16X03B17X03B18X					
19REM UV STIM	3	1T2 1		R 2	2 1 1
03B08X03B 03A 15A04 01A02					
20INST IRR STIM	15	1T2 1	12	16I 1	8 2 7
03B06X03B07X03B 03A 01A02 15A04					
21CHANGE S/C POSITION	120	1T2	12	20T16	120
00000					
22TURN OFF POWER	5	T2	12	12T27	5
00000					
23TURN ON POWER	5	T2	12	22T27	5
00000					
24TURN OFF POWER	14	T2	12	23T27	14
00000					
25INST NARR TV COVER	2	1T2	9	6I 1	2
03B12X03B 03A 15A04 01A02					
26INST UV STIM COVER	8	1T2 1 2	12	19I 1	4 2 4
03B08X03B09X03B 03A 15A04 01A02					
27REM A B TV CAMERAS	17	2T2 1 2	9	6R 2	8 1 9
03B10X03B11 03B 03A 15A04 01A02 03B12X					
28CHANGE S/C POSITION	3	1T2	12	27T16	3
00000					
29REM BATT	2	2T2 1 2	9	1R 2	1 1 1
12B06X12A01					
30REM SIT	3	2T2 1 2	9	1R 2	2 1 1
01B05X12B06 12A01					
31REM TV CAMERA DRIVE	5	1T2 1 2 5	1	13R 2	3 1 2
11B07X11B 11C 11A01					
32REM TV DATA CONVERT	2	1T2 1 2 5	1	14R 2	1 1 1
11B06X11B 11C 11A01					
33REM TV CONT	13	1T2 1 2 5		R 2	6 1 7
11B08X11B 11C 11A01					
34REM TV POWER	5	1T2 1 2 5	1	16R 2	2 1 3
11B05X11B 11C 11A01					
35SEC IN AREA	10	T2	12	34T27	10
00000					
36SEC IN TENT	736	T2	12	35T17	736
00000					
TASK 13 DAY 083 9/07/68					
1SEC IN TENT	30	T2	12	36T17	30
00000					
2PRESS GAS SYS	390	3T2 4 610		T 1 100 2 10010 190	
13A					
3SEC IN TENT	1020	T2	13	2T171020	
00000					
TASK 14 DAY 084 9/08/68					
1SEC IN TENT	1390	T2	13	3T171390	
00000					
2REM BAY 4	50	T2 1 2 5	9	13R 2	25 1 25

08A01X08B00W08C00W

TASK 15 DAY 085 9/09/68

1REM BAY 4	20	T2	1	2	5	14	2R	2	10	1	10
08A01X08B00W08C00W											
2REM MARS GATE ASSY	15	1T2	1	2		4	6R	2	7	1	8
03B01X03B 03A 15A04 01A02											
3INST MARS GATE ASSY	15	1T2	1	2		15	2I	1	8	2	7
03B01X03B 03A 15A04 01A02											
4INST BAY 4	5	T2	1	2	5	15	1I	1	3	2	2
08A01X08B00W08C00W											
5INST BATT	30	2T2	1	2		12	29I	1	15	2	15
12906X12A01 01905X											
6TURN POWER ON	300	T2				12	24T27		300		
00000											
7TURN OFF POWER	65	T2				15	6T27		65		
00000											
8TURN ON POWER	135	T2				15	7T27		135		
00000											
9TURN OFF POWER	5	T2				15	8T27		5		
00000											
10TURN ON POWER	105	T2				15	9T27		105		
00000											
11TURN OFF POWER	15	T2				15	10T27		15		
00000											
12SEC IN TENT	730	T2				15	11T17		730		
00000											

TASK 16 DAY 086 9/10/68

1REM CASE 1	15	2T2	1	2	5		R	2	8	1	7
05A 05B 05C											
2WRAP TCFM SENSOR	15	2T2					I	1	15		
05C03X											
3REM CASE 4	15	1T2	1	2		15	4R	1	8	2	7
08A01X08B 08C											
4INST CASE 4	15	1T2	1	2		16	3I	1	8	2	7
08A01X08B 08C											
5INST CASE 4 SCREWS	10	1T2	1	2		16	4I	1	5	2	5
08A01X08B 08C											
6REM CASE 5	30	2T2	1	2		11	8R11		15	2	15
09A01X											
7REM POWER SUPPLY	30	2T2	1	2		16	1R	2	10	1	1011 10
09B05X09B 09C 09A01											
8SEC LOW GAIN ANT TO LAM	5	1T2					T	1	325		2
02A01X											
9UPDATE CASE 1 FOR ETL	5	1T2				16	1T	9	5		
05A01X05B X05C X											
10UPDATE CASE 5 FOR ETL	5	1T2				16	6T	9	5		
09A01X09B X09C X											
11REM TCFM SEN XDUCT ASSY	8	1T2	1	2			R	2	4	1	4
02B01X											
12INST XDOC ON LOW GAIN	7	1T2	1	2		16	8I	1	3	2	4
02B01X02A010											
13DISCON N TANK PRESS XDOC	2	1T2	2	4	6		R	2	1	1	1
06A 06B											
14ROUT TCFM SEN HARN	5	2T2	1	5		16	2T	1	2	2	214 1
02B02X02A01											
15CHECK PRESS	1	1T210				16	13T10		1		
06A 06B 06C											
16INST N TANK PRESS XDOC	2	1T2				16	15I	1	1	2	1
06A 06B											
17TORQUE TCFM SEN WIR HARN	10	2T2	5			16	2I	1	5	2	5
06B02X02A01 02B											
18INST POWER SUPPLY	10	2T2	1	2		16	7I	1	3	2	311 4

09805X09B	09C	09A01							
19TIE CASE I HARN			5	2T212	16	17I 1	211	214	1
05C00W05B	05A01								
20INST CASE 5			5	1T2 1 2 5	16	9I 1	3 2	2	
09808X09B	09C	09A01							
21REM TCFM XDUC ASSY			20	1T2 1 2	16	11R 2	10 1	10	
02801X02802	02A01	02A03 02A04							
22INST CASE 1			100	2T2 1 2 5	16	19I 1	50 2	50	
05401X05B	05C								
23MATE TCFM 1			15	2T2 1 2 5	16	22I 1	5 2	511	5
05809X05B	05C	05A01 02B							
24REM MARS GATE			2	1T2 1 2	15	3R 2	1 1	1	
03801X03B	03A								
25INST MARS GATE			3	1T2 1 2 5	16	24I 1	2 2	1	
03901X03B	03A								
26INST TCFM HARN			125	2T2 1 2 5	1216	21I 1	50 2	5014	25
02802X02801	02A	01A02							
27INST BURN WIRES ON S/P			25	2T2 1		I 1	13 2	12	
04A00W04B00W06A00W06B00W06C00W03816X03B		03A00W15A04 01A02							
28INST BURN WIRE SQUIB SIM			10	2T2 1	16	27I 1	5 2	5	
06004X06005X06006X06007X									
29CHK BURN WIRE RESIST			27	1T2	16	28T27	27		
00000									
30TURN ON POWER			23	12	15	11T27	23		
00000									
31REM FEPS			13	1T2 1 2		T 1	6 2	626	1
03903X03B	03A	15A04 01A02							
32INST FEPS			70	1T2 1 2	16	31I 1	34 2	3425	2
03803X03B	03A	15A04 01A02							
33COMP FEPS ALIGN TEST			35	2T210	16	32T 9	35		
03803X03B	03A	15A04 01A02							
34REM NARR ANG MARS GATE			12	2T2 1 2	12	27T 1	4 2	426	4
03902X03B	03A	15A04 01A02							
35BEGIN NAMG ALIGN			35	2T210		T 9	35		
03802X03B	03A	15A04 01A02							
36COMP ALIGN OF NAMG			5	2T210	16	35T 9	5		
03802X03B	03A	15A04 01A02							
37TILT S/C			15	1T2	16	36T16	15		
00000									
38CHK NAMG ALIGN			20	2T210	16	36T 9	20		
03802X03B	03A	15A04 01A02							
39CHANGE S/C POSITION			30	1T2	16	36T16	30		
00000									
40CHK NAMG ALIGN			35	2T210	16	36T 9	35		
03801X03B	03A	15A04 01A02							
41REVERIFIED NAMG ALIGN			10	2T210	16	40T27	10		
00000									
42START ALIGN VERIFICATION			60	2T210	16	41T 1	20 2	20 9	20
03801X03B	03A	15A04 01A02							
43TURN OFF POWER			5	1T2	16	30T27	5		
00000									
44COMP ALIGN VERIFICATION			5	2T2	16	42T 9	5		
03801X03B	03A	15A04 01A02							
45VER SCAN PLAT ALIGN			15	2T2		T 9	15		
03901X03B	03A	15A04 01A02							
46COMP VERIFICATION			5	2T2	16	45T 9	5		
03801X03B	03A	15A04 01A02							
47ROTATED S/C			10	1T2	16	46T16	10		
48INST OSE HOOD ON NAMG 1			1	1T2 1 2	16	46I 2	1		
03801X									
49INST OSE HOOD ON NAMG 2			1	1T2 1 2	16	46I 2	1		

						A43
03802X						
SOREM BAFFLE	1	1T2 1 2	16 32R 2	1		
03803X						
51INST OSE HOOD	1	1T2 1 2	16 46I 2	1		
03803X						
52RETURN BAFFLE TO B/S	1	1T2	16 50T26	1		
00000						
53SEC IN TENT	505	T2	16 52T17	505		
00000						
TASK 17 DAY 087 9/11/68						
1SEC IN TENT	65	T2	16 53T17	65		
00000						
2TURN ON POWER	85	T2	16 43T27	85		
00000						
3VERIFY BURN WIRES FIRED	20	1T2	16 29T 9	20		
G0000						
4REM BURN WIRES FROM S/C	20	3T2 1	17 3R 2	10 1	10	
01B09X03B24X03B25X04B08X04B10X04B11X06D05X06D06X06D07X01A02				03A	03B	
5INST BURN WIRE SIMS	20	T2 1	17 4I 1	10 2	10	
01B09X03B24X03B25X04B08X04B10X04B11X06D05X06D06X06D07X01A02				03A	03B	
6RET BURN WIRES TO LAB	15	T2	17 4T27	15		
00000						
7SEC NAMG CABLE	15	T2	16 44T27	15		
00000						
8TURN OFF POWER	70	T2	17 2T27	70		
00000						
9PREP TO OPEN CASE 1	15	2T2 1 2 5	16 22T 1	8 2	7	
05A01X						
10REM TCFM MODS	5	2T2 1 2 5	17 9R 2	2 1	3	
05B08X05B 05C 05A01						
11REM TCFM MODS	5	2T2 1 2 5	1 8R 2	2 1	3	
05B09X05B 05C 05A01						
12REM CASE 3 MODS	5	2T2 1 2 5	17 9R 2	2 1	226	1
07B01X07B02X07B03X07B04X07B05 07B06 07C 07A05 07A01						
12REM POWER HARN	4	2T2 1 512	17 12R 2	1 1	111	114 1
05C01X05C 05B 05A01						
13INST POWER HARN	4	2T2	17 12I 1	1 2	111	114 1
05C01X05C 05B 05A01						
14INST HEAT ON OSE HOOD	5	1T2 1	16 51I 1	3 2	2	
13B10X13B03 13B09 13B11						
15INST THERMO ON S/C	15	3T2 5	I 1	5 2	512	5
11A04X12A03X03B18X03B14X03B19X03B21X05A03X05A02X06A04X07A04X08A02X09A03X10A02X						
16REM GYRO CONT	4	2T2 1 2 5	1 24R 2	2 1	2	
07B06X07B05 07C 07A05 07A01						
17REL GYRO TIMER TO GAS	3	1T2	17 16R26	3		
00000						
18MATE AND TORQUE POW HARN	15	2T2 5	17 13I 1	5 2	511	5
05C01X05C 05B 05A01						
19DEMATE CONN	2	2T2 1	17 17R 2	111	1	
07C03X07C 07B05 07A05 07A01						
20MATE CONN	3	2T2 1	17 19I 2	211	1	
07C03X07C 07B05 07A05 07A01						
21INST CASE 1	5	2T2 1 2	17 12I 1	3 2	2	
05A01 05B 05C						
22SEC GYRO CONT IN GAS	5	2T2	17 16T26	5		
00000						
23REM CASE 6	7	2T2 1 2 5	R 2	4 1	3	
10A01X10B 10C						
24REM CASE 3	8	2T2 1 2 5	1 8R 2	4 1	4	
07A01 07A05 07B05 07C						
24INST CC+S MODS	30	2T2 1 2 5	17 11I 1	15 2	15	
07B01X07B02X07B03X07B04X07B05 07C 07A01 07A05						

25TOR SHEAR PLATE SCREWS	10 2T2 5	T 2	10		
12AD1X12AC2X					
26REL SHEAR PLATE FROM GAS	2 1T2 1 2	T 2	1 9	1	
07AD3X07AC1X07AC5 07B 07C					
26SEC SHEAR PLATE IN GAS	3 1T2	17 26T26	3		
00000					
27INST MOD BACK SCREWS	15 2T2 5	17 24I 1	8 2	7	
07B00W07C 07AD5 07AD1					
28MAIE.ATT CONT HARN	15 2T2 1 2 5	T 1	5 2	511	5
07C02X07C01 07CC3 07B 07AC5 07AD1					
29SEC SHEAR PLATE SUBASSY	15 T2 1 2 5	17 26T 1	8 2	7	
07AD3X07AD1					
30INST THERMO	15 T2 5	17 15I 1	5 2	512	5
11AD4X12AC3X03B18XC3B14XC3B19XD3B21X05AD3X06AD2X06AD4X07AD4X08AD2X09AD3X10AD2X					
31INST HEAT ON A/C JETS	15 T2 1 2	I 1	8 2	7	
13AD3X13AD4X13AD5X13A11X13A12X13A13X					
32SEC IN TENT	900 T2	17 31T17	900		
00000					
STAGE 3 SPACE SIMULATION TEST					
TASK 01 DAY 088 9/12/68					
1PREP THERMO	10 T2 5	T 1	3 2	312	4
11AD4X12AD3X03B18XC3B14XC3B19XD3B21X05AD3X06AD2X06AD4X07AD4X08AD2X09AD3X10AD2X					
2REM CASE 8	20 2T2 1 2	T 1	7 2	7 5	6
12AD1 12B01 12C					
3REM CLOCK AXIS	5 1T2 1 2	R 2	3 1	2	
03B04X01AD2					
4REM CONE AXIS	5 1T2 1 2	R 2	3 1	2	
03B05X03A 03B 15AD4 01AD4					
5RETIE ATT HARN	5 2T2 1 2	I 1	2 2	111	114 1
07C02X07C01 07C03 07B 07AD5 07AD1					
6VERIFY TORQUE CASE 8	15 1T2 5	1 2T 1	8 2	7	
12AD1X					
7TORQUE A/C GAS SYSTEM	10 1T2 1 2 5	I 1	5 2	5	
13AD1X05AD1					
8INST CASE 8	5 2T2	1 6I 1	3 2	2	
12AD1 12B01 12C					
9INST CLAMPS ON ATT CONT	3 2T2 1 2 5	1 5I 1	1 2	114	1
07C02X07C01 07C03 07B 07AD5 07AD1					
10REM CASE 3	2 2T2 1 2	R 2	1 1	1	
07AD1 07AD5 07AC3 07B 07C					
11INSP WIRING HARNESS	10 T2111213	T 2	5 8	5	
15AD1X15AD2 15AD3 15AD5 15AD6 01AD2					
12TORQUE CASE 6 CONN	33 T2 1 2 5	I 1	17 2	16	
10B00W10C01W10C02 10C03 10C04 10AD1					
13TORQUE CASE 6 MODS	34 2T2 1 2 5	I 1	17 2	17	
10B00W10C01W10C02 10C03 10C04 10AD1					
14TILT S/C	3 1T2	T16	3		
00000					
15REM SIT	5 1T2 1 2	R 2	3 1	2	
01B05X12B06X12AD1					
16REM BATT	15 2T2 1 2	R 2	8 1	7	
12B06X12AD1					
17CLEAN CABL + LLP	30 2T2	T27	30		
00000					
18TORQUE CASE 6 CONN	2 1T2 5	1 13I 2	2		
10C00W					
19REM PROP SYS	34 1T2 1 2 4 5	R 1	10 2	10 5	411 10
06AC0W06B00W06C00W06D00W					
20CABLE CASE 3	34 2T2 1 2	T 1	10 2	1011	1025 4
07AD0W07B00W07C00W					
21REL L/G SHORT DAMPER	15 1T2	T25	15		
00000					

22REL L/G LOWER DAMPER 00000	20 1T2	T25	20			
23INST DAMPER BRACK 01A02 02A01	8 2T2 1 2	I 1	4 2	4		
24REL SUPER STRUCT ASSY 00000	15 1T2	T25	15			
25TORQUE CABLES ON S/C 04B04X04B05X05B06X05B07X	30 2T2 5T2	I 1	10 2	1014	10	
26INST SUPER STRUCTURE 02C01002A01	5 3T2 1 2 5	1 24I 1	3 2	2		
27TORQUE SUPER STRUCTURE 02C01X02A01	30 1T2 5	1 26I 2	30			
28INST L/G SHORT DAMPER 02A03X02A02 02A01 02B 02C01	15 2T2 1 2	1 21I 1	8 2	7		
29REM SUPER STRUCTURE 02C01X02A01	20 3T2 1 2	1 27R 2	10 1	10		
30REP A/C GAS ASSY 13A09X	5 4T2 1 2	1 7X 1	3 2	2		
31REINST SUPER STRUCTURE 02C01X02A01	5 3T2 1 2 5	1 29I 1	3 2	2		
32INST L/G LOWER DAMPER 02A04X02A03 02A02 02A01 02B 02C01	5 2T2 1 2 5	1 22I 1	3 2	2		
33TORQUE L/G SHORT DAMPER 02A03X02A04 02A02 02A01 02B 02C01	5 1T2 5	1 28I 2	5			
34INST CASE 3 07A 07B 07C	5 2T2 1 2 5	1 20I 1	3 2	2		
35REL GYRO CONT FROM GAS 00000	5 1T2	T25	5			
36INST GYRO CONT 07B06X07B 07C 07A05 07A01	5 2T2 1 2 5	1 35I 1	3 2	2		
37INST SIT 01B05X	40 2T2 1 2	1 15I 1	20 2	20		
38REM L/G ANT ASSY 02A01X02A02 02A03 02A04 02B 02C01 01A02	25 3T2 1 2 5	R 1	10 2	1026	5	
39REM CASE 5 09A01X09B00W09C	20 2T2 1 2 5	R 2	8 1	8 5	4	
40SECUPE IN TENT 00000	882 T2	T19	882			
TASK 02 DAY 089 9/13/69						
1REM OSE CABLES FROM S/C 01A01X	30 2T2	R 1	30			
2INST CASE 6 10A01X10B 10C	45 2T 1 2 5	1 18I 1	23 2	22		
3REM CLOTH FROM SCAN PLAT 03A	15 2T2	R 1	15			
4TORQUE CASE 6 10A01 10C00W10B 15A04	40 2T2	2 2I 2	40			
5REM CLOTH FROM SUPER ST 03A	20 2T2	1 31R 1	20			
6REROUT MARS GATE CABLE 15B X03B01X03B 03A	5 2T2 1 2 12	T 1	1 2	111	114	2
7REL HARD FROM GAS 00000	5 1T2	T25	5			
8INST SHEARPLATE 07A03X07A01	5 2T2 1 2	I 1	3 2	2		
9SEC SCAN PLAT 03A01 03B	10 2T2	1 3T 1	10			
10TORQUE GYRO CONTROL 07B06X07A05 07A01	10 1T2 5	1 36I 2	10			
11REL PRIM SS 00000	1 1T2	T25	1			
12REL SCAN PLAT STRUCT ASS	29 1T2	T25	29			

00000									
13INST PRIM SS	15	1T2 1 2	2	11I 1	8 2	7			
13B01X									
14VERIFY TORQUE CASE 3	5	1T2 5		T 2	5				
07A01X07A03X									
15INST SHEAR PLATE XDUC	10	2T2 1 2		I 1	3 2	312	4		
07A04X07A03 07A01									
16INST CONE AXIS	65	2T2 1 2	1	4I 1	33 2	32			
03B05X03B 03A01 01A02 15A04									
17INST CLOCK AXIS	4	2T2 1 2	1	3I 1	2 2	2			
03B04X01A02									
18TORQUE SCAN HARN CLAMP	10	2T2 1 2 5	2	12I 1	5 2	5			
05C04X15B									
19TORQUE CONNECTORS	22	2T2 5	2	18I 2	22				
05C04X15B									
20INST CABLE CLAMPS	13	2T2 1 2		I 1	7 2	6			
05C04X15B									
21INST THERMOCOUPLES	15	2T2 1 5		I 1	5 2	512	5		
05A03X07A04X08A03X09A03X10A02X11A00W12A03X									
22INST LOUV ON S/C	15	2T2 1 2 5	2	7I 1	8 2	7			
08A02X08A01 08A03									
23TORQUE LOUV/CLOCK/CONE	15	1T2 5	2	22I 2	15				
08A02X08A01 08A03 03B04X03B05X									
24REM MONO TEL FROM S/C	25	3T2 1 2 4 5		R 2	12 1	13			
03B16X03B15 03B17 03B18 03B19 03B 03A 01A02 15A04									
25REM PURGE FROM IRS	60	2T2 4 6		R 2	20 1	2011	20		
03B16X03B15 03B17 03B18 03B19 03B 03A 01A02 15A04									
26INST LOUVER COVER	15	1T2 1		I 1	8 2	7			
08A03 08A02									
27PREP TO LOWER S/C TO PIT	5	H2		T27	5				
00000									
28TILT S/C	2	1H2		T16	2				
00000									
29COVER S/C	2	4H2	2	28T29	2				
01A01									
30TILT S/C	5	1H2	2	28T16	5				
00000									
31HOOK UP CRANE TO S/C	5	3H2 4 6	2	30T 1	2 2	2 3	1		
01A01									
32LIFT S/C OFF POSITIONER	7	4H2	2	31T 3	7				
01A01									
33MOUNT S/C ON RING	18	4H2 4 6	2	32T 1	6 2	616	6		
01A01									
34HOOK UP IRS MOVE TO PIT	5	3P2 4 6		I 1	1 2	110	128	2	
03B17X03B 01A01									
35CK PRESSURE ON IRS	45	1P2	2	30T10	45				
00000									
36PURGE IRS VENT	5	1P2	2	35T10	5				
00000									
37PURGE IRS STRUCT	20	1P2	2	36T10	20				
00000									
38PRESS IRS STRUCT	20	1P2	2	37T10	20				
00000									
39PRESS IRS VENT	20	1P2	2	36T10	20				
00000									
40INST THERMO ON IRS STRUC	10	2P2 1 5		38I 1	3 2	312	4		
03B18X03B19X03B									
41INST THERMO ON IRS VENT	10	2P2 1 5		39I 1	3 2	312	4		
03B18X03B19X03B									
42INST SAFE PLATE CASE 7	7	2P2 1 2		I 1	38 2	37			
11A01X11A03 11A04									
43PRESS COMPLETE ON IRS ST	2	P2	2	38T27	2				

00000					
44PRESS COMPLETE ON IRS VT	3	1P2	2	39T27	3
00000					
45STABLIZE S/C GAS SYSTEM	55	1P2	2	38T27	55
00000					
46SECURE IN PIT	622	P2	2	45T20	622
00000					
TASK 03 DAY 090 9/14/68					
1SECURE IN PIT	1440	P2	2	46T201440	
TASK 04 DAY 091 9/15/68					
1SECURE IN PIT	1397	P2	3	1T201397	
00000					
2REM HIGH PRESS LINE	6	2P2 4 6	R 2	3 1	3
00000					
3REM COV MOVE FROM PIT	7	4P2 4 6	R 1	2 2	2 3 3
01A01					
4REM S/C ROLLER CASTER	10	4H2 4 6	R 2	5 1	5
01A02					
5INST S/C ON POSITIONER	20	4H2 4 6	4	1I 1	7 2 7 3 6
01A01					
TASK 05 DAY 092 9/16/68					
1INST S/C ON POSITIONER	15	H2 4 6	4	5I 1	5 2 5 3 5
01A01					
2TORQ FASTENERS	1	2H2 5	5	1I 2	1
00000					
3REM S/C PLASTIC COVER	14	2H2	2	28R29	14
01A01					
4INST SCAN BRACKETS	30	2T2 1 2	2	9I 1	15 2 15
03A					
5INST CASE 5	15	2T2 1 2	1	39I 1	8 2 7
09A 09B 09C					
6INST SCAN HARN CLAMPS	5	2T2 1 2 5	I 1	2 2	214 1
05C04X05C 05B					
7CLEAN SOLAR PANEL	10	2T2	T 6	10	
04A02X					
8TIE COAX ON S/C	30	T2 2 6	I 1	10 2	1014 10
02C04X02C03					
9TORQUE CASE 5 SCREWS	45	T2 5	2	26I 1	15 2 30
09A					
10TURN POWER ON	65	T2	T27	65	
00000					
11TURN POWER OFF	85	T2	5	10T27	85
00000					
12TURN POWER ON	65	T2	5	11T27	65
00000					
13REM SHEAR PLATE	5	1T2 1 2	2	14R 2	2 1 226 1
07A03X07A01 07A04					
14PREP HIGH GAIN ANTENNA	15	1T2	T 1	8 9	7
02C01X					
15INST HIGH GAIN ANTENNA	10	3T2 1 2	5	14I 1	5 2 5
02C01X02C02X02C03X02C04X					
16PREP LOW GAIN ANTENNA	7	1T2	T 1	4 9	3
02A01X					
17INST LOW GAIN ANTENNA	8	3T2 1 2	5	16I 1	4 2 4
02A01X02A02X02A03X02A04X					
18REM CLOCK ACTUATOR	5	2T2 1 2	2	17R 2	3 1 2
03B04X					
19INST PTM CLOCK MODS	30	2T2	127	30	
15A01 15A02 15A03 15A04					
20POTTED TEMP XDUCS	45	2T2 5	I 1	15 2	1512 15

05A03X05A01 11A04X11A01					
21SECURE IN TENT	935 T2	5 20T17 935			
00000					
TASK 06 DAY 093 9/17/68					
1SECURE IN TENT	30 T2	5 21T17 30			
00000					
2INST THERMAL COVER	35 1T2 1 2 5	I 1 20 2 15			
C3B03X03B C3A					
3INST COAX TO ANT PROBE	55 2T2 1 2	5 8I 1 20 2 2014 15			
15A04X02C04XC1A02					
4TORQUE COAX	15 1T2 5	6 3I 2 15			
15A04X02C04XD1A02					
5REL THERMAL BLANKET GAS	5 1T2	T25 5			
00000					
6INST THERMAL BLANKET	145 3T2 1 2 5	6 5I 1 73 2 72			
14A01X14A02X14A03XC1A01001BC0003A G3B	G5AC0005BCC0005C0C006A00006B000006C000	M			
60CCCLUDE AREA OF ZONES					
C6D00007A00007BC00007C00008AG0008B0C00ECC00009ADG009BC0009C00010AAD0010B0C010DC000					
60CCCLUDE AREA OF ZONES					
11ACC011B00011CC0012ACCC12BC0012C00013AC0013B00015ADD015B0C014A000					
7INST LOUVER BAY 5	10 2T2 1 2 5	I 1 5 2 5			
09A02					
8CK A/C GAS VALVES	35 1T2	T10 35			
13A01 13A09					
9INST MOTION SEN CLAMP	30 1T2 1 2	5 4I 1 15 2 15			
01B02X03A					
10REL WIDE ANG TV CAMERA	1 1T2	T25 1			
00000					
11REL NARR ANG TV CAMERA	1 1T2	T25 1			
00000					
12REL TV POWER SUPPLY	1 1T2	T25 1			
00000					
13REL TV DATA CONV	1 1T2	T25 1			
00000					
14REL TV CAMERA DRIVERS	1 1T2	T25 1			
15REL TV CONTROL ASSY	1 T2	T25 1			
00000					
16INST WIDE ANG TV CAMERA	34 2T2 1 2 5	6 10I 1 17 2 17			
C3B10X03B C3A					
17INST NARR ANG TV CAMERA	15 2T2 1 2 5	6 11I 1 8 2 7			
C3B12X03B C3A					
18INST TV POWER SUPPLY	5 1T2 1 2 5	6 12I 1 3 2 2			
11B05X11A01 11C 11B01 11B02 11B03 11B04					
19INST TV DATA CONV	5 1T2 1 2 5	6 13I 1 3 2 2			
11B06X11A01 11C 11B01 11B02 11B03 11B04 11B05					
20INST TV CAMERA DRIVERS	5 1T2 1 2 5	6 14I 1 3 2 2			
11B07X11A01 11C 11B01 11B02 11B03 11B04 11B05 11B06					
21INST TV CONTROL ASSY	5 1T2 1 2 5	6 15I 1 3 2 2			
11B08X11A01 11C 11B					
22INST SUPPORT BRACKETS	15 3T2 1 4 6	I 1 5 2 S15 5			
03B12 03B10 03B C3A					
23INST AB STIMULUS	5 T2 1 4 6	I 1 2 2 215 1			
03B12 03B10 03B C3A					
24REM NARR ANG TV COVER	15 T2	6 17R27 15			
00000					
25TURN POWER ON	20 T2	5 12T27 20			
00000					
26TURN POWER OFF	9 T2	6 25T27 9			
00000					
27TURN POWER ON/OFF	113 T2	6 26T27 113			
00000					

28SECURE IN TENT	828	T2	6	27	17	828	
00000							
TASK 07 DAY 094 9/18/68							
1TEST IRR POWER ON	210	T2				T27	210
00000							
2REL IRR ASSY FROM GAS	135	T2				T25	135
00000							
3MATE IRR	105	T2				7	2127 105
00000							
4DEMATE IRR	90	T2				7	3127 90
00000							
5TURN POWER OFF	7	T2				7	1127 7
00000							
6INST NARR ANG TV COVER	8	1T2				6	241 1 8
03812X							
7REM OSE SCI PLAT	45	3T2 4 6				R 2	15 1 1515 15
03A 03B 15A04 01A02							
8INST HEATERS	5	1T2				I27	5
00000							
9INST HEATERS TO IRS	5	1T2 1 2				6	9I 1 3 2 2
11C04X11C 03A							
10INST THERMOCOUPLE HARN	80	2T2 1 5				I 1	30 2 3014 20
03821X03B 03A							
11INST HEATER HARN	10	2T2 1 5				I 1	4 2 414 2
11C04X11C							
12INST TC SHIELD	2	3T2 1 2 5				I 1	1 2 1
14A33 14A34 14A35 14A36							
13HOOK THERMOCOUPLE LEADS	2	2T2				I 1	2
03807X03809X03811X03813X03814X03818X03819X03822X							
14STOP HOOKING TC LEADS	13	T2				7	1127 13
00000							
15SEC LOOSE TC WIRES	125	2T2				7	13T 1 125
03807X03809X03811X03812X03814X03818X03819X03822X							
16TORO SCAN HEAT	15	1T2 5				I 1	5 2 10
11C04X03A 03B							
17INST LOWER CLOCK TUBE HT	10	T2 1 2				I 1	5 2 5
03804X03B 03A							
18INST UP OCTAGON HEATERS	105	T2 1 2				I 1	53 2 52
01A02							
19SECURE IN TENT	468	T2				T17	468

TASK 08 DAY 095 9/19/68							
1INST TC CONNS	30	2T2 1 5				7	13I 1 10 2 1012 10
05A03X06A02X06A04X07A04X08A03X09A03X10A02X11A04X12A03X							
2REL SHEAR PLATE	90	1T2				T25	90
00000							
3PREP TC	15	2T2				8	1T 1 6 2 612 3
05A03X06A02X06A04X07A04X08A03X09A03X10A02X11A04X12A03X							
4INST HEATER JUMPER	5	2T2				I27	5
00000							
5REM SUN GATE STIMULUS	40	1T2 1 2				R 2	20 1 20
13807X							
6REL TCFM 1	4	1T2				T25	4
00000							
7REL TCFM 2	4	1T2				T25	4
00000							
8REL TCFM SENSOR	6	1T2				T25	6
00000							
9REM PROTECTIVE COVER	1	1T2				R 1	1
03817X							

10INST TCFM SENSOR	15	T2 1 2	8	8I 1	8 2	7	
02B01X02B02 02A							
11REL TCFM INTER CONN HARN	25	1T2		T25	25		
00000							
12INST SUN GATE DETECTOR	13	2T2 1 213	8	5I 1	5 2	5 8	3
13B07X01A02							
13INST TCFM 1	5	1T2 1 2 5	8	6I 1	3 2	2	
05B08X05B 05A01 05C							
14INST TCFM 2	10	1T2 1 2 5	8	7I 1	5 2	5	
05B09X05B 05A01 05C							
15REL CC+S POWER	7	1T2		T25	7		
00000							
16TORQUE MOD + RATE CON AY	25	2T2 1 2 5		I 2	12 1	13	
08B11X08B 08A 08C							
17INST CC+S POWER SUPPLY	5	2T2 1 2 5	8	15I 1	3 2	2	
07B01X07B 07C 07A05 07A01							
18REL SHEAR PLATE	11	1T2		T25	11		
00000							
19TORQUE TCFM HARN	29	1T2 1 2	8	13T 1	10 2	1014	9
05C03X05C 05B 05A01							
20TORQUE SHEAR PLATE	1	1T2 5	8	18T 2	1		
07A03X07A04 07A01							
21INST CASE 7 COVER PLATE	44	1T2 1 2		I 1	22 2	22	
11A03 11A04 11A01							
22INST A/C MANIF	7	2T2 4 6	7	9I 1	3 2	4	
13A01X							
23INST A/C VENT	8	2T2 4 6	8	22I 1	4 2	4	
13A09							
24CLOSE WIDE ANG TV COVER	15	1T2	6	16T 1	15		
03B10X							
25VERIFY CASE 1	1	2T2		T 9	1		
00000							
26VERIFY CASE 2	1	2T2		T 9	1		
00000							
27VERIFY CASE 3	1	2T2	5	13T 9	1		
00000							
28VERIFY CASE 4	1	2T2	5	9T 9	1		
00000							
29VERIFY CASE 5	1	2T2	6	7T 9	1		
00000							
30VERIFY CASE 6	1	2T2	2	4T 9	1		
00000							
31INST GAS SYS BRACKETS	9	2T2 1 4 6	6	8I 1	5 2	4	
13A02X13A10X							
32INST A/C ASSY FOR TEST	15	2T2 4 6	8	22I 1	8 2	7	
13A01X13A09X							
33REM TAPE FROM LOW GAIN	3	1T2	5	17R 1	1 6	2	
02A00W							
34PREP S/C FOR ETL	20	2T2	8	30T27	20		
00000							
35REL LOUVER 1 FROM QAS	25	1T2		T25	25		
00000							
36REL LOUVER 7 FROM QAS	25	1T2		T25	25		
00000							
37REL LOUVER 8 FROM QAS	20	1T2		T25	20		
00000							
38INST SCREWS CASE 7	7	2T2 1 2	8	21I 1	4 2	3	
01A01X01A03X01A04							
39TORQUE CASE 7	3	1T2 1 2 5	8	38I 1	1 2	2	
01A01X01A03X01A04							
40REM CASE 7 GUIDE PINS	20	2T211	8	39R 2	10 1	10	
01A01X01A03X01A04							

41INST LOUVER 1	45 2T2 1 2 5	8 35I 1	23 2	22	
05A02X05A01 05A03					
42INST SHEAR PLATE 7	10 2T2 1 2 5	8 20I 1	5 2	5	
11A03X11A04 11A01					
43INST BATT	5 2T2 1 2 5	I 1	3 2	2	
12B06X12A01 12A03					
44INST CASE 7 CLOSURE FAST	15 1T2 12 5	8 42I 1	8 2	7	
11A03X11A04 11A01					
45INST LOUVER 7	30 2T2 1 2 5	8 36I 1	15 2	15	
11A02X11A03 11A04					
46INST CASE 7 CABLE STD OFF	95 1T2 1 2 5	8 45I 1	48 2	47	
12C01X					
47INST PROT COVER CASE 1	15 1T2 1 2	8 41I 1	8 2	7	
05A02X					
48INST PROT COVER CASE 7	15 1T2 1 2	8 45I 1	8 2	7	
11A02X					
49INST PROT COVER CASE 8	15 1T2 1 2	8 37I 1	8 2	7	
12A02X					
50INST SP CRUISE DAMPER	5 2T2 2 4	I 1	3 2	2	
04B03X01A02					
51DRILL HOLES IN PLUMB SYS	10 2T2 7	I 1	2 2	4 4	4
00000					
52REL PROP SYS ASSY	15 1T2	T25	15		
00000					
53INST PROP SYS	30 3T2 1 2 4 6 8	52I 1	10 2	10 9	10
06A00W06B00W06C00W06D00W					
54INST CRUISE DAMP BAY 1	5 2T2 2 4	I 1	3 2	2	
04B03X01A02					
55INST THERMAL SHIELD	30 2T2 1 5	I 1	15 2	15	
06D03X06A06					
56INST CANOPUS SENSOR	5 2T2 1 2 5	I 1	3 2	2	
13B08X13B09X13B10X13B11X					
57INST SP CRUISE DAMPER	30 2T2 2 4	I 1	15 2	15	
04B03X01A02					
58TORQUE SP CRUISE DAMPER	5 1T2 5	8 57I 1	2 2	3	
04B03X01A02					
59REM SUN SENSOR HOOD	5 1T2 1	R 2	2 1	3	
13B04X					
60INST CLOCK TUBE COVER	10 1T2 1 2	7 16I 1	5 2	5	
03B04X					
61TORQUE SIT	25 1T2 5	1 37I 1	12 2	13	
01B05X12B06X					
62INST SCAN LOUV BRACKET	30 2T2 1 2	I 1	15 2	15	
03A02X03A 03B					
63INST UV SPECTROMETER	10 2T2 1 2 5	I 1	5 2	5	
03B08X03A 03B					
64SECURE IN TENT	412 T2	T17	412		
00000					
TASK 09 DAY 096 9/20/68					
1SECURE IN TENT	40 T2	8 64T18	40		
00000					
2DEMATE PYRO ARMING SWITC	5 1T2	I 1	311	2	
01B06X					
3ADJ PYRO ARMING SWITCH	30 1T2 1 2	9 2T 1	15 2	15	
01B06X					
4TERMINATE ADJ	49 1T2 1 2	9 3T 1	25 2	24	
01B06X					
5INST THERMOCOUPLE	2 2T2	I 1	2		
05A03X06A02X06A04X					
6REL MONO TEL FROM GAS	5 1T2	T25	5		
00000					

7INST HEATERS ON MONO TEL	20 2T2 1	9 6I 1	10 2	10	
03B19X03B18XC3B16 03B17					
8INST MONO TEL	10 2T2 1 2 5	9 7I 1	5 2	5	
03B16X03B 03A					
9MATE CONN TO MONO TEL	25 2T2 6	9 8I 1	8 2	811	9
05C04X15B 03A 03B					
10INST THERMAL BRACKET	5 2T2 1 2 4	I 1	3 2	2	
14A56X14A03X					
11PEM WIDE ANG TV CAMERA	105 2T2 1 2	8 24R 2	53 1	52	
03B10X03B 03A					
12INST SCAN LINE	5 1T2 1 2	I 1	3 2	2	
03B15X					
13INST SCAN LATCH BRACKET	5 1T2 1 2	I 1	3 2	2	
01B01 01A20 01A19					
14STOW STRUCTURE ASSY	20 2T2	5 6T 1	10 9	10	
01A19 01A20 01B01 03A 03B					
15TORQUE STRUCTURE ASSY	30 1T2 1 2 5	9 14I 1	15 2	15	
01A19 01A20 01B01 03A 03B					
16PRESS STRUCTURE ASSY	30 1T2	9 15T27	30		
00000					
17CK STRUCTURE ASSY	1 T2	9 16T 9	1		
00000					
18TORQUE STRUCTURE ASSY	24 T2 1 2 5	9 17I 1	12 2	12	
01A19 01A20 01B01 03A 03B					
19DEMATE S/C	35 T2	5 1T27	35		
00000					
20PREP TO MOVE TENT	15 4T2	T27	15		
00000					
21SECURE POSITIONER	1 1H2 4 6	5 1T15	1		
00000					
22INST CLAM SHELL TO S/C	4 4H2 4 6	I 1	1 2	1 3	129 1
01A01X					
23BOLT S/C TO POSITIONER	30 2H2 4 6	9 21I 1	10 2	1016	10
01A01X					
24PLACE S/C ON CART	10 4H2	9 23T13	516	5	
01A01X					
25INST LIFTING BARS TO S/C	5 2H2 1 2 5	9 24I 1	3 2	2	
01A01					
26TORQUE CLAM SHELL	2 2H2 5	9 22I27	2		
00000					
27INST FRAME SPACER	3 2H2 1 2 5	I 1	2 2	1	
00000					
28TORQUE CLAM SHELL	30 2N5 5	9 26I27	30		
00000					
29REL THERMAL BLANKETS	20 1N5	T13	20		
00000					
30TRANSPORT S/C TO SOL SIM	30 N5	9 29T21	30		
00000					
31REM CLAM SHELL	14 4S2 4 6	9 30R 2	2 1	229	10
01A01					
32REM S/C FROM CART	64 4S2	9 31R 1	22 3	2116	21
01A01					
33MATE S/C TO END BELL	4 4S2 1 2 4 6	9 32T 1	1 2	116	2
01A01					
34ROLL BELL UNDER CHAMBER	144 4S2	9 33T16	144		
01A01					
35REM HOLDING FRAMES	24 2S2	9 34R27	24		
00000					
36INST SP ON BAY 7	27 2S2 1 2	9 35I 1	14 2	13	
13A01 13A09 01A01					
37INST SP ON BAY 5	5 2S2 1 2	9 35I1	3 2	2	
13A01 13A09 01A01					

38REM BAY 7 GAS SYS	25 2S2 1 2	9 35R 2 13 1 12
13A01 13A09 01A01		
39REM BAYS GAS SYS	30 2S2 1 2	9 35R 2 15 1 15
13A01 13A09 01A01		
40INST SP ON BAY 3	24 2S2 1 2	9 35I 1 12 2 12
13A01 13A09 01A01		
41INST SP ON BAY 1	8 2S2 1 2	9 35I 1 4 2 4
13A01 13A09 01A01		
42CONN TC TO SOLAR PANELS	39 2S2	9 41I27 39
00000		
43SECURE IN CHAMBER	436 S2	9 42T19 436
00000		
TASK 10 DAY 097 9/21/68		
1CABLE-UP S/C	30 3S2	9 43I27 30
00000		
2INST IRS GAS ASSY OSE	3 3S2	8 9I27 3
00000		
3INST IRS VENT OSE	3 2S2	2 44I27 3
00000		
4CK TC OSE	3 2S2	9 42T27 3
00000		
5CK SWITCHES OSE	22 2S2	10 3I27 22
00000		
6TERM CHECKOUT OSE	30 2S2	10 5I27 30
00000		
7CK HEATERS OSE	47 2S2	10 6I27 47
00000		
8INST SUN SENSOR STIMULUS	20 1S2 1 2	I 1 10 2 10
13805X		
9REM SUN SENSOR HOODS	120 1S2 1	R 2 60 1 60
13803X13804X13805X13806X		
10INST IRS GAS STORAGE	1 2S2	I 1 1
03815X-		
11INST TC ON MONO TEL	57 2S2 1 2	9 9I 1 19 2 1912 19
03818X03819X03817 03816 038	03A	
12REGASKET IRS GAS ASSY	60 2S2 4 6	10 2I 1 20 2 2011 20
03817X03815X038 03A		
13INST WIDE ANG TV CAMERA	30 2S2 1 2	9 11I 1 15 2 15
03810X038 03A		
14INST SQUIB VALVE	1 2S2 1 4 6	I 2 1
03824X03825X03A 03B		
15TORQUE IRS VENT ASSY	14 2S2 5	10 3I 1 7 2 7
03817X03816X03A 03B		
16CK SCAN SQUIBS	9 1S2	10 14T27 9
00000		
17REPRESS GAS SYS	16 1S2	9 16T11 827 8
00000		
18COMPLETE PRESS GAS SYS	14 1S2	10 17T10 727 7
00000		
19INST IRS THERM PROBE	8 1S2 1 2	10 2I 1 4 2 4
11C04X		
20TORQUE IRS GAS ASSY	10 1S2 5	10 19T 2 10
03815X03816X03817X038 03A		
21INST HEATER ON MONO TEL	4 2S2 1 2	10 11I 1 2 2 2
03815X03816X03817X038 03A		
22TORQUE WIDE ANG TV	7 2S2 1 2 5	10 13I 1 3 2 327 1
03810X03811X038 03A		
23MATE CONN TO WIDE ANG TV	3 1S2	10 22T11 3
03810X03811X038 03A 158	05C04	
24INST UVS STIMULUS	6 1S2 1	10 23I 1 315 3
03808X03809 03B		

25TORQUE MONO TELE FAST	7 1S2 5	10 23I 2	7	
03B15X03B16X03B17X03B	03A			
26INST SCI STIM PLAT	55 3S2 1 4 6	7 7I 1	20 2	2015 15
03B				
27MATE PAS CONNECTORS	53 1S2	111	53	
01B06X01A02				
28INST TC BRACKETS	8 3S2 1 2 4 6 9 29I 1	4 2	4	
14A19X14A20X14A21X14A22X14A23X14A24X14A25X14A26X14A27X14A28X14A29X14A30X				
29REM PS COVER	5 1S2	8 53R 1	5	
06B03X06B04X06C03X				
30REM IRS COVERS	4 1S2	10 20R 1	4	
03B15X03B16X03B17X				
31INST TCM BLANKETS	8 3S2 1 2	10 28I 1	4 2	4
14A01X				
32INST TOP TCM BLANKET	4 3S2 1 2	10 31I 1	2 2	2
14A01X01A02				
33WIRE CANOPUS SENSOR	31 2S21113	1 1	10 2	11 8 10
13B08X13B09X13B10X13B07X				
34MATE UVS ASSY	10 2S2 5	8 63T 1	3 2	311 4
03B08 03B09 05C03 05C04				
35REM IRR STIMULUS	10 1S2	7 4R75	10	
03B06X03B07X				
36LOOSEN SCAN HARNESS	88 S2 1 212	9 16T 1	22 2	2211 2214 22
05C04X05B 05A 14A03				
37MOVE SCAN HARNESS	117 3S2 1 212	10 36T 2	59 1	58
05C04X05B 05A 14A03				
38INST TC CHANNELS	4 3S2 1 2 5	10 31I 1	2 2	2
14A14X14A15X14A16X14A17X14A18X14A07X14A08X14A09X14A10X14A11X14A12X14A13X				
39INST PAS FIX	4 1S2 1 2	9 3I 1	2 2	2
01B06X				
40ADJ 8AY 7 SHEAR PLATE	2 2S2 1 2 5	8 42T 1	1 2	1
11A03X11A04 11A01				
41SECURE IN SIMULATOR	512 S2	10 40T19	512	
00000				
TASK 11 DAY 098 9/22/68				
1SECURE IN SIMULATOR	24 S2	10 41T19	24	
00000				
2CK GAS LEAK TEST	24 2S2	10 18T10	24	
00000				
3OPEN THERM BLANKETS	8 1S2 1 2	10 28T 1	4 2	4
14A01X				
4AC LEAK CHECK	2 1S2	11 2T10	2	
13A01 13A09 14A01 01A01				
5AC LEAK CHECK	19 1S2	11 4T10	19	
13A01 13A09 14A01 01A01				
6OPEN VALVES ON A/C	9 2S2	10 30T11	511	4
13A01 13A09 14A01 01A01				
7CK A/C LEAK	9 2S2	11 6T10	511	4
13A01 13A09 14A01 01A01				
8EXHAUST LEAK	24 2S2	11 7T10	1211	12
13A01 13A09 14A01 01A01				
9EXHAUST LEAK	24 2S2	11 6T10	1211	12
13A01 13A09 14A01 01A01				
10TERMINATE A/C LEAK	32 2S2	11 9T10	1611	16
13A01 13A09 14A01 01A01				
11CLOSE A/C VALVES	1 2S2	11 8T10	1	
13A01 13A09 14A01 01A01				
12OPEN A/C VALVES SYS	1 2S2	11 9T10	1	
13A01 13A09 14A01 01A01				
13INST SUN SENSOR H0CD	45 1S2 1	10 9I 1	23 2	22
13B03X13B04X13B05X13B06X				
14SECURE IN SIMULATOR	1158 S2	11 13T191158		

```

00000
15CK LEAK IRS 1 2S2 11 10T10 1
03R15 03B16 03B17 03A
16INST SUN SENSOR OSE HOOD 4 1S2 1 11 13I 1 2 2 2
13B03 13B04 13B05 13B06
17INST IRS BELLOW 5 2S2 1 2 11 15I 1 3 2 2
03B17X03B15X03B16X03B
18PUMP IRS ASSY 20 1S2 11 17T27 20
00000
19REM NARR ANG TV COVER 5 1S2 6 17R 1 5
03B12X
20LEAK TEST IN PROGRESS 11 1S2 10 21T27 11
00000
21INST CONN TO S/C 14 1S2 11 14
01B05X01B06X

TASK 12 DAY 099 9/23/68
1ADJ WIDE ANG TV STIMULUS 1 1S2 1 10 22T 2 1
03B10X
2REM DUST COVER FROM A/C 1 1S2 11 8R 1 1
13A14X13A15X
3REM DUST COVER A/C VENT 1 1S2 11 9R 1 1
13A14X13A15X
4REM TCFM COVER 16 1S2 8 10R 1 16
C2B01X02B02X02A 14A01
5LEAKING GAS IRS VENT 21 1S2 12 3T10 1127 10
00000
6CLOSE VALVE ON A/C VENT 6 1S2 12 5T 1 311 3
13A01 13A09 14A01
7IRS XDUC LEAK 14 1S2 12 6T10 14
00000
8REM UVS STIMULUS 8 1S2 1 10 34R 2 4 1 4
03B08X03B09X03B 03A 14A02 14A03
9INST UVS STIMULUS 8 1S2 1 12 8I 1 4 2 4
03B08X03B09X03B 03A 14A02 14A03
10REM UVS DESICCANT 1 1S2 12 9R 1 1
03B08X03B09X03B 03A 14A02 14A03
11INST FOIL ON STIMULUS 9 S2 12 9I27 9
00000
12REPAIR CANOPUS SEN CABLE 1 2S212 10 33T 2 1
13B08X13B09X
13LEAK IN IRS VENT 1 1S2 12 7T27 1
00000
14REM PYRO ARMING PIN 18 1S211 10 39R 2 9 1 9
01B06X
15INST NEEDLE VALVE 5 1S2 1 2 5 1 1 3 2 2
13A02X13A10X
16INST IRR STIMULUS 5 1S2 1 10 35I 1 3 2 2
03B06X03B07X03B 03A 14A02 14A03
17REPAIR CANOPUS SEN WIPE 5 1S212 12 12T 2 5
13B08X13B09X
18LEAKING IRS ASSY 5 1S2 12 13T27 5
00000
19SEC GROUND STRAP 3 1S2 2 12 10R 1 1 2 127 1
00000
20TURN POWER ON 43 S2 6 27T27 43
00000
21REM THERMAL BLANKETS 1 1S2 1 2 5 11 3R 2 1
13A01X13B02X14A01X05A00E05B00E05C00E06A00E06B00E06C00E06D00E07A00E07B00E07C00E
21REM THERMAL BLANKETS 1S2 1 2 5 11 3R 2
08A00E08B00E08C00E09A00E09B00E09C00E10A00E10B00E10C00E11A00E11B00E11C00E12A00E
21REM THERMAL BLANKETS 1S2 1 2 5 11 3R 2

```

1230CE12C00E13A00E15A00E01A00E01800E					
22INST STIM FOR WID ANG TV	1 IS2 1	10 23I 2	1		
03910X03B11X03B 03A 14A02 14A03					
23LEAKING IRS ASSY	1 IS2	12 18T27	1		
00000					
24INST SCAN VENT	7 2S2 1 2	10 36I 1	4 2	3	
01B09X03AC2X03A01X03B 14A02 14A03					
25CK IRS LEAK	1 IS2	12 23T10	1		
00000					
26REM LOUVER BAY 8	1 IS2 1	8 49R 2	1		
12A02X					
27LEAK TEST IRS	7 IS2	12 23T10	7		
00000					
28INST BOB CASE 7	36 IS2 1 2	9 36I 1	18 2	18	
11A00W11B00W11C00W					
29TEST PRESS XDUC IRS	42 IS2	12 27T10	42		
00000					
30INST TC OVER SUN SENSOR	1 IS2 1 2	11 16I 2	1		
14A04X14A05X14A01					
31REM LINE FROM IRS VENT	25 IS2 4 6	12 29R 2	12 1	13	
03815X03B17X03B 03A 14A02 14A03					
32TORQUE IRS VENT ASSY	28 IS2 5	12 31I 1	14 2	14	
03915X03B17X03B 03A 14A02 14A03					
33CK SQUIBS	3 IS2	10 14T27	3		
01909X03B24X03B25X					
34INST FILTER ON IRS VENT	4 S2	12 32I27	4		
00000					
35TURN POWER OFF	15 S2	12 20T27	15		
00000					
36TURN POWER ON	30 S2	12 35T27	30		
00000					
37TURN GYROS ON	15 S2	12 36T27	15		
00000					
38TURN GYROS OFF	75 S2	12 37T27	75		
00000					
39INST LN CABLE	55 IS2	127	55		
00000					
40RAISE S/C TO CHAMBER	75 IS2	116	75		
01A01 14A01 14A02 14A03					
41TURN POWER OFF	15 S2	12 36T27	15		
00000					
42TURN POWER ON	15 S2	12 41T27	15		
00000					
43REM IRS COVERS	15 IS2	12 32R 1	15		
03815X03B16X03B17X03A 03A 14A02 14A03					
44CLOSE CHAMBER DOORS	8 S2	9 30T27	8		
00000					
45START PUMPS	15 IN2	12 44T27	15		
00000					
46CLOSE BOTTOM OF CHAMBER	20 IN2	12 44T27	20		
00000					
47SECURE CRAFT IN CHAMBER	757 N2	12 46T19	757		
00000					
TASK 13 DAY 100 9/24/68					
1SECURE IN SIMULATOR	1440 N2	12 47T19	1440		
00000					
TASK 14 DAY 101 9/25/68					
1SECURE IN SIMULATOR	1440 N2	13 1T19	1440		
00000					
TASK 15 DAY 102 9/26/68					
1SECURE IN SIMULATOR	1440 N2	14 1T19	1440		
00000					

17INST MONO TEL IN CAN	5 2S2	23 15I27	5	
00000				
18INST SHIELD ON UVS	2 1S2	10 34I 1	2	
03A02X03B08X03B09X				
19REM LINES A/C CAP/TORQ	25 2S2 4 5 6	6 8R 1	12 2	13
13A02X13A10X				
20INST WIRE ON IRS CAN	5 1S2	127	5	
00000				
21REM THERMAL BLANKETS	5 3S2 1 2 5	11 3R 2	2 1	3
14A01X01A01 02A01				
22REM UVS STIMULUS	10 1S2 1 2	12 9R 2	5 1	5
03B08X03B09X03B 03A				
23REM THERMAL BLANKETS	5 3S2 1 2 5	11 3R 2	2 1	3
03A02X14A03X15B00E				
24REM SIT ACTUATOR	10 1S2 1 2	8 61R 2	5 1	5
01B05X				
25REM PAS ACTUATOR	8 1S2 1 2	10 27R 2	4 1	4
01B06X				
26REM THERM SHIELDS	7 2S2 1 2 5	R 2	4 1	3
14A14X14A15X14A16X14A17X14A18X14A19X14A20X14A21X14A22X14A23X14A24X				
27REM BELLWS IRS ASSY	5 1S2	12 32R27	5	
00000				
28REM LOWER THERMAL BLANK	45 3S2 1 2 5	10 28R 2	22 1	23
14A02X03A 03A 15AC4 01A02 13B00E				
29CAP SUN SENSORS	5 2S2	11 15T 1	5	
13B01X13B02X13B04 13B05 13B06 13B03				
30RECOCK SIT	1 1S2	8 61I 1	1	
01B05X				
31REM SHIELD ON H/G ANTEN	24 1S2 1 2	R 2	12 1	12
14A44X				
32REM IRR COVER /REPLACE	3 S2 1 2 5	23 5X 2	1 1	2
03B06X03B07X				
33REM FAR ENCOUNTER HOOD	6 1S2 1	R 2	3 1	3
03B03X03B 03A				
34INST FAR ENCOUNTER HOOD	6 1S2 1	23 33I 1	3 2	3
03B03X03B 03A				
35INST IRR STIMULUS	5 1S2 1	10 35I 1	3 2	2
03B06X03B07X				
36REM FAR ENCOUNTER HOOD	14 1S2 1	23 34R 2	7 1	7
03B03X03B 03A				
37INST FAR ENCOUNTER HOOD	2 1S2 1	23 36I 1	1 2	1
03B03X03B 03A				
38TORQUE FAR ENCOUNT HOOD	9 1S2 5	23 37I 2	9	
03B03X03B 03A				
39COVER MARS GATE	22 1S2	I 1	22	
03B01X03B02X03B 03A 01A02 15A04				
40REM CLOCK ACTUATOR	2 2S2 1 2	2 17R 2	1 1	1
03B04X02C 02A 02B 15A01 15A02 15A03				
41INST CLOCK ACTUATOR	2 2S2 1 2	23 40I 1	1 2	1
03B04X02C 02A 02B 15A01 15A02 15A03				
42REM CONE ACTUATOR	2 2S2 1 2	2 16R 2	1 1	1
03B05X03B 03A 15A04 01A02				
43INST CONE ACTUATOR	3 2S2 1 2	23 43I 1	2 2	1
03B05X03B 03A 15A04 01A02				
44REM CANOPUS SENSOR HOOD	30 1S2 1 2	10 33R 2	15 1	15
14A48X13B08X13B09 13B11				
45INST BAFFLE ON CAN SEN	10 2S2 1 2	23 44I 1	5 2	5
13B10X14A48 13B08 13B09 13B11				
46TORQUE BAFFLE	10 1S2 5	23 45I 2	10	
13B10X14A48 13B08 13B09 13B11				
47INST DUMMY SQUIB	15 1S2 1 2	12 33I 1	8 2	7
01B09X03A				

48CLOSE WIDE ANG TV COVER	1 1S2	12 17 1 1	
03B10X03B11X			
49REM COVER ON NARR ANG TV	44 1S2	23 4R 1 44	
03B12X03B13X03B 03A 01A02 15A04			
50INST H/G LOWER CABLE	60 2S2 1 2 5	I 1 30 2 30	
02C03X02C04X02C02 02C01 02A 01A02			
51INST L/G CABLE	60 2S2 1 2 5	I 1 30 2 30	
02A02X02A01 02A03 02A04 02B 02C			
52SECURE IN SIMULATOR	802 S2	119 802	
00000			
TASK 24 DAY 111 10/05/68			
1INST TC ON CDS	53 1S2 1 2	I 1 20 2 2012 13	
13B10X13B08 13B09 13B11			
2A0J WIRES ON BAY 8	120 1S212	12 26T 1 60 2 60	
12A01X12A02X12A03			
3REL IRS VENT IN CHAMBER	12 S2	23 27T13 12	
00000			
4MOUNT TC SUP A/C BOTTLES	10 1S2 1 2 4 6	T 1 5 2 5	
13A01X13A02X13A09X13A10X			
5REL MONO TEL TO CHAMBER	20 1S2	23 17T27 20	
00000			
6INST MONO TEL	25 3S2 1 2 4 524	5I 1 13 2 12	
15A04 03B10X01A02 03B18X03B19X03B 03A			
7REL IRS ASSY	10 1S2	24 3T27 10	
00000			
8INST IRS ASSY	15 3S2 1 2 5 24	7I 1 8 2 7	
03B15X03B16X03B17XC3B18X03B19XC3B 03A 15A01 01A02			
9INST THERMOSHIELD	25 2S2 1 2 5	I 1 13 2 12	
07A02X			
10REM MONO TEL COVER	28 1S2 1 2	24 6R 2 14 1 14	
03B16X03B 03A 01A02 15A04			
11INST TC ON IRS ASSY	12 2S2 1	24 8I 1 4 2 412 4	
03B18X03B 03A			
12INST HEATER ON MONO TEL	5 2S2 1 2	24 10I 1 3 2 2	
03B16X			
13REM WIDE ANG TV	40 2S2 1 2	23 48R 2 20 1 20	
03B10X03B 03A 01A02 15A04			
14INST IRS ASSY SCREWS	10 2S2 1 2 5 24	8I 1 5 2 5	
03B15X03B 03A			
15INST THERM SHIELD	47 3S2 1 2 5	I 1 25 2 22	
14A44X14A14X14A15X14A16X14A17X14A18X14A19X14A20X14A21X14A22X14A23X14A24X			
16REL MAG SHIELD	3 1S2	T27 3	
00000			
17INST THERM CONT	15 2S2 1 2 5	I 1 8 2 7	
14A04X14A05X14A49X14A50X14A51X14A52X			
18INST MAG SHIELD ON WA TV	25 2S2 1 2 5 24	16I 1 13 2 12	
03B10X03B11 03B 03A 01A02 15A04			
19INST THERM CONT	11 2S2 1 2 5	I 1 6 2 5	
14A07X14A08X14A09X14A10X14A11X14A12X14A13X14A45X14A46X14A47			
20PEWORK MAG SHIELD	1 2S2 1 2 5 24	18T 2 1	
03B10X03B11 03B 03A			
21TORQUE CANOPUS SENSOR	3 1S2 5	10 33I 2 3	
13B08X13B09 13B10 13B11			
22CK LEAK IRS ASSY	1 1S2	24 8T27 1	
00000			
23CK LEAK IRS VENT	2 1S2	23 10T27 2	
00000			
24REM MAG SHIEL WIDE TV	14 2S2 1 2 5 24	18R 2 7 1 7	
03B10X03B11X03B 03A			
25INST MAG SHIEL WIDE TV	4 2S2 1 2 5 24	24I 1 2 2 2	
03B10X03B11X03B 03A			
26INST TEFLON TAPE WIDE TV	10 S2	I27 10	

03R10X								
27INST WIDE ANG TV	12	2S2	1	2	5	24	13I	1 6 2 6
03B10X03B11X03B 03A								
28TORQUE WIDE ANG TV	20	1S2	5			24	27T	2 20
03B10X03B11X03B 03A								
29TORQUE WID ANG TV FAST	25	1S2	5			24	28T	2 25
03B10X03B11X03B 03A								
30LOWER SCAN PLAT	35	3S2				2	12T	1 35
03A XC3B 01A20 01A19 01B01 15A04 01A02								
31REM SCAN PLAT PROTEC SHD	30	1S2				24	30R	1 30
03A02X03A								
32INST SCAN PLAT T/C SHD	5	1S2	1	2	5	24	31I	1 3 2 2
14A01X14A02X14A03X03A 03B								
320CCLUDED ZONES								
01A00001B0000C5A0000C5B0000C5C0000C6A0000C6B0000C6C0000C6D0000C7A0000C7B0000C7C0000C8A0000								
320CCLUDED ZONES								
08B0000C8C0000C9A0000C9B0000C9C0000C10A0000C10B0000C10C0000C11A0000C11B0000C11C0000C12A0000C12B0000								
320CCLUDED ZONES								
12C0000C13A0000C13B0000C15A0000C15B0000								
33INST ACTUATOR	10	1S2	1	2	5		I	1 5 2 5
01B06X								
34MATE IN FLIGHT CONNECT	17	1S2					I	1 7 11 10
01B05X01B06X								
35INST BAY CHANELS	28	2S2	1	2	5		I	1 14 2 14
14A25X14A26X14A27X14A28X14A29X14A30X14A31X14A32X								
36INST TC CORNER SHIELDS	10	2S2	1	2	5		I	1 5 2 5
14A37X14A48X14A54X								
37REM CANOPUS BAFFLE BOX	10	1S2	1	2	5	23	46R	2 5 1 5
14A48X13B10X13B08 13B09 13B11								
38INST CANOPUS BAFFLE BOX	6	1S2	1	2	5	24	37I	1 3 2 3
14A48X13B10X13B08 13B09 13B11								
39REM ALL LOUVER COVERS	49	1S2	1	2	5	23	11R	2 25 1 24
05A02X07A03XC8A02X09A02X10A01X11A02X01A02								
40INST LOUVER CLOSER	10	1S2	1	2	5	24	39I	1 5 2 5
12A02X								
41LEVEL S/C	25	1S2					T15	1327 12
01A01								
42RAISE S/C INTO CHAMBER	45	1S2				24	41T16	45
00000								
43SEC LOCK CHAMBER	15	1N2				24	42T19	15
44SECURE IN SIMULATOR	567	N2				24	43T19	567
00000								
TASK 25 DAY 112 10/06/68								
1SECURE IN STIMULATOR	1440	N2				24	44T191440	
00000								
TASK 26 DAY 113 10/07/68								
1CK TC	5	1S2				24	36T	9 5
01A01								
2FIRE L-S BAY 8	25	1S2				24	2T27	25
00000								
3RECOCK L-S	45	1S2				26	2T	1 45
12A01X								
4FIRE L-S BAY 8	10	S2				26	2T27	10
00000								
5TURN POWER OFF	5	S2				12	42T27	5
00000								
6TURN POWER ON	30	S2				26	5T27	30
00000								
7TURN GYRO ON	30	S2				26	6T27	30
00000								
8TURN GYRO OFF	30	S2				26	7T27	30

00000	9TURN POWER OFF	45	S2	26	8T27	45			
00000	10REM PROTECTIVE COVERS	10	1S2		R 1	10			
03B00W	11SEC CRAFT IN CHAMBER	1205	S2	26	10T191205				
00000	TASK 27 DAY 114 10/08/68								
	1SECURE IN SIMULATOR	1440	N2	26	11T191440				
00000	TASK 28 DAY 115 10/09/68								
	1SECURE IN SIMULATOR	1440	N2	27	1T191440				
00000	TASK 29 DAY 116 10/10/68								
	1SECURE IN SIMULATOR	1440	S2	28	1T191440				
00000	TASK 30 DAY 117 10/11/68								
	1SECURE IN SIMULATOR	122	S2	29	1T19 122				
00000	2PREP TO REM STIM PLAT	20	2S2 4 6	21	35T 1	7 2	715	6	
03A 03B 01A02 15A04	3REM STIM PLAT	40	3S2 4 6	30	2R 2	14 1	1415	12	
03A 03B 01A02 15A04	4REM L/G CONN CABLE	20	2S2 1 212	23	51R 2	10 1	10		
02A02X02A 02B 14A01	5REM H/G CONN CABLE	10	2S2 1 212	23	50R 2	5 1	5		
02C04X02C 02B 02AG1 02AC3 C2A04 01A02 14A01	6REL CASE 6	3	1S2	8	30T25	3			
00000	7PREP TO INST CASE 6	7	1S2 1 2 5	30	6T 1	4 2	3		
10A 10B 10C	8INST CASE 6	40	2S2 1 2 5	30	7T 1	20 2	20		
10A 10B 10C	9SECURE IN SIMULATOR	1178	S2	30	8T191178				
00000	TASK 31 DAY 118 10/12/68								
	1SECURE IN SIMULATOR	1440	S2	30	9T191440				
00000	TASK 32 DAY 119 10/13/68								
	1SECURE IN SIMULATOR	1440	S2	31	1T191440				
00000	TASK 33 DAY 120 10/14/68								
	1SECURE IN SIMULATOR	1440	S2	32	1T191440				
00000	TASK 34 DAY 121 10/15/68								
	1SECURE IN SIMULATOR	1440	S2	33	1T191440				
00000	TASK 35 DAY 122 10/16/68								
	1SECURE IN SIMULATOR	1440	S2	34	1T191440				
00000	TASK 36 DAY 123 10/17/68								
	1SECURE IN SIMULATOR	55	S2	35	1T19 55				
00000	2INST ADAPT HARNESS	15	2S2 1 2 5		I 1	5 2	514	5	
01A23X01B04X01A24X	3DRILL HOLES IN COAX CONN	170	2H2 7		T 4	170			
01A23X01B04X01A24X15A10X15A11X15A12X15A13X	4ROUT SIGNAL HARN	100	2H2 1 2 5		T 1	33 2	3314	34	
01A23X01B04X01A24X15A01X15A11X15A12X15A13X	5INST NA TV STIM/ADAPT	35	2H2 11113	23	49T 1	12 2	12 8	11	
01A23X01B04X01A24X15A10X15A11X15A12X15A13X	6COMPLETE SIG HARN/ADAPT	35	2H2 1 2 5	36	3I 1	9 2	911	914	8

01A23X01B04X01A24X15A10X15A11X15A12X15A13X
 7SECURE IN HIGH BAY 1015 H2 36 6T181015
 00000
 8OPEN SIMULATOR DOOR 2 1H2 24 43T27 2
 00000
 9COVER IRS SCOPE 1 1H2 24 14T 1 1
 03B16X03B15X
 10REM MONO TEL RAD 2 1H2 24 6R 1 2
 03B16X03B15X
 11LOWER BELL 2 H2 36 8T27 2
 00000
 12INST WOOD FLOOR 8 H2 127 8
 00000
 STAGE 4 VIBRATION TEST ETL LAB 144
 TASK 01 DAY 123 10/18/68
 1REM OSE CABLES 5 S2 R27 5
 00000
 2INST LOUV COVER 30 1S2 1 2 I 1 15 2 15
 12A02X12A01 12A03
 3TURN ON POWER 10 1S2 127 10
 00000
 4INST COVER ON NARR TV 5 1S2 I 1 5
 03B12X03B13X03B14X
 3REM T/C SHIELD CORNERS 25 2S2 1 2 R 2 12 1 13
 14A07X14A08X14A09X14A10X14A11X14A12X14A13X14A45 14A46 14A47
 4REM T/C SHIELD SPACERS 2 2S2 1 2 1 3R 1 1 2 1
 01A02
 5REM LTB/CHANL LOW BAYS 9 2S2 1 2 R 2 4 1 5
 14A04X14A19X14A20X14A21X14A22X14A23X14A24X
 6TEST S/C 2 1S2 127 2
 00000
 7INST AL FOIL COV ON IRR 10 1S2 I 1 10
 03B06X03B07X
 8REM CANOPUS CAD SUL LIGH 2 1S2 1 R 2 1 1 1
 14A53X
 9REM UP THERM SHIELD BLAN 4 3S2 1 2 5 R 2 2 1 2
 14A01X02A 02B 02C
 9EXPOSED ZONES M
 01A00E01800E05A00E05B00E05C00E06A00E06B00E06C00E06D00E07A00E07B00E07C00E08A00E
 9EXPOSED ZONES M
 08B00E08C00E09A00E09B00E09C00E10A00E10B00E10C00E11A00E11B00E11C00E12A00E12B00E
 9EXPOSED ZONES M
 12C00E13A00E15A00E
 10REM SCAN PLAT T/C BLANK 2 2S2 1 2 5 R 2 1 1 1
 14A03X03A 03B 15A04 01A02 15B00E
 11REM ATTACH ANG5 4 2S2 1 2 6 R 2 2 1 2
 14A25X14A26X14A27X14A28X14A29X14A30X14A31X14A32X
 12REM SHIELD CANOPUS BAFFL 3 1S2 1 R 2 1 1 2
 13B10X13B08 13B09 13B11
 13REM SHIELD S/P HINGES 7 2S2 1 2 R 2 3 1 4
 14A49 14A50 14A51 14A52
 14INST MONO TEL RAD COVER 3 1S2 1 2 I 1 2 2 1
 03B19 03B17X03B18X03B 03A
 15REM CANOPUS SEN ASSY 4 2S2 1 2 R 2 2 1 2
 13B08X13B09X13B11
 16REM CASE 8 LOUV RESTRANT 2 2S2 1 2 R 2 1 1 1
 12A01 12A02 12A03
 17COVER PRIM SS WITH PLAST 4 1S2 I 1 4
 14A04 14A05
 18REM TC EQUIP 2 2S2 1 2 5 6 R 2 1 1 1
 14A55X14A56X14A57X14A58X
 19REM UP CHANNEL 25 2S2 1 2 R 2 12 1 13

14A14X14A15X14A16X14A17X									
20REM LOUV BRACKET	4	1S2	1	2		R 2	2	1	2
14A54X									
21INST SS PLASTIC BAGS	2	1S2			1	17I	1	2	
13B01X13B02X									
22REM CASE 6 LOUV	2	2S2	1	2		R 2	1	1	1
10A01X10A02 10A03 10A04 10A05									
23INST PAS PIN	2	1S2	11			I 1	1	2	1
01B06X									
24REM CASE 6	2	2S2	1	2	5	1	22R	2	1
10A00W10B00W10C00W									
25REM BAFFLE FROM CANOPUS	2	2S2	1	2		1	15R	2	1
14A48X13B08									
26INST BAFFLE IN CARRY CAS	2	1S2				1	25I	27	2
00000									
27REM BAFFLE TO DIVISION	20	1S2				1	26R	26	20
00000									
28REM S/P STUBBY HEATERS	2	2S2	1	2		R 2	1	1	1
01A01									
29INST OSE A/C FRAMES	10	3S2	1	2	4	6	I 1	3	2
13A01X13A06X									
30REM CABLES TO END BELL	10	1S2					R27	10	
00000									
31INST PROTECT COVERS/A/C	1	1S2					I 1	1	
13A02 13A10									
32INST RADIO HARDLN COAX	5	2S2	1	2	5		I 1	3	2
10C02X10C03X10C04X									
33CAP ANTENNA INTERFACE	4	1S2					I 1	4	
10C02X10C03X10C04X									
34INST IN PLASTIC BAGS	4	1S2				1	33I	1	4
10C02X10C03X10C04X									
35SEC TO BUS WITH STRING	5	1S2					T27	5	
00000									
36INST SUPPORT RACK /A/C	15	3S2	1	2	4	6	1	29I	1
13A01X13A09X									
37INSP PROP PYRO WIRE HARN	45	S2					T 9	45	
00000									
38REM STUBBY HEATERS	10	1S2	1	2			1	28R	2
13A01X13A09X									
39INST OSE FRAMES/A/C	45	3S2	1	2	4	6	1	29I	1
13A01X13A09X									
40CHECK S/C	17	S2					T 9	17	
00000									
41INST BRACK AROUND BELLOW	10	2S2	1	2			1	40I	1
13A02X13A10X									
42INST S/C LIFT BRACKETS	1	2S2	4	6			I15	1	
01A02									
43INST SCAN PLAT LNH POSIT	2	2S2					I 1	2	
03A 03B									
44INST RED COVER ON UVS	5	1S2					I 1	5	
03B08X									
45REM BLACK COVER FOR TEST	3	1S2					R 1	3	
03B08X									
46PREP TO MOVE S/C	66	3S2					T16	66	
01A01									
47PREP TO BRING IN TRANS	4	S2					T27	4	
00000									
48PREP CLAM SHELL	4	S2					T27	4	
00000									
49MONITOR BATT	33	S2					T27	33	
00000									
50REM PLAT SHIELD	10	S2					R27	10	

00000				
51PREP TO RAISE END BELL	5 S2	1 30T27	5	
00000				
52PREP END BELL	5 S2	1 51T27	5	
00000				
53ROLL END BELL TO CRANE	3 S2	1 52T27	3	
00000				
54REM GAS SYS HEAT/SCAN	10 2S2 1 2	R 2	5 1	5
03A 03B				
55INST GAS SYS COVER	5 2S2 1 2	1 54I 1	3 2	2
03A				
56INST LIFT SLING TO S/C	5 4S2	I16	5	
01A01				
57REM TIE BOLTS	2 3S2 2	R 2	116	1
00000				
58LIFT S/C	2 4S2	1 56T 3	2	
01A01				
59LIFT S/C	4 4S2	1 58T 3	4	
01A01				
60REM END BELL TO CHAMBER	4 4S2	1 53R27	4	
00000				
61SEC TRANS UNDER S/C	3 4S2	1 42T15	3	
00000				
62OPEN CAN	2 4S2	1 R27	2	
00000				
63INST S/C ONTO TRANS	35 4S2	1 61I 3	35	
01A24X01A02				
64INST HOLD DOWN CLAMPS	35 4S2	1 63I 1	35	
01A24X01A02				
65COMPLETE TENSION	1 1S2	1 64T10	1	
01A24X01A02				
66REM SLING	2 1S2	1 56R27	2	
00000				
67INST PURGE LNS CAN	2 1S2	1 62I27	2	
00000				
68CLOSE CAN	2 4N2	1 67I29	2	
00000				
67INST BASE CIRCLE BOLTS	2 2N2 5	I 1	1 2	1
00000				
68SET UP PURGE TEST	1 1N2	1 67T27	1	
00000				
69SEC TRANSPORTER	10 4N2	T15	10	
00000				
70REMOVE SLING FROM CRANE	15 4N2	R27	15	
00000				
71REM HYRASET FROM CRANE	15 3N2	R27	15	
00000				
71REM MISC ITEMS	12 3N2	R27	12	
00000				
72INST TRANS TO FORKLIFT	23 3N5	I21	23	
00000				
73ARRIVED IN SAF	30 3N5	T21	30	
00000				
74SEC S/C ON TRANS	120 3N2	T27	120	
00000				
75PREP TO REM S/C	15 3N2	1 74T27	15	
00000				
76INST ON LOW POSITIONER	15 3N2	1 75I27	15	
00000				
77REM TENT FROM LOW POSIT	15 3N2	R27	15	
00000				
78REM CAN FROM TRANS	10 3N2	1 68R27	10	

00000				
79REM CAN	2 4H2	1 78R 3	2	
01A01				
80STORE CAN	3 3H2	1 79T15	3	
00000				
81INST HYDOSET ON CRANE	2 3H2	1 71I25	2	
00000				
82INST SLING ON CRANE	3 3H2	I25	3	
00000				
83INST SLING ON S/C	10 3H2	1 82I16	10	
01A01				
84LIFT S/C	2 4H2	1 83 16	2	
01A01				
85SEC ON LOW POSITIONER	3 4H2	T 3	116	2
01A01				
86BOLT S/C ON LOW POSITION	5 4H2 5 6	1 85I 1	2 2	3
01A01				
87PULL TENT OVER S/C	5 4T2	1 86I27	5	
00000				
88TORQUE BOLTS	10 2T2 5	1 86I 1	5 2	5
00000				
89REL LOUVER FROM QABS	3 1T2	T25	3	
00000				
90REM THERMO	3 3T2 1 5	R 2	1 1	2
05AC3X07AD4X08AC2X09AD3X10AC2X11AD4X12AD3X				
90INSTALL PARTS	T	I		
07AD0W11AD0W12AC0W				
91REM THERMO PROPULSION	3 3T2 1 5	R 2	1 1	2
06AD1XC6AD2XC6AD3XC6AD4XD6AD5X				
92REM BATT	3 2T2 1 2	R 2	2 1	1
12B06X12B 12AD1 12C				
93SEC BATT IN BS	3 2T2 1 2	T26	3	
12B06X12B 12AD1 12C				
94CHANGE S/C POSITION	35 1T2	T16	35	
00000				
95REM WIDE ANG TV CAMERA	1 2T2 1 2	R26	1	
03B10X03B11X				
96REM HALF LOUVER	2 1T2 1 2	1 89R 2	1 1	1
03AD2X03AD1 03B				
97REM PROTECT COVER	2 1T2 1 2	R 2	1 1	1
03AD2X03AD1 03B				
98REM THERMOCOUPLES	1 1T2 1	1 97R 2	1	
03B21X03B22X				
99INST HALF LOUVER	2 1T2 1 2	1 96I 1	1 2	1
03AD2X03AD1 03B				
01INST PROTECT COVER	2 1T2 1 2	1 97I 1	1 2	1
03AD2X03AD1 03B				
02LOW SCAN PLAT	5 1T2	R27	5	
00000				
03INST SUPP BRACKETS	3 2T2 1 2	I 1	1 2	2
03AD1 03B				
04REM SCAN PLAT HEAT	2 2T2 1 2	R 2	1 1	1
11C04X03AD1 03B				
05SEC IN TENT	378 T2	1 A4T17	378	
00000				
06REM THERMOCOUPLES	15 2T2 1	1 98R 2	7 1	8
03B07X03B13X03B14XC3B18X03B19X03B21X03B22X				
07REM HEAT SUPP BRACKETS	7 1T2 1 2	1 A3R 2	3 1	4
03AD1 03B				
08REM TEST SYS EXHAUST	8 2T2	R27	8	
00000				

TASK 02 DAY 124 10/19/68

1REM GAS HEATERS	56 2T2 1 2	R 2	28 1	28	
13A01X13A09					
2REM THERMO SUPP RING	56 3T2	1 A6R27	56		
00000					
3REM CASE 1 THERMO SHIELD	2 2T2 1 2	R 2	1 1	1	
14A34X					
4PREP TO REM PROPUL SYS	2 2T2 1 2	T 2	1 1	1	
00000					
5REM TC CENT SUPP	3 2T2 1 2	R 2	1 1	126	1
14A33X					
6REM LOW TCB SPRINGS	2 2T2 1 2	R 2	126	1	
14A35X					
7REM CASE 4 ANG ATTACH	2 2T2 1 2	R 2	1	126	1
14A37X					
8REM LOUVER PROTECT COVER	4 1T2 1 2	1 A1R 2	2 1	2	
12A02X					
9OPEN CASE 8	4 1T2 1 2	R 2	2 1	2	
12A01 12B 12A02X12C					
10PREP TO REM BATT	3 1T2 1 2	1 93R 2	2 1	1	
00000					
11REM PROPULSION SYS ASSY	15 3T2 1 2 4 6 2	4R 2	5 1	5 5	5
06A00W06BC0W06C0C0W06D00W					
12REM BATT	3 2T2 1 2	2 10R 2	1 1	126	1
12R06X12A 12B 12C					
13INST PARTIAL CASESCREW	9 1T2 1 2	I 1	5 2	4	
12A01X					
14REM CASE 3 LOUVER	10 2T2 1 2	R 2	4 1	3 5	3
07A02X07A01					
15FIT/REM CHANL UP CASE 3	1 1T2 1 2	2 14X26	1		
14A15X07A01					
16FIT/REM CASE 3 ANG ATTACH	1 1T2	2 15X26	1		
14A26X07A01					
17REM S/P CRUISE DAMPS	8 2T2	R 1	3 2	326	2
04B03X					
18FIT/REM CASE 7 ANG ATTACH	1 1T2	X26	1 1		
14A28X11A01					
19FIT/REM CHANL UP CASE 7	1 1T2 1 2	X26	1		
14A17X11A01					
20REM THERMO	27 2T2	1 A6R 2	14 1	13	
03B07X03B13X03B14X03B18X03B19X03B21X03B22X					
21REM CASE 7 LOUVER	2 2T2 1 2	R 2	1 1	1	
11A02X11A01					
22FIT/REM SHLD CORN STRUT	3 1T2 1 2	R 2	1 1	126	1
14A39X					
23REM CC+S ATT CONT SHEAR	10 2T2 1 2	2	4 1	426	2
07A03X07A01					
24REM S/P SUPP DEPLOYMENTS	10 2T2 1 2	F 2	4 1	426	2
04B01X01A02					
25REM SHEAR PLATE SCI EQUIP	55 2T2 1 2	R 1	25 2	2526	5
11A03X11A01					
26REM CASE 7	25 2T2 1 2 5	2 21R	10 1	10 5	326 2
12A 12B 12C					
27REM TAPE	34 2T2	R 1	17 6	17	
13B01X13B02X13B03X13B04X13B05X13B06X13B07X03B01X03B02X03B03X					
28REM GYRO CONT	3 T2	R 1	1 1	126	1
07B06X07B 07C 07A05 07A01					
29REM TV MODS	10 T2	R 2	4 1	426	2
11B05X11B06X11B07X11B08X11B01 11B02 11B03 11B04 11A 11C					
30SEC CASE 7 IN GAS	2 T2 1 2	2 26T	126	1	
11A 11C 11B01 11B02 11B03 11B04					
31REM CASE 3	2 T2 1 2	2 9R	126	1	
07A 07B 07C					

32REM HARDWARE FROM CASE 3	1 2T2 1 2	R 2	1			
07A05X07A01 07B 07C						
33REM TCFM INTER CONN HARN	3 2T2 1 212	R 2	1 1	111	1	
05C03X05C 05B						
34REM CC+S MODS	2 2T2 1 2 5	R 2	126	1		
07B01X07B02X07B03X07B04X07B05 07C 07A01						
35FIT/REM CHAN CP CASE11	1 2T2 1 2	R 2	1			
14A14 05A01						
36REM ATT CONT	1 1T2 1 2 5	R	1			
07B05X07C 07A01						
37INST SUN GATE CLAMP	1 1T212	I14	1			
13B07X						
38REM LOUVER CASE 1	1 1T2	R 2	1			
05A02X05A01						
39REM TCFM MODS	16 2T2 1 2 5	R 2	6 1	626	4	
05B08X05B09X05B 05C 05A01						
40REM IR SPECT GAS ASSY	12 2T2 1 2 5	R 2	4 1	426	4	
03B15X03B 03A01						
41REM IR SPECT VENT ASSY	10 2T2 1 2 5	R 2	4 1	426	2	
03B17X03B 03A01						
42REM CASE 3 HARN	25 2T2 1 212	R 2	7 1	611	626	6
07C02X07C03X						
43WRAP IN PLASTIC COVER	25 1T2	2 42I26	25			
07A01X07C01X						
44SEC CASE 3 IN GAS	10 1T2	T26	10			
00000						
45CAP IRS GAS ASSY LINES	1 1T2	I27	1			
00000						
46CAP MONO TEL LINES	1 1T2	I27	1			
00000						
47CAP IRS VENT ASSY LINES	2 1T2	I27	2			
00000						
48REPLACE RADIATOR SCREWS	4 2T2 1 2	R 1	2 2	2		
00000						
49FILE CLAMP ON IRS LN	12 1T2	I 4	627	6		
00000						
50SEC SCAN PLAT	28 3T2	1 A3T 1	28			
01A19X01A20X01B01X03A01X033 X15A04 01A02						
51MOD MONO TELE EXHAUST LN	6 2T2	T27	6			
00000						
52INST IN PLASTIC BAG	6 2T2	2 51I27	6			
00000						
53PREPTO REM NARR ANG TV	8 2T2	T27	8			
00000						
54MOD MONO TELE CLAMP	12 2T2	2 51T27	12			
00000						
55PEM NARR ANG TV CAMERA	30 T2	2 53R 2	15 1	15		
03B12X03A01 03B 15A04 01A02						
56SEC IN TENT	356 T2	2 55T17	856			
00000						
TASK 03 DAY 125 10/20/68						
1SEC IN TENT	1440 T2	2 56T17	1440			
00000						
TASK 04 DAY 126 10/21/68						
1VERIFY SCREWS IN CASE 4	51 1T2 5	T 1	26 2	25		
08A01						
2FIT/REM CHANL LOW CASE 4	16 1T2 1 2	R 2	8 1	8		
14A21X08A01						
3OPEN CASE 4	25 2T2 1 2	T 1	13 2	12		
08A01X						

REP	STANDOFF	SUPP	CAB	HN	20	1T2	1	2	5	4	3R	1	6	2	611	8
08C01X08C02X088	08A01				25	2T2	1	2		4	4I	1	13	2	12	
5INST EXT SCREWS PARTIAL																
08A01					13	3T2				4	5T27		13			
6TAKING MICRO SWABS																
00000					15	1T2	1	2		4	2I	1	8	2	7	
7INST CHANNEL LOW CASE 4																
14A21X08A01					7	1T2	5			4	5I	1	3	2	4	
6TORQUE CASE SCREWS																
08A01					10	3T2	1	2	512		R	2	2	1	311	214
7REM S/P PIN PULL HARNS					04801	04802										
04804X04805X04806X04807X04808					20	2H2				4	7I	1	20			
8PREP TO INST S/P HARNS																
04804X04805X04806X04807X					3	1H2					T25		3			
9PEL S/P BOOST DAMPS																
00000					95	4H2	1	2	5	4	8I	1	32	2	3214	31
10INST S/P PIN PULL HARNS					04804X04805X04806X04807X04808	04801X04802X04803X										
04804X04805X04806X04807X04808					15	2H2	1	212		4	10I	1	4	2	411	414
11MATE P/P HARN TO BD A																
04804X04802X04801 04801X04803					15	2H2	1	212		4	10I	1	4	2	411	414
12MATE P/P HARN TO BD B																
04805X04802X04802X04801 04803					16	2H2	1	212		4	10I	1	4	2	411	414
13MATE P/P HARN TO BD C																
04806X04803X04802X04801 04803					16	2H2	1	212		4	10I	1	4	2	411	414
14MATE P/P HARN TO BD D																
04807X04804X04802X04801 04803					1	1H2				1	11I	9	1			
15INSP BELLOWS LEG G																
00000					4	3T2				4	12I	1	2	5	2	
16INST S/P +Y IN HAND FRAM																
04804X04807X					4	3T2				4	14I	1	2	5	2	
17INST S/P -Y IN HAND FRAM																
04806X04803X					5	2H2	1	2	512	4	10I	1	1	2	111	114
18PEROUT P/P HARN A																
04804X04802 04801X					5	2H2	1	2								

32INST CASE 1 MODS	100	2T2 1 2 5	2 34I 1	50 2	50	
C5B X05A01 05C						
33INST CASE 7 MODS	10	2T2 1 2 5	2 29I 1	5 2	5	
11B X11A01 11C						
34INST TCFM INTER CONN HN	5	2T2	2 33I 1	311	2	
05C03X05C 05B 05A01						
35INST TCFMS CABLE	10	2T2	4 31I 1	511	5	
05C03X05C 05B 05A01						
36INST NUT ASSY ON PLAT	25	1T2 2		1 13 2	12	
03A01X						
37INST ACCELEROMETER	30	1T2 1 2 5	4 36I 1	15 2	15	
03B20X						
38INST CASE I LOUVER	10	2T2 1 2	2 6I 1	5 2	5	
05A02X05A01X						
39INST A/C CC+S CHASSIS	5	2T2 1 2	2 32I 1	3 2	2	
C7A05X07A01X07C						
40INST CASE I LOUVER COVER	10	2T2 1 2	4 38I 1	5 2	5	
05A02X05A01						
41INST GYRO CONT	5	2T2 1 2 5	2 28I 1	3 2	2	
07B06X07C 07A01 07A05						
42INST SCI EQUIP CHASSIS	15	2T2 1 2 5	2 26I 1	8 2	7	
11A01X						
43INST A/C CC+S SHEAR PLT	5	2T2 1 2 5	4 39I 1	3 2	2	
07A03X07A01X						
44INST EAGLE SHIELD	5	2T2 1 2 5	I 1	3 2	2	
07A02X07A03X						
45INST CASE 3 HARDWARE	20	T2 1 2 5	I 1	10 2	10	
C1B01X07B02X07B03X07B04X07B05X07C						
07A05 07A02 07A01						
46SEC IN TENT	435	T2	4 45T17	435		
00000						
TASK 05 DAY 127 10/22/68						
1COMPLETE GEN TASKS	135	2T2	4 46T27	135		
00000						
2TILT S/C TO HORIZTAL POS	1	2T2	T16	1		
00000						
3REM A/C GAS EXHAUST LNS	2	2T2 4 6	4 23R 2	1 1	1	
13A02X13A10X						
4ATTACH CASE 3 4 7 CONNS	57	3T2	I11	57		
07C01X07C02X07C03X07B 07A	08C01X08C02X08B		11C00W11B	11A	15A01	
5REL SCAN PLAT PYRO VALVE	3	1T2	T25	3		
6REM SCAN PLAT PYRO PTM	27	2T2	R27	27		
00000						
7REL SCAN PLAT MAN ASSY	5	2T2	T25	5		
00000						
8REM SCAN PLAT MAN ASSY	5	2T2 1 2	R 2	3 1	2	
03B23X03B 03A01						
9INST SCAN PLAT MAN ASSY	2	2T2 1 2	5 7I 1	1 2	1	
03B23X03B 03A01						
10INST SCAN PLAT PYRO VALV	3	1T2 1 2	5 5I 1	2 2	1	
01B08X03B 03A01						
11INST DUMMY SGUIB	2	1T2 1 2	5 10I 1	1 2	1	
03B24X03B25 13B 03A01						
12INST BATT	20	2T2 1 2 5	2 12I 1	10 2	10	
12B06X12A01 12B 12C						
13CLOSE CASE 8	3	2T2 1 2 5	2 9I 1	2 2	1	
12A01						
14INST CASE HARDWARE	17	2T2 1 2 5	I 1	9 2	8	
11B00W11A01 1C						
15INST CASE HEAT	10	2T2 1 2 5	2 25I 1	5 2	5	
11C04X11C						
16TORQUE IN 8 NUTS	8	1T2 5	I 1	4 2	4	

[illegible]

25TORQ DAMPS	50 2T2 5	6 24R 2	25 1	25
04802X04803X04A 04B				
26INST S/P SCREWS	55 2T2 5	6 25I 1	28 2	27
04A00W04800W				
27INST PYRO CABLE CLAMPS	75 2T2 1 2T2	I 1	25 2	2514 25
15802X15A05X15A06X				
28INST CABLE CLAMPS CN S/P	30 2T2 1 2	6 27I 1	10 2	1014 10
15802X15A05X15A06X04804X04805X04806X04807X15A01				
29MATE NARR ANG TV CAMERA	15 2T2	6	111	15
03812X03B 03A 05C04				
30SEC IN TENT	500 12	6 29T17	500	
00000				

TASK 07 DAY 129 10/24/68

1REM WIDE ANG TV CAMERA	70 2H2 1 2 5	6 21R 2	35 1	35
03810X03B11X03B 03A01 15A04 01A02				
2PREP FOR C+G IN PROGRESS	10 2H2	6 18T27	10	
00000				
3WARM-UP ELECT FORCE IND	60 1H2	T27	60	
00000				
4INST LIFT FIX TO PROP SY	10 2H2	7 3I 5	10	
06A 06B 06C 06D				
5PREP TO RAISE BY CRANE	15 1H2	7 4T27	15	
00000				
6MOUNT PROP SYS ON CIG	15 1H2	7 5I 3	15	
00000				
7INST C/G FIXTURE TO PROP	13 2H2 5	I 1	4 2	4 3 5
06A 06B 06C 06D				
8MOVE PROP SYS OVER C/G	11 H2	7 6I 3	11	
00000				
9LOWER PROP SYS INTO POS	10 H2	7 8T 3	10	
00000				
10TURN 120 FOR POSIT NUM 2	11 H2	7 9T 3	11	
00000				
11TURN 240 FOR POSIT NUM 3	10 H2	7 10T 3	10	
00000				
12REM PROP SYS	15 2T2	7 6R 3	15	
00000				
13REM HORIZ CUPS	15 2T2	7 12R27	15	
00000				
14SET UP TEST X COORDINATE	10 2T2	T27	10	
00000				
15INST LIFT FIXTURE	2 2T2	I27	2	
00000				
16MOVE PROP SYS TO CG FIX	2 2T2	7 12T 3	2	
00000				
17LOW PROP SYS TO POSIT 1	1 2T2	7 16T 3	1	
00000				
18MOVE 120 FOR POSIT NUM 2	10 2T2	7 17T 3	10	
00000				
19ZERO OUT FORCE INDICATOR	10 2T2	T27	10	
00000				
20TURN 240 FOR POSIT NUM 3	5 2T2	7 18T 3	5	
00000				
21INST LIFT FIXTURE	2 2T2	T27	2	
00000				
22LIFT PROP SYS OFF CG FIX	3 2T2	7 17T 3	3	
00000				
23REM HORIZ CUPS	5 2T2	7 22R27	5	
00000				
24INST PROP SYS IN FRAME	5 2T2	7 22I 3	2 5	3
06A 06B 06C 06D				

25INST NONFLIGHT ITEMS	2 2T2	I27	2		
00000					
26INST MT PROP SYS IN CONT	2 2T2	7 21I 5	2		
00000					
27INST MAG SHIELDS	6 2T2 1 2 5	7 1I 1	3 2	3	
03B10X03B 03A					
28INST WIDE ANG TV CAMERA	10 2T2 1 2 5	7 27I 1	5 2	5	
03B10X03B 03A					
29INST SCAN LATCH	3 2T2	I 1	2 2	1	
01B01X					
30CHANGE S/C POSIT	4 2T2	7 20T16	4		
00000					
31LATCH SCAN PLAT	48 3T2	7 29I 1	48		
01B01X01A20 01A19 03A01 03B					
32CHARGE LATCHES	2 2T2	7 31T27	2		
00000					
33REPLACE COVER	3 2T2	7 31I27	3		
00000					
34INST TV CABLE TIES	5 2T2	I14	5		
03B10X					
35WIRE SCAN PLAT	20 1T2 1 2	7 33I 1	7 2	714	6
01B09X03A01 03B					
36CHANGE S/C POSIT	30 1T2	7 30T16	30		
00000					
37CHECK CONN	10 1T210	T10	10		
10C01X10C					
38SEC RADIO CABLE	5 2T2 1 2 5	T 1	2 2	214	1
10C01X10C 10B 10A01					
39VERIFY ELECT CONN	5 1T2	7 38T27	5		
00000					
40SEC CABLE WITH TIES	15 2T212	7 34T 1	5 2	514	5
10C01X10C 10B 10A01					
41INST HIGH GAIN COAX CAB	10 2T2 1 2 5	I 1	5 2	5	
02C04X02C 10C					
42INST LOW GAIN COAX CAB	10 2T2 1 2 5	I 1	5 2	5	
02A02X02A 10C					
43INST HARDWARE	35 2T2 1 2 5	I 1	18 2	17	
02C03X02C 01A01					
44REM HIGH GAIN BULLETS	15 2T2	7 41R 1	15		
02C04X02C 02A02X02A					
45PREP FOR HIGH GAIN STAND	70 2T2 1 2	T 1	35 2	35	
02C04X					
46INST HARDWARE CASE 7	20 2T2 1 2 5	I 1	10 2	10	
11B00W11A01 11C					
47REM HARDWARE CASE 2	7 2T2 1 2	R 2	4 1	3	
06D04X06D05X06D06X06D07X					
48INST FLIGHT SCREWS	8 2T2 1 2 5	I 1	4 2	4	
06D00W					
49CHANGE S/C POSIT	35 1T2	7 36T16	35		
00000					
50REPLACE HARDWARE	10 2T2 1 2 5	7 48I 1	5 2	5	
06D04X06D05X06D06X06D07X					
51REM GAS LN FRAME	15 2T2 1 2	5 19R 2	5 1	515	5
13A01X13A09X					
52INST S/P 7	7 4T2 1 2 5	6 4I 1	3 2	4	
04A04X04B07X04B08 04B01 04B02 04B03 01A01					
53INST GAS LN ON S/P	8 2T2 1 2	7 51I 1	3 2	314	2
04A04X04B07X04B08 04B01 04B02 04B03 13A01 13A09					
54INST SHIELD S/P HINGES	15 1T2 1 2 5	I 1	7 2	8	
01A08X					
55TORQUE GAS LN SCREWS	10 1T2 5	7 53I 1	5 2	5	
04A04X04B07X04B08X04B01 04B02 04B03 01A08 01A12					

56REM GAS LN FFRAME CASE 1	20	T2 1 2 4 6	R 2	7 1	715	6
13A01X13A09X01A01						
57INST S/P 1	5	4T2 1 2 5	6 4I 1	3 2	2	
04A01X04B04X04B08X04B01 04B02	04B03	01A05	01A09	01A01		
58INST S/P PIN PULLERS	5	2T2 1 2	7 57I 1	3 2	2	
04B08X						
59INST CABLE CLAMPS	60	2T2 1 2 5	7 57I 1	20 2	2014	20
04A01X04B04X04B08X04B01 04B02	04B03	01A05	01A09	01A01		
60MATE PIN PULLER	15	2T2	7 58I11	15		
04B08X04B04X						
61INST CLAMPS ON S/PS	25	1T2 1 2 5	7 57I 1	8 2	811	9
15A01X04B04X04B05X04B06X04B07X						
62CHANGE S/C POSIT	15	1T2	7 49T16	15		
00000						
63INST CASE 2 HARDWARE	15	2T2 1 2 5	I 1	7 2	8	
01A13X01A14X01A15X01A16X01A17X01A18X						
64INST DEPLOY MECHS	15	3T2 1 2 5	I 1	8 2	7	
04B01X01B03X04A01 04A04 04B02 04B03						
65INST MICRSWTCH	7	1T2 1 2	I 1	3 2	4	
04B09X04A01						
66INST ACUATOR BRACKET	8	2T2 1 2	I 1	4 2	4	
04B10X04A01						
67INST MICRSWTCH	2	1T2 1 2	I 1	1 2	1	
04B09X04A04						
68INST ACUATOR BRACKET	3	2T2 1 2	I 1	2 2	1	
04B11X04A04						
69SEC IN TENT	480	T2	7 68T17	480		
00000						
TASK 08 DAY 130 10/25/68						
1SEC IN TENT	50	T2	7 69T17	50		
2MATE MONO TELE	7	2T2 1 2	54I 1	2 2	211	3
03B16X05C04X05C01X						
3INST CASE 3 ANG ATTACH	8	2T2 1 2 5	2 18I 1	4 2	4	
14A26X07A01						
4INST UP CHANNEL	16	2T2 1 2 5	I 1	8 2	8	
14A15X07A01						
5INST SCAN BLANKET	2	3T2 1 2 5	I 1	1 2	1	
14A03X03A01 03B 14A03015B000						
6INST UP CHANNEL	2	2T2 1 2 5	I 1	1 2	1	
14A14X05A01X14A17X11A01						
7INST HL STRUT BLANK	45	2T2 1 2 5	I 1	23 2	22	
14A43X						
8INST PROP TC	25	2T2 1 2 5	I 1	13 2	12	
06D03X						
9REM THERM SHIELD	15	2T2 1 2 5	8 6R 2	7 1	8	
14A03X03A01 03A02 03B 14A03E15B00E						
10REP MOTION SEN HARD	30	2T2 1 2	R 2	15 1	15	
04B01X04A 04B						
11INST THERM SHIELD	130	3T2 1 2 5	8 9I 1	65 2	65	
14A03X03A01 03A02 03B 14A03015B000						
12REM THERM SHIELD	60	3T2 1 2 5	8 11R 2	30 1	30	
14A03X03A01 03A02 03B 14A03E15B00E						
13INST TC RING	4	2T2 1 2 5	8 12 1	2 2	2	
14A33X03A01 03B						
14INST TC SPRINGS	4	2T2 1 2 5	8 13I 1	2 2	2	
14A35X03A01 03B						
15INST TC CLAMPS	4	2T2 1 2 5	8 13I 1	2 2	2	
14A36X03A01 03B						
16PRESS SCAN PLAT	17	1T2	7 35T10	17		
00000						
17TORQUE SCAN LATCH CAP	3	1T2	8 16I10	3		

00000					
18WIRE SAFETY CAP	8	1T2	8	17I10	8
00000					
19PREP TO REM CASE 7	45	2T2		T27	45
00000					
20REM LOUVER CASE 7	1	2T2 1 2	5	19R 2	1
11A02X11A01					
21REM S/P 7 CRUISE OAMP	1	2T2 1 2	2	17R 2	1
04B03X					
22REM CHANNEL UP CASE 7	1	2T2 1 2	2	15R 2	1
14A17X11A01					
23REM CASE 7 ANG ATTACH	30	2T2 1 2	2	18R 2	15 1 15
14A28X11A01					
24REM SHEAR PLATE SCI EQUP	15	2T2 1 2	2	24R 2	7 1 8
11A03X11A01					
25REM TV MODS	60	2T2 1 2 5	2	29R 2	30 1 30
11B05X11B06X11B07X11B08X11B	11C	11A01			
26INST TV MODS	75	2T2 1 2 5	8	25I 1	25 2 2511 25
11B05X11B06X11B07X11B08X11B	11C	11A01			
27INST CASE 7 SHEAR PLATE	150	2T2 1 2	8	24I 1	75 2 75
11A03X11A01					
28INST CANOPUS SEN ASSY	42	2T2 1 2 5	1	25I 1	21 2 21
13B08X13B09 13B10 13B11					
29MOVE TENT	2	4H2		T27	2
00000					
30PREP TO MOVE S/C	1	4H2	8	29T27	1
00000					
31MOVE S/C TO LOW LEVEL	17	4H2	8	30T 3	916 8
00000					
32INST S/C ON LOW LEVEL	10	4H2 4 6	8	31I 1	4 2 416 2
00000					
33REM S/C FROM LOW LEVEL	10	4H2	8	32R 3	516 5
00000					
34MOVE S/C TO ADAPTER	10	4H2	8	33T 3	516 5
00000					
35REM INSTRU COVERS	10	2H2		R 1	10
03B00W03A01					
36LOWER S/C TO ADAPTER	6	4H2	8	34T 3	316 3
01A01X01A23					
37REL V-BAND ASSY	1	1H2		T25	1
00000					
38COVER S/C WITH TENT	34	4T2	8	29T27	34
00000					
39PREP TO INST V-BAND	49	2T2	8	37T27	49
00000					
40INST V-BAND	30	2T2 1 210	8	39I 1	10 2 1010 10
01A24X01A23X01A01X					
41SET TENSION	1	1T2 5	8	40T10	1
00000					
42CLEAN UP	17	2T2		T27	17
00000					
43CHECK PAS PIN	5	1T2		T 9	5
00000					
42SEC IN TENT	387	T2	8	43T17	387
00000					
TASK 09 DAY 131 10/26/68					
1SEC IN TENT	50	1T2	8	44T17	50
00000					
2TURN ON POWER	23	1T2		T27	23
00000					
3TURN OFF POWER	16	1T2	9	2T27	16
00000					

4MATE STRAIN GAUGE CONN	5 2T210	I10 5		
01A23X				
5TURN ON POWER	277 T2	9 3T27 277		
00000				
6TURN OFF POWER	4 T2	9 5T27 4		
00000				
7SEC IN TENT	1065 T2	9 6T171065		
00000				
TASK 10 DAY 132 10/27/68				
1SEC IN TENT	1440 T2	9 7T171440		
00000				
TASK 11 DAY 133 10/28/68				
1SEC IN TENT	32 T2	10 1T17 32		
00000				
2TURN ON POWER	661 T2	8 6T27 661		
00000				
3TURN OFF POWER	99 T2	11 2T27 99		
00000				
4INST LOUVER COVERS	5 2T2 1 2	I 1 3 2 2		
05A02X07A03X08A02 09A02 11A02 10A01 12A02				
5REM V-BAND	1 2T2 4 6	8 40R 2 1		
01A24X01A23X01A01				
6INST V-BAND IN CONTAINER	4 2T2	11 5I26 4		
00000				
7PREP TO REM S/C	10 2T2	8 36T27 10		
00000				
8PEM S/C FROM ADAPT	12 4T2	11 7R 3 616 6		
00000				
9INST INST COVERS	6 1T2	8 35I 1 6		
03B00W03A01				
10INST SHORT PAS PING	2 1T212	I 1 1 2 1		
01B06X				
11LOWER S/C	5 H2	11 8T 3 316 2		
00000				
12PREP TO REM ADAPTER	10 2H2	17 8T27 10		
00000				
13INST ADAPT IN CONTAINER	3 4H2	11 12I 1 2 5 1		
01A23X				
14REM S/C TO TENT AREA	10 H2	11 11T 3 516 5		
00000				
15MOVE TENT OVER S/C	32 H2	11 14T 1 32		
00000				
16SEC IN TENT	548 T2	11 15T17 548		
00000				
TASK 12 DAY 134 10/29/68				
1PREP TO REM LOW THERM	12 T2	8 12T27 12		
00000				
2REM SCAN BLANK	4 3T2 1 2 5	12 1R 2 2 1 2		
14A03X03A 03B 14A02				
3REM THERM SHIELD	26 3T2 1 2 5	8 11R 2 13 1 13		
14A02X03A 03B				
4REM ACCEL SCAN PLAT	5 1T2 1 2	4 37R 2 3 1 2		
03B20X03A 03B				
5INST WASHER	5 1T2	12 4I 1 3 2 2		
03B20X03A 03B				
6INST ACCEL SCAN PLAT	1 2T2	12 4I 2 1		
03B20X03A 03B				
7REM CANOPUS SEN	48 2T2 1 2 5	8 28R 2 24 1 24		
13B08X13B09X13B10X13B11X				
8INST ACCELEROMETERS	45 2T2 1 2	12 6I 1 23 2 22		
01A22X01B07X01B08X03B20X15B05X15A08X				
9UNLATCH S/P -X	12 2T2 1 2	7 57R 2 6 1 6		

04801X04A03X					
10INST BAFFLE ON CANOPUS	33 2T2 1 2	12 7I 1	17 2	16	
13810X13808 14A48					
11LATCH S/P -X	5 2T2 1 2	12 9I 1	3 2	2	
04801X04A03X					
12INST CANOPUS SEN	35 T2	12 10I 1	18 2	17	
13810X13809X13808X13811X					
13CHECK ACCELEROMETERS	100 T2	12 8T27	100		
00000					
14BLEED SCAN PLAT	58 2T2	4 23T27	58		
00000					
15REM SCAN PLAT LOUV	62 2T2 1 2 5	R 2	31 1	31	
03A02X03A01 03B					
16INST SCAN PLAT LOUV	42 2T2 1 2 5	12 15I 1	21 2	21	
03A02X03A01 03B					
17VERIFY CABLES CONNECTED	3 1T2	T 9	3		
00000					
18PREP TO PRESS SCAN LATCH	10 2T2	8 17T27	10		
00000					
19SEC SCAN PLAT IN LAUNCH	5 3T2	12 16I 1	5		
03A 03B 03A20 01A19 01801 01A02					
20PRESS SCAN PLAT	15 2T2	12 18T27	15		
00000					
21WIRE FILL VALVE COVER	15 1T211	I 1	7 2	8	
03824X03825X03B 03A01					
22PREP TRANSPORTER	10 1T2	T27	10		
00000					
23MOVE THERM SHIELD SUPP	8 1T2	12 3T27	8		
14A34X14A35X14A36X03B 03A					
24INST THERM SHIELD	42 3T2 1 2 5	12 3I 1	21 2	21	
14A02X03A 03B 14A06X14A07X14A08X14A09X14A10X14A11X14A12X14A13X14A01X14A03X					
240CCLUDED ZONES		M			
01A000018000005A0000058000005C000006A0000068000006C000006D000007A000007B000007C000008A000					
240CCLUDED ZONES		M			
0880C0003C000009A0000098000009C00010A00010B00010C00011A00011800011C00012A000128000					
240CCLUDED ZONES		M			
12C0C013A00013800015A000158000					
25CHANGE S/C POSIT	30 T2	8 31T16	30		
00000					
26REM TCFM COVER	30 1T2	4 31R 1	30		
02801X02802X02A					
27PREP TO MOVE TENT	10 4T2	11 15T27	10		
00000					
28ATTACH SLING	2 4H2	8 30I 3	116	1	
00000					
29LIFT S/C	2 4H2	12 28T 3	116	1	
00000					
30MOVE S/C TO TRANSPORTER	3 4H2	12 29T 3	216	1	
00000					
31LOWER S/C TO ADAPTER	3 4H2	11 8T 3	216	1	
00000					
32PREP TO INST CLAMHELL	10 4H2	12 31T27	10		
00000					
33INST CLAMHELL	10 4H2	12 32T29	10		
01A01X					
34INST PURGE	10 N5	12 33T27	10		
00000					
35SEC IN HIGH BAY	729 N5	12 34T18	729		
00000					
TASK 13 DAY 135 10/30/68					
1PREP TO TRANSPORT S/C	90 N5	12 33T27	90		
00000					

2LEAVE SAF TO ETL	25 N5	13 1T21	25	
00000				
3ARRIVE AT ETL	5 N5	13 2T21	5	
00000				
4ASSEMBLE V-BAND	12 N5	11 6I27	12	
00000				
5REM ADAPT FROM CONTAINER	10 4V2	12 31R 1	10	
01A23X				
6INST V-BAND	22 2V2 4 6	13 4I 1	11 2	11
01A24X01A23X				
7OPEN CLAMSHELL	13 4V2 1 2	12 33R29	13	
01A01				
8REM S/C	13 4V2	13 7R 3	716	6
01A01				
9CALIBRATE 2 CABLES	23 2V210	13 6T10	23	
01A23X01A22X01A24 10C03 10C04				
10SEC PURGE	10 2V2	12 34R27	10	
00000				
11CLEAN INSIDE ADAPT STRUT	6 2V2	13 6C 6	6	
01A22X01A23X01A24X				
12MATE ADAPT STRUT TO S/C	1 2V2	13 11I16	1	
01A01X01A23X01A24X				
13REM PROTECT COVERS	10 1V2	11 9R 1	10	
03A 03B 14A03				
14LIFT S/C	13 4V2	13 8T16	13	
00000				
15SEC ADAPT TO S/C	65 2V2 4 6	I 1	33 2	32
01A22X01A23X01A24X01A01 02A	02B 02C			
16INST SCREW ON MONO TELE	8 2V2 1 2 5	I 1	4 2	4
03B16X03B15 03B17 03B18 03B19				
17REL CANOP SHLD AT ETL	30 1V2	T25	30	
00000				
18TORQUE S/C ADAPT	16 2V2 5	13 15I 1	8 2	8
01A22 01A23 01A24 01A01 02A	02B 02C			
19TORO V-BAND ASSY	24 2V2 5	13 6I10	24	
01A23X01A24X01A02				
20CK TENSION MON RACK /OSE	10 2V2	T27	10	
00000				
21ADJUST V-BAND ASSY	40 2V2 5	13 19T10	40	
01A23X01A24X01A02				
22INST AL TAPE OVER SEN	10 2V2	12 12I 1	10	
13B01X13B02X13B08X				
23INST SAFETY STRAP	1 2V2 1 2	13 19I 2	1	
01A24X01A23X				
24INST AL TAPE OVER SEN	8 2V2	I 1	8	
13B07X				
25CHANGE S/C POSIT	20 V2	13 14T16	20	
00000				
26LOWER ONTO CENTAUR ADAPT	5 4V2	13 25T 3	316	2
01A01 01A02 02A 02B 02C				
27CABLE S/C /OSE	5 2V2	13 26I27	5	
00000				
28TORQUE ADAPT BOLTS	9 1V2 5	13 26T 1	4 2	5
01A23X				
29CHARGE A/C SYST CONNS	9 2V2 4 6	12 11I27	9	
13A01X13A09X				
30TURN ON POWER	12 1V2	11 3T27	12	
00000				
31CHARGE A/C SYST CONNS	10 2V2 4 6	T27	10	
13A01X13A09X				
32CALIB ACCELEROMETERS	25 V2	12 8T10	25	
00000				

33INST THERM SHIELD	24 1V2 1 2	12 2I 1 12 2 12
14A48X13B08 13B09 13B10 13B11		
34INST V-BAND CABLES /CENT	1 2V2	13 21I27 1
00000		
35REM PAS/SIT PINS	1 2V211	R 2 1
01B05X01B06X		
36TURN OFF POWER	2 V2	13 30T27 2
00000		
37SEC IN VIBRATION	801 V2	13 36T24 801
38TURN ON POWER	51 V2	T27 51
00000		
TASK 14 DAY 136 10/31/68		
1TURN ON POWER	30 V2	13 38T27 30
00000		
2VERIFY ACCEL TORQUES	10 2V210	13 32T10 10
00000		
3REM LOUVER COVER	65 1T2 1 2	T 1 33 2 32
11A02X11A03X		
4RUN TEST 1	25 8T2	13 3T27 25
00000		
5INSP AFTER TEST	10 1T2	13 4T 9 5 6 5
01A23X		
6INSP AFTER TEST	7 1T2	10 4R 9 4 6 3
01A23X		
7CK OSE CABLES	6 1T2	I27 6
00000		
8RUN TEST 2A	9 8T2	14 5T27 9
00000		
9INST BLOWER	20 2T2 1 2	I 1 10 2 10
01A23X03A 03B 14A03 14A02		
10RUN TEST 2B	10 8T2	14 8T27 10
00000		
11INSP AFTER TEST	3 2T2	14 10T 6 2 9 1
01A23X		
12RUN TEST 2C	15 8T2	14 11T27 15
00000		
13INSP AFTER TEST	6 2T2	14 12T 6 3 9 3
01A23X		
14RUN TEST 2D	12 8T2	14 13T27 12
00000		
15REM ACCEL FROM CENTAUR	8 2T2 1 2	12 8R 1 4 2 4
00000		
16INST ACCEL /CENTAUR	1 2T2 1 2	14 15I 2 1
00000		
17INST V-BAND STRAP	3 2T2 4 610	13 23I10 3
01A23X01A24X		
18TURN OFF POWER	55 T2	14 1T27 55
00000		
19TURN ON POWER	15 T2	14 18T27 15
00000		
20REM V-BAND STRAP	10 T2 4 610	14 17R10 10
01A23X01A24X		
21REM V-BAND BLOWER	10 T2 4 610	14 9R10 10
01A23X01A24X		
22RUN TEST 3	20 8T2	14 14T27 20
00000		
23RUN TEST 3R	17 8T2	14 22T27 17
00000		
24RUN TEST 4	5 8T2	14 23T27 5
00000		
25COMP ALL RUNS Z AXIS	10 T2	14 24T27 10

00000								
26INST V-BAND STRAP	8	T2	4	610	14	20I10	8	
01A23X01A24X								
27TURN OFF POWER	12	T2			14	19T 1	12	
00000								
28PREP TO MOVE S/C	19	4T2				T27	10 2	9
00000								
29MOVE TENT	1	4T2				T 1	1	
00000								
30ATTACH CRANE CABLES	3	4V2			14	28I 3	216	1
01A01 02A 02B 02C								
31LIFT S/C	5	4V2			14	30T 3	316	2
01A01 02A 02B 02C								
32LOWER S/C TO SLIDER	5	4V2			14	31T 3	316	2
01A01 02A 02B 02C								
33INST S/C ON SLIDER	37	4V2			14	32I 3	2016	17
01A01 02A 02B 02C								
34SEC SLIDER BOLTS	1	2V2	5		14	33I 2	1	
01A02X01A23X								
35INST PLYWOOD FLOOR	4	V2				I27	4	
00000								
36COVER S/C WITH TENT	2	4T2			14	29I 1	2	
00000								
37INST CABLE /OSE	4	3T2				I27	4	
00000								
38TURN ON POWER	9	T2			14	27T27	9	
00000								
39INST ACCELEROMETERS/CENT	40	2T2			14	16I27	40	
00000								
40MATE ACCEL CONN /CENT	25	2T2			14	39I27	25	
00000								
41REM LOUVER COVERS	20	2T2	1 2		14	6R 2	10 1	10
05A02X07A03X07A02X08A02X09A02X10A01X12A02X								
42RUN TEST 5	26	8T2			14	25T27	26	
00000								
43RUN TEST 6A	5	8T2			14	42T27	5	
00000								
44RUN TEST 6B	23	8T2			14	43T27	23	
00000								
45INST V-BAND	2	2T2			13	19I 1	1 2	1
01A23X01A24X01A02								
46TURN OFF POWER	15	T2			14	38T27	15	
00000								
47PREP TO MOVE S/C	5	4V2				T27	5	
00000								
48INST LIFT FIXTURE	5	2V2	1 2		14	47I 1	3 2	2
01A02								
49UNBOLT ADAPT	5	2V2	4 6		14	47I 1	3 2	2
01A22X01A24X01A02								
50INST SLING	5	2V2			14	47I 3	316	2
01A01 02A 02B 02C								
51INST HOIST	5	2V2			14	47I 3	316	2
01A01 02A 02B 02C								
52LIFT S/C	5	4V2			14	48T 3	316	2
01A01 02A 02B 02C								
53ROTATE TO X-AXIS	8	4V2			14	52T 3	416	4
01A01 02A 02B 02C								
54LOWER S/C	8	4V2			14	52T 3	416	4
01A01 02A 02B 02C								
55REM SLING	8	4V2			14	50T 1	8	
01A01 02A 02B 02C								
56BOLT TO ADAPT	8	2V2	5		14	49T 2	4 1	4

01A23X01A24X01A02					
57REM LIFT FIXTURE	8	2V2 1 2	14	48T 2	4 1 4
01A02X					
58SEC IN TENT	722	T2	14	57T17	722
00000					
TASK 15 DAY 137 11/01/68					
1PREP FOR TEST 7A	10	T2	14	T27	10
00000					
2TURN ON POWER	10	T2	14	46T27	10
00000					
3REM V-BAND COVER	2	2T2 1 2	14	45R 2	1 1 1
01A23X01A24X					
4TORO LOUV	75	2T2 1 2	14	41R 2	38 1 37
05A02X07A03X07A02X08A02X09A02X10A01X12A02X					
5RUN TEST 7A	27	T2	15	1T27	27
00000					
6RUN TEST 7B	10	T2	15	5T27	10
00000					
7PREP TO REM CENTAUR	4	2T2	14	15T27	4
00000					
8INST V-BAND STRAP	1	2T2 1 2 5	15	3I 2	1
01A23X01A24					
9INST LOUVER COVERS	1	2T2 1 2 5	15	4I 2	1
05A02X07A03X07A02X08A02X09A02X10A01X12A02X					
10INST BAFFLE COVER	4	2T2 1 2	12	12I 1	2 2 2
13B10X13B09 13B08 13B11					
11TURN OFF POWER	7	T2	15	2T27	7
00000					
12INST LIFT BRACKETS	6	2T2 1 2	14	48I 1	3 2 3
01A02					
13REM ADAPT SCREWS	15	2T2 4 6	15	7R 2	8 1 7
01A23X01A24X01A01					
14MOVE TENT	12	4V2	14	29T 1	12
00000					
15LIFT S/C	10	4V2	15	14T 3	516 5
01A01X02A 02B 02C					
16COVER S/C WITH TENT	1	4T2	15	14T 1	1
00000					
17REM CENTAUR ADAPT	2	2T2	15	7R27	2
00000					
18PREP FOR X-AXIS RUNS	20	2T2	15	15T27	20
00000					
19SEC RING TO SLIDER	5	4T2	15	17I27	5
00000					
20PREP TO MOVE RING	5	4T2	15	19T27	5
00000					
21ATTACH CABLES TO S/C	10	4V2		I 3	516 5
01A01X02A 02B 02C					
22LOWER S/C	5	4V2	15	20T 3	316 2
01A01X02A 02B 02C					
23COVER S/C WITH TENT	20	4T2	15	16T27	20
00000					
24TURN ON POWER	15	T2	15	11T27	15
00000					
25RUN TEST 8	30	8T2	15	6T27	30
00000					
26INST S/C	30	T2	15	25T 6	15 9 15
01A23X					
27RUN TEST 9	2	8T2	15	26T27	2
00000					
28INS S/C	15	T2	15	27T 9	15
00000					

29PUN TEST 9R	3 8T2	15 28T27	3		
00000					
30INSP S/C	19 T2	15 29T 9	19		
00000					
31RUN TEST 9RR	16 8T2	15 30T27	8 9	8	
00000					
32INSP S/C	2 T2	15 31T 9	2		
00000					
33RUN TEST 10	2 8T2	15 32T27	2		
00000					
34INST V-BAND STRAP	2 2T2 1 2	15 8T 1	1 2	1	
01A22X01A23X01A24					
35INST LOUVER COVERS	1 2T2 1 2	15 9I 2	1		
05A02X07A03X07A02X08A02X09A02X10A01X12A02X					
36INST BAFFLE COVER	10 1T2	15 10I 1	10		
13B10X13B08 13B09 13B11					
37TURN OFF POWER	1 T2	15 24T27	1		
00000					
38INST LIFT BRACKETS	5 4T2 1 2	15 12I 1	3 2	2	
01A02					
39REM ADAPT BOLTS	10 4T2 4 6	15 13R 2	5 1	5	
01A22X01A23X01A24X01A02					
40REM TENT	15 4V2	15 16R 1	15		
00000					
41LIFT S/C	2 4V2	15 40T 3	116	1	
01A01 02A 02B 02C					
42REORIENT 6 IN RING	18 4V2	15 39T27	18		
00000					
43LOWER S/C	5 4V2	15 41T 3	316	2	
01A01 02A 02B 02C					
44INST BOLTS	15 4V2 5	15 39I 2	9 1	6	
01A22X01A23X01A24X01A02					
45COVER S/C WITH TENT	7 4T2	15 40I 1	7		
00000					
46INST ACCEL	8 2T2 1 2	14 39I 1	3 2	310	2
01B07X01B08X03B22X					
47TORQUE ADAPT	3 2T2 5	15 42I 2	2 1	1	
01A22X01A23X01A24X01A02					
48REM LOUVER COVERS	3 2T2 1 2	15 35R 2	2 1	1	
05A02X07A03X07A02X08A02X09A02X10A01X12A02X					
49INST ACCEL /OSE	1 2T2	15 46I27	1		
00000					
50REM SAFETY STRAP	4 2T2 1 2	15 34R 1	2 2	2	
01A24X01A23					
51INST SAFETY STRAP	4 2T2 1 2	15 50I 1	2 2	2	
01A24X01A23					
52CHECK ACCEL	1 T2	15 49I10	1		
00000					
51TURN ON POWER	1 T2	15 37T27	1		
00000					
52RUN TEST 11	43 8T2	15 33T27	43		
00000					
53RUN TEST 11R	15 8T2	15 52T27	15		
00000					
54RUN TEST 11RR	4 8T2	15 53T27	4		
00000					
55RUN TEST 11RRR	37 8T2	15 54T27	37		
00000					
56RUN TEST 12	4 8T2	15 55T27	4		
00000					
57INST V-BAND COVER	6 2T2 1 2	15 51I 1	3 2	3	
01A24X01A23					

58INST LOUVER COVERS	4 2T2 1 2	15 48I 1	2 2	2
05A02X07A03X07A02X08A02X09A02X10A01X12A02X				
59PREP TO BLOW V-BAND	55 2T2	T27	55	
00000				
60REL SQUIBS FROM GAS	15 1T2	T25	15	
00000				
61ADJUST PYRO LIGHTS	5 2T2	T27	5	
00000				
62TURN OFF POWER	2 T2	15 51T27	2	
00000				
63INST SQUIBS	27 2T2 1 2	15 60I 1	14 2	13
01B10X01A24 01A23				
64FIRE PYRO DEVICES	11 1T2	15 61T27	11	
00000				
65REM SQUIBS	10 2T2 1 2	15 63T 2	5 1	5
01B10X01A24 01A23				
66PREP TO MOVE CLAM	15 4T2	13 7T27	15	
00000				
67INST LIFT BARS	20 2T2 1 2	15 38I 1	10 2	10
01A02				
68REM FROM ADAPTER	5 4T2 1 2	15 47R 2	3 1	2
01A23X01A22 01A24 01A02				
69INST EQUIP COVERS	10 1T2 1 2	13 13I 1	5 2	5
038COW03A 14A03 14A02 01A02				
70REM SCAN PLAT BLANKET	10 T2 1 2 5	12 16R 1	5 2	5
14A03X14A02 03A 03B 01A02	15800E			
71INST LOUVER COVER	2 3T2 1 2 5	15 58I 1	1 2	1
03A02X03A 03B				
72INST SCAN PLAT BLANKET	3 3T2 1 2 5	15 70I 1	2 2	1
14A03X14A02 03A 03B 01A02	158000			
73INST ON TRAILER	5 4H2	I 3	216	3
01A01 02A 02B 02C				
74INST CLAM	20 4N5	15 66I29	20	
00000				
75MOVE TO SAF	60 N5	15 74I21	60	
00000				
76REMOVE CLAM	15 4H2	15 74R29	15	
01A01 02A 02B 02C				
77INST CRANE	15 4H2	13 1I 3	716	8
01A01 02A 02B 02C				
78MOVE S/C TO LOW LEVEL	15 4H2	15 77T 3	716	8
01A01 02A 02B 02C				
79REM CASE 2 SHLD / ANG	2 2H2 1 2 5	7 63R 1	1 2	1
06D03X14A31X				
80REM HARDWARE	3 2H2 1 2 5	7 63R 1	2 2	1
13B11X13B07X				
81REM CANOPUS SEN	10 2H2 1 2 5	12 12R 2	5 1	5
13B08X13B09X13B10X14A48X				
82REM BAFFLE	5 2H2 1 2 5	15 36R 2	3 1	2
13B10X13B08X				
83REM PROPUL SYS	35 3H2 1 2 5	R 2	12 1	12 5 11
06A00W06B00W06C00W06D00W				
84REM ACCEL	10 2H2 1 2	15 49R 2	5 1	5
03B22X				
85SEC IN HIGH BAY	430 H2	15 84T18	430	
00000				
STAGE 5 SYSTEMS TEST INCLUDING WEIGHT AND CG				
TASK 01 DAY 138 11/02/68				
1MOVE TENT	35 4H2	T 1	35	
00000				
2MOVE POSITIONER	5 4H2	T 3	316	2
01A01 02A 02B 02C				

3LOWER S/C ON POSITIONER	5 4H2	1 2T16	3 3	2	
01A01 02A 02B 02C					
4INST LIFTING BARS	5 2H2 1 2	I 1	3 2	2	
01A02					
5REM CABLE	2 2H2	R27	2		
00000					
6LIFT S/C	10 4H2	1 3T16	5 3	5	
01A01 02A 02B 02C					
7LOWER S/C	2 4H2	1 6T 3	116	1	
01A01 02A 02B 02C					
8REM CRANE	11 4H2	T27	11		
00000					
9REM LIFT BARS	4 4H2 1 2	R 2	2 1	2	
01A02					
10INST S/P MECH	13 4H2 1 2	I 1	7 2	6	
01A10X01A09X01A11X01A12X04B01X04B02X04B03X					
11INST/ALIGN S/P	105 4H2 1 2 5	T 1	45 2	459	15
04A01XC4A02X04A03X04A04X04B					
12SECURE U.RING	40 1H2	T27	40		
00000					
13REM LOUVER COVERS	40 2H2 1 2	R 2	20 1	20	
05A02X07A02X07A03X08A02X09A02X10A01X12A02X					
14REM MOTOR MOUNTS	52 2H2 1 2 5	R 2	26 1	26	
01A13X01A14X01A15X01A16X01A17X01A18X					
15TEST WEIGHT STAND	2 2H2	I27	2		
00000					
16TRANSFER S/C TO WT STAND	4 4H2	1 15T 3	216	2	
01A01 02A 02B 02C 04A					
17ALIGN S/C TO WT STAND	1 4H2	1 16T 9	1		
00000					
18WEIGH S/C	40 4H2	1 16T10	40		
00000					
19INST LIFTING BARS	12 2H2 1 2	I 1	6 2	6	
01A02					
20REM LIFTING BARS	70 2H2 1 2	1 19R 2	35 1	35	
01A02					
21INST LIFTING BARS	9 2H2 1 2	1 20I 1	5 2	4	
01A02					
22PREP TO MOVE S/C	10 4H2	1 18T27	10		
00000					
23MOVE S/C TO POSITIONER	4 4H2	1 22T 3	216	2	
01A01 02A 02B 02C 04A					
24REM LIFTING BRACKETS	32 2H2 1 2	1 21R 2	16 1	16	
01A02					
25INST MOTOR MOUNTS	19 2H2 1 2 5	1 14I 1	10 2	9	
01A13X01A14X01A15X01A16X01A17X01A18X					
26REM CRUISE DAMPER	3 2H2 1 2	R 2	2 1	1	
04B03X					
27REM UP CHANNELS	5 2H2 1 2 5	R 2	3 1	2	
14A14X14A15X14A16X14A17X14A18X					
28INST OSE BRACKET	3 2H2 1 2 5	I 1	2 2	1	
08A01X08A02X11A01X11A02X					
29REM PLATE OSE	120 2H2 1 2 5	R 9	120		
01A13X01A14X01A15X01A16X01A17X01A18X					
30LOQSEN STRUTS S/P 1/3	267 4H2 1 2 5	1 10T 2	134 1	133	
01A09X01A10X01A11X01A12X04A	04B 01A01				
31REM TC SHIELD	3 2H2 1 2 5	1 27R 2	2 1	1	
14A49X14A50X14A51X14A52X					
32REM CRUISE DAMPER	1 2H2 1 2 5	1 26R 2	1		
04B03X					
33REM SUPER ST CORNERS	5 2H2 1 2 5	R 2	3 1	2	
14A06X14A07X14A08X14A09X14A10X14A11X14A12X14A13X					

34REM CRUISE DAMPER	3 2H2 1 2 5	1 32R 2	2 1	1
04803X				
35REM CASE 6	1 2H2 1 2 5	R26	1	
10A00W10800W10C00W				
36REM HIGH LOW COAX	35 H2 1 2 5	R 2	18 1	17
02C04X02A02X02A 028 02C				
37SECURE IN TENT	462 H2	1 36T17	462	
00000				
TASK 02 DAY 139 11/03/68				
1SECURE IN TENT	1440 T2	1 37T17	1440	
00000				
TASK 03 DAY 140 11/04/68				
1SECURE IN TENT	185 T2	2 17T17	185	
00000				
2REM IRR ASSY	58 2T2 1 2 5	R 2	29 1	29
03B06X03B07X03B 03A				
3REM SPRINGS SOL PANEL 4	58 3T2 1 2 5	R 2	29 1	29
01A09X01A10X01A11X01A12X04A	048 01A02			
4TILT S/C	2 4T2	1 23T16	2	
00000				
5REM CABLE CLAMPS SOL P 1	10 1T2 11112	R 2	5 1	5
04A01X04804X				
6REM TC HARDWARE	10 2T2 1 2	R 2	5 1	5
14A45X14A46X14A47X				
7REM SOLAR PANEL 1	5 4T2 1 2 5	3 5R 2	2 1	2 5 1
04A01X04804X				
8REM PIN PULLERS	5 2T2 1 2	R 2	3 1	2
04808X				
9INST GS BELLOWS	10 T2 1 2 5	I 1	4 2	415 2
13A01X13A09X01A02				
10REM CABLE CLAMPS SOL P 4	7 2T2 11112	R 2	3 1	4
04A02X04805X				
11REM SOL PANEL BOOST DAMP	6 2T2 1 2 5	R 2	3 1	3
04802X				
12REM SOL PANEL BOOST DAMP	7 2T 1 2 5	3 11R 2	4 1	3
04802X				
13REM POWER HARN	10 3T2 1 212	R 2	3 1	314 4
04804X				
14MEASURE SP STRUTS	10 2T216	T10	10	
01A05X01A06X01A07X01A08X				
15REM SOL PAN CABLE CLAMPS	20 2T2 11112	R 2	7 1	714 6
04A04X04807X				
16REM SOLAR PANEL 7	10 3T2	3 15R 2	3 1	3 4 4
04A04X04807X				
17INST SUPPORT RACK	10 2T2 1 2 5	I 1	3 2	315 4
13A01X13A09X01A02				
18REM SOLAR PAN BOOST DAMP	2 2T2 1 2 5	R 2	1 1	1
04802X				
19REM SOLAR PAN BOOST DAMP	3 2T2 1 2 5	R 2	2 1	1
04802X				
20REM SOLAR PAN BOOST DAMP	4 2T2 1 2 5	R 2	2 1	2
04802X				
21REM SOLAR PAN BOOST DAMP	3 2T2 1 2 5	R 2	2 1	1
04802X				
22REM POWER HARN	3 2T2 1 2 5	R 2	1 1	114 1
04807X				
23REM SOLAR PANEL 3	7 3T2 1 2 5	R 2	2 1	2 5 3
04A02X04805X				
24REM PIN PULLER	5 2T2 1 2	R 2	3 1	2
04808X				
25REM SUPER STRUCT HARDWRE	5 2T2 1 2	3 6R 2	3 1	2
14A38X14A39X14A40X14A41X14A42X14A43X				

26INST SUPPORT RACK	5 2T2 1 2 5	I 1	2 2	215	1	
13AD1X13AD9X01AD2						
27REM POWER HARN	15 3T2 1 2 5	R 2	5 1	514	5	
04805X						
28REM SOLAR PANEL 5	10 3T2 1 2 5	R 2	4 1	4 5	2	
04AD3X04B06X						
29INST SUPPORT RACK	10 2T2 1 2 5	I 1	4 2	415	2	
13AD1X13AD9X01AD2						
30REM UP TS BLANKET	10 2T2 1 2	R 2	5 1	5		
14AD1X						
30EXPOSED ZONES		M				
C1ADCE01B00E05AC0E05B00E05C00E06AD0E06B00E06C00E06D00E07AD0E07B00E07C00E08AD0E						
30EXPOSED ZONES		M				
08B00E08C00E09AC0E09B00E09C00E10AD0E10B00E10C00E11AD0E11B00E11C00E12AD0E12B00E						
30EXPOSED ZONES		M				
12C00E13AD0E15AD0E						
31REM SUPER STRUCT HARDWRE	20 2T2 1 2	R 2	10 1	10		
14A44X14A55X						
32REM PROTECTIVE COVERS	10 2T2 1 2	R 2	5 1	5		
05AD2X07AD2X07AD3X08AD2X09AD2X10AD1X12AD2X						
33REM SUPER STRUCT HARDWRE	4 2T2 1 2	R 2	2 1	2		
14A19X14A20X14A21X14A22X14A23X14A24X						
34REM LOUVER BAY 8	2 2T2 1 2 5	R 2	1 1	1		
12AD2X12AD1						
35REM SUPER STRUCT HARDWRE	44 2T2 1 2 5	R 2	22 1	22		
14A57X14A58X						
36REM BATT	10 2T2 1 2 5	R 2	4 1	426	2	
12B06X12B 12A						
37CLOSE CASE 8	20 2T2 1 2	3 34T 1	10 2	10		
12AD1X						
38REM LOUVER BAY 7	3 2T2 1 2 5	R 2	2 1	1		
11AD2X11AD1 11AD3						
39SEC BATT QAS	7 1T2	3 36T25	7			
00000						
40INST BATT	110 2T2 1 2	3 39I 1	55 2	55		
12B06X12AD1 01AD2						
41REM LOUVER BAY 5	10 2T2 1 2 5	R 2	5 1	5		
09AD2X09AD1						
42REM LOUVER BAY 4	58 2T2 1 2 5	R 2	29 1	29		
08AD2X08AD1						
43REM LOUVER BAY 1	40 2T2 1 2 5	R 2	20 1	20		
05AD2X05AD1						
44REM SCAN PLAT LOUV	48 2T2 1 2 5	R 2	24 1	24		
03AD2X03A 03B						
45INST PROT COV ON BOTTLES	18 2T2	R 1	18			
13AD2X13AD10						
46SECURE IN TENT	531 T2	T17 531				
00000						
TASK 04 DAY 141 11/05/68						
1SECURE IN TENT	15 T2	3 46T17	15			
00000						
2ROTATE S/C	30 4T2	1 23T16	30			
00000						
3DEPRESSURIZE SCAN PLAT	5 2T2	3 44T27	5			
00000						
4ROTATE S/C	20 4T2	4 2T16	20			
00000						
5LOOSEN SCREWS ON SCAN PT	20 2T2 1 2 5	4 3T 2	10 1	10		
03A X03B X						
6TORQUE SCREWS ON SCAN PT	75 2T2 1 2 5	4 5I 2	40 1	35		
03AD0W03B00W						
7TILT S/C	17 4T2	4 4T16	17			

00000					
8REM SIT /MOUNT	1	1T2 1 2 5	X 2	1	
01B05X12B06X12AD1					
9INST SUN GATE HOOD	4	1T2 1	I 1	2 2	2
13B07X					
10MEASURE CONE	3	1T2	T10	3	
00000					
11MEASURE CLOCK	2	2T2	T10	2	
00000					
12INST SUN SENSOR HOODS	1	2T2 1	I 2	1	
13B01X13B02X13B03X13B04X13B05X13B06X					
13INST SP MICROSWITCHES	19	1T2 1 2	I 1	9 2	10
04B09X					
14CABLE CRAFT OSE	10	1T2 1 2	T27	10	
00000					
15REL CANOPUS SENSOR	10	2T2	T25	10	
00000					
16INST CANOPUS SENSOR	10	2T2 1 2 5	I 1	5 2	5
13B09X13B10X13B11X					
17INST CABLES OSE	13	2T2	I27	13	
00000					
18INST IRR	10	2T2 1 2 5	I 1	5 2	5
03B06X03B07X03B 03A					
19MATE CONNECTORS	10	2T2 1 2 5	T 1	4 2	411 2
03B06X05C04					
20ALIGN INSTRUMENTS	35	3T2	T 9	2015	15
00000					
21REM NARR ANG TV COVER	5	2T2	R 1	5	
03B12X					
22TURN POWER ON	21	T2	T27	21	
00000					
23CALIBRATE NARR ANG TV	114	3T2	4 21T10	114	
00000					
24CALIBRATE WIDE ANG TV	5	3T2	T10	5	
00000					
25INST NARR ANG TV COVER	45	1T2	4 21I 1	45	
03B12X03B13 03B14					
26PACKAGE ADAPT STRUCT	40	2T2	T27	40	
00000					
27REM IRR COVER	40	2T2	4 18R 1	40	
03B06X03B 03A					
28INST IRR COVER	20	2T2	4 27I 1	20	
03B06X03B 03A					
29REM IRS COVER	10	2T2	R 1	10	
03B16X03B15 03B17 03B18 03B19					
30COVER WIDE ANG TV CAMERA	5	1T2	T 1	5	
03B10X03B11					
31CALIBRATE IRS	60	3T2	4 29T10	60	
00000					
32PURGE IRS	2	2T2	4 31T27	2	
00000					
33REM UVS COVER CALIBRATE	41	3T2	R 1	610	35
03B08X03B09					
34INST UVS COVER	12	1T2	4 33I 1	12	
03B08X03B09					
35TURN POWER OFF	15	T2	4 22T27	15	
00000					
36TURN POWER ON	10	T2	4 35T27	10	
00000					
37CALIB FAR PL SENSOR	60	3T210	T 1	3010	30
03B03X					
38TURN POWER OFF	7	T2	4 36T27	7	

00000	3	2	T	1	3					
39COVER FEPS WITH TAPE	3	2	T	1	3					
03803X										
40SECURE IN TENT	615	T2				117	615			
00000										
TASK 05 DAY 142 11/06/68										
1SECURE IN TENT	75	T2	4	40	T17	75				
00000										
2REM IRR	5	2	T2	1	2	5	4	18	R 2 3 1 2	
03806X03807										
3DECREASE BELLEVILLE SPRG	5	2	T2	10			T 1	2 2	210 1	
03B16X03B15 03B17 03B18 03B19										
4ADJ BELLVILLE SPRING	40	2	T2	10			5	3	T 1 12 2 1410 14	
03B16X03B15 03B17 03B18 03B19										
5VENT PRESS IN A/C SYS	5	2	T2	10			4	32	T27 5	
13A09X										
6VENT PRESS A/C SYS	5	2	T2	10				T27	5	
13A09X										
7ADJ A/C SYS	13	2	T2	10			5	5	T 1 5 2 510 3	
13A01X13A09X										
8ALIGN MARS GATE	180	2	T2					T27	180	
00000										
9COMPLETE MARS GATE ALIGN	85	2	T2				5	8	T27 85	
00000										
10ECALIBRATE IRS	32	2	T2				4	31	T27 32	
00000										
11PRESS IRS VENT	39	2	T2				5	6	T27 39	
03B17X										
12TURN POWER ON	7	T2					4	38	T27 7	
00000										
13TURN POWER OFF	7	T2					5	12	T27 7	
00000										
14MATE PAS CABLE	12	1	T2					R 1	611 6	
01B06X										
15INST MOTOR MTS	3	2	T2	1	2			R 2	2 1 1	
01A13X01A14X01A15X01A16X01A17X01A18X										
16PRESS IRS ASSY	20	T2					5	7	T27 20	
00000										
17INST MOTOR	5	3	T2	1	2	5	5	14	T 1 3 2 2	
06A X06B X06C X06D X										
18STOP PRESS IRS ASSY	5	1	T2				5	16	T27 5	
00000										
19TORQUE MOTOR	15	2	T2	5				I 1	7 2 8	
06A00W06B00W06C00W06D00W										
20LOOSEN CABLE CLAMP/MATE	35	2	T2	1	2	5	12	5	19	T 2 10 1 1011 1014 5
15A02X15A01 15A03 06D02X06D01X										
21INST IRR	10	2	T2	1	2	5	5	2	I 1 5 2 5	
03B06X03B07X03B 03A										
22INST SCAN STIMULUS PLAT	10	3	T2	4	6			I 1	4 2 415 2	
03B 03A										
23INST UVS STIMULUS	1	2	T2	1				I 2	1	
03B08X										
24INST IRR STIMULUS	4	1	T2	1			5	2	I 1 2 2 2	

29TURN POWER ON	24	T2	5	13T27	24	
00000						
TASK 06 DAY 143 11/07/68						
1TURN GYROS ON	225	T2	5	29T27	225	
00000						
2TURN GYROS OFF	410	T2	6	1T27	410	
00000						
3REM CLOCK	10	2T2 1 2 5		R 2	5 1	5
03B04X01A02 02A 02B 02C						
4INST CLOCK	5	2T2 1 2 5		I 1	3 2	2
03B04X01A02 02A 02B 02C						
5REM CONE	10	2T2 1 2 5	4	10R 2	5 1	5
03B05X03A C3B 01A02 15A04						
6INST CONE	10	2T2 1 2 5	6	5I 1	5 2	5
03B05X03A C3B 01A02 15A04						
7SEC CABLES /0SE	5	T2		T27	5	
00000						
8SECURE IN TENT	765	T2	6	7T27	765	
00000						
TASK 07 DAY 144 11/08/68						
1TURN POWER ON	140	T2	6	8T27	140	
00000						
2REM SCI PLAT	310	3T2 4 6		R 1	102 2 10515	103
03A 03B 15A04 01A02						
3INST SCI PLAT	190	T2 4 6	7	2I 1	60 2 6015	70
03A 03B 15A04 01A02						
4TURN POWER OFF	5	T2	7	1T27	5	
00000						
5SECURE IN TENT	795	T2	7	4T17	795	
00000						
TASK 08 DAY 145 11/09/68						
1SECURE IN TENT	15	T2	7	5T17	15	
00000						
2TURN POWER ON	565	T2	7	4T27	565	
00000						
3TURN POWER OFF	50	T2	8	2T27	50	
00000						
4SECURE IN TENT	810	T2	8	3T17	810	
00000						
TASK 09 DAY 146 11/10/68						
1SECURE IN TENT	1440	T2	8	4T171440		
00000						
TASK 10 DAY 147 11/11/68						
1SECURE IN TENT	1440	T2	9	1T171440		
00000						
TASK 11 DAY 148 11/12/68						
1SECURE IN TENT	30	T2	10	1T17	30	
00000						
2PREP TO REM BAY 6	12	T2		T27	12	
00000						
3REM BAY 6	163	2T2 1 2 5		R 2	82 1 81	
10A00W10B00W10C00W						
3INSTALL PARTS		T		I		
10B00W						
4RETURN CASE 6 TO GAS	100	2T2		T 5	5026 50	
10A X10B X10C X						
5PREP FOR TV SIM TESTS	73	2T2		T27	73	
00000						
6TURN POWER ON	481	T2	8	3T27	481	
00000						
7TURN POWER OFF	13	T2	11	7T27	13	
00000						

8REM SCI WIRING	15 2T2	7 2R11 15	
03800W03A			
9SECURE IN TENT	553 T2	11 8T17 553	
00000			
TASK 12 DAY 149 11/13/68			
1SECURE IN TENT	30 T2	11 9T17 30	
00000			
2REM IRR	10 2T2 1 2 5	5 21R 2	5 1 5
03806X03B07 03A			
3REM WIDE ANG CAMERA	2 2T2 1 2 5	R 2	1 1 1
03810X03B11 03A			
4REM FEPS	3 2T2 1 2 5	5 26R 2	2 1 1
03803X03A			
4REM UVS	15 2T2 1 2 5	5 23R 2	7 1 8
03808X03B09 03A			
5REM MARS GATE	5 2T2 1 2 5	5 9R 2	3 1 2
03801X03A			
6REM MARS GATE 2	10 2T2 1 2 5	R 2	5 1 5
03802X03A			
7REM NARR ANG TV	95 2T2 1 2 5	R 2	47 1 48
03812X03B13 03B14 03A			
8REM IRS GAS STORAGE	5 2T2 1 2 5	5 18R 2	3 1 2
03815X03A			
9REM IRS VENT	5 2T2 1 2 5	5 11R 2	3 1 2
03817X03B18 03B19 03A			
10REM MONO TEL	20 2T2 1 2 5	R 2	10 1 10
03816X03A			
11REM L/G ANT DAMPER	5 2T2 1 2 5	R 2	3 1 2
02A03X02A 02B 02C			
12REM H/G ANT DAMPER	5 2T2 1 2 5	R 2	3 1 2
02A04X02A01 02A02 02B 02C			
13REM L/G ASSY	15 2T2 1 2 5	12 11R 2	7 1 8
02A01X02A02X02B 02C			
14REM TCFM	15 2T2 1 2 5	R 2	7 1 8
02B01X02B02 02C			
15REM H/G ASSY	25 2T2 1 2 5	12 12R 2	13 1 12
02C01X02C02 02C03 02C04			
16REM H/G ANT CABLE	25 2T2 1 2 5	12 15R 2	13 1 12
02C03X02C02X02C04X			
17REM MOTOR	35 2T2 1 2 5 4	R 2	10 1 10 5 15
06A00W06B00W06C00W06D00W			
18REM SIT	1 2T2 1 2 5	4 8R 2	1
01B05X			
19REM BATT	12 2T2 1 2	3 40R 2	4 1 426 4
12B06X12A01			
20REM SCAN ACTUATOR 1	5 2T2 1 2 5	R 2	3 1 2
03804X01A02			
21REM SCAN ACTUATOR 2	10 2T2 1 2 5	R 2	5 1 5
03805X01A02 03A			
22REM SHEAR PLATE	45 1T2 1 2 5	R 2	23 1 22
11A03X11A01			
23REM CASE 7	115 2T2 1 2 5	R 2	58 1 57
11A01X11B 11C			
24REM MODS CASE 7	60 2T2 1 2 5	12 24R 2	30 1 30
11B05X11B06X11B07X11B08X11B01X11B02X11B03X11B04X11A01 11C			
25REM CANOPUS SENSOR	115 2T2 1 2 5	4 16R 2	58 1 57
13B08X13B09 13B10 13B11 01A02			
26REM CASE 5	10 2T2 1 2 5	R 2	5 1 5
09A00W09B00W09C00W			
27DEMATE CONNECTORS	10 2T2 1 2 5	12 26R 2	4 1 411 2
09C01X			
28REM CASE 5 MODS	15 2T2 1 2 5	12 27R 2	7 1 8

09B00W09A01	09C01														
29REM CASE 3 SHEAR PLATE		45	1T2	1	2	5		R 2	23	1	22				
07A03X07A															
30REM GYRO CONTROL		15	2T2	1	2	5		R 2	8	1	7				
07B06X07B01 07B02 07B03 07B04	07B05 07AC5 07A01														
31REM BAY 3		15	2T2	1	2	5		R 2	8	1	7				
07A00W07B00W07C															
32REM SUPPORT CHAS		15	2T2	1	2		12	31R 2	8	1	7				
07A05X07A01 07B 07C															
33REM BAY 3 MODS		15	2T2	1	2	5	12	31R 2	8	1	7				
07B01X07B02X07B03X07B04X07B05X07C	07A01														
34REM WIRE HARN BAY 5		45	3T2	1	2	5	12	31R 2	23	1	22				
09C01X09A01															
35REM CASE 1		10	2T2	1	2	5		R 2	5	1	5				
05A00W05B00W05C00W															
36REM WIRE HARN CASE 3		10	3T2	1	2	5	12	35R 2	5	1	5				
07C02X07C01 07C03 07A01															
37REM CASE 4		15	2T2	1	2	5		R 2	7	1	8				
08A00W08B00W08C00W															
38REM CASE 8		10	2T2	1	2	5	3	37R 2	5	1	5				
12A01X12B 12C															
39DEMATE HARN CASE 8		5	3T2	1	2	5	12	38R 2	2	1	211	1			
12C01X12B 12A01															
39INSTALL PARTS		T					I								
12C00W															
4CREM MODS CASE 8		10	2T2				12	38R 2	5	1	5				
12B01X12B02X12B03X12B04X12B05X12C01 12A01															
41SECURE IN TENT		507	T2				12	40T17	507						
00000															
TASK 13 DAY 150 11/14/68															
1SECURE IN TENT		20	T2				12	41T17	20						
00000															
2REM MODS BAY 4		20	2T2	1	2	5		R 2	10	1	10				
08B00W08A01 08C															
3REM OSE CABLES		15	3T2	1	2	5		R27	15						
00000															
4REM HARN BAY 4		8	3T2	1	2	5	12	3R 2	2	1	211	214	2		
08C01X08A01 08C02															
5REM HARN BAY 4		18	3T2	1	2	5	12	3R 2	5	1	511	414	4		
08C02X08A01															
6REM CASE 1 PYRO MODS		8	2T2	1	2	5	12	35R 2	4	1	4				
05B01X05B02X05B 05A01 05C															
7REM MODS CASE 1		5	2T2	1	2	5	13	6R 2	3	1	2				
05B03X05B04X05B06X05B07X05B08X05B09X05B10X05B11X05B12X05A01 0															

15INST SCAN POWER	1 2T2 1 2 5	I 2 1			
05B11X05B10 05B12 05A01					
16INST HEAT DC DIST	1 2T2 1 2 5	I 2 1			
05B07X05B10 05B11 05B12 05A01					
17INST CASE 1 MODS	30 2T2 1 2 5	1 12I 1 15 2 15			
05B00W05A01					
18SECURE IN PIT	1002 P2	1 17T201002			
00000					
TASK 02 DAY 158 11/22/68					
1PREP TO MOVE S/C FROM PT	30 4P2	1 18T27 30			
00000					
2REM S/C FROM PIT	12 4P2	2 1R13 616 6			
01A01X13A01X13A09X					
3LOWER S/C TO HIGH BAY FL	48 4H2	2 2T 3 2416 24			
01A01X13A01X13A09X					
4REM S/C FROM U RNG/ROTAB	2 4H2	2 3R 3 116 1			
01A01X13A01X13A09X					
5INST TIE CLAMPS BAY 3	40 2T2 1 212	1 7I 1 13 2 1314 14			
07C00W07A01					
6INST BAY 1 HARNS	7 3T2 1 2 5	1 12T 1 1 2 211 214 2			
05C04X05C01X05A01 05B					
7INST BAY 3 GUIDE PINS	43 2T2 1 2 5	I 1 22 2 21			
07C00W07C01					
8INSP OCTAGON ASSY	20 2H2	T 9 20			
00000					
9INST FIXTURE BAY 7	8 2T2 1 2	I 1 3 2 3 5 2			
11A01X					
10INST HARN BAY 7	7 3T2 1 2 5	I 1 2 2 214 3			
11C01X11C02X11C03X11A01					
11INST TIE WRAPS BAY 7	93 2T2 1 2	2 10I 1 30 2 3014 23			
11C01X11C02X11C03X11A01					
12SEC CONN BAY 8	30 T2 1 2	1 10I 1 8 2 811 814 6			
11C01X11C02X11C03X11A01					
13SEC CONN BAY 7	155 T2 1 2	2 11I 1 39 2 3911 3914 38			
00000					
14SEC CONN BAY 7	8 T2 1 2	2 13I 1 2 2 211 214 2			
00000					
15SECURE IN TENT	947 T2	2 14T117 947			
00000					
TASK 03 DAY 159 11/23/68					
1INST HARN SCAN PLAT	30 3T2 1 2 5	I 1 8 2 711 714 8			
15B01X15B02X15B03X15B04X03A01					
2SEC TORQ TUBE	42 2T2 1 2 5	3 1I 1 21 2 21			
15B01X15B02X15B03X15B04X03A01					
3INST SCAN PLAT HARN	20 3T2 1 2 5	I 1 5 2 511 514 5			
15B01X15B02X15B03X15B04X03A01					
4ADJUST SCAN TORQ TUBE	60 2T2 1 2 5	3 3T 1 30 2 30			
15B01X15B02X15B03X15B04X03A01					
5ROUT HARN	10 2T2 1 2 5	3 3T 1 5 2 5			
15B01X15B02X15B03X15B04X03A01					
6SEC CONN SCAN SCI HARN	10 2T2 1 2 5	T 1 5 2 5			
15B01X15B02 15B03 15B04 03A01					
7TORQUE CLAMPS SCAN PLAT	10 2T2 5	T 2 5 1 5			
03A01X15B01 15B02 15B03 15B04					
8INST PLAT HEAT HARN	5 2T2 1 2 5	T 2 2 1 111 114 1			
15A07X03A01 15B01 15B02 15B03 15B04					
9TORQUE CLAMPS SCAN PLAT	23 T2	T 2 12 1 11			
15A07 03A01X15B01 15B02 15B03 15B04					
10SECURE IN TENT	1230 T2	T171230			
00000					
TASK 04 DAY 160 11/24/68					
1SECURE IN HIGH BAY	1440 H2	T181440			

00000

TASK 05 DAY 161 11/25/68

1SECURE IN HIGH BAY	30	H2	4	1T18	30				
00000									
2INSP OCTAGON STRUCT	175	2H2	2	8T 9	60 6	60 7	55		
01A01 13A01 13A09									
3MOVE S/C TO TENT/C2/REQ	265	4T2	2	4T16	165 3	100			
01A01 13A01 13A09									
4INST SCAN PLAT ASSY	15	3T2 1 2 5	3	4I 1	5 2	5 9	5		
03A01X15B 01A02 15A04									
5INST OSE BRACE	20	2T2 1 4 6		I 1	7 2	715	6		
01A02X									
6REM CASE 8 MOD	35	2T2 1 2 5	1	2R 2	18 1	17			
12B01X12B 12C 12A01									
7SECURE IN TENT	900	T2	1	717	900				

00000

TASK 06 DAY 162 11/26/68

1SECURE IN TENT	25	T2	5	7T17	25				
00000									
2INST HARN ON UPPER RING	20	2T2 1 2 5		I 1	5 2	511	514	5	
15B01X15A03XD1A02 15A01 15A02									
3INST HARN ON UPPER RING	13	2T2 1 2 5		I 1	4 2	411	314	2	
15B03X15A03XD1A02 15A01 15A02									
4INST HARN ON UPPER RING	4	2T2 1 2 5		I 1	1 2	111	114	1	
15B04X15A03XD1A02 15A01 15A02									
5TORQUE SCAN PLAT BEAR	13	1T2 5	5	4I 1	7 2	6			
03A01X									
6CK VIOLATIONS C/2	45	T2		T27	45				
00000									
7INST HARN ON UPPER RING	30	2T2 1 2 5		I 1	7 2	811	714	8	
15A06X15A03XD1A02 15A01 15A02									
8DIP-DAUBED SCREWS	15	1T2		T12	15				
11A01X									
9INST CABLE CLAMPS	33	2T2 1 2 5		I 1	11 2	1114	11		
03A01X15B									
10SPICE SCAN HARN	11	1T212	6	7T14	11				
03B21X15B 01A02 15A04									
11INST SCAN PLAT COVER	90	2T2 1 2 5	5	4I 1	45 2	45			
03A01X15B 15A04 01A02									
12CK TORQUE SCAN PLAT	45	2T210	5	4T10	45				
03A01X									
13REWORK OCTAGON ASSY	112	3T2	5	2T12	112				
01A01X									
14INSP OCTAGON ASSY	2	T2	6	14T 9	2				
00000									
15REM DUMMY SCAN PLAT	26	2T2 1 2	5	4R 2	13 1	13			
03A01X15B									
16INST MODS CASE 3	20	2T2 1 2 5	1	11I 1	10 2	10			
07B01X07B02X07B03X07C 07A01									
17SECURE IN TENT	254	T2	6	16T17	254				
00000									
18INST/TORQ CASE 8 MODS	31	2T2 1 2 5		I 1	16 2	15			
12B01X12B 12A01 12C01									
19INST CASE 8	25	2T2 1 2 5		I 1	13 2	12			
12A01X12B 12C									
20INST CASE 1 MODS	35	2T2 1 2 5		I 1	18 2	17			
05B01X05B02X05B 05C 05A01									
21INST/TORQ CASE 1 MODS	5	2T2 1 2 5		I 2	3 1	2			
05B08X05B09X05B 05C 05A01									
22TORQUE CASE 1 MODS	70	2T2 5		I 2	35 1	35			
05B08X05B09X05B 05C 05A01									
23INST ICEM HARN	7	2T2 1 2 5		I 2	2 1	211	214	1	

05C02X05C01 05C04 05A01 05B									
24INST CASE 7 MODS /TORQ	8 2T2 1 2 5	I 1	4 2	4					
11B01X11B02X11B03X11B04X11C	11A01								
25SECURE IN TENT	501 T2	6 24T17	501						
00000									
TASK 07 DAY 163 11/27/68									
1SECURE IN TENT	35 T2	6 25T17	35						
00000									
2INST MOD CASE 3	10 2T2 1 2 5	1 11I 1	5 2	5					
07B04X07B01 07B02 07B03 07C	07A01								
3INST SUPP CHAS	16 2T2 1 2 5	I 1	8 2	8					
07A05X07A01 07B01 07B02 07B03 07B04 07C	9 1T2 5	7 2T 2	9						
4TORQUE CASE 3 SCREWS	9 1T2 5								
07A05X07A01 07B01 07B02 07B03 07B04 07C	15 1T2	6 20I 9	15						
5INSP PYRO CONNS	15 1T2								
00000									
6INST MODS CASE 4	16 2T2 1 2 5	6 24I 1	8 2	8					
08B00WC8A01									
7TORQUE CASE 4	12 1T2 5	7 6T 1	6 2	6					
08B X08A01									
8VERIFY TORQUE HARN BRACK	13 1T2 5	7 7T 2	13						
08B X08A01									
9INST HARN CASE 4	6 2T2 1 2 5	I 1	2 2	111 114	2				
08C01X08C02X08A01 08B									
10VERIFY TORQUE HARN SUPP	4 1T2 5	7 8T 1	2 2	2					
08A01 08B 08C									
11TORQUE CONN CASE 4	86 2T2	7 9I11	86						
08C01X08C02X									
12INST CASE 1	32 2T2 1 2 5	1 12I 1	16 2	16					
05A01X05B00W05C00W									
13INST CASE 4	13 2T2 1 2 5	7 9I 2	7 1	6					
08A01X08B 08C									
14TORQUE CASE 7	10 1T2 5	2 14I 2	10						
11A01X11B01X11B02X11B03X11B04X11C									
15INST CASE 7	27 2T2 1 2 5	7 14I 1	13 2	14					
11A01X11B01X11B02X11B03X11B04X11C									
16INST CLOCK ACTUATOR	3 2T2 1 2 5	I 1	1 2	2					
03B04X									
17INST CONE ACTUATOR	4 2T2 1 2 5	I 1	2 2	2					
03B05X03A01									
18INST DRIVE LINKS	13 2T2 1 2	I 1	7 2	6					
03B04X03B05X01A02 03A01 15A04									
19SECURE IN TENT	1115 T2	7 18T171116							
00000									
TASK 08 DAY 164 11/28/68									
1SECURE IN TENT	1440 T2	7 19T171440							
00000									
TASK 09 DAY 165 11/29/68									
1SECURE IN TENT	1440 T2	8 1T171440							
000000									
TASK 10 DAY 166 11/30/68									
1SECURE IN TENT	1440 T2	9 1T171440							
00000									
TASK 11 DAY 167 12/01/68									
1SECURE IN TENT	1440 T2	10 1T171440							
00000									
TASK 12 DAY 168 12/02/68									
1SECURE IN TENT	40 T2	11 1T17 40							
00000									
2INSP TENT/C/2	35 3T2	T27	35						
00000									
3INST TOOL PLATE	55 2T2 1 2 5	I 1	20 2	2015 15					

07A01X									
4INST OPTICAL INSTRUMENTS	12	2T2	1	2		I	1	4	2 4 9 4
03A01X									
5CK HORIZONTAL BAR	12	2T2				T	9	12	
07A01X									
6SET HORIZONTAL AXIS	8	1T2				T	15	8	
00000									
7INST FEPS	3	2T2	1	2	5	I	1	1	2 2
03B03X03A01									
8INST FEPS HOOD	15	1T2	1			12	7I	1	7 2 8
03B03X03A01									
9INST ANVIL PLATE	21	1T2	1	2		I	1	7	2 715 7
03A01X									
10RAISE S/C	3	1T2				5	3T	16	3
00000									
11INST SUPPORT LINKAGE	146	2T2	1	2		I	1	50	2 5015 46
03A01 03B03 03B04 03B05 15A04 01A02									
12COMPLETE OPTICAL SET UP	35	2T2				12	4T	27	35
00000									
13TURN POWER ON	95	T2					T	27	95
00000									
14INST VECTOR ON PROP	35	T2	1	2	4	6	I	1	18 2 17
06B01X06B02X06A 06C 06D									
15TURN POWER OFF	25	T2				12	13T	27	25
00000									
16SECURE IN TENT	900	T2				12	15T	17	900
00000									
TASK 13 DAY 169 12/03/68									
1ALIGN SCAN	30	T2					T	9	30
00000									
2TURN POWER ON	200	T2				12	15T	27	200
00000									
3TURN POWER OFF	60	T2				13	2T	27	60
00000									
4TURN POWER ON	155	T2				13	3T	27	155
00000									
5COMPLETE ALIGNMENT	25	T2				13	1T	9	25
00000									
6MOVE S/C	10	4T2				12	10T	16	10
00000									
7REM SCAN PLAT OPT EQUIP	14	2T2	1	2	4	613	5R	2	5 1 515 4
03A01X07A01 01A02									
8TURN POWER OFF	16	T2				13	4T	27	16
00000									
9SECURE IN TENT	930	T2				13	8T	17	930
00000									
TASK 14 DAY 170 12/04/68									
1SECURE IN TENT	85	T2				13	9T	17	85
00000									
2TURN POWER ON	138	T2				13	8T	27	138
00000									
3TURN POWER OFF	63	T2				14	2T	27	63
00000									
4TURN POWER ON	4	T2				14	3T	27	4
00000									
5COMPLETE ALIGN	90	2T2					T	9	90
03A01X									
6REM CLOCK ACTUATOR	10	2T2	1	2	5	7	16R	2	5 1 5
03B04X									
7REM CONE ACTUATOR	41	2T2	1	2	5	7	17R	2	21 1 20
03B05X03B03 03A01 01A02									
8TURN POWER OFF	26	T2				14	4T	27	26

00000									
9LATCH SCAN PLAT	4	1T2	13	7I	1	4			
01A19X01A20X01B01X01B02X03A01X03B03									
10INST DUMMY ACT	13	2T2 1 2		I	1	7 2	6		
03A01X03B03									
11CK SCAN TORQUE/CLOCK	41	2T210	14	6T	10	41			
03A01X									
12REALIGN SCAN TO CONE	2	2T2	14	10T	16	2			
03A01X									
13CK SCAN TORQUE/CONE	85	2T210	14	7T	10	85			
03A01X									
14MOVE S/C	13	4H2	13	6T	3	616	7		
01A01X13A01 13A09									
15POSITION S/C /TORQ	30	72 2 4 5 6		I	3	1516	15		
01A01X13A01 13A09									
16VACUUM TENT	20	T2		T27	20				
00000									
17SECURE IN TENT	775	T2	14	16T	17	775			
00000									
STAGE 7 SYSTEM TEST									
TASK 01 DAY 171 12/05/68									
1PREP JET VALVE LEAK TEST	30	1T2		T27	30				
00000									
2TEST JET VALVE LEAK	152	2T210		T10	152				
13A05X13A13X13A14X13A15X									
3INST CASE 5 MODS	30	2T2 1 2 5		T	1	15 2	15		
09B X09A01									
4TORQUE CASE 5 MODS	8	2T2 5	1	3I	2	8			
09B00W09A01									
5INST HARN CASE 5	12	2T2 1 2 5	1	4I	1	3 2	311	314	3
09C01X09B 09A01									
6TEST JET VALVE LEAK	2	1T210	1	2T	10	2			
00000									
7MATE MODS	20	2T2	1	5I	11	20			
09C01X09B00W09A01									
8TERM JET VALVE TEST	70	1T2	1	6T	27	70			
00000									
9PREP TO INST CASE 3	1	2T2		T27	1				
00000									
10PREP TO INST CASE 5	1	2T2	1	5T	27	1			
00000									
11INST CASE 5	28	2T2 1 2 5	1	10I	1	14 2	14		
09A01X09B00W09C00W									
12INST CASE 3	12	2T2 1 2 5	1	9I	1	6 2	6		
07B01X07B02X07B03X07B04X07C	07A01								
13INST SUN SENSOR HOOD	4	2T2 1		I	1	2 2	2		
13B01X									
14INST OSE STIMULUS	2	2T2 1		I	1	1 2	1		
13B02X									
15INST OSE SS STIMULI	4	2T2 1		I	1	2 2	2		
13B03X13B04X13B05X13B06X									
16INST ATT CONTROL	52	2T2 1 2 5		I	1	26 2	26		
07B05X07B01 07B02 07B03 07B04 07C 07A05 07A01									
17INST GYRO CONTROL	6	2T2 1 2 5		I	1	3 2	3		
07B00W07C 07A01 07A05									
18INST CLOCK ACTUATOR	7	2T2 1 2		I	1	3 2	4		
03B04X									
19INST CANOPUS SENSOR	1	2T2 1 2 5		I	2	1			
13B08X13B09X13B10X13B11X									
20INST CONE ACTUATOR	6	2T2 1 2		I	1	3 2	3		
03B05X									
21PREP FOR TEST	6	T2		T27	6				

[illegible]

21TORQUE 280 NUTS A/C	10 2T2 5	I 2 10	
13A01X13A09X			
22TORQUE CONN	3 2T2 5	2 18I 2 3	
03A01 03B			
23INST TV COL	2 3T2	115 2	
03B			
24INST DUMMY SQUIBS PROP	29 2T2 1 2	I 1 15 2 14	
06D02X06D04X06D05X06D06X06D07X06C03X06C06X			
25TURN POWER OFF	119 T2	2 3T27 119	
00000			
26REM OSE PLAT	5 3T2 1 2 4 6 1	14R 2 2 1 215 1	
03B 03A01			
27INST NARR ANG TV COVER	5 1T2	2 16I 1 5	
03B12X			
28MOVE S/C	5 T2	115 5	
00000			
29SECURE IN TENT	779 T2	2 28T17 779	
00000			
TASK 03 DAY 173 12/07/68			
1SECURE IN TENT	1440 T2	2 29T171440	
00000			
TASK 04 DAY 174 12/08/68			
1SECURE IN TENT	1440 T2	3 1T171440	
00000			
TASK 05 DAY 175 12/09/68			
1SECURE IN TENT	1440 T2	4 1T171440	
00000			
TASK 06 DAY 176 12/10/68			
1SECURE IN TENT	39 T2	5 1T17 39	
00000			
2TURN POWER ON	1 T2	2 25T27 1	
00000			
3TEST SYSTEMS	9 1T2	T27 9	
00000			
4REM HANDLING FRAME BAY 3	16 T2 1 2	1 12R 2 5 1 515 6	
07A01X			
5REM NARR ANG TV COVER	3 1T2	2 27R 1 3	
03B12X			
6REM IRS COVER	46 2T2 1 2	1 24R 1 23 2 23	
03B16X03A01 03B			
7INST L/G ANT	51 3T2 1 2 5	I 1 26 2 25	
02A00W			
8INST IRS COVER	53 2T2 1 2	6 6I 1 27 2 26	
03B16X03A01 03B			
9REM IRS COVER	62 2T2 1 2	6 8R 1 31 2 31	
03B16X03A01 03B			
10TURN POWER OFF	22 T2	6 2T27 22	
00000			
11DEMATE CASE 7 ELECTRONIC	2 2T2	R11 2	
11B0CW11A01 11C			
12INST IRS COVER	1 2T2 1 2	6 9I 2 1	
03B16X03A01 03B			
13INST NARR ANG TV COVER	5 1T2	6 5I 1 5	
03B12X			
14REM STM PLAT	15 3T2 1 2 4 6 2	26R 2 5 1 515 5	
03B0CW03A01 01A02 15A04			
15REM IRR	25 2T2 1 2 5	1 29R 2 13 1 12	
03B06X03B07X03B 03A01			
16REM WIDE ANG TV	13 2T2 1 2 5	2 17R 2 7 1 6	
03B10X03B11X03B16 03B12 03B09 03B01 03B02 03B03 03B04 03B05 03A01			
17REM NARR ANG TV	2 2T2	2 16R 2 1 1 1	
03B12X03B13X03B14X03B16 03B08 03B01 03B02 03B03 03B04 03B05 03A01			

18TURN POWER ON 00000	17 T2	6 10T27 17			
19PREP TO REM TV MODS 00000	1 2T2	2 14T27 1			
20REM EMI SOURCE 00000	1 2T2	6 7R27 1			
21REM BATT 12B06X01B05X12A01	8 2T2 1 2 5	R 2 4 1 4			
22REM TV CONSOLS 11B05X11B06X11B07X11B08X11B01	5 2T2 1 2 5	2 15R 2 3 1 2			
23INST SIT 01B05X12A01	93 2T2 1 2	I 1 47 2 46			
24TURN POWER OFF 00000	10 T2	T27 10			
25SECURE IN TENT 00000	940 T2	6 24T17 940			
TASK 07 DAY 177 12/11/68					
1PREP TO TURN POWER ON 00000	30 T2	6 24T27 30			
2INST BATT 12B06X12A01X01B05	2 2T2 1 2 5	I 1 1 2 1			
3TURN POWER ON 00000	180 T2	7 1T27 180			
4TEST IN PROGRESS 00000	333 T2	T27 333			
5TURN POWER OFF 00000	25 T2	7 3T27 25			
6SECURE IN TENT 00000	870 T2	T17 870			
TASK 08 DAY 178 12/12/68					
1SECURE IN TENT 00000	12 T2	7 6T17 12			
2TURN POWER ON 00000	438 T2	7 5T27 438			
3TURN POWER OFF 00000	2 T2	8 2T 1 2			
4PREP TO CHANGE TCFM 00000	11 2T2	T27 11			
5REM HARNESS 05C03X05C 05B 05A01	10 2T2 1 2 512	R 2 2 1 311 214 3			
6REM/INST TCFM MODS 05B09X05B09X05B 05C01 05C02 05C04 05C05 05A01	17 2T2 1 2 5	X 1 9 2 8			
7INST TCFM HARN 05C03X05C 05B 05A01	13 2T2 1 2 5	I 2 3 1 311 314 4			
8SECURE IN TENT 00000	937 T2	8 7T17 937			
TASK 09 DAY 179 12/13/68					
1SECURE IN TENT 00000	15 T2	8 8T17 15			
2TURN POWER ON 00000	357 T2	8 3T27 357			
3INST SWITCH 02C03X10B	8 2T2 1 2	I 1 4 2 4			
4INST CABLE CASE 6 02A02X10C02X10C03X10C04X01B06X10B 10C01 10A01	12 3T2	I 1 3 2 311 314 3			
5TURN POWER OFF 00000	2 T2	9 2T27 2			
6TEST CONN CASE 6 10B X10C01X10A01	25 2T2	T11 25			
7PREP TO REMOVE CASE 5 00000	19 2T2	1 11T27 19			
8REM BATT	1 2T2 1 2	7 2R 2 1			

[illegible]

03B12X03B	SINST NARR ANG TV COVER	5	1T2			13	4I 1	5							
03B12X03B	6TURN POWER OFF	5	T2			13	3T27	5							
00000	7SECURE IN TENT	870	T2			13	6T17	870							
00000	TASK 14 DAY 184 12/18/68														
	1PREP TO REMOVE IRR	30	T2			12	8T27	30							
00000	2REM IRR	10	2T2	1	2	5	14	1R 2	5	1	5				
03B06X03B07X	3TURN POWER ON	280	T2			13	6T27	280							
00000	4TURN POWER OFF	30	T2			14	3T27	30							
00000	5INST IRR	10	2T2	1	2	5	14	2I 1	5	2	5				
03B06X03B07X	6INST SCI STIM PLAT	5	3T2	1	2	4	6	I 1	2	2	215	1			
03B00W03A01	7TURN POWER ON	205	T2			14	4T27	205							
00000	8TURN POWER OFF	60	T2			14	7T27	60							
00000	9SECURE IN TENT	810	T2			14	8T17	810							
00000	TASK 15 DAY 185 12/19/68														
	1SECURE IN TENT	35	T2			14	9T17	35							
00000	2INST NARR ANG TV COVER	15	1T2			14	6I 1	15							
03B12X03B	3REM IRR ASSY	5	2T2	1	2	5	14	5R 2	2	1	3				
03B06X03B07X03B	4REM SCI STIM PLAT	105	3T2	1	2	4	614	6R 2	35	1	3515	35			
03B 03A01 01A02 15A04	5INST LEAK CK ON IRS	20	1T2			6	9I10	1027	10						
00000	6REPLACE IRS VALVES	265	2T2	1	2	4	515	5T 1	90	2	9010	85			
03B16X03B15X03A01 03B 01A02 15A04	7DEMATE CONN	5	2T2			15	6T11	5							
03B10X03B12X	8REM TVS	15	2T2	1	2	5	R 2	5	1	526	5				
03B10X03B11X03B12X03B13X03B14X03A01	9REM CASE 7 MODS TV	50	2T2			12	5R 2	20	1	2026	10				
11B05X11B06X11B07X11B08X11B01 11B02 11B03 11B04 11C 11AD1	10CLEAN IRS VALVE	5	2T2			15	6T 6	5							
03B16X03B15X	11SECURE IN TENT	920	T2			15	10T17	920							
00000	TASK 16 DAY 186 12/20/68														
	1SECURE IN TENT	25	T2			15	11T17	25							
00000	2INST NARR ANG TV	5	2T2	1	2	5	I 1	3	2	2					
03B10X03B11X	3INST WIDE ANG TV	12	T2	1	2	5	I 2	6	1	6					
03B12X03B13X03B14X	4INST TV POWER SUPPLY	103	2T2	1	2	5	I 1	52	2	51					
11B05X11B06X11B07X11B08X11B01 11B02 11B03 11B04 11A01 11C	5SOLDER IRS WIRES	15	2T21113			15	10T 1	5	2	5	8	5			
03B15X03B16	6SET UP TEST EQUIP	5	2T2			9	11T 1	315	2						
03B X															

7	RESOLDER IRS WIRES	195	2T2	16	5T 1	50	2	50	8	95	A102
03815X03816											
8	INST NARR ANG TV COVER	10	1T2	16	6I 1	10					
03812X											
9	DEMATE WIDE ANG TV	2	2T2	16	2T11	2					
03910X											
10	DEMATE NARR ANG TV	13	2T2	16	6T11	13					
03812X											
11	MATE BREAKOUT BOX	10	T2		127	10					
00000											
12	TURN POWER ON	47	T2	14	8T27	47					
00000											
13	TURN POWER OFF	3	T2	16	12T27	3					
00000											
14	DEMATE BREAKOUT BOX	15	T2	16	11T27	15					
00000											
15	TURN POWER ON	50	T2	16	13T27	50					
00000											
16	TURN POWER OFF	10	T2	16	15T27	10					
00000											
17	REM WIDE ANG TV	5	2T2 1 2 5	16	9R 2	3	1	2			
03810X03811X											
18	REM NARR ANG TV	10	2T2 1 2 5	16	10R 2	5	1	5			
03812X03813X03814X											
19	REM CASE 7 MODS	49	2T2 1 2 5	15	9R 2	24	1	25			
11B05X11B06X11B07X11B08X11B01		11B02	11B03	11B04	11C	11A01					
20	TEST IRS	10	T2	16	7T10	10					
00000											
21	SECURE IN TENT	846	T2	16	20T17	846					
00000											
TASK 17	DAY 187 12/21/68										
1	SECURE IN TENT	1440	T2	16	21T17	1440					
00000											
TASK 18	DAY 188 12/22/68										
1	SECURE IN TENT	1440	T2	17	1T17	1440					
00000											
TASK 19	DAY 189 12/23/68										
1	SECURE IN TENT	70	T2	18	1T17	70					
00000											
2	REM OSE STIM	2	2T2 1 2	1	14R 1	1	2	1			
03803X											
3	INST FLT HOOD	1	1T2 1 2		R 2	1					
14A57X											
4	REM STIM UVS	1	1T2 1 2		R 2	1	1				
03808X											
5	INST UVS COVER	1	1T2		I 1	1					
03808X											
6	REM STIM MARS GATE	55	2T2 1 2	1	27R						

00000

14SECURE IN TENT

865 T2

19 13T17 865

00000

STAGE 8 PREPERATION FOR SHIPMENT , SHIP TO CAPE

TASK 01 DAY 190 12/24/68

1SECURE IN TENT

15 T2

T17 15

00000

2REM GYRO CONTROL

15 2T2 1 2 5

R 2 7 1 8

07B06XD7B D7C 07AD5 07AD1

3REM PROP UNIT

15 3T2 1 2 4 6

R 2 5 1 5 5 5

06ADDWD6B00WD6C00WD6D00W

4REM CASE 3 PINS

5 2T2 1 2 5

R 2 3 1 2

07AD1X

5REM CANOPUS SENSOR

5 2T2 1 2 5

R 2 3 1 2

13B08X13B09X13B10X13B11X

6INST SHEAR PLATE

85 2T2 1 2 5

I 2 43 1 42

07AD3X07AD1X

7INST CASE 4

10 2T2 1 2 5

I 1 5 2 5

08AD1X08B 08C

8INST CASE 5

15 2T2 1 2 5

I 1 7 2 8

09AD1X09B 09C

9INST CASE 8

15 2T2 1 2 5

I 1 8 2 7

12AD1X12B 12C

10INST CASE 1

15 2T2 1 2 5

I 1 8 2 7

05AD1X05B 05C

11SECURE IN TENT

1245 T2

1 10T171245

00000

TASK 02 DAY 191 12/25/68

1SECURE IN TENT

1440 T2

T171440

00000

TASK 03 DAY 192 12/26/68

1PREP S/C FOR SHIPMENT

50 4T2

T30 50

01AD2X

2REM CASE 7 PINS DAS MODS

25 1T211

R 2 13 1 12

11B01X11B02X11B03X11B04X11AD1 11C

3INST SHEAR PLATE CASE 7

15 2T2 1 2 5

I 1 7 2 8

11AD3X11AD1

4INST BAY 2 SHIELD

75 2T2 1 2 5

R 2 38 1 37

06D03X06B

5INST DUMMY PLATE CASE 6

20 2T2 1 2 5

1 7R 2 10 1 10

10AD1X10A

6TORQUE @V@ BAND

160 1T2 5

I 2 160

01AD2X

7WRAP S/C

30 3T2

T29 30

01AD1X13AD1 13AD9

8INST H/G ANTENNA

55 3T2 1 2 5

I 1 28 2 27

02C00W

9INST TENT FRAME/SHIP

45 4T2 2 4 6

I 1 23 2 22

01AD1X13AD1 13AD9 02C

10INST COVER

5 4T2

I29 5

01AD1X13AD1 13AD9

11MOVE S/C TO VERT POS

30 T2

3 7T16 30

00000

12SECURE IN TENT

930 T2

3 11T17 930

00000

TASK 04 DAY 193 12/27/68

1PREP TO MOVE S/C TO TRAN

75 H2

3 11T15 3816 37

00000

2INST S/C ON TRANSPORTER

195 H2

4 1116 100 3 95

00000

3SECURE IN SHIP

1170 N5

4 2T311170

00000

TASK 05 DAY 194 12/28/68									
1SECURE IN SHIP	1440	N5	4	3T311440					
00000									
TASK 06 DAY 195 12/29/68									
1SECURE IN SHIP	1440	N5	5	1T311440					
00000									
TASK 07 DAY 196 12/30/68									
1SECURE IN SHIP	45	N5	6	1T31	45				
00000									
2REM S/C FROM TRANSPORTER	20	4T2	4	2R 3	1016	10			
01A01X13A01 13A09 02C									
3PREP TO LOWER SCAN PLAT	20	T2		T27	20				
00000									
4DEMATE SCAN PLAT HARN	40	2T2 1 2 5	7	3T11	40				
05C04X05B X15A01X15A02X15A03X03B15 03B16 03B01				03B02	03B03				
5DEPRESS SCAN PLAT	5	2T2	7	3T27	5				
00000									
6LOWER SCAN PLAT	10	3T2	7	5T 1	10				
01A19X01A20X01A21X01801X01802X03A01X									
7REM CLOCK ACTUATOR	85	2T2 1 2 5	7	6R 2	43 1	42			
03B04X01A02 02C									
8REM SCAN PLAT HARN	105	3T2 1 2 5 12 7	4R 2	26 1	2611	2714	26		
05C04X05B00W15A01X15A02X15A03X03B15 03B16 03B01				03B02	03B03				
9INST CLOCK ACTUATOR	1	2T2 1 2 5	7	7I 2	1				
03B04X									
10PREP TO SHIP S/C	9	4T2	7	9T30	9				
01A01X									
11RAISE SCAN PLAT	1	2T2	7	10T15	1				
03A01X									
12PRESS SCAN PLAT	9	2T2	7	5T27	9				
00000									
13STOP PRESSURIZATION	15	T2	7	12T27	15				
00000									
14RAISE S/C TO VERT POS	5	T2	7	13T16	5				
00000									
15LOWER S/C TO TRANSPORTER	5	H2	7	14T16	3 3	2			
01A01X13A01 13A09 02C									
16COVER S/C START PURGE	10	N2		T29	10				
01A01X13A01 13A09 02C									
17SECURE IN SHIP	1055	N2	7	16T311055					
00000									
TASK 08 DAY 197 12/31/68									
1TRANSPORT S/C	1440	N5	7	17T211440					
00000									
TASK 09 DAY 198 01/01/69									
1TRANSPORT S/C	1440	N5	8	1T211440					
00000									
TASK 10 DAY 199 01/02/69									
1TRANSPORT S/C	1440	N5	9	1T211440					
00000									
TASK 11 DAY 200 01/03/69									
1TRANSPORT S/C	1440	N5	10	1T211440					
TASK 12 DAY 201 01/04/69									
1TRANSPORT S/C	1440	N5	11	1T211440					
00000									
TASK 13 DAY 202 01/05/69									
1TRANSPORT S/C	1440	N5	12	1T211440					
00000									
STAGE 9 SYSTEM TEST AND (AO OPERATIONS) CHECKOUT, PREPERATION									
TASK 01 DAY 203 01/06/69									
1SEC S/C IN AO HANGER	122	02		T27	122				

00000	2REM S/C FROM VAN	268 02	1 1R27 268			
00000	3SEC S/C IN AO HIGH BAY	2 02	1 2T27 2			
00000	4PREP TO MOVE S/C TO POS	40 02	1 3T27 40			
00000	5SEC S/C ON POSITIONER	18 02	1 4T16 9 3 9			
00000	6REM PLASTIC CAGE COVER	2 02	1 5R 3 1 1 1			
00000	7PREP TO REMOVE CAGE	2 02	1 6T27 2			
00000	8REM CAGE	18 402 1 4 6	1 7R29 18			
01A01X13A01 13A09 02C	9CK SCAN PRESS	1 0210	T10 1			
00000	10VACUUM OSE EQUIP	7 02	T27 7			
00000	11SECURE IN AO HIGH BAY	960 02	1 10T22 960			
00000	TASK 02 DAY 204 01/07/69					
00000	1SECURE IN AO HIGH BAY	62 02	1 11T22 62			
00000	2VACUUM L/G ANT	13 302	T 7 13			
02A X02B X	3BLEED SCAN PLAT	1 102	T27 1			
00000	4REM S/C PLASTIC COVER	6 402	R29 6			
01A01X13A01 13A09 02C	5REM SAFETY LOCKS	8 102	2 4R27 8			
00000	6BLEED SCAN PLAT SYS	2 102	2 3T27 2			
00000	7LOWER SCAN PLAT	1 302 1 2 5	T12 1			
01A19X01A20X01A22X01B01X01B02X01A01	8REM MONO TELE	49 202 1 2	R 2 25 1 24			
03B15X03B16X03B17X03A01 03B01 03B02 03B03	9ROUT SCAN PLAT HARN	10 202 1 2 5	R 2 5 1 5			
15B00W03A01	10REM IRS VENT ASSY	10 202	2 7R 2 5 1 5			
03B17X03B15X03B01 03B02 03B03 03A01 01A02	11REM UVS	30 202 1 2 5	R 2 15 1 15			
03B08X03B09X03A01 15A04 01A02	12REM CLOCK ACTUATOR	3 202 1 2 5	R 2 2 1 1			
03B04X02C	13INST SCAN PLAT HARN	115 302 1 2 5	I 1 30 2 3011 3014 25			
15B00W03A01X03B01 03B02 03B03 15A01 15A02 15A03 15A04 01A02	14INSP CRACKED CABLE	2 202	T 9 2			
00000	15CALIBRATE RADIO	10 0210	T10 10			
00000	16INST HARN	48 302 1 2 5	I 1 12 2 1211 1214 12			
15B00W03A01X03B01 03B02 03B03 15A01 15A02 15A03 15A04 01A02	17CONN SCI HARN AT TRAY	60 202 1 2 5	I 2 30 1 30			
15B03X15A03X15B01 15B02 15B04 15B05 15A01 15A02	18INST SCAN PLAT HARNESS	32 02 1 2 5	I 1 8 2 811 814 8			
15B00W03A01X03B01 03B02 03B03 15A01 15A02 15A03 15A04 01A02	19SECURE IN AO HIGH BAY	978 02	T22 978			
00000	TASK 03 DAY 205 01/08/69					
00000	1SECURE IN AO HIGH BAY	120 02	2 19T22 120			

00000		42	02	1	5T16	42		
2TILT S/C								
00000								
3INST SCAN PLAT HARN		10	302		I 1	2 2	311	214 3
15BC0W03A01X03B01 03B02 03B03		15A01	15A02	15A03	15A04	01A02		
4INST IRR ASSV		33	202 1 2 5		I 1	17 2	16	
03BC6X03B07X03B01 03B02 03B03		03A01						
5INST L/G ANTENNA		5	302 1 2 5	2	8I 1	3 2	2	
02A01X02C 13A01 13A09 02A02X								
6INST L/G DAMPER		2	202 1 2 5	3	5I 1	1 2	1	
07A03X02A01 02A02 02B								
7INST L/G DAMPER		1	202 1 2 5	3	5I 2	1		
02A04X02A 02B 02C								
8REM THERM SHIELD CASE 2		33	202 1 2 5		R 2	17 1	16	
06D03X06B								
9REM CASE 4 SHEAR PLATE		9	102 1 2 5	3	8R 2	5 1	4	
08A01X								
10REM CASE 3/7 SHEAR PLATE		2	102 1 2 5		R 2	1 1	1	
07A01 07A03X11A03X11A01								
11PREP TO INST HARDWARE		2	202		T27	2		
00000								
12INST RAILS CASE 3		28	202 1 2 5		I 2	14 1	14	
07A01X07A05X07B 07C								
13INST GYRO CONTROL		3	202 1 2 5		I 1	2 2	1	
07B06X07B 07C 07A01 07A05								
14INST INTERNAL SCREWS		48	202 5		I 1	24 2	24	
07B05X07B 07C 07A01 07A05								
15INST TV POWER SUPPLY		3	202 1 2 5		I 1	2 2	1	
11B05X11B01 11B02 11B03 11B04		11A01	11C					
16INST TV DATA CONVERTER		4	202 1 2 5		I 1	2 2	2	
11B06X11B01 11B02 11B03 11B04		11B05	11A01 11C					
17INST TV CAMERA DRIVER		11	202 1 2 5		I 1	6 2	5	
11B07X11B01 11B02 11B03 11B04		11B05	11B06 11A01 11C					
18INST TV CONTROL ASSV		5	202 1 2 5		I 1	3 2	2	
11B08X11B01 11B02 11B03 11B04		11B05	11B06 11B07 11A01 11C					
19INST CASE 3 SHEAR PLATE		5	202 1 2 5	3	12I 1	3 2	2	
07A03X07A01 07A05 07B06								
20VERIFY TORQUE		30	202 5	3	19I 1	15 2	15	
07A03X11A03X								
21SECURE IN A0 HIGH BAY		1044	02	3	20I221044			
00000								
TASK 04 DAY 206 01/09/69								
1VACCU CASE 6		32	202		T 7	32		
10A01X10B X10C X								
2CLEAN CASE 6		30	202	4	1T 6	30		
10A01X10B X10C X								
3SPlice XDUC CABLE		30	2021112	2	10T 1	10 2	1014 10	
03B21X03B22X								
3INSTALL PARTS		0			I			
02C00W								
4INST CLOCK ACTUATOR		60	202 1 2 5	2	12I 1	30 2	30	
03B01X03B02 03B03 03B06 03B07		03A01						
5TORQUE SCAN PLAT STRUCT		43	202 5	3	3I 2	43		
03A02X03A01 03B01 03B02								

10CAST HARNESSSES	15 30215	112 10 2 5	
15A07X			
11PREP TO INST UVS	30 202	2 11T 7 30	
03B08X03B09X			
12INST UVS	30 202 1 2 5	4 11I 1 15 2 15	
03B08X03B09X03B 03A01			
13CABLE UP S/C /OSE	30 202	127 30	
00000			
14TORQUE SCI EQUIP	210 202 5	4 12I 2 210	
03B00W03A01			
15SECURE IN A0 HIGH BAY	780 02	4 14T22 780	
00000			
TASK 05 DAY 207 01/10/69			
1TIE CABLES	30 202 1 2 512 4	9I 1 8 2 811 714 7	
15B00W03A01 03B			
2INST OSE HOODS	30 202 1	I 1 15 2 15	
03B01X03B02X03B03X			
3REM H/G FROM S/C	2 202 1 2 5	R 2 1 1 1	
02CC0W02A 02B			
4INST CANOPUS SENSOR	30 202 1 2	I 1 15 2 15	
13B08X13B09X13B10X13B11X			
5INST OSE CABLES	628 02	127 628	
00000			
6SECURE IN A0 HIGH BAY	720 02	5 5T22 720	
00000			
TASK 06 DAY 208 01/11/69			
1SECURE IN A0 HIGH BAY	237 02	5 6T22 237	
00000			
2INST PROP UNIT	103 202 1 2 4 6	I 1 45 2 45 7 13	
06A00W06B00W06C00W06D00W			
3SECURE IN A0 HIGH BAY	1100 02	6 2T221100	
00000			
TASK 07 DAY 209 01/12/69			
1SECURE IN A0 HIGH BAY	1440 02	6 3T221440	
00000			
TASK 08 DAY 210 01/13/69			
1SECURE IN A0 HIGH BAY	1440 02	7 1T221440	
TASK 09 DAY 211 01/14/69			
1CABLE UP S/C OSE	15 302	4 13T27 15	
00000			
2INST NARR ANG B08	38 202	4 7I27 38	
00000			
3TURN POWER ON	267 02	127 267	
00000			
4PRESS A/C SYSTEM 7G1	10 102	T10 527 5	
00000			
5PRESS A/C SYST 7G2	20 102	9 4T10 1027 10	
00000			
6TORQUE A/C 282 NUTS 7G1	5 202 5	9 4T 2 5	
13A01X13A09 01A01			
7TORQUE A/C 7G2 282 NUTS	5 202 5	9 5T 2 5	
13A01X13A09 01A01			
8CABLE UP OSE	31 202	5 1R27 31	
00000			
9CLEAN NARR ANG TV CONN	31 202	T 6 31	
05C04X			
10INSP CAMERA PIN	8 202	9 10T 9 8	
05C04X			
11TURN POWER OFF	85 02	9 3T27 85	
00000			
12INST NARR ANG TV COVER	15 102	4 7I 1 15	

3INST CC+S HARN	15 202 1 2 5 112	21 1	7 2	211	314	3
07C03X07C01X07C02 07B 07A05 07A01	92 02	11 14T27	92			
4TURN POWER ON						
00000						
5REM STIM SCI PLAT	1 302 1 2 4 6	R15	1			
03B 03A01						
6FIT/TEST CANOPUS SEN	32 202 1 2 5	5 4T 1	16 2	16		
13B08X13B09X13B10X13B11X						
7MEASURE CANOPUS SENSOR	25 02	12 6T27	25			
00000						
8MATE CASE 6 CABLE	15 202 1 2	4 8I 1	5 2	511	5	
10C02X10C03X10C04X						
9REM CABLE CASE 6	2 202 1 2	12 8R 2	1 1	1		
10C02X10C03X10C04X						
10MATE CASE 6 CABLE	58 202 1 2	12 9I 1	20 2	1911	19	
10C02X10C03X10C04X						
11MOVE S/C	15 02	4 5T16	15			
01A01						
12ALIGN SCAN PLAT	15 20210	12 11T10	15			
03A01X03B						
13TERMINATE ALIGNMENT	12 0210	12 12T10	12			
03A01X03B						
14REM NARR ANG TV COVER	3 02	11 13R 1	3			
03B12X						
15PREP TO ALIGN TV	1 02	12 15T27	1			
00000						
16PREP TO ALIGN IRS	1 02	9 15T27	1			
00000						
17INST NARR ANG TV COVER	10 102	12 14I 1	10			
03B12X						
18INSP MONO TEL	98 202	11 11T 9	98			
03B15X03B 03A01						
19ALIGN IRS /TV	42 20210	12 15T10	42			
03B12X03B15X03B 03A01						
20COMPLETE NARR ANG ALIGN	6 20210	12 19T10	6			
03B12X03B 03A01						
21REM WIDE ANG TV COV/ALGN	52 10210	11 12R 1	2210	30		
03B10X03B 03A01						
22INST WIDE ANG TV COVER	20 102	12 21I 1	20			
03B10X						
23TURN POWER OFF	55 02	12 4T27	55			
00000						
24MATE PIN PULL CONNS	15 202	111	15			
04B08X04B04X04B05X						
25MATE PIN PULL CONNS	21 202	111	21			
04B08X04B06X04B07X						
26DEMATE PROP SQUIBS/TEST	6 202	R11	527	1		
06D04X06D05X06D06X06D07X						
27MATE/TEST PROP SQUIBS	20 202	111	1627	4		
06D04X06D05X06D06X06D07X						
28MATE PYRO HARN/PYRO MOD	15 202 1 2 5	1 1	5 2	511	5	
05B01X05B02X05C05X04B10 04B11 06D04 06D05 06D06 06D07						
29SECURE IN AO HIGH BAY	778 02	12 28T22	778			
00000						
TASK 13 DAY 215 01/18/69						
1SECURE IN AO HIGH BAY	1440 02	12 29T22	1440			
00000						
TASK 14 DAY 216 01/19/69						
1SECURE IN AO HIGH BAY	1440 02	13 1T22	1440			
00000						
TASK 15 DAY 217 01/20/69						
1ALIGN CK OF SCI INSTRU	15 102	4 14T27	15			

00000	2INSP BREAKOUT BOX	10 102	T27	10		
00000	3INSP CONN	5 102	T27	5		
00000	4INSP CABLES OSE	1 102	15 2T27	1		
00000	5MATE MONO TEL	10 202	12 18I11	10		
03B15X	6TURN POWER ON	13 02	12 23T27	13		
00000	7INSP BREAKOUT CABLE	5 02	15 4T27	5		
00000	8MATE BREAKOUT BOX TO IRR	17 02	15 5I27	17		
00000	9REM IRR STIM	8 102 1 2	15 8R 2	4 1	4	
03B06X03B07X	10REM IRR COVER	65 102 1	15 7R 1	65		
03B06X	11REM MONO TEL DUST COVER	2 102 1	15 5R 1	2		
03B15X	12INST IRR MIRROR COVER	10 102 1 2	3 4I 1	5 2	5	
03B06X03B07X	13INST IRR STIM	63 202 1 2	15 9I 1	32 2	31	
03B06X03B07X03B	03A01	2 20210	15 11T10	2		
00000	14ALIGN MONO TEL	58 102 1	15 14I 1	827	50	
03B15X03B16X03B17X03B	03A01	3 102 1	4 12I 1	2 2	1	
03B06X03B09X	17TURN POWER OFF	37 02	15 6T27	37		
00000	18REM OSE HOODS	5 102 1	5 2R 2	3 1	2	
03B01X03B02X	19MATE MONO TEL BENDIX	5 102	15 5I11	5		
03B15X	20MATE CABLE TO IRR ASSY	5 102	15 8I11	5		
03B06X03B07X	21ALIGN MARS GATES	2 202	T27	2		
00000	22REM FEPS HOOD	1 102 1	R 1	1		
03B03X	23INST FEPS HOOD	47 102 1 2	15 22I 1	24 2	23	
03B03X	24TURN POWER ON	40 02	15 17T27	40		
00000	25MATE MONO TEL EXT/TEST	132 202	15 20I11	1027	122	
03B15X	26UNLATCH PAS	8 102 1 2	T 1	4 2	4	
03B06X	27ROTATE S/C	35 102	1 5T16	35		
00000	28ALIGN MARS GATE	85 20210	15 21T10	85		
00000	29COMPLETE ALIGNMENT	30 20210	15 28T10	30		
00000	30TURN POWER OFF	10 02	15 24T27	10		
00000	31TURN POWER ON	10 02	15 30T27	10		
00000	32CONN CASE 1 CABLES/OSE	11 202	I27	11		

00000							
33TURN POWER OFF	9	02		15	31T27	9	
00000							
34TEST LEAK A/C GAS SYS	5	20210			T10	5	
00000							
35REM FEPS HOOD	25	102 1 2		15	23R 1	13 2	12
03B03X							
36REM SHEAR PLATE	29	102 1 2 5		3	10R 1	15 2	14
11A01X11A03X11B 11C							
37REM BATT	6	202 1 2 5		11	3R 2	2 1	226 2
12B06X12A01 01B05							
38REM TV MODS CASE 7	5	202 1 2 5		3	18R 2	3 1	2
11B05X11B06X11B07X11B08X11B	11A01 11C						
39PIN RETENTION CHECK	35	20210		15	36T10	35	
11C03X11B05X11B06X11B07X11B08X							
40INST OSE HOODS	5	202 1 2		15	18I 1	3 2	2
03B01X03B02X							
41VACUUM CASE 7 TV MODS	2	202		15	39T 7	2	
11B05X11B06X11B07X11B08X							
42INST TV MODS CASE 7	43	202 1 2 5		15	38I 1	22 2	21
11B05X11B06X11B07X11B08X11B	11A01 11C						
43REM GUIDE PINS CASE 7	10	10211		15	39R 2	5 1	5
11C00W							
44INST SHEAR PLATE CASE 7	2	202 1 2 5		3	10I 1	1 2	1
11A03X							
45INST BATT	13	202 1 2 5		15	37I 1	7 2	6
12B06X12A01 01B05X							
46SECURE IN AO HIGH BAY	501	02		15	45T22	501	
00000							
TASK 16 DAY 218 01/21/69							
1MATE OSE CABLE TO BATT	15	202		15	45I11	15	
12B06X01B05X							
2TURN POWER ON	2	02		15	33T27	2	
00000							
3INST TEST EQUIP	33	202		15	42I15	33	
03B 803A01							
4REM NARR ANG TV COVER	100	102 1		12	17R 1	100	
03B12X							
5MATE OSE CABLES TO FEPS	305	102		16	11I11	305	
03B03X							
6MATE OSE CAB TO MARS GAT	305	102		16	51I11	305	
03B01X03B02X							
7COMP TV CAMERA TEST	1	102		16	47I15	1	
00000							
8INST NARR ANG TV COVER	14	102		16	7I 1	14	
03B12X							
9TURN POWER OFF	4	02		16	2T27	4	
00000							
10REM SHEAR PLATE CASE 3	1	202 1 2 5		3	19R 2	1	
07A03X07A01X07A05							
11REM BACK SCREWS CS 3/MOD	6	202 1 2 5		16	10R 2	3 1	3
07B05X07B06X07C 07B 07A05							
12CONN RADIO BOX CASE 6	2	102		12	10I11	2	
10C01X							
13INST GYRO CONT	2	202 1 2 5		3	13I 2	1 1	1
07B06X07B 07C 07A05 07A01							
14REM ATT CONTROL MOD	1	102 1 2 5			R 2	1	
07B05X07B 07C							
15REM GYRO CONT	14	202 1 2 5		16	11T 1	7 2	7
07B06X07B 07C 07A05 07A01							
16INST GYRO CONTROL	4	202 1 2 5		16	13I 1	2 2	2
07B06X07B 07C 07A05 07A01							

17INST ATT CONTROL MODS	6 102 1 2 5	16 14I 1	3 2	3	
07B05X07B 07C					
18REM ATT CONT OSE SHELF	12 202	16 17R27	12		
00000					
19REM GUIDE PINS A/C MOD	1 10211	16 16R 2	1		
07B05X07B 07C 07A01 07A05					
20VACUUM CASE 3	3 102	16 15T 7	3		
07A01X07A05X07B X07C X					
21INST SHEAR PLATE CASE 3	44 202 1 2 5	16 10I 1	22 2	22	
07A03X07A01 07A05 07B06					
22TURN POWER ON	20 02	16 9T27	20		
00000					
23TURN POWER OFF	4 02	16 22T27	4		
00000					
24DEMATE RADIO CASE 6	37 202	16 12T11	37		
10C01X					
25LATCH PAS	1 102	15 26T 1	1		
01B06X					
26TURN POWER ON	203 02	16 23T 1	203		
00000					
27TURN POWER OFF	30 02	16 26T 1	30		
00000					
28SECURE IN A0 HIGH BAY	270 02	16 27T22	270		
00000					
TASK 17 DAY 219 01/22/69					
1SECURE IN A0 HIGH BAY	40 02	16 28T22	40		
00000					
2INSP RADIO BOB	10 02	16 24I27	10		
00000					
3TURN POWER ON	85 02	16 27T27	85		
00000					
4TEST TCFM /INST	3 202 1 2 5	T 1	2 2	1	
05B08X05B09X05B 05C02X05C	05A01				
5TORQ CASE SCREWS	84 02 5	R 2	84		
05A01X					
6TURN POWER OFF	13 02	17 3T27	13		
00000					
7REM/INST TCFM HARN	5 202 1 2 512	X 2	2 1	111 114	1
05C03X05C 05B 05A01					
8REM/INST TCFM MODS	35 102 1 2 5	X 1	18 2	17	
05B06X05B09X05B 05C 05A01					
8INSTALL PARTS	0	I			
05B00W					
9REM TCFM XDUCER	10 202 1 2 5	17 4R 2	5 1	5	
02B01X02B02 02A 02C					
10INST TCFM XDUCER	35 202 1 2 5	17 9I 1	18 2	17	
02B01 02B02 02A 02C					
11TURN POWER ON	39 02	17 6T27	39		
00000					
12UNLATCH PAS	1 102	16 25T 1	1		
01B06X					
13LATCH PAS	1 102	17 12T 1	1		
01B06X					
14ARM SIT SWITCH	14 102	I 1	14		
01B05X					
15TEST TCFM	240 202	17 10T27	240		
00000					
16TEST SYSTEMS	320 202	T27	320		
00000					
17TURN POWER OFF	20 02	17 11T27	20		
00000					
18CONN BREAKOUT BOX/05E	10 202	15 8I27	10		

DESCRIPTION	QTY	UNIT	DATE	TIME	LOCATION	STATUS	REMARKS
00000							
19DEMATE A/C GAS SYSTEMOSE	4	202		15 34T11	4		
00000							
20TURN POWER ON	21	02		17 17T27	21		
00000							
21TURN POWER OFF	25	02		17 20T27	25		
00000							
22CONN A/C GAS FRAMES	14	202 1 2 5		17 19T11	7 2	7	
13A01X13A09X							
23CONN CABLE /INST FILTER	1	202		17 22T27	1		
00000							
24PREP TO REM A/C VAL/7G1	8	202		17 22T27	8		
00000							
25VENT PRESS 7G1	3	102		17 23T27	3		
00000							
26VENT PRESS 7G1	3	102		17 25T27	3		
00000							
27REM A/C VALVE 7G1	21	202 1 2 5		17 24R 2	11 1	10	
13A03X13A01							
28CLEAN VALVE 7G1	23	202		17 27T 6	12 7	11	
13A03X							
29INST VALVE 7G1	11	02 1 2 5		17 28I 1	6 2	5	
13A03X13A01							
30PRESS A/C GAS SYS 7G1	3	02		17 29T27	3		
00000							
31CK VALVE LEAK 7G1	2	102		17 30T10	127	1	
00000							
32VENT PRESS 7G1 TORQ MAN	16	202 1 2 5		17 31T 1	6 2	627	4
13A03X13A01							
33REM VALVE 7G1	13	202 1 2 5		17 32R 2	7 1	6	
13A03X13A01							
34INST VALVE 7G1	12	202 1 2 5		17 33I 1	6 2	6	
13A03X13A01							
35SOLDER VALVE PINS	2	2021113		17 34I 8	2		
13A03X13A01							
36PRESS VALVE 7G1	8	02		17 35T27	8		
00000							
37DIS CONN PRESS 7G1	2	02		17 36T11	127	1	
00000							
38LOCK SCREWS 7G1	22	202 512		17 37T 1	11 2	11	
13A03X13A01							
39SEC A/C GAS SYS 7G1	21	202 1 2 5		17 38R 2	11 1	10	
13A01X13A09 01A01 02A	02B	02C					
39INSTALL PARTS	0			I			
13A00W							
40SECURE IN AO HIGH BAY	240	02		17 39T22	240		
00000							
TASK 18 DAY 220 01/23/69							
1SECURE IN AO HIGH BAY	44	02		17 40T22	44		
00000							
2TURN POWER ON	28	02		17 21T27	28		
00000							
3PREP TO REM PROP	1	102		11 15T27	1		
00000							
4REM PROP	79	202 1 2 4 618		3R 2	26 1	26 5	27
06AC0W06B00W06C00W06D00W							
5ROUT OSE CABLES	40	202		16 6T 1	2014	20	
01A02X07A03 05A01							
6TILT S/C	18	102		15 27T16	18		
00000							

8DEMATE HEATER + POW DIST	3 202	111	3	
11C04X				
9TURN POWER OFF	35 02	18	2727	35
00000				
10REM MONO TEL	20 202 1 2 5	15	5R 2	10 1 10
03B15X03B 03A01 15A04 01A02				
11REM FEPS	10 202 1 2 5	15	35R 2	5 1 5
03B03X03B				
12INST FEPS	10 202 1 2 5	18	11I 1	5 2 5
03B03X03B				
13INSP CABLES IRS	10 202	12	16T 9	10
00000				
14MATE HEATER + POW DIST	80 202	18	8I11	80
11C04X				
15REM MONO TEL FROM CAN	23 202	18	10R 1	23
03B15X03B16X03B17X03B18X03B19X				
16TURN POWER ON	112 02	18	9T27	112
00000				
17TURN POWER OFF	5 202	18	16T27	5
00000				
18INST MONO TEL COVER	22 102	18	15I 1	22
03B15X03B16X03B17X03B18X03B19X				
19INST MONO TEL	23 302	18	18I 1	12 2 11
03B15X03B16X03B17X03B18X03B19X03A01 03B				
20MATE MONO TEL CONN	7 202	18	19T11	7
05C04X15B01X				
21TURN POWER ON	18 02	18	17T27	18
00000				
22REM IRS COVER/ALIGN	70 10210	18	20R 1	1010 60
03B15X03B16X03B17X03B18X03B19X				
23TURN POWER OFF	5 02	18	21T27	5
00000				
24CLEAN FEPS	5 102	18	12T 7	5
03B03X				
25TURN POWER ON	13 02	18	23T27	13
00000				
26INST FEPS HOOD	22 102	18	24I 1	22
03B03X				
27ALIGN IRS	3 10210	18	22T10	3
00000				
28INST IRS COVER	2 102	18	27I 1	2
03B16X				
29ALIGN FEPS	55 202	18	24T10	30 1 25
03B03X				
30COMPLETE FEPS ALIGNMENT	15 20210	18	29T10	15
00000				
31INST FEPS STIM	5 102 1	18	30I 1	5
03B03X				
32REM FEPS OSE HOOD	8 102 1	18	30R 1	8
03B03X				
33TURN POWER OFF	14 02	18	25T27	14
00000				
34DEMATE FEPS OSE CABLE	8 102	18	32T27	8
00000				
35PREP TO TRANS S/C TO ESF	15 202	18	34T27	15
00000				
36REM HEATER + POW DIST	45 202	18	14R 2	23 1 22
05B07X05B				
37REM CONE	40 202	12	12R 2	20 1 20
03B05X03B 03A01 01A02 15A04				
38REM BATT	33 202 1 2 5	16	1R 2	17 1 16
12B06X01B05X12A01				

39LATCH SCAN PLAT	2 102	18 37T 1 2	
01A19X01A20X01A21X01B01X01B02X03A01 03B			
40SECURE IN AO HIGH BAY	480 02	18 39T22 480	
00000			
TASK 19 DAY 221 01/24/69			
1PREP TO MOVE S/C V-BAND	50 202 1 2 5	1 8T 1 20 2 2016 10	
01A24X			
2SEC CAGE ADAPT	10 402 1 2 5	19 1T 2 3 1 415 3	
01A01 13A01 13A09 02A 02B	02C		
3SEC LIFTING CABLES	12 402	19 2T 3 616 6	
01A01 13A01 13A09 02A 02B	02C		
4VACUUM TRANSPORTER	2 02	127 2	
00000			
5SLOWER S/C TO TRANSPORTER	3 02	19 4T16 2 3 1	
01A01 13A01 13A09 02A 02B	02C		
6SEC TO TRANSPORTER	4 402 5	19 5T 1 2 2 2	
01A01 13A01 13A09 02A 02B	02C		
7INST CLAM SHELL	1 402 1 2 5	19 6I29 1	
01A01X			
8SEC CLAM SHELL TO TRANSP	1 402	19 7I29 1	
01A01X			
9INST TARP	9 402	19 8I29 9	
01A01X			
10START PURGE	28 2N5	19 9T27 28	
00000			
11TRANSPORT TO ESF	40 2N5	19 10T21 40	
00000			
12VACUUM TRANSPORTER	5 2N5	19 11T27 5	
00000			
13INST BOOTIES ON TIRES	15 2N5	19 12I27 15	
00000			
14REM CLAM SHELL	4 4F2 1 2 5	19 7R29 4	
01A01 13A01 13A09 02A 02B	02C		
15MOVE S/C INTO TENT	4 4F2	19 11T16 2 3 2	
01A01 13A01 13A09 02A 02B	02C		
16REM GYRO PROT COVER	71 1F2	19 1R 1 71	
07B05X07B06X07B 07C 07A01 07A05	F	I	
16INSTALL PARTS			
07A00W07B00W			
17REM ATT CONT COVER	72 1F2	19 1R 1 72	
13A01X			
18TEST A/C GAS SYSTEM	375 2F210	17 39T10 37510	
13A01X13A09X01A01 02A 02B	02C		
19SECURE IN ESF TENT	734 F2	19 18T23 734	
00000			
TASK 20 DAY 222 01/25/69			
1SECURE IN ESF TENT	1440 F2	19 19T231440	
00000			
TASK 21 DAY 223 01/26/69			
1SECURE IN ESF TENT	1440 F2	20 1T231440	
00000			
TASK 22 DAY 224 01/27/69			
1SECURE IN ESF TENT	1440 F2	21 1T231440	
00000			
TASK 23 DAY 225 01/28/69			
1SECURE IN ESF TENT	70 F2	22 1T23 70	
00000			
2STOP LEAK CK	20 F2	19 18T27 20	
00000			
3START VALVE LEAK CK	60 F2	23 2T10 60	
00000			
4COMPLETE DEPRESS	5 2F2	23 3T27 5	

00000	50EMATE PRESS LINES	15 2F2	23 4T11	927	6
00000	6STOP VALVE LEAK CK	130 2F2	23 3T27	130	
00000	7INST GAS SYS PROT COVERS	23 1F2	23 6I 1	20	
13A02X13A10X	8COVER S/C	20 4F2	23 7I29	20	
01A01 13A01 13A09 02A 02B	9MOVE S/C TO A0	02C 32 4N5	23 8T21	32	
00000	10ARRIVED A/O REC	18 4N5	23 9T21	18	
00000	11CLEAN CLAM SHELL	42 4N5	23 10T 6	21 7	21
00000	12REM CLAM SHELL	1 4N5 1 2 5	23 11R29	1	
01A01 13A01 13A09 02A 02B	13CONN S/C TO CRANE	02C 20 402	23 12T 3	1016	10
01A01 13A01 13A09 02A 02B	14LOWER S/C TO POSITIONER	02C 12 02	23 13T16	6 3	6
01A01 13A01 13A09 02A 02B	15TORQUE S/C TO LLP	02C 5 02 5	23 14I 2	5	
01A02	16REM CLAM SHELL ADAPTER	10 202 1 2 5	23 12R 2	5 1	5
01A02	17TORQ V-BAND	1 202 5	23 15T 2	1	
01A24X01A02	18REM GAS SYS PROT COVERS	4 202	23 7R 1	4	
13A02 13A10	19INST CONE ACTUATOR	25 202 1 2 5	I 1	13 2	12
03B05X03B 03A01 01A02 15A04	20INST HEAT + POW DIST MOD	10 202 1 2 5	18 36I 1	5 2	5
05B07X05B 05C 05A01	21DEMAE CASE 8 CONN	15 202	23 18T11	15	
12B01X12B04X12B02X12C01X12A01	22INST BATT	20 202 1 2 5	18 38I 1	10 2	10
12B06X01B05X12A01	23CONN CABLES OSE	1 202	T27	1	
00000	24MATE CASE 8 CONN	24 202	23 21T11	24	
12B01X12B04X12B02X12C01X12A01	25TORQUE SIT	6 102 5	17 14I 2	6	
01B05X	26INST IRR STIM	5 102 1	15 10I 1	5	
03B06X03B07X03B 03A01	27CONN BENDIX CONE AXIS	10 102	23 19T11	10	
03B05X05C04X15A01X03B 03A01	28UNLACH SCAN PLAT	6 202	18 37T 1	6	
01A19X01A2CX01A21X01B01X01B02X01B03 03A01 03B	29INST OSE STIM FRAME	8 302 1 2 4 623	17I 1	3 2	315 2
03B 03A01	30INST UVS STIM	15 102 1 2	I 1	8 2	7
03B08X03B09X03B 03A01	31REM NARR ANG TV COVER	11 102	16 8R 1	11	
03912X	32TURN POWER ON	33 02	18 33T27	33	
00000	33REM WIDE ANG TV COVER	1 102	16 15R 1	1	
03B10X	34UNLATCH PAS	30 102	17 13T 1	30	
01B06X	35LATCH PAS	65 102	23 34T 1	65	

20TORQUE H/G CABLE	22 202	24 181 2	22		
02C04X02C 02A 02B					
21TIE HARN	23 202 1 2 5	24 201 1	6 2	611	614 5
02A02X02A 02B 02C					
22DIP-DAUB SUN SENSOR	8 20215	T12	8		
13B01X13B02X13B03X13B04X13B05X13B06X13B07X					
23TURN POWER ON	47 202	23 45127	47		
00000					
24DIP-DAUB SCAN PLAT SWTCH	5 20215	23 44112	5		
04B09X					
25INST A/C NOZZLE 761	12 202 1 2 4	523 361 1	6 2	6	
13A05X13A14X13A01					
26INST A/C NOZZLE 762	13 202 1 2 4	523 361 1	7 2	6	
13A13X13A15X13A09					
27TORQ A/C SYS	45 202 5	T11	23 2	22	
13A14X13A15X13A01 13A09					
28LOCKWIRE NOZZLES	45 20212	T11	23 2	22	
13A14X13A15X13A01 13A09					
29PRESS A/C SYS	15 202	I27	15		
00000					
30TEST LEAK A/C SYS	20 10210	I10	20		
13A14X13A15X13A01 13A09					
31REM MANIFOLD ASSY	25 202 1 2 5	R 2	13 1	12	
03B23X03A 03A01					
32INST MANIF ASSY	30 202 1 2	24 291 1	15 2	15	
03B23X03A 03A01					
33TORQ MANIF ASSY	30 102 5	24 301 2	30		
03B23X03A 03A01					
34DISCONN SCAN PRESS LN	5 202	24 31127	5		
00000					
35TURN POWER OFF	129 02	24 23127	129		
00000					
36LOCK MANIFOLD ASSY WIRE	30 20212	24 311 1	15 2	15	
03B23X03B 03A01					
37SECURE IN AO HIGH BAY	355 02	24 36122	355		
00000					
38PREP FOR MONO TEL ALIGN	12 202	23 36127	12		
00000					
39TORQUE/ADJ MONO TELE	48 02 1 2 5	24 381 2	24 1	24	
03B16X03B15 03B17 03B18 03B19 03A01 03B					
TASK 25 DAY 227 01/30/69					
1SECURE IN AO HIGH BAY	11 02	24 39122	11		
00000					
2TURN POWER ON	11 02	24 35127	11		
00000					
3REM MONO TEL COVER/ALIGN	50 102 110	18 18R 1	1010	40	
03B16X03B15 03B17 03B18 03B19 03A01 03B					
4ALIGN MONO TEL	18 202	25 3110	18		
00000					
5INST MONO TEL COVER	22 102 1	25 41 1	22		
03B16X03A01 03B					
6TURN POWER OFF	81 02	25 2127	81		
00000					
7REM HARNESS	137 302 1 2 512	R 2	30 1	3011	3014 47
04B04X04B05X04B06X04B07X13A01 13A09 02A 02B 02C					
8INST FLIGHT CAPS CONN	2 102	I27	2		
00000					
9CAST CONN	41 20215	T12	41		
04B04X04B05X04B06X04B07X					
10DIP-DAUB JET VALVE	7 20215	25 26112	7		
13A05X13A03X13A11X13A13X					
11CAST CONN CASE 6	52 20215	16 24112	52		

02AD2X02CD4X09CD1X									
12DIP-DAUB SUN SENSOR	23	20215		24	22T12	23			
13B01X13B02X13B03X13B04X13B05X13B06X									
13INST BACK SCREWS CASE 3	17	202 1 2 5		16	11I 1	9 2	8		
07AD3X07AD1X									
14CAST CONN	28	20215			112	28			
07C03X07C 07B 07AD1 07A05									
150EMATE ACCESS CABLES/05E	45	202			127	45			
00000									
16CAST CASE 5 MODS	45	20215			112	45			
09B01X09B02X09B03X09B04X09B05X09B06X09B07 09B08 09B09 09C							09A		
17INST CLAMP	20	202 1 2 5			114	20			
11C01X11C 11B 11A01									
18TORQUE ALL CASES	20	202 5		25	13I 2	20			
05AD1X07AD1X08AD1X09AD1X10AD1X11AD1X12AD1X									
19REM CANOPUS SENSOR	15	202 1 2 5		12	7R 2	8 1	7		
13B08X13B09X13B10X13B11X12AD1									
20INST CANOPUS SENSOR	15	202 1 2 5		25	19I 1	7 2	8		
13B08X13B09X13B10X13B11X12AD1									
21CLEAN THERMAL SURFACE	10	202		19	1T 6	5 7	5		
05AD1X07AD1X08AD1X09AD1X10AD1X11AD1X12AD1X									
22INST PIN PULLER HARNESS	35	202 1 2 5		25	15I 1	6 2	611 614 17		
04AD0W04B04X04B05X04B06X									
23REM A/C FRAMES 05E	40	202 1 2 5		25	21T 1	13 2	1315 14		
13AD1X13A09 02A 02B 02C									
24REM NARR ANG TV COVER	28	102 1		24	11R 1	28			
03B12X									
25CLEAN NARR ANG TV	25	202		25	24T 6	25			
03B12X									
26INST NARR ANG TV COVER	7	102 1		25	25T 1	4 6	3		
03B12X									
27REM WIDE ANG TV COVER	14	102 1		23	38R 1	7 6	7		
03B10X									
28INST WIDE ANG TV COVER	16	102 1		25	27T 1	16			
03B10X									
29CLEAN SCAN PLAT	20	202		24	24T 6	20			
03AD1X03B									
30INST ANG ATTACH	35	202 1 2 5		17	10I 1	18 2	17		
14A26X									
31INST SHIELD CORNER	4	202 1 2 5		25	30I 1	2 2	2		
14A43X									
32CLEAN H/G ANTENNA	5	202		24	10T 6	5			
02C X									
33INST SHIELD CORNER	8	202 1 2 5		25	31I 1	4 2	4		
14A42X									
34INST SHIELD DAMPER	5	202 1 2 5		25	33I 1	3 2	2		
14A44X									
35INST SHIELD CORNER	9	202 1 2 5		25	33I 1	5 2	4		
14A41X14A40X									
36INST CAP PYRO MODS	1	202 1 2 5			1 2	1			
05B01X05B02X									
37INST BATT CAP	16	202 1 2 5		23	22I 1	8 2	8		
12B06X									
38INST CORNER BRACKETS	34	202 1 2 5		25	35I 1	17 2	17		
14A38X14A39X									
39INST LOUVER BRACK	14	202 1 2 5			1 1	7 2	7		
03AD1X03B									
40INST HALF LOUVER	1	202 1 2 5		25	39I 2	1			
03AD2X03AD1 03B									
41INST TC ANG ATTACHMENT	22	202 1 2 5		25	30I 1	11 2	11		
14A25X14A26X14A27X14A28X14A29X14A30X14A31X14A32X									
42INST LOUVER CASE 4/1	13	202 1 2 5		3	19I 1	7 2	6		

05A02X05AD1X08AD2X08AD1	1	202	1	2	5	15	42I 2 1
43INST LOUVER CASE 5							
09A02X09A01							
44INST TC HARDWARE	6	202	1	2	5	25	41I 1 3 2 3
14A45X14A46X14A47X14A04X14A05X							
45INST CASE 7 LOUVER	7	202	1	2	5	15	44I 1 3 2 4
11A02X11A01 11A03							
46INST CASE 8 LOUVER	10	202	1	2	5	23	24I 1 5 2 5
12A02X12A01							
47INST ALL LOUVER COVERS	9	202	1	2	5	25	46I 1 5 2 4
05A02 08A02 09A02 10A01 11A02 12A02							
48INST EAGLE SHIELD	8	202	1	2	5	I 1	4 2 4
07A02X07A03 07A01							
49INST UPPER THERMAL BLANK	47	402	1	2	5	25	47I 1 24 2 23
14A01X01A02 02A 02B 02C	13A01	13A09	14A14	14A15	14A16	14A17	14A18
490CCCLUDED ZONES						M	
14A01005A000							
50SECURE IN A0 HIGH BAY	330	02				25	49T22 330
00000							
TASK 26 DAY 228 01/31/69							
1REL BOOST DAMPS FROM GAS	15	102				T25	15
00000							
2INST BOOST DAMPS	39	202	1	2	5	T 1	20 2 19
04B02X01A05 01A06 01A07 01A08 01A09 01A10 01A11 01A12							
3TURN POWER ON	56	02				25	6T27 56
00000							
4TEST SCAN	42	202				T27	42
00000							
5CK SCI INST CONN	23	102				25	41T 9 23
00000							
6STOW SCAN PLAT SUPER ST	30	202				26	4T 1 30
01A19X01A20X01A21X01B01 01B02 03A 03B							
7TORQUE IPR CONN	30	102	5			23	42I 2 30
03B06X03B07X03B 03A01							
8PREP FOR SOL PANEL INST	13	02				T27	13
00000							
9TURN POWER OFF	57	02				26	3T27 57
00000							
10REM CANOPUS SEN OSE HOOD	108	102	1	2		25	20R 2 54 1 54
13B08X13B09X13B10X13B11X							
11INST SOLAR PANELS	153	402	1	2	5	26	8I 1 51 2 5111 51
04A00W04B00W01A05X01A06X01A07X01A08X01A09X01A10X01A11X01A12X							
12CK SOLAR PANEL INST	10	102				26	11T 9 10
00000							
13ROTATE S/C /CLAMP S/P	98	202	1	2	5	23	15T 1 40 2 4016 18
04A X04B04X04B05X04B06X04B07X							
14CABLE UP NARR ANG TV	24	102				25	25T11 24
03B12X							
15CABLE UP WIDE ANG TV	23	102				11	12T11 23
03B10X							
16TURN POWER ON	9	02				26	9T27 9
00000							
17TURN POWER OFF	9	02				26	16T27 9
00000							
18UNLATCH SCAN PLAT	10	202	1	2	5	26	6T 1 5 2 5
03A 03B							
19REM WIDE ANG TV CAMERA	2	202	1	2	5	26	15R 2 1 1 1
03B10X03B11X03B 03A							
20INST WIDE ANG TV CAMERA	5	202	1	2	5	26	19I 1 3 2 2
03B10X03B11X03B 03A							
21REM NARR ANG TV CAMERA	13	202	1	2	5	25	26R 2 7 1 6
03B12X03B13X03B14X03B 03A01							

22TEST WIDE ANG TV PIN/RET 11C03X	1 102	26 20T11	1		
23TEST NARR ANG TV PIN/RET 11C03X	2 102	26 21T11	2		
24REM LOUVER CASE 5 09A02X09A01	3 202 1 2 5	25 43R 2	2 1	1	
25REM LOUVER CASE 7 11A02X11A01 11A03	10 202 1 2 5	25 45R 2	5 1	5	
26DEPATE CASE 5 BENDIX 09C01X15A01X15A02X	1 102	15 42T11	1		
27DEPATE CASE 7 BENDIX 15A01X15A02X15B03X11C X	9 102	15 43T11	9		
28REM TCFM ANG ATTACHMENTS 14A27X14A28X	3 202 1 2 5	25 41R 2	2 1	1	
29REM CASE 5 09A01X09B00W09C00W	1 202 1 2 5	26 26R 2	1		
30CAST ANALOG TAPE TRANS 09B01X09B X09A01 09C	11 20215	25 16T12	11		
31INST CASE 5 09A01X09B00W09C00W	3 202 1 2 5	26 29I 1	2 2	1	
32REM CASE 7 /SPEAR PLATE 11A01X11A03X11B00W11C00W	10 202 1 2 5	26 27R 2	5 1	5	
33INST CASE 7 11A01X11A03X11B00W11C00W	50 202 1 2 5	26 32I 1	25 2	25	
34CABLE UP S/C 07C01X09C01X11C03X11C01X12C01X	60 202	26 15T11	60		
35INST NARR ANG TV 03B12X03B13X03B14X03A01 03B	25 202 1 2 5	26 21I 1	13 2	12	
36INST STIM FRAME 03B 03A	20 302 1 2 4	623 29I 1	7 2	715	6
37SECURE IN AO HIGH BAY 00000	462 02	26 36T22	462		
TASK 27 DAY 229 02/01/69 1TURN POWER ON	14 02	26 17T27	14		
00000 2INST UVS STIM	90 102 1	23 43I 1	90		
03B08X03B09X03A 03B 3PREP FOR TV ALGN/REM COV	10 102 1	26 35T 1	10		
03B10X03B12X 4TEST TV	12 02	27 31T27	12		
00000 5REL TAPE FROM GAS	78 02	T25	78		
00000 6TEST S/C	72 02	26 34T27	72		
00000 7PREP TO REM UVS STIM PLT	3 02	27 2T27	3		
00000 8REM UVS STIM PLAT	15 302 1 2 4	627 7R 2	5 1	515	5
03B 03A 9INST ALIGNMENT PLAT	15 20210	27 3I10	15		
00000 10TEST TV ALIGNMENT	15 20210	27 9T10	15		
00000 11MOVE S/C TO ADAPT	120 102	T 3	6016	60	
01A01 02A 02B 02C 04A 12RET S/C TO LLP	14A01 75 102	T 3	3816	37	
01A01 02A 02B 02C 04A 13COMPLETE TV ALIGNMENT	14A01 25 02	27 12T27	25		
00000 14REM CANOPUS SENSOR PLATE	15 202 1 2 5	26 10R 2	8 1	7	
13B08X13B09X13B10X13B11X 15INST CANOPUS SENSR PLATE	80 202 1 2 5	27 14I 1	40 2	40	

13B08X13B09X13B10X13B11X							
16TURN POWER OFF	6	02		27	1T27	6	
00000							
17REM TV MODS CASE 7	49	202	1	2	5	26	33R 2 25 1 24
11B06X11B07X11B 11C 11A01							
18INST NARR ANG TV COVER	12	102	1			26	35I 1 12
03B12X03B 03A							
19TIE WIDE ANG TV CABLES	14	102				26	22I14 14
11C03X							
20TIE NARR ANG TV CABLES	14	102				26	35I14 14
11C03X							
21INSP/DIP-DAUB/VC TV MOD	10	202	12	15		27	17T 9 3 7 312 4
11B06X							
22INSP/DIP-DAUB/VC TV MOD	18	202	12	15		27	17T 9 6 7 612 6
11B07X							
23TEST PIN RETENTION	11	202	10			27	21T10 11
11B06X							
24TEST PIN RETENTION	11	202	10			27	22T10 11
11B07X							
25INST TV DATA CONV CASE 7	10	02	1	2	5	27	23I 1 5 2 5
11B06X11B 11C 11A01							
26INST TV CAMERA DR CASE 7	17	02	1	2	5	27	24I 1 9 2 8
11B07X11B 11C 11A01							
27INSTAL OSE STIM FRAME	21	102	1	2	4	626	36I 1 7 2 715 7
03A 03B							
28TURN POWER ON	2	02				27	16T27 2
00000							
29REM NARR ANG TV COVER	9	102				27	18R 1 9
03B12X							
30INST NARR ANG TV COVER	4	102				27	29I 1 4
03B12X							
31REM OSE STIM FRAME	25	02	1	2	4	627	27R 2 8 1 915 8
03A 03B							
32REM FEPS STIM	36	102	1			27	31R 1 36
03B03X							
33INST FEPS SHIELD	42	202	1	2		27	32I 1 15 2 15 5 12
14A57X03B03X							
34INST WIDE ANG TV COVER	2	102	1			27	13I 1 2
03B10X							
35REM IRR STIM	30	102	1			26	7R 1 30
03B06X03B07X03A 03B							
36TORQUE FEPS SHIELD	30	202	5			27	33I 2 30
14A57X03B03X							
37REM BRACK/LATCH SCAN	20	202	1	2	5	27	31R 2 10 1 10
01A19X01A20X01A21X01B01X01B02X03A00W03B00W							
38TURN POWER OFF	2	02				27	28T27 2
00000							
39INST UVS STIM	34	102	1			27	8I 1 17 2 17
03B08X							
40REM UVS STIM	13	102	1			27	39R 1 7 2 6
03B08X							
41TORQUE TV DATA CONVERTER	17	102	5			27	25I 2 17
11B06X11B 11C 11A01							
42TORQUE TV CAMERA DRIVER	12	102	5			27	26I 2 12
11B07X11B 11C 11A01							
43SECURE IN AO HIGH BAY	330	02				27	42T22 330
00000							
TASK 29 DAY 230 02/02/69							
1PREP TO WEIGH S/C	5	102				27	43T27 5
00000							
2REL/INST SHEAR PLATE	20	202	1	2	5	T25	5 1 7 2 8
11A03X11A01X							

3CK TORQUE POWER SPRINGS	7 20210	26 11T10	7			
04B01X						
4INST POWER SPRING SCREWS	18 202 1 2 5	28 31 1	9 2	9		
04B01X						
5TORQUE SHEAR PLATE SCREW	22 102 5	28 21 2	22			
11A03X						
6INST CASE 5 LOUVER	28 202 1 2 5	26 24I 1	14 2	14		
09A02X09A01X						
7INST CASE 7 LOUVER	20 202 1 2 5	26 25I 1	10 2	10		
11A02X11A03X11A01						
8INST SOL PANEL SQUIB	112 02 1 2	28 4I 1	40 2	4011	2014	12
04B10X04B11X04B01X04A						
9PRESS SCAN PLAT	8 0210	26 6T27	8			
00000						
10INST TC ANG CASE 5	2 202 1 2 5	28 6I 1	1 2	1		
14A27X09A02X						
11INST TC ANG CASE 7	2 202 1 2 5	28 7I 1	1 2	1		
14A28X11A02X						
12REM PROP MOUNT 1	1 202 1 2 4	618 4R 2	1			
01A13X01A14X01A15X						
13TILT S/C	2 102	26 13T16	2			
00000						
14REM PROP MOUNT 2	1 202 1 2 4	628 12R 2	1			
01A16X01A17X01A18X						
15INST SOL PANEL CLAMPS/PP	1 202 1 2	28 8I14	1			
04B04X04B05X04B06X04B07X04A						
16SUB PROP MOUNT SCREWS	22 202 1 2	28 12I 1	11 2	11		
01A13X01A14X01A15X01A16X01A17X01A18X						
17TORQ PROP MOUNT SCREWS	5 202 5	18 4R 2	5			
01A13X01A14X01A15X01A16X01A17X01A18X						
18TIE SOL PANEL HARN/PP	48 202	26 11I14	48			
04B04X04B05X04B06X04B07X04A						
19COMPLETE SOL PANEL INST	30 202 1 2 5	28 18I 1	8 2	811	714	7
04B04X04B05X04B06X04B07X04A						
20INST LOW THERMAL BLANKET	60 302 1 2 5	25 49I 1	30 2	30		
14A02X01A02 03B 03A						
21INST SCAN PLAT THER BLK	32 302 1 2 5	28 20I 1	16 2	16		
14A03X03B00W03A00W14A02						
22TORQUE SCAN PLAT BLANKET	23 202 5	28 21I 2	23			
14A02X14A03X14A02014A030138000158000						
22OCCLUDED ZONES						
01A00001B00005A0000C5B000005C00006A00006B00006C00006D000007A00007B00007C00008A000						
22OCCLUDED ZONES						
08B00008C00009A000009B000009C00010A00010B00010C00011A00011B00011C00012A00012B000						
22OCCLUDED ZONES						
12C00013A000						
23CLEAN TV LENS	5 102 1	27 35T 1	2 6	3		
03B12X						
24INST TC HARDWARE	20 202 1 2 5	26 18I 1	10 2	10		
14A54X14A53X14A55X14A58X						
25INST CRUISE DAMPS	52 202 1 2 5	I 1	26 2	26		
04B03X04B02 04B01						
26INST IRS GAS STOR ASSY	3 202 1 2 5	24 32I 1	2 2	1		
03915X14A02 14A03						
27LIFT S/C	15 402	28 25T16	7 3	8		
01A01						
28INST SOL PANEL STRUTS	20 202 1 2 5	28 19I 1	10 2	10		
04A00W						
29REM SHORT PLUG FROM IRS	13 102 1	28 26R 1	13			
03B16X03B17X14A02 14A03						
30OPEN SOLAR PANELS	76 202	28 28T 1	76			
01A09X01A10X01A11X01A12X04A						

31DEMATE IRS	4 202	28 26T27	4	
00000				
32LIFT S/C	8 402	28 27T16	4 3	4
01A01				
33INST HOLD FIX TO U RING	2 02	28 32I27	2	
00000				
34REM PROTECT COVERS	10 102 1	28 31R 1	10	
03B08X03B06X03B12X03B15X03B16X				
35REM LOUVER COVERS	13 202 1 2 5	28 7R 1	7 2	6
05A02 07A03 08A02 09A02 10A01 11A02 12A02				
36MOVE S/C ONTO SCALE	185 02	28 32T16	100 3	85
01A01				
37TEST FOR CENT OF GRAVITY	80 02	28 36T27	80	
00000				
38COMPLETE WEIGHING	2 02	28 37T27	2	
00000				
39INST PROTECT COVERS	13 102 1	28 34I 1	13	
03B08X03B06X03B12X03B15X03B16X				
40INST LOUVER COVERS	25 202 1 2 5	28 35I 1	13 2	12
05A02 07A03 08A02 09A02 10A01 11A02 12A02				
41CLOSE SOLAR PANELS SECPP	18 202 1 2 5	28 30T 1	9 2	9
04A X04B01X04B08X				
42LIFT S/C	37 102	28 36T16	19 3	18
01A01				
43WEIGH U RING	25 102	28 33T27	25	
00000				
44INST IRS PURGE LINE	2 102	28 31I27	2	
00000				
45REM HOIST BRACKETS	3 202 1 2 5	28 25R 1	2 2	1
01A01				
46INST TCFM COVER/JET VALV	40 102 1	17 4I 1	40	
13A13X13A05X13A01 13A09 02B01X				
47SECURE IN AO HIGH BAY	300 02	28 46T22	300	
00000				
TASK 29 DAY 231 02/03/69				
1SECURE IN AO HIGH BAY	30 02	28 47T22	30	
00000				
2REM PIN PULLER	62 202 1 2 5	25 22R 2	31 1	31
04B08X04A				
3VERIFY SOL PANEL 5	18 202 1 2 5	28 41T27	18	
00000				
4INST PIN PULL	12 202 1 2	29 3T 1	6 2	6
04B08X04A				
5VERIFY SOL PANEL 1	10 02	28 41T 1	3 2	327 4
04B08X				
6COMPLETE SOL PANEL 1 CK	1 02	29 5T27	1	
04B08X				
7ROTATE S/C	2 02	28 42T16	2	
00000				
8VERIFY SOL PANEL 7	5 02	28 41T 1	2 2	227 1
04B08X				
9COMPLETE SOL PANEL 7 CK	2 02	29 8T27	1 2	1
04B08X				
10VERIFY SOL PANEL 3	8 02	28 41T 1	2 2	227 4
04B08X				
11COMPLETE SOL PANEL 3 CK	20 02	29 10T27	8 1	6 2 6
04B08X				
12PREP TO INST CAN BAFFLE	32 102	27 15T27	32	
00000				
13REP FEPS SCREW	1 202 1 2	27 36T 2	1	
03B03X				
14INST CANOPUS BAFFLE	32 202 1 2 5	29 12I 1	16 2	16

13B08X13B09X13B10X13B11X				
15TORQUE FEPS	5	202 5	29 13I 2	5
03B03X				
16OPEN SOLAR PANELS	22	202 1 2 5	28 41T 1	11 2 11
04A X04B08X				
17TORQUE CANOPUS BAFFLE	108	102 5	29 14I 2	108
13AC8X13A09X13A10X13A11X				
18PREP TO INST CRUISE DAMP	30	102	29 16T27	30
00000				
19INST CRUISE DAMPER	99	202 1 2 5	29 18I 1	50 2 49
04B03X04B02 04B01 04A				
20ROTATE S/C	26	102	29 7T16	26
00000				
21TORQUE SOL PANEL 3	30	202 1 2 5	29 10I 2	30
04A03X				
22SET CRUISE DAMP MCSWITCH	2	102 1	T 1	2
04B09X				
23REM IRS GAS STORAGE	13	202 1 2 5	28 39R 2	7 1 6
03B15X14A02X14A03X				
23EXPOSED ZONES			M	
12C0CE13A00E13B00E15A00E				
24SET MICROSWITCH	70	102 1	29 9T 1	70
04B09X				
25REM IRS VENT ASSY	16	202 1 2	29 23R 2	8 1 8
03B17X14A02X14A03				
26CAST CRUISE DAMP	14	0210	T12	14
04B03X				
27WEIGH IRS GAS SYS	76	02	29 25T27	76
03B15X				
28INST PROP MOUNTS	29	02 1 2 5	28 16I 1	15 2 14
01A13X01A14X01A15X01A16X01A17X01A18X				
29ALIGN PROP MTS	30	0210	28 14I10	30
01A13X01A14X01A15X01A16X01A17X01A18X				
30CK MOUNT SETTINGS	7	02	29 29T27	7
00000				
31TORQUE FEPS HOOD	198	02 5	29 15I 2	198
03B03X				
32SET PROP	5	02	29 30I27	5
00000				
33REM IRS PURGE LINE	60	02	28 44R27	60
00000				
34MOVE S/C TO CLAM SHELL	10	02	29 20T16	5 3 5
01A01				
35CONN PURGE TO CLAM SHELL	25	N5	29 34T29	25
36SECURE SHIP CAN	210	N5	29 35T31	210
00000				
37PREP TO MOVE TO ESF	15	N5	29 35T27	15
00000				
38MOVE S/C TO ESF	45	N5	29 37T21	45
00000				
39COMPLETE TRANSFER TO ESF	15	N5	29 38T21	15
00000				
40VACUUM TRANSPORTER	15	N5	29 39T27	15
00000				
41MOVE S/C TO SOUTH BAY	30	N5	29 40T21	30
00000				
TASK 30 DAY 232 02/04/69				
1MOVE S/C TO SOUTH BAY	75	N5	29 41T21	75
00000				
2REM S/C FROM CLAM SHELL	15	4F2	29 34R29	15
00000				

3REM S/C FROM TRANSPORTER	5 4F2	30	2R16	3 3	2	
01A01						
4LOWER S/C TO POSITIONER	10 2F2	30	3T16	5 3	5	
01A01						
5SEC TO POSITIONER	10 F2 1 2 5	30	4T 3	516	5	
01A01						
6MOVE TENT OVER S/C	1 4F2	30	5T27	1		
00000						
7SEC GROUND STRAP TO S/C	34 2F2 1 2 5	30	5T 1	17 2	17	
14A46X						
8PREP TO PRESS	30 1F2	30	7T27	30		
00000						
9INST SHIPPING BRACKETS	30 2F2	30	7I27	30		
00000						
10PRESS SCAN PLAT	16 1F2	30	8T27	16		
00000						
11INST SCAN PLAT VALVES	101 2F2 1 2 5	30	10I11	101		
03A01						
12REM CHANEL CASE 3	20 2F2 1 2	29	21R 2	10 1	10	
14A20X						
13REM GSE MIRROR	10 F2	27	27T27	10		
03A01						
14INST CHANEL CASE 3	95 2F2 1 2	30	12I 1	48 2	47	
14A20X						
15TORQUE SCAN PLAT VALVES	30 2F2 5	30	11I 2	30		
03A01						
16TILT S/C	32 1F2	30	5T16	32		
00000						
17INST SQUIBS S/P	18 2F2 1 2 5		I 1	5 2	511	8
04B10X04B11X04A						
18INST PIN PULLERS	55 2F2 1 2 5	29	2I 1	20 2	2011	15
04B08X04A						
19INST SQUIB PULLER	32 2F2 1 2 5	30	17I 1	11 2	1111	10
01909X						
20INST IRS GAS VENT	13 2F2	29	25I27	10 2	3	
00000						
21REM IRS GAS VENT	10 2F2	30	20R27	10		
00000						
22CK PIN PULLER	3 2F2	30	18T27	3		
00000						
23TORQUE SQUIB PULLER	6 2F2 5	30	19I 2	6		
01809X						
24CONN BENDIX ON VENT SQUI	10 2F2	30	23T11	10		
01809X						
25LOCK WIRE LATCH VENT SQU	40 2F212	30	24T 1	20 2	20	
01809X						
26PREP TO INST PROP	10 2F2	18	4T27	10		
00000						
27INST PROP	10 2F2 1 2 5	30	26I 1	3 2	3 3	4
06A00W06B00W06C00W06D00W						
28REM PROP WIRE	35 1F2 1	30	27R 1	35		
06A00W						
29INST IRS PURGE LINE	90 2F2	29	33I27	90		
00000						
30SECURE IN ESF TENT	594 02	30	29T23	594		
00000						
STAGE 10 ESF OPERATION						
TASK 01 DAY 233 2/05/69						
1TEST IN PROGRESS	40 1T2		T27	40		
00000						
2REM CASE 3 CHANNEL	25 2T2 1 2 5		R 1	13 2	12	
14A26X07A02						

3TURN ON POWER	25 T2	T27 25	
00000			
4RETURN BATT TO DIVISION	59 2T2	T27 59	
00000			
5COMPLETE BATT CHECK	8 2T2	1 4T27 8	
00000			
6VERIFY A/C GAS JETS	113 2T2	T27 113	
00000			
7TEST IN PROGRESS	30 1T2	T 30	
00000			
8CK SENSORS	2 2T2	T 9 2	
00000			
9TEST IN PROGRESS	14 1T2	T27 14	
00000			
10TURN OFF POWER	14 T2	1 3T27 14	
00000			
11REM DIR ACCESS CONNS OSE	2 2T2	R11 2	
00000			
12INST FLIGHT DUST CAPS	3 1T2 1	I 1 3	
00000			
13REM SHORT PLUGS	5 2T2 1 2	R 2 3 1 2	
15A05X			
14MATE DIR ACCES CONNS	10 2T2	1 11I11 10	
15A05X			
15UNMATE SQUIB HARN CONNS	1 2T2	R11 1	
15A05X			
16INST SHORT PLUGS	1 2T2 1 2	1 13I 2 1	
15A05X			
17REM BATT MON CABLE OSE	70 1T2	R27 70	
00000			
18PREP FOR A/C PRESS	5 2T2	1 6T27 5	
00000			
19INST DUST CAPS	5 1T2	1 12I11 5	
12A02X07A02			
20SET UP A/C PRESS	1 1T210	1 18T10 1	
00000			
21REM NAMG TAPE	1 1T210	R10 1	
03901X03B02X			
22CK TORQUE ON CONNS	8 2T210	T10 8	
00000			
23PRESS A/C GAS SYS	120 2T210	1 20T10 120	
00000			
24CK GAS SYS	40 2T210	1 23T10 40	
00000			
25CLOSE GAS VALVES	140 2T2	1 24I27 140	
13A02X			
26CK GAS SYS	15 2T210	1 25T10 15	
00000			
27PRESS GAS SYS	45 2T210	T10 45	
00000			
28CK GAS SYS	120 2T210	1 27T10 120	
00000			
29CLOSED GAS VALVES	30 2T2	1 28I27 30	
13A10X			
30SEC IN TENT	488 T2	1 29T23 488	
00000			
TASK 02 DAY 234 2/06/69			
1SEC IN TENT	30 T2	1 30T23 30	
00000			
2PREP TO REM FILL MANIFS	2 1T2	T27 2	
00000			
3PREP TO INST OSE CONNS	10 1T2	T27 10	

00000								
4CLOSE FILL MANIF	68	2T2	2	2I 1	68			
13A02X								
5CLOSE FILL MANIF	250	2T2	2	2I 1	250			
13A10X								
6INST THERM SHIELD	60	2T2 1 2		I 1	30 2	30		
06003X								
7PREP IRS BOTTLES	15	1T2		T27	15			
00000								
8INST CASE 2 ANG ATTACH	60	2T2 1 2		I 1	30 2	30		
14A31X06003								
9INST EXHAUST LNS OSE	15	2T2		T27	15			
00000								
10REL IRS GAS STORAGE ASSY	35	1T2		T25	35			
00000								
11RUN TEST ON MONO FLOW	10	1T210		T10	10			
00000								
12STATIC CK	47	1T210	2	11T10	47			
00000								
13INST IRS GAS SYS	18	3T2 1 2 5	2	10I 1	9 2	9		
03B15X14A02 14A03								
14CONN GAS LNS	10	2T2 1 2 5	2	13I 1	3 2	311	4	
03B15X03B16X14A01 14A03								
15RUN TEST	30	1T2		T27	30			
00000								
16SEC IN TENT	780	T2	2	15T23	780			
00000								
TASK 03 DAY 235 2/07/69								
1SEC IN TENT	90	T2	2	16T23	90			
00000								
2BEGIN LEAK TESTS	90	2T210		T10	90			
00000								
3INST IRS VENT	30	2T2 1 2 5		I 1	15 2	15		
03B17X03B16X03B15X14A01 14A03								
4ASSEMBLED V-BAND	20	T2 1 2 4 6		I 1	10 2	10		
01A24X								
5POSIT V-BAND CASE 1	20	2T2 1 2 5		I 1	10 2	10		
01B10X01A24X05A02								
6POSIT V-BAND CASE 5	20	2T2 1 2 5		I 1	10 2	10		
01B10X01A24X11A02								
7INST NUTS ON ADAPT ASSY	30	2T2 1 2 5		I 1	15 2	15		
01A23X								
8INST V-BAND MON CONSOLE	90	3T2		T27	90			
00000								
9FLOW TEST MONO TELE	5	2T2	2	11T27	5			
00000								
10CLEAN ADAPT ASSY	5	T2	2	7C 6	5			
01A23X								
11INST BOLTS ON ADAPT RING	19	2T2 5	2	10I 1	9 2	10		
01A23X								
12CONN GAS SYS FILL LINES	81	2T2	2	13I27	81			
00000								
13CK LINE HOOKUPS	45	1T2	3	12T27	45			
00000								
14RUN FLOW TEST	40	2T210		T10	40			
00000								
15SET UP AIR SOURCE	45	2T2		T27	45			
00000								
16SEC IN TENT	810	T2	3	15T23	810			
00000								
TASK 04 DAY 236 2/08/69								
1MOVE CRANE OUT OF S BAY	30	1H2		T27	30			

00000	2PRESS IRS GAS SYS	20 1T2	2 13T27	20	
00000	3READ PRESS/3LEED VALVES	77 2T210	3 2T10	39 1	38
03B15X14A02 14A03	4TEST MONO TELE	360 2T2	2 11T27	360	
00000	5REPRESS GAS SYS/LOCK WR	3 2T212	2 13T 1	1 2	2
00000	6TEST IRS	19 2T2	3 3T 9	1010	9
03B15X	7MON STRAIN GAUGE	50 2T210	3 4T10	50	
00000	8SEC IN TENT	881 T2	3 7T23	881	
00000	TASK 05 DAY 237 2/09/69				
00000	1SEC IN TENT	65 T2	3 8T23	65	
00000	2REM SCAN PLAT BRACKETS	5 2T2 1 2 5	R 2	3 1	2
14A02X14A03X	3INST IRS GAS CONN	11 2T2	2 13I11	11	
00000	4CLEAN S/C	14 2T2	5 3C 1	5 6	5 7 4
03B X14A02X14A03X01A01X	5REM TCFM COVER	5 1T2 1	R 1	5	
02B00W02A 02C	5INSTALL PARTS	T	I		
02B00W02C00W	6ADJUST IRR	20 1T2 1 2 5	T 1	10 2	10
03B06X14A02 14A03	7CAST CABLES	5 2T215	112	5	
01A22X01A23X	8LOOSEN THERM BLANKET	24 2T2 1 2 5	R 2	12 1	12
14A03X14A02	9INST THERM BLANKET	2 2T2 1 2 5	I 1	1 2	1
14A03X14A02 14A03005A000	10REM IRR COVER	1 1T2 1	5 6R 1	1	
03B06X	11DEMATE CONNS	5 2T2 1 2 5	5 3R11	5	
03B15X	12MATE CONNS	23 2T2 1 2 5	5 11I11	23	
03B15X	13REM NARR ANG TV COVER	3 1T2 1	R 1	3	
03B12X	14INSP NARR ANG TV	10 2T2	5 13T 9	10	
00000	15INSP NARR ANG TV/CLEAN	62 2T2	T 9	31 6	31
03B12X	16REM UVS COVER	16 1T2 1	R 1	16	
03B08X	17REM HALF LOUVER	4 1T2 1 2	R 2	2 1	2
03B08X	18REM IRS COVER	6 1T2	5 12R 1	6	
03B23X03B17X	19REM IRS GAS CAPS	9 2T2 1 2	5 18R 1	5 2	4
03B15X03B16X	20INST OSE MOUNT PINS	9 T2 1 2 5	I 1	5 2	4
01A23X01A22 01A24	21INST LIFT BRACKETS	61 T2 1 2 5	I 1	31 2	30
01A02	22SEC IN TENT	1080 T2	5 21T231080		
00000					

TASK 06 DAY 238 2/10/69

1SEC IN TENT

180 T2

5 22T23 180

00000

2ENCAPSILATE CTP GDC

75 2H2

127 75

00000

3CONNECT S/C CABLES

2 2H2 1 2 5

R 2 1 1 1

01A02

4REM V-BAND CABLE

1 2H2 1 2 5

3 8R 2 1

01A24X01A23

5LIFT S/C

7 1H2

5 21T16 4 3 3

01A01 04A 02A 02B 02C

14A01

6VACCUH TV LENS

16 2H2

5 13C 7 16

03B12X

7LOWER S/C TO ADAPT

26 2H2

6 5T16 13 3 13

01A01 04A 02A 02B 02C

14A01 01A23

8MATE INFLIGHT CONNS

8 2H2

111 8

01A23

9CHECK S/C FEET/ADAPT

6 2H210

T10 6

01B04X01B03X

10TORQUE V-BAND ASSY

14 2H2 5

3 8I 2 14

01A23X01A24X

11ADJUST V-BAND ASSY

21 2H2

6 10T 1 11 2 10

01A23X01A24X

12REM SIT/PAS PINS

1 2H2 1 2

R 2 1

01B05X01B06X

13INST 3LOW /ADAPT

55 2H2 1 2

I 1 28 2 27

01A23X

14TURN POWER ON

2 H2

T27 2

00000

15TURN POWER OFF

3 H2

6 14T27 3

00000

16INST VB PYRO/LANYARD

185 2H2 1 2 5

I 1 100 2 85

01A24X01B10X01A23

17FINAL TORO ALL BAYS

10 2H2 1 2 5

I 1 5 2 5

05A02X07A02X08A02X09A02X10A01X11A02X12A02X

18INST FLGHT SQUIBS CASE 1

55 2H2 1 2 5

I 1 28 2 27

01B10X05A02

19INST FLGHT SQUIBS CASE 5

65 2H2 1 2 5

I 1 33 2 32

01B10X09A02

20LOCKWIRE CS 1/5/GS MANIF

15 2H212

T 1 8 2 7

01B10X09A02 05A02 03B23X13A14X13A15X

21SEC IN TENT

693 2H2

6 20T23 693

00000

TASK 07 DAY 239 2/11/69

1REM SUN BAF CV/INST TC

32 2H2 1 2 5

X 2 16 1 16

13B11X14A48

2CAST CONNS

28 2H215

112 28

01A22X01A23

3CLEAN CASE 6

30 1H2

C 6 30

10A01X

4TEST V-BAND CABLES

36 2H210

6 11T10 36

00000

5LIFT S/C

3 2H2

6 5T16 1 3 2

01A01 02A 02B 02C 04A

14A01

6MOVE TO GTV

2 4H2

7 5T16 1 3 1

01A01 02A 02B 02C 04A

14A01

7LOWER TO GTV

57 4H2

7 6T16 27 3 30

01A01 02A 02B 02C 04A

14A01

8SEC TO PLATE

8 4H2 1 2 4 6 7 7I 1 4 2 4

01A02

9REM CABLES

20 2H2 1 2

R 2 10 1 10

01A02

10REM LIFT FIXTURES	1	H2 1 2 5	5 21R 2	1	
01A02X					
11MOVE S/C UNDER TENT	1	4T2 1	7 10T16	1	
00000					
12REM LOUVER COVERS	3	T2 1 2 5	R 1	2 2	1
05A02X07A02X08A02X09A02X10A01X11A02X12A02X					
13INST CLOTURE	10	T2 1 2 5	I 1	5 2	5
07A03X11A03X					
14INST CORN SHIELDS	25	2T2 1 2 5	I 1	13 2	12
14A07X14A06X14A08X14A09X14A10X14A11X14A12X14A13X					
15VACCUM S/C	65	2T2	7 14T 7	65	
01A01X02A X02B X02C X04A	14A01	14A02 14A03			
16VACCUM SUN SEN PED	20	2T2	C 7	20	
14A04X14A05X13B07X					
17BOLT DOWN NOSE CONE	52	2T2	I27	52	
00000					
18INST TOROUS RING GDC	11	3T2	I27	11	
00000					
19INST HOIST ARMS GDC	22	3T2	I27	22	
00000					
20INST CAPS GDC	5	3T2	6 19I27	5	
00000					
21ENCAPS COMPLETE GDC	25	4T2	7 20I27	25	
00000					
22INST OSE CABLES GDC	10	3T2	I27	10	
00000					
23INST N2 PURGE GDC	8	2N5	7 23I27	8	
00000					
24TURN POWER OFF GDC	107	2N5	6 18T27	107	
00000					
25TURN POWER ON GDC	400	2N5	7 24T27	400	
00000					
26REM UMBILICAL CABLES GDC	15	2N5	R27	15	
00000					
27CK IRS GDC	10	2N5	T27	10	
00000					
28UNPLUG STRAIN GAUGE GDC	5	2N5	R27	5	
00000					
29SEC IN NOSE FAIRING GDC	217	2N5	7 28T32	217	
00000					
30CLEAVE ESF AREA GDC	72	4N5	7 28T21	72	
00000					
31ARRIVE AT PAD GDC	5	4N5	7 30T21	5	
00000					
32REM TRANS BOTTLE GDC	11	2N5	R27	11	
00000					
33MOVE UNDER HOIST GDC	16	4N5	T27	16	
00000					
34ATTACH GROUND STRAP GDC	18	2N5	T27	18	
00000					
35REM ALL FASTENERS GDC	6	2N5	R27	6	
00000					
36DISCONN PURGE	4	1N5	7 23R27	4	
00000					
37RAISE TO TOP OF MISSLE	5	4N5	7 36I16	321	2
00000					
38MOVE INTO TOWER GDC	20	1N5	7 37T16	20	
00000					
39CHARGE O BOTTLE GDC	5	2N5	T 2	5	
00000					
40LOWER S/C GDC	20	4N5	7 38T 3	20	
00000					

41REM GROUND STRAPS GDC	30 2N5	7 34R 2 15 1 15
00000		
TASK 08 DAY 240 2/12/69		
1SEC A/C EQUIP GDC	5 N5	I27 5
00000		
2REM SLING GDC	25 N5	R27 25
00000		
3SEC ON PAD GDC	1410 N5	8 21321410
00000		
TASK 09 DAY 241 2/13/69		
1SEC ON PAD	1440 N5	8 31321440
00000		
TASK 10 DAY 242 2/14/69		
1SEC ON PAD	422 N5	9 1132 422
00000		
2REM S/C FROM CENTAUR GDC	8 4N5	7 40R27 8
00000		
3LOWER S/C GDC	12 5N5	10 2 27 12
00000		
4POSITION S/C GDC	6 4N5	10 3127 6
00000		
5FINISH LOWER S/C GDC	17 5N5	10 3127 17
00000		
6SEC S/C ON GTV GDC	1 5N5	10 5127 1
00000		
7CONN A/C GDC	9 N5	8 1127 9
00000		
8RUN LEAK TEST GDC	15 N5	10 7127 15
00000		
9START FOR ESF AREA GDC	85 N5	10 6121 85
00000		
10ARRIVED AT ESF AREA GDC	5 N5	10 9121 5
00000		
11MOVE S/C TO AIR LOCK GDC	15 N5	10 10121 15
00000		
12CONN STRAIN GAUGE CABLES	6 N5	6 11127 6
00000		
13CLEAN SHROUD GDC	74 N5	10 12C27 74
00000		
14RINSE SHROUD	13 5N2	10 13C27 13
00000		
15MOVE TO TENT	12 5N2	10 14127 12
00000		
16E-ENCAPSULATE S/C	65 4H2 1 2 4 610 15R 3 3316 32	
01A01 02A 02B 02C 04A	14A01	
17INSP S/C	15 3H2	10 161 9 15
00000		
18INST V-BAND COVER	1 2H2 1 2 5	7 41 2 1
01A24X01A23		
19COVER CANOPUS TRACKER	12 1H2 1	I 1 12
13908X13B09 13B10 13B11		
20REM 1C CORNER SHIELDS	60 2H2 1 2 5	7 14R 1 30 2 30
14AC7X14AC8X14AC9X14A10X14A11X14A12X14A13X		
21INST LCOVER COVERS	2 H2 1 2 5	7 121 1 1 2 1
05AC2X08AC2X09AC2X10AC1X11AD2X12AD2X		
22GROUND S/C	1 H2	10 17127 1
00000		
23READ V-BAND STRAIN GAUGE	5 H210	7 4110 5
00000		
24INST U-RING ON LLP OSE	4 H2	I27 4
00000		
25LATCH SIT	10 1H2 1	I 1 10

4MOUNT NARR ANG ON CKOUT	24 2T2	11 3I27	24		
00000					
5TURN OFF POWER	10 T2	7 25T27	10		
00000					
6TURN ON POWER	10 T2	7 25T27	10		
00000					
7TEST NARR ANG TV	28 2T2	11 4T27	28		
00000					
8SEC INCLINOMETER	11 2T2	T27	11		
00000					
9TEST VERT ATTIT OF S/C	23 2T2	11 8T27	23		
00000					
10SEC IN TENT	254 T2	11 9T23	254		
00000					
11ROTATE S/C	62 4T2	11 9T16	62		
00000					
12REM V-BAND	15 2T2 1 2 5	10 36R 2	7 1	8	
01A24X					
13INST V-BAND	10 2T2 1 2 5	11 12I 1	5 2	5	
01A24X					
14REM CASE 3 UP CHANNEL	5 2T2 1 2 5	R 2	2 1	3	
14A15X07A02					
14INSTALL PARTS	T	I			
14A00W					
14OCCLUDE ZONES		M			
04A00004800013A00013B00015A00012C000006C00010A000					
15INST ACCESS TO ATT CONT	9 2T2	I27	9		
00000					
16CLEAN ADAPT STUCT ASSY	11 2T2	6 13C 6	6 7	5	
01A23X01A22					
17ROTATE S/C	60 T2	11 11T16	60		
00000					
18TURN OFF POWER	20 T2	11 6T27	20		
00000					
19INST CASE FLT CAP OSE	5 T2	I27	5		
00000					
20TURN ON POWER	90 T2	11 18T27	90		
00000					
21ROTATE S/C	174 4T2	11 17T16	174		
00000					
22TURN OFF POWER	11 T2	11 20T27	11		
00000					
23REM INFLGHT TEST CBC/OSE	3 2T2	6 8R27	3		
00000					
24REM UVS LOUVER COVER	3 2T2 1 2 5	10 40R 1	2 2	1	
14A54					
25INST UVS LOUVER COVER	4 2T2 1 2 5	11 24R 1	2 2	2	
14A54					
26LOWER S/C	37 4T2	11 9T16	37		
00000					
27INSP SUN SEN	18 2T2	T 9	18		
00000					
28INSP NARR ANG TV	2 2T2	11 7T27	2		
00000					
29CLEAN NARR ANG TV	3 2T2	11 28C 6	3		
03912X					
30DEMATE ADAPT STRUCT	10 2T2	11 16R 3	516	5	
01B05X01B06X01B04X01B03X01A23X01A22X					
31INST OSE GUIDE PINS	88 2T2	11 30I27	88		
00000					
32REM ADAPT STRUCT	7 3T2	11 30T16	7		
01A23X					

33REM IRS COVERS	5 1T2 1	10 44R 1	5	
03916X03B17X03B15X				
34INSP IRS	6 1T2	11 33T 9	6	
00000				
35REM IRR COVER	9 1T2 1	10 39R 1	9	
03806X				
36REM UVS COVERS	3 1T2 1	11 25R 1	3	
03808X				
37REM FEPS TAPE/NAMG	4 2T2 1	10 43R 1	4	
03801X03802X03803X				
38TORQUE SEN CABLE CLAMPS	28 2T2 5	I 2	28	
04809X				
39TILT S/C VERTICALLY	5 4T2	11 26T16	5	
00000				
40SEC IN TENT	319 T2	11 39T23	319	
00000				
TASK 12 DAY 244 2/16/69				
1SEC IN TENT	40 T2	11 40T23	40	
00000				
2COMPLETE V-BAND ASSY	55 2T2 1 2 5	11 13I 1	28 2 27	
01A24X01B10X				
3MATE A/C TO ADAPT ASSY	90 2T2	11 16I27	90	
00000				
40EMATE A/C FROM ASSY	15 2T2	12 3R27	15	
00000				
5REM TENT	15 4H2	10 46T27	15	
01A01				
6REM S/C FROM LLP	25 4H2	10 45R 3	1316 12	
01A01X02A 02B 02C 04A	14A01			
7CLEAN SUN SEN LENS	25 1H2	11 27C 6	25	
13801X13802X				
8CLEAN MARS GATE LENSES	10 1H2	C 6	10	
03801X03802X				
9REM IRS BOTTLE COVERS	5 1H2 1	10 38R 1	5	
03815X				
9INSTALL PARTS	H	I		
03800W				
10CLEAN CANOPUS SEN LENS	25 1H2	10 19C 6	25	
13808X13809X13810X13811X				
11REM GUIDE PINS	20 2H2 1 2 5	12 4R 2	10 1 10	
01804X01A23X				
12INST V-BAND	75 2H2 1 2 5	12 2I 1	38 2 37	
01A24X01A23X				
13INSP V-BAND FOR BINDING	5 1H210	12 12T10	3 9 2	
00000				
14MOVE TENT OVER S/C	25 4T2	12 5I27	25	
01A01				
15READ V-BAND TENSION	10 1T210	12 13T10	10	
00000				
16SEC IN TENT	75 T2	12 15T23	75	
00000				
17TURN ON POWER	20 T2	11 22T27	20	
00000				
18START PYRO CHECK	10 2T2	12 17T27	10	
00000				
19REM SIT PIN	10 2T2 1 2	10 25R 2	5 1 5	
01805X				
20REM PAS PIN	5 2T2 1 2	10 26R 2	3 1 2	
01806X				
21STOP PYRO CHECK	15 2T2	12 18T27	15	
00000				
22TURN OFF POWER	25 T2	12 17T27	25	

00000				
23CONTINUE PYRO CHECK	10 2T2	12 21T27	10	
00000				
24REM SHORT PLUGS	80 2T2 1 2 5	10 33R 2	40 1	40
15AC6X15B02X15A05X				
24INSTALL PARTS	I	I		
15ADGW15B00W				
25COMPLETE PYRO CHECK	5 2T2	12 23T27	5	
00000				
26INST TC CORN SHIELDS CS2	115 2T2 1 2 5	10 20I 1	58 2	57
14A07X14A31				
27INST V-BAND STRAP	45 2T2 1 2 5	12 15I 1	23 2	22
28INST V-BAND HOLD TOOLS	35 2T2 4 6	12 27I 1	18 2	17
01A24X				
29TORQUE V-BAND	45 2T2 5	12 12I 2	45	
01A24X				
30SEC IN TENT	42 T2	12 29T23	42	
00000				
31RETIGHTEN V-BAND	43 2T2 5	12 29T 2	43	
01A24X				
32INST V-BAND SQUIBS	8 2T2 1 2 5	12 31I 1	4 2	4
01B10X01A24X01A23X				
33MATE CONNS OSE	11 2T2	12 32I27	11	
00000				
34INST V-BAND HARN CLAMPS	34 2T2 1 2 5	11 13R 1	17 2	17
01A23X01A24X01B10				
35SEC IN TENT	367 T2	12 34T23	367	
00000				
TASK 13 DAY 245 2/17/69				
1READ V-BAND	15 1T210	12 32T10	15	
00000				
2ADJUST CASE 3 TENSION/VB	5 2T210	13 1T10	5	
00000				
3READ V-BAND	5 1T2	12 32T10	5	
00000				
4CK VB TENSION CS 7	5 2T210	T10	5	
00000				
5READ V-BAND	2 1T210	12 32T10	2	
00000				
6REM V-BAND HOLDERS	13 2T2 4 6	12 34R 2	6 1	7
01A23X01B10X01A24X				
7VACCU V-BAND	45 2T2	13 6T 7	45	
01A23X01A24X01B10X				
8REM OSE MON CABLES	2 2T2	13 7R27	2	
00000				
9INSP V-BAND	1 1T2	13 8T 9	1	
00000				
10REM OSE CABLES	1 2T2	12 16R27	1	
00000				
11REM ADAPT ASSY AIR	1 2T2	13 10R27	1	
00000				
12PREP TO MOVE TENT	1 4T2	13 11T27	1	
00000				
13MOVE TENT	4 2H2	13 12T27	4	
01A01				
14INST CRANE	11 4H2	13 13I 3	11	
00000				
15MOVE S/C TO GTV	9 4H2	13 14I 3	416	5
01A01X02A 02B 02C 04A	14A01			
16LOWER S/C TO GTV	5 4H2	13 15T 3	216	3
00000				

17REM CRANE	5 3H2	13 16R 3	5	
00000				
18SEC BOLTS TO ADAPT	10 2H2 1 2 4	613 10I 1	5 2	5
01A23X01A02				
19REM S/C LIFT BRACKETS	30 2H2 1 2 5	13 17R 2	15 1	15
01A02X				
20MOVE S/C INTO TENT	15 4T2	13 13T27	15	
01A01				
21INSP S/C	10 1T2	13 20T 9	10	
00000				
22REM LOUVER COVERS	15 2T2 1 2 5	11 25R 2	7 1	8
05A02X08A02X09A02X10A01X11A02X12A02				
22INSTALL PARTS	T	I		
05A00W08A00W09A00W10A00W				
23TORQUE CLOSURE PLATES	3 1T2 1 2 5	13 2I 2	3	
07A02X07A03				
24TORQUE CLOSURE PLATES	2 1T2 1 2 5	13 4I 2	2	
11A02X11A03				
25TORO CORNER SHIELDS	5 2T2 5	10 20I 1	3 2	2
14A07X14A08X14A09X14A10X14A11X14A12X14A13X				
26DEMATE TEMP TRANS CABLE	2 T2	13 23R27	2	
00000				
27DEMATE TEMP TRANS CABLE	3 T2	13 24R27	3	
00000				
28REM V-BAND COVER	20 2T2 1 2 5	13 9R 2	10 1	10
01A22 01A23X01A24X01B10X01B04 01B03				
28INSTALL PARTS	T	I		
01A00W01B00W				
29REM CANOPUS SEN COVER	20 1T2 1 2	12 10R 2	10 1	10
13B08X				
29INSTALL PARTS	T	I		
13A00W13B00W				
30VACCUM V-BAND	15 2T2	13 28T 7	15	
01A24X01A23X				
31VACCUM CORN SHIELDS TC	15 2T2	13 25T 7	15	
05A02X06D03X07A02X08A02X09A02X10A01X11A02X12A02X14A01X14A03X14A02X				
32ENCAPSULATE S/C	125 4E2	13 31T32	125	
00000				
33SEC IN CAPSULE	1020 E2	13 32T32	1020	
00000				
TASK 14 DAY 246 02/18/69				
1SEC IN CAPSULE	1180 E2	13 33T32	1180	
00000				
2MOVE S/C TO SNA AIRLOCK	20 1E4	13 32T27	20	
00000				
3MOVE S/C TO TRUCK	2 4E4	14 2T21	2	
00000				
4START PURGE	3 1N5	14 3T27	3	
00000				
5INST HYDROGEN LEAK DETEC	5 2N5	14 4T27	5	
00000				
6INST SPEEDOMETER	10 2N5	14 3I27	10	
00000				
7MOVE S/C TO PAD	62 4N5	14 6T21	62	
00000				
8REM LEAK DETECT	48 2N5	14 5R27	48	
00000				
9INST GANTRY GRND CABLE	5 2N5	14 7I27	5	
00000				
10HOIST S/C	30 4N5	14 9T27	30	
00000				
11INST S/C ON CENTAUR	7 4N5	14 10T27	7	

00000			
12REM HOISTING ARMS	39 2N5	14 10T27	39
00000			
13REM TORUS RING	4 3N5	7 18R27	4
00000			
14SEC ON PAD	25 N5	14 13T32	25
00000			
STAGE 11 LAUNCH COMPLEX 36B OPERATIONS			
TASK 01 DAY 247 02/19/69			
1HOISTING S/C ON GANTRY	195 4N5	T21	195
00000			
2X-RAY S/C	70 4N5	1 1T27	70
00000			
3SECURE ON PAD	1175 N5	1 2T311175	
00000			
TASK 02 DAY 248 02/20/69			
1SECURE ON PAD	1440 N5	1 3T311440	
00000			
TASK 03 DAY 249 02/21/69			
1SECURE ON PAD	150 N5	2 1T31	150
00000			
2REM MONO BALLS FROM ADAP	60 2N5	R27	60
00000			
3INST COVER PLATES	60 2N5	I27	60
00000			
4SECURE ON PAD	1170 N5	3 3T311170	
00000			
TASK 04 DAY 250 02/22/69			
1SECURE ON PAD	1440 N5	3 4T311440	
00000			
TASK 05 DAY 251 02/23/69			
1SECURE ON PAD	510 N5	4 1T31	510
00000			
2REM SHORTING PLUG	90 2N5	R27	90
00000			
3MATE PYRO CABLE TO S/C	90 3N5	T27	90
00000			
4SECURE ON PAD	750 N5	5 3T31	750
00000			
END			