

DRA

COMPUTER SIMULATOR FOR A MOBILE TELEPHONE SYSTEM

NASA-LEWIS Research Center

Cleveland Ohio

April 21, 1982 - April 19, 1983

NASA Grant: NAG 3-277

Final Report



Donald L. Schilling

Chaim Ziegler

Professor of Electrical Engineering

Assoc. Prof. of Computer Science

Principal Investigator

Co-Principal Investigator

(NASA-CR-174533) COMPUTER SIMULATOR FOR A
 MOBILE TELEPHONE SYSTEM Final Report, 21
 Apr. 1982 - 19 Apr. 1983 (City Coll. of the
 City Univ. of New York.) 96 p HC A05/MF A01

Unclassified
 CSCL 17B G3/32 15172

N84-10401

COMMUNICATIONS SYSTEMS LABORATORY

DEPARTMENT OF ELECTRICAL ENGINEERING

The City College
 New York, N.Y. 10031



~~ORIGINAL PAGE IS
OF POOR QUALITY~~

Table of Contents

	Page

Introduction	1
The Present Simulator	2
Processing Voice Via The Simulation	26
Users's Guide	36
Sample Runs	52
Results	54
Proposed Research fo the Forthcoming Year	65

~~ORIGINAL PAGE IS
OF POOR QUALITY~~

1. Introduction

This project is the result of a joint effort between the Department of Electrical Engineering at the City College, CUNY; and the Department of Computer & Information Science at the Brooklyn College, CUNY.

The goal of this project is to develop a software simulator to help NASA in the design of the LMSS. The simulator will be used to study the characteristics and implementation requirements of the LMSS's configuration with specifications as outlined by NASA.

This report represents progress made in implementing the simulator during the period 4/21/82 - April 19, 1983.

ORIGINAL PAGE IS
OF POOR QUALITY

2. The Present Simulator

The basic components of the present simulator were described previously in the first report (NASA Grant: NAG 3-119). However, previously, not all the components of the system were operational and only scenario 1 was implemented.

The current simulation now includes all the components, such as the interference sources, the S-band channels, the noise sources, the gateways, a revised master controller for the simulator, as well as other components which were recently completed.

The present simulator is now capable of executing all 5 scenarios, which are described below .

2.1 The Communication Scenarios

Through the use of the five scenarios, it is possable to study all the different possible combinations of types and modes of calls. The five scenarios are described below:

(1). Single Hop System:

For those calls which require the communication between two mobile units, without going through a gateway, we group them together and form scenario 1. In this scenario, a mobile will generate a call, for which the call will go up to the satellite, and be transponded down directly to the destination mobile. This can be seen in

figure 2.1.

(2). Double Hop, Single Gateway System:

For those calls which require communication between two mobile units by going through a gateway, we group the together and form scenario 2. In this scenario, a mobile will initiate a call, which will be transponded by the satellite to a gateway. After processing by the gateway, the call is once again transponded by the satellite to the destination mobile. This can be seen in figure 2.2.

(3). Double Hop, Double Gateway System:

For those calls which have to go through two gateways, we form scenario 3. In this scenario a mobile will generate a call, which is transponded to a gateway. The gateway forwards the call to the master control station. The master control station then routes the call to the destination gateway. Then the call is once again transponded by the satellite to the destination mobile. This can be seen in figure 2.3.

(4). Mobile-to-Wireline System

For any call that was initiated by a mobile and was desired to go through a fixed phone or to a mobile serviced by the cellular system, we have scenario 4. In this scenario, the call is initiated by the mobile and transponded by the satellite to a gateway. Then, the gateway forwards the call into the wireline network. This can be seen in figure 2.4.

(5). Wireline-to-Mobile System:

If a call is initiated by a fixed phone or mobile in a cellular system to a mobile in the LMSS, we resort to scenario 5. In this scenario a call is received from the wireline telephone network into a gateway. The call is then transponded by the satellite to the destination mobile. This can be seen in figure 2.5.

2.2 Output Facilities

Also new in the present simulator is the revised version of the Master Controller (see 4.1.2, first report). In the present simulator it is possible to go through a range of values for any one of the components in the scenario. It is possible to consider a range of values for up to 14 different components simultaneously. Previously, if a type 2 measurement was chosen, the simulator would display a two column table of the input vs output SNR values, for a given set of system parameters. With the present simulator it is possible in a type 2 measurement for the simulator to display up to 15 columns (15 th column is output signal to noise ratio), one for each range of component values. In the present simulator, it is also possible to get plots of the input vs. output SNR values for any range of values of the other components (see section 5, "Sample Runs"). The looping or ranging feature mentioned above can also be used in a type 1 measurement, where the input signal, output signal (no disturbances present), and output signal (with all specified disturbances) are displayed in a table. It is now possible to consider a type 1 measurement over a range of values (up to 14 possible ranges of parameters). Once again, a plotting facility is available for every type 1 measurement table displayed (see section 5,"Sample Runs").

The revised master controller function has the following algorithm:

ORIGINAL PAGE IS
OF POOR QUALITY

/SIMULATION MASTER CONTROLLER FUNCTION/:

```
<initialize simulation master controller function>

DO <range of Specular-to Multipath Power Ratio--UHF Uplink >
    <range of Specular-to-Multipath Power Ratio--S-Band Downlink>
    <range of Specular-to-Multipath Power Ratio--S-Band Uplink>
    <range of Specular-to-Multipath Power Ratio--UHF Downlink>
    <range of carr.-to-interf. power ratio--UHF Uplink Interference>
    <range of phase values--UHF Uplink Interference >
    <range of carr.-to-interf. power ratio--S-Band Downlink Interf>
    <range of phase values--S-Band Downlink Interference>
    <range of carr.-to-interf. power ratio--S-Band Uplink Interf.>
    <range of phase values--S-Band Uplink Interf.>
    <range of carr.-to-interf. power ratio--UHF Downlink Interf>
    <range of phase values--UHF Downlink Interf.>
    <RANGE OF SNR >
    <calculate SNR>
    <calculate standard deviation for white noise>
    <perform simulation reset>
    <set flag for mobile transmitter>
    <PERFORM a simulation run>
    <perform master controller instrumentation package>
END <signal to noise ratio>

END /simulation master controller function/
```

2.3 System Structure

The present modular structure can be seen in the flowchart of figure 2.6, with its subroutines defined in table 2.7.

ORIGINAL PAGE IS
OF POOR QUALITY




Figure 2.1 : Single Hop Single Gateway System




Figure 2.2 : Double Hop Single Gateway

ORIGINAL PAGE IS
OF POOR QUALITY




Figure 2.3 : Double Hop Double Gateway





Figure 2.4 : Mobile to Wireline System



ORIGINAL PAGE IS
OF POOR QUALITY

Figure 2.5 : Wireline to Mobile System

ROUTINES FOR EACH
SCENAROTO

(1)

SCENARIO 1

SETMSX----->	SETSSG
SETIS1	SETMOD
SETUSC--->SETCFG	SETSPX--->SETCOM
SETNG1 SETFAD	SETNL SETEMP
SETUUT	SETFLR SETDEL
SETIS6	SETPDL
SETSUC--->SETCFG	
SETNG6 SETFAD	
SETMSR----->	SETRSP
	SETFMD
	SETRCF
	SETSPR--->SETDPH
	SETEXP

SCENARIO 2

SETMSX----->	SETSSG
SETIS1	SETMOD
SETUSC--->SETCFG	SETSPX--->SETCOM
SETNG1 SETFAD	SETNL SETEMP
SETUBT	SETFLR SETDEL
SETIS2	SETPDL
SETSBC	
SETNG2	
SETGSR	
SETGAT	
SETGSX	
SETIS5	
SETBSC	
SETSUT	
SETIS6	
SETSUC--->SETCFG	
SETNG6 SETFAD	

13

ORIGINAL PAGE IS
OF POOR QUALITY

***** LMSS SIMULATOR *****

FLOW CHART OF LMSS SIMULATOR

MAIN

^

^

SELECT

SETUP-----> (1)

SETCON

MASCON

^

SETMC

RESET----->

SUBCON----->

INSTRM

ENDSIM

SCENAR-->

UPCON

RSTUPK-->GAUS

RSTDLK-->GAUS

RSTPLT

SIGSRC

^-SCEN1-->(2)

^-SCEN2-->(3)

SELECT ONE-----> ^ SCEN3-->(4)

^-SCEN4-->(5)

^-SCEN5-->(6)

~~ORIGINAL PAGE IS
OF POOR QUALITY~~

```
SETMSR----->SETRSP  
                      SETFMD  
                      SETRCF  
                      SETSPR--->SETPDH  
                                         SETEXP
```

SCENARIO 3

SETMSX----->SETSSG			
SETIS1	SETMOD		
SETUSC----->SETCFG	SETSPX--->SETCOM		
SETNG1	SETFAD	SETNL	SETEMP
SETUBT		SETFLR	SETDEL
SETIS2			SETPDL
SETSBC			
SETNG2			
SETGSR			
SETGAT			
SETGCX			
SETIS3			
SETGCC			
SETNG3			
SETMCS			
SETIS4			
SETCGC			
SETNG4			
SETGCR			
SETGSX			
SETIS5			
SETRSC			
SETNG5			
SETSUT			
SETIS6			
SETSUC----->SETCFG			
SETNG6	SETFAD		
SETMSR----->SETRSP			
	SETFMD		
	SETRCF		
	SETSPR--->SETDPH		
	SETEXP		

ORIGINAL PAGE IS
OF POOR QUALITY

SCENARIO 4

SETMSX----->SETSSG
SETIS1
SETUSC---->SETCFG
SETNG1 SETFAD
SETUBT
SETIS2
SETSBC
SETNG2
SETGSR
SETGAT
SETWNR

SETMOD
SETSPX--->SETCOM
SETNL SETEMP
SETFLR SETDEL
SETPDL

SCENARIO 5

SETWNX
SETGAT
SETGSX
SETI55
SETBSC
SETNG5
SETSUT
SETI56
SETSUC---->SETCFG
SETNG6 SETFAD
SETMSR----->SETRSP
SETFMD
SETRCF
SETSPR----->SETPDH
SETEXP

*
** SCENARIO 1 **
*

(2)

```

MSXMTR----->SIGSRC
INTFS1                      SIPRXT----->COMPRS
UPMTSC----->FADE           MODSTG---->PHASE    PEMPHA
NOISE1                      MPCOEFF   NONLTN     QUAD      DEVLM
SATLT                         FLTR          ,          PDEVLI
INTFS6
DNSTMC----->               GAUS
NOISE6----->               DOPFLT
MSRCVR----->
INSTRS
^           ^           FADE---->MPCOEFF----->GAUS
^           ^           FADE---->                               DOPFLT
^           ^           MPCOEFF----->GAUS
^           ^           DOPFLT
^
^           GAUSS
^           GAUSS
^
^
RSPDIV----->LPFLT1
FMDEMO----->FMDCRT          LPFLT1
SIGRR--->DEMMPH1           RCFLTR-->LPFLT
                           EXPAND

```


*
** SCENARIO ? **
*

(3)

```

MSXMTR----->STGSR
INTFS1                               STPRXT----->COMPRS
UPMTSC--->FADE                      MODSIG--->PEMPHA
NOISE1      MPCOEFF--->GAUS          NONLIN     ^    DEVLIM
SATLT           DOPFLT             FLPTR      ^    PDEVLI
INTFS2
DNSTGC
NOISE2
GSRCVR
GATE
GSXMTR
INTFS5
UPGTSG
NOISE5
SATLT
INTFS6
DNSTMCR----->FADE----->
NOISE6----->GAUSS      FADE----->^
MSRCVR----->    GAUSS            ^          ^
INSTRS      ^                   MPCOEFF   ^    ^
                           ^           ^          ^
                           ^           GAUS      ^
                           ^           DOPFLT   ^
                           ^           ^
                           ^           MPCOEFF   ^
                           ^           ^
                           ^           GAUS      ^
                           ^           DOPFLT   ^
                           ^           ^
                           ^           MPCOEFF   ^
                           ^           ^
                           ^           GAUS      ^
                           ^           DOPFLT   ^

```

ORIGINAL PAGE IS
OF POOR QUALITY

ORIGINAL PAGE IS
OF POOR QUALITY

```

RSPDIV----->
FMDEMO-----> ^
SIPRRC----> ^          LPFLT1
                ^          LPFLT1
                ^          CHOICE
                ^          ^
                ^          FMDCRI
                ^          RCFLTR
                ^          ^
                ^          LPFLT
DEMPHA-->
EXPAND   ^
LPFLT2

```



```

*****  

*          *  

** SCENARIO 3 **  

*          *  

*****
```

(4)

```

^
^
^
^

MSXMTR----->SIGSRC
INTFS1                      SIPRXT----->COMPRS
UPMTSC---->FADE           MODSIG-->      PEMPHA
NOISE1                       NONLIN   ^      DEVLIM
SATLT            MPCOEFF       FLTR     ^      PDEVLI
INTFS2
DNSTGC             GAUS
NOISE2             DOPFLT
GSRCVR
GATE
```

GSXMTR
INTFS3
GTCC
NOTSE3
MSTRCS
INTFS4
CTGC
NOISE4
GCRCVR
GATE
GSXMTR
INTFS5
UPGTSC
NOISE5
SATLT
INTFS6
DNSTMC----->FADE----->
NOTSE6----->GAUSS FADE--> ^
MSRCVR-----> GAUSS ^ MPCOEFF
^ ^ ^ ^
^ ^ ^ ^ GAUS
MPCOEFF DOPFLT
RSPDTV----->
FMDEMO-----> ^ GAUS
SIPRRRC--> ^ LPFLT1 DOPFLT
^ ^ ^ ^
^ ^ ^ ^ CHOICE
^ ^ ^ ^
^ ^ ^ ^ FMDCRI
^ ^ ^ ^ RCFLTR---->LPFLT
DEMPHA--->LPFLT2
EXPAND

* *
** SCENARO 4 **
* *

(5)

^
^
^
^

MSXMTR----->STGSRC
INTFS1
UPMTSC----->FADE
NOTSEL
SATLT MPCOEFF
INTFS2
DNSTGC GAUS
NOISE2 DOPFLT
GSRCVR
GATE
WNCVR
INSTRS
STPRXT----->
MODSIG--> ^
NONLTN ^ ^
FLPTR ^ ^
^ COMPRS
^ PEMPHA
^ DEVLT
^ PDEVLT
^
PHASE
QUAD

ORIGINAL PAGE IS
OF POOR QUALITY

***** SCENARIO 5 *****

(5)

**ORIGINAL PAGE IS
OF POOR QUALITY.**

LMSS SIMULATOR

Subprocedures Dictionary:

CHOICE	space diversity receiver controller
CTGC	master control station to gateway channel
DNSTGC	S-band downlink satellite channel
DNSTMC	UHF downlink satellite channel
ENDSIM	test if it is end of simulation
FLTR	quadrature components filtered
FMDCRI	FM discriminator
FMDEMO	FM demodulator
GATE	gateway
GAUSS	gaussian generator
GCRCVR	gateway from master control station rcvr
GCXMTR	gateway to master control station xmtr
GSRCVR	gateway from satellite rcvr
GSXMTR	gateway to satellite xmtr
GTCC	gateway to master control station channel
INSTRM	update simulation master-control report
INSTRS	update simulation sub-control report
INTFS1	interference sources 1
INTFS2	interference sources 2
INTFS3	interference sources 3
INTFS4	interference sources 4
INTFS5	interference sources 5
INTFS6	interference sources 6
MASCON	simulation master control function
MODSIG	modulation of the input sample
MSRCVR	mobile from satellite rcvr
MSTRCS	master control station
MSXMTR	mobile to satellite xmtr
NOISE1	noise generator 1
NOTSE2	noise generator 2
NOISE3	noise generator 3
NOISE4	noise generator 4
NOISE5	noise generator 5
NOISE6	noise generator 6
NONLIN	nonlinearity routine
PHASE	calculation of the phase angle
QUAD	claculation of the quadrature components
RANDOM	random number generator

ORIGINAL PAGE IS
OF POOR QUALITY

REPORT report generator
 RESET (re)initialization for a simulation run
 RSPDIV space diversity receiver
 SATLT the satellite
 SCENAR scenario execution selection
 SCEN1 scenario 1
 SCEN2 scenario 2
 SCEN3 scenario 3
 SCEN4 scenario 4
 SCEN5 scenario 5
 SELECT selection of call to be simulated
 SETBSC initialize S-band uplink satellite channel
 SETCGC initialize master control station to gateway channel
 SETFLR initialization of the filter
 SETCON initialize the simulation control function
 SETFMD initialization of FMDEMO routine
 SETGAT initialize gateway
 SETGCC initialize gateway to master control station channel
 SETGCR initialize gateway from master control station rcvr
 SETGCX initialize gateway to master control station xmtr
 SETGSR initialize gateway from satellite rcvr
 SETGSX initialize gateway to satellite xmtr
 SETIS1 initialize interference sources 1
 SETIS2 initialize interference sources 2
 SETIS3 initialize interference sources 3
 SETIS4 initialize interference sources 4
 SETIS5 initialize interference sources 5
 SETIS6 initialize interference sources 6
 SETMC initialize simulation master control function
 SETMCS initialize master control station
 SETMOD initialization of modulator
 SETMSR initialize mobile from satellite rcvr
 SETMSX initialize mobile to satellite xmtr
 SETNG1 initialize noise generator 1
 SETNG2 initialize noise generator 2
 SETNG3 initialize noise generator 3
 SETNG4 initialize noise generator 4
 SETNG5 initialize noise generator 5
 SETNG6 initialize noise generator 6
 SETNL initialization of nonlinearity
 SETRCF initialization of RCFLTR routine
 SETRSP initialization of RSPDIV routine
 SETSBC initialize S-band downlink satellite channel
 SETSSG initialization of the signal generator
 SETSUC initialize UHF downlink satellite channel
 SETSUT initialize S-band to UHF satellite transponder
 SETUBT initialize UHF to S-band satellite transponder

INITUP	initialization of simulation run
HATUSC	initialize UHF uplink satellite channel
SETUUT	initialize UHF to UHF satellite transponder
SIGSRC	sample generator
SETWNR	initialize wireline network rcvr
SETWNX	initialize wireline network xmtr
SUBCON	simulation sub-control function
UPCON	update the simulation control function
UPGTSC	S-band uplink satellite channel
UPMTSC	UHF uplink satellite channel
WNRCVR	wireline network rcvr
WNXMTR	wireline network xmtr

36

3. Processing Voice Via The Simulation

One of the systems greatest present attributes is its ability to process voice. The present simulator can be utilized to listen to any of the following effects on voice (via each of the five scenarios):

- (a). Listen to the effects of noise.
- (b). Listen to the effects of interference.
- (c). Listen to the effects of modulation.
- (d). Listen to the effects of the fading channel.
- (e). Listen to the effects of filtering on the voice.
- (f). Listen to the effects of the space diversity receiver.
- (g). Listen to the effects of the satellite nonlinearity.
- (h). Listen to the effects of varying sampling rates.
- (i). All combinations of the above.

An analysis of a number of the above tests are included within the report (see section 6.2).

A basic model of how to use the simulation to process voice is shown in figure 3.1. In this model, an analog to digital converter samples voice at a rate of at least 8 kilohertz (minimum sampling rate for voice bandlimited to 4000 Hz.), producing 12 bit samples. In the second stage, these 12 bit samples are converted into 16 bit integer format (IBM format). These 16 bit integers are then read by the LMSS simulator. (see section users manual

for simulator voice setup). The output of the LMSS simulator is then converted from 32 bit floating point form (IBM format) back into a 12 bit integer format by the fourth stage. In the fifth stage, a digital to analog converter with the proper hardware connected, converts the samples into voice. In between each of the above stages, any type of storage device could have been used for intermediate storage.

The system outlined above is general, and actual implementation depends on the particular intermediate systems involved (stages 1,2,4, and 5).

In figure 3.2 we have a detailed block diagram of the specific algorithm we used in implementing what was shown in figure 3.1.


The first stage consisted of a 12 bit analog to digital converter interfaced into a Hewlett Packard 1000 (HP 1000) computer system. This system sampled the voice (bandlimited to 4000 Hz) with a sampling rate of 8 Khz, and stored it on tape with a "WRITT" format (This is an HP utility which stores data onto a tape in an ultra-condensed coded format, which can only be read by another HP system). We had to store it in this form because the system we used didn't have enough storage facility to do it any other way. In the next stage, we used another HP 1000, with much greater storage facility to convert the WRITT format tape into straight ASCII data. For error control and checking purposes, data was stored in the format of an integer (16 bit integer, represented by 4 characters) followed by a space.

This tape was now to be mounted on the IBM machine. We used the program shown in figure 3.3 to convert from ASCII into EBCDIC

(IBM) format. We stored the data on a disc. We than used the LMSS simulator to process the voice samples.

The LMSS simulator has the facility to read in integers (16-bit) in the format mentioned above. The simulator then interpolates between these samples if specified by the user, and then processes them. The output data set is a stream of 32-bit (IBM format) floating point numbers. Module 3.4 (see figure 3.4) is then used to convert this 32-bit data stream into a 16 bit interger data stream (format 16(1x,I4)), with sample values normalized to plus or minus 2047 (12-bit number). Module 3.5 (see figure 3.5) is then used to convert the data from EBCDIC to ASCII format, and stores it on tape. The tape is then read in by module 3.6 (see figure 3.6) using the HP-1000. This module converts data into the format needed by the digital to analog converter. Then finally the D/A converts the samples back to voice.

All the above steps were needed because of code conversions between machines as well as numerical format (the IBM is a 32-bit machine while the HP-1000 is a 16-bit machine). Ideally, one would use the setup of figure 3.1 if the proper equipment is attainable.



3.1 Voice Processing Set Up

ORIGINAL PAGE IS
OF POOR QUALITY




Figure 3.3

This program reads a tape in ASCII Format, and converts it to a file in EBCDIC format (file: TAPRD)

```
// JOB  
//STEP1 EXEC PGM=PRESS  
//SYSPRINT DD SYSOUT=A  
//SYSIN DD DUMMY  
//SYSUT1 DD DSN=ONE,DISP=(OLD,PASS),LABEL=(1,NL),VOL=SER=CCT260,  
// UNIT=TARF,DCB=(1 RECL=80,BLKSIZE=80,RECFM=FB,LEN=3,OPT(1)=Q)  
//SYSUT2 DD DSN=WYL,CC,BHC,TAPRD,UNIT=3380,DISP=(,CATLG),  
// VOL=SER=SCROOP2,DCB=(1 RECL=6233,BLKSIZE=6233,RECFM=U,DSORG=PS),  
// SPACE=(TRK,(20,5),RLSE)  
/*  
/*
```

Figure 3.4

```

1.      This program reads a file of 32 bit floating point numbers
2.      (format 4(E14.7) per record), and converts them into a file of 12
3.      bit numbers (integers), for use in the D/A system.
4.
5.
6.
7.      // JOB TIME=4,REGION=400K
8.      // *MAIN LINES=50
9.      // EXEC FORTGCG
10.     //FORT.SYSIN DD *
11.     C ****
12.     REAL MAX
13.     DIMENSION X(32768),IX(32768)
14.     MAX=0
15.     READ(1,100,END=200) (X(J),J=1,32768)
16.     100 FORMAT(4(E14.7))
17.     DD 55 J=1,32768
18.     IF (ABS(X(J)) .GT. MAX) MAX=ABS(X(J))
19.     55      CONTINUE
20.     PRINT 70,MAX
21.     70      FORMAT(' ', 'MAX=', E14.7)
22.     DO 66 J=1,32768
23.     X(J)=X(J)/MAX
24.     X(J)=X(J)*2046.
25.     X(J)=X(J)+2047.
26.     K(J)=X(J)+.5
27.     IX(J)=X(J)
28.     66      CONTINUE
29.     WRITE(2,303) (IX(J),J=1,32768)
30.     303    FORMAT(1R(1X,I4))
31.     200    CONTINUE
32.     STOP
33.     END
34.     //GO.FT01F001 DD DSN=WYL.CC.BHC.RS1B,DISP=SHR
35.     //GO.FT02F001 DD DSN=WYL.CC.PUB.XS18,UNIT=3330,
36.     // DISP=(NEW,CATLG,CATLG),SPACE=(TRK,(14,5),RLSE),
37.     // VOL=SER=SCRO03,
38.     // DCB=(DSORG=PS,RECFM=FB,LRECL=80,BLKSIZE=6160)
39.     //GO.SYSIN DD *

```

Figure 3.5

1. This program takes a file in EBCDIC Format (FILE11)
2. - and stores it on tape in ASCII Format.
3.
4.
5. // JOB TIME=5,REGION=800K
6. //STEP1 EXEC PGM=JERGENER
7. //SYSPRINT DD SYSOUT=A
8. //SYSIN DD DUMMY
9. //SYSUT1 DD DSN=WYL.CC.PUB.FILE11,DISP=SHR,
0. // UNIT=SYSDA
1. //SYSUT2 DD DSN=ONE,UNIT=TAPE,DCB=(LRECL=80,BLKSIZE=80,RECFM=FB,
2. // DFN=3,OPTCD=Q),VOL=SER=CCT004,LABEL=(1,NL),DISP=(NEW,KEEP)
3. /*
4. //STEP6 EXEC PGM=PRESS
5. //SYSPRINT DD SYSOUT=A
6. //SYSIN DD DUMMY
7. //SYSUT1 DD DSN=ONE,DISP=(OLD,KEEP),LABEL=(1,NL),VOL=SER=CCT004,
8. // UNIT=TAPE,DCB=(LRECL=80,BLKSIZE=80,RECFM=FB,DFN=3,OPTCD=Q)
9. //SYSUT2 DD DSN=WYL.CC.PUB.NASA,UNIT=3380,DISP=(,CATLG),
0. // VOL=SER=SCR002,DCB=(LRECL=6233,BLKSIZE=6233,RECFM=U,DSORG=PS),
1. // SPACE=(TRK,(400,5),RLSE)
2. /*
3. //

Figure 3.6

```

2 PROGRAM G6WIA
3 C DEVELOPED BY: HARI P SINGH
4 C DECEMBER 1982

```

THIS PROGRAM IS DESIGNED TO READ ASCII DATA OFF A TYPE 1 FILE, CONVERTS IT INTO HP FLOATING POINT FORMAT, AND THEN STORE IT IN A TYPE 1 FILE. IT IS ASSUMED THAT THE ORIGINAL DATA IS STORED ON THE TAPE IN 80 COLUMN RECORDS 16(X,2A2), AND THAT AFTER EVERY 2048 RECORDS A NEW FILE IS TO BE CREATED.

```

12 C
13 INTEGER I,
14      IBUFF(40),
15      IDCBC(144),
16      IEPR,
17      + INAM(3),
18      + ISIZE(2),
19      + ITYPE,
20      + ITEMP,
21      + J,
22      + TRBUFF(J)
23 C
24      REAL RBUFF(4)
25 C
26      DATA ISIZE /512,128/
27      DATA ITYPE /1/
28 C
29 C
30      WRITE(1,0025)
31      FORMAT('WHAT DO YOU WANT TO NAME THIS FILE ')
32      READ ('3A2'),INAM
33 C
34      CALL CREATE(IDCBC,IERR,INAM,ISIZE,ITYPE,ISC,32767)
35      IF(IERR.LT.0)THEN
36          WRITE(1,0030)IERR
37          FORMAT('FHP ERROR NUMBER ',I4,' WHILE BUILDING DISC FILE')
38          GO TO 9999
39      ENDIF
40 C
41      DO 1000 IREC=1,512
42          DD 0300 J=1,4
43          READ(8,0100)IBUFF
44          0100
45          0200
46          FORMAT(1X,14,3X,40A2)
47 C
48 C
49 C
50 C
51 C
52 C
53 C
54 C
55 C

```

ORIGINAL PAGE IS
OF POOR QUALITY

4 THIS LOOP IS USED TO DECODE THE ASCII DATA. IN EACH OF THE EIGHT ITERATIONS TWO OF THE 16 INTEGERS ARE DECODED. THE DATA ON TAPE IS LAID OUT IN THE FORM 16(X,2A2). FIRST THREE WORDS ARE BROUGHT INTO TRBUFF. THESE WORDS CONTAIN 6 CHARACTERS: A LEADING BLANK, FOUR CHARACTERS REPRESENTING AN INTEGER, & ANOTHER BLANK. THESE ARE THE INTEGERS IN POSITIONS (1,3,5,7,9,11,13,15) NEXT THE FOUR CHARACTERS REPRESENTING THE INTEGERS IN POSITIONS (2,4,6,8,10,12,14,16) ARE DECODED

56 DD 0800 I=1,8
57 00 0800 I=1,8
58 00 0800 I=1,8
59 00 0800 I=1,8
60 00 0800 I=1,8
61 00 0800 I=1,8
62 00 0800 I=1,8
63 00 0800 I=1,8
64 00 0800 I=1,8
65 00 0800 I=1,8
66 00 0800 I=1,8
67 00 0800 I=1,8
68 00 0800 I=1,8
69 00 0800 I=1,8
70 00 0800 I=1,8
71 00 0800 I=1,8
72 00 0800 I=1,8
73 00 0800 I=1,8
74 00 0800 I=1,8
75 00 0800 I=1,8
76 00 0800 I=1,8
77 00 0800 I=1,8
78 00 0800 I=1,8
79 00 0800 I=1,8
80 00 0800 I=1,8
81 00 0800 I=1,8
82 00 0800 I=1,8
83 00 0800 I=1,8
84 00 0800 I=1,8
85 00 0800 I=1,8
86 00 0800 I=1,8
87 00 0800 I=1,8
88 00 0800 I=1,8
89 00 0800 I=1,8
90 00 0800 I=1,8
91 00 0800 I=1,8
92 00 0800 I=1,8
93 00 0800 I=1,8
94 00 0800 I=1,8
95 00 0800 I=1,8
96 00 0800 I=1,8
97 00 0800 I=1,8
98 00 0800 I=1,8
99 00 0800 I=1,8
100 00 0800 I=1,8
101 00 0800 I=1,8
102 00 0800 I=1,8
103 00 0800 I=1,8
104 00 0800 I=1,8
105 00 0800 I=1,8
106 00 0800 I=1,8
107 00 0800 I=1,8
108 00 0800 I=1,8
109 00 0800 I=1,8
110 00 0800 I=1,8
111 00 0800 I=1,8
112 00 0800 I=1,8
113 00 0800 I=1,8
114 00 0800 I=1,8
115 00 0800 I=1,8
116 00 0800 I=1,8
117 00 0800 I=1,8
118 00 0800 I=1,8
119 00 0800 I=1,8
120 00 0800 I=1,8
121 00 0800 I=1,8
122 00 0800 I=1,8
123 00 0800 I=1,8
124 00 0800 I=1,8
125 00 0800 I=1,8
126 00 0800 I=1,8
127 00 0800 I=1,8
128 00 0800 I=1,8
129 00 0800 I=1,8
130 00 0800 I=1,8
131 00 0800 I=1,8
132 00 0800 I=1,8
133 00 0800 I=1,8
134 00 0800 I=1,8
135 00 0800 I=1,8
136 00 0800 I=1,8
137 00 0800 I=1,8
138 00 0800 I=1,8
139 00 0800 I=1,8
140 00 0800 I=1,8
141 00 0800 I=1,8
142 00 0800 I=1,8
143 00 0800 I=1,8
144 00 0800 I=1,8
145 00 0800 I=1,8
146 00 0800 I=1,8
147 00 0800 I=1,8
148 00 0800 I=1,8
149 00 0800 I=1,8
150 00 0800 I=1,8
151 00 0800 I=1,8
152 00 0800 I=1,8
153 00 0800 I=1,8
154 00 0800 I=1,8
155 00 0800 I=1,8
156 00 0800 I=1,8
157 00 0800 I=1,8
158 00 0800 I=1,8
159 00 0800 I=1,8
160 00 0800 I=1,8
161 00 0800 I=1,8
162 00 0800 I=1,8
163 00 0800 I=1,8
164 00 0800 I=1,8
165 00 0800 I=1,8
166 00 0800 I=1,8
167 00 0800 I=1,8
168 00 0800 I=1,8
169 00 0800 I=1,8
170 00 0800 I=1,8
171 00 0800 I=1,8
172 00 0800 I=1,8
173 00 0800 I=1,8
174 00 0800 I=1,8
175 00 0800 I=1,8
176 00 0800 I=1,8
177 00 0800 I=1,8
178 00 0800 I=1,8
179 00 0800 I=1,8
180 00 0800 I=1,8
181 00 0800 I=1,8
182 00 0800 I=1,8
183 00 0800 I=1,8
184 00 0800 I=1,8
185 00 0800 I=1,8
186 00 0800 I=1,8
187 00 0800 I=1,8
188 00 0800 I=1,8
189 00 0800 I=1,8
190 00 0800 I=1,8
191 00 0800 I=1,8
192 00 0800 I=1,8
193 00 0800 I=1,8
194 00 0800 I=1,8
195 00 0800 I=1,8
196 00 0800 I=1,8
197 00 0800 I=1,8
198 00 0800 I=1,8
199 00 0800 I=1,8
200 00 0800 I=1,8
201 00 0800 I=1,8
202 00 0800 I=1,8
203 00 0800 I=1,8
204 00 0800 I=1,8
205 00 0800 I=1,8
206 00 0800 I=1,8
207 00 0800 I=1,8
208 00 0800 I=1,8
209 00 0800 I=1,8
210 00 0800 I=1,8
211 00 0800 I=1,8
212 00 0800 I=1,8
213 00 0800 I=1,8
214 00 0800 I=1,8
215 00 0800 I=1,8
216 00 0800 I=1,8
217 00 0800 I=1,8
218 00 0800 I=1,8
219 00 0800 I=1,8
220 00 0800 I=1,8
221 00 0800 I=1,8
222 00 0800 I=1,8
223 00 0800 I=1,8
224 00 0800 I=1,8
225 00 0800 I=1,8
226 00 0800 I=1,8
227 00 0800 I=1,8
228 00 0800 I=1,8
229 00 0800 I=1,8
230 00 0800 I=1,8
231 00 0800 I=1,8
232 00 0800 I=1,8
233 00 0800 I=1,8
234 00 0800 I=1,8
235 00 0800 I=1,8
236 00 0800 I=1,8
237 00 0800 I=1,8
238 00 0800 I=1,8
239 00 0800 I=1,8
240 00 0800 I=1,8
241 00 0800 I=1,8
242 00 0800 I=1,8
243 00 0800 I=1,8
244 00 0800 I=1,8
245 00 0800 I=1,8
246 00 0800 I=1,8
247 00 0800 I=1,8
248 00 0800 I=1,8
249 00 0800 I=1,8
250 00 0800 I=1,8
251 00 0800 I=1,8
252 00 0800 I=1,8
253 00 0800 I=1,8
254 00 0800 I=1,8
255 00 0800 I=1,8
256 00 0800 I=1,8
257 00 0800 I=1,8
258 00 0800 I=1,8
259 00 0800 I=1,8
260 00 0800 I=1,8
261 00 0800 I=1,8
262 00 0800 I=1,8
263 00 0800 I=1,8
264 00 0800 I=1,8
265 00 0800 I=1,8
266 00 0800 I=1,8
267 00 0800 I=1,8
268 00 0800 I=1,8
269 00 0800 I=1,8
270 00 0800 I=1,8
271 00 0800 I=1,8
272 00 0800 I=1,8
273 00 0800 I=1,8
274 00 0800 I=1,8
275 00 0800 I=1,8
276 00 0800 I=1,8
277 00 0800 I=1,8
278 00 0800 I=1,8
279 00 0800 I=1,8
280 00 0800 I=1,8
281 00 0800 I=1,8
282 00 0800 I=1,8
283 00 0800 I=1,8
284 00 0800 I=1,8
285 00 0800 I=1,8
286 00 0800 I=1,8
287 00 0800 I=1,8
288 00 0800 I=1,8
289 00 0800 I=1,8
290 00 0800 I=1,8
291 00 0800 I=1,8
292 00 0800 I=1,8
293 00 0800 I=1,8
294 00 0800 I=1,8
295 00 0800 I=1,8
296 00 0800 I=1,8
297 00 0800 I=1,8
298 00 0800 I=1,8
299 00 0800 I=1,8
300 00 0800 I=1,8
301 00 0800 I=1,8
302 00 0800 I=1,8
303 00 0800 I=1,8
304 00 0800 I=1,8
305 00 0800 I=1,8
306 00 0800 I=1,8
307 00 0800 I=1,8
308 00 0800 I=1,8
309 00 0800 I=1,8
310 00 0800 I=1,8
311 00 0800 I=1,8
312 00 0800 I=1,8
313 00 0800 I=1,8
314 00 0800 I=1,8
315 00 0800 I=1,8
316 00 0800 I=1,8
317 00 0800 I=1,8
318 00 0800 I=1,8
319 00 0800 I=1,8
320 00 0800 I=1,8
321 00 0800 I=1,8
322 00 0800 I=1,8
323 00 0800 I=1,8
324 00 0800 I=1,8
325 00 0800 I=1,8
326 00 0800 I=1,8
327 00 0800 I=1,8
328 00 0800 I=1,8
329 00 0800 I=1,8
330 00 0800 I=1,8
331 00 0800 I=1,8
332 00 0800 I=1,8
333 00 0800 I=1,8
334 00 0800 I=1,8
335 00 0800 I=1,8
336 00 0800 I=1,8
337 00 0800 I=1,8
338 00 0800 I=1,8
339 00 0800 I=1,8
340 00 0800 I=1,8
341 00 0800 I=1,8
342 00 0800 I=1,8
343 00 0800 I=1,8
344 00 0800 I=1,8
345 00 0800 I=1,8
346 00 0800 I=1,8
347 00 0800 I=1,8
348 00 0800 I=1,8
349 00 0800 I=1,8
350 00 0800 I=1,8
351 00 0800 I=1,8
352 00 0800 I=1,8
353 00 0800 I=1,8
354 00 0800 I=1,8
355 00 0800 I=1,8
356 00 0800 I=1,8
357 00 0800 I=1,8
358 00 0800 I=1,8
359 00 0800 I=1,8
360 00 0800 I=1,8
361 00 0800 I=1,8
362 00 0800 I=1,8
363 00 0800 I=1,8
364 00 0800 I=1,8
365 00 0800 I=1,8
366 00 0800 I=1,8
367 00 0800 I=1,8
368 00 0800 I=1,8
369 00 0800 I=1,8
370 00 0800 I=1,8
371 00 0800 I=1,8
372 00 0800 I=1,8
373 00 0800 I=1,8
374 00 0800 I=1,8
375 00 0800 I=1,8
376 00 0800 I=1,8
377 00 0800 I=1,8
378 00 0800 I=1,8
379 00 0800 I=1,8
380 00 0800 I=1,8
381 00 0800 I=1,8
382 00 0800 I=1,8
383 00 0800 I=1,8
384 00 0800 I=1,8
385 00 0800 I=1,8
386 00 0800 I=1,8
387 00 0800 I=1,8
388 00 0800 I=1,8
389 00 0800 I=1,8
390 00 0800 I=1,8
391 00 0800 I=1,8
392 00 0800 I=1,8
393 00 0800 I=1,8
394 00 0800 I=1,8
395 00 0800 I=1,8
396 00 0800 I=1,8
397 00 0800 I=1,8
398 00 0800 I=1,8
399 00 0800 I=1,8
400 00 0800 I=1,8
401 00 0800 I=1,8
402 00 0800 I=1,8
403 00 0800 I=1,8
404 00 0800 I=1,8
405 00 0800 I=1,8
406 00 0800 I=1,8
407 00 0800 I=1,8
408 00 0800 I=1,8
409 00 0800 I=1,8
410 00 0800 I=1,8
411 00 0800 I=1,8
412 00 0800 I=1,8
413 00 0800 I=1,8
414 00 0800 I=1,8
415 00 0800 I=1,8
416 00 0800 I=1,8
417 00 0800 I=1,8
418 00 0800 I=1,8
419 00 0800 I=1,8
420 00 0800 I=1,8
421 00 0800 I=1,8
422 00 0800 I=1,8
423 00 0800 I=1,8
424 00 0800 I=1,8
425 00 0800 I=1,8
426 00 0800 I=1,8
427 00 0800 I=1,8
428 00 0800 I=1,8
429 00 0800 I=1,8
430 00 0800 I=1,8
431 00 0800 I=1,8
432 00 0800 I=1,8
433 00 0800 I=1,8
434 00 0800 I=1,8
435 00 0800 I=1,8
436 00 0800 I=1,8
437 00 0800 I=1,8
438 00 0800 I=1,8
439 00 0800 I=1,8
440 00 0800 I=1,8
441 00 0800 I=1,8
442 00 0800 I=1,8
443 00 0800 I=1,8
444 00 0800 I=1,8
445 00 0800 I=1,8
446 00 0800 I=1,8
447 00 0800 I=1,8
448 00 0800 I=1,8
449 00 0800 I=1,8
450 00 0800 I=1,8
451 00 0800 I=1,8
452 00 0800 I=1,8
453 00 0800 I=1,8
454 00 0800 I=1,8
455 00 0800 I=1,8
456 00 0800 I=1,8
457 00 0800 I=1,8
458 00 0800 I=1,8
459 00 0800 I=1,8
460 00 0800 I=1,8
461 00 0800 I=1,8
462 00 0800 I=1,8
463 00 0800 I=1,8
464 00 0800 I=1,8
465 00 0800 I=1,8
466 00 0800 I=1,8
467 00 0800 I=1,8
468 00 0800 I=1,8
469 00 0800 I=1,8
470 00 0800 I=1,8
471 00 0800 I=1,8
472 00 0800 I=1,8
473 00 0800 I=1,8
474 00 0800 I=1,8
475 00 0800 I=1,8
476 00 0800 I=1,8
477 00 0800 I=1,8
478 00 0800 I=1,8
479 00 0800 I=1,8
480 00 0800 I=1,8
481 00 0800 I=1,8
482 00 0800 I=1,8
483 00 0800 I=1,8
484 00 0800 I=1,8
485 00 0800 I=1,8
486 00 0800 I=1,8
487 00 0800 I=1,8
488 00 0800 I=1,8
489 00 0800 I=1,8
490 00 0800 I=1,8
491 00 0800 I=1,8
492 00 0800 I=1,8
493 00 0800 I=1,8
494 00 0800 I=1,8
495 00 0800 I=1,8
496 00 0800 I=1,8
497 00 0800 I=1,8
498 00 0800 I=1,8
499 00 0800 I=1,8
500 00 0800 I=1,8
501 00 0800 I=1,8
502 00 0800 I=1,8
503 00 0800 I=1,8
504 00 0800 I=1,8
505 00 0800 I=1,8
506 00 0800 I=1,8
507 00 0800 I=1,8
508 00 0800 I=1,8
509 00 0800 I=1,8
510 00 0800 I=1,8
511 00 0800 I=1,8
512 00 0800 I=1,8
513 00 0800 I=1,8
514 00 0800 I=1,8
515 00 0800 I=1,8
516 00 0800 I=1,8
517 00 0800 I=1,8
518 00 0800 I=1,8
519 00 0800 I=1,8
520 00 0800 I=1,8
521 00 0800 I=1,8
522 00 0800 I=1,8
523 00 0800 I=1,8
524 00 0800 I=1,8
525 00 0800 I=1,8
526 00 0800 I=1,8
527 00 0800 I=1,8
528 00 0800 I=1,8
529 00 0800 I=1,8
530 00 0800 I=1,8
531 00 0800 I=1,8
532 00 0800 I=1,8
533 00 0800 I=1,8
534 00 0800 I=1,8
535 00 0800 I=1,8
536 00 0800 I=1,8
537 00 0800 I=1,8
538 00 0800 I=1,8
539 00 0800 I=1,8
540 00 0800 I=1,8
541 00 0800 I=1,8
542 00 0800 I=1,8
543 00 0800 I=1,8
544 00 0800 I=1,8
545 00 0800 I=1,8
546 00 0800 I=1,8
547 00 0800 I=1,8
548 00 0800 I=1,8
549 00 0800 I=1,8
550 00 0800 I=1,8
551 00 0800 I=1,8
552 00 0800 I=1,8
553 00 0800 I=1,8
554 00 0800 I=1,8
555 00 0800 I=1,8
556 00 0800 I=1,8
557 00 0800 I=1,8
558 00 0800 I=1,8
559 00 0800 I=1,8
560 00 0800 I=1,8
561 00 0800 I=1,8
562 00 0800 I=1,8
563 00 0800 I=1,8
564 00 0800 I=1,8
565 00 0800 I=1,8
566 00 0800 I=1,8
567 00 0800 I=1,8
568 00 0800 I=1,8
569 00 0800 I=1,8
570 00 0800 I=1,8
571 00 0800 I=1,8
572 00 0800 I=1,8
573 00 0800 I=1,8
574 00 0800 I=1,8
575 00 0800 I=1,8
576 00 0800 I=1,8
577 00 0800 I=1,8
578 00 0800 I=1,8
579 00 0800 I=1,8
580 00 0800 I=1,8
581 00 0800 I=1,8
582 00 0800 I=1,8
583 00 0800 I=1,8
584 00 0800 I=1,8
585 00 0800 I=1,8
586 00 0800 I=1,8
587 00 0800 I=1,8
588 00 0800 I=1,8
589 00 0800 I=1,8
590 00 0800 I=1,8
591 00 0800 I=1,8
592 00 0800 I=1,8
593 00 0800 I=1,8
594 00 0800 I=1,8
595 00 0800 I=1,8
596 00 0800 I=1,8
597 00 0800 I=1,8
598 00 0800 I=1,8
599 00 0800 I=1,8
600 00 0800 I=1,8
601 00 0800 I=1,8
602 00 0800 I=1,8
603 00 0800 I=1,8
604 00 0800 I=1,8
605 00 0800 I=1,8
606 00 0800 I=1,8
607 00 0800 I=1,8
608 00 0800 I=1,8
609 00 0800 I=1,8
610 00 0800 I=1,8
611 00 0800 I=1,8
612 00 0800 I=1,8
613 00 0800 I=1,8
614 00 0800 I=1,8
615 00 0800 I=1,8
616 00 0800 I=1,8
617 00 0800 I=1,8
618 00 0800 I=1,8
619 00 0800 I=1,8
620 00 0800 I=1,8
621 00 0800 I=1,8
622 00 0800 I=1,8
623 00 0800 I=1,8
624 00 0800 I=1,8
625 00 0800 I=1,8
626 00 0800 I=1,8
627 00 0800 I=1,8
628 00 0800 I=1,8
629 00 0800 I=1,8
630 00 0800 I=1,8
631 00 0800 I=1,8
632 00 0800 I=1,8
633 00 0800 I=1,8
634 00 0800 I=1,8
635 00 0800 I=1,8
636 00 0800 I=1,8
637 00 0800 I=1,8
638 00 0800 I=1,8
639 00 0800 I=1,8
640 00 0800 I=1,8
641 00 0800 I=1,8
642 00 0800 I=1,8
643 00 0800 I=1,8
644 00 0800 I=1,8
645 00 0800 I=1,8
646 00 0800 I=1,8
647 00 0800 I=1,8
648 00 0800 I=1,8
649 00 0800 I=1,

PAGE 2 DATA UPTS. LVI 4:17 PM MON., 22 FEB . 1982

```

57    TRUFF(1)=IBUFF(((I-1)*5)+1)
58    TRUFF(2)=IBUFF(((I-1)*5)+2)
59    TRUFF(3)=IBUFF(((I-1)*5)+3)
60    DECUE(j,500,TRUFF)ITEMP
61    RBUF(((J-1)*16)+((I-1)*2)+1)=REHL(ITEMP)
62    TRUFF(1)=IBUFF(((I-1)*5)+4)
63    TRUFF(2)=IBUFF(((I-1)*5)+5)
64    DECUE(4,0500,TRUF)ITEMP
65    RBUF(((J-1)*16)+((I-1)*2)+2)=REHL(ITEMP)
66    FORMAT(16)
67    0800
68    C
69    0900  CONTINUE
70    C
71    CCCC WRITE(6,0905)RBUFF
72    0905  FORMAT(4,16X,F5,0),'
73    CALL WRIT(1DCB,TERR,RBUFF)           ! WRITE A RECORD TO DISC
74    IF(IERR.LT.0)THEN                  ! FMP ERROR
75    WRITE(1,0920)IERR                 ! WRITE ERROR MESSAGE
76    0920  FORMAT(F1P,EERR,HUIER      ! 14, WHILE WRITING TO DISC
77    GO TO 9999                         ! EXIT PROGRAM
78    ENDIF
79    1000  CONTINUE
80    C
81    WRITE(1,0930)                      ! CLOSE FILE
82    0930  FORMAT('DO YOU WISH TO BUILD ANOTHER FILE (Y/N) ')
83    READ '(A2)',IANSUR
84    IF(IANSUR.EQ.'Y')GO TO 0010
85    9999  CONTINUE
86    C
87    CALL CLOSE(1DCB,TERR)              ! CLOSE FILE
88    IF(IERR.LT.0)THEN                  ! FMP ERROR
89    WRITE(1,0920)IERR                 ! WRITE ERROR MESSAGE
90    0920  FORMAT(F1P,EERR,NUMBER ',P4,   ! WHILE CLOSING FILE,
91    ENDIF
92    C
93    END

```

FTH4X COMPILER: HP92834 REV. 2226 (820503)

* NO WARNINGS * NO ERRORS ** PROGRAM: 745 COMMON: <NONE>

4. User's Guide

This user's guide will provide the user with a step by step explanation of the questions that will be asked during a typical session with the simulator. References are given in each question so that the user can refer to the appropriate sections if an in depth discussion about the topic is desired (references made refer to the first report, "A Computer Simulator for a Mobile Telephone System", NASA Grant 3-119).

The following is a typical question-and-answer session with all the possible questions either being asked or presented in the explanation. The answers shown here are for a batch version version for a run. In an actual run, the answers shown would come out on the same line as the question. However we have separated them here onto separate lines for clarity. For an online session, merely the question will be prompted unto the user terminal, for which he would interactively enter his response.

The first question asked prompts the user as to whether the session is an online or batch session, and is displayed as follows:

Is this an online session? (Y/N) (1)
N

The user should answer a 'Y' if it is an online session, or an 'N' if it is a batch session. In this case the response is "N" (no).

Next, the type of calls that are available in the communication system are displayed as follows:

communication system are displayed as follows:

TYPE OF CALL AVAILABLE: (2)

- 1: M1->M2, rural mobile to rural mobile in same UHF beam
 - 2: M1->M3, rural mobile to rural mobile in different UHF beam, in same S-band
 - 3: M1->M4, rural mobile to rural mobile in different UHF beam, in different S-band.
 - 4: M1->FC1, rural mobile to fixed in same S-band beam
 - 5: M1->FC2, rural mobile to fixed in different S-band beam
 - 6: FC1->M1, fixed to rural mobile in same S-band beam
 - 7: FC2->M1, fixed to rural mobile in different S-band beam
- INPUT TYPE OF CALL TO BE SIMULATED:

1

Here the type of calls that are available in the communication system are displayed, each one being designated by a number from 1 through 7. Right after the list, the user is prompted to input the type of call he wishes to be simulated by inputting a number from 1 through 7. In this case, the first call ("1") was chosen. For an explanation of each of these calls, see section 2.2.

After the user has inputted the type of call to be simulated, the modes of call available within the type of call selected will be displayed (refer to section 2.3). In this case, the user chose to simulate type 1, which is rural mobile calling rural mobile in the same UHF-beam and S-beam. Correspondingly, the following choice of modes was displayed:

MODE OF CALL AVAILABLE: (3)

- 1: M1->M2, hard wired transponder
 - 2: M1->M2, direct switched transponder
 - 3: M1->M2, indirect switched transponder
 - 4: M1->G1->M2, double hop system
- INPUT MODE OF CALL TO BE SIMULATED:

1

Note that the type of modes that will be displayed depends on the type of call that is chosen (in this case type 1 was chosen). A full list of the range of possible modes corresponding to the

**ORIGINAL PAGE IS
OF POOR QUALITY**

type of call chosen is found in section 2.3. (table 2.3.1).

One notes that following the list of modes available, the user is prompted to input the mode of the call by entering its corresponding number. In this case the user chose "1", from a choice of 1 to 4.

Based on the type of call and mode of call selected, the program will determine which scenario to be simulated (refer to section 3.3). The questions asked from this point on will vary depending on the features to be simulated within the scenario. Even though each of the five scenarios are different, the questions to be answered for each of them are more or less of the same nature. Therefore the rest of our discussion will focus only on those questions that are asked when the single hop system is to be simulated (which is the case of this particular simulation run).

In the next question, the user is asked to choose from the types of signal sources available. Choice 1, corresponds to a program generated sinusoid which can be used for making analytical tests. If choice "1" is chosen, no further questions about the signal source are asked and question (4) is then displayed. Choice "2" corresponds to sampled voice. If type 2 is chosen, then see section 3.2 for an explanation of procedures to be used.

TYPES OF SIGNAL SOURCES AVAILABLE:

- 1: Program generated single tone sinusoid.
 - 2: Sampled voice from tape source.
- Choose type of signal to be used (1l):

1

In the next question,

FREQUENCY OF THE BASEBAND SIGNAL (LESS THAN 3000 HZ.) (4)
(IN HERTZ, F7.2):

1000.00 HZ

the user is asked to input the frequency of the baseband signal in hertz using the format "F7.2". The baseband signal has an upper limit of 3000 Hz (refer to section 5).

The next question displayed is as follows:

NOTE: POWER OF THE BASEBAND SIGNAL HAS TO BE LESS OR EQUAL (5)
THAN .5 WATTS;
SO THAT THE MAXIMUM INSTANTANEOUS FREQUENCY DEVIATION IS
LESS OR EQUAL THAN 12000 HZ
POWER OF THE BASEBAND SIGNAL (IN WATTS, F7.2): (6)
0.50 WATTS

Here the user inputs the power of the baseband signal in watts using the format F7.2. The power of the baseband signal has to be less than or equal to .5 watts, so that the maximum instantaneous frequency deviation is less than or equal to 12000 Hz (refer to section 5).

In the next question that appears

THE CARRIER POWER (IN WATTS, F7.2): (7)
1.00 WATTS

the user is asked to input the carrier signal power in watts using the format F7.2.

The next question appearing,

THE FREQUENCY DEVIATION (IN HERTZ, F8.2): 12000 HZ. (8)
(FIXED FOR NOW)

asks the user to input the frequency deviation in Hertz using the format F8.2. Under the current version, the frequency deviation is fixed at 12,000 Hz in order for the simulator to meet AMPS specifications (refer to section 5).

The next question is displayed as follows:

How many times the nyquist rate do you want the sampling frequency to be? (2 - 4, 11): (9)

Here the user is asked to input the sampling frequency in terms of a multiple of the Nyquist rate. Acceptable values are from twice the nyquist rate to four times the Nyquist rate. Twice the Nyquist rate is the minimum in order for the simulator to intergrate and differentiate correctly. Four times the Nyquist rate is the maximum since any increase of the sampling frequency beyond this point will not improve any significant approximation, but will prolong run time substantially (refer to section 3.2).

In the next question,

THE CARRIER FREQUENCY (IN HERTZ, F7.2):(NOT USED FOR NOW) (10)

the user is asked to input the carrier frequencyin Hertz using the format F7.2. Under the current version of the simulator, the carrier frequency is not used in the simulation.

The next question is displayed as follows:

DO YOU WANT THE COMPRESSOR/EXPANDER IN? Y-YES , N-NO : (11)
Y

Here the user is asked whether the compressor/expander (AMPS specs) are used in the transmitter and receiver (refer to section 5). This question is answered either with a "Y" (yes) or an "N" (no).

The next question appears as follows:

DO YOU WANT THE PRE-EMPHASIS - DE-EMPHASIS FILTERS IN ? (12)
Y-YES , N-NO :
Y

Here the user is asked whether pre-emphasis and de-emphasis filters (AMPS specs) are used in the transmitter and receiver (see section 5).

The user is then prompted as to whether or not interference is

present in the UHF uplink satellite channel. This question is displayed as follows:

DO YOU WANT A CO-CHANNEL INTERFERER IN THE UPLINK? (13)
Y-YES,N-NO:

Y
Are multiple values of the carrier to interference power ratio to be tested? (Y/N): (14)

Y
Input the range of values to be tested (in dB): (15)
Input the initial value (-99 -- +99,I3): 10 DB

Input the increment value (01 -- 99,I3): 10 DB (16)
Input the final value (01 -- 99,I3): 70 DB (17)

Y
Are multiple values of the interference phase values to be tested? (Y/N): (18)

Y
Input the range of values to be tested (in degrees): (19)
Input the initial value (F6.2) : 10.00 DEGREES

Input the increment value (F6.2) : 5.00 DEGREES (20)
Input the final value (F6.2) : 25.00 DEGREES (21)

Note the answer to the first of these questions was "Y" (yes). If the response was "N" (no interference), then the next eight questions would not have appeared. However, since in this case the response is yes, they did appear. In the first of these questions (14), the user is asked if he wishes to input a range of values for the carrier to interference power ratio. If the answer is "Y" (yes), as in this case, then questions 15-17 will follow. Here, the user inputs the initial value, increment value, and final value respectively (in dB, using the format I3) of the carrier to interference power ratio. If the answer to question (14) was "N" (no), then the user would have just been asked to input one value of the carrier to interference power ratio in the same format as above. After question 17, the user is asked whether he wants to

input a range of phase values for the interference source (question 18). If the response to this is "Y" (yes), then questions 19-21 will appear, asking the user to input the initial, incremental, and final value of the phase, respectively (using format F6.2 , in degrees). If the response to question 18 was "N" (no), then a question would have appeared asking only one value for the phase.

In the next question,

IS FADING PRESENT IN THE UPLINK CHANNEL? Y-YES,N-NO: (22)
Y

one responds as to whether or not the uplink satellite channel is a fading channel or not. One responds to the question by either typing a "Y" for yes or a "N" for no. If the response is no, the next five questions (questions 23-28) will not appear. However, as in this case, if the response is yes, then questions 24 through 28 will definitely appear. If interference is present, as is the case in the current simulation run, then question 23 will also appear. If interference were not present in the uplink, then question 23 would have not been asked. Questions 23-28 are displayed as follows:

IS THE INTERFERENCE FADED? Y-YES,N-NO: (23)
Y

THE UPLINK FADING CHANNEL IS PRESENT
TYPES OF FADING CHANNELS AVAILABLE: (24)
1: NO SPECULAR COMPONENT (RALEIGH FADING)
2: SPECULAR COMPONENT, SHORTEST PATH
3: SPECULAR COMPONENT, MEAN PATH
INPUT TYPE OF CHANNEL:
2

ENTER THE MULTIPATH SPREAD TIME (IN MICROSECONDS, F9.2): (25)
500.00 MICROSECONDS

ENTER THE DOPPLER SPREAD BANDWIDTH (IN HERTZ, F7.2): (26)
1.00 Hz

Are multiple values of the specular to multipath power ratio to be tested? (Y/N) : (27)

N

ENTER THE SPECULAR-TO-MULTIPATH POWER RATIO (IN DB, I3): (28)
- - -
100 DB

In the first of these questions, the user respond's as to whether or not the interference is effected by the fading channel. If it is, it is done so independently of the signal and is added at the end. If it is not, then the interference is just added to the faded signal.

In the second of these questions, the user decides which type of fading is present, by entering a 1 digit number from 1 to 3 corresponding to the type of fading that is present. If (1) is chosen, then the fading channel will be a Rayleigh distributed one with no specular component. If (3) is chosen, then the channel will have Rician statistics, with the specular component in the middle. In other words, the mean path is taken. In the last case, (2), the channel has Rician statistics with the shortest path being taken (refer to section 6).

In the third of these questions (25), the user is asked to input the total multipath spread time of the fading channel in microseconds using the format F9.2. In this case, "500.00" was entered as data.

In question (26), the user is asked to input the doppler spread bandwidth of the fading channel in Hertz using the format F7.2. In this case the number "1.00" was entered as data.

Question (27) will only be asked if the response to question (24) is either 2 or 3. If the response is 1, then Rayleigh fading is being used which exhibits no specular component. Question (27)

44

once again asks whether or not the user wishes to input a range of values for the specular to multipath power ratios (in dB). In this case the answer is "N" (no), and thus question (28) appears, which asks the user to input only one value of the specular to multipath power ratio (in dB) using the format I3 (in this case 100 was entered as data). If the response to question (27) was yes, then three questions asking for the initial, incremental, and final values respectively (using the same input format as question (28)) would have been displayed as they have in the questions asked previously.

The next question,

DO YOU WANT A CO-CHANNEL INTERFERER IN THE DOWNLINK? (29)
Y-YES,N-NO:

Y
Are multiple values of the carrier to interference power ratio to be tested ? (Y/N) : (30)

N
INPUT CARRIER TO INTERFERENCE POWER RATIO IN DB(I3): (31)
30 DB

Are multiple values of the interference phase values to be tested ? (Y/N): (32)

N
INPUT PHASE OF INTERFERENCE IN DEGREES (F7.2): (32.1)
30.80 DEGREES

is the dual of the uplink interference case. The data entry is exactly the same as it were for the uplink case. Note however, in this case that the responses to the questions asking if the user wants to input a range of values are both negative. In this case the user is only inputting single values (030 dB for the power ratio, and 30.80 Degrees for the phase).

The next question,

IS FADING PRESENT IN THE DOWNLINK CHANNEL? Y-YES,N-NO: (33)
Y

is basically the dual of the uplink case, the only exception however is the facility for a space diversity receiver. Once again, if the response to the above question is "N" (no), then questions 34 through 45 will not be asked. If the response is "Y" (yes), the next question that will be displayed is:

IS A SPACE DIVERSITY RECEIVER BEING USED? Y-YES,N-NO: (34)
Y

If a space diversity receiver is being used (response "Y"), as is the case for this example, then parameters for 2 fading channels will have to be set; questions 36 through 40 for the first channel and questions 41 through 45 for the second channel. If a space diversity receiver is not being used (response "N"), then the user will only be prompted to enter parameters for one channel.

If co-channel interference is present in the downlink channel (response to (29) is "Y"), then the following question will be displayed:

IS THE INTERFERENCE FADED? Y-YES,N-NO: (35)
Y

Here one enters whether or not the interference should be faded. If yes (as in this case), the user enters a "Y", and if not, the user enters an "N".

Questions 36 through 40 or questions 36 through 45 if a space diversity receiver is present, are entered in an analogous way as were the questions for the uplink satellite channel.

THE DOWNLINK FADING CHANNEL IS PRESENT
SET PARAMETERS FOR FIRST FADING CHANNEL: (36)
TYPES OF FADING CHANNELS AVAILABLE:
1: NO SPECULAR COMPONENT (RALEIGH FADING)
2: SPECULAR COMPONENT, SHORTEST PATH
3: SPECULAR COMPONENT, MEAN PATH

INPUT TYPE OF CHANNEL:

ENTER THE MULTIPATH SPREAD TIME (IN MICROSECONDS, F9.2): (37)
 500.00 MICROSECONDS

ENTER THE DOPPLER SPREAD BANDWIDTH (IN HERTZ, F7.2): (38)
 1.00 HZ

Are multiple values of the specular to multipath power (39)
ratio to be tested? (Y/N):

N

ENTER THE SPECULAR-TO-MULTIPATH POWER RATIO (IN DB, I3): (40)
 100 DB

SET PARAMETERS FOR THE SECOND FADING CHANNEL: (41)

TYPES OF FADING CHANNELS AVAILABLE:

- 1: NO SPECULAR COMPONENT (RALEIGH FADING)
- 2: SPECULAR COMPONENT, SHORTEST PATH
- 3: SPECULAR COMPONENT, MEAN PATH

INPUT TYPE OF CHANNEL:

2

ENTER THE MULTIPATH SPREAD TIME (IN MICROSECONDS, F9.2): (42)
 500.00 MICROSECONDS

ENTER THE DOPPLER SPREAD BANDWIDTH (IN HERTZ, F7.2): (43)
 1.00 HZ

Are multiple values of the specular to multipath power (44)
ratio to be tested? (Y/N):

N

ENTER THE SPECULAR-TO-MULTIPATH POWER RATIO (IN DB, I3): (45)
 100 DB

In the next question,

Are multiple SNR values to be tested? Y-yes,N-no: (46)
 Y

the user is asked whether multiple SNR values are to be tested.
If the response is "Y" (yes), then questions 47.1 through 47.3
will appear asking the user to input the range of SNR's (in this
case, the carrier to noise ratio) for the Gaussian noise in the
mobile receiver. If multiple SNR values are not to be tested
(response "N"), then the user will be asked to input only one SNR
value.

Questions 47.1/47.3 would appear as follows:

ORIGINAL PAGE IS
OF POOR QUALITY

Input the range of SNR values to be tested (in Db): (47)
Input the initial value of SNR (-99 -- +99, I3): (47.1)

36 DB

Input the increment value (01 -- 99, I2): (47.2)

4 DB

Input the ending value of SNR (-99 -- +99, I3): (47.3)

40 DB

In the next question,

IS A SPACE DIVERSITY RECEIVER REQUIRED? (Y/N) (48)
Y

the user is asked whether or not a space diversity receiver is to be used. If it is present (response "Y"), then the user will be asked (next question) to input the duration of the decision period which is the duration of the lapse time before a decision is made to determine which receiver is receiving a stronger signal. If it is not present (response "N"), then the next question (49) will not displayed.

INPUT DURATION BETWEEN DECISION TIMES FOR THE S.D. RECEIVER (F7.5, IN SECONDS) (49)
0.00020SEC.

The next question is displayed as follows:

Input the approximate duration of simulation in seconds (50)
(0.01 - 9.99, F4.2):
0.01 SEC.

Here the user inputs the approximate duration of the input signal to be tested in seconds using the format F7.5. For now, the boundary imposed is from 0.01 seconds to 9.99 seconds (refer to section 4.1).

In the next question displayed,

Type of performance measurement available: (51)
1. Compare recovered output signal to original input signal
2. Measure output signal to noise ratio

Input type:

1

the user is asked to input the type of performance to be measured. Under the current version, the user has the choice of choosing either to compare the recovered output signal to the original input signal (choice "1"), or (choice "2") to measure the output signal to noise ratio vs input signal to noise ratio (refer to section 4.2). If choice 2 is chosen, the user will be asked if he wishes that a plot be displayed of the input vs output SNR values. asked. However, if choice 1 is chosen, as is the case in this example, than the following will be the last question displayed:

DO YOU WANT OUTPUT TO BE PLOTTED? (52)

Y

Here the user has the option of having the output vs input signals plotted. If the response to this question is "Y" (yes), then following the printing of the input vs output signal values (for each respective SNR value), a graph will be plotted corresponding to these values. The maximum possible length of the graph is 2000 lines (per SNR value). If the response is "N" (no), then just the values without a graph will be printed.

A few lines of the resulting output are printed as follows:

ORIGINAL PAGE IS
OF POOR QUALITY

Input signal	Output signal (No Noise)	Output signal (With Noise)
The SNR is 36.00 DB		
0.1000000E 01	-0.3008653E 02	0.6992087E 02
0.9972572E 00	-0.9639141E 03	0.2256493E 04
0.9890135E 00	-0.7375438E 04	0.1755339E 05
0.9752213E 00	-0.2662992E 05	0.6575075E 05
0.9557958E 00	-0.6205368E 05	0.1653216E 06
0.9305050E 00	-0.1081285E 06	0.3328434E 06
0.8994539E 00	-0.1487061E 06	0.5898719E 06
0.8620588E 00	-0.1609989E 06	0.9725955E 06
0.8180044E 00	-0.1277967E 06	0.1540994E 07
0.7666720E 00	-0.5651906E 05	0.2387130E 07
0.7071075E 00	-0.7818813E 03	0.3643070E 07
0.6377603E 00	0.7991531E 05	0.5487024E 07
0.5558942E 00	0.4918778E 06	0.8145275E 07
0.4559756E 00	0.1515125E 07	0.1188825E 08
0.3233112E 00	0.3496630E 07	0.1701875E 08
0.1490450E-02	0.6825587E 07	0.2384659E 08
-0.3233029E 00	0.1189424E 08	0.3265666E 08
-0.4559686E 00	0.1904904E 08	0.4366894E 08
-0.5558881E 00	0.2853454E 08	0.5699677E 08
-0.6377543E 00	0.4043526E 08	0.7258918E 08
-0.7071018E 00	0.5462040E 08	0.9018307E 08
:	:	:

720.
 721.
 722.
 723.
 724.
 725.
 726.
 727.
 728.
 729.
 730.
 731.
 732.
 733.
 734.
 735.
 736.
 737.
 738.
 739.
 740.
 741.
 742.
 743.
 744.
 745.
 746.
 747.
 748.
 749.
 750.
 751.
 752.
 753.
 754.
 755.
 756.
 757.
 758.
 759.
 760.
 761.
 762.
 763.
 764.
 765.
 766.
 767.
 768.
 769.
 770.
 771.
 772.
 773.
 774.
 775.
 776.
 777.
 778.
 779.

-0.8134990E 00
 -0.7462617E 00
 -0.6746396E 00
 -0.5940157E 00
 -0.5066984E 00
 -0.4138190E 00
 -0.3164213E 00
 -0.2155436E 00
 -0.1123206E 00
 -0.7652316E -02
 0.9668676E -01
 0.2001023E 00
 0.1014705E 00
 0.1994715E 00
 0.9300380E 00
 0.5813091E 00
 0.6631559E 00
 0.737512E 00
 0.8042567E 00
 0.0619632E 00
 0.9102221E 00
 0.9485188E 00
 0.9764227E 00
 0.9936365E 00
 0.9999666E 00
 -0.3250146E 05
 -0.3871931E 05
 -0.4453807E 05
 -0.4990534E 05
 -0.5476577E 05
 -0.5906239E 05
 -0.5905626E 05
 -0.6273901E 05
 -0.6574794E 05
 -0.6804550E 05
 -0.6960200E 05
 -0.7039825E 05
 -0.7042663E 05
 -0.6968919E 05
 -0.6819650E 05
 -0.6596506E 05
 -0.6301504E 05
 -0.5936834E 05
 -0.5504795E 05
 -0.5008057E 05
 -0.4450350E 05
 -0.3837407E 05
 -0.3177484E 05
 -0.2480832E 05
 -0.1758397E 05
 -0.1020682E 05
 -0.3252382E 05
 -0.3873486E 05
 -0.4455445E 05
 -0.4991791E 05
 -0.5477025E 05
 -0.5905626E 05
 -0.6271593E 05
 -0.6570694E 05
 -0.6800881E 05
 -0.6950081E 05
 -0.7036119E 05
 -0.7040781E 05
 -0.6967275E 05
 -0.68010431E 05
 -0.65953631E 05
 -0.62999948E 05
 -0.5935133E 05
 -0.5503618E 05
 -0.5008200E 05
 -0.4452383E 05
 -0.3841241E 05
 -0.3181984E 05
 -0.2404891E 05
 -0.1761883E 05
 -0.1023401E 05

```

=====
* = INPUT SIGNAL, + = OUTPUT-NO NOISE, * = FADED OUTPUT
** = 1-SPACE = 0.181618E-01
** = 1-SPACE = 0.128064E 04
** = 1-SPACE = 0.126119E 04

```

ORIGINAL PAGE IS
OF POOR QUALITY

5. Sample Runs

One of the biggest advantages of the present simulator is its ability to span over a range of inputs for the different devices, as opposed to only entering one value at a time as was the case in the previous simulation. This facility is illustrated in figure 1. In this particular example, 4 parameters are variables: the specular to multipath power ratio of the UHF downlink channel, the carrier to interference power ratio of the UHF downlink co-channel interferer, the phase values for the UHF downlink co-channel interferer, and the input signal to noise ratio of the Gaussian noise source. One can see from figure 1 that every possible permutation of the above values is exhibited. In this simulation run, a type one measurement is chosen with the plotting facility on. Thus the output is a list of the input vs. output values of the system, followed by its corresponding plot. One notes that a type one output exists for each of the possible permutations as mentioned above.

Figure 2 illustrates the above mentioned "looping" feature for a type 2 measurement. In this output, a type 2 measurement of the input vs. output SNR values and its corresponding plots are exhibited for every possible permutation of the 7- input parameters (columns) shown.

In figure 3, the output SNR values are being plotted as a function of the input SNR values for different values of the carrier to interference power ratio of the UHF uplink interference source. Again, the looping facility is exhibited here. One notes

from the output curves, that as the carrier to interference power ratio gets smaller, the output curves flatten out. At large values, the curves remain linear above threshold as expected.

Figure 4 illustrates the execution of a double hop system (scenario 2 in this case). One notes here that both an S-band and an UHF band uplink channel are set, as well as an S-band and an UHF band downlink channel.

6. Results

The results of the present simulator are divided into two sections; The analytical results (section 6.1), and the processed voice results (section 6.2). In both cases, tests are made using a single hop system (scenario 1).

6.1 Analytical Results

The system discussed can be seen to have the responses shown on various plots obtained for several different Rician channels over a single hop system (scenario 1).

We first analyzed a single hop system over a channel without fading or interference present as a function of the input SNR values. A pure sinusoid was used as input. The results can be seen in figure 6.1 (referenced from first report). Note that the results are analyzed for various combinations of signal processing stages. These results represent a pure FM system with white noise present.

We next simulated a single hop system over a Rician channel with no interference present, and analyzed the output vs input SNR values for various values of the specular-to-multipath component power ratios of the fading channel. The results are summarized in the plot of figure 6.2. First, we note that when the specular-to-multipath power ratio of the channel is 100 db, no

real effects of fading can be seen and the output vs input SNR curve remains a linear one as expected. An analysis of the various plots, however, does show that as the specular-to-multipath power ratio is decreased, a flattening out of the linear curve does occur and the effects of fading become increasingly destructive.

We next analyzed a single hop system over a Rician channel with no interference present, with and without a space diversity receiver present. The results are summarized in figure 6.3. One observes from this plot that there is a significant improvement with the space diversity receiver on.

We next plotted the output signal-to-noise ratio as a function of the specular-to-multipath power ratio of the fading channel, with no other disturbances present. We started with a specular-to-multipath power ratio of -35 dB (practically Raleigh fading), and went all the way up to a specular-to-multipath power ratio of 100 dB. The results are summarized in figure 6.4. Here we noticed a threshold effect beginning at a specular-to-multipath power ratio of about +05 dB. The curve moves up very quickly in a linear fashion from 5 dB to 50 dB, and then flattens out to its maximum value.

Figure 6.5 considers the effects of interference on the output signal to noise ratio. One can observe from the plot that an interference source with a carrier to interference power ratio ranging from 100 dB all the way down to 20 dB has no major effect on the output performance. However, as one gets below 20 dB, a flattening out of the input vs. output SNR curve does occur above

PRECEDING PAGE BLANK NOT FILMED

threshold. As the carrier to interference power ratio is taken below 8 dB, the flattening out effects become very predominant and output performance starts getting poor. At 0 dB, the curve flattens out completely to about .5 dB (Threshold effect).

Figure 6.6 considers results obtained using scenario 2. In this plot we analyze the input vs. output SNR values of a double hop system assuming all four channels are Rician fading channels. The UHF uplink channel, the S-band downlink channel, the S-band uplink channel, and the UHF downlink channel are the channels which are considered. As one can see from the plot, various permutations of the 4 channels (specular to multipath power ratio of the fading channel is varied) are considered.

These are just a few of the vast number of results obtainable with this simulation. Section 5 contains various sample runs illustrating some of the various possible results obtainable.

ORIGINAL PAGE IS
OF POOR QUALITY

6.2. Results: Voice

In addition to the analytical results, we were also able to use the simulation to process sampled voice and actually listen to it. In particular, the following tests were made on the voice:

First, we put the sampled voice through the simulation with no fading, interference, or thermal noise present, or in other words, "pure FM". The output voice sounded exactly the same as the input. We listened to the voice (still pure FM) with the pre-emphasis de-emphasis filters both off and on, and could here a slight improvement with the latter case. With the expander - compander on or off, difference in voice quality was so slight to be heard.

Next, with no other disturbances present, we listened to the voice as a function of the thermal noise power. Results could be summarized as follows:

Carrier-to-Noise Power Ratio (dB)	Speech Quality
+40	Excellent
+35	Excellent
+30	Excellent
+25	Excellent
+20	Excellent
+16	Very good
+14	Good
+12	Good (very light static)
+10	Fair (light crackling)
+08	Fair-Poor (crackling louder)
+06	Poor (crackling loud)
+03	Very Poor (Basically only crackling)
-02	No sign of voice (only loud crackling)


As the above indicates, the quality of voice went from excellent just above threshold, to poor just below threshold, consistent with our analytical results as well as theoretical results.

We then listened to the voice as a function of the specular-to-multipath power ratio (dB) of the fading channel (see sample run 5.1 for channel parameters), with no other disturbances present (input carrier-to-noise power ratio at +40dB). Within the range of specular-to-multipath power ratios from +6 dB and better, output voice quality was excellent. Within the range from -10 dB through +6 dB, voice quality was good (tonal characteristics of the voice were altered somewhat). Below -12 dB, voice quality was fair (tonal characteristics altered), with some crackling present.

The above examples are a few of the many possible tests on voice. Any of the 5 scenarios can be tested on the voice, with all possible parameter variations. (note that the above tests correspond to scenario 1).

FIGURE
6.1

Input v. Output SNR Curves with and without Pre-emphasis/
De-emphasis and/or Compressor/Expander




PE - Pre-emphasis-De-emphasis
CE - Compressor-Expander.

FIGURE

Input vs. Output SNR values for Rician Fading

6.2




Input SNR Values in db.

Note: Pre-emphasis
De-emphasis
Compressor
Expander.

FIGURE
6.3...

Output vs Input SNR Values with and without
Space Diversifying Receiver




Input SNR Values in dB.

Specular-to-multipath
power ratio = 20 dB,
for both cases..


* Decision time = .000016 Sec

FIGURE 6.4 Specular-to-Multipath power ratio vs Output SNR


Output SNR (CDB)



6.5 Output vs Input SNR as a function of
the Carrier-to-Interference Power Ratio



6.6 Multichannel Performance of a Double Hop System (Scenario 2)



7. Proposed Research for the Forthcoming Year

Because of the present system's very modular structure, simulation of other modulation techniques over any one of the five scenarios can be done with relative ease. Since the simulation is designed in such a way that the inphase and quadrature phase components of the input signal are being passed through the components of the system in a parallel fashion, any type of modulation scheme which can be broken up into these components can be easily implemented. For example, the present simulator could be used to test the performance characteristics of duo-binary FM or tamed FM, both which use less bandwidth than standard FM.

At the same time, one could use the simulation to process voice using various modulation techniques to see which types produce the best subjective voice quality. In the report, we propose to construct a system to allow for simple testing of actual voice input. This system will allow for simple interfacing of voice input to the IBM system on which the actual simulation took place. We plan to build this device using a personal computer as the controller.

Also because of the systems modular structure, it would be possible test other types of components or noise sources.

1. Is this an online session? (Y/N) N
2. --- - 3. --- -
4. TYPE OF CALL AVAILABLE:
5. 1: M1->M2, rural mobile to rural mobile in same UHF beam
 6. 2: M1->M3, rural mobile to rural mobile in different UHF beam, in same S-band
 7. 3: M1->M4, rural mobile to rural mobile in different UHF beam, in different S-band
 8. 4: M1->C1, rural mobile to fixed in same S-band beam
 9. 5: M1->C2, rural mobile to fixed in different S-band beam
 10. 6: FC1->M1, fixed to rural mobile in same S-band beam
 11. 7: FC2->M1, fixed to rural mobile in different S-band beam
 12. INPUT TYPE OF CALL TO BE SIMULATED: 1
13. MODE OF CALL AVAILABLE:
14. 1: M1->M2, hard wired transponder
 15. 2: M1->M2, direct switched transponder
 16. 3: M1->M2, indirect switched transponder
 17. 4: M1->G1->M2, double hop system
 18. INPUT MODE OF CALL TO BE SIMULATED: 1
19. FREQUENCY OF THE BASEBAND SIGNAL (LESS THAN 3000 Hz.) (IN HERTZ, F7.2): 1000.00 Hz
20. NOTE : POWER OF THE BASEBAND SIGNAL HAS TO BE LESS OR EQUAL THAN .5 WATTS;
21. SO THAT THE MAXIMUM INSTANTANOUS FREQUENCY DEVIATION IS
22. LESS OR EQUAL THAN 1200 Hz.
23. POWER OF THE BASEBAND SIGNAL (IN WATTS, F7.2): 0.50 WATTS
24. THE CARRIER POWER (IN WATTS, F7.2): 1.00 WATTS
25. THE FREQUENCY DEVIATION (IN HERTZ, F8.2): 12000 Hz. (FIXED FOR NOW)
26. How many times the nyquist rate do you want the sampling frequency to be? (2 - 4, 11): 2
27. THE CARRIER FREQUENCY (IN HERTZ, F7.2): (NOT USED FOR NOW)
28. DO YOU WANT THE COMPRESSOR/EXPANDER IN? Y-YES . N-NO : N
29. DO YOU WANT THE PRE-EMPHASIS - DE-EMPHASIS FILTERS IN ? Y-YES . N-NO : N
30. DO YOU WANT A CO-CHANNEL INTERFERER IN THE UPLINK? Y-YES ,N-NO: N
31. IS FADING PRESENT IN THE UPLINK CHANNEL? Y-YES ,N-NO: N
32. DO YOU WANT A CO-CHANNEL INTERFERER IN THE DOWNLINK? Y-YES ,N-NO: Y
33. Are multiple values of the carrier to interference power ratio to be tested? (Y/N): Y
34. Input the range of values to be tested (in dB):
35. Input the initial value (-99 -- 99,13) : 6000
36. Input the increment value (01 -- 99,13) : 10DB
37. Input the final value (01 -- 99,13) : 6000
38. Are multiple values of the interference phase values to be tested? (Y/N): Y
39. Input the range of values to be tested (in degrees):
40. Input the initial value (F6.2) : 10.000DEGREES
41. Input the increment value (F6.2) : 10.000DEGREES
42. Input the final value (F6.2) : 10.000DEGREES
43. --- -
44. --- -
45. --- -
46. --- -
47. --- -
48. --- -
49. --- -
50. --- -
51. --- -
52. --- -
53. --- -
54. --- -
55. --- -
56. --- -
57. --- -
58. --- -
59. --- -

**ORIGINAL PAGE IS
OF POOR QUALITY.**

**ORIGINAL PAGE IS
OF POOR QUALITY**

60. Input the increment value (F6.2) : 5.000 DEGREES
 61. Input the final value (F6.2) : 5.000 DEGREES
 62. IS FADING PRESENT IN THE DOWNLINK CHANNEL? Y-YES, N-NO: Y
 63. IS A SPACE DIVERSITY RECEIVER BEING USED? Y-YES, N-NO: Y
 64. IS THE INTERFERENCE FADED? Y-YES, N-NO: Y
 65. THE DOWNLINK FADING CHANNEL IS PRESENT
 66. SET PARAMETERS FOR FIRST FADING CHANNEL:
 67. INPUTS OF FADING CHANNELS AVAILABLE:
 68. 1: NO SPECULAR COMPONENT (HALF-LIGHT FADING)
 69. 2: SPECULAR COMPONENT, SHORTEST PATH
 70. 3: SPECULAR COMPONENT, MEAN PATH
 71. INPUT TYPE OF CHANNEL: 2
 72. ENTER THE MULTIPATH SPREAD TIME (IN MICROSECONDS, F9.2) : 500.00 MICROSECONDS
 73. ENTER THE DOPPLER SPREAD BANDWIDTH (IN HERTZ, F7.2) : 1.00 Hz
 74. Are multiple values of the specular to multipath power
 ratio to be tested? (Y/N) : Y
 75. Input the range of values to be tested (in dB) :
 76. Input the initial value (-99 -- +99, I3) : 550B
 77. Input the increment value (-99 -- +99, I2) : 10dB
 78. Input the final value (01 -- 99, I2) : 550B
 79. SET PARAMETERS FOR THE SECOND FADING CHANNEL:
 80. INPUTS OF FADING CHANNELS AVAILABLE:
 81. 1: NO SPECULAR COMPONENT (HALF-LIGHT FADING)
 82. 2: SPECULAR COMPONENT, SHORTEST PATH
 83. 3: SPECULAR COMPONENT, MEAN PATH
 84. INPUT TYPE OF CHANNEL: 2
 85. ENTER THE MULTIPATH SPREAD TIME (IN MICROSECONDS, F9.2) : 500.00 MICROSECONDS
 86. ENTER THE DOPPLER SPREAD BANDWIDTH (IN HERTZ, F7.2) : 1.00 Hz
 87. Are multiple values of the specular to multipath power
 ratio to be tested? (Y/N) : Y
 88. Input the range of values to be tested (in dB) :
 89. Input the initial value (-99 -- +99, I3) : 550B
 90. Input the increment value (01 -- 99, I2) : 10dB
 91. Input the final value (01 -- 99, I2) : 550B
 92. SET PARAMETERS FOR THE THIRD FADING CHANNEL:
 93. INPUTS OF FADING CHANNELS AVAILABLE:
 94. 1: NO SPECULAR COMPONENT (HALF-LIGHT FADING)
 95. 2: SPECULAR COMPONENT, SHORTEST PATH
 96. 3: SPECULAR COMPONENT, MEAN PATH
 97. INPUT TYPE OF CHANNEL: 2
 98. ENTER THE MULTIPATH SPREAD TIME (IN MICROSECONDS, F9.2) : 500.00 MICROSECONDS
 99. ENTER THE DOPPLER SPREAD BANDWIDTH (IN HERTZ, F7.2) : 1.00 Hz
 100. Are multiple values of the specular to multipath power
 ratio to be tested? (Y/N) : Y
 101. Input the range of values to be tested (in dB) :
 102. Input the initial value (-99 -- +99, I3) : 550B
 103. Input the increment value (-99 -- +99, I2) : 10dB
 104. Input the final value (01 -- 99, I2) : 550B
 105. Input the range of values to be tested (in dB) :
 106. Input the initial value (-99 -- +99, I3) : 550B
 107. Input the increment value (-99 -- +99, I2) : 10dB
 108. Input the final value (01 -- 99, I2) : 550B
 109. Input the range of values to be tested (in dB) :
 110. Input the initial value (-99 -- +99, I3) : 550B
 111. Input the increment value (01 -- 99, I2) : 4 dB
 112. Input the final value (01 -- 99, I2) : 550B
 113. Are multiple SNR values to be tested? Y-Yes, N-no: Y
 114. Input the range of SNR values to be tested (in dB) :
 115. Input the initial value of SNR (-99 -- +99, I3) : 36 dB
 116. Input the increment value (01 -- 99, I2) : 4 dB
 117. Input the final value (01 -- 99, I2) : 4 dB
 118. Input the increment value (01 -- 99, I2) : 4 dB
 119. Input the final value (01 -- 99, I2) : 4 dB

120. Input the ending value of SNR (-99 -- +99, I3): 40 DB
 121.
 122.
 123. IS A SPACE DIVERSITY RECEIVER REQUIRED? (Y/N) Y
 124. INPUT DURATION BETWEEN DECISION TIMES FOR THE S.D. RECEIVER (F7.5, IN SECONDS)
 125. Input the approximate duration of simulation in seconds (0.01 - 9.99, F4.2): 0.00020SEC.
 126. Input type:
 127.
 128.
 129. Type of performance measurement available:
 1. Compare recovered output signal to original input signal
 2. Measure output signal to noise ratio
 130.
 131.
 132.
 DO YOU WANT OUTPUT TO BE PLOTTED? Y
 133.
 134.
 135. 1-Specular to multipath power ratio- Downlink Channel
 136. 2-Carrier to interference power ratios- UHF Downlink Channel
 137. 3-Phase values of interference- UHF Downlink Channel
 138. 4-Input SNR Value
 139. 1 2 3 4
 140.
 141. 55.00 60.00 10.00 36.000000
 142. Input signal Output signal (No Noise) Output signal (With Noise)
 143.
 144. 0.1000000E 01 -0.3546265E 03 0.9127492E 02
 145. 0.9945219E 00 -0.1308870E 04 0.3438616E 03
 146. 0.9781477E 00 -0.2297429E 04 0.6371396E 03
 147. 0.9510567E 00 -0.2868278E 04 0.9103672E 03
 148. 0.9135456E 00 -0.2998826E 04 0.1268146E 04
 149. 0.8660256E 00 -0.2613447E 04 0.1859902E 04
 150. 0.8090173E 00 -0.1619970E 04 0.2839659E 04
 151. 0.7431453E 00 0.4053467E 02 0.4315348E 04
 152. 0.6691312E 00 0.2359897E 04 0.6330977E 04
 153. 0.5877059E 00 0.5289641E 04 0.8883230E 04
 154. 0.5000010E 00 0.8754652E 04 0.1193763E 05
 155. 0.4067382E 00 0.1265577E 05 0.1541877E 05
 156. 0.3090183E 00 0.1686925E 05 0.1921204E 05
 157. 0.2079136E 00 0.2125362E 05 0.2310742E 05
 158. 0.1045300E 00 0.2565789E 05 0.2720433E 05
 159. 0.2221441E -0.5 0.2992696E 05 0.311171E 05
 160. -0.1045247E 00 0.3390678E 05 0.3478890E 05
 161. -0.2079074E 00 0.3745015E 05 0.3807883E 05
 162. -0.3090113E 00 0.40942305E 05 0.4084572E 05
 163. -0.4067307E 00 0.42207941E 05 0.4295670E 05
 164. -0.4499930E 00 0.4421439E 05 0.4431964E 05
 165. -0.587774E 00 0.4806550E 05 0.486210E 05
 166. -0.6691231E 00 0.4461211E 05 0.4453346E 05
 167. -0.7431371E 00 0.4342422E 05 0.4329643E 05
 168. -0.8090096E 00 0.4129246E 05 0.4135496E 05
 169. -0.8660184E 00 0.3823110E 05 0.3805855E 05
 170. -0.9135392E 00 0.3428400E 05 0.3410566E 05
 171. -0.9510516E 00 0.2952932E 05 0.2935406E 05
 172. -0.9781443E 00 0.2407629E 05 0.2391016E 05
 173. -0.9945199E 00 0.1805300E 05 0.1709995E 05
 174. -0.1000600E 01 0.1159213E 05 0.1145747E 05
 175. -0.9945242E 00 0.4822430E 04 0.4713137E 04
 176. -0.9781522E 00 -0.2134279E 04 -0.2213715E 04
 177. -0.9510636E 00 -0.9164684E 04 -0.9219867E 04
 178. -0.9135556E 00 -0.1616573E 05 -0.1621178E 05
 179. -0.8660361E 00 -0.2304510E 05 -0.2309281E 05

ORIGINAL PAGE IS
OF POOR QUALITY

180. -0.8090329E 00 -0.2972033E 05
 181. -0.7431634E 00 -0.3611538E 05
 182. -0.6691524E 00 -0.421545E 05
 183. -0.5176101E 00 -0.4777842E 05
 184. -0.500271E 00 -0.5290458E 05
 185. -0.4067667E 00 -0.5746700E 05
 186. -0.309497E 00 -0.6139990E 05
 187. -0.2079459E 00 -0.6464539E 05
 188. -0.1045648E 00 -0.6715650E 05
 189. -0.3710153E-04 -0.689931E 05
 190. -0.1044899E 00 -0.6905300E 05
 191. 0.2076722E 00 -0.7000956E 05
 192. 0.3097781E 00 -0.6937213E 05
 193. 0.4066978E 00 -0.6795208E 05
 194. 0.4999627E 00 -0.6577056E 05
 195. 0.5167492E 00 -0.6284800E 05
 196. 0.6690964E 00 -0.5920971E 05
 197. 0.743136E 00 -0.5488154E 05
 198. 0.0089866E 00 -0.4989328E 05
 199. 0.8660005E 00 -0.4429588E 05
 200. 0.9136250E 00 -0.3812075E 05
 201. 0.9510405E 00 -0.3149445E 05
 202. 0.9781367E 00 -0.2448261E 05
 203. 0.9945163E 00 -0.1722654E 05
 204. 0.1000000E. 01 -0.9822348E 04
 205. 0.4945278E 00 -0.2367284E 04
 206. 0.9791597E 00 -0.5050090E 04
 207. 0.9510749E 00 0.1235017E 05
 208. 0.9135698E 00 0.1945291E 05
 209. 0.8880561E 00 0.2632707E 05
 210. 0.8000535E 00 0.3288803E 05
 211. 0.7431874E 00 0.3909482E 05
 212. 0.6691790E 00 0.4889691E 05
 213. 0.5078384E 00 0.5024172E 05
 214. 0.5000582E 00 0.5507376E 05
 215. 0.4067986E 00 0.5933614E 05
 216. 0.3090030E 00 0.6297383E 05
 217. 0.2079611E 00 0.6593744E 05
 218. 0.1045996E 00 0.6819663E 05
 219. 0.7309525E-04 0.6969169E 05
 220. -0.1044542E 00 0.7043463E 05
 221. -0.2073381E 00 0.7040856E 05
 222. -0.3099439E 00 0.6961644E 05
 223. -0.4066659E 00 0.6806944E 05
 224. -0.4999316E 00 0.6407779E 05
 225. -0.5877201E 00 0.6278211E 05
 226. -0.6690704E 00 0.5909429E 05
 227. -0.7130896E 00 0.5471427E 05
 228. -0.6009681E 00 0.4969926E 05
 229. -0.86549830E 00 0.4407779E 05
 230. -0.1000000E 01 0.9659547E 04
 231. -0.9135104E 00 0.3790904E 05
 232. -0.9510297E 00 0.3127739E 05
 233. -0.9781253E 00 0.2428645E 05
 234. -0.9945125E 00 0.1704566E 05
 235. -0.9495316E 00 0.2224056E 04
 236. -0.9781669E 00 -0.5173293E 04
 237. -0.9510657E 00 -0.1245371E 05
 238. -0.9135844E 00 -0.195474E 05
 239. -0.9660736E 00 -0.2639459E 05
 240. -0.9495316E 00 -0.2976236E 05

ORIGINAL PAGE IS
OF POOR QUALITY

6
 720. -0.8134990E 00 -0. 3250146E 05
 721. -0.7452617E 00 -0. 3873486E 05
 722. -0.674396E 00 -0. 4453807E 05
 723. -0.5940157E 00 -0. 4990534E 05
 724. -0.5066484E 00 -0. 5476577E 05
 725. -0.4138190E 00 -0. 5906239E 05
 726. -0.3164213E 00 -0. 6273980E 05
 727. -0.2155436E 00 -0. 6574794E 05
 728. -0.1123206E 00 -0. 6804550E 05
 729. -0.752316E-02 -0. 6960200E 05
 730. 0.9666676E-01 -0. 7039825E 05
 731. 0.201823E 00 -0. 7042663E 05
 732. 0.3014705E 00 -0. 6968919E 05
 733. 0.5944715E 00 -0. 6819550E 05
 734. 0.430438E 00 -0. 6596506E 05
 735. 0.5813091E 00 -0. 6301504E 05
 736. 0.6915159E 00 -0. 5936834E 05
 737. 0.7377512E 00 -0. 5504795E 05
 738. 0.80042567E 00 -0. 5006057E 05
 739. 0.6619632E 00 -0. 4450350E 05
 740. 0.9102221E 00 -0. 3837407E 05
 741. 0.9485188E 00 -0. 3177484E 05
 742. 0.9744727E 00 -0. 2480832E 05
 743. 0.9135365E 00 -0. 1750397E 05
 744. 0.999966E 00 -0. 1020682E 05
 745.
 746.
 747. * = INPUT SIGNAL, * = OUTPUT-NC NOISE, # = FADED OUTPUT

748. #: 1-SPACE= 0.181818E-01
 749. #: 1-SPACE= 0.128063E 04
 750. #: 1-SPACE= 0.128119E 04

780
781
782
783
784
785
786
787
788
789
790
791
792
793
794
795
796
797
798
799
800
801
802
803
804
805
806
807
808
809
810
811
812
813
814
815
816
817
818
819
820
821
822
823
824
825
826
827
828
829
830
831
832
833
834
835
836
837
838
839

ORIGINAL PAGE IS
OF POOR QUALITY

U40. 0841.
U42. 0842.
U43. 0843.
U44. 0844.
U45. 0845.
U46. 0846.
U47. 0847.
U48. 0848.
U49. 0849.
U50. 0850.
U51. 0851.
U52. 0852.
U53. 0853.
U54. 0854.
U55. 0855.
U56. 0856.
U57. 0857.
U58. 0858.
U59. 0859.
U60. 0860.
U61. 0861.
U62. 0862.
U63. 0863.
U64. 0864.
U65. 0865.
U66. 0866.
U67. 0867.
U68. 0868.
U69. 0869.
U70. 0870.
U71. 0871.
U72. 0872.
U73. 0873.
U74. 0874.
U75. 0875.
U76. 0876.
U77. 0877.
U78. 0878.
U79. 0879.
U80. 0880.
U81. 0881.
U82. 0882.
U83. 0883.
U84. 0884.
U85. 0885.
U86. 0886.
U87. 0887.
U88. 0888.
U89. 0889.

ORIGINAL PAGE IS
OF POOR QUALITY.

ORIGINAL PAGE IS
OF POOR QUALITY

900.
901.
902.
903.
904.
905.
906.
907.
908.
909.
910.
911.
912.
913.
914.
915.
916.
917.
918.
919.
920.
921.
922.
923.
924.
925.
926.
927.
928.
929.
930.
931.
932.
933.
934.
935.
936.
937.
938.
939.
940.
941.
942.
943.
944.
945.
946.
947.
948.
949.
950.
951.
952.
953.
954.
955.
956.
957.
958.

**ORIGINAL PAGE IS
OF POOR QUALITY**

320.						
321.						
322.						
323.						
324.						
325.						
326.						
327.						
328.						
329.						
330.						
331.						
332.						
333.						
334.						
335.						
336.						
337.						
338.						
339.						
340.						
341.						
342.						
343.						
344.						
345.						
346.						
347.						
348.						
349.						
350.						
351.						
352.						
353.						
354.						
355.						
356.						
357.						
358.						
359.						
360.						
361.						
362.						
363.						
364.						
365.						
366.						
367.						
368.						
369.						
370.						
371.						
372.						
373.						
374.						
375.						
376.						
377.						
378.						
379.						
380.						
381.						
382.						
383.						
384.						
385.						
386.						
387.						
388.						
389.						
390.						
391.						
392.						
393.						
394.						
395.						
396.						
397.						
398.						
399.						
400.						
401.						
402.						
403.						
404.						
405.						
406.						
407.						
408.						
409.						
410.						
411.						
412.						
413.						
414.						
415.						
416.						
417.						
418.						
419.						
420.						
421.						
422.						
423.						
424.						
425.						
426.						
427.						
428.						
429.						
430.						
431.						
432.						
433.						
434.						
435.						
436.						
437.						
438.						
439.						
440.						
441.						
442.						
443.						
444.						
445.						
446.						
447.						
448.						
449.						
450.						
451.						
452.						
453.						
454.						
455.						
456.						
457.						
458.						
459.						
460.						
461.						
462.						
463.						
464.						
465.						
466.						
467.						
468.						
469.						
470.						
471.						
472.						
473.						
474.						
475.						
476.						
477.						
478.						
479.						
480.						
481.						
482.						
483.						
484.						
485.						
486.						
487.						
488.						
489.						
490.						
491.						
492.						
493.						
494.						
495.						
496.						
497.						
498.						
499.						
500.						
501.						
502.						
503.						
504.						
505.						
506.						
507.						
508.						
509.						
510.						
511.						
512.						
513.						
514.						
515.						
516.						
517.						
518.						
519.						
520.						
521.						
522.						
523.						
524.						
525.						
526.						
527.						
528.						
529.						
530.						
531.						
532.						
533.						
534.						
535.						
536.						
537.						
538.						
539.						
540.						
541.						
542.						
543.						
544.						
545.						
546.						
547.						
548.						
549.						
550.						
551.						
552.						
553.						
554.						
555.						
556.						
557.						
558.						
559.						
560.						
561.						
562.						
563.						
564.						
565.						
566.						
567.						
568.						
569.						
570.						
571.						
572.						
573.						
574.						
575.						
576.						
577.						
578.						
579.						
580.						
581.						
582.						
583.						
584.						
585.						
586.						
587.						
588.						
589.						
590.						
591.						
592.						
593.						
594.						
595.						
596.						
597.						
598.						
599.						
600.						
601.						
602.						
603.						
604.						
605.						
606.						
607.						
608.						
609.						
610.						
611.						
612.						
613.						
614.						
615.						
616.						
617.						
618.						
619.						
620.						
621.						
622.						
623.						
624.						
625.						
626.						
627.						
628.						
629.						
630.						
631.						
632.						
633.						
634.						
635.						
636.						
637.						
638.						
639.						
640.						
641.						
642.						
643.						
644.						
645.						
646.						
647.						
648.						
649.						
650.						
651.						
652.						
653.						
654.						

ORIGINAL PAGE IS
OF POOR QUALITY

1920. -0.6636401E 00 0.5934346E 05
 1921. -0.7301990E 00 0.5501893E 05
 1922. -0.6046411E 00 0.5004760E 05
 1923. -0.5622911E 00 0.446686E 05
 1924. -0.9104099E 00 0.3833419E 05
 1925. -0.6437236E 00 0.3173232E 05
 1926. -0.9756231E 00 0.2476388E 05
 1927. -0.4937092E 00 0.1751024E 05
 1928. -0.9999716E 00 0.1016046E 05
 1929. -0.956526E 00 0.2727003E 04
 1930. -0.9796954E 00 0.4674066E 04
 1931. -0.953756E 00 0.1196336E 05
 1932. -0.616194E 00 0.1907083E 05
 1933. -0.956184E 00 0.2593510E 05
 1934. -0.6134490E 00 0.3250172E 05
 1935. -0.742617E 00 0.3871952E 05
 1936. -0.6748396E 00 0.4453023E 05
 1937. -0.594157E 00 0.4991544E 05
 1938. -0.506984E 00 0.5476582E 05
 1939. -0.4134140E 00 0.5906240E 05
 1940. -0.316213E 00 0.6273977E 05
 1941. -0.2155439E 00 0.6574788E 05
 1942. -0.1123201E 00 0.6801544E 05
 1943. -0.7542116E -02 0.6960183E 05
 1944. 0.963678E -01 0.7398119E 05
 1945. 0.2001623E 00 0.704265E 05
 1946. 0.304705E 00 0.6968913E 05
 1947. 0.394715E 00 0.6819644E 05
 1948. 0.4130638E 00 0.6596494E 05
 1949. 0.513091E 00 0.630495E 05
 1950. 0.61559E 00 0.5935682E 05
 1951. 0.7377512E 00 0.5504783E 05
 1952. 0.842567E 00 0.5008044E 05
 1953. 0.9619632E 00 0.4450338E 05
 1954. 0.9102221E 00 0.3837396E 05
 1955. 0.9455186E 00 0.3177475E 05
 1956. 0.9764227E 00 0.2490826E 05
 1957. 0.4936365E 00 0.1758392E 05
 1958. 0.909666E 00 0.1020677E 05
 1959. -0.5934452E 05
 1960. -0.5501455E 05
 1961. -0.5003273E 05
 1962. -0.4444214E 05
 1963. -0.3830346E 05
 1964. -0.3170295E 05
 1965. -0.2474108E 05
 1966. -0.1752593E 05
 1967. -0.1015360E 05
 1968. -0.2220426E 04
 1969. -0.4675140E 04
 1970. -0.1194940E 05
 1971. -0.1904743E 05
 1972. -0.2591674E 05
 1973. -0.3248980E 05
 1974. -0.3870435E 05
 1975. -0.4451641E 05
 1976. -0.4980629E 05
 1977. -0.5475410E 05
 1978. -0.5905006E 05
 1979. -0.6272255E 05
 1980. -0.6573019E 05
 1981. -0.6803163E 05
 1982. -0.6959406E 05
 1983. -0.7039825E 05
 1984. -0.7043130E 05
 1985. -0.6969200E 05
 1986. -0.6019773E 05
 1987. -0.6597180E 05
 1988. -0.6302990E 05
 1989. -0.5930573E 05
 1990. -0.5506212E 05
 1991. -0.5008456E 05
 1992. -0.4450699E 05
 1993. -0.3837339E 05
 1994. -0.3177151E 05
 1995. -0.2490826E 05
 1996. -0.1758392E 05
 1997. -0.1020677E 05
 1998. -0.1019132E 05

======
 * = INPUT SIGNAL, + = OUTPUT NO 10151, - = ADDED OUTPUT
 :: 1-Space = 0.101810E-01
 :: 1-Subtract = 0.133157E 04
 :: 1-Multiply = 0.133161E 04

1960.
1961.
1962.
1963.
1964.
1965.
1966.
1967.
1968.
1969.
1970.
1971.
1972.
1973.
1974.
1975.
1976.
1977.
1978.
1979.
1980.
1981.
1982.
1983.
1984.
1985.
1986.
1987.
1988.
1989.
1990.
1991.
1992.
1993.
1994.
1995.
1996.
1997.
1998.
1999.
2000.
2001.
2002.
2003.
2004.
2005.
2006.
2007.
2008.
2009.
2010.
2011.
2012.
2013.
2014.
2015.
2016.
2017.
2018.
2019.
2020.
2021.
2022.
2023.
2024.
2025.
2026.
2027.
2028.
2029.
2030.
2031.
2032.
2033.
2034.
2035.
2036.
2037.
2038.
2039.

**ORIGINAL PAGE IS
OF POOR QUALITY**

1. SIGTP=1
 2.
 3. Is this an online session? (Y/N) N
 4.
 5. TYPE OF CALL AVAILABLE:
 6. 1: M1->M2. rural mobile to rural mobile in same UHF beam
 7. 2: M1->M3. rural mobile to rural mobile in different UHF beam. In same S-band
 8. 3: M1->M4. rural mobile to rural mobile in different UHF beam. In different S-band
 9.
 10. 4: M1->FC1. rural mobile to fixed in same S-band beam
 11. 5: M1->FC2. rural mobile to fixed in different S-band beam
 12. 6: FC1->M1. fixed to rural mobile in same S-band beam
 13. 7: FC2->M1. fixed to rural mobile in different S-band beam
 14. INPUT TYPE OF CALL TO BE SIMULATED: 1
 15. MODE OF CALL AVAILABLE:
 16. 1: M1->M2. hard wired transponder
 17. 2: M1->M2. direct switched transponder
 18. 3: M1->M2. indirect switched transponder
 19. 4: M1->G1->M2. double hop system
 20. INPUT MODE OF CALL TO BE SIMULATED: 1
 21.
 22. FREQUENCY OF THE BASEBAND SIGNAL (LESS THAN 3000 HZ.) (IN HERTZ. F7.2): 1000.00 Hz
 23.
 24. NOTE : POWER OF THE BASEBAND SIGNAL HAS TO BE LESS OR EQUAL THAN .5 WATTS:
 25. SO THAT THE MAXIMUM INSTANTANEOUS FREQUENCY DEVIATION IS
 26. LESS OR EQUAL THAN 12000 Hz
 27. POWER OF THE BASEBAND SIGNAL (IN WATTS. F7.2): 0.50 WATTS
 28.
 29. THE CARRIER POWER (IN WATTS. F7.2): 1.00 WATTS
 30.
 31. THE FREQUENCY DEVIATION (IN HERTZ. F8.2): 12000 Hz. (FIXED FOR NOW)
 32. How many times the nyquist rate do you want the sampling frequency to be? (2 - 4. (1)): 2
 33.
 34. THF CARRIER FREQUENCY (IN HERTZ. F7.2): NOT USED FOR NOW
 35. DO YOU WANT THE COMPRESSOR/EXPANDER IN? Y-YES . N-NO : Y
 36.
 37. DO YOU WANT THE PRE-EMPHASIS - DE-EMPHASIS FILTERS IN ? Y-YES . N-NO : Y
 38.
 39. DO YOU WANT A CO-CHANNEL INTERFERER IN THE UPLINK? Y-YES . N-NO: Y
 40.
 41. Are multiple values of the carrier to interference power ratio to be tested? (Y/N): Y
 42.
 43.
 44. Input the range of values to be tested (in dB):
 45. Input the initial value (-99 -- +99.13) : 30dB
 46.
 47. Input the increment value (01 -- 99.13) : 10dB
 48.
 49.
 50.
 51.
 52. Are multiple values of the interference phase values to be tested? (Y/N): Y
 53.
 54. Input the range of values to be tested (in degrees):
 55. Input the initial value (F6.2) : 5.00 DEGREES
 56.
 57. Input the increment value (F6.2) : 1.00 DEGREES
 58.
 59.

ORIGINAL PAGE IS
OF POOR QUALITY

60. IS FADING PRESENT IN THE UPLINK 6.00 DEGREES
 61. CHANNEL? Y-YES.N-NO: Y
 62.
 63. IS THE INTERFERENCE FADED? Y-YES.N-NO: Y
 64.
 65. THE UPLINK FADING CHANNEL IS PRESENT
 66. TYPES OF FADING CHANNELS AVAILABLE:
 67. 1: NO SPECULAR COMPONENT (RALEIGH FADING)
 68. 2: SPECULAR COMPONENT. SHORTEST PATH
 69. 3: SPECULAR COMPONENT. MEAN PATH
 70. INPUT TYPE OF CHANNEL: 2
 71.
 72. ENTER THE MULTIPATH SPREAD TIME (IN MICROSECONDS. F9.2): 500.00 MICROSECONDS
 73.
 74. ENTER THE DOPPLER SPREAD BANDWIDTH (IN HERTZ. F7.2): 1.00 Hz
 75.
 76. Are multiple values of the specular to multipath power
 ratio to be tested? (Y/N): Y
 77.
 78. Input the range of values to be tested (in dB):
 79. Input the initial value (-99 -- +99.13): 50DB
 80.
 81. Input the increment value (-99 -- +99.12): 50DB
 82.
 83.
 84. Input the final value (01 -- 99.12): 100D
 85.
 86. DO YOU WANT A CO-CHANNEL INTERFERER IN THE DOWNLINK? Y-YES.N-NO: Y
 87.
 88. Are multiple values of the carrier to interference power
 ratio to be tested? (Y/N): Y
 89.
 90.
 91. Input the range of values to be tested (in dB):
 92. Input the initial value (-99 -- +99.13) : 10DB
 93.
 94. Input the increment value (01 -- 99.13) : 10DB
 95.
 96. Input the final value (01 -- 99.13) : 20D
 97.
 98. Are multiple values of the interference phase values
 to be tested? (Y/N): Y
 99.
 100.
 101. Input the range of values to be tested (in degrees):
 102. Input the initial value (F6.2) : 10.00DEGREES
 103.
 104.
 105.
 106.
 107. IS FADING PRESENT IN THE DOWNLINK CHANNEL? Y-YES.N-NO: Y
 108.
 109.
 110.
 111.
 112. IS THE INTERFERENCE FADED? Y-YES.N-NO: Y
 113.
 114. THE DOWNLINK FADING CHANNEL IS PRESENT
 115. SET PARAMETERS FOR FIRST FADING CHANNEL:
 116. TYPES OF FADING CHANNELS AVAILABLE:
 117. 1: NO SPECULAR COMPONENT (RALEIGH FADING)
 118. 2: SPECULAR COMPONENT. SHORTEST PATH
 119.

120. INPUT TYPE OF CHANNEL: ²
 121. ENTER THE MULTIPATH SPREAD TIME (IN MICROSECONDS. F9.2): 500.00 MICROSECONDS
 122. ENTER THE DOPPLER SPREAD BANDWIDTH (IN HERTZ. F7.2): 1.00 Hz
 123.
 124.
 125.
 126. Are multiple values of the specular to multipath power ratio to be tested? (Y/N):
 127. Y
 128. Input the range of values to be tested (in DB):
 129. Input the initial value (-99 -- +99.13): 11DB
 130. Input the increment value (-99 -- +99.12): 10DB
 131. Input the final value (01 -- 99.12): 23DB
 132.
 133.
 134.
 135.
 136. SET PARAMETERS FOR THE SECOND FADING CHANNEL:
 137. TYPES OF FADING CHANNELS AVAILABLE:
 138. 1: NO SPECULAR COMPONENT (RALEIGH FADING)
 139. 2: SPECULAR COMPONENT, SHORTEST PATH
 140. 3: SPECULAR COMPONENT, MEAN PATH
 141. INPUT TYPE OF CHANNEL: ²
 142.
 143. ENTER THE MULTIPATH SPREAD TIME (IN MICROSECONDS. F9.2): 500.00 MICROSECONDS
 144. ENTER THE DOPPLER SPREAD BANDWIDTH (IN HERTZ. F7.2): 1.00 Hz
 145.
 146.
 147. Are multiple values of the specular to multipath power ratio to be tested? (Y/N):
 148. Y
 149. Input the range of values to be tested (in DB):
 150. Input the initial value (-99 -- +99.13): 11DB
 151. Input the increment value (-99 -- +99.12): 10DB
 152.
 153.
 154.
 155.
 156.
 157. Are multiple SNR values to be tested? Y=Yes, N=No:
 158.
 159. Input the range of SNR values to be tested (in DB): ^Y
 160. Input the initial value of SNR (-99 -- +99.13): 10 DB
 161.
 162. Input the increment value (01 -- 99. 12): 4 DB
 163.
 164. Input the ending value of SNR (-99 -- +99. 13): 40 DB
 165.
 166. IS A SPACE DIVERSITY RECEIVER REQUIRED? (Y/N): ^Y
 167.
 168. INPUT DURATION BETWEEN DECISION TIMES FOR THE S.D. RECEIVER (F7.5. IN SECONDS) 0.00020 SEC.
 169.
 170. Input the approximate duration of simulation in seconds (0.01 - 9.99. F4.2): 0.01 SEC.
 171.
 172. Type of performance measurement available:
 173. 1. Compare recovered output signal to original input signal
 174. 2. Measure output signal to noise ratio
 175. Input type:
 176. ²
 177. 1- Specular to multipath power ratio- Uplink Channel.
 178. 2-Specular to multipath power ratio- Downlink Channel
 179. 3-Carrier to interference power ratios- UHF Uplink Channel

ORIGINAL PAGE IS
OF POOR QUALITY

ORIGINAL PAGE IS
OF POOR QUALITY

4-Phase values of interference- UHF Uplink Channel
5-Carrier to Interference power ratios- UHF Downlink Channel
6-Phase values of interference- UHF Downlink Channel

7-Inout SNR Value
8-Output SNR Value

	1	2	3	4	5	6	7	8
180.								
181.								
182.								
183.								
184.								
185.								
186.								
187.	50.00	11.00	30.00	5.00	10.00	10.00	10.00	30.3934021
188.	50.00	11.00	30.00	5.00	10.00	10.00	10.00	47.3245239
189.	50.00	11.00	30.00	5.00	10.00	10.00	10.00	50.2981110
190.	50.00	11.00	30.00	5.00	10.00	10.00	22.00	51.2792206
191.	50.00	11.00	30.00	5.00	10.00	10.00	26.00	54.7541809
192.	50.00	11.00	30.00	5.00	10.00	10.00	30.00	52.6393585
193.	50.00	11.00	30.00	5.00	10.00	10.00	34.00	56.1096954
194.	50.00	11.00	30.00	5.00	10.00	10.00	38.00	56.5043640
195.	50.00	11.00	30.00	5.00	10.00	15.00	10.00	44.7787476
196.	50.00	11.00	30.00	5.00	10.00	15.00	14.00	48.3026123
197.	50.00	11.00	30.00	5.00	10.00	15.00	18.00	49.7561340
198.	50.00	11.00	30.00	5.00	10.00	15.00	22.00	50.7426758
199.	50.00	11.00	30.00	5.00	10.00	15.00	26.00	56.9706879
200.	50.00	11.00	30.00	5.00	10.00	15.00	30.00	56.2624512
201.	50.00	11.00	30.00	5.00	10.00	15.00	34.00	56.3648682
202.	50.00	11.00	30.00	5.00	10.00	15.00	38.00	53.2024231
203.	50.00	11.00	30.00	5.00	20.00	10.00	10.00	43.4536896
204.	50.00	11.00	30.00	5.00	20.00	10.00	14.00	45.6832581
205.	50.00	11.00	30.00	5.00	20.00	10.00	18.00	49.5190517
206.	50.00	11.00	30.00	5.00	20.00	10.00	22.00	51.9888763
207.	50.00	11.00	30.00	5.00	20.00	10.00	26.00	52.6079559
208.	50.00	11.00	30.00	5.00	20.00	10.00	30.00	54.6950989
209.	50.00	11.00	30.00	5.00	20.00	10.00	34.00	53.6224518
210.	50.00	11.00	30.00	5.00	20.00	10.00	38.00	56.5738373
211.	50.00	11.00	30.00	5.00	20.00	15.00	10.00	44.2585754
212.	50.00	11.00	30.00	5.00	20.00	15.00	14.00	47.7853851
213.	50.00	11.00	30.00	5.00	20.00	15.00	18.00	50.1994781
214.	50.00	11.00	30.00	5.00	20.00	15.00	22.00	51.7635803
215.	50.00	11.00	30.00	5.00	20.00	15.00	26.00	56.5586243
216.	50.00	11.00	30.00	5.00	20.00	15.00	30.00	53.9149475
217.	50.00	11.00	30.00	5.00	20.00	15.00	34.00	57.5394592
218.	50.00	11.00	30.00	5.00	20.00	15.00	38.00	54.844366
219.	50.00	11.00	30.00	6.00	10.00	10.00	10.00	45.7154999
220.	50.00	11.00	30.00	6.00	10.00	10.00	14.00	47.1175690
221.	50.00	11.00	30.00	6.00	10.00	10.00	18.00	50.5426788
222.	50.00	11.00	30.00	6.00	10.00	10.00	22.00	51.5821606
223.	50.00	11.00	30.00	6.00	10.00	10.00	26.00	55.7178497
224.	50.00	11.00	30.00	6.00	10.00	10.00	30.00	51.8821564
225.	50.00	11.00	30.00	6.00	10.00	10.00	34.00	53.1560211
226.	50.00	11.00	30.00	6.00	10.00	10.00	38.00	52.5801348
227.	50.00	11.00	30.00	6.00	10.00	15.00	26.00	53.6389618
228.	50.00	11.00	30.00	6.00	10.00	15.00	30.00	52.2198944
229.	50.00	11.00	30.00	6.00	10.00	15.00	34.00	48.3472900
230.	50.00	11.00	30.00	6.00	10.00	15.00	38.00	54.8455865
231.	50.00	11.00	30.00	6.00	10.00	15.00	40.00	58.1746674
232.	50.00	11.00	30.00	6.00	10.00	15.00	44.00	55.4336243
233.	50.00	11.00	30.00	6.00	10.00	15.00	48.00	43.6742096
234.	50.00	11.00	30.00	6.00	10.00	15.00	52.00	46.3095856
235.	50.00	11.00	30.00	6.00	20.00	10.00	10.00	48.9533997
236.	50.00	11.00	30.00	6.00	20.00	10.00	18.00	49.1971588
237.	50.00	11.00	30.00	6.00	20.00	10.00	22.00	54.4777325
238.	50.00	11.00	30.00	6.00	20.00	10.00	26.00	

ORIGINAL PAGE IS
OF POOR QUALITY

ORIGINAL PAGE IS
OF POOR QUALITY

Is this an online session? (Y/N) N

1. TYPE OF CALL AVAILABLE:
2. 1: M1->M2, rural mobile to rural mobile in same UHF beam, in same S-band
3. 2: M1->M3, rural mobile to rural mobile in different UHF beam, in same S-band
4. 3: M1->M4, rural mobile to rural mobile in different UHF beam, in different S-band
5. 4: M1->FC1, rural mobile to fixed in same S-band beam
6. 5: M1->FC2, rural mobile to fixed in different S-band beam
7. 6: FC1->M1, fixed to rural mobile in same S-band beam
8. 7: FC2->M1, fixed to rural mobile in different S-band beam
9. INPUT TYPE OF CALL TO BE SIMULATED: 1
10. MODE OF CALL AVAILABLE:
11. 1: M1->M2, hard wired transponder
12. 2: M1->M2, direct switched transponder
13. 3: M1->M2, indirect switched transponder
14. 4: M1->G1->M2, double hop system
15. INPUT MODE OF CALL TO BE SIMULATED: 2
16. TYPE OF SIGNAL SOURCES AVAILABLE:
17. 1: Program generated single tone sinusoid.
18. 2: Sampled voice from tape source.
19. Choose type of signal to be used (1/2) : 1
20. FREQUENCY OF THE BASEBAND SIGNAL (LESS THAN 3000 HZ.) (IN HERTZ, F7.2) : 1000.00 HZ
21. NOTE : POWER OF THE BASEBAND SIGNAL HAS TO BE LESS OR EQUAL THAN .5 WATTS;
22. SO THAT THE MAXIMUM INSTANTANEOUS FREQUENCY DEVIATION IS
23. LESS OR EQUAL THAN 12000 HZ
24. POWER OF THE BASEBAND SIGNAL (IN WATTS, F7.2) : 0.50 WATTS
25. THE CARRIER POWER (IN WATTS, F7.2) : 1.00 WATTS
26. THE FREQUENCY DEVIATION (IN HERTZ, F8.2) : 12000 HZ. (FIXED FOR NOW)
27. How many times the nyquist rate do you want the sampling frequency to be? (2 - 4, 11) : 2
28. THE CARRIER FREQUENCY (IN HERTZ, F7.2) : (NOT USED FOR NOW)
29. DO YOU WANT THE COMPRESSOR/EXPANDER IN? Y-YES . N-NO : Y
30. DO YOU WANT THE PRE-EMPHASIS - DE-EMPHASIS FILTERS IN ? Y-YES , N-NO : N
31. DO YOU WANT A CO-CHANNEL INTERFERER IN THE UPLINK? Y-YES , N-NO: Y
32. Are multiple values of the carrier to interference power ratio to be tested? (Y/N): Y
33. Input the range of values to be tested (in DB):
34. Input the initial value (-99 -- +99,I3) : 0DB
35. Input the increment value (01 -- 99,I3) : 4DB
36. Input the final value (01 -- 99,I3) : 20DB
37. Are multiple values of the interference phase values to be tested? (Y/N): N
38. INPUT PHASE OF INTERFERENCE IN DEGREES (F7.2) : 0.0 DEGREES
39. IS FADING PRESENT IN THE UHF - UPLINK CHANNEL? Y-YES ,N-NO: N
- 40.
- 41.
- 42.
- 43.
- 44.
- 45.
- 46.
- 47.
- 48.
- 49.
- 50.
- 51.
- 52.
- 53.
- 54.
- 55.
- 56.
- 57.
- 58.
- 59.

ORIGINAL PAGE IS
OF POOR QUALITY

ORIGINAL PAGE IS
OF POOR QUALITY

Page Intentionally Left Blank

ORIGINAL PAGE IS
OF POOR QUALITY

**ORIGINAL PAGE IS
OF POOR QUALITY**

ORIGINAL PAGE IS
OF POOR QUALITY

ORIGINAL PAGE IS
OF POOR QUALITY

76 |
75 |
74 |
73 |
72 |
71 |
70 |
69 |
68 |
67 |
66 |
65 |
64 |
63 |
62 |
61 |
60 |
59 |
58 |
57 |
56 |
55 |
54 |
53 |
52 |
51 |
50 |
49 |
48 |
47 |
46 |
45 |
44 |
43 |
42 |
41 |
40 |
39 |
38 |
37 |
36 |
35 |
34 |
33 |
32 |
31 |
30 |
29 |
28 |
27 |
26 |
25 |
24 |
23 |
22 |
21 |
20 |
19 |
18 |
17 |
16 |
15 |
14 |
13 |
12 |
11 |
10 |
9 |
8 |
7 |
6 |
5 |
4 |
3 |
2 |
1 |
0 |

**ORIGINAL PAGE IS
OF POOR QUALITY**

ORIGINAL PAGE IS
OF POOR QUALITY

62 |
61 |
543 | 54 |
544 | 56 |
545 | 55 |
546 | 58 |
547 | 57 |
548 | 56 |
549 | 55 |
550 | 54 |
551 | 53 |
552 | 52 |
553 | 51 |
554 | 50 |
555 | 49 |
556 | 48 |
557 | 47 |
558 | 46 |
559 | 45 |
560 | 44 |
561 | 43 |
562 | 42 |
563 | 41 |
564 | 40 |
565 | 39 |
566 | 38 |
567 | 37 |
568 | 36 |
569 | 35 |
570 | 34 |
571 | 33 |
572 | 32 |
573 | 31 |
574 | 30 |
575 | 29 |
576 | 28 |
577 | 27 |
578 | 26 |
579 | 25 |
580 | 24 |
581 | 23 |
582 | 22 |
583 | 21 |
584 | 20 |
585 | 19 |
586 | 18 |
587 | 17 |
588 | 16 |
589 | 15 |
590 | 14 |
591 | 13 |
592 | 12 |
593 | 11 |
594 | 10 |
595 | 9 |
596 | 8 |
597 | 7 |
598 | 6 |
599 | 5 |

ORIGINAL PAGE IS
OF POOR QUALITY

ORIGINAL PAGE IS
OF POOR QUALITY

3.
 4. TYPE OF CALL AVAILABLE:
 5. 1: M1->M2, rural mobile to rural mobile in same UHF beam, in same S-band
 6. 2: M1->M3, rural mobile to rural mobile in different UHF beam, in different S-band
 7. 3: M1->FC1, rural mobile to rural mobile in same S-band beam
 8. 4: M1->FC2, rural mobile to fixed in different S-band beam
 9. 5: M1->H1, fixed to rural mobile in same S-band beam
 10. 6: FC1->H1, fixed to rural mobile in different S-band beam
 11. 7: FC2->H1, fixed to rural mobile in different S-band beam
 12. INPUT TYPE OF CALL TO BE SIMULATED: 1
13. MODE OF CALL AVAILABLE:
 14. 1: M1->H2, hard wired transponder
 15. 2: M1->H2, direct switched transponder
 16. 3: M1->H2, indirect switched transponder
 17. 4: M1->G1->H2, double hop system
 18. INPUT MODE OF CALL TO BE SIMULATED: 4
19. TYPE OF SIGNAL SOURCES AVAILABLE:
 20. 1: Program generated single tone sinusoid.
 21. 2: Sampled voice from tape source.
 22. Choose type of signal to be used (11) : 1
23. FREQUENCY OF THE BASEBAND SIGNAL (LESS THAN 3000 HZ.) (IN HERTZ, F7.2) : 1000.00 HZ
24. NOTE : POWER OF THE BASEBAND SIGNAL HAS TO BE LESS OR EQUAL THAN .5 WATTS;
 SO THAT THE MAXIMUM INSTANTANEOUS FREQUENCY DEVIATION IS
 LESS OR EQUAL THAN 12000 HZ
25. POWER OF THE BASEBAND SIGNAL (IN WATTS, F7.2) : 0.50 WATTS
26. THE CARRIER POWER (IN WATTS, F7.2) : 1.00 WATTS
27. THE FREQUENCY DEVIATION (IN HERTZ, F8.2) : 12000 HZ. (FIXED FOR NOW)
 How many times the nyquist rate do you want the sampling frequency to be? (2 - 4, I1) : 2
28. 29. 30. 31. 32. 33. 34. 35. 36. 37. 38. 39. 40. 41. 42. 43. 44. 45. 46. 47. 48. 49. 50. 51. 52. 53. 54. 55. 56. 57. 58. 59.
- THE CARRIER FREQUENCY (IN HERTZ, F7.2) : (NOT USED FOR NOW)
 DO YOU WANT THE COMPRESSOR/EXPANDER IN? Y-YES , N-NO : Y
 DO YOU WANT THE PRE-EMPHASIS - DE-EMPHASIS FILTERS IN? Y-YES , N-NO : N
 DO YOU WANT A CO-CHANNEL INTERFERER IN THE UPLINK? Y-YES, N-NO: N
 IS FADING PRESENT IN THE UHF - UPLINK CHANNEL? Y-YES, N-NO: Y
 IS THE INTERFERENCE FADED? Y-YES, N-NO: N
 THE UPLINK FADING CHANNEL IS PRESENT
 TYPES OF FADING CHANNELS AVAILABLE:
 1: NO SPECULAR COMPONENT (RALEIGH FADING)
 2: SPECULAR COMPONENT, SHORTEST PATH
 3: SPECULAR COMPONENT, MEAN PATH
 INPUT TYPE OF CHANNEL: 2
- ENTER THE MULTIPATH SPREAD TIME (IN MICROSECONDS, F9.2) : 500.00 MICROSECONDS
- ENTER THE DOPPLER SPREAD BANDWIDTH (IN HERTZ, F7.2) : 1.00 HZ
- Are multiple values of the specular to multipath power

ORIGINAL PAGE IS
OF POOR QUALITY

Ratio to be tested? (r/r): Y

61. Input the range of values to be tested (In DB):
 62. Input the initial value (-99 -- +99,I3): 10DB
 63. Input the increment value (-99 -- +99,I2): 25DB
 64. Input the final value (01 -- 99,I2): 90DB
 65. DO YOU WANT A CO-CHANNEL INTERFERER IN THE S-BAND DOWNLINK? Y-YES,N-NO: N
 66. IS FADING PRESENT IN THE S-BAND DOWNLINK CHANNEL? Y-YES,N-NO: Y
 67. IS A SPACE DIVERSITY RECEIVER BEING USED? Y-YES,N-NO: N
 68. THE DOWNLINK FADING CHANNEL IS PRESENT
 69. SET PARAMETERS FOR FADING CHANNEL.
 70. TYPES OF FADING CHANNELS AVAILABLE:
 71. 1: NO SPECULAR COMPONENT (RALEIGH FADING)
 72. 2: SPECULAR COMPONENT, SHORTEST PATH
 73. 3: SPECULAR COMPONENT, MEAN PATH
 74. INPUT TYPE OF CHANNEL:
 75. ENTER THE MULTIPATH SPREAD TIME (IN MICROSECONDS, F9.2): 500.00 MICROSECONDS
 76. ENTER THE DOPPLER SPREAD BANDWIDTH (IN HERTZ, F7.2): 1.00 HZ
 77. Are multiple values of the specular to multipath power
 78. ratio to be tested? (Y/N): Y
 79. Input the range of values to be tested (In DB):
 80. Input the initial value (-99 -- +99,I3): 11DB
 81. Input the increment value (-99 -- +99,I2): 25DB
 82. Input the final value (01 -- 99,I2): 90DB
 83. DO YOU WANT A CO-CHANNEL INTERFERER IN THE S-BAND UPLINK? Y-YES,N-NO: N
 84. IS FADING PRESENT IN THE S-BAND UPLINK CHANNEL? Y-YES,N-NO: Y
 85. IS THE INTERFERENCE FADED? Y-YES,N-NO: N
 86. THE UPLINK FADING CHANNEL IS PRESENT
 87. TYPES OF FADING CHANNELS AVAILABLE:
 88. 1: NO SPECULAR COMPONENT (RALEIGH FADING)
 89. 2: SPECULAR COMPONENT, SHORTEST PATH
 90. 3: SPECULAR COMPONENT, MEAN PATH
 91. INPUT TYPE OF CHANNEL:
 92. ENTER THE MULTIPATH SPREAD TIME (IN MICROSECONDS, F9.2): 500.00 MICROSECONDS
 93. ENTER THE DOPPLER SPREAD BANDWIDTH (IN HERTZ, F7.2): 1.00 HZ
 94. Are multiple values of the specular to multipath power
 95. ratio to be tested? (Y/N): Y
 96. Input the range of values to be tested (In DB):
 97. Input the initial value (-99 -- +99,I3): 12DB
 98. Input the increment value (-99 -- +99,I2): 25DB
 99. Input the final value (01 -- 99,I2): 90DB
 100. DO YOU WANT A CO-CHANNEL INTERFERER IN THE S-BAND DOWNLINK? Y-YES,N-NO: N
 101. IS FADING PRESENT IN THE S-BAND DOWNLINK CHANNEL? Y-YES,N-NO: Y
 102. IS THE INTERFERENCE FADED? Y-YES,N-NO: N
 103. THE DOWNLINK FADING CHANNEL IS PRESENT
 104. TYPES OF FADING CHANNELS AVAILABLE:
 105. 1: NO SPECULAR COMPONENT (RALEIGH FADING)
 106. 2: SPECULAR COMPONENT, SHORTEST PATH
 107. 3: SPECULAR COMPONENT, MEAN PATH
 108. INPUT TYPE OF CHANNEL:
 109. ENTER THE MULTIPATH SPREAD TIME (IN MICROSECONDS, F9.2): 500.00 MICROSECONDS
 110. ENTER THE DOPPLER SPREAD BANDWIDTH (IN HERTZ, F7.2): 1.00 HZ
 111. Are multiple values of the specular to multipath power
 112. ratio to be tested? (Y/N): Y
 113. Input the range of values to be tested (In DB):
 114. Input the initial value (-99 -- +99,I3): 12DB
 115. Input the increment value (-99 -- +99,I2): 25DB
 116. Input the final value (01 -- 99,I2): 90DB
 117. DO YOU WANT A CO-CHANNEL INTERFERER IN THE S-BAND UPLINK? Y-YES,N-NO: N
 118. IS FADING PRESENT IN THE S-BAND UPLINK CHANNEL? Y-YES,N-NO: Y
 119. IS THE INTERFERENCE FADED? Y-YES,N-NO: N

ORIGINAL PAGE IS
OF POOR QUALITY

-) 120. Input the increment value (-99 -- +99, I2) : 25DB
121.
122.
123.
124. DO YOU WANT A CO-CHANNEL INTERFERER IN THE DOWNLINK? Y-YES, N-NO: N
125.
126.
127.
128. IS A SPACE DIVERSITY RECEIVER BEING USED? Y-YES, N-NO: Y
129.
130. THE DOWNLINK FADING CHANNEL IS PRESENT
SET PARAMETERS FOR FADING CHANNEL:
131.
132. TYPES OF FADING CHANNELS AVAILABLE:
133. 1: NO SPECULAR COMPONENT (RALEIGH FADING)
134. 2: SPECULAR COMPONENT, SHORTEST PATH
135. 3: SPECULAR COMPONENT, MEAN PATH
136. INPUT TYPE OF CHANNEL: 2
137.
138. ENTER THE MULTIPATH SPREAD TIME (IN MICROSECONDS. F9.2) : 500.00 MICROSECONDS
139.
140. ENTER THE DOPPLER SPREAD BANDWIDTH (IN HERTZ. F7.2) : 500.00 HZ
141.
142.
143. Are multiple values of the specular to multipath power
ratio to be tested? (Y/N): Y
144.
145. Input the range of values to be tested (In DB):
146. Input the initial value (-99 -- +99, I3) : 14DB
147.
148. Input the increment value (-99 -- +99, I2) : 25DB
149.
150. Input the final value (01 -- 99, I2) : 90DB
151.
152. Are multiple SNR values to be tested? Y-Yes, N-no: Y
153.
154. Input the range of SNR values to be tested (In Db):
155. Input the initial value of SNR (-99 -- +99, I3) : 1 DB
156.
157. Input the increment value (01 -- 99, I2) : 5 DB
158.
159. Input the ending value of SNR (-99 -- +99, I3) : 40 DB
160.
161. IS A SPACE DIVERSITY RECEIVER REQUIRED? (Y/N) N
162.
163. Input the approximate duration of simulation in seconds (0.01 - 9.99, F5.2) : 0.02 SEC.
164.
165. Type of performance measurement available:
166. 1. Compare recovered output signal to original input signal
167. 2. Measure output signal to noise ratio
Input type:
168.
169.
170. Do you want output to be plotted ? (Y/N) : N
171.
172.
173. 1-Specular to multipath power ratio- UHF UpLink Channel.
174. 2-Specular to multipath power ratio- S-BANDDownlink Channel.
175. 3-Specular to multipath power ratio- S-BANDUpLink Channel.
176. 4-Specular to multipath power ratio- UHF DownLinkChannel
177.
178.
179. 5-Input SNR Value
6-Output SNR Value
1 2 3 4 5
6

**ORIGINAL PAGE IS
OF POOR QUALITY**

| | | | | | | |
|------|-------|-------|-------|-------|------------|-------------|
| 181. | 10.00 | 11.00 | 12.00 | 14.00 | 1.0000000 | 31.6197632 |
| 182. | 10.00 | 11.00 | 12.00 | 14.00 | 6.0000000 | 34.6829987 |
| 183. | 10.00 | 11.00 | 12.00 | 14.00 | 11.0000000 | 38.5540161 |
| 184. | 10.00 | 11.00 | 12.00 | 14.00 | 16.0000000 | 40.3591614 |
| 185. | 10.00 | 11.00 | 12.00 | 14.00 | 21.0000000 | 36.0269775 |
| 186. | 10.00 | 11.00 | 12.00 | 14.00 | 26.0000000 | 40.2135925 |
| 187. | 10.00 | 11.00 | 12.00 | 14.00 | 31.0000000 | 41.0075531 |
| 188. | 10.00 | 11.00 | 12.00 | 14.00 | 36.0000000 | 41.8792419 |
| 189. | 10.00 | 11.00 | 37.00 | 14.00 | 1.0000000 | 32.0381775 |
| 190. | 10.00 | 11.00 | 37.00 | 14.00 | 6.0000000 | 38.1804352 |
| 191. | 10.00 | 11.00 | 37.00 | 14.00 | 11.0000000 | 37.1580200 |
| 192. | 10.00 | 11.00 | 37.00 | 14.00 | 16.0000000 | 42.1793671 |
| 193. | 10.00 | 11.00 | 37.00 | 14.00 | 21.0000000 | 43.2643585 |
| 194. | 10.00 | 11.00 | 37.00 | 14.00 | 26.0000000 | 46.9673157 |
| 195. | 10.00 | 11.00 | 37.00 | 14.00 | 31.0000000 | 48.9451447 |
| 196. | 10.00 | 11.00 | 37.00 | 14.00 | 36.0000000 | 42.9842072 |
| 197. | 10.00 | 11.00 | 62.00 | 14.00 | 1.0000000 | 33.0088196 |
| 198. | 10.00 | 11.00 | 62.00 | 14.00 | 6.0000000 | 37.2350464 |
| 199. | 10.00 | 11.00 | 62.00 | 14.00 | 11.0000000 | 41.6312103 |
| 200. | 10.00 | 11.00 | 62.00 | 14.00 | 16.0000000 | 42.7033081 |
| 201. | 10.00 | 11.00 | 62.00 | 14.00 | 21.0000000 | 39.6892242 |
| 202. | 10.00 | 11.00 | 62.00 | 14.00 | 26.0000000 | 39.7191010 |
| 203. | 10.00 | 11.00 | 62.00 | 14.00 | 31.0000000 | 44.9123077 |
| 204. | 10.00 | 11.00 | 62.00 | 14.00 | 36.0000000 | 39.7061920 |
| 205. | 10.00 | 11.00 | 87.00 | 14.00 | 1.0000000 | 20.8714905 |
| 206. | 10.00 | 11.00 | 87.00 | 14.00 | 6.0000000 | 36.3129120 |
| 207. | 10.00 | 11.00 | 87.00 | 14.00 | 11.0000000 | 40.22752686 |
| 208. | 10.00 | 11.00 | 87.00 | 14.00 | 16.0000000 | 42.8176880 |
| 209. | 10.00 | 11.00 | 87.00 | 14.00 | 21.0000000 | 40.7845306 |
| 210. | 10.00 | 11.00 | 87.00 | 14.00 | 26.0000000 | 45.0499725 |
| 211. | 10.00 | 11.00 | 87.00 | 14.00 | 31.0000000 | 40.1223450 |
| 212. | 10.00 | 11.00 | 87.00 | 14.00 | 36.0000000 | 45.1003876 |
| 213. | 10.00 | 36.00 | 12.00 | 14.00 | 1.0000000 | 32.4762726 |
| 214. | 10.00 | 36.00 | 12.00 | 14.00 | 6.0000000 | 34.8208313 |
| 215. | 10.00 | 36.00 | 12.00 | 14.00 | 11.0000000 | 37.4087982 |
| 216. | 10.00 | 36.00 | 12.00 | 14.00 | 16.0000000 | 42.6144714 |
| 217. | 10.00 | 36.00 | 12.00 | 14.00 | 21.0000000 | 38.4624634 |
| 218. | 10.00 | 36.00 | 12.00 | 14.00 | 26.0000000 | 43.3883820 |
| 219. | 10.00 | 36.00 | 12.00 | 14.00 | 31.0000000 | 40.4772797 |
| 220. | 10.00 | 36.00 | 12.00 | 14.00 | 36.0000000 | 43.5606537 |
| 221. | 10.00 | 36.00 | 37.00 | 14.00 | 1.0000000 | 33.0967865 |
| 222. | 10.00 | 36.00 | 37.00 | 14.00 | 6.0000000 | 37.3872528 |
| 223. | 10.00 | 36.00 | 37.00 | 14.00 | 11.0000000 | 38.3372498 |
| 224. | 10.00 | 36.00 | 37.00 | 14.00 | 16.0000000 | 43.0029449 |
| 225. | 10.00 | 36.00 | 37.00 | 14.00 | 21.0000000 | 31.4471283 |
| 226. | 10.00 | 36.00 | 62.00 | 14.00 | 6.0000000 | 35.7543030 |
| 227. | 10.00 | 36.00 | 62.00 | 14.00 | 11.0000000 | 41.5781708 |
| 228. | 10.00 | 36.00 | 62.00 | 14.00 | 16.0000000 | 43.9695587 |
| 229. | 10.00 | 36.00 | 62.00 | 14.00 | 21.0000000 | 41.0463257 |
| 230. | 10.00 | 36.00 | 62.00 | 14.00 | 26.0000000 | 43.2192688 |
| 231. | 10.00 | 36.00 | 62.00 | 14.00 | 31.0000000 | 41.2209320 |
| 232. | 10.00 | 36.00 | 62.00 | 14.00 | 36.0000000 | 42.5592041 |
| 233. | 10.00 | 36.00 | 62.00 | 14.00 | 1.0000000 | 31.7581329 |
| 234. | 10.00 | 36.00 | 62.00 | 14.00 | 6.0000000 | 36.1853180 |
| 235. | 10.00 | 36.00 | 62.00 | 14.00 | 11.0000000 | 40.9545441 |

**ORIGINAL PAGE IS
OF POOR QUALITY**