

2000 NASA Aerospace Battery Workshop

**Recent Developments in Silver/Zinc
Rechargeable Cell Studies**

**Harlan L. Lewis
NAVSEA Crane**

14-16 November 2000

Recent Developments In Silver/Zinc Rechargeable Cell Studies



Introduction – History of cellophane and sausage casing model cell studies.

Objective – Reduce number of layers of separation on cathode while maintaining cell performance.

Experimental – Five cell sets of thirteen cells each. Eight cycle life and five wet life. Periodic cell removal for design performance analysis.

Recent Developments In Silver/Zinc Rechargeable Cell Studies



Cell Separation Configurations;

Set 1 – Reference standard set – six layer of 1-mil untreated Flexel clear cellophane provided by Yardney Technical Products (YTP), cathode wrap.

Set 2 – Reference standard set – six layers of 1-mil Flexel cellophane silver-treated (C-19) by YTP, cathode wrap.

Set 11 – Double layer SC set – one layer of 1-mil tubular SC followed by one layer of 2-mil PVA, followed by two layers of 2.3-mil SC from split SC tubing, cathode wrap.

Set 12 – Single layer SC set – one layer of 1-mil tubular SC followed by one layer of 2-mil PVA, followed by one layer of 2.3-mil SC from split SC tubing, cathode wrap. Cells were shimmed with cell case plastic to provide constant internal stack pressure vs. set 1.

Set 13 – Split wrap set – three layers of 1-mil Flexel cellophane silver-treated (C-19) by YTP, cathode wrap, plus three layers anode wrap. (The anodes were wrapped in a split L-configuration to seal the bottom of the anodes.)

Recent Developments In Silver/Zinc Rechargeable Cell Studies




- **Results and Discussion**
 - ✓ **Discharge capacity comparisons**
 - ✓ **Silver migration comparisons**

Recent Developments In Silver/Zinc Rechargeable Cell Studies




**Cycle life data
show approx.
equivalent
performance.**



Recent Developments In Silver/Zinc Rechargeable Cell Studies




All but one of
the clear Flexel
wet life cells
shorted out by
the tenth
month, while
none of the
C19 cells
shorted, so
comparison is
flawed.



Recent Developments In Silver/Zinc Rechargeable Cell Studies




**Cycle life data
show a significant
performance
advantage for split
wrap.**



Recent Developments In Silver/Zinc Rechargeable Cell Studies




**Wet life data
also show a
significant
capacity
advantage for
split wrap.**



Recent Developments In Silver/Zinc Rechargeable Cell Studies




**Combined plots
for split wrap vs.
both standard
wraps in cycle life.
The split wrap
performance is
clearly superior.**



Recent Developments In Silver/Zinc Rechargeable Cell Studies




The Set 1 cells shorted out beginning at the 6th month, while no cells in Sets 2 and 13 shorted at all, so the discharge capacity averages do not reflect the actual performance adequately. Sets 2 and 13 were actually superior to Set 1, overall.



Recent Developments In Silver/Zinc Rechargeable Cell Studies




**Cycle life data for
the two SC
configurations
exhibit slightly
lowered capacity
vs. C19, but no
shorts occurred
in any Set.**



Recent Developments In Silver/Zinc Rechargeable Cell Studies




Wet life data
indicate that single
layer SC performed
as well as C19 in
late life.



Recent Developments In Silver/Zinc Rechargeable Cell Studies




**Silver migration in
cycle life cells was
identical for clear
vs. silver-treated
cellophane.**




Recent Developments In Silver/Zinc Rechargeable Cell Studies




**Silver migration in wet
life cells occurred at a
much lower rate for
C19 cells.**



Recent Developments In Silver/Zinc Rechargeable Cell Studies




**Silver migration
for split wrap
similar to
standard wrap in
cycle life.**



Recent Developments In Silver/Zinc Rechargeable Cell Studies




**Silver migration in
split wrap cells
occurred at a much
greater rate than
for standard wrap
cells in wet life.**



Recent Developments In Silver/Zinc Rechargeable Cell Studies




Although it appears that the single SC layer cells have a much higher silver migration rate than C19, layer-by-layer data show that all the silver in both SC sets was trapped at the PVA layer.




Recent Developments In Silver/Zinc Rechargeable Cell Studies



As in the cycle life data, here also the layer-by-layer data show that all the silver in the SC cells was stopped by the PVA film.



Recent Developments In Silver/Zinc Rechargeable Cell Studies



Conclusions

Clear vs. Silver-Treated Cellophane

Split wrap vs. “Standard” Wrap

Cellophane vs. Sausage Casing



Recent Developments In Silver/Zinc Rechargeable Cell Studies

Recommendations

➤ **Use silver-treated cellophane instead of clear cellophane**

Use split wrap for cellophane whenever possible

Strongly consider use of sausage casing with PVA film in the following configuration:

**1-mil (tubular) SC/1-mil PVA film/2.3-mil plain or
6-mil fiber-reinforced SC tubular**

Recent Developments In Silver/Zinc Rechargeable Cell Studies



Acknowledgements

➤ Cellophane film samples were purchased from
Yardney Technical Products

Sausage Casing samples were furnished by Viskase
Corporation

Funding support came from NAVSEA 03Z,
SPECWARCOM, and Viskase Corporation