

N64 11325

Final Report

CODE-1

to

NASA CR 52878

National Aeronautics and Space Administration
Houston 1, Texas

Contract No. NASr-70

ELECTROLYTIC PRODUCTION OF OXYGEN AND
REDUCTION OF CARBON DIOXIDE

R.E. Shearer
C.A. Palladino
J.C. King

4 June 1963

MSA Research Corporation

Subsidiary of Mine Safety Appliances Company

Callery, Pennsylvania

XA 720291

OTS PRICE

XEROX \$ 3.60 ph
MICROFILM \$ 1.34 mf.

(NASA CR-52878
MSAR 63-82) OTS: ...

Final Report

to

National Aeronautics and Space Administration
Houston 1, Texas

2 ELECTROLYTIC PRODUCTION OF OXYGEN AND
REDUCTION OF CARBON DIOXIDE *Final ...*

MSAR Job No. XA 720291

(NASA Contract No. NASr-70)

auths.

R.E. Shearer,
C.A. Palladino, and
J.C. King

date 38 p

refs

4 June 1963

5961008

MSA RESEARCH CORPORATION
Callery, Pennsylvania
Pa.

TABLE OF CONTENTS

	Page No.
I. INTRODUCTION	1
II. CONCEPT	2
III. ANALYTICAL DEVELOPMENTS	3
Analysis of Electrolytes	3
Analysis of Gas Phases	5
Results of Analytical Procedures	5
IV. ELECTROCHEMICAL STUDIES	7
Cathode Material and Structure	17
Diaphragms	21
Catalysts and Promoters	22
Catholytes	22
Pressure	25
Temperature	27
Summary on Reduction of Formic Acid	27
Summary on Reduction of Carbon Dioxide	28
V. COLLATION WITH THE LITERATURE	29
VI. CONCLUSIONS	32
VII. BIBLIOGRAPHY	33

ABSTRACT

11325

Work is reported on studies of the cathodic reduction of carbon dioxide with simultaneous anodic production of breathing oxygen from aqueous solutions.

Studies included those of analytical procedures for possible organic products such as formic acid, formaldehyde, methanol and methane. Details are given on the chemical and gas chromatographic procedures adopted for routine analysis.

Details of studies of various parameters normally influencing cathodic reduction are given. It was found that use of mercury cathodes and electrolytes of either Li_2SO_4 , K_2SO_4 , Na_2SO_4 or BeSO_4 consistently gave rise to reduction of CO_2 to formic acid with efficiencies as high as 20%. However, while concentrated formic acid was reduced, further reduction of the formic acid of the concentrations up to 1% obtained by reduction of CO_2 was not obtained. Since such further reduction is needed for good control of space capsule atmospheres, no attempt was made to develop a prototype system for atmosphere control.

AUTHOR

Final Report

to

National Aeronautics and Space Administration
Houston 1, Texas

on

ELECTROLYTIC PRODUCTION OF OXYGEN AND REDUCTION OF CARBON DIOXIDE


I. INTRODUCTION

The work performed under the subject contract involved the investigation of scientific principles and processes for the anodic production of breathing oxygen and the simultaneous cathodic reduction of carbon dioxide. A number of variables influence these processes, including cathode current density, cathode material and physical structure, types of diaphragms, electrolyte composition, temperature, pressure; and these variables were studied along with methods of analysis for the various possible products of reduction. Details of these studies were reported in Status Reports I through VI on the subject contract and a paper prepared for publication in Proceedings of the Symposium on Space Vehicle Thermal and Atmosphere Control (1963). The overall result of these studies was the establishment of sensitive and accurate methods of analysis and the demonstration of reduction of carbon dioxide to formic acid and of higher concentrations of formic acid to trace amounts of formaldehyde.

This final report is presented to summarize the results reported in the Status Reports, to collate these results and those reported in the literature and to make assessment of the proposed processes and of related but unstudied processes.

II. CONCEPT

Cathodic reduction of reducible compounds is a standard electrochemical process. It was conceived that reduction of carbon dioxide to formic acid, formaldehyde or methanol might be coupled with anodic production of oxygen in an aqueous system as a means of control of atmospheres in confined spaces. If reducibility to equimolar amounts of formaldehyde and methanol could be demonstrated, complete consumption of carbon dioxide and full production of human breathing oxygen would be attainable. This is based on the fact that production of carbon dioxide represents utilization of 82% of the human's oxygen requirement. If oxygen were produced from carbon dioxide mole per mole, then 82% of the oxygen requirement would be produced. This process would be obtained in production of formaldehyde according to the equation:



Production of 123% of the human oxygen requirement would be obtained from production of methanol according to the equation:



The sum of equations 1 and 2 would then be



Thus, cathodic reduction of carbon dioxide to equimolar amounts of formaldehyde and methanol would be an interesting tool for atmosphere control, resulting in production of breathing oxygen and in conversion of carbon dioxide to liquid products with consumption of water, which could be obtained from recycled urine or from condensate of cabin air. An intriguing extension is the use of the formaldehyde and methanol to produce edible materials by synthesis.

III. ANALYTICAL DEVELOPMENTS

An investigation of analytical methods for anticipated products was carried out concurrently with the electrolysis experiments. These anticipated products from the reduction of CO_2 included aqueous solutions containing formaldehyde, formic acid, methanol, methylal and possibly methyl formate; and gaseous products such as methane, carbon dioxide, hydrogen, oxygen and carbon dioxide. As work progressed experiments were conducted with organic solvents and it became necessary to analyse for the electrolysis products in the presence of various organic solvents.

The analytical methods used to monitor the experimental cells were selected in order to fulfill two basic requirements: the need for rapid qualitative tests in order to follow closely the course of the experiments, and quantitative methods for final evaluation.

Gas chromatography was adopted as the most versatile analytical method. A testing program of various column packings was carried out in order to find a system for the analysis of aqueous solutions of the expected organics. A satisfactory column was found that adequately resolved methyl formate, methanol, methylal, water and formaldehyde but was not effective for formic acid. The column also resolved various organic solvents such as dioxane, acetone, ethers and pyridine which allowed analysis of the organic electrolyte systems. Chemical methods for formic acid were found necessary.

Gas chromatography was also used for analysis of the gas phase containing carbon monoxide, methane, hydrogen and oxygen. Carbon dioxide was analyzed, when necessary, on a mass spectrometer.

Analysis of Electrolytes

A sample up to 10 ml was taken from the cathode or anode of the electrolysis cell. A qualitative test for formaldehyde was made using a modified Schiff's Reagent.²³ To 5 ml of sample cooled in an ice bath containing 10-50 ug of formaldehyde, 1 ml of concentrated H_2SO_4 was added. After allowing to cool, 5 ml of Schiff Reagent (Fisher Scientific Co.) was added and the solution removed from the ice bath. A blue color develops after standing, indicating a positive test for formaldehyde. A quantitative result up to 15 ug could be attained by reading the absorption on a photometer at 570 to 590 m μ .

A qualitative test for formic acid was also run on the sample. In the absence of formaldehyde, formic acid was reduced to formaldehyde with magnesium in acid solution and tested for formaldehyde with the Schiff Reagent. To one ml of sample immersed in an ice

bath was added a small coil of magnesium (~ 80 mg). Concentrated H_2SO_4 was added dropwise at the rate of 1 drop per minute until the magnesium was completely reacted. The solution was tested for formaldehyde by adding 1 ml of concentrated H_2SO_4 and 5 ml of the Schiff Reagent. A positive formic acid was indicated by a blue color. If formaldehyde is present in the original sample, it can be removed by adding a small amount of phenylhydrazine hydrochloride before reduction with magnesium. Methanol does not interfere with the method.

After the preliminary qualitative tests for formaldehyde and formic acid, the remaining sample required distillation in order to separate the inorganic salts before injection into the chromatograph. The sample was made acid with H_2SO_4 and distilled. A 2 μl sample was then injected into the chromatograph for the quantitative analysis of formaldehyde, methanol or other volatile organics present.

A Wilkens Instrument and Research, Inc. A-90-P chromatograph was used for the analysis with a 15 ft long 1/4 inch diameter copper column packed with 10% Ethofat 60/25 (Armour Industrial Co.) on 40-60 mesh Columpak-T (Fisher Scientific Co.). The helium carrier gas flowrate was 40 cc/min, column temperature 120°C , sample injection temperature 150°C and a sample size of 2 μl . The column adequately resolved the following compounds: methyl formate, acetone, ethers, methyl alcohol, methallyl, pentanone, pyridine, acetonitrile, water and formaldehyde. Individual calibrations for methanol and formaldehyde were made by injecting known amounts and measuring peak area. A stock solution of formaldehyde was prepared by refluxing para-formaldehyde in water for two hours and filtering. The formaldehyde concentration of this stock solution was determined by the sodium sulfite method.²⁴ Standards were prepared by appropriate dilutions with water. Aqueous formaldehyde and methanol were determined in concentrations as low as 0.1%.

Quantitative analysis of formic acid was performed on the electrolytes at the end of the run by the alkaline oxidation of the formate with standard KMnO_4 . An aliquot of the solution to be analyzed was made acid with H_2SO_4 and distilled into a Na_2CO_3 solution. The distillate was warmed slightly and an excess of N/10 KMnO_4 was added. MnO_2 precipitated as the formate was oxidized. A quantity of 10 ml of dilute H_2SO_4 was added and an excess of N/10 oxalic acid was added until all the precipitate dissolved. The excess oxalic acid was titrated with N/10 permanganate and the formic acid content determined by the KMnO_4 required.

Analysis of Gas Phases

Where applicable, gases were collected in a 200 ml gas buret and transferred to the chromatograph by a gas-tight syringe or passed directly through the instrument's sampling valve.

A Consolidated Electrodynamics Model 26-201 gas chromatograph equipped with a 6 ft long 1/4 inch diameter copper column packed with 13X Molecular Sieves was used for the routine analysis of hydrogen, oxygen, methane and carbon monoxide. Helium flowrate was 80 cc/min at a column temperature of 30°C. Calibrations were made by using known mixtures and measuring the peak height. Methane was detected as low as 50 ppm and CO to 100 ppm using a 1 mv recorder.

A Consolidated Electrodynamics 21-620 mass spectrometer was used for analysis of CO₂ or for confirming analysis where necessary.

Results of Analytical Procedures

Elution times of various compounds of interest are shown in Table 1. These compounds include both possible products and solvents and both liquid and gas phases. The elution times are from columns operated according to the detailed procedures above.

TABLE 1 - ELUTION TIMES OF VARIOUS COMPOUNDS

Liquid Phase		Gas Phase	
<u>Compound</u>	<u>Time (Min)</u>	<u>Compound</u>	<u>Time (Min)</u>
Air	1.6	Hydrogen	0.6
Ether	2.7	Oxygen	1.1
Methyl formate	2.9	Nitrogen	1.8
Methylal	3.3	Methane	3.1
Acetone	3.8	Carbon monoxide	4.7
Methanol	4.6		
Water	5.9		
Acetonitrile	6.2		
Pentanone	8.3		
Dioxane	12.3		
Formaldehyde	14		
Pyridine	20		

IV. ELECTROCHEMICAL STUDIES

As was mentioned in the Introduction above, variables such as current density, electrode material and physical structure, type of diaphragm, catalyst, electrolyte composition, promoters, temperature and pressure influence electrode reactions and products thereof. These variables, therefore, were the subject of experimental study, on reduction of both CO_2 and formic acid. Details are reported in the various Status Reports on the subject contract and are summarized in Table 2. To simplify tabulation in Table 2, runs 73 through 79 are not listed. These runs involved studies of direct reduction of CO_2 and aqueous formic acid with alkali and alkaline earths and their amalgams. Results showed CO_2 to be reduced to formic acid by potassium amalgam and small amounts of formic acid to formaldehyde by lithium, calcium and beryllium but not by amalgams of potassium, lithium, calcium, sodium or magnesium. Similarly, runs 132-135 and 158-179 are not tabulated for reasons of conciseness since they all involved use of organic catholyte solvents and showed either extremely low conductivities with no detectable current at 45 volts or showed no detectable reductions. They included systems with solvents of ether, dioxane, bis-2-dimethoxyethyl ether, acetone, anisole, pentanone, pyridine, acetonitrile, propylene carbonate, both with and without Raney nickel catalyst and both with cation exchange membranes between organic catholyte and aqueous anolyte and without membranes. It was hoped that reduction of CO_2 might be obtained without reduction of the solvent. However, when some reduction products were detected, it was found in blank runs that these products were the result of decomposition of the organic solvents. Systems with poor conductivity are listed in Table 3 and those with no detectable reduction in Table 4. Platinum anodes were used throughout all the tests.

These runs would be interesting to see.

During this investigation the cells used ranged from a simple "beaker" type cell to a one liter autoclave at 50 atmospheres CO_2 . Under these circumstances each cell was set up and operated according to the experimental objective. However, the following general procedure was used for all cells: The electrolytes were made up according to the experimental conditions and placed in the prepared cell. Pressure cells were tested for leaks before electrolysis was started. The current was adjusted to the desired level and the cell was thermostatted as required. Most runs were of long duration therefore it was necessary to adjust the current at regular intervals. Samples were extracted from the cell and analyzed for the products of interest at intervals during the electrolysis.

TABLE 2 - SUMMARY OF ELECTROCHEMICAL TESTS

Run	Type of Cell	Diaphragm	Anolyte	Cathode	Catholyte	Time (hrs)
1	U tube of 2" pipe rubbercoated	1 7/8 x 5" aluminum cup	Sat. Li_2SO_4 sol.	Folded in Zn sheet	Sat. Li_2SO_4 sol.	3 up to 150 lbs
2	"	"	"	"	"	3 up to 300 lbs
3	Glass H cell	Small ceramic cup	Sat. Li_2SO_4 sol.	10" x 5" Zn sheet folded	Sat. Li_2SO_4 10% HCOOH	4
	"	"	"	"	"	16
4	Glass H cell	"	"	Zn rod	"	3
5	"	"	"	"	"	16
6	Concentric	1 3/4" x 6" Norton alundum cup	"	Amalgamated Zn sheet folded	"	6
7	Concentric	"	"	Zn rod	"	6
8	Concentric	"	"	Amalgamated Zn sheet folded	"	7
9	Concentric	New "	Fresh "	New Zn rod	Fresh "	7
10	Continued	"	"	"	"	16
11	Continued	"	"	"	H_2SO_4 added	6
12	Glass H cell	Small alundum cup with double layer cellophane	Sat. Li_2SO_4 sol.	New Zn rod	Sat. Li_2SO_4 10% HCOOH	5
13	Glass H cell	New cup and double layer cellophane	"	Zn sheet folded	"	5
14	Continued	"	"	"	"	16
15	Glass H cell	"	"	New Zn rod	Sat. Li_2SO_4 10% HCOOH	4
16	Continued	"	"	"	"	16 4 2
17	New H cell	1 3/4" x 6" alundum cup	30% LiClO_4 sol.	Folded Zn sheet	30% LiClO_4 10% HCOOH	3 2
18	New H cell	"	15 ml H_2SO_4 added	"	"	6
19	U tube of 2" pipe rubber coated	1 3/4" x 6" alundum cup	Sat. Li_2SO_4 sol.	New folded Zn sheet	Sat. Li_2SO_4 sol.	3 300 lbs
	continued	"	"	"	"	7 300 lbs
20	"	"	30 ml H_2SO_4 added	"	"	6 200 lbs 20 hrs
21	Glass U tube	Conc. H_2SO_4 bottom of U	Sat. Li_2SO_4 sol.	Amalgamated Zn sheet	LiCl Sol. HCOOH added	3
22	Glass H cell	Alundum cup	Li_2SO_4 sol.	New Zn rod	Li_2SO_4 HCOOH	18
23	Glass H cell	Alundum cup	New "	Zn rod from above	New "	20
24	Glass H cell	"	"	"	"	18
25	Glass H cell	"	"	"	"	20
26	Glass U tube	Alundum cup	Li_2SO_4 sol.	New Zn sheet	Li_2SO_4 HCOOH	18
	continued	"	"	"	"	25
27	Large H cell	Large alundum cup	Li_2SO_4 sol.	3 new Zn rods	Li_2SO_4 HCOOH	18
28	Continued	"	"	"	"	7
29	Above cell washed and refilled	"	"	New Zn sheet	"	16

Amps	Cathode Current Density (ma/cm ²)	Volts	Tests	Remarks
2.5 - 3	3.86 - 4.66	14 - 8	Schiffs positive for HCHO, basic. Heavy precipitate.	Later same sample, may test for both HCHO and HCOOH. Cell became quite warm.
"	"	"	Anode gas-O ₂ , no HCHO cathode - 30% CO ₂	Black insulating film on Zn.
0.3	.465	13	Trace HCHO	Grey ppt formed. Conductivity increased.
high		10	No HCHO. Basic, formate present.	Much ppt. Much Zn deposit next leg, corrosion opposite.
0.3	13.3	13	No HCHO	
0.3	"	13	No HCHO	Once an immediate violet which soon faded. Considerable Zn deposit.
3.5 - 4	5.4 - 6.2	5	No HCHO	Cell became warm. Hg-Zn electrode remained shiny.
3 - 4	4.6 - 6.2	5	No HCHO	Zn developed black film. No organics in cathode gas by IR.
1	1.5	3.5	No HCHO	Significant CO ₂ in anode gas by IR.
0.2	8.9	2.5	No HCHO No HCHO	
0.2	8.9	3	No HCHO	Tests showed the formate came through the cellophane readily.
0.2 - 0.3	0.31 - .46	12 - 14	No HCHO	
high			No HCHO, basic	Water level down, cell hot, much grey ppt both sides.
.03	1.3	5	No HCHO	
			Trace HCHO More HCHO Less HCHO	
.3	0.46	5	No HCHO	Trace Cl ₂ from anode by Draeger tubes.
.15	0.23	4	No HCHO	
.2	0.31	4	No HCHO	
.3	0.46	5.5	No HCHO or HCOOH Heavy precipitate.	Over 90% O ₂ from anode as press lowered. Nearly 100 CO ₂ from cathode as press lowered.
.45	0.70	5.7	No HCHO, basic Heavy precipitate.	Precipitate dissolves with acid, evolving gas.
.4	0.62	5	"	Precipitate dissolves. Electrolyte clear green.
.05	0.08	12	AgNO ₃ indicated Cl in anolyte. No HCHO.	Reaction at LiCl - H ₂ SO ₄ interface.
.05	2.2	5	Good HCHO	
.05	"	5.2	Faint HCHO test.	
.05	"	5.2	No HCHO	
.05	"	5.2	Faint HCHO test	Still much HCOOH in catholyte.
.01	0.016	5	Good HCHO test	
			Good HCHO test	
.05	0.75	3.3	Faint HCHO test	
.14	2.1	5	Good HCHO test	
.13	0.2	5	Faint HCHO test	

Run	Type of Cell	Diaphragm	Anolyte	Cathode	Catholyte	Time (hrs)
30	Continued					4
31	Continued	"	"	"	"	20
32	Concentric	Around large alundum cup	"	New Zn sheet	"	18
33	Continued					5
34	Continued					20
35	Glass U tube	Alundum cup	6.5% tetra-butyl-ammonium iodide in 75% dioxane	New Zn rod	Anolyte + HCOOH	40
36	Glass U tube	Alundum cup	Li ₂ SO ₄ sol.	Zn sheet	Li ₂ SO ₄ HCOOH	20
37	Large H cell	Large alundum cup	"	"	"	60
38	Continued	"	"	Blackened section removed	"	20
39	Continued	"	"	"	"	20
40	Glass H cell	Alundum cup	"	Pt sheet	"	20
41	Continued					20
42	Continued			Amalgamated Zn sheet	"	
43	Continued			Zn rod used previously		20
44	New U tube of 35 mm tubing	Parchment	Li ₂ SO ₄ sol.	New Zn sheet	Li ₂ SO ₄ HCOOH	20
45	35 mm U cell	Alundum in cellophane	"	Zn sheet	"	20
46	35 mm U cell	"	Li ₂ SO ₄ sol.	Cd. rod	"	20 20
47	Concentric	Large alundum cup	"	Zn sheet outside cup	"	60
48	Small U tube	Dowex 50W-X8	H ₂ SO ₄ Sol.	Zn sheet	"	30
49	Large H cell	Alundum cup	Li ₂ SO ₄ Sol.	Mg rod 5/8" dia.	Li ₂ SO ₄ HCOOH HCOONa	3
50	Concentric	Large alundum cup	Na ₂ SO ₄ Sol.	Mg rod	"	1
	Continued					2
51	Large H cell	"	"	"	Na ₂ SO ₄ HCOONa H ₂ SO ₄ added	20
	Continued					20
52	35 mm U cell	Alundum in cellophane	Li ₂ SO ₄ Sol.	Zn sheet	Li ₂ SO ₄ HCOOH	20
53	Glass H cell	Alundum cup	Na ₂ SO ₄ Sol.	1/4" lead rod	20% Na ₂ SO ₄ 10% HCOOH	6
54	Glass H cell				Sb ₂ O ₅ added	20
55	Glass H cell				H ₂ SO ₄ added	20
56	Large U cell	Large alundum cup	Na ₂ SO ₄ Sol.	1/4" amalgamated Cu U tube	20% Na ₂ CO ₃ 10% HCOOH	6
57	Large U cell	"	"	"	H ₂ SO ₄ added	20
58	Large H cell	Large alundum cup	Li ₂ SO ₄ Sol.	Hg and dry ice	10% Li ₂ SO ₄	2
59	Large H cell	"	"	Hg	"	20
60	Large H cell	Large alundum cup	10% Li ₂ SO ₄ 5% H ₂ SO ₄	Hg	10% Li ₂ SO ₄ 5% H ₂ SO ₄	2
61	"	"	"	"	"	5

Amps	Cathode Current Density (ma/cm ²)	Volts	Tests	Remarks
.25	0.39	7.5	Fainter HCHO test	
.15	0.23	5	Good HCHO	
.1	0.15	2.6	No HCHO	
1.0	1.5	3.7	No HCHO	
.05	0.08	2.6	No HCHO	
.003	0.13	25	Catholyte lost yellow color.	Gave deep red with Schiff's. Yellow ppt with H ₂ SO ₄ . Free I ₂ on anode.
.005	0.008	5	Good HCHO	
.03	0.047	3	Good HCHO	Only previously used section of Zn sheet was producing gas. It was badly corroded.
.12	0.186	5	No increase in HCHO	
.12	0.186	5	Good HCHO	
.05	1.4	5	No HCHO	To determine if a hydrogenation catalyst instead of the overvoltage was responsible for HCHO formation.
"	"	"	"	" " "
"	0.07	"	"	" " "
"	2.0	"	Trace HCHO	
.05	0.07	3	Very good HCHO	Nothing by gas chromatograph. HCHO appeared to go through parchment.
.1	0.15	4	Some HCHO	Considerable plating of Zn.
.12	1.3	5	No HCHO Trace HCHO	No corrosion or plating of Cd.
.15	0.97	3	No HCHO	Zn not attacked much.
.05	0.07	6	Good HCHO	Connecting leg filled with exchange resin. No HCHO or HCOOH diffused to anolyte.
.5	8.3	10	Good HCHO	From action of acid on Mg.
4.5	75	15		Overheated
1.0	16.7	5	Good HCHO	
.6	10	14	No HCHO	Brown jelly-like ppt - dissolves in acid.
.7	11.7	10	No HCHO	
.1	0.15	5	Good HCHO	Zn chips in U. HCOOH added from anode side. Zn deposit non-adhering.
.5	22.2	20	No HCHO	Cell in ice bath.
"	"	"	"	Catholyte became basic..
"	"	"	Trace	
1 - 3	22.2 - 66.7	24	No HCHO	Ice water through cathode. Cell in ice bath.
1	22.2	20	No HCHO	Most Hg lost from cathode.
1	66	20	Some formate - no HCHO.	Dry ice held under Hg as CO ₂ source.
1	66	20	No HCHO	No CO ₂ added. Attempt to reduce HCOOH from #58.
2.5	165	19	No formate	Dry ice under Hg as CO ₂ source.
1	66	18	No formate or HCHO	Tank CO ₂ bubbled through Hg. In ice bath.

Run	Type of Cell	Diaphragm	Anolyte	Cathode	Catholyte	Time (hrs)
62	"	"	"	"	"	20
63	Small H cell	Alundum cup	K ₂ SO ₄ -H ₂ SO ₄	K-Hg amalgam	K ₂ SO ₄	4
64	35 mm U cell	Alundum cup	HCOOH-H ₂ SO ₄	1/4" dia. x 1 1/2 lead rod	HCOOH 10% H ₂ SO ₄	2
65	"	"	"	"	Ce(SO ₄) ₂ added	2
66	"	"	"	"	"	50
67	"	"	H ₂ O added	Porous Ni	"	20
68	"	"	"	Lead rod	"	40
69	Large H cell	Large alundum cup	MgSO ₄	Hg with Mg rod	MgSO ₄	2
70	"	"	"	"	HCOOH added	1
71	Small H cell	Alundum cup	MgSO ₄	Hg	MgSO ₄	20
72	"	"	"	"	HCOOH added	20
80	2" pyrex pipe	Cation exchange	10% MgSO ₄	Mg 3/4" rod	MgCO ₃ slurry	16
81	"	"	"	"	"	7
82	H cell	Alundum cup	Sat BeSO ₄ + H ₂ SO ₄	Hg	HCOOH added	18
83	35 mm U cell	Alundum cup	10% H ₂ SO ₄	Speer graphite	10% H ₂ SO ₄	4
84	H Cell	Alundum cup	Sat BeSO ₄	Hg	Sat BeSO ₄	15+
85	"	"	"	"	" + HCOOH formed	60
86	U cell	"	H ₂ SO ₄ (10%)	Speer graphite	10% HCOOH + 10% H ₂ SO ₄	20
87	"	"	"	"	"	30
88	"	"	"	"	"	
89	Small H cell	"	Sat BeF ₂	Hg	Sat BeF ₂ + HCOOH	1 1/4
90	"	"	"	"	"	18
91	Concentric cell	Large alundum cup	BeSO ₄	Hg	BeSO ₄ -HCOOH	5
92	"	"	"	"	"	20
93	Concentric cell	"	"	Hg + CO ₂	BeSO ₄	5
94	"	"	"	"	BeSO ₄ + H ₂ SO ₄	15
95	35 mm U cell	Alundum cup	10% NaOH	Speer graphite	10% NaOH	5
96	100 ml beaker	Alundum cup	10% H ₂ SO ₄	Al. foil	90% HCOOH	1
97	Concentric cell	Alundum cup	BeSO ₄	Hg and CO ₂	BeSO ₄	40
98	"	"	"	Hg	BeSO ₄ + HCOOH	3
99	"	"	"	"	"	20
100	"	"	"	"	Added BeSO ₄ and HCOOH	25
101	30 mm U tube	Alundum cup	10% H ₂ SO ₄	Pd. tube + CO ₂	10% H ₂ SO ₄	3
102	"	"	"	"	"	5
103	Steel pressure cell	Alundum cup	10% H ₂ SO ₄ 50 psig O ₂	Micrometallic nickel	10% H ₂ SO ₄ 50 psig CO ₂	2 125°F

Amps	Cathode Current Density (ma/cm ²)	Volts	Tests	Remarks
.5	33	9	No formate or HCHO	CO ₂ in
.8	254	18	Considerable formate	CO ₂ bubbled through amalgam.
.9	125	18	No HCHO	
"	125	"	No HCHO	Ce (SO ₄) ₂ did not appear to dissolve.
.2	27.8	6	No HCHO	Big deposit of soft grey matter on lead.
.2	31.8	6	No HCHO	Developed a grey deposit.
.4	17.8	18	No HCHO	No grey deposit formed.
1.5	99	18	No HCHO	CO ₂ bubbled into Hg. Formed black jelly-like ppt
"	"	"	No HCHO	Black ppt. reacted forming a grey ppt.
.4	128	18	No HCHO	CO ₂ bubbled into Hg.
"	128	"	No HCHO	
0.05	0.034	12	No HCHO, No CH ₄	CO ₂ bubbled through catholyte
0.29	1.99	23	No HCHO, No CH ₄	MgCO ₃ deposit on the cathode
0.05	15.9	10	Slightly + Schiff No MeOH	
1.0	16.7	10	No HCHO, No HCOOH	CO ₂ bubbled through catholyte
0.05	3.3	10	Much HCOOH	CO ₂ bubbled through catholyte
0.05	3.3	10	Slight HCHO	No CO ₂ in
2 to 4	33.3 - 66.7	8	Slight HCHO	Cell held at about 90°C
3	50	6	No additional HCHO	Nothing indicated on gas chromatograph
3	50	6	No HCHO	" "
0.035	11.3	20		
0.05	16.2	26	No HCHO	
1.0	80	8	Good HCHO test	Possible trace MeOH indicated by G.C.
0.2	16	4	Good HCHO test	
0.4	32	10	No HCHO, some HCOOH	
0.7	56	10	No HCHO	Electrolyte ran low
1.1	18.3	12	MeOH) HCHO) Neg HCOOH)	White ppt. formed after 4 hrs
0.6	-	16	HCHO-neg	
0.4	32	10	HCHO neg	
0.9	72	10	Good test HCHO	
0.9	72	10	Better test HCHO	
0.9		10	Not as good HCHO test	No MeOH or HCHO on chromatograph
2.0	200	10	Some HCOOH	Became green from corrosion of the support
2.0	200	9	HCHO neg CH ₄ neg	Iron "whiskers" formed on cathode Brown film on Pt anode
1.5	231	4	HCHO neg	Produced internal explosions Electrolyte green from corrosion

Run	Type of Cell	Diaphragm	Anolyte	Cathode	Catholyte	Time (hrs)
104	2" glass pipe	Alundum cup	Sat BeSO_4 30 psig O_2	Hg	Sat BeSO_4 30 psig CO_2	3 75°F
105	"		40 psig O_2		40 psig CO_2	2 150°F
106	"		"	"	"	4 210°F
107	Small U cell	Alundum cup	BeSO_4	Lead rod	BeSO_4 -HCOOH	60
108	Small H cell	Alundum cup	BeSO_4	Hg- CO_2	BeSO_4	7
109	"					20
110	Large H cell	Alundum cup	Sat BeSO_4 10% Li_2SO_4	Hg- CO_2	BeSO_4 - Li_2SO_4	7
	Continued					80
111	Large H cell	"	"	Raney Ni added	"	34
112	2" glass pipe	Alundum cup	" 40 psig O_2	Hg	" 40 psig CO_2	20
113	"	"	Sat BeSO_4 40 psig O_2	Hg + Raney Ni	BeSO_4 40 psig CO_2	15
114	Small H cell	Small alundum cup	Sat Li_2SO_4	Hg + Raney Ni	Li_2SO_4 + CO_2	20
115	"	"	10% H_2SO_4	"	10% H_2SO_4 + CO_2	20
116	"	"	"	"	"	6
117	2" glass pipe	Alundum cup	Sat BeSO_4 40 psig CO_2	Hg + Raney Ni	BeSO_4 40 psig CO_2	6
118	"	"	"	"	"	6
119	"	"	"	"	"	9
120	30 mm U tube	"	Sat Li_2SO_4	Speer carbon + Raney Ni	Li_2SO_4 + CO_2	8
121	"	"	"	"	Li_2SO_4 + H_2SO_4 + CO_2	8
122	Large U cell	Alundum cup	Sat MgSO_4	Lead rod	Sat MgSO_4 and 5% HCOOH	24
123	Beaker	Alundum cup	Sat Li_2SO_4	Hg	20% mono- ethanol amine " " + CO_2 gas	1/4 2
124	Beaker	Alundum cup	Sat BeSO_4	Hg	Sat BeSO_4 + CO_2	12
125	"	"	"	"	"	5
	"	"	"	"	"	27
					" + HCOOH	15
126	Concentric pressure cell	Alundum cup	Sat BeSO_4	Hg + Raney Ni	Sat BeSO_4 40 psig CO_2	9
127	2" glass pipe	Alundum cup	Sat BeSO_4 + 40 psig O_2	Hg Raney Ni	Sat BeSO_4 40 psig CO_2	9
128	2" glass pipe	Alundum cup	"	Cd rod Raney Ni	"	18 1/2
129	"	"	"	"	"	16
130	2" glass pipe	Cation exchange membrane	10% H_2SO_4	Hg	10% LiCl + CO_2 in MeOH	30
131	2" glass pipe	2 cation exchange 1 parchment 1 paper cup	10% H_2SO_4	Hg	MgSO_4 -MeOH + CO_2	30

Amps	Cathode Current Density (ma/cm ²)	Volts	Tests	Remarks
0.5	15.6	20	HCHO neg	No test made for HCOOH
0.85	26.6	20	CH ₄ neg	O ₂ in cathode gas.
0.95	29.7	20	HCHO neg	1.4% CO ₂ in anode gas
0.05	2.2	12	HCHO pos	
0.07	22.6	18	HCHO neg	No test made for HCOOH
0.09	29	18	Trace HCHO	No test made for HCOOH
0.45	29.6	18	HCHO neg-HCOOH trace	
0.70	46	18	HCHO neg	HCOOH very slight trace. CH ₄ and CH ₃ OH neg.
0.70	46	18	HCHO neg	
0.5	15.6	18	HCHO neg	2.4% CO ₂ in anode. CH ₄ neg
0.5	15.6	18	HCHO neg	CH ₃ OH neg. 0.02% CO or CH ₄ in cathode gas
0.05	16.1	20		Plugged-blewout electrolyte
0.1	32.2	6	HCHO neg	
0.5	161	8	HCHO neg	
0.5	15.6	18	HCHO neg	
1.5	46.8	41	HCHO neg CH ₄ neg	
2.0	62.4	42	HCHO neg MeOH neg CH ₄ neg	
1.5	25	20	HCHO neg	
1.5	25	20	HCHO neg MeOH neg CH ₄ neg	
1.0	44.5	14	HCHO neg CH ₄ neg	
0.02	0.74	18		
2.0	74	18	HCHO neg	Preliminary test for conductance, etc.
2.0	74	10	HCHO neg	
4.0	148	18	HCHO neg	Pulsating D.C. 10 sec. on, 5 sec. off
2.0	74	10	HCHO, HCOOH, MeOH, CH ₄ neg	
0.5	18.5		HCHO pos	
1-2	80 - 160	42	HCHO, HCOOH, MeOH, CH ₄ neg	Catholyte in center of cell in porous cup heated up
2	62.4	42	HCHO, HCOOH, MeOH, CH ₄ neg	Cell thermostatted at 105°C
2	0.89	41	HCHO, HCOOH, MeOH, CH ₄ neg	
2	62.5	41	HCHO, HCOOH, MeOH, CH ₄ neg	Cell thermostatted at 105°C
0.5	15.6	8	Catholyte-HCHO Pos HCOOH Pos Anolyte-Cl ₂ , Cl HCHO Pos, MeOH 2.3%	HCHO possibly came from anodic oxidation of CH ₃ OH
0.03	0.94	25	Catholyte-HCHO Pos, Anode- HCHO Pos, MeOH 5%	" "

Run	Type of Cell	Diaphragm	Anolyte	Cathode	Catholyte	Time (hrs)
136	Beaker	Alundum cup	Sat Na_2SO_4	Hg	Sat Na_2SO_4 + CO_2	36
137	Beaker	None	Sat K_2SO_4	Hg	Sat K_2SO_4	34
138	Beaker	None	Sat K_2CO_3	Hg	Sat K_2CO_3	24
139	Beaker	Alundum cup	Li_2SO_4	Hg + Hg black	Li_2SO_4 + CO_2	48
140	"	"	"	"	"	20
141	Beaker	Alundum cup	0.1 N KOH	Lead rod	0.1 N KOH	73
142	"	"	Sat BeSO_4	Pb stick	Sat BeSO_4 + CO_2	41
143	Beaker	Alundum cup	BeSO_4 + H_2SO_4	Pb stick	BeSO_4 + H_2SO_4 + CO_2	48
144	"	"	Sat BeSO_4	Pb stick	Sat BeSO_4 + CO_2	36
145	"	"	BeSO_4 + H_2SO_4	Pb stick	BeSO_4 + H_2SO_4 + CO_2	30
146	Beaker	Alundum cup	Sat BeSO_4	Zn stick	Sat BeSO_4 + CO_2	41
147	"	"	BeSO_4 + H_2SO_4	Zn stick	BeSO_4 + H_2SO_4 + CO_2	48
148	"	"	Sat BeSO_4	Zn stick	Sat BeSO_4 + CO_2	36
149	"	"	BeSO_4 + H_2SO_4	Zn stick	BeSO_4 + H_2SO_4 + CO_2	30
150	Beaker	Alundum cup	Sat BeSO_4	Sn stick	Sat BeSO_4 + CO_2	41
151	"	"	BeSO_4 + H_2SO_4	Sn stick	BeSO_4 + H_2SO_4 + CO_2	48
152	"	"	Sat BeSO_4	Sn stick	Sat BeSO_4 + CO_2	36
153	Beaker	Alundum cup	BeSO_4 + H_2SO_4	Sn stick	BeSO_4 + H_2SO_4 + CO_2	30
154	Beaker	Alundum cup	Sat BeSO_4	Cd stick	Sat BeSO_4 + CO_2	41
155	Beaker	Alundum cup	BeSO_4 + H_2SO_4	Cd stick	BeSO_4 + H_2SO_4 + CO_2	48
156	Beaker	Alundum cup	Sat BeSO_4	Cd stick	Sat BeSO_4 + CO_2	36
157	Beaker	Alundum cup	BeSO_4 + H_2SO_4	Cd stick	BeSO_4 + H_2SO_4 + CO_2	30

Amps	Cathode Current Density (ma/cm ²)	Volts	Tests	Remarks
1	141	4	HCHO, MeOH neg HCOOH pos	CO ₂ bubbled through dry section of cathode.
1.5	212	5	HCHO, HCOOH neg	CO ₂ flow through dry section of Hg cathode
2	282	7	HCHO, HCOOH neg	" "
2	74	9	HCHO, HCOOH, MeOH Neg	
0.5	18.5	3	HCHO, HCOOH, MeOH Neg	
0.002	0.089	3	HCHO, HCOOH, MeOH Neg	Controlled potential electrolysis
0.6	41.4	5.2	HCHO, HCOOH Neg	Pb cathode cast in mold at 25°C
1.6	111	6.2	HCHO, HCOOH Neg	Pb cathode cast in mold at 25°C
1.5	103	8.8	HCHO, HCOOH Neg	Pb cathode cast in mold at 275°C
1.0	69	5.0	HCHO, HCOOH Neg	" "
1.3	90	5.2	HCHO, HCOOH Neg	Zn cathode cast in mold at 25°C
0.45	31	6.2	HCHO, HCOOH Neg	" "
0.15	10.3	8.8	HCHO, HCOOH Neg	Zn cathode cast in mold at 370°C
1.5	103	5.0	HCHO, HCOOH Neg	" "
0.44	30.3	5.2	HCHO, HCOOH Neg	Sn cathode cast in mold at 25°C
0.55	38	6.2	HCHO, HCOOH Neg	" "
0.35	21.2	8.8	HCHO, HCOOH Neg	Sn cathode cast in mold at 180°C
0.55	38	5.0	HCHO, HCOOH Neg	" "
1.0	69	5.4	HCHO, HCOOH Neg	Cd cathode cast in mold at 25°C
1.15	79	6.2	HCHO, HCOOH Neg	" "
0.95	64.5	8.8	HCHO, HCOOH Neg	Cd cathode cast in mold at 280°C
1.45	100	5.0	HCHO, HCOOH Neg	" "

Run	Type of Cell	Anolyte	Diaphragm	Cathode	Catholyte	Time* (hrs)	Amps.	Cathode Current Density (ma/cm)
180	Battery Jar	Na ₂ SO ₄	Porous battery cup	Mercury	Na ₂ SO ₄ CO ₂ flow through dry cathode	3 5-1/2 15	4.0 4.0 4.0	125 125 125
181	Glass "H" Cell	BeSO ₄	Alundum cup	Mercury	BeSO ₄ solution	11 47 52	1 0.1 1.2	31.3 3.1 37.5
182	Battery Jar	Li ₂ SO ₄	Porous battery cup	Mercury	Li ₂ SO ₄ CO ₂ flow through dry cathode section	16 23	0.1p 0.1p	14 14
183	Small H-Cell	5% H ₂ SO ₄ Sat. K ₂ SO ₄	Alundum cup	K amalgam CO ₂ bubbled through wet K-Hg	K ₂ SO ₄	4-1/2 21 28 49 51 63	0.8 0.5 0.8 0.8 1.5 0.5	257 161 257 257 485 161
184	Large H-Cell	5% H ₂ SO ₄ Sat. K ₂ SO ₄	Alundum cup	Mercury CO ₂ bubbled through Hg	K ₂ SO ₄	7 23-1/2	0.8 0.5	52.5 33
185	Steel pressure 50 atms CO ₂	Sat. K ₂ SO ₄	None	Mercury	Sat. K ₂ SO ₄	4 7-1/2	1.0 1.0	114 114
186	Steel pressure 50 atms CO ₂	1% H ₂ SO ₄ K ₂ SO ₄	None	Mercury	1% H ₂ SO ₄ K ₂ SO ₄	3	0.5	57
187	Steel pressure 50 atms CO ₂	Sat. K ₂ SO ₄	None	Mercury	Sat. K ₂ SO ₄	6	0.4	46
188	2" Glass pipe	Sat. K ₂ SO ₄	Ion exchange membrane (I)	K-Hg CO ₂ bubbled through K-Hg	Sat. K ₂ SO ₄	4-3/4 19-1/4 27-1/4 49-1/2	0.5 1.7 1.7 1.7	15.6 53 53 53
189	2" Glass Pipe	Sat. K ₂ SO ₄	Ion exchange membrane (I)	K-Hg CO ₂ bubbled through K-Hg	5% HCOOH K ₂ SO ₄	2 15	1.7 4.5	53 140
190	Small H-cell	Sat. Li ₂ SO ₄	Alundum cup	Mercury CO ₂ bubbled through Hg	Sat. Li ₂ SO ₄ + H ₂ SO ₄	2 5 29 109	0.2 0.15 0.2 0.2	64.5 48.5 64.5 64.5
191	Large H-cell	5% H ₂ SO ₄ Sat. Li ₂ SO ₄	Alundum cup	Mercury CO ₂ bubbled through Hg	Sat. Li ₂ SO ₄	2 11 24 105	2 1 1 1	132 66 66 66
192	Autoclave 50 atms CO ₂	Sat. K ₂ SO ₄	Alundum cup	Mercury CO ₂ 50 atms	Sat. K ₂ SO ₄	8	1 1/2	72.8 36.4
192A	Autoclave 50 atms CO ₂	Sat. K ₂ SO ₄	Mercury	Mercury CO ₂ 50 atms	Sat. K ₂ SO ₄	3-1/2 10-1/2 17-1/2 23 28	1.2 2.5 2.5 2.2 2.2	87 182 182 159 159
193	Autoclave 50 atms CO ₂	Sat. K ₂ SO ₄	Alundum cup	Amalgamated zinc	Sat. K ₂ SO ₄	15	0.1-1.0	0.43-4.3
194	Nickel beaker	Sat. Na ₂ SO ₄	Alundum cup	Carbon rod	Sat. Na ₂ SO ₄	4-1/2	10	266
195	Beaker	Sat. Na ₂ SO ₄	Alundum cup	Carbon rod	Sat. Na ₂ SO ₄	4	5-10	133-266

Volts	Temperature	Tests		Remarks
		Gas Phase Products	Catholyte Organic Product	
7	Ambient	Cathode CH ₄ neg, CO neg	Negative	Dry section of cathode flushed into catholyte before each sample.
7	Ambient		Negative	
7	Ambient		Negative	
32	30	Cathode CH ₄ neg, CO neg	Negative	Recycle mixing of CO ₂ at the cathode. Cumulative gas samples.
9	30		Negative	
45	30		Negative	
3.6	Ambient	Cathode CH ₄ neg, CO neg	Negative	Gas collected in dry section of cathode and flushed into catholyte before samples.
3.6	Ambient	Cathode CH ₄ neg, CO neg	Negative	
35	Water cooled		HCHO neg, MeOH neg, HCOOH pos.	
28	Water cooled		HCHO weak pos, MeOH neg, HCOOH pos.	
35	Water cooled		HCHO weak pos, MeOH neg, HCOOH pos.	
35	Water cooled		HCHO pos, MeOH neg, HCOOH pos.	
	Cathode 70°C		HCHO weak pos, MeOH neg, HCOOH pos.	
25	Water cooled		HCHO pos, MeOH neg, HCOOH pos.	
29	Water cooled		HCHO neg, MeOH neg, HCOOH pos.	
	Water		HCHO neg, MeOH neg, HCOOH pos.	
18	Water cooled	Cathode CH ₄ neg, CO neg	HCHO weak pos, MeOH neg, HCOOH weak pos.	
18	Water cooled	Cathode CH ₄ neg, CO neg	HCHO weak pos, MeOH neg, HCOOH weak pos.	
18	Water cooled	Cathode CH ₄ neg, CO neg	HCHO neg, MeOH neg, HCOOH pos.	Electrode blowout
21.5	Ice bath	Cathode CH ₄ neg, CO neg	HCHO weak pos, MeOH neg, HCOOH weak pos.	
13	Water cooled		HCHO neg, MeOH neg, HCOOH pos.	After 49-1/2 hrs anolyte showed weak positive test for HCOOH.
13			HCHO neg, MeOH neg, HCOOH pos.	
13			HCHO neg, MeOH neg, HCOOH pos.	
13			HCHO neg, MeOH neg, HCOOH pos.	
19			HCHO neg	Electrolyte pushed into cathode section overnight.
19				
19	Water cooled		Negative	10 cc 10% H ₂ SO ₄ added to catholyte after 5 hrs.
19			HCHO neg, MeOH neg, HCOOH weak pos.	
19			HCHO neg, HCOOH pos.	
19			HCHO neg, MeOH neg, HCOOH pos.	
24	Water cooled		Negative	
24				
24			HCHO neg, MeOH neg, HCOOH pos.	
			HCHO neg, MeOH neg, HCOOH neg	
5.2	Water cooled	CH ₄ and CO neg.	HCHO neg, MeOH neg, HCOOH weak pos.	Cathode contact wire pushed out of lig by pressure sometime after 5 hrs.
4.5	Water cooled	CH ₄ and CO neg.	HCHO neg, MeOH neg, HCOOH weak pos.	
5.5		CH ₄ and CO neg.	HCHO neg, MeOH neg, HCOOH weak pos.	
5.5		0.04% CO		
5.7		0.04% CO		
6.0		0.04% CO		
	Water cooled		HCHO neg, MeOH neg, HCOOH pos.	
			HCHO neg, MeOH neg, HCOOH pos.	Cathode broke off. 0.1 amp on overnight to counter galvanic effect. Next morning cell was warm and 1 amp current.
6.5	Oil cooled	0.04% CO	HCHO neg, MeOH neg, HCOOH neg.	Cathode gas collected in gas buret.
6-7	Oil cooled	0.07% CO	HCHO neg, MeOH neg, HCOOH neg.	Cathode gas collected in gas buret.

Run	Type of Cell	Anolyte	Diaphragm	Cathode	Catholyte	Time (hrs)	Amps	Cathode Current Density (ma/cm)
196	Beaker	Sat. K ₂ SO ₄	Alundum cup	1 in. diameter carbon impregnated with Hg	Sat. K ₂ SO ₄	7 11-1/2	1 1	26.6 26.6
197	2" Glass pipe	Sat. K ₂ SO ₄	Ion exchange membrane (N) heavy	Hg	Sat. K ₂ SO ₄	3 16 28	1.0 .35 .35	31.2 10.9 10.9
198	Battery jar	Sat. K ₂ SO ₄	Alundum cup	Cd Fe mix 3 x 6" plate	Sat. K ₂ SO ₄	5 26-1/2 46-1/2	1.4 1.4 1.4	6.3 6.3 6.3
199	Large H-cell	Sat. K ₂ SO ₄	Alundum cup	Cd powder on Ag grid	Sat. K ₂ SO ₄	7-1/2	0.8	61.8
200	Battery jar	Sat. K ₂ SO ₄	Alundum cup	Cd Fe mix 3 x 6" plate amalgamated	Sat. K ₂ SO ₄	32	1.5	6.75
201	Large H-cell	Sat. K ₂ SO ₄	Alundum cup	Cd powder on Ag grid amalgamation	Sat. K ₂ SO ₄	32	0.5	38.5
202	Autoclave 50 atms CO ₂	Sat. K ₂ SO ₄	Alundum cup	Amalgamated Zn	Sat. K ₂ SO ₄	2-1/2 17-1/2 24	1.5 0.1 1	6.45 0.43 4.3
203	Autoclave 50 atms CO ₂	Sat. K ₂ SO ₄	Alundum cup	Amalgamated Cu	Sat. K ₂ SO ₄	3 6 14	1 1 1	4.3 4.3 4.3
204	Beaker	Sat. K ₂ SO ₄	Alundum cup	Hg	Sat. K ₂ SO ₄	92	25	2000
205	2" Glass pipe	Sat. K ₂ SO ₄	Alundum cup	Hg	Sat. K ₂ SO ₄ 20 gm Ce(SO ₄) ₂ · 10 H ₂ O per liter	100	1	31.2
206	2" Glass pipe	Sat. K ₂ SO ₄	Alundum cup	Hg	Sat. K ₂ SO ₄ 10 gm cobaltic acetate per liter	100	1	31.2

* Cumulative time

I Ionac MC 3142 cation exchange membrane

p Pulsating current, 10 seconds on, 5 seconds off

N Nepton CR-61 cation exchange membrane

<u>Volts</u>	<u>Temperature</u>	<u>Tests</u>		<u>Remarks</u>
		<u>Gas Phase Products</u>	<u>Catholyte Organic Product</u>	
3.4	Ambient	Cathode CH ₄ & CO neg.	HCHO neg, MeOH neg, HCOOH neg.	
3.5	Ambient	Cathode CH ₄ & CO neg.	HCHO neg, MeOH neg, HCOOH neg.	
15	Oil cooled		Negative	Osmosed into catholyte (about 1/2 of anolyte)
6			Negative	
6			Negative	
6.2	Water Cooled		Negative	
6.2			Negative	
6.2			Negative	
13	Oil cooled		Negative	
6.2	Water cooled		Negative	
<hr/>				
7.0	Oil cooled		Negative	
4.6	Water cooled		Negative	
3.1		0.07% CO		
4.1		0.02% CO	Negative	
4.1	Water cooled	0.04% CO		HCOOH pos. anolyte and catholyte
4.1		0.03% CO		
4.1		Trace CO		
5.3	Water cooled		HCHO neg, HCOOH pos.	
14.8	Water cooled		HCHO neg, HCOOH weak pos.	
12.0	Water cooled		HCHO neg, HCOOH weak pos.	

TABLE 3 - CATHOLYTE SOLUTIONS WITH EXTREMELY POOR CONDUCTIVITY
AT 45-48 VOLTS

Concentrations ? & values.

<u>Ether Solvent</u>	<u>Bis-2-dimethoxyethyl Ether Solvent</u>	<u>Anisole Solvent</u>
Li ₂ SO ₄	Li ₂ SO ₄	LiCl
K ₂ SO ₄	LiCl	Li ₂ SO ₄
LiCl	NaNO ₃	NaCl
BeSO ₄	Na ₂ CO ₃	Na ₂ SO ₄
	BeCl ₂	MgSO ₄
	K ₂ CO ₃	
	MgSO ₄	

TABLE 4 - ORGANIC SYSTEMS WITH CONDUCTIVITY
BUT NO SIGNIFICANT REDUCTIONS

Concentrations - values.

LiCl in acetone
LiCl in pentanone
LiCl in pyridine (with and without Raney nickel catalyst)
LiCl in acetonitrile (with and without Raney nickel catalyst)
LiCl in propylene carbonate

The source of direct current used in these experiments was rectified alternating current up to 110 volts. The higher voltages were used for the non-aqueous systems. Several experiments were performed with pulsating d.c. 10 seconds on and five seconds off. A proportional timer in series with a relay provided a reliable automatic pulsating current.

a. Cathode Material and Structure

Table 5 lists the various materials used as cathodes in exploratory studies. Emphasis was placed on materials with high hydrogen overvoltages; but a few other materials were tried for

TABLE 5 - MATERIALS SCREENED AS POSSIBLE CATHODES

<u>High Overvoltages</u>	<u>Large Surface Areas</u>	<u>Reducing Agents</u>
Pb, Cd, Hg, Zn, Zn-Hg, Cu-Hg, Sn, Mg, Pb	C, porous Ni	K-Hg, Mg
	<u>Other</u>	
	Pd, Al	

reasons of having large surface areas, of being permeable to hydrogen or of being reducing agents. Hydrogen overvoltages are related to position of the cathode metal in the Periodic Table²² as is shown in Table 6. It is seen that Group II metals have high typical overvoltages; and thus, cadmium, mercury and its amalgams, zinc and magnesium were chosen for high hydrogen overvoltages; carbon and porous nickel for high surface areas; palladium for its permeability to hydrogen and catalytic properties; and platinum also for its catalytic properties. Lead has an anomalously high overvoltage at high current densities considering its position in the Periodic Table and was thus tested also.

TABLE 6 - HYDROGEN OVERVOLTAGE OF METALS AND THEIR
POSITION IN THE PERIODIC TABLE

<u>Group in the Periodic Table</u>	<u>Metal</u>	<u>Typical Overvoltage</u>
I	Na, Cu, Ag, Au	0.35 volt
II	Mg, Zn, Cd, Hg	0.70 volt
III	Al, Tl	0.50 volt
IV	C, Sn, Pb	0.45 volt
V	Sb, Ta, Bi	0.42 volt
VI	Cr, Mo, W	0.32 volt
VII	Mn	0.25 volt
VIII	Fe, Ni, Rh, Pt, Ir	0.18 volt


Since physical condition of the cathode often influences its reducing ability and since casting temperature can influence the physical state of metals, tests were made on the effect of casting temperature upon cathode performance. Table 7 shows materials and temperatures used in the tests.

TABLE 7 - CASTING TEMPERATURES OF VARIOUS CATHODE MATERIALS

Material	Pb	Zn	Sn	Cd
Casting Temp. (°C)	25, 275	25, 370	25, 180	25, 280

Because of the varied experiments and type cells studied it was not feasible to use a standard electrode area and shape. The cathodes were generally used in the form obtained such as solid round or rectangular bars, sheets, screen or liquid mercury and amalgams. The cathode shapes and dimensions were dictated by the type of cell. Simple glass cells such as the "H" or "beaker" type required only that the cathode material extended above the electrolyte so that the connecting wires would be clear of the electrolyte. Special electrodes were required for the high pressure cells. The solid electrodes were attached to a stainless steel rod which served as the connecting lead through an insulated Conax electrode gland. Cathodes in sheets form such as lead, zinc and copper were placed by the same method. The cathode material was attached to the 1/8 in. stainless steel rod above the electrolyte level. The section of the stainless steel rod that was exposed inside the cell was wrapped with Teflon tape in order to protect against corrosion products contaminating the electrolyte. Mercury cathodes were usually placed inside small glass or plastic cups in the cathode area of the cell. Contact was made by platinum wire sealed in a glass tube. For pressure cells this type of contact was soldered to a 1/8 in. rod which served as the connecting lead through a Conax electrode gland.

Under conditions of the tests, reduction of CO₂ was obtained only with mercury or certain amalgams (K-Hg and Zn-Hg) as cathodes and to a limited extent with palladium. The tests were carried out in different manners, depending upon the nature of the cathode. In the case of a liquid cathode, CO₂ was bubbled through the liquid metal and into the catholyte during electrolyte or through the liquid metal and into the air (Fig 1). In the case of exhausting



R-1477

FIG 1 - DRY AMALGAM CELL

to the air, the reduction products were exposed to hydrolysis action from time to time to repeat the conditions of Miller et al¹², who exposed the reaction products to hydrolysis by the action of $3\text{NH}_2\text{SO}_4$. Alternately, an attempt was made to hydrolyze reaction products on a closed cycle basis. This was accomplished by shutting off the vent and forcing the dry liquid amalgam under CO_2 pressure into the electrolyte solution. In the case of porous materials, the gas was forced out of the pores and into the electrolyte; and in case of solid cathodes contact was only by dissolved CO_2 , at times under pressure. Coulombic efficiencies of as high as about 20% were measured with a mercury cathode and about 12% with amalgamated copper using K_2SO_4 electrolytes.

b. Diaphragms

Diaphragms can serve to prevent transfer of oxidizable cathode products to the anode compartment where they might be oxidized or to prevent mixing of anolyte and catholyte. In the latter case, ion-exchange membranes were considered useful, especially where it was desirable to keep aqueous anolytes from contaminating anhydrous organic catholytes. Cation exchange membranes thus would permit transport of current by means of transfer of hydrogen ions from anolyte to catholyte. Table 8 lists the types of diaphragms used.

TABLE 8 - TYPES OF DIAPHRAGMS USED

Porous alundum	Parchment
Porous alundum plus cellophane	Nepton CR-61 Cation-exchange membrane
Cellophane	Ionac MC-3142 Cation-exchange membrane

No effects of use of membranes in reduction of CO_2 were shown, possibly because of the low concentrations of formic acid produced. In the case of starting with high concentrations of formic acid in the catholyte to determine its reducibility, electrical endosmosis of anolyte into catholyte occurred, through the cation exchange membranes, interfering with cell operation. Furthermore, it was found that the ion-exchange membranes had a finite permeability to water, water content of the catholyte did build up to as high as 20%.

c. Catalysts and Promoters

Exploratory tests on use of potential reduction promoters and catalysts failed to show promise. These materials were either suspended in the catholyte or dissolved therein, depending on whether they were insoluble or soluble. A list of materials tested is given in Table 9.

TABLE 9 - MATERIALS TESTED FOR PROMOTER AND CATALYST ACTIVITY

Raney Nickel	$\text{Ce}(\text{SO}_4)_2$	$\text{Co}(\text{CH}_3\text{COO})_2 \cdot 4\text{H}_2\text{O}$
Mercury Black	Sb_2O_5	

d. Catholytes

As will be pointed out in Collation with the Literature below, strongly acid electrolytes and electrolytes of the sulfates of potassium, sodium and lithium have been reported as promoting reductions. Such solutions were tested in studies of electrolyte composition. Similar salts were also tested, especially those with high decomposition potentials. These included the sulfates of beryllium and magnesium.

In efforts to increase the discharge potential of the electrolyte by reducing hydrogen ion concentration in the catholyte, organic catholyte solvents were tested in combination with cation exchange membranes and aqueous anolytes to provide anodic oxygen. The organic catholytes were prepared by placing the catholyte salt to be used in a 500 ml flask and adding the organic solvent. The mixture was stirred several hours to insure saturation. The prepared catholyte was then transferred to the cathode compartment of the cell along with some solid electrolyte to insure maximum saturation. The cell arrangement for this is shown in Fig 2. The literature shows deposition of beryllium from ethereal solutions and of lithium from acetone^{10,16} and pyridine¹³ and these systems were tested along with other similar ones as indicated in Table 10, which also shows the complete list of catholyte systems tested. The cell incorporates pressure balance controls to prevent mixing of cathode and anode gases and to prevent pressure unbalances that might rupture the membrane. Control involves use of two




FIG 2 - GLASS PIPE PRESSURE CELL

TABLE 10 - CATHOLYTE SYSTEMS TESTED

<u>Aqueous</u>	<u>Non-Aqueous</u>
Li_2SO_4	monoethanol amine
$\text{Li}_2\text{SO}_4 + \text{H}_2\text{SO}_4$	MgSO_4 in methanol
Na_2SO_4	BeSO_4 in dioxane
$\text{Na}_2\text{SO}_4 + \text{H}_2\text{SO}_4$	K_2SO_4 in dioxane
K_2SO_4	Li_2SO_4 in dioxane
$\text{K}_2\text{SO}_4 + \text{H}_2\text{SO}_4$	Li_2SO_4 , K_2SO_4 , LiCl , BeSO_4 , MgSO_4 in diethyl ether
MgSO_4	Li_2SO_4 , LiCl , NaNO_3 , Na_2CO_3 , BeCl_2 , K_2CO_3 in bis-2-dimeth- oxyethyl ether
BeSO_4	
H_2SO_4	LiCl in acetone, pentanone, pyridine, acetonitrile, propylene carbonate
KOH	
BeF_2	LiCl , Li_2SO_4 , NaCl , Na_2SO_4 , MgSO_4 in anisole

differential switches and two solenoid valves. One switch, operating through a relay, controlled venting of the cathode and anode gases according to a set reference pressure. The other switch controlled the cathode vent according to the pressure differential between the anode and cathode. In this way the cathode, which evolves hydrogen at twice the rate of oxygen at the anode, would vent and maintain equal pressures. Excessive increase of cell pressure over reference pressure is relieved through the other switch on the anode. Relief of cathode pressure would occur simultaneously by operation of the first switch.


The organic systems, with the exception of that with methanol as solvent, all had high resistivity so that any reduction if any would be accomplished with low energy efficiency; and none excepting possibly methanol gave indications of reduction. With use of mercury cathodes, the following aqueous catholytes gave reduction of CO_2 to formic acid: Li_2SO_4 , K_2SO_4 , Na_2SO_4 and BeSO_4 . These same systems gave reduction of some formic acid to small amounts of formaldehyde when high concentrations of formic acid were built up prior to electrolysis. Any electrochemical reactivity in methanol may have been that of the anodic oxidation of methanol rather than cathodic reduction of CO_2 . This is because while membranes were used to inhibit transfer of methanol to the anolyte, this inhibition was not very effective and methanol was detected in the anolyte at the end of the runs.

e. Pressure

Several types of pressure tests were run up to 50 psig. One of them was in a glass cell made by joining two standard flanged glass pipe ells with a 4 in. flanged nipple on each side. (Fig 2) Closure was accomplished by flanging special plates to the tops of the two legs of the cell. Provision was made to permit sampling both anode and cathode compartments, which were separated by use of membranes at the connecting flange.

Another type of pressure run at 50 psig was made in a 4 in. glass pipe cup having a concentric cathode compartment and platinum-rhodium unimesh anode. The cathode was a pool of mercury in a container at the bottom of an alundum cup (Fig 3).

In order to develop higher pressures of CO_2 for reduction, two other types of cell were used. One consisted of a steel pipe lined with a polyethylene cup having a mercury cathode of 8.8 cm^2 area at the bottom. Cathode connection was made with a Teflon-insulated platinum-tipped wire fitted through a Conax electrode gland. Pressures up to 50 atmospheres were developed in these tests.



R-1386

FIG 3 - CONCENTRIC PRESSURE CELL

Another type of high pressure run was made in a one liter autoclave equipped with a stirrer to provide agitation of the electrolyte during electrolysis. The gas phases from the anode and cathode were mixed in the autoclave; and analysis did not distinguish between the two product streams.

No beneficial effects of increased pressure were observed in any of the runs.

f. Temperature

It was necessary to provide some means of temperature control for the cells during extended tests in order to minimize localized heating at the electrode areas. The cells were placed in cooling baths of running tap water that maintained temperatures of 25-30°C. Cooling for low temperature tests was done by placing the cell in an ice bath. Cold mercury cathodes were obtained in several tests by submerging dry ice in the mercury cathode. This served a dual purpose in that the dry ice supplied the CO₂ at the cathode. Thermostatted oil baths were used for uniform elevated temperature operation.

Runs 53, 56, 58, 60, 61 and 169 were made with the cells held at lowered temperature and runs 86, 103-106, 117-119 and 127-129 at elevated temperatures to see if significant improvement in reduction might be thereby obtained. No such improvement was observed.

g. Summary on Reduction of Formic Acid

Since formic acid is an intermediate in the reduction of carbon dioxide to formaldehyde, some runs were made to determine reducibility of formic acid to formaldehyde directly. Success was attained in runs 1, 3, 16, 22, 25-31, 36-39, 44-45, 48-50, 52, 85-86, 91-92, 99-100, 107, 109, 125 and 130-131. There is some evidence that in the earlier runs (1-52) reduction was chemical since the zinc and magnesium cathodes showed signs of corrosion in areas remote from the anodes and since zinc metal was seen to be redeposited in areas near the anode. Furthermore, the reductions were obtained only at low current densities, at which only poor cathodic protection against corrosion is obtained.

All other strongly positive tests were obtained with mercury cathodes and BeSO₄ catholytes. No exceptions were found on reducibility of formic acid with this system, which may be based on the fact that the very active beryllium metal does not amalgamate with mercury.²⁵

h. Summary on Reduction of Carbon Dioxide

Reduction of carbon dioxide to formic acid was regularly accomplished with mercury cathodes and sulfates of alkali metals as electrolytes in glass cells at room temperature. Current densities ranged from 0.4 ma/cm^2 to 485 ma/cm^2 ; and a coulombic efficiency (run 184) as high as 20% was measured. Runs 58, 63, 183-5, 187, 188, 190, 191, 192A and 204 form the basis of this generalization.

Non-reproducible reductions were obtained with a similar cathode and BeSO_4 electrolyte (runs 84 and 93) and with similar electrolytes with zinc and mercury amalgam cathodes (run 193 and 203). Some reduction was also observed with sulfuric acid electrolyte and a palladium cathode (run 101).

Reductions of carbon dioxide beyond formic acid were only in trace amounts at best.

V. COLLATION WITH THE LITERATURE

A basic reference to reduction of CO_2 ³ indicates that pure aqueous solutions and strongly acid solutions of carbon dioxide yield traces of formic acid, that there is good reduction with cathodes of mercury, amalgamated zinc, zinc or amalgamated copper. Lead cathodes were reported to work well under certain conditions; and electrolytic zinc, amalgamated copper and specially prepared lead cathodes are to give good results.¹⁹ Increased pressures were reported to promote reduction and solutions of the sulfates of potassium, sodium or lithium to be the best electrolytes.¹⁰

We have observed reduction of CO_2 to formic acid consistently with mercury cathodes and catholytes of lithium sulfate, potassium sulfate or beryllium sulfate; and concentrations of formic acid between one and two percent have been built up. However, coulombic efficiencies have proved to be very low as is shown in Table 11; and concentrations of formic acid built up from CO_2 have not proved large enough to permit further reduction to formaldehyde or methanol. Energy efficiencies were even lower with operating voltages running many times the normal decomposition voltages of alkali metal salts. In the case of run 203, with an operating voltage of 4.1 volts, compared with a reversible voltage of 1.02, energy efficiency was found to be about 3%.

Tafel¹⁸ supports the use of cathodes with high hydrogen over-voltages such as lead and mercury for reduction of compounds reducible only with difficulty, and other metals such as those in Group II of the Periodic Table. Mg, Zn and Cd fall into this category. This is because the higher the hydrogen overpotential of the electrode generally the more powerful is its reducing ability, or the greater the energy content of the hydrogen liberated. This overpotential is simply difference between the potential at which gas evolution is first observed and the theoretical reversible potential of the electrode in the same solution. We have made exploratory studies of these metals and have found only mercury to give consistently positive results under conditions of the tests. Similarly we have made tests on the effect of working of the metals, described as sometimes critical¹³; and under conditions of the tests were not able to observe any effect. Higher overvoltages are reported¹⁹ to be obtained at higher current densities and at lower temperatures; but here again under conditions of our tests, no effects were observed. Carbon is listed⁵ as

TABLE 11 - SUMMARY OF EXPERIMENTAL CONDITIONS INVOLVING QUANTITATIVE ANALYSES

Run No.	CO ₂ Pressure Atmos.	Cathode	Catholyte	Anolyte	Current Density a/cm ²	HCOOH Content g/cc x 10 ³	Coulombic Efficiency (%)
183	1	Hg-K	K ₂ SO ₄	5% H ₂ SO ₄ in sat. K ₂ SO ₄	0.25-0.16	7.36	0.8
184	1	Hg	K ₂ SO ₄	5% H ₂ SO ₄ in sat. K ₂ SO ₄	0.03-0.05	11.08	19.8
190	1	Hg	Li ₂ SO ₄	Li ₂ SO ₄	0.06	5.55	1.6
191	1	Hg	Li ₂ SO ₄	5% H ₂ SO ₄ in sat. Li ₂ SO ₄	0.06	2.02	1.0
192	50	Hg	K ₂ SO ₄	K ₂ SO ₄	0.07	1.32	0.16
202	50	Hg-Zn	K ₂ SO ₄	K ₂ SO ₄	0.0004 to 0.006	0	0
203	50	Hg-Cu	K ₂ SO ₄	K ₂ SO ₄	0.0043	7.12	11.7

having a fairly high hydrogen overvoltage; and use of this material has been suggested⁷ for the synthesis of alcohols. No reduction of CO_2 was observed in our tests; but a slight amount of formaldehyde was obtained from reduction starting with formic acid.

Salts of Cu, Ti, Sn, Pb and V and the oxides of As and Sb have been reported¹⁷ to be promoters of reduction; but here again under conditions of our tests no effects were observed.

Reductions of formic acid to formaldehyde were found under a variety of conditions when starting with high concentrations of formic acid; but apparently the concentrations of HCOOH developed in reduction of CO_2 are not high enough to yield formaldehyde from CO_2 . BeSO_4 electrolyte with cathodes of Hg or Pb gave the best tests. No yields of methanol or methane have been obtained even though they have been reported in the literature.^{8,1} As opposed to the references on good reduction, it should be pointed out that there is precedent in the literature for our difficulty in reducing formic acid² and for failure to reduce CO_2 beyond formic acid.^{4,9} Even when direct chemical reductions with magnesium were performed, yields of formaldehyde were reported as very small.⁹

If the concentration of organic product can be built up in further development, separation of such compounds should be studied. Single stage distillation would not effect separation.¹⁵ Adsorption on a fixed or moving bed of activated charcoal should be given consideration on the basis of favorable citation of such processes.^{21,14}

VI. CONCLUSIONS

It has been demonstrated that carbon dioxide might be reduced to formic acid in concentrations up to 1 or 2 per cent and with coulombic efficiencies up to 20 per cent and measured energy efficiency of about 3 per cent in the case of run 203. Reduction to formaldehyde has been regularly accomplished with mercury cathodes and beryllium sulfate anolytes but only with higher concentrations of formic acid and not directly from carbon dioxide. Since competitive systems operate at higher energy efficiencies and since a workable system for control of cabin atmospheres by cathodic reduction requires production of at least 50% formaldehyde, further work on this system was not deemed feasible.

VII. BIBLIOGRAPHY

1. Allen, M.J. Organic Electrode Processes. Reinhold 1958.
2. Baur, Zeit. Elektrochem. 25 102 (1919).
3. Brockman, C.J. Electro-Organic Chemistry, John Wiley & Sons 1926.
4. Coehn and Jahn Berichte 37 2836 (1904).
5. Creighton, H.J. Principles and Applications of Electrochemistry, Vol. 1, p 249, John Wiley & Sons, 1943.
6. Creighton, H.J. Principles of Electrochemistry, John Wiley & Sons, 1943 (4th Ed.).
7. Cristesco, J. Fuel XIV p 23 (1935).
8. Ellis and McElroy, U.S. Patent 867575 (1907).
9. Fenton, H.J.H. J. Chem. Soc. 91 p 687ff (1907).
10. Fischer, F. and Prziza, O. Ber. 47 (pt 1) 256-260 (1914).
11. Lasycynski, St. V. Zeit.fur Elektrochemie 2, 56 (1895).
12. Miller, R.M. et al "Reduction of Carbon Dioxide with Amalgams" J. Org. Chem. 27 p 2646 (1962).
13. Minnick, L. and Pregrave, C. British Patent 642034, Aug.23, 1950.
14. Moeller, W. "The Adsorbtion of Formaldehyde by Animal Charcoal" Kolloid Zeit. XXVIII p 127,(1921).
15. Priet, E. L. and Hall, M.W. "Distillation Principles of Formaldehyde Solutions" Ind. & Eng. Chem. 46 pp 661-672 (1948).
16. Seimens, A. Zeit. fur Anorg. Chem. 41 271 (1904).
17. Swann, Sherlock, Jr. in Technique of Organic Chemistry II, "Electrolytic Reactions" Interscience 1956.

18. Tafel, Zeit. Physik. Chem. 34 187 (1900) and Ber. 33 p 2209(1900).
19. Weissberger, A., ed., Technique of Organic Chemistry, Vol. II, "Catalytic Photochemical and Electrolytic Reactions."
20. Wood, G.B., and Brenner, A., J. Electrochem. Soc. 104 29 (1957).
21. Zabezhinski, Y. "Kinetics of Sorbtion on Granular Substances"
J. Phys. Chem. (USSR) 17 p 32-44 (1943).
22. Creighton, H.J. Principles and Applications of Electrochemistry, Vol. 1, p 244, John Wiley & Sons, 1943.
23. Walker, F.J., Formaldehyde, p 367 Reinhold (1953).
24. *ibid*, p 383.
25. Bodforss, S., Zeit. Phys. Chem. 124 p 68 (1926).