

NASA CR-54902
MRB5010Q2

Quarterly Report No. 2
"RESEARCH AND DEVELOPMENT OF THE DRY TAPE BATTERY CONCEPT"
9 September to 8 December 1965

Contract No. NAS3-7624

18 January 1966

MRC Report No. MRB5010Q2

For
NATIONAL AERONAUTICS AND SPACE ADMINISTRATION
Lewis Research Center
Cleveland, Ohio

Authors

Joseph J. Byrne, Project Leader
Bernard A. Gruber
Lee F. Athearn
John C. MacDonald
David L. Williams

Technical Management
NASA Lewis Research Center
Cleveland, Ohio
Space Power Division
W. J. Nagle, Technical Manager

MONSANTO RESEARCH CORPORATION
BOSTON LABORATORY
Everett, Massachusetts 02149
Tel: 617-389-0480

SUMMARY

The ACL-85[®] tape cathodes when activated by acid electrolyte can undergo active chlorine loss by disproportionation to Cl_2 and isocyanuric acid. The extent of loss depends on pH, electrolyte volume, and time of electrolyte contact. Cathode efficiencies in the 70-80% range are obtained using mixed electrolyte (AlCl_3 , MgCl_2 for moderate pH) and minimum electrolyte volume. Chlorine loss does not occur above pH 5.

Salts of trichlorotriazinetrione are much more stable than ACL-85. No significant chlorine evolution occurs when discharged in acid electrolyte, and no capacity loss occurs during tape formulation. Cathode efficiencies up to 85% of theoretical (no loss assumed during processing or discharge) were obtained at 0.5 amp/in.² in AlCl_3 electrolyte. Discharge voltages vs Mg are similar to the ACL-85 system.

The best energy density output to date is 315 watt hours per pound of complete tape cell excluding electrolyte for the system Mg/AlCl_3 , $\text{MgCl}_2/\text{ACL-85}$ at 0.5 amp/in.² current density. Further improvement can be made only by reducing activity loss during processing and cell activation.

High capacity ACL-85 tapes (10-18 amp-min/in.²) were successfully discharged at current densities up to 1 amp/in.² vs Mg in mixed AlCl_3 , MgCl_2 electrolytes. Efficiencies ranged from 60-75% at high drain rates.

Fairly flat discharge curves (2.4-2.6 volt vs Mg) were obtained when ACL-compound tape cathodes are discharged at low current densities (0.05 amp/in.²) in neutral (MgCl_2 and MgBr_2) electrolyte. Cell voltage decay at higher drain rates was apparently due to increased resistance caused by electrochemical reaction products.

The full cell system Li/LiClO_4 , methylformate/ACL-85 or ACL-70[®] maintain 3.0 volts at 0.10 amp/in.². A conventional tape cathode was used. The best coulombic efficiencies obtained for these systems to date are 25% (ACL-85) and 50% (ACL-70).

Initial effort to prepare a high surface area lithium from dispersions and by electroplating were unsuccessful. Dispersed lithium was poorly conductive and highly reactive chemically. Initial electroplating resulted in alloy formation. Further technique refinements are necessary.

Magnesium was found to discharge well in a nonaqueous basic electrolyte system LiOCH_3 , CH_3OH . Open circuit voltage was -2.2 volt vs NCE and -1.85 volt at 0.1 amp/in.².

TABLE OF CONTENTS

	<u>Page No.</u>
I. INTRODUCTION.	1
A. BACKGROUND.	1
B. SECOND QUARTER OBJECTIVES	1
II. TASK I. HIGH ENERGY COUPLE RESEARCH.	3
A. CATHODE RESEARCH AND DEVELOPMENT.	3
1. 2,4,6-Trichlorotriazinetrione and Derivatives in Aqueous Electrolyte.	3
2. 2,4,6-Trichlorotriazinetrione and Derivatives in Nonaqueous Electrolyte	21
3. Plans for Third Quarter (Cathode Research and Development)	31
B. ANODE RESEARCH AND DEVELOPMENT.	34
1. Lithium in Nonaqueous Electrolyte	34
2. Magnesium in Nonaqueous Electrolyte	37
3. Plans for Third Quarter (Anode Research and Development).	39
III. TASK II. TAPE CELL CONFIGURATION.	40
A. TAPE CELL PREPARATION.	40
B. DYNAMIC TESTING.	40
IV. SUPPORTING RESEARCH: TEST EQUIPMENT DESING AND IMPROVEMENT	41
V. REFERENCES	42

LIST OF TABLES

<u>Number</u>	<u>Title</u>	<u>Page</u>
1	Activity Loss of ACL-85 Tape Cathodes During Discharge.	3
2	Effect of Electrolyte on ACL-85 Tape Cathode Activity Loss.	5
3	The Effect of Acidic Electrolyte on ACL-85 Disproportionation	6
4	Discharge of ACL-85 Tape Cathodes in Mixed Electrolytes	6
5	Description of ACL-85 Derivatives.	7
6	Activity Loss During Processing for Various "ACL" Cathode Tapes.	8
7	The Effect of Polyvinyl Formal Binder on ACL-85 Activity Loss During Tape Processing	8
8	The Effect of Electrolyte System on Discharge Characteristics of Mg/ACL-85 Tape Cathode.	13
9	Discharge Characteristics of High Capacity (15-22 Ampere-Minutes/inch ²) Mg/ACL-85 Tape Cells in Aqueous Electrolyte	14
10	Discharge Characteristics of "ACL" Salt Tape Cells in Acidic Aqueous Electrolyte.	17
11	The Effect of Low Current Densities on Discharge Characteristics of ACL-85, ACL-75 and ACL-66 Tape Cathodes in Neutral Electrolyte	20
12	Full Cell Data	22
13	Current-Voltage Data on Discharge of Various Nonaqueous Tape Cell Battery Systems	24
14	Discharge of Li/ACL Compound Tape Cells in Methyl Formate at Constant Current	29
15	Lithium Anode (Free Electrolyte) Half Cell Data	36

LIST OF TABLES (continued)

<u>Number</u>	<u>Title</u>	<u>Page</u>
16	Magnesium-Nonaqueous Electrolyte Systems.	38
A-1	Static Cell Discharge Data for Tri-N- Chlorotriazinetrione ("ACL-85") Tape Cathodes . . .	43
A-2	Static Cell Discharge Data for ACL Compound Tape Cathodes	48

LIST OF FIGURES

<u>Number</u>	<u>Title</u>	<u>Page</u>
1	Shape of Mg/ACL-85 Discharge Curve in 2M $\text{AlCl}_3 \cdot 0.5\text{M HCl}$ Electrolyte.	4
2	Typical Discharge Data for ACL-85 Tapes in Various Electrolytes, versus Primary Magnesium . . .	11
3	Projected Energy Density Output (Excluding Electrolyte) As a Function of Efficiency and Capacity for the Mg/ACL-85 Tape System	12
4	Representative Discharge Curves of ACL-85 Cathode Tapes of Various Theoretical Coulombic Capacities	16
5	Typical Discharge Data for ACL-59, ACL-66 and ACL-75 Versus Primary Magnesium.	18
6	The Effect of Mid-discharge Shutdown on Discharge of Mg/2M MgCl_2 /ACL-85 System at 0.17 amp/in. ²	19
7	Discharge of Mg/2M MgCl_2 /ACL-85 System at 0.05 amp/in. ²	19
8	Effect of Electrolyte Salts and of H_2O on Current- Voltage Data for Li/Methyl Formate/ACL-85 Systems (Area = 3 in. ²).	25
9	Current-Voltage Data on the Mg/ $\text{AlCl}_3(\text{AN})$ /ACL-85 System (A = 3 in. ²).	27
10	Constant Current Discharge of the Mg/ $\text{AlCl}_3(\text{AN})$ / ACL-85 System (C.D. = 0.05 amp/in. ² , A = 3 in. ²)	
11	Discharge of the Li/ACL-85 Tape System in LiClO_4 (Methyl Formate) and KPF_6 (Methyl Formate) Electrolytes	30
12	Discharge of ACL Compounds vs Lithium in $\text{LiClO}_4(\text{MF})$ at 0.10 amp/in. ²	32
13	Discharge of the Li/ACL-70 System in $\text{LiClO}_4(\text{MF})$. . .	33

I. INTRODUCTION

A. BACKGROUND

During the first quarter a new tape couple, based on the Mg/AlCl₃, HCl/trichlorotriazinetrione (Monsanto ACL-85[®]) system was developed. Static cell output data demonstrated a flat discharge curve with cell voltages above 2.0 volts at current densities close to 1 amp/in.². Actual cathode coulombic efficiencies above 80% were measured, but output reproducibility was erratic. High energy output (~300 watt-hours/pound of complete tape cell excluding electrolyte) indicated promise for this system as a potential 200 watt-hour/pound cell.

Both lithium and magnesium were examined as potential non-aqueous system tape anode materials. Lithium was found to work satisfactorily with lithium perchlorate or potassium hexafluorophosphate in methyl formate. Magnesium results were still erratic at the end of the quarter, primarily because of surface preparation problems.

Emphasis during the second quarter was to improve and optimize the Mg/ACL-85 tape system. In addition, the discharge characteristics of active chlorine compounds were to be examined versus lithium and magnesium in nonaqueous tape configuration systems.

B. SECOND QUARTER OBJECTIVES

The specific objectives for this quarter were to:

1. Optimize the energy density output of the aqueous Mg/ACL-85 system and evaluate the complete tape system under dynamic conditions.
2. Determine the performance of active chlorine compounds in nonaqueous electrolyte and start full cell tape configuration studies using a lithium foil anode.
3. Continue screening of selected lithium and magnesium systems in nonaqueous electrolyte using the free electrolyte test cell.
4. Determine the effect of lithium purity and system water content on anode discharge characteristics.
5. Develop a tape configuration lithium anode with a specific effort to produce a high surface area electrode.
6. Produce continuous lengths of ACL-85 tapes.

Production of continuous lengths of tape and dynamic evaluation of Mg/ACL-85 tape cells were postponed to completely analyze the causes of ACL compound instability during tape preparation and cell activation. In addition, other ACL salts were evaluated in acidic aqueous electrolyte, and the ability to discharge ACL compound tape cells in neutral electrolyte was investigated. All other objectives were accomplished.

II. TASK I. HIGH ENERGY COUPLE RESEARCH

A. CATHODE RESEARCH AND DEVELOPMENT

1. 2,4,6-Trichlorotriazinetrione and Derivatives in Aqueous Electrolyte

a. Chemical Stability of ACL-85[®] in Aqueous Electrolyte

During the first quarter, it was found that ACL-85 tapes would lose activity during processing and on standing unless the acetylene black was vacuum dried beforehand. Using pre-dried conductor material, tape cathodes were made that consistently discharged at 70-80% efficiency in $\text{AlCl}_3 \cdot \text{HCl}$ electrolyte. Recent discharge data with new batches of electrodes have been erratic, with substantially lower efficiencies in many cases. Investigation has shown considerable active chlorine loss only after contact with certain electrolytes. This phenomenon is illustrated in Table 1 for a typical cathode formulation* containing 65 wt-% ACL-85. Active chlorine analyses were performed on fresh tapes from the same batch and on discharged tapes immediately after passing the cut-off voltage (-1.5 volt vs Mg).

Table 1

ACTIVITY LOSS OF ACL-85 TAPE CATHODES DURING DISCHARGE

Electrolyte - $2\text{M AlCl}_3 \cdot 0.5\text{M HCl}$

Current Density - 0.5 amp/in.²

Anode - Primary Magnesium

Measured Cathode Efficiency %	Active Chlorine Analysis, %	
	Before Discharge	After Discharge
48	91**	10
49	91**	5
48	91**	4

** Based on known amount of active material added initially.

These data are for extreme cases but they do illustrate the possible extent of activity loss. It is apparent that most of the active chlorine reacted during discharge. However, only half reacted electrochemically with magnesium. The other half reacted by another mechanism. The shape of typical discharge curves (Figure 1) for two apparent low efficiency tests illustrates essential cathode depletion at cutoff voltage (1.5 volts).

* Standard cathode tape formulations contain 2.75 wt-% binder (polyvinyl formal) and 2.75 wt-% fiber (1/4 in. dynel). Active cathode material and acetylene black comprise the remainder.





Figure 1. Shape of Mg/ACL-85 Discharge Curve In 2M $\text{AlCl}_3 \cdot 0.5\text{M HCl}$ Electrolyte

The extent of activity loss varied from test series to test series, but results indicate that this activity loss is peculiar to acid electrolyte. Data in Table 2 show active chlorine loss when fresh tape cathodes are immersed in various electrolyte solutions for five minutes. A typical 65 wt-% ACL-85 cathode formulation was used.

Table 2
EFFECT OF ELECTROLYTE ON ACL-85 TAPE CATHODE ACTIVITY LOSS

<u>Electrolyte Solution</u>	<u>Original Active Chlorine Remaining After Five Minute Soak, %</u>
2M $\text{AlCl}_3 \cdot 1\text{M HCl}$	53
2M $\text{AlCl}_3 \cdot 0.5\text{M HCl}$	65
1M $\text{AlCl}_3 \cdot 0.5\text{M HCl} \cdot 1\text{M LiClO}_4$	74
2M LiClO_4	93
H_2O	95

The activity loss for ACL-85 cathode tapes when activated by acid electrolyte is due to breakdown to isocyanuric acid and chlorine, the reverse of the initial



preparative reaction. Table 3 shows the comparative effect of 3 ml of water and various acid electrolytes on the active chlorine content of 0.05-g sample of ACL-85. A strong Cl_2 odor is evident when the strong acid electrolyte solutions are used.

This is a solution reaction and explains the nonreproducibility of previous results. ACL-85 tape cathode disproportionation depends on electrolyte volume, soak time prior to discharge, and the discharge time itself. High rate discharges with minimum electrolyte soak times resulted in high efficiencies.

The best discharge results were obtained by eliminating free HCl as an original constituent and using mixed electrolytes. Elimination of acidic electrolyte completely resulted in poor discharge characteristics, at least at high current densities. Behavior in neutral electrolyte is discussed below. Some typical data in Table 4 illustrate these facts.

Table 3

THE EFFECT OF ACIDIC ELECTROLYTE
ON ACL-85 DISPROPORTIONATION

Electrolyte Solution Volume - 3 ml
ACL-85 Sample Weight - 0.05 g
Exposure Time Before Analysis - 5 minutes

<u>Solution</u>	<u>Original Active Chlorine Remaining, %</u>
blank	100
H ₂ O	100
0.5M HCl	10
2M AlCl ₃ ·0.5M HCL	19
2M AlCl ₃	56
2M MgCl ₂	90

Table 4

DISCHARGE OF ACL-85 TAPE CATHODES
IN MIXED ELECTROLYTES

Cathode Formulation - Standard 65 wt-% ACL-85 Formulation
Anode - Primary Magnesium
Electrode Area - 3 in.²
Current Density - 0.5 amp/in.²
Approximate Total Capacity - 14-16 amp-min




<u>Electrolyte</u>	<u>Cathode Coulombic Efficiency*, %</u>	<u>Average Discharge Voltage, volts vs Mg</u>
2M AlCl ₃ ·0.5M HCl	40-60	2.35-2.40
2M AlCl ₃	64-68	2.20-2.25
1.5M AlCl ₃ ·0.5M LiClO ₄	65-70	2.15-2.20
1.0M AlCl ₃ ·1.0M LiClO ₄	61-68	2.15-2.20
2M LiClO ₄	~30	~1.7
1.5M AlCl ₃ ·0.5M MgCl ₂	73-77	2.20-2.30
1.0M AlCl ₃ ·1.0M MgCl ₂	70-80	2.15-2.25
2M MgCl ₂	30-50	~1.90

* Based on active chlorine content as analyzed
prior to activation.

Even with the best mixed electrolyte systems (AlCl_3 , MgCl_2) there appears to be 10-15% activity loss during discharge based on final active chlorine analysis. In addition, there is also 5-15% activity loss in processing ACL-85 tapes.

Preliminary data with salts of chlorinated triazinetriones indicate they are much more stable than the fully chlorinated material. The various materials being examined are listed in Table 5.

Table 5
DESCRIPTION OF ACL-85 DERIVATIVES

<u>Active Chlorine Compound</u>	<u>Capacity Amp-min/g</u>
ACL-85	41.5
	
ACL-70 [®]	32.5
	
ACL-59 [®]	27.0
	
ACL-66 [®] (mixed salt of ACL-59 and ACL-85)	30.5
ACL-75 [®] (mixed salt of ACL-59 and ACL-85)	35.0

ACL-85, -70, and -59 are commercially available materials. ACL-66 and -75 are experimental materials supplied by Monsanto Company. Initial results with ACL-59 and ACL-66 show no significant activity loss on processing. In addition, cathode efficiencies up to 85% have been obtained with ACL-66 in AlCl_3 electrolyte. No chlorine formation was noted for either ACL-59 or ACL-66.

The discharge voltages are identical to those obtained with ACL-85. Despite lower capacities compared with ACL-85, ACL-66 and -75 may be promising if chemical stability is maintained.

In general, the dichlorotriazinetriones are more stable than the trichloro derivative. The first chlorine of the trichloro compound is very labile and easily hydrolyzed or reduced. The increased stability of the "ACL" salts is reflected in high activity retention after processing (Table 6).

Table 6

ACTIVITY LOSS DURING PROCESSING FOR VARIOUS "ACL" CATHODE TAPES

Formulation: 65 wt-% "ACL" material, 2.75 wt-% polyvinyl formal binder, 2.75 wt-% dynel fiber, 29.5 wt-% acetylene black

Technique: Slurry of cathode mix in trichloroethylene cast on 4-mil dynel tape and vacuum dried.

<u>Active Material</u>	<u>Original Active Chlorine Remaining After Processing, %</u>
ACL-85	89.6 \pm 2.8% (24 tests)
ACL-75	94.5 \pm 1.3% (11 tests)
ACL-66	96.5 \pm 2.1% (17 tests)
ACL-59	98.1 \pm 1.0% (3 tests)

The activity loss of ACL-85 during tape preparation appears to be caused primarily by the acetylene black. During the first quarter, the beneficial effect of vacuum drying the acetylene black before tape processing was demonstrated. More recent work has shown that ACL-85 can interact with binder (Table 7).

Table 7

THE EFFECT OF POLYVINYL FORMAL BINDER ON ACL-85 ACTIVITY LOSS
DURING TAPE PROCESSING

	<u>Original Active Chlorine Remaining After Processing, %</u>
PVF Present	91 \pm 1 (based on four tests)
No PVF	95 \pm 1 (based on four tests)

Elimination of polyvinyl formal binder coupled with the vacuum drying pretreatment of acetylene black has led to consistent active chlorine retentions of 91-95%. Removal of the binder does not interfere with electrochemical tests, but a new inert binder material will be necessary for satisfactory mechanical properties.

b. Discharge of ACL-85 Tape Cathodes and Derivatives in Aqueous Electrolyte

During the second quarter, work in this area was directed toward improving the energy density output in acidic aqueous electrolyte and determining the feasibility of successful discharge in neutral electrolyte where anode gassing and ACL-85 active chlorine loss does not occur. A complete compilation of static cell discharge experiments is contained in the Appendix (Table A-1). Only selected or summarized data are presented in the following sections.

(1) Discharge in Acidic Aqueous Electrolyte

The shape of the discharge curve for ACL-85 tape cathodes and absence of significant residual active chlorine after cell voltage drop indicates the electrochemical reduction of tri-chlorotriazinetrione in the tape configuration to be highly efficient. Measured efficiencies in aluminum chloride-hydrochloric acid electrolytes are consistently in the range of 75-85%. These figures do not take into account active chlorine loss due to disproportionation of ACL-85 in acid. They are based on as-measured ACL-85 content prior to discharge and, therefore, are corrected for activity loss during processing.

During the first quarter, energy densities of 290-300 watt-hours/pound of dry ingredients were obtained for the Mg/ACL-85 tape system. There are two areas where improvements must be made to increase energy density output to the 350-400 watt-hour/pound (dry ingredients) objective:

- (i) Eliminate active chlorine loss on tape processing
(possible maximum improvement 10-15%)
- (ii) Eliminate active chlorine loss during activation
(possible maximum improvement 10%).

Some progress has been made in area (i). Losses during processing have been cut to 5-7% although good reproducibility has not yet been achieved. Two approaches have been explored to reduce active chlorine loss during activation. The first is the use of mixed salt electrolyte with reduction or elimination of free hydrochloric acid. The second involves use of ACL-85 derivatives that are more stable chemically than ACL-85 itself.

The various electrolyte systems examined, together with results obtained, are shown in Table 8. For maximum efficiency, the best mixed electrolyte system is aluminum chloride-magnesium chloride where magnesium chloride concentration is equal to or less than aluminum chloride concentration. Coulombic cathode efficiencies were generally 80% or better. Cell voltages were somewhat lower than those obtained with aluminum chloride-hydrochloric acid electrolyte. Discharge curves for the best cell from each electrolyte series are illustrated in Figure 2.

Using performance data acquired to date, a projection can be made of the ultimate energy density output that can be expected from the Mg/ACL-85 tape system in aqueous acidic electrolyte. The best coulombic efficiencies are obtained with cathode mix containing a maximum of 70 wt-% ACL-85 and a primary magnesium foil anode. A delivered cell voltage of 2.4 volts is obtained at current densities of 0.5 amp/in.² to 0.7 amp/in.².

Figure 3 shows the energy density output (excluding electrolyte) for a complete tape cell as a function of overall coulombic efficiency and capacity. Overall efficiency includes activity loss during processing and chemical losses during activation. The best energy density obtained to date is 315 watt-hours/pound complete cell excluding electrolyte for cell no. 80482-2. The overall efficiency was 75% including an approximate 10% active chlorine loss during processing. The "X" denoted in Figure 3 represents the best experimental output to date. Energy density increases can be expected through further development in the following areas:

- (i) Increase tape capacity from present levels (8-12 amp-min/in.²) to 20-25 amp-min/in.². Further increases in capacity for this formulation would probably make the tapes too bulky to handle in a practical manner.
- (ii) Decrease active chlorine loss during processing. Losses have been held to 5% and further improvements appear likely.
- (iii) Active chlorine loss during activation are expected to decrease during dynamic operation since electrolyte contact time is minimized compared with static cell operation.

It would appear that an overall efficiency of 85% is a reasonable goal with ultimate expected energy densities of 350-370 watt-hours/pound of tape cell excluding electrolyte.

The discharge characteristics of higher capacity ACL-85 tape cathode (15-22 amp-min/in.²) are summarized in Table 9.





Figure 2. Typical Discharge Data for ACL-85 Tapes in Various Electrolytes, versus Primary Magnesium




Figure 3. Projected Energy Density Output (Excluding Electrolyte) As a Function of Efficiency and Capacity For The Mg/ACL-85 Tape System

Table 8

THE EFFECT OF ELECTROLYTE SYSTEM ON DISCHARGE CHARACTERISTICS
OF Mg/ACL-85 TAPE CATHODE

Cathode Formulation: 65 wt-% ACL-85
29.5 wt-% Shawinigan Acetylene Black
2.75 wt-% 1/8 in. Dynel Fiber
2.75 wt-% Polyvinyl Formal Binder
Separator: 3.5-mil Dynel
Anode: 5-mil perforated primary magnesium
Cell Area: 3 in.²

Cell No.	Electrolyte	Current, amp	Average Voltage, volts	Cathode Coulombic Efficiency (1.5 volt cutoff), %
80442-6	2M AlCl ₃ ·0.5M HCl	1.5	2.4	63
80455-16	" "	1.5	2.5	67
80455-14	" "	1.5	2.3	73
80482-2	" "	1.5	2.4	79
80482-3	" "	1.5	2.3	75
80439-2	2M AlCl ₃	1.5	2.25	72
80450-3	"	1.5	2.35	79
80455-1	1.5M AlCl ₃ ·0.5M MgCl ₂	1.5	2.20	80
80455-2	" "	1.5	2.20	83
80455-4	" "	1.5	2.15	76
80450-1	" "	1.5	2.30	81
80450-7	" "	2.0	2.23	80
80455-15	" "	2.0	2.30	83
80455-11	" "	2.5	2.15	74
80455-20	" "	3.0	2.00	67
80455-12	" "	3.0	1.95	64
80450-4	1M AlCl ₃ ·1M MgCl ₂	1.5	2.20	84
80450-6	" "	2.0	1.90	72
80482-11	2M AlCl ₃ ·0.5M MgCl ₂	1.0	2.50	75
80445-5	0.5M AlCl ₃ ·1.5M MgCl ₂	1.5	1.90	42
80439-3	1.5M AlCl ₃ ·0.5M LiClO ₄	1.5	2.20	75
80439-9	" "	1.5	2.10	70
80442-8	" "	1.5	2.15	73
80442-2	" "	1.5	2.15	71

Table 9
DISCHARGE CHARACTERISTICS OF HIGH CAPACITY (15-22 AMPERE-MINUTES/INCH²)
Mg/ACL-85 TAPE CELLS IN AQUEOUS ELECTROLYTE

Cell No.	ACL-85 In Cathode Mix, wt-%	Capacity amp-min/in. ²	Electrolyte	Current Density amp/in. ²	Cathode Efficiency %(to-1.5volts)	Operating Voltage volts
80455-12	65	14	1.5M AlCl ₃ ·0.5M MgCl ₂	1.0	71	1.95
80455-15	"	16	" "	0.7	76	2.30
80455-11	"	17	" "	0.8	82	2.10
80455-14	"	17	" "	0.5	72	2.25
80455-13	"	18	" "	0.8	74	2.15
80463-2	"	19	" "	0.7	62	2.15
80455-20	"	20	" "	1.0	67	2.00
80460-3	70	20	" "	0.7	78	2.20
80460-8	"	20	" "	0.5	59	2.20
80455-17	65	18	1.5M AlCl ₃ ·0.5M MgCl ₂ · 0.2M HCl	0.7	77	2.20
80455-18	"	20	1.0M AlCl ₃ ·1M MgCl ₂ · 0.2M HCl	0.5	73	2.25
80460-5	70	21	1M AlCl ₃ ·1M MgCl ₂	0.7	54	2.10
80455-19	65	18	" "	0.7	54	2.10
80455-10	65	17	2M AlCl ₃ ·0.5M HCl	0.8	56	2.30
80455-16	"	17	" "	0.5	71	2.50
80463-9	"	18	" "	0.7	59	2.25
80460-1	70	19	" "	0.7	55	2.20
80460-6	"	22	2M AlCl ₃	0.7	57	2.25
80463-4	65	20	"	0.5	52	2.10

In general, increasing capacity, at least up to 20 amp-min/in.² does not markedly change the discharge characteristics. As expected, the heavier tapes maintain slightly higher voltages at high current drains. Representative discharge curves are illustrated in Figure 4.

The discharge characteristics of the various salts of ACL-85, ACL-59, ACL-66, and ACL-75 (see Table 5), were screened in various acidic aqueous electrolytes. The results are summarized in Table 10. A comparison of the four systems is illustrated in Figure 5.

The ACL-59 tapes ran poorly, with cathode efficiencies no higher than 50%. Since there is no activity loss during tape preparation, poor efficiencies may be due to high solubility (9 g/100 g H₂O at 20°C). Because of poor performance and relatively low capacity, ACL-59 was eliminated from further consideration.

The polarization characteristics of ACL-66 and ACL-75 are similar to those for ACL-85. Because of better chemical stability, these mixed salts exhibit better overall cathode efficiencies. ACL-66 shows no activity loss during processing with the result that overall efficiencies as high as 85% were obtained. ACL-75 exhibited slightly lower efficiencies (65-71%), which directly reflect the 5-8% activity loss during processing. As with the ACL-85 tape cathodes, the aluminum chloride-magnesium chloride solution appears to be the best electrolyte system.

The ability to discharge ACL-85 cathode successfully in neutral electrolyte is highly desirable. Elimination of the acidic electrolyte would avoid anode gassing and activity loss due to cathode decomposition. Initial work, during the first quarter, showed that ACL-85 tape cathodes exhibit steadily increasing polarization during discharge in neutral electrolyte. Further work was carried out to clarify the nature of this polarization and determine under what conditions, if any, a neutral electrolyte system could be used successfully. Discharge data indicate that polarization is caused by the accumulation of an electrochemical discharge product rather than a chemical decomposition product. Contact of ACL-85 tape cathodes with various neutral electrolyte systems for varying periods of time resulted in no significant activity loss. As illustrated in Figure 6, polarization is related to discharge time rather than elapsed time after activation. Current shut-down during a run has no effect upon ultimate efficiency or polarization. Extending the discharge time by decreasing the current actually improves output (Figure 7) with no loss in efficiency.

Indications are that ACL-85 and "ACL-salts" can be discharged successfully in neutral electrolyte at low current densities. Typical results are shown in Table 11.




Figure 4. Representative Discharge Curves of ACL-85 Cathode Tapes of Various Theoretical Coulombic Capacities




Figure 5. Typical Discharge Data For ACL-59, ACL-66 and ACL-75 Versus Primary Magnesium

Table 10
DISCHARGE CHARACTERISTICS OF "ACL" SALT TAPE CELLS IN ACIDIC
AQUEOUS ELECTROLYTE

Cathode Formulation: 65 wt-% "ACL" salt, 30 wt-% acetylene black, 2.5 wt-% carbon fibers (1/8 in.),
2.5 wt-% polyvinylformal binder

Separator: 4-mil dynel

Anode: 5-mil perforated primary magnesium

Cell Configuration: 3 x 1 in.

Cell No.	Capacity amp-min	Capacity Loss During Processing %	Electrolyte	Cathode Efficiency to 1.5 volts %	Current I amp	Operating Voltage, volts
<u>ACL-75 (35 amp-min/g capacity)</u>						
80483-1	18	8	1.5M AlCl ₃ ·0.5M MgCl ₂	66	1.5	2.15
80472-1	20	8	" "	70	1.5	2.30
80472-2	25	5.5	2M AlCl ₃	71	1.5	2.35
80472-3	20	5.5	2M AlCl ₃ ·0.5M HCl	65	1.5	2.35
<u>ACL-66 (30.5 amp-min/g capacity)</u>						
80470-3	17	0	1.5M AlCl ₂ ·0.5M MgCl ₂	85	1.5	2.35
80486-4	14	0	" "	67	1.5	2.30
80486-2	31	0	" "	68	1.0	2.40
80474-8	21	0	" "	82	1.5	2.30
80474-9	28	0	" "	63	3.0	2.00
80486-3	31	0	1.5M MgCl ₂ ·0.5M AlCl ₃	70	1.0	2.00
80470-1	15	0	2M AlCl ₃	70	1.5	2.30
80484-5	19	0	" "	75	1.5	2.10
80474-2	29	0	" "	72	3.0	2.00
80470-2	21	0	2M AlCl ₃ ·0.5M HCl	67	1.50	2.35
80474-1	24	0	" "	53	3.00	2.00
<u>ACL-59 (27 amp-min/g capacity)</u>						
80466-7	31	0	1.5M AlCl ₃ ·0.5M MgCl ₂	53	1.5	2.10
80466-10	31	0	" "	51	1.5	2.00
80466-4	22	0	2M AlCl ₃ ·0.5M HCl	46	1.5	2.20




Figure 6. The Effect of Mid-discharge Shutdown on Discharge of Mg/2M MgCl₂/ACl-85 System at 0.17 amp/in.²




Figure 7. Discharge of Mg/2M MgCl₂/ACl-85 System at 0.05 amp/in.²

Table 11
THE EFFECT OF LOW CURRENT DENSITIES ON DISCHARGE CHARACTERISTICS
OF ACL-85, ACL-75 AND ACL-66 TAPE CATHODES
IN NEUTRAL ELECTROLYTE

Cathode Formulation: 65 wt-% ACL compound, 30 wt-% acetylene black, 2.5 wt-% carbon fiber (1/8 in.),
2.5 wt-% polyvinyl formal binder
Separator: 4-mil Dynel
Anode: 5-mil perforated primary magnesium
Cell Configuration: 3 x 1 in.

<u>Cell No.</u>	<u>Capacity amp-min.</u>	<u>Electrolyte</u>	<u>Cathode Efficiency to 1.5 volts %</u>	<u>Current, I amp</u>	<u>Operating Voltage volts</u>
<u>ACL-85</u>					
80477-6	27	2M MgBr ₂	63	0.5	1.90
83804-3	11	"	60	0.15	2.10
80482-10	14	"	68	0.15	2.10
80482-7	22	2M MgCl ₂	75	0.5	2.00
80450-8	11	"	54	0.5	1.80
80463-5	44	"	56	0.5	1.80
80455-1	25	"	59	0.15	2.00
<u>ACL-75</u>					
80483-9	19	2M MgBr ₂	75	0.15	2.20
80483-10	20	2M MgCl ₂	77	0.50	1.90
<u>ACL-66</u>					
80474-6	22	2M MgBr ₂	70	0.50	2.00
80488-1	20	"	72	0.15	2.20
80486-5	28	"	75	0.15	2.20
80484-1	18	"	71	0.15	2.20
80474-11	24	2M MgCl ₂	71	0.50	1.70
80484-3	20	"	53	0.50	2.0
80486-5	28	"	78	0.15	1.85

The mixed salts, ACL-66 and ACL-75, appear to give better efficiencies and cell voltages than ACL-85. In addition, substantially higher voltages are obtained with 2M MgBr₂ compared with 2M MgCl₂ for all cathode systems studied.

2. 2,4,6-Trichlorotriazinetrione and Derivatives in Nonaqueous Electrolyte

a. Full Cell Preparation

The solubility of organic N-chlorine compounds in typical organic electrolyte systems makes the free electrolyte half-cell screening technique unsuitable for most ACL cathodes. Hence, most of the cathode research has been done using tape configuration full cells with lithium as the working anode. The lithium potential is read separately (vs NCE) so that cathode and anode polarizations can be separated.

In the early experiments the lithium anode was prepared from the same lithium used for half-cell tests. This anode was prepared by slicing block lithium (Fisher), sealing the slice in polypropylene in the drybox, pressing it to a foil in a Carver press at 10,000 psi outside the drybox, followed by unsealing the enclosed foil back in the drybox.

The full cell construction and cathode formulations were similar to those for the aqueous system with the following variations. The static test sandwich type cell was made of polypropylene. Cathode formulations used carbon fibers rather than dynel and polypropylene separators were used. These variations were necessary to insure stability of materials in various organic solvents. A 65% depolarizer content was used unless otherwise noted.

The polypropylene separator offers no resistance problems in the methyl formate system. This was shown by half cell tests of the Li/KPF₆(MF) system in which essentially identical results were obtained with and without a polypropylene separator covering the lithium anode. Some of this preliminary data using this system is shown in Table 12.

These initial polarization data indicated that a Li/ACL-85 tape configuration system could maintain a substantial discharge voltage at reasonable current drains.

b. Full Tape Cell Screening Tests of Various Cathode Types in Nonaqueous Electrolytes

Screening experiments were carried out to test a variety of cathode materials in the full cell configuration and served as an introduction to the more detailed work with the ACL compounds.

Table 12

FULL CELL DATA

Test No.	System	Area, in. ²	Voltage at Various Currents (ma)												Principle Cause of Failure	Notes
			0	2	5	10	20	40	60	80	100	200	300	450		
1	Li/LiClO ₄ (BL)/AgCl	1 in. ²	2.95	2.6	2.3	1.6	1.3	0.85	0.55							Some Anode (cathode loss)
2	Li/LiClO ₄ (MF)/AgCl	1 in. ²	2.9	2.3	1.9	1.7	1.9	1.6								
3	Li/LiClO ₄ (MF)/ACL-85	1.5 in. ²	4.05	3.95	3.9	3.85	3.7	3.6	3.55	3.5	3.2	2.95				Addn. of electrolyte improves >2.0 volts for 8 min at 0.2 A/in. ²
4	" "	2.0 in. ²	4.00	3.95	3.9	3.85	3.75			3.5	3.2	3.0				
5	Li/KPF ₆ (MF)/AgCl	1 in. ²	3.0	1.4	0.15											Anode and Cathode
6	Li/KPF ₆ (MF)/ACL-85	3 in. ²	4.1	4.0	3.95	3.85	3.7	3.6	3.5	3.45	3.05	2.8	2.55	1.95		Anode and Cathode

Some
Anode (cathode loss)

Cathode

Anode

Anode

Anode and Cathode


Anode and Cathode

Addn. of electrolyte improves
>2.0 volts for 8 mth at 0.2 A/in.²

The results of these experiments are given in Table 13. It is evident from the data that the lithium anode operated effectively in the electrolytes tested. The electrolyte choices were drawn primarily from the half-cell screening data.

Three N-chloro- compounds were chosen for current-voltage screening in methyl formate. One inorganic active chlorine compound (LiOCl) was chosen, and two silver salts were tested (AgCl and AgO).

The N-halogen compounds normally exchange Cl for H upon reduction. However, in non-protonic solvents it may be possible to substitute Li for H when reducing N-halogen acids such as ACL-85 and ACL-59. For example:



Hence, we postulate that hexachloromelamine did not discharge effectively because this compound cannot accept lithium in place of hydrogen. The amine hydrogen is not acidic.

Other active chlorine compounds that could discharge in nonaqueous solvents are halogen addition compounds (e.g. pyridine perbromide) and N-halogen compounds that discharge to give further unsaturation or coupling (e.g. N,N'-dichlorobenzoquinone-diimine (ref. 1)). Some of these will be tested next quarter.

Figure 8 shows the current-voltage discharge data of ACL-85 in methyl formate. LiClO₄ and KPF₆ are shown to be equally effective as electrolyte salts. Water appears to decrease the full cell voltage. This loss is due to cathode polarization.

Of the inorganic active chlorine compounds, LiOCl is of interest for nonaqueous solvents (ref. 2). Two samples of LiOCl were tested in tapes prepared similarly to the ACL tapes. The commercial grade of LiOCl (Lithium Corporation of America) included stabilizers and was 25% LiOCl. The K and K Chemical sample also assayed at 30% LiOCl by the iodine-thiosulfate titration method. Both samples discharged similarly in LiClO₄(MF). There was considerable activity but very little capacity in these tapes. A tape was discharged in LiCl(DMF) in an attempt to obtain more capacity since one of the products, LiCl, is soluble. The instability and insolubility of the LiOCl is presumably most of the problem, because the discharge in DMF showed no improvement.

Table 13
CURRENT-VOLTAGE DATA ON DISCHARGE OF VARIOUS NONAQUEOUS TAPE CELL BATTERY SYSTEMS

Ref.	System	Cell Voltages at c.d. in amp/in. ²										Anode Potential vs NCE at c.d. in amp/in. ²									
		0.0	.005	0.01	0.02	0.03	0.05	0.10	0.15	0.20		0.0	.005	0.01	0.02	0.03	0.05	0.10	0.15	0.20	
897	Li/LiClO ₄ (MF)/ACL-85	4.05	3.95	3.80	3.70	3.60	3.30	2.90	2.65	2.30		3.00	3.00	3.00	3.00	2.90	2.80	2.70	2.60	2.60	
897	Li/KPF ₆ (MF)/ACL-85	4.00	3.95	3.85	3.70	3.45	3.20	3.0	2.30			3.05	3.00	2.95	2.90	2.65	2.45	2.40	2.20		
312	Li/LiClO ₄ (MF)/ACL-59	3.90	3.40	3.10	2.65	2.45	2.20	2.40	2.0	1.2		3.00	2.80	2.75	2.70	2.60	2.60	2.70	2.60	2.50	
891	Li/LiClO ₄ (MF)/HCM*	2.85	2.40	1.80	1.20	0.9	0.4					2.20	2.20	2.20	2.15	2.05	1.95				
860	Li/LiClO ₄ (MF)/AgCl	2.9	1.8	1.8	1.6							3.15	3.10	3.00	2.90						
323	Li/LiClO ₄ (MF)/AgO	3.6	2.9	2.7	2.2	1.8	1.55	1.05	0.90			3.05	3.00	2.95	2.90	2.85	2.80	2.75	2.65		
316	Li/LiClO ₄ (MF)/LiOCl	3.90	3.85	3.75	2.80	2.30	1.80	1.25				3.05	3.05	3.05	3.05	3.00	2.95	2.85			
321	Li/LiCl(DMF)/LiOCl	3.50	3.10	2.85	2.50	2.00	1.30	0.20				3.15	3.15	3.15	3.15	3.10	3.05	3.00			
324	Li(Hg)/LiOMe(MeOH)/ACL-85	3.00	2.80	2.60	2.40	2.10	1.80	0.70				2.20	2.00	1.80	1.60	1.40	1.00	0.00			
328	Mg/LiOMe(MeOH)/ACL-85	2.75	2.55	2.35	2.10	1.70	1.00					2.00	2.00	2.00	1.95	1.85	1.60				
328	Mg/LiOMe(MeOH)/ACL-59	2.50	.20	2.10	1.85	1.60	1.10					2.05	2.00	1.90	1.75	1.55	1.25				
885	Mg/AlCl ₃ (AN)**/ACL-85			2.80			2.60	2.45		2.05		1.95			1.75		1.60	1.50		1.10	

* hexachloromelamine

** acetonitrile




Figure 8. Effect of Electrolyte Salts and of H₂O on Current-Voltage Data for Li/Methyl Formate/ACl-85 Systems (Area = 3 in.²)

Since a good discharge has been shown for AgO (ref. 3) in nonaqueous batteries, tapes were made for this program by a method developed previously in this laboratory (ref. 4). The discharge of this tape in $\text{LiClO}_4(\text{MF})$ showed considerable initial voltage loss and was much less active than the active chlorine compounds. The AgCl data was collected early in the quarter and the cathode was produced by reducing a Yardney Silcad AgO (YS10) cathode and re-oxidizing it in $\text{HCl}(\text{aq})$. The data is given in Table 13 for comparison and completeness.

One test was performed on an amalgamated Li anode. This electrode was prepared by wetting lithium with mercury and then annealing the anode at 135°C in vacuum. The anode was indeed deactivated (50/50 wt-% Li/Hg). The result indicates that more work could be done in this area. For example, at 50/50 wt-%, a more active electrolyte than $\text{LiOMe}(\text{MeOH})$ could be used. Amalgamation by inclusion of Hg^{++} in solution might also be possible.

Full cell data was also obtained for ACL compounds with magnesium anodes in $\text{LiOMe}(\text{MeOH})$ and in $\text{AlCl}_3(\text{AN})$. ACL-85 discharged readily against magnesium in AlCl_3 and reasonably well in $\text{LiOMe}(\text{MeOH})$. From Figure 9 it would appear that the polarization is mostly IR-loss in the $\text{AlCl}_3(\text{AN})$ system. A constant current discharge (Figure 10) exhibited a flat discharge potential at 2.5 volts but a cathode efficiency of only 25%.

c. Discharge of ACL-Compound Tape Cathodes in Nonaqueous Electrolyte Systems

Emphasis this quarter was placed on the discharge of ACL-compounds versus lithium in methyl formate, since such cells have a large theoretical energy capacity, and have been shown to discharge at drain rates of 0.1 amp/in.² in methyl formate.

The solubility of ACL-85 in methyl formate had been found to be less than in the other nonaqueous solvents used. The addition of salt might be expected to decrease the solubility. However, the solubility increases greatly with addition of LiClO_4 . Thus, 2.2 g of ACL-85 dissolves in 100 ml of MF. However, more than 20 g of ACL-85 dissolves readily in 100 ml of 1M $\text{LiClO}_4(\text{MF})$. In $\text{KPF}_6(\text{MF})$, the solubility of ACL-85 is not noticeably increased. In γ -BL and EF the addition of LiClO_4 also increases the ACL-85 solubility. Active chlorine analysis on the $\text{LiClO}_4(\text{MF})$ solution showed almost no loss of active chlorine, even though there was no solid phase.

Since solubility of ACL-85 is likely to give chemical depolarization, low OCV and low capacities might be expected. Increasing separator thickness, and using KPF_6 rather than LiClO_4 , might improve results.




Figure 9. Current-Voltage Data on the $\text{Mg}/\text{AlCl}_3(\text{AN})/\text{ACl-85}$ System
($A = 3 \text{ in.}^2$)




Figure 10. Constant Current Discharge of the $\text{Mg}/\text{AlCl}_3(\text{AN})/\text{ACl-85}$ System (C.D. = 0.05 amp/in.^2 , $A = 3 \text{ in.}^2$)


The results, shown in Table 14 and in Figure 11, indicate that LiClO_4 and KPF_6 are equally effective as electrolyte salts in methyl formate, for ACL-85 discharge. Decreasing the separator thickness also had no effect on performance with KPF_6 .

In Table 14 initial ampere-minute capacities are determined by weight of the tape and iodimetric titration on a tape section. Electrochemical ampere-minute capacities are simply the products of current x minutes to reach the specified voltage or end of the experiment. Final ampere-minute capacities are determined by iodimetric titration on the used tape. "Loss" is the "Initial" capacity minus the total of the "Final" and "Electrochemical Total" capacities in amp-min.

Decreasing the current density from 0.10 amp/in.² to 0.05 and 0.01 amp/in.² improved voltages considerably in the Li/ KPF_6 (MF) ACL-85 system. However, the capacities are similar at all drain rates. Thus we assume that product build-up limits the capacity or that ACL-85 discharges in steps and that the product of the two-electron discharge cannot be further reduced. Increasing the carbon percentage in the cathode was as effective as lowering the current density in increasing voltages. However, the increased electrolyte volume and electrode surface area did not improve capacities.

The "Loss" column may be a loss by chemical reaction of ACL-85 with the lithium or a loss of ACL-85 by reaction with the solvent. However, the recovery of active chlorine after dissolving ACL-85 in MF makes the reaction with solvent theory unlikely. If the loss is due to chemical depolarization, then the fact that the "loss" is no greater at 0.01 amp/in.² is surprising, since the contact time is 10 times as long. The problem may be one of adsorption of products on the carbon or an inability to react the products with aqueous acidic KI solution.

The per cent utilization indicates that only one of the three chlorines are available. (Approximately the same utilization is found for the discharge of ACL-85 vs Mg in AN with AlCl_3 --Figure 10). However, the shape of the discharge curves in methyl formate would indicate a complicated reaction mechanism. Thus the reduction may not yield the Li salt, but rather may go through a series of steps from the radical intermediate shown below.







Figure 11. Discharge of the Li/ACL-85 Tape System in LiClO₄ (Methyl Formate) and KPF₆ (Methyl Formate) Electrolytes

Table 14

DISCHARGE OF Li/ACL COMPOUND TAPE CELLS IN METHYL FORMATE AT
CONSTANT CURRENT

Ref	Cathode	Electrolyte	Variation from Norm†	Capacity, amp-min.							% Utili- zation at 2 volts
				Initial	Electrochemical				Final	Loss	
					3.0v	2.5v	2.0v	Total			
337	ACL-85	LiClO ₄	-	19.3	1.8	4.5	5.4	6.9	4.0	8.4	28
308	ACL-85	LiClO ₄	-	20.3	0	1.8	3.0	6.0	4.3	10.0	15
336	ACL-85	KPF ₆	-	19.8	1.8(m)	4.2	5.2	6.3	4.3	9.2	26
301	ACL-85	KPF ₆	-	23.5	0	3.6	6.6	8.7	3.2	11.6	28
306	ACL-85	KPF ₆	1/2 sep	22.5	1.5	3.0	5.7	7.5	5.6	9.4	25
322	ACL-85	KPF ₆	1/2 I	19.1	2.4	5.2	6.2	8.3	4.6	6.2	32
338	ACL-85	KPF ₆	1/10 I	20.8	4.4	6.9	7.4	8.1	2.8	9.9	35
340	ACL-85	LiClO ₄	1/2 <u>ACL</u> <u>SAB</u>	9.8	1.2	3.3	3.6	5.1	2.4	2.3	37
341	ACL-85	KPF ₆	1/2 <u>ACL</u> <u>SAB</u>	10.4	0.9	2.4	3.3	3.9	2.7	3.8	32
313	ACL-59	LiClO ₄	-	12.5	0	3.6	5.1	6.1	2.6	3.8	41
319	ACL-59	LiClO ₄	-	8.8	0	0	3.0	4.2	3.0	1.6	34
318	ACL-59	KPF ₆	-	8.1	0	0	0	0.3	4.5	3.3	0
329	ACL-66	LiClO ₄	-	16.0	0	2.4	8.1	9.9	3.9	2.2	51
333	ACL-66	LiClO ₄	-	16.1	0	2.7	6.3	8.4	5.5	2.2	39
330	ACL-66	KPF ₆	-	14.4	0	0	0	5.4	5.7	3.3	0
335	ACL-75	LiClO ₄	-	18.9	0.9	3.9	5.4	8.1	6.0	4.8	29
334	ACL-75	KPF ₆	-	18.2	0	3.3(m)	7.2	9.9	6.2	2.1	40
342	ACL-70	LiClO ₄	-	14.8	3.0	6.3	7.2	8.7	2.0	4.1	49
343	ACL-70	KPF ₆	-	17.0	2.4(m)	3.6	6.6	11.4	1.1	4.5	39
344	ACL-70	LiClO ₄	1/2 tape wt	7.1	0.6	1.8(m)	2.4	3.2	0.3	3.6	34
345	ACL-70	LiClO ₄	1/2 I	16.4	6.0	7.7	8.7	9.5	0.1	6.8	53

† Norms = I = 0.10 amp/in.² area = 3 in.²
 Separator = 0.012 in.
 ACL/SAB = 2.12 g/g
 Cathode wt. ≈ 0.25 g/in.²

(m) reaches value via maximum

The resulting products could be high molecular weight species that are insoluble in the electrolyte and in the KI solution.

Other ACL compounds were tested to obtain better discharge, better chemical stability, lower solubility, and, in general, to gather information about discharge of ACL compounds and possible reduction products of ACL-85. Three compounds were available from Monsanto Company: ACL-59, ACL-66, ACL-75 and ACL-70. These materials were identified in an earlier section of this report.

ACL-59, the potassium salt of dichloroisocyanuric acid, is less soluble in organic electrolytes than ACL-85. Its stability is better than that of ACL-85 and it could be considered the first reaction product of ACL-85 in $\text{KPF}_6(\text{MF})$ if the reaction were the simple formation of salts of the acid.

ACL-59 was reduced at 0.10 amp/in.^2 in $\text{LiClO}_4(\text{MF})$ but not in $\text{KPF}_6(\text{MF})$. Thus we postulate that the lithium salt of dichloroisocyanuric acid is more soluble than the potassium salt, and that this increased solubility is required for discharge at this drain rate. The discharge voltage in LiClO_4 is inferior to that of ACL-85 and the per cent utilization is not greatly increased. The discharge of ACL-59, -66, and -75 are shown in Figure 12.

ACL-66 is a mixed salt of two parts ACL-59 to one part ACL-85. This material, like ACL-59, would not discharge in KPF_6 . The discharge in $\text{LiClO}_4(\text{MF})$ was more efficient than with ACL-85. However, the voltage was lower.

ACL-75 discharged with KPF_6 and with LiClO_4 in MF. The discharge potential, however, was improved by using LiClO_4 . The effect of Li^+ entering the solution was an increase of potential with increasing discharge time in the KPF_6 electrolyte system.

ACL-70 is dichloroisocyanuric acid. Its discharge is significantly superior to that of ACL-85 (see Figure 13). Approximately 50% utilization can be obtained above 2.0 volts at 0.10 or 0.05 amp/in.^2 . At 0.05 amp/in.^2 , 36% utilization is obtained above 3.0 volts. In this instance $2.0 \text{ amp-min/in.}^2$ was obtained above 3.0 volts. The weight of this tape was 0.29 g/in.^2 . Decreasing the tape weight decreased performance, similarly to that expected from increasing the current density.

3. Plans for Third Quarter (Cathode Research and Development)

The couple research phase (Task No. I) for the Mg/ACL compound system in acidic electrolyte is essentially complete. Development under Task II (Complete Cell Evaluation) will be emphasized, particularly continuous tape cell preparation and optimization of energy density output under dynamic test conditions.




Figure 12. Discharge of ACL Compounds vs Lithium in $\text{LiClO}_4(\text{MF})$ at 0.10 amp/in.²





Figure 13. Discharge of the Li/ACL-70 System in LiClO₄ (MF)

A small effort will be carried out to determine the energy density limits of Mg/ACL-Compound tape cells discharged at low current densities in neutral electrolyte.

The energy density output for Li/ACL-Compound tape cells in nonaqueous electrolyte will be optimized for the static cell configuration.

CuF_2 and AgF_2 cathodes will be tested in a tape cell configuration to determine maximum current density limits.

B. ANODE RESEARCH AND DEVELOPMENT

1. Lithium in Nonaqueous Electrolyte

a. Electrode Preparation

In addition to using a solid foil electrode, two techniques for preparing a high surface area lithium anode were screened. Half cell experiments on plating lithium* on aluminum foil showed that plating from LiClO_4 in MF was impractical. Since LiCl is insoluble in methyl formate, electrodes were prepared from LiCl in DMF. (These could then be used in a full cell with methyl formate.) The results indicated alloy formation since the potential of lithium removal was less negative than for solid lithium. The method would have to be refined for future use.

A lithium dispersion in hexane was obtained from Foote Mineral Company, and this was spread on a separator, dried, and used as an anode for the Li/LiClO_4 (MF)/ACL-85 cell. The anode OCV = 1.0 volt and the cell OCV = 0 volt, indicated chemical or electrical shorting. The resistance through the anode ($A = 3 \text{ in.}^2$, $l = 0.05 \text{ in.}$) was 50 ohms, as measured between two platinum plates. Upon drying of the MF, the lithium caught fire. Since the ACL-85 was not in contact with the Li and the combustion ash showed Cl^- , we suspect LiClO_4 was the oxidant. Using KPF_6 electrolyte we again obtained a cell OCV of zero volts.

Reversing the power supply, we needed 50 ma/in.² to obtain 4.0 volts, indicating a chemical discharge of this magnitude was occurring. The lithium dispersion experiments were discontinued at this point.

A lithium ribbon of 0.015 in. was obtained from Foote Mineral Company (packed in argon). This material was easier to process than the Fisher lithium, which had to be cut and pressed.

* Technical information was received from
P. R. Mallory on methods of plating lithium.

Without surface preparation the Foote Lithium anode was slow to reach a stable open circuit potential. Cleaning with methanol improved this situation. Cleaning with methanol and rinsing with hexane showed no further improvement. In operation in the Li/KPF₆ (MF)/ACL-85 cell all three anodes worked equally well under load. Thus Foote Mineral lithium ribbon with MeOH etch was used for the remainder of the quarter.

b. Discharge Characteristics of Lithium Half Cells in Nonaqueous Electrolyte

The screening of selected lithium-electrolyte systems in half-cells was continued, with the same electrochemical test apparatus, materials purification, and analysis as was reported last quarter. The data reported here (Table 15) are presented in a manner similar to Table 6 of Report No. 1. These data complete our lithium anode half-cell program.

The test apparatus will be used to improve full cells by controlling and studying variables in the half-cell tests or to test new electrolyte systems if any are found that warrant half-cell investigation.

The data collected in this phase have been based on systems largely suggested by other researchers in the nonaqueous battery field. However, the data were collected to determine applicability to dry tape use, where lithium stability is less important than current drain.

Methyl formate was previously shown to be a good electrolyte for lithium anodes. However, its low boiling point (31°C) is undesirable for certain practical applications. Hence ethyl-formate (bp 54°C) was tested and compared with other likely electrolyte systems. The conductivity of LiClO₄ in ethyl formate ($0.64 \times 10^{-2} \text{ ohm}^{-1}\text{cm}^{-1}$) is only half that of the methyl formate system, whereas the conductivity with KPF₆ is only $7 \times 10^{-4} \text{ ohm}^{-1}\text{cm}^{-1}$. The latter system was therefore not tested with lithium. The results indicate that LiClO₄ (ethyl formate) system might be useful for some applications.

Since there had been an indication that water improved the discharge of ACL compounds in methyl formate, the effect of water on lithium performance was studied in this electrolyte. Methyl formate/water samples from 0.065 mg H₂O/ml to 10 mg/ml were prepared and the current-voltage results showed no decreased performance. At increased water concentrations gassing increased and performance improved slightly, due to improved conductivity.

It had been observed while cleaning lithium with methanol that the gassing of lithium decreased with time. We prepared a 1.4M solution of lithium methoxide (LiOMe) in methanol and found

Table 15

LITHIUM ANODE (FREE ELECTROLYTE) HALF CELL DATA

Electrolyte System	Kx10 ² mg/ml	H ₂ O mg/ml	Gasling	Voltages (-ve vs NCE) at Various Current Densities (amps/in. ²)										IR at I Volts A/in. ²	Notes
				0	0.025	0.05	0.1	0.2	0.3	0.4	0.5	0.6	0.7		
Ethylformate-LiClO ₄ (1M)	0.64	2.1	none	3.0	2.9	2.8	2.65	2.35	2.05	1.75	1.45	0.60	0.2	0.2	No change noticed
Methylformate-NaSBF ₆ (0.27M)	0.52	0.10	none	3.15	2.80	2.65	2.5	2.3	2.1	2.0	1.9	not square	0.2	0.2	Grey coat on surface
Methylformate-MPF ₆ (0.55M)	0.72	0.3	yes	2.95	2.9	2.85	2.7	2.45	2.20	1.95	1.65	0.65	0.2	0.2	Solution turns yellow
γ-Butyrolactone-MPF ₆ (1M)	1.36	0.74	yes	3.05	3.0	3.0	2.95	2.75	2.45	falls	0.22	0.2	0.2	0.2	Loose grey film on surface
Dimethylformamide-NaSBF ₆ (0.25M)	1.2	0.26	slight	3.20	3.00	2.85	2.65	2.40	2.05	falls	0.40	0.2	0.2	0.2	Grey-black surface
Methanol-LiOMe(1.4M)	1.06	-	yes	2.60	-0.20										
Dimethylsulfoxide-LiCl(1M)	0.67	0.85	none	3.05	2.85	2.25	2.60	2.05	falls			0.7	0.2	0.2	Film formed
Methyl Formate-LiClO ₄ (1M)	1.22	0.065		3.0	2.95	2.90	2.80	2.60	2.40	2.25	2.15	0.5	0.2	0.2	
		2.0		3.0	2.95	2.90	2.80	2.60	2.45	2.30	2.20	0.5	0.2	0.2	
		3.0		3.0	2.95	2.90	2.85	2.75	2.65	2.60	2.50	0.25	0.2	0.2	
		5.0		2.95	2.95	2.90	2.80	2.70	2.55	2.40	2.20	0.3	0.2	0.2	
		7.0		3.00	2.95	2.95	2.90	2.80	2.70	2.60	2.45	0.2	0.2	0.2	
		10.0		3.00	3.0	2.95	2.90	2.80	2.70	2.55	2.40	Gas Interference			

the conductivity of the solution to be $1.06 \times 10^{-2} \text{ ohm}^{-1}\text{cm}^{-1}$. However, when lithium was tested as a half cell with this electrolyte, the lithium developed a passive coating and was ineffective as an anode.

A dry, purified sample of dimethylsulfoxide (DMSO) was made available to us from another group in our laboratory. This solvent was tested with Li and Mg to obtain a comparison to data from the first quarter's work. The conductivity of the 1M solution of LiCl was $0.67 \times 10^{-2} \text{ ohm}^{-1} \text{ cm}^{-1}$.

The other results presented in Table 15 are self explanatory; the systems were chosen to complete our screening program.

An $\text{AlCl}_3(\text{AN})$ electrolyte was prepared and was found to be too reactive for testing with lithium.

2. Magnesium in Nonaqueous Electrolyte

The experiments described in this section were performed with the same materials and equipment as for the lithium studies. In many instances the same solutions were used. Last quarter the importance of magnesium cleaning was emphasized. During this report period other etch solutions were tried. The one chosen for use is the following:

35 ml methanol
35 ml ethanol (absolute)
5 ml Ansul 141 Ether
6 g HCl (gas)
10 ml HNO_3 (98%)

This etch solution is based on patent literature (ref. 3), but it is more nearly nonaqueous than the patent etch. The etch solutions were evaluated on the LiCl (γ -butyrolactone) system. This etch solution was used for all the tests with magnesium reported in this report.

Several methanolic electrolytes were tested with magnesium to attempt to improve the voltage from that in the aqueous system. Anode gassing would also be expected to be less in methanol. The results are shown in Table 16. The oscilloscope trace of each of these tests was a square wave, indicating that, at the current density tested (0.2 amp/in.^2), the polarization was entirely due to IR loss.

In acidic electrolytes gassing was heavy and potentials were lower than in neutral or basic solutions. Acidic methanol solutions appear to offer no advantages over the aqueous electrolytes now in use in this program. In basic solution, voltages

Table 16
MAGNESIUM-NONAQUEOUS ELECTROLYTE SYSTEMS

Electrolyte System	κ $\text{ohm}^{-1}\text{cm}^{-1}$ $\times 10^4$	Gassing	Voltage vs NCE at Various Current Densities (amp/in. ²)							IR at I volts N/in. ²
			0.00	0.025	0.05	0.10	0.20	0.30	0.40	0.50
Methanol-HCl (gas)(0.1M)	1.8	v. heavy	1.93	1.89	1.87	1.80	1.65	1.51	1.32	1.19
Methanol-AlCl ₃ (0.5M)	0.84	heavy	1.94	1.90	1.83	1.73	1.52	1.29	1.07	0.82
Methanol-LiAlCl ₄ + AlCl ₃ (0.75M + 0.05M)	1.42	moderate	1.98	1.93	1.87	1.76	1.58	1.37	1.14	0.87
Methanol-LiCl (1M)	1.8	light	2.05	1.98	1.92	1.80	1.59	1.40	1.22	1.08
Methanol-LiClO ₄ (1M)	3.1	light	2.10	2.02	1.98	1.89	1.73	1.60	1.44	1.30
Methanol-LiOMe (1.4M)	1.06	slight	2.20	2.10	2.00	1.80	1.65	1.20		
Ethylformate-LiClO ₄ (1M)	0.64	none	1.72	0.96	0.50	0.15				
Methylformate-MPF ₆ *	0.72	none	1.73	0.94	0.49					
v-BL* -MPF ₆ * (1M)	1.36	none	1.63	0.91	0.65					
DMF* -NaSbF ₆ (0.25M)	1.2	none	1.51	1.0	0.87	0.64				
AN* -AlCl ₃ (1M)	2.5	none	1.86	1.75	1.61	1.49	1.42	1.30	1.06	0.80
DMSO* -LiCl (1M)	0.67	none	1.5	1.5	1.47	1.25	fails			

* v-BL = γ -butyrolactone; DMF = dimethylformamide; AN = acetonitrile; DMSO = dimethylsulfoxide
MPF₆ = morpholinium hexafluorophosphate

improve significantly. Full cell tests have been performed with the LiOMe(MeOH) system.

Even with the present etch solution used in the dry box, other nonaqueous (non-protonic) systems showed poor performance in general. Again this quarter, the slight beneficial effect of chloride ion can be seen in breaking down the passive layer. Magnesium, with these non-protonic solvents, showed a minimum voltage in the oscilloscope trace, indicating a breakdown of the passive film with continuing electrolysis (Quarterly Report No. 1).

The AlCl_3 in the AlCl_3 acetonitrile system developed by Globe Union (ref. 16) is apparently capable of breaking down the passive film on magnesium to an extent where the anode operates effectively. This system was tested in half cell, and in full cell with AlCl -compounds (see Section A2b).

In the half cell test of Mg/AlCl_3 , 1M in acetonitrile ($K = 2.55 \times 10^{-2} \text{ ohm}^{-1} \text{ cm}^{-1}$) a slight gassing and passivation of the magnesium was noticed at open circuit (peak in oscilloscope trace). The magnesium also improved with use.

3. Plans for Third Quarter (Anode Research and Development)

Lithium will continue to be used as the major nonaqueous system anode in conjunction with full cell testing of various cathodes. The foil configuration operates satisfactorily, and further anode testing will be directed to evaluating new tape anode configurations.

Thin-foil beryllium anode material, suitable for a tape configuration, will be tested in strong basic aqueous electrolyte.

III. TASK II - TAPE CELL EVALUATION

A. TAPE CELL PREPARATION

Full scale production of continuous lengths of Mg/ACL-85 tapes, scheduled for the second quarter, was postponed to complete the analysis of ACL-85 instability. A new binder system must be devised for ACL-compound tapes. Production of tape lengths suitable for dynamic testing is expected by the middle of the third quarter.

B. DYNAMIC TESTING

Complete evaluation of the Mg/ACL-85 system and other Mg/ACL-compound systems will be carried out during the third quarter. Energy density output will be optimized under these test conditions.

IV. SUPPORTING RESEARCH: TEST EQUIPMENT DESIGN AND
IMPROVEMENT

No work was required during the second quarter.

A suitable modification of the present dynamic test facility will be designed to evaluate lithium anode based nonaqueous tape systems during the third quarter.

V. REFERENCES

1. Kirk-Othmer, "Encyclopedia of Chemical Technology", Vol. 4, second edition. Interscience, N. Y. 1964, 924.
2. Ibid., Vol. 5, 15.
3. W. F. Meyers and S. G. Abends, "Development of High Energy Density Primary Batteries 200 Watt Hours per Pound Total Battery Weight Minimum", Contract NAS3-6004, Quarterly Report No. NASA CR-54659.
4. B. A. Gruber, et al. "Feasibility Proof of Dry Tape", Contract NAS3-2777, Final Report, 31 March 1964.
5. A. H. Wisken, U. S. Patent 2,849,297.
6. W. E. Elliott et al., "A Program to Develop A High-Energy Density Primary Battery with A Minimum of 200 Watt Hours Per Pound of Total Battery Weight", Contract NAS3-6015, NASA CR-54450, August 1965.

Table A-1

STATIC CELL DISCHARGE DATA FOR TRI-N-CHLOROTRIAZINETRIONE ("ACL-85") TAPE CATHODES

Cathode Composition: Tri-N-chlorotriazinetrione (Monsanto ACL-85)
 Acetylene Black (Shawinigan)--unless otherwise noted
 Binder (2.75 wt. %)--polyvinyl formal--unless otherwise noted
 Fibrous filler--1/8 in. dynel or carbon fiber

Tape Cell Area: 3 inches x 1 inch

Anode: Primary magnesium (Dow)

Separator: 4 mil dynel unless otherwise noted

Run No.	Wt. % Active Material	Theoretical Capacity amp-min/in ²	Electrolyte	Current Density amp/in. ²	Cathode Efficiency %	Operating Voltage, volts	Remarks
80401-2	65	9.5	2M AlCl ₃ -0.5M HCl	0.50	39	2.4	Nylon separator
80401-3	65	9.5	"	"	35	2.4	"
80401-8	65	10	"	"	44	2.3	Polypropylene separator
80401-9	65	8.8	"	"	39	2.4	"
80402-1	65	8.7	2M AlCl ₃ -1M HCl	"	48	2.45	Acetylene black vacuum dried for 24 hours at 200°C
80403-2	65	8.3	"	"	59	2.50	"
80403-3	65	8.7	0.5M HCl	0.67	52	2.15	"
80403-5	65	9.2	"	0.33	51	2.45	"
80403-6	65	8.7	1M HCl	0.50	54	2.45	"
80404-1	65	9.6	0.5M HCl	"	62	2.30	"
80404-5	65	7.8	"	"	61	2.35	"
80405-1	65	8.5	"	"	53	2.4	"
80405-2	65	8.5	"	"	48	2.45	Polypropylene separator
80405-5	65	10.3	"	"	50	2.40	Nylon separator
80404-2	65	8.5	"	0.67	44	2.00	"
80404-3	65	10	1M HCl	0.50	50	2.35	"
80404-4	65	10.1	"	"	50	2.30	"
80404-6	65	8.5	0.5M HCl	0.33	42	2.40	"
80407-1	70	8.9	"	0.50	54	2.20	Acetylene black vacuum dried for 20 hours at 200°C
80407-2	70	11.4	"	0.67	51	2.05	"
80407-3	70	9.0	1M HCl	0.33	44	2.30	"
80408-1	65	9.0	0.5M HCl	0.50	50	2.35	30 hours at 185°C
80408-2	65	10.5	"	0.67	50	2.05	"
80408-3	65	8.9	"	0.33	59	2.45	"
80408-4	65	8.9	1M HCl	0.50	55	2.35	"
80408-5	65	8.1	"	0.33	54	2.45	"
80408-6	65	8.9	"	0.67	51	2.15	"
80410-1	65	8.1	0.5M HCl	0.50	50	2.05	Polypropylene separator-Acetylene black preground
80412-3	50	6.7	0.5M HCl	0.67	34	1.85	Polypropylene separator-poor wetting
80412-4	50	7.0	"	0.50	54	2.10	"
80412-5	50	6.6	"	0.50	45	2.20	"
80414-1	65	11	"	0.50	57	2.35	"
80414-2	65	10.7	"	0.67	54	2.25	"
80415-1	65	10	"	0.50	56	2.40	"

Table A-1 (continued)

Run No.	Wt. % Active Material	Theoretical Capacity amp-min/in. ²	Electrolyte	Current Density amp/in. ²	Cathode Efficiency %	Operating Voltage, volts	Remarks
80415-2	65	13	2M AlCl ₃ ·0.5M HCl	0.67	57	2.20	
80414-4	65	12.1	" 1M HCl	0.50	48	2.45	
80414-5	65	12.2	" 0.5M HCl	0.67	49	2.30	9.7% active chlorine analysis after discharge
80415-3	65	13.3	" 1M HCl	0.50	49	2.35	4.1% active chlorine analysis after discharge
80418-1	65	7	2M AlCl ₃ ·0.5M HCl	0.50	56	2.15	5% active chlorine analysis after discharge
80418-2	65	11.5	" 1M HCl	0.67	54	2.20	
80418-3	65	3.4	2M LiClO ₄	0.33	56	1.65	
80418-9	65	9.8	"	0.17	44	1.75	
80418-10	65	16.1	1.5M AlCl ₃ ·0.7M HCl	0.50	62	2.20	
			·0.5M LiClO ₄				
80421-1	65	8.3	1M AlCl ₃ ·1M LiClO ₄	0.17	74	2.55	
			·0.5M HCl				
80421-3	65	11.0	2M AlCl ₃ ·1M HCl	0.67	46	2.20	
80421-4	65	9.6	1M AlCl ₃ ·1M LiClO ₄	0.50	64	2.30	
			·0.5M HCl				
80421-6	65	7.2	1M AlCl ₃ ·1M LiClO ₄	0.50	69	2.35	
			·0.5M HCl				
80423-1	65	4.0	1M AlCl ₃ ·1M LiClO ₄	0.17	72	2.50	
			·0.5M HCl				
80423-2	65	4.0	2M AlCl ₃ ·1M HCl	0.33	53	2.50	
80423-3	65	8.1	1.5M AlCl ₃ ·0.5M LiClO ₄ ·0.5M HCl	0.50	72	2.30	
80423-4	65	6.5	1M AlCl ₃ ·1M LiClO ₄	0.33	68	2.30	
			·0.5M HCl				
80423-5	65	6.9	1.5M AlCl ₃ ·0.5M LiClO ₄ ·0.5M HCl	0.50	66	2.40	
80423-7	65	5.8	1.5M AlCl ₃ ·0.5M LiClO ₄ ·0.5M HCl	0.33	68	2.40	
80423-9	65	6.5	2M AlCl ₃ ·0.5M HCl	0.33	50	2.40	
80423-10	65	4.3	1M AlCl ₃ ·1M LiClO ₄	0.33	58	2.20	
			·0.5M HCl				
80426-1	60	3.4	1M AlCl ₃ ·1M LiClO ₄	0.17	75	2.40	
			·0.5M HCl				
80426-2	60	6.8	1M AlCl ₃ ·1M LiClO ₄	0.50	64	2.30	
			·0.5M HCl				
80426-3	60	7.4	1.5M AlCl ₃ ·0.5M LiClO ₄ ·0.5M HCl	0.50	69	2.35	
80426-4	60	5.5	1M AlCl ₃ ·1M LiClO ₄	0.50	74	2.25	
			·0.5M HCl				
80426-7	60	5.3	1M AlCl ₃ ·1M LiClO ₄	0.50	49	2.30	
			·0.5M HCl				
80426-9	60	3.3	1M AlCl ₃ ·1M LiClO ₄	0.17	69	2.30	
			·0.5M HCl				
80429-1	70	6.2	2M AlCl ₃ ·1M HCl	0.50	57	2.25	
80429-2	70	6.1	2M AlCl ₃ ·0.5M HCl	0.50	66	2.20	
80429-3	70	7.4	1.5M AlCl ₃ ·0.5M LiClO ₄ ·0.5M HCl	0.50	55	2.10	
80429-4	70	6.2	2M LiClO ₄	0.50	did not	maintain 2.00 volts	
80429-8	70	4.6	1M AlCl ₃ ·1M LiClO ₄	0.50	bb	2.10	
			·0.5M HCl				

Table A-1 (continued)

Run No.	Wt. % Active Material	Theoretical Capacity, ^a amp-min/in. ²	Electrolyte	Current Density, ^a amp/in. ²	Cathode Efficiency, %	Operating Voltage, volts	Remarks
80429-9	70	5.6	1.5M AlCl ₃ ·0.5M LiClO ₄ ·0.5M HCl	0.50	63	2.10	
80429-10	70	7.6	1M AlCl ₃ ·1M LiClO ₄ ·1M HCl	0.67	38	2.00	
80481-1	67.5	4.9	2M AlCl ₃ ·0.5M HCl	0.50	57	2.25	
80431-2	67.5	4.4	1M AlCl ₃ ·1M LiClO ₄ ·0.5M HCl	0.50	58	2.10	
80431-3	67.5	6.0	2M AlCl ₃ ·1M HCl	0.50	44	2.30	
80431-4	67.5	4.9	1.5M AlCl ₃ ·0.5M LiClO ₄ ·0.5M HCl	0.50	58	2.25	
80431-5	67.5	5.4	1M AlCl ₃ ·1M LiClO ₄ ·0.5M HCl	0.50	61	2.15	
80431-6	67.5	5.8	1.5M AlCl ₃ ·0.5M LiClO ₄ ·0.5M HCl	0.50	65	2.25	
80431-7	67.5	5.4	1.5M AlCl ₃ ·0.5M LiClO ₄ ·0.6M HCl	0.50	55	2.20	
80436-1	65	5.6	1M AlCl ₃ ·1M LiClO ₄ ·0.3M HCl	0.50	63	2.10	Tested immediately after drying
80436-2	65	6.6	2M AlCl ₃ ·0.5M HCl	0.50	44	2.35	Tested after 24 hours in desiccator
80436-3	65	5.3	1M AlCl ₃ ·1M LiClO ₄ ·0.3M HCl	0.50	68	2.25	Tested after 24 hours in desiccator
80436-7	65	5.3	2M AlCl ₃ ·0.5M HCl	0.50	42	2.35	Tested after 24 hours standing in air
80436-10	65	8.7	1M AlCl ₃ ·1M LiClO ₄ ·0.3M HCl	0.50	57	2.10	Tested after 24 hours standing in air
80439-1	65	4.2	2M LiClO ₄	0.50	28	1.72	
80439-2	65	4.8	2M AlCl ₃	0.50	72	2.20	
80439-3	65	5.9	1.5M AlCl ₃ ·0.5M LiClO ₄	0.50	75	2.20	
80439-4	65	6.2	1.5M LiClO ₄ ·0.5M AlCl ₃	0.50	35	1.90	
80439-5	65	5.9	1M AlCl ₃ ·1M LiClO ₄	0.50	55	1.95	
80439-6	65	4.1	1.5M AlCl ₃ ·0.5M LiClO ₄	0.50	63	2.00	4 cc electrolyte used (Added by pipet)
80439-8	65	4.1	1.5M AlCl ₃ ·0.9M LiClO ₄	0.50	54	2.00	2 cc electrolyte used
80439-9	65	4.5	1.1M AlCl ₃ ·0.5M LiClO ₄	0.50	70	2.15	excess electrolyte used
80439-10	65	8.0	1.5M AlCl ₃ ·0.5M LiClO ₄	0.50	72	2.15	7 cc electrolyte used
80442-1	65	4.6	1.5M AlCl ₃ ·0.5M LiClO ₄	0.50	59	2.10	5 cc electrolyte
80442-2	65	4.3	1.5M AlCl ₃ ·0.5M LiClO ₄	0.50	71	2.10	6 cc electrolyte
80442-4	65	3.4	1M AlCl ₃ ·1M MgCl ₂	0.50	67	2.15	6 cc electrolyte
80442-5	65	4.3	2M AlCl ₃	0.50	67	2.15	10 cc electrolyte
80442-6	65	9.6	2M AlCl ₃ ·0.5M HCl	0.50	63	2.40	excess electrolyte
80442-7	65	4.5	2M AlCl ₃ ·0.1M HCl	0.50	51	2.30	excess electrolyte
80442-8	65	5.4	1.5M AlCl ₃ ·0.5M LiClO ₄	0.50	73	2.10	8 cc electrolyte
80442-9	65	6.7	1.5M AlCl ₃ ·0.5M LiClO ₄	0.50	76	2.20	10 cc electrolyte

Table A-1 (continued)

Run No.	Wt. % Active Material	Theoretical Capacity amp-min/in. ²	Electrolyte	Current Density amp/in. ²	Cathode Efficiency %	Operating Voltage, volts	Remarks
80442-10	65	3.9	1.5M AlCl ₃ ·0.5M MgCl ₂	0.50	69	2.25	12 cc electrolyte
80445-1	65	6.9	1.5M AlCl ₃ ·0.5M MgCl ₂	0.50	80	2.20	8 cc electrolyte--tested immediately after drying
80445-2	65	7.1	1.5M AlCl ₃ ·0.5M MgCl ₂	0.50	83	2.10	9 cc electrolyte--tested after 24 hours under vacuum
80445-3	65	7.6	1.5M AlCl ₃ ·0.5M MgCl ₂	0.50	75	2.15	4 cc electrolyte
80445-4	65	6.7	1M AlCl ₃ ·1M MgCl ₂	0.50	76	2.10	6 cc electrolyte
80445-5	65	6.1	1.5M MgCl ₂ ·0.5M AlCl ₃	0.50	42	1.90	8 cc electrolyte
80445-6	65	6.9	2M AlCl ₃	0.50	73	2.20	6 cc electrolyte
80445-7	65	4.7	1.8M AlCl ₃ ·0.2M MgCl ₂	0.50	76	2.15	
80445-8	65	6.1	2M MgCl ₂	0.50	31	1.80	
80445-9	65	8.6	2M AlCl ₃ ·0.5M HCl	0.50	58	2.30	
80445-10	65	10.0	PH-4 buffer-CH ₃ COOH, 0.50 CH ₃ COONa	0.50	Ran for a few minutes between 2.00 and 1.50 volts		
80450-1	65	7.4	1.5M AlCl ₃ ·0.5M MgCl ₂	0.50	81	2.30	
80450-2	65	8.2	1.3M AlCl ₃ ·0.7M MgCl ₂	0.50	77	2.20	
80450-3	65	7.4	2M AlCl ₃	0.50	79	2.35	Tested after 84 hours air storage
80450-4	65	6.1	1M AlCl ₃ ·1M MgCl ₂	0.50	84	2.20	Tested after 84 hours air storage
80450-5	65	7.4	1.3M MgCl ₂ ·0.7M AlCl ₃	0.50	65	2.00	
80450-6	65	5.1	1M AlCl ₃ ·1M MgCl ₂	0.67	78	1.90	
80450-7	65	6.2	1.5M AlCl ₃ ·0.5M MgCl ₂	0.67	80	2.20	
80450-8	65	5.0	2M MgCl ₂	0.17	54	1.80	
80450-9	65	8.0	2M AlCl ₃ ·1M HCl	0.50	60	2.35	
80450-10	65	8.4	2M AlCl ₃ ·0.5M HCl	0.50	65	2.35	
80455-1	65	11.9	2M MgCl ₂	0.05	59	2.10	
80455-10	65	19.7	2M AlCl ₃ ·0.5M HCl	0.83	56	2.30	
80455-11	65	20.6	1.5M AlCl ₃ ·0.5M MgCl ₂	0.83	82	2.10	
80455-12	65	18.3	1.5M AlCl ₃ ·0.5M MgCl ₂	0.83	74	2.10	
80455-13	65	21.3	1.5M AlCl ₃ ·0.5M MgCl ₂	1.0	71	1.95	
80455-14	65	20	1.5M AlCl ₃ ·0.5M MgCl ₂	0.5	72	2.30	
80455-15	65	19.5	1.5M AlCl ₃ ·0.5M MgCl ₂	0.67	76	2.30	8 cc electrolyte used
80455-16	65	19.7	2M AlCl ₃ ·0.5M HCl	0.50	71	2.30	
80455-17	65	22.1	1.3M AlCl ₃ ·0.7M MgCl ₂	0.67	77	2.10	
80455-18	65	23.9	1M AlCl ₃ ·1M MgCl ₂ ·0.25M HCl	0.50	73	2.25	

Table A-1 (continued)

Run No.	Wt. % Active Material	Theoretical Capacity, amp-min/in. ²	Electrolyte	Current Density, amp/in. ²	Cathode Efficiency %	Operating Voltage, volts	Remarks
80455-19	65	22.2	1M AlCl ₃ ·1M MgCl ₂	0.67	54	2.00	8 cc electrolyte used
80455-20	65	26	1.5M AlCl ₃ ·0.5M MgCl ₂	1.00	67	2.00	
80460-1	70	17.5	2M AlCl ₃ ·0.5M HCl	0.67	55	2.15	
80460-3	70	19	1.5M AlCl ₃ ·0.5M MgCl ₂	0.67	71	2.10	
80477-1	65	4.7	2M MgCl ₂	0.17	50	1.95	
80477-2	65	5.6	2M AlCl ₃ ·0.5M HCl	0.50	60	2.25	
80477-3	65	5.9	2M Mg(ClO ₄) ₂	0.17	43	1.90	
80477-4	65	10.8	1.5M AlCl ₃ ·0.5M MgCl ₂	0.50	75	2.10	
80477-5	65	14.8	2M AlCl ₃	0.67	83	2.20	
80477-6	65	10.0	2M MgBr ₂	0.17	63	1.90	
80477-7	65	10.0	2M AlCl ₃ ·0.5M HCl	1.00	46	1.80	
80477-8	65	11.7	1.5M AlCl ₃ ·0.5M MgCl ₂	0.50	61	2.15	
80477-9	65	11.2	2M AlCl ₃	0.67	53	2.05	
80477-12	65	14.3	1.5M AlCl ₃ ·0.5M MgCl ₂	1.00	48	1.60	
80482-1	65	9.8	2M AlCl ₃	0.50	68	2.35	No binder (PVF) No binder (PVF)
80482-5	65	11.7	1.5M AlCl ₃ ·0.5M MgCl ₂	0.67	67	2.20	
80482-6	65	8.8	2M AlCl ₃ ·0.5M HCl	0.67	56	2.20	No binder (PVF) No binder (PVF)
80482-2	65	10.3	2M AlCl ₃ ·0.5M HCl	0.50	79	2.40	
80482-3	65	14.8	1.3M AlCl ₃ ·0.7M MgCl ₂	0.50	75	2.20	No binder (PVF) No binder (PVF)
80482-4	65	12.2	2M AlCl ₃ ·0.5M HCl	0.67	50	2.10	
80482-7	65	7.4	2M MgCl ₂	0.17	75	2.00	No binder (PVF) No binder (PVF)
80482-10	65	4.7	2M MgBr ₂	0.05	68	2.10	
80482-11	65	7.2	1.3M AlCl ₃ ·0.7M MgCl ₂	0.33	75	2.45	No binder (PVF)

Table A-2
STATIC CELL DISCHARGE DATA FOR ACL COMPOUND TAPE CATHODES

Cathode Formulation: Identical to that for ACL-85 in Table A-1
Anode: Primary Magnesium (Dow)
Cell Area: 3 inches by 1 inch

Run No.	Active Material	Wt. % Active Material	Theoretical Capacity amp-min/in. ²	Electrolyte	Current Density amp/in. ²	Cathode Efficiency %	Operating Voltages volts	Remarks
80466-1	ACL-59	65	4.3	2M AlCl ₃	0.50	fell below 1.5 volts after 2 minutes		
80466-2	"	"	7.1	2M MgCl ₂	"	fell below 1.0 volt immediately		
80466-4	"	"	8.7	2M AlCl ₃ -0.5M HCl	"	46	2.10	Sharp dip to 1.6 v initially
80466-6	"	"		CH ₃ COOH, CH ₃ COONa buffer	"	fell below 1.0 volt immediately		
80466-7	"	"	10.1	1.5M AlCl ₃ -0.5M MgCl ₂	"	53	2.10	
80466-10	"	"	10.2	"	"	51	2.15	
80483-1	ACL-75	"	5.8	2M AlCl ₃ -0.5M HCl	"	71	2.15	
80483-2	"	"	8.6	2M MgBr ₂	0.05	47	2.05	
80483-9	"	"	6.2	2M MgCl ₂	0.17	75	2.20	
80483-10	"	"	6.6	"	"	77	1.90	
80484-2	ACL-66	"	8.2	1.5M AlCl ₃ -0.5M MgCl ₂	0.50	50	1.75	
80484-7	"	"	6.8	"	"	25	1.75	
80484-11	"	"	8.2	2M MgBr ₂	0.05	56	2.10	
80486-1	"	"	7.1	1.5M MgCl ₂ -0.5M AlCl ₃	0.05	75	2.15	No binder
80486-2	"	"	8.8	2M MgBr ₂	0.33	70	2.00	"
80486-3	"	"	9.0	1.5M AlCl ₃ -0.5M MgCl ₂	0.05	60	2.05	"
80486-4	"	"	4.0	"	0.50	67	2.30	"
80486-5	"	"	9.1	2M MgCl ₂	0.17	78	1.90	"

DISTRIBUTION LIST

Contract NAS3-7624

National Aeronautics + Space Administration
Washington, D. C. 20546
Attention: E. M. Cohn, Code RNW
A. M. Greg Andrus, Code FC
J. R. Miles, Code SL

National Aeronautics + Space Administration
Goddard Space Flight Center
Greenbelt, Maryland 20771
Attention: Thomas Hennigan, Code 632.2
Joseph Sherfey, Code 652
Paul Donnelly, Code 636.2
E. R. Stroup, Code 636.2

National Aeronautics + Space Administration
Lewis Research Center
21000 Brookpark Road
Cleveland, Ohio 44135
Attention: Library - Mail Stop 3-7
N. D. Sanders - Mail Stop 302-1
J. E. Dilley - Mail Stop 500-309
R. L. Cummings - Mail Stop 500-201
B. Lubarsky - Mail Stop 500-201
H. J. Schwartz - Mail Stop 500-201
W. J. Nagle - Mail Stop 500-201
(2 copies)
M. J. Saari - Mail Stop 500-202
J. J. Weber - Mail Stop 3-16
R. R. Miller - Mail Stop 500-202
Report Control - Mail Stop 5-5
*V. F. Hlavin - Mail Stop 3-14

National Aeronautics + Space Administration
Scientific + Technical Information Facility
P. O. Box 5700
Bethesda 14, Maryland
Attention: NASA Representative
(2 plus 1 reproducible)

National Aeronautics + Space Administration
Marshall Space Flight Center
Huntsville, Alabama 35812
Attention: Philip Youngblood
Richard Boehme - Bldg. 4487-BB
M-ASTR-EC

*Final Report Only

U.S. Army Research Office
Box CM, Duke Station
Durham, North Carolina
Attention: Paul Greer
Dr. Wilhelm Jorgensen

U.S. Army Research Office
Chief, Rand D.
Department of the Army
3D442, The Pentagon
Washington, D. C. 20546
Attention: Dr. Sidney J. Mangram

U.S. Army Mobility Command
Research Division
Center Line, Michigan 48090
Attention: O. Renius (AMSMO-RR)

National Aeronautics + Space Administration
Manned Spacecraft Center
Houston, Texas 77058
Attention: William R. Dusenbury
Propulsion + Energy Systems Br.
Bldg. 16, Site 1
Robert Cohen, Gemini Project Off.
Richard Ferguson (EP-5)
James T. Kennedy (EE-5)
Forrest E. Eastman (EE-4)

National Aeronautics + Space Administration
Ames Research Center-Pioneer Project
Moffett Field, California 94035
Attention: James R. Swain
A. S. Hertzog
Jon Rubenzer-Biosatellite Proj.

National Aeronautics + Space Administration
Jet Propulsion Laboratory
4800 Oak Grove Drive
Pasadena, California 91103
Attention: Aiji Uchiyama

U.S. Army Engineer R + D Labs.
Fort Belvoir, Virginia 22060
Attention: Dr. Galen Frysinger
Electrical Power Branch
SMOFB-EP

U.S. Army Engineer R + D Labs.
Fort Monmouth, New Jersey
Attention: David Linden (Code SELRA/PS)
U.S. Army R + D Liaison Group (9851 DV)
APO 757
New York, New York
Attention: B. R. Stein

Commanding Officer
U.S. Army Electronics R + D Labs.
Fort Monmouth, New Jersey 07703
Attention: Power Sources Division

Research Office
Rand D. Directorate
Army Weapons Command
Rock Island, Illinois
Attention: Mr. G. Riensmith, Chief

Army Materiel Command
Research Division
AMCRD-RSCM-T-7
Washington, D. C.
Attention: John W. Crellin

U.S. Army TRECOM
Fort Eustis, Virginia 23604
Attention: Leonard M. Bartone (SMOFE-ASE)

Office of the Deputy Commander AFSC for
Aerospace Systems
U.S.A.F.
Los Angeles 45, California
Attention: W. J. Bennison

Headquarters, U.S. Army Materiel Command
Development Division
Washington 25, D. C.
Attention: Marshall D. Aiken (AMCRD-DE-MO-P)

A.F. Cambridge Research Lab.
L. G. Hanscom Field
Bedford, Massachusetts
Attention: Francis X. Doherty

Headquarters, USAF (AFRDR-AS)
Washington, D. C.
Attention: MAJ G. Starkey

National Bureau of Standards
Washington 25, D. C.
Attention: Dr. W. J. Hamer

Office, DDR + E, USW + BSS
The Pentagon
Washington, D. C.
Attention: G. B. Wareham

U.S. Atomic Energy Commission
Auxiliary Power Branch (SNAP)
Division of Reactor Development
Washington 25, D. C.
Attention: LT COL George H. Ogburn, Jr.

LT COL John H. Anderson
Advanced Space Reaction Branch
Division of Reactor Development
U.S. Atomic Energy Commission
Washington 25, D. C.

Mr. Donald B. Hoatson
Army Reactor, DRD
U.S. Atomic Energy Commission
Washington 25, D. C.

Institute for Defense Analyses
R + E Support Division
400 Army-Navy Drive
Arlington, Virginia 22202
Attention: Mr. R. Hamilton
Dr. George C. Szego

Office of Naval Research
Washington, D. C. 20360
Attention: Dr. Ralph Roberts, Code 429
Head, Power Branch
H. W. Fox, Code 425

Naval Research Laboratory
Washington, D. C. 20390
Attention: Dr. J. C. White, Code 6160

Bureau of Naval Weapons
Department of the Navy
Washington, D. C.
Attention: Whitewell T. Beatson
(Code RAAE-52)
Milton Knight
(Code RAAE-50)

Naval Ammunition Depot
Crane, Indiana
Attention: E. Bruess
H. Schultz

Atomics International Division
North American Aviation, Inc.
Canoga Park, California
Attention: Dr. H. L. Recht

Flight Vehicle Power Branch
Air Force Aero Propulsion Laboratory
Wright-Patterson Air Force Base, Ohio
Attention: J. E. Cooper

Rome Air Development Center, ESD
Griffiss AFB, New York 13442
Attention: Commander, RAALD

Naval Ordnance Laboratory
Department of the Navy
Corona, California
Attention: William C. Spindler
(Code 441)

Naval Ordnance Laboratory
Department of the Navy
Silver Spring, Maryland
Attention: Philip B. Cole (Code WB)

Bureau of Ships
Department of the Navy
Washington, D.C.
Attention: C. F. Viglotti (Code 660)
Bernard B. Rosenbaum (Code 340)

Natick Labs.
Clothing and Organic Materials Div.
Natick, Mass.
Attention: Robert N. Walsch
G. A. Spano

Power Information Center
University of Pennsylvania
Moore School Bldg.
200 South 33rd St.
Phil. 4, Pa.

Office of Technical Services
Department of Commerce
Washington 25, D. C. 20009

Aerojet-General Corporation
Chemical Products Div.
Azusa, California
Attention: Dr. S. O. Rosenberg

Aeronutronic Div.
Philco Corporation
Ford Road
Newport Beach, California
Attention: Dr. S. W. Weller

Aerospace Corporation
P. O. Box 95085
Los Angeles 45, California
Attention: Library

Allis Chalmers Manufacturing Co
1100 South 70th St.
Milwaukee 1, Wisconsin
Attention: Dr. Joyner

American University
Massachusetts and Nebraska Avenues, N.W.
Washington, D. C. 200016
Attention: R. T. Foley, Chemistry Dept.

Arthur D. Little, Inc.
Cambridge, Mass. 02140
Attention: Library
Dr. Ellery W. Stone

Battelle Memorial Institute
505 King Avenue
Columbus, Ohio 43201
Attention: Dr. C. L. Faust

Bell Laboratories
Murray Hill, New Jersey
Attention: U. B. Thomas
David A. Feder

The Boeing Company
Seattle, Washington
Attention: Dr. Theodore Beck

Borden Chemical Company
Central Research Lab.
P. O. Box 9524
Phil. 24, Pa.

Burgess Battery Company
Freeport, Ill.
Attention: Dr. Howard J. Strauss

C + D Batteries
Division of Electric Autolite Company
Conshohocken, Pa.
Attention: Dr. Eugene Willihnganz

Calvin College
Grand Rapids, Michigan
Attention: Prof. T. P. Dirkse

Catalyst Research Corporation
6101 Falls Road
Baltimore 8, Maryland
Attention: J. P. Wooley

Delco Remy Division
General Motors Corporation
Anderson, Indiana
Attention: Dr. J. J. Lander

Douglas Aircraft Company, Inc.
Astropower Laboratory
2121 Paularino Avenue
Newport Beach, California
Attention: Dr. Carl Berger

Dynatech Corporation
17 Tudor St.
Cambridge, Mass.
Attention: R. L. Wentworth

Eagle-Picher Company
Post Office Box 290
Joplin, Missouri
Attention: E. M. Morse

Elgin National Watch Co.
107 National St.
Eglin, Ill.
Attention: T. Boswell

Electric Storage Battery Company
Missile Battery Division
Raleigh, North Carolina
Attention: A. Chreitzberg

Electric Storage Battery Company
Carl F. Norberg Res. Center
Yardley, Pa.
Attention: Dr. R. A. Schaefer

Electrochimica Corporation
1140 O'Brien Drive
Menlo Park, California
Attention: Dr. Morris Eisenberg

Electro-Optical Systems, Inc.
300 North Halstead
Pasadena, California
Attention: E. Findl

Emhart Manufacturing Co.
Box 1630
Hartford, Conn.
Attention: Dr. W. P. Cadogan

Engelhard Industries, Inc.
497 DeLancy St.
Newark, New Jersey
Attention: Dr. J. G. Cohn

Dr. Arthur Fleischer
466 South Center St.
Orange, New Jersey

General Electric Co.
Schenectady, New York
Attention: Dr. William Carson
Advanced Technology Lab.

General Electric Co.
Missile and Space Div.
Spacecraft Dept.
P.O. Box 8555
Phil., Pa.
Attention: E. W. Kipp, Room T-2513

General Electric Co.
Battery Products Section
P.O. Box 114
Gainesville, Florida

General Electric Co.
Res. Labs.
Schenectady, New York
Attention: Dr. H. Lebhafsky

General Motors-Defense Res. Labs.
P.O. Box T
Santa Barbara, California
Attention: Dr. J. S. Smatko
Dr. C. R. Russell

Globe-Union, Inc.
900 East Keefe Ave.
Milwaukee, Wisconsin
Attn: Dr. Warren Towle
Dr. C. K. Morehouse

Gould-National Batteries, Inc.
Engineering and Res. Center
2630 University Ave, S.E.
Minneapolis 14, Minnesota
Attention: J. F. Donahue

Culton Industries
Alkaline Battery Div.
Metuchen, New Jersey
Attention: Dr. Robert Shain

Hughes Aircraft Corp.
Culver City, California
Attention: T. V. Carvey

Hughes Research Labs., Corp.
Malibu, California
Attention: T. M. Hahn

ITT Research Institute
10 West 35th St.
Chicago, Ill.
Attention: Dr. H. T. Francis

Inland Testing Labs.
Dayton, Ohio
Attention: W. Ingling

ITT Federal Labs.
500 Washington Ave.
Nutley 10, New Jersey
Attention: Dr. P. E. Lighty

Johns Hopkins University
Applied Physics Lab.
8621 Goerge Ave.
Silver Spring, Maryland
Attention: Richard Cole

Leesona Moos Labs.
Lake Success Park, Community Drive
Great Neck, New York 11021
Attention: Dr. H. Oswin

Livingston Electronic Corporation
Route 309
Montgomeryville, Pa.
Attention: William F. Meyers

Lockheed Missiles + Space Co.
Dept. 52-30
Palo Alto, California
Attention: J. E. Chilton
Larry Nelson

Magna Corporation
Division of TRW, Inc.
101 South East Ave
Anaheim, California
Attention: Dr. G. Rohrbach

Mallory Battery Company
60 Elm St.
North Tarrytown, New York
Attention: R. R. Clune

Marquardt Corporation
16555 Saticoy St.
Van Nuys, California
Attention: Dr. H. G. Krull

Material Res. Corporation
Orangeburg, New York
Attention: V. E. Adler

Metals and Controls Division
Texas Instruments, Inc.
34 Forest St.
Attleboro, Mass.
Attention: Dr. E. M. Jost

Midwest Res. Inst.
425 Volker Blvd.
Kansas City, Missouri
Attention: Dr. B. W. Beadle

Motorola, Inc.
9201 McDowell Road
Scottsdale, Arizona 85252
Attention: Mr. J. J. Fenner

North American Aviation, Inc.
Rocketdyne Division
6633 Canoga Ave.
Canoga Park, California

North American Aviation, Inc.
1221 Lakewood Blvd.
Downey, California
Attention: Burton M. Otzinger

Dr. John Owen
P. O. Box 87
Bloomfield, New Jersey

P. R. Mallory and Co., Inc.
Technical Services Lab.
3029 E. Washington St.
Indianapolis, Indiana 46206
Attention: A. S. Doty
Technical Librarian

P. R. Mallory and Co., Inc.
Northwest Industrial Park
Burlington, Mass.
Attention: Dr. R. Selim
Dr. Per Bro

Power Sources Division
Whittaker Corp.
9601 Canoga Ave.
Chatsworth, California 91311
Attention: Dr. W. Shaw

Power Sources Division
Whittaker Corp.
P. O. Box 337
Newbury Park, California
Attention: Mr. John Rhyme

Power Sources Division
Whittaker Corp.
Denver, Colorado
Attention: Borch Wendir

Philco Corp.
Division of the Ford Motor Co.
Blue Bell, Pa.
Attention: Dr. Phillip Cholet

Radiation Applications, Inc.
36-40 37th St.
Long Island City, New York
Attention: Monroe Pofcher

Radio Corporation of America
Astro Division
Heightstown, New Jersey
Attention: Seymour Winkler

Radio Corporation of America
P.O. Box 800
Princeton, New Jersey
Attention: I. Shulman

Space Technology Labs., Inc.
One Space Park
Redondo Beach, California
Attention: Dr. A. Krausz

Southwest Research Institute
8500 Culebra Road
San Antonio 6, Texas
Attention: Dr. Jan Al

Tyco Labs., Inc.
Bear Hill
Waltham, Mass.
Attention: W. W. Burnett

Sonotone Corp.
Saw Mill River Road
Elmsford, New York
Attention: A. Mundel

Texas Instruments, Inc.
13500 North Central Expressway
Dallas, Texas
Attention: Dr. Isaac Trachtenberg

Thomas A. Edison Res. Lab.
McGraw Edison Co.
Watchung Ave.
West Orange, New Jersey
Attention: Dr. P. F. Grieger

Thompson Ramo Wooldridge, Inc.
23555 Euclid Ave.
Cleveland, Ohio 44117
Attention: Librarian

Union Carbide Corp.
Development Lab. Library
P.O. Box 6065
Cleveland, Ohio 44101
Attention: Miss C. M. Foecking
M. S. Wright-Library

University of California
Space Science Lab.
Berkeley 4, California
Attention: Dr. C. W. Tobias

University of Pa.
Electrochemistry Laboratory
Philadelphia, Pennsylvania
Attention: Prof. J. O'M. Bockris

Western Co.
Suite 803, RCA Building
Washington, D. C.
Attention: R. J. Fiske

Westinghouse Electric Corp.
Res. and Development Center
Churchill Borough
Pittsburgh, Pennsylvania
Attention: Dr. A. Langer

Yardney Electric Corporation
40-50 Leonard Street
New York, New York
Attention: Dr. Paul Howard