QUARTERLY PROGRESS REPORT

PROGRAM TO DEVELOP AN INORGANIC SEPARATOR FOR A HIGH TEMPERATURE SILVER-ZINC BATTERY

by

C. Berger, F. C. Arrance, A. D. Taylor, and A. Himy

prepared for

NATIONAL AERONAUTICS AND SPACE ADMINISTRATION

March 1966

CONTRACT NAS 3-7639

Technical Management
NASA Lewis Research Center
Cleveland, Ohio
Solar and Chemical Power Branch
Daniel G. Soltis

MISSILE & SPACE SYSTEMS DIVISION
ASTROPOWER LABORATORY
Douglas Aircraft Company, Inc.
Newport Beach, California

FOREWORD

This report was prepared under Project Work Order Number 177091-01, and covers the period October 29, 1965 through January 29, 1966. The research, development and testing activities discussed herein are sponsored by Lewis Research Center, National Aeronautics and Space Administration, Cleveland, Ohio, under Contract NAS 3-7639.

SM-48461-Q2 ii

TABLE OF CONTENTS

				Page			
FORE	EWORE)		ii			
1.0	INTE	INTRODUCTION AND SUMMARY					
2.0	TEC	HNICAL	DISCUSSION	8			
	2.1	TASK I	- Design of Multiplate 5 AH Cell	8			
		2.1.1 2.1.2 2.1.3	Grooved Cell Case Grooved Frame Cell Design Molded Cases	8 8 9			
	2.2		I - Fabrication, Testing and Evaluation of emponents	10			
		2.2.1	Electrodes	10			
			2.2.1.1 Case Configuration 2.2.1.2 Testing	10 13			
		2.2.2 2.2.3 2.2.4 2.2.5	Inorganic Separator Cases Terminals Connections and Current Collectors	21 23 30 30			
	2.3	Summa	ry of Results and Conclusions	31			
3.0	WOF	RK PLAN	NED	34			
		TASK I	- Design of a Multiplate 5 AH Cell I - Fabrication, Testing and Evaluation of emponents (Single Electrode Cell)	34 34			
		3.2.1 3.2.2 3.2.3 3.2.4 3.2.5 3.2.6 3.2.7	Electrodes Separators Case Terminal Connections Electrolyte Multiplate Cells	34 34 34 34 35 35			
4.0	PER	SONNEL	ı.	36			
REFI	ERENC	ES		37			

LIST OF ILLUSTRATIONS

Figure		Page
1	Cell Assembly	2
2A	Case, Cell	3
2B	Cover, Cell	4
3	Frame E and E', Separator and Electrode	5
4	Assembly, Cell Terminal	6
5	Assemblies, Terminal and Valve, Cell	7
6	Case, Test Cell, 177091-01-BE (ESC Type)	11
7	Single Electrode Test Case With 2-Separator Grooved Frame (ESC-B Type)	12
8	Charge-Discharge Curves Multiplate Silver-Zinc Test Cell Number MC-2 Cycling at Room Temperature at a Test Regime of 30-Minute Discharge and 30-Minute Charge	22
9	Test Samples of Celcon and PPO Prior to the 1000-hour KOH Compatibility Test	24
10	Stainless Steel Pressure Vessel	25
11	Test Samples of Celcon and PPO Following the 1000-hour KOH Compatibility Test	26
12	Silver Electrode Current Collector Grids Following Exposure to 150°C for 168 Hours in 35% KOH	32

SM-48461-Q2 iv

LIST OF TABLES

Table		Page
I	Cycle Test Results, Electrode Test Cell Configuration - One Positive and One Negative	14
П	Cycle Test Results, Electrode Test Cell Configuration One Positive and Two Negatives	17
Ш	Electrode Test Cell Construction - One Positive and Two Negatives	20

SM-48461-Q2 v

1.0 INTRODUCTION AND SUMMARY

During the reporting period, work has continued related to the objectives of NASA Program NAS 3-7639 "Program to Develop an Inorganic Separator for a High Temperature Silver-Zinc Battery". As in the first quarter of this program, (1) work during the second quarter has emphasized component fabrication, testing and evaluation as specified under Task II of the work statement. Work has also continued on Task I which is devoted to cell and component design.

Task I of this program, related to cell design, is nearly completed. The five ampere-hour (5 AH) cell design that has been selected is based on the experimental work carried out on components in Task II and consists of a grooved frame subassembly of separators and electrodes. It is then assembled in a cell case along with the cover and terminals. The cell case, cover and frames are made from polyphenylene oxide (PPO). Detail and assembly drawings of this design are shown in Figures 1 through 5. Molded PPO cases have been ordered and should be received by about March 1, 1966.

Task II, concerned with component fabrication and evaluation, is also on schedule. The best components produced thus far are described and applicable test results are presented. Except for the zinc electrodes, where additional work must be done to satisfactorily meet all program requirements, the cell components are being finalized for use in Task III multiplate cells. A number of test cells have completed 140 cycles, as required by the work statement, at 25°C and 100°C at 20 ma/cm². Tests at higher rates are under way to determine practical discharge and charging limits. Two multiplate cells have been given a preliminary cycle test at 25°C. These cells completed 1165 and 427 cycles, respectively, when they were disassembled for component analysis but do not, however, represent the best assembly of components. The results of this component analysis are being used for further guidance of Task II component development efforts.

Physical property and KOH compatibility tests have been completed on Celcon and PPO case materials. Based upon these tests, PPO has been selected as the case material for use in Task III of this program.

In general, the results obtained during the first two quarters of this program are favorable and the entire program is on schedule.




Figure 1. Cell Assembly




Figure 2A. Case, Cell




Figure 2B. Cover, Cell






Figure 3. Frame E and E', Separator and Electrode





2.0 TECHNICAL DISCUSSION

2.1 TASK I - Design of Multiplate 5 AH Cell

2.1.1 Grooved Cell Case

The first design concept of a 5 AH multiplate cell consisted of a grooved-wall cell case. In this design the separators were cemented into grooves machined in the side walls of the cases; the electrodes were then inserted and the leads were run through hollow terminals mounted in the cell cover and soldered in place.

A model built in accordance with this design was submitted to environmental testing and satisfactorily proved the test specifications called for in the work statement. These tests, which included vibration, shock and acceleration, are reported in detail in SM-48461-Q1. (1)

2.1.2 Grooved Frame Cell Design

The cell assembly described above was somewhat cumbersome to assemble and could be unreliable on an assembly line basis. A design modification was introduced after approval by the NASA ProjectManager. In this design a grooved frame holding separators and electrodes is assembled first. After attaching the electrode tabs to the base of the terminals (previously assembled in the cover), the entire assembly consisting of frame, electrode pack, and attached cover is inserted into a smooth wall cell case. The cover is then assembled to the cell case which is provided with a recess to locate the cover and to provide a sealing area.

To keep the cell size as close as possible to conventional 5 AH cells, the dimensions of all components were held to a minimum. The dimensions of the cell components are shown in Figures 1 through 5.

The assembly of the cell was made as follows:

(a) Cell Case: The case walls and the bottom are sealed together on a mandrel. The case material used is PPO. Chloroform or a 10 to 20% PPO solution in chloroform was used as the cement. The case assembly is dried at room temperature under light pressure. After air drying, the assembly is baked in an oven at 60 - 70°C to eliminate solvent traces.

The assembled case is then tested for gas leakage at five psi pressure and for KOH leakage by filling the case with 45% KOH and letting it stand for 24 hours at room temperature and for 24 hours at 100°C. The case assembly is accepted for use if it passes these tests without evidence of leakage.

(b) Frame: The frame consists of three parts – two sides and one bottom. The three parts have aligned grooves. The separators are assembled by cementing them into the frame grooves.

The spacings between separators are then checked using feeler gages to insure ease of electrode insertion.

- (c) Cover: The terminals are assembled to the cover using Shell Resin 901/B-3 which has proven to be leak proof at temperatures ranging from -30°C to 150°C.
- (d) Plates: The electrode plates are fabricated with the connector tabs cut to length and punched at the proper location for attachment to the terminal base.

Positive plates are prepared from Handy and Harmon Silpowder 130. Negative plates are prepared from a mixture of 98% ZnO and 2% HgO and are wrapped in KT paper approximately 20 mils thick.

- (e) Assembly: The plates are then slipped into their respective cavities. The positive plates are wrapped in a "U" of absorbent material that serves as an electrolyte retainer.

 The punched connector tabs are attached to the cell terminals. Finally, the entire assembly is inserted in the case and the cover is sealed in place.
- (f) Valve: Presently a valve is used as a means of sealing the cell temporarily until more data are obtained on gassing characteristics and the magnitude of pressure build up which will be encountered during operation at 25° and 100°C.

2.1.3 Molded Cases

To expedite the work on this contract, a survey of existing molds available from several battery manufacturers was made. A case has been selected that very closely approximates the dimensions of the fabricated cases described above. One hundred of these cell cases molded from PPO have been ordered. Delivery is expected about 1 March 1966.

SM-48461-Q2

2.2 TASK II - Fabrication, Testing and Evaluation of Cell Components

2.2.1 Electrodes

Electrode specifications have been established covering fabrication procedures, dimensions and weights of active materials.

The current collector used for both positive and negative electrode plates is silver expanded metal, 3 AG 10 - 3/0 to which a 1/4" x .006" silver strip is attached by spotwelding.

The electrode weight is controlled to +2.5%.

During the first quarter, the electrode formulations were:

Positive: 50% Ag powder, 50% monovalent Ag oxide

Negative: 98% zinc oxide, 2% HgO

KT paper pressed on both sides of the electrodes was changed. Based on test results obtained during the first quarter, the positive formulations were changed to Handy-Harmon Silpowder 130 sintered at 650°C for three minutes after electrode pressing. The negative electrode formulation has not been changed.

2.2.1.1 Case Configuration

Two unit cell case configurations have been used in this program for the evaluation of electrodes and inorganic separators. The first design consisted of a two-compartment cell containing one inorganic separator, one positive and one negative electrode. Figure 6 shows this design. This test cell design is designated as 'ESC-0000''.

The new test cell for electrode and separator testing is shown in Figure 7. This cell consists of a grooved three-sided frame that can hold either one or two inorganic separators so that cells can be tested having either one positive electrode and one negative electrode or one positive and two negative electrodes. This approach is used in guiding the electrochemical development of the electrodes toward the multiplate configuration.





Figure 6. Case, Test Cell, 177091-01-BE (ESC Type)

65/13



c/4/0

Figure 7. Single Electrode Test Case With 2-Separator Grooved Frame (ESC-B Type)

Cell cases are being fabricated in Lucite and polystyrene for tests at 25°C and PPO for tests at 100°C.

2.2.1.2 <u>Testing</u>

The principal test for determining electrode characteristics is ability to cycle. In accordance with the work statement, cycle testing is performed on each electrode configuration and formulation at room temperature and at 100°C on a 30-minute discharge, 60-minute charge test schedule using 140 cycles as the cut-off criterion. Electrode effectiveness is first determined by cycling at a discharge current density of 20 ma/cm² and then raised until the maximum operating discharge current density is established.

The cycle test data on the single tests cells presented in the first quarterly progress report⁽¹⁾ indicated that the 140-cycle cutoff requirement specified in the work statement was readily obtained on cells at both 100°C and 25°C at a discharge current density of 20 ma/cm² and a charge current density of 11 ma/cm². When the discharge current density was increased to 27 ma/cm², no test cells reached the 140 cycle cutoff due to the higher charge rate required. It was, therefore, decided to establish two experimental cycle test regimes, one at a discharge current density of 20 ma/cm² with a charge current density of 11 ma/cm², and the other at 40 ma/cm² discharge current density and a 22 ma/cm² charge current density to permit evaluation of electrodes in order to determine the maximum current density for practical cell operation at 25°C and 100°C.

Table I summarizes the cycle test results for a number of two-plate test cells cycled at 100°C and 25°C at discharge current densities of 20 ma/cm² and 40 ma/cm². At room temperature four cells completed the required 140 cycles on a 30-minute discharge and 60-minute charge cycle test schedule at 20 ma/cm² discharge current density and an 11 ma/cm² charge current density. These were Test Cell Nos. ESC-0112, ESC-0113, ESC-0121, and ESC-0127. During assembly of Test Cell No. ESC-0114 the separator was apparently broken, as was evidenced when the cell was disassembled following the completion of 23 cycles. Test Cell Nos. ESC-0128 and ESC-0137 also completed 140 cycles on the same cycle test schedule at

SM-48461-Q2

TABLE I

CYCLE TEST RESULTS ELECTRODE TEST CELL CONFIGURATION - ONE POSITIVE AND ONE NEGATIVE

Cycle Test Regime: 30-Minute Discharge and 60-Minute Charge NOTE:

Remarks Zinc Electrode	Note 1 Zinc Electrode Note 1	Zinc Electrode		Note 1	during Assembly Note 1	Zinc Electrode Cause of Failure Unknown Note 1 Zinc Electrode
Number of Cycles Successfully Completed 114 54	78 120 140 101 140	88 93 134	100 96 100 66	140 140 23	140 140	46 21 140 72
Density Charge (ma/cm^2) 1	>		>	=	→	²⁵ →
Current Density Discharge Char (ma/cm ²) (ma/c	>	0	>	2		0 →
Cycle Test Temp.	>	100°C		55°C	>	25°C
Test Cell No. ESC-0122 ESC-0123	ESC-0124 ESC-0126 ESC-0128 ESC-0135 ESC-0137	ESC-0130 ESC-0131 ESC-0132 ESC-0133	ESC-0134 ESC-0136 ESC-0138 ESC-0141	ESC-0112 ESC-0113 ESC-0114	ESC-0121 ESC-0127	ESC-0116 ESC-0117 ESC-0118 ESC-0119

TABLE I (continued)

ELECTRODE TEST CELL CONFIGURATION - ONE POSITIVE AND ONE NEGATIVE CYCLE TEST RESULTS

Remarks Zinc Electrode Note 1 Note 1 Zinc Electrode
Number of Cycles Successfully Completed 45 140 140 79
Density Charge $\frac{(m a/\text{cm}^2)}{}$
Current Density Discharge Char (ma/cm²) (ma/c
Cycle Test Temp. 25°C
Test Cell No. ESC-0120 ESC-0140 ESC-0142 ESC-0143

Cell successfully completed the cycling requirement of the contract, however, the cell is capable of continued cycling. Note 1.

100°C. Three additional test cells (ESC-0122, ESC-0126 and ESC-0135) had completed more than 100 cycles at 100°C and 20 ma/cm² discharge current density when they lost capacity due to the depletion of active material in the zinc electrode.

Several test cells (ESC-0118, ESC-0140 and ESC-0142) cycled at 25°C at a discharge current density of 40 ma/cm² and a charge current density of 22 ma/cm² on a 30-minute discharge and a 60-minute charge test schedule completed the required 140 cycles. Test Cell No. ESC-0132 completed 134 cycles and Test Cell Nos. ESC-0135 and ESC-0138 successfully completed 100 cycles at 100°C and 40 ma/cm² discharge current density.

A number of two-plate test cells cycled at 100°C and 25°C at discharge current densities of 40 ma/cm² and at 20 ma/cm² did not complete 140 cycles. Test Cell No. ESC-0132 completed 134 cycles and Test Cell Nos. ESC-0134 and ESC-0138 completed 100 cycles at 100°C and 40 ma/cm^2 discharge current density.

These cells were tested in half-case assemblies in which electrode cavities were deeper than the thickness of the positive and negative plates. Because of the excessive space available around the zinc electrode, slumping and expansion of the electrode resulted during cycling. This expansion exerted pressure on the separator causing it to bow because of the space available behind it in the positive compartment. The problem appears to be overcome in the new three-electrode test cases where the positive electrode is held firmly between the two separators with one zinc electrode on either side. Because all components fit together in a tight pack, lateral movement is precluded and zinc electrode changes should be minimized.

Recent experimental results show that the cycle performance of the new three-plate cell design is considerably better than that of the former two-plate cell design previously described in the monthly progress report for September 1965. (2) The cell identification number for the three-plate test cell is "B", i.e., ESC-B-000.

Table II is a summary of the three-plate test cells being cycled at 100° C and 25° C on a 1/2-hour discharge and a 1-hour

TABLE II

CYCLE TEST RESULTS
ELECTRODE TEST CELL CONFIGURATION - ONE POSITIVE AND TWO NEGATIVES

Cycle Test Regime: 30-Minute Discharge and 60-Minute Charge NOTE

Note 1 (Table I) Silver Electrode Swelled	and cracked separator Loose Electrode/Separator frame	Test in Progress Cell Case Bulged Due to accidental overheating Test in Progress	Note (Table I)
Number of Cycles Successfully Completed 140 140 140 140 140 28	30	50 443 37 118 118 12 28 35 69	34 4 0 ——————————————————————————————————
Charge (ma/cm2)	\rightarrow		÷ 2————————————————————————————————————
Current Density Discharge Char (ma/cm²) (ma/c	\rightarrow	30	→ °2 ←
Cycle Test Temp. 100°C	\rightarrow	100°C	→ So C S C S C S C S C S C S C S C S C S
Test Cell No. ESB-B-157 ESC-B-158 ESC-B-160 ESC-B-166	ESC-B-167	ESC-B-168 ESC-B-169 ESC-B-171 ESC-B-171 ESC-B-175 ESC-B-177 ESC-B-177 ESC-B-181 ESC-B-184 ESC-B-186	ESC-B-187 ESC-B-144 ESC-B-145 ESC-B-146 ESC-B-147 ESC-B-147 ESC-B-149 ESC-B-150 ESC-B-151

TABLE II (continued)

CYCLE TEST RESULTS
ELECTRODE TEST CELL CONFIGURATION - ONE POSITIVE AND TWO NEGATIVES

Remarks	Test in Progress Cell Dried Out Completely Possible Cell Short Test in Progress	Cell reversed* Broken lead to zinc electrode Test in Progress Cell reversed* Test in Progress Test in Progress
Number of Cycles Successfully Completed	97 22 51 52 70 79	67 24 69 121 83 66 34
Density Charge (ma/cm^2)	50	> %>
Current Density Discharge Char (ma/cm ²) (ma/c	30	→ ⁴ →
Cycle Test Temp.	Do 22	50C ← − − − − − − − − − − − − − − − − − −
Test Cell No.	ESC-B-165 ESC-B-172 ESC-B-173 ESC-B-174 ESC-B-178 ESC-B-179	ESC - B - 154 ESC - B - 155 ESC - B - 155 ESC - B - 156 ESC - B - 161 ESC - B - 163

*cycle test timer failure

charge schedule at discharge current densities of 20 ma/cm² and 40 ma/cm². Ten of these test cells have completed the required 140 cycles at 25°C and 20 ma/cm² discharge current density. Several of these new test cells were permitted to continue cycling and have run for more than 400 cycles this far and continue under test. Test Cell Nos. ESC-B-147, ESC-B-149, and ESC-B-152 have cycled at 25°C and at a discharge current density of 20 ma/cm² (equivalent to 35% depth of discharge based on rated capacity) and continue under test. Test Cell No. ESC-B-139 has completed 700 cycles to the present time under the same test conditions. These cells were assembled in molded C-11 polystyrene cell cases purchased from a battery manufacturer. A Lucite shim was used in these cell assemblies to provide electrode cavities of the same dimensions as used in the Lucite and PPO cell cases fabricated in the machine shop. Test Cell No. ESC-B-139 is assembled in a Lucite cell case.

Test Cell Nos. ESC-B-157, ESC-B-158, ESC-B-159, and ESC-B-160 have completed the required 140 cycles at 100° C and 20 ma/cm² discharge current density indicating that the three-plate test cell design can successfully meet the 140 cycle requirement at both 100° C and 25° C at a discharge current density of 20 ma/cm² and a charge current density of 12 ma/cm².

Based upon the successful attainment of 140 cycles at both 100°C and 25°C at 20 ma/cm² discharge current density and 12 ma/cm² charge current density, another group of test cells was placed on cycle test at 25° and 100°C at 30 ma/cm² discharge current density and a 20 ma/cm² charge current density. These cycle tests are continuing and typical performance data are shown in Table II. Concurrent cycle testing is also in progress at 40 ma/cm² discharge current density.

Several of the new test cells are being discharged through a fixed resistance. This method provides a more realistic procedure under flight conditions than constant current operation. The fixed resistance discharge method will be used during the remainder of the program when single test cells are cycled.

Table III shows electrode construction and formulation for all test cells of the new configuration (one positive and two

SM-48461-Q2

			sitive						
		Forr	nulation		Nega		rmulati		
							T Paper	:	
Test	Case	100%	50-50	ZnO	HgO	U-	10%		
Cell Number	Material	$\mathbf{A}g$	Ag/Ag ₂ O	%	%	Wrap	Fibres	Other	Comments
ESC-B-144	Lucite	3 7		98	2	x			Collector
ESC-B-145	Δicite Λ	x x	•	98	2	^		Pellon	(All Cells):
ESC-B-146				98	2	17		U-	Ag EXMET
	į	x		98	2	x		Wrap	3Ag-10-3/0
ESC -B-147		x		98	2	x		Wiap	JAg-10-3/0
ESC-B-148		x		98	2	x			Lead (All
ESC-B-149		x		70	2	x			Cells):
ESC-B-150		x		98	2	x			Ag tab 1/4"
ESC-B-151		x		98	2	x			x . 006"
ESC-B-152		x		98	2	x			Tab spot
ESC-B-153		x		98	2 2	x			welded to
ESC-B-154	Lucite	x		98	2	x			grid for all
ESC-B-155	PPO	x		98	2	x			electrodes
ESC-B-156	1	x		98		x			Cicciiodes
ESC-B-157		x		98	2 2	x			
ESC-B-158		x		98		x			
ESC-B-159		x		98	2 2	x			
ESC-B-160		x		98	2	x			
ESC-B-161		x		98	2	x			
ESC-B-162		x		98	2	x			
ESC-B-162		x		98	2	x			
ESC-B-164		x		98	2	x			
ESC-B-165		x		98	2	A.		Asbes	_
ESC-B-166		x		98	2	x		tos U-	
ESC-B-167				98	2	x		Wrap	
ESC-B-168		x x		98	2	x		птар	
ESC-B-169		×		98	2	×			
ESC-B-170		x		98	2	x			
ESC-B-170	V PP O	x		98	2	x			
ESC-B-171	Lucite	x		98	2	Α.	x		
ESC-B-172		x		98	2		x		
ESC-B-173	↓ Lucite	x		98	2		x		
ESC-B-175	PPO	x		98	2		x		
ESC-B-176	₽ ₽ ©	x		98	2		x		
ESC-B-177	PPO	x		98	2		x		
ESC-B-178	Lucite	x		98	2		x		
ESC-B-178	Lucite	x		98	2		x		
ESC-B-179	PPO			98	2		x		
ESC-B-181		×		98	2 2 2 2 2 2 2 2 2 2		x X		
ESC-B-181 ESC-B-182		x		98	2		x		
ESC-B-182 ESC-B-183		x x		98	2		x		
ESC-B-184		x		98	2	x	^		
ESC-B-185				98	2				
ESC-B-186		x		98	2	x			
ESC-B-187	PP O	x		98	2	x x			
E9C-D-101	FFU	x		70	4	^			

negative electrodes and two inorganic separators). The positive electrode formulation was identical for all cells but several different methods were used in applying the network support material in the negative electrode. The electrode current collectors and tabs were of the same design in all cells.

Preliminary cycle testing of multiplate cells for component evaluation continued throughout the report period. Multiplate cell No. MC-2 completed 1,165 cycles at 25°C on a 1/2-hour discharge and 1/2-hour charge cycle test schedule. Prior to placing on cycle, this cell was formed by charging to 2.1 volts and discharging at constant current (1.0 ampere) to 1.0 volt cut-off. At this rate the cell had an initial capacity of 13.0 ampere hours. Following a full recharge, the cell was cycled under the following regimes to obtain charge and discharge rate data:

Discharge	Charge	Discharge	Charge	Total Cycles
4.0 Amps.	2.8 Amps.	1/2 hr.	l hr.	17 cycles
2.8 Amps.	1.6 Amps.	1/2 hr.	l hr.	10 cycles
1.0 Amps.	1.6 Amps.	1/2 hr.	1/2 hr.	652 cycles
l.l Amps.	2.0 Amps.	1/2 hr.	1/2 hr.	513 cycles

Figure 8 shows the 28th and 338th cycles for this multiplate cell. At cycle 338 there was a degradation of the monovalent silver oxide plateau voltage probably caused by geometric changes in the zinc electrode, resulting in reduced area of the zinc electrode which increased current density.

Multiplate Cell No. MC-3 was placed on a 30-minute discharge, 60-minute charge cycle test schedule at 25°C at 2.8 amperes and 2.0 amperes respectively. This cell completed 427 cycles when it was disassembled for analysis.

2.2.2 Inorganic Separator

Inorganic separators have been fabricated during this reporting period as required for component evaluation and cell testing. Process and quality control tests indicate a consistent high level of uniformity and quality.




Figure 8. Charge-Discharge Curves Multiplate Silver-Zinc Test Cell Number MC-2 Cycling at Room Temperature at a Test Regime of 30-Minute Discharge and 30-Minute Charge.

2.2.3 Cases

The statement of work requires that a physical property evaluation of cell structural materials be performed in order to select materials having satisfactory strength and rigidity. The following two materials were tested and evaluated.

Material

Manufacturer


Polyphenylene Oxide (PPO)
Acetal Copolymer (Celcon)

General Electric Company
Celanese Plastics Company

The material tests performed included:


- (a) modulus of rupture
- (b) tensile strength
- (c) modulus of elasticity
- (d) dimensional compatibility
- (e) thermal degradation

One thousand hour KOH-high temperature compatibility tests on PPO and Celcon case materials were completed during the reporting period. These tests involved the complete submergence of test samples of PPO and Celcon (shown in Figure 9) in 35% KOH which were sealed in stainless steel pressure vessels. The sealed pressure vessels were heated to 100°C +2°C for 1000 hours. Figure 10 shows one of the stainless steel pressure vessels used in these tests. At each 100-hour interval, the test samples were removed from the container, washed, dried, and inspected for evidence of degradation, and then returned to the pressure vessel for continuation of the test. The 100-hour inspections showed no visible degradation of either PPO or Celcon after a total of 1000 hours of exposure. Test samples were photographed prior to the start of the tests (Figure 9) and again after completion of the tests (Figure 11). The only visible change which occurred as a result of the test was a change in color of the Celcon test specimens from white to beige where the test specimen protruded from the KOH solution. This discoloration can be noted in Figure 11 at the right ends of the two top Celcon test specimens. The PPO test specimens were unchanged in color as a result of the test.



C/38/

Figure 9. Test Samples of Celcon and PPO Prior to the 1000-hour KOH Compatibility Test



C/382

Figure 10. Stainless Steel Pressure Vessel




Figure 11. Test Samples of Celcon and PPO Following the 1000-hour KOH Compatibility Test

SM-48461-Q2

Test results on the PPO and Celcon test specimens after 1000 hours exposure to KOH at 100° C are shown below:

1. Tensile strength and modulus of elasticity after exposure; tested and computed in accordance with ASTM D-638-64T.

Sample No.	Material	Ultimate Tensile (psi)	Average (psi)	Modulus of Elasticity	Average (psi)
1	Celcon	9,540		3.36×10^5	
2	Celcon	9,370		8.28×10^{5}	
3	Celcon	9,510	9430	5.17×10^{5}	5.17×10^5
4	Celcon	9,480		4.18×10^{5}	
5	Celcon	9,310		5.22×10^{5}	
6	Celcon	9,360		4.82×10^{5}	
7	PPO	10,600		5.05×10^{5}	
8	PPO	10,600		6.01×10^5	
9	PPO	10,600	10600	5.43×10^{5}	5.64×10^{5}
10	PPO	10,700		6.08×10^{5}	
11	PPO	10,700		6.02×10^{5}	
12	PPO	10,600		5.26×10^{5}	

2. Modulus of rupture after exposure; tested and computed per ASTM D-790-63.

Sample No.	Material	Modulus of Rupture (psi)	Average (psi)
1	Celcon	11,240	
2	Celcon	10,900	11,000
3	Celcon	10,900	
4	PPO	14,690	
5	PPO	15,210	15,000
6	PPO	15,100	

3. Dimensional stability and weight change after exposure. For this test the thickness and width were measured with a dial thickness gauge, to the nearest 0.001 inch, at several points along each sample before exposure. Following exposure, measurements were taken at identical points and compared with the initial values. In a like manner the length of each sample was measured between

two specific points before and after exposure. For the weight change the samples were weighed on an analytical balance to four decimal places before and after exposure.

Material	Celcon	PPO
Average thickness change	0	0
Average width change	-0.16%	-0.05%
Average length change	-0.24%	0
Average weight change	-0.15%	-0.01%

- 4. Appearance after exposure: The samples after exposure were compared with unexposed samples for color. The Celcon had changed in color from a milk white to a light blue-gray in the area of total immersion in the solution. In the area where the tensile tabs were out of the solution in the vapor phase the color had changed to a dark beige. The color of both areas was the same in the interior of the sample as on the surface. After testing, the tensile bars turned blue in the areas of strain. The gloss of the Celcon resin was unchanged by exposure. The PPO was essentially unchanged in color and gloss after exposure.
- 5. Summary of test results:

Material	Test	Manufacturer's Data	Initial Astropower Laboratory (Results)	Final Astropower Laboratory (Results)
Celcon	Ultimate Tensile	8,800 psi	8,470 psi	9,430 psi
Celcon	Modulus of Elasticity	No value given	$3.69 \times 10^5 \text{ psi}$	5.17×10^5 psi
Celcon	Modulus of Rupture*	13,000 psi	12,000 psi	11,000 psi
PPO	Ultimate Tensile	9,000 - 10,000 psi	9,460 psi	10,600 psi
PPO	Modulus of Elasticity	$3.5 - 3.8 \times 10^5 \text{ psi}$	3.4×10^5 psi	$3.4 \times 10^5 \mathrm{psi}$
PPO	Modulus of Rupture*	14,000 - 15,000 psi	13,600 psi	15,000 psi

^{*}The modulus of rupture is a measurement of the load per unit area, placed in the center of a beam of test material, required to develop five (5) percent strain in the outer fiber.

One task to be performed later in the program involves the thermal cycling of activated multiplate cells at $145^{\circ}\text{C} \pm 2^{\circ}\text{C}$ for three 36-hour soak periods. It was decided to submit test samples of PPO and Celcon to this test while submerged in 45% KOH during the evaluation of case materials in order to select a case material which would also satisfactorily meet this requirement. Due to an error in calibration of the temperature recorder, a

SM-48461-Q2 28

higher temperature was obtained for two and one-half of the 36 hour periods of test than planned. As a result, the test samples of PPO and Celcon were heated to 193° C for 93 hours plus 15 hours at 145° C. The PPO samples were unaffected by this test but the Celcon samples melted into a lump. An additional test on new Celcon test samples was conducted by heating the submerged samples in 45% KOH for 6 hours at 145° C $\pm 2^{\circ}$ C. These samples also melted into a lump during this test. Based on these tests it was determined that PPO was a satisfactory case material and that Celcon was unsuitable for use in this program.

The test results on the PPO test specimens are shown below:

1. Tensile strength and modulus of elasticity after exposure to 45% KOH (tested in accordance with ASTM D-638-64T).

Sample No.	Material	Ultimate Tensile (psi)	Average (psi)	Modulus of Elasticity	Average (psi)
1	PPO	11,250		3.47×10^5	
2	PPO	11,250	11,260	3.58×10^5	3.49×10^{5}
3	PPO	11,340		3.51×10^{5}	
4	PPO	11,190		3.40×10^{5}	

2. Modulus of rupture, after exposure (tested in accordance with ASTM D-790-63).

	Modulus of		
Sample No.	Material	Rupture (psi)	Average (psi)
1	PPO	14,590	
2	PPO	14,980	14,900
3	PPO	14,720	
4	PPO	15,330	

Dimensional Stability: For this test the thickness and width were measured with a dial thickness gauge in the nearest 0.001 inch, at several points along each sample, before exposure. Following exposure, measurements were taken at identical points and compared with the initial values. In a like manner the length of each sample was measured between two specific points before and after exposure.

Average thickness change +1.6%

Average width change +0.3%

Average length change -1.4%

4. Weight Change: The samples were weighed on an analytical balance to four decimal places before and after exposure.

Average weight change

-0.01%

Based upon preliminary sealing tests, it also appears that PPO can be sealed by solvent bonding, thereby effecting a satisfactory seal between cell cover and case.

At the suggestion of the NASA Project Officer, molded polystyrene cell cases and covers of the approximate 5 AH cell size have been purchased. These cell cases and covers are being used for evaluations at 25° C. Molded 5 AH cell cases and covers made from PPO have also been ordered for tests at 100° C and higher.

2.2.4 Terminals

As reported in the first Quarterly Report, (1) the terminal seal design successfully passed thermal cycling, pressure and KOH leakage tests as required by the work statement.

After testing in accordance with these specifications, no trace of alkalinity was detected at the external end of the terminal during the test period and as long as 24 hours later. The terminal was disassembled for examination and no attack could be detected on any material used or on the entire configuration. The attachment of electrode tabs to the base of the terminal was modified subsequently for ease of assembly, as shown in Figure 4.

2.2.5 Connections and Current Collectors

The electrode tab (current collector) connection to the cell terminal consists of two basic designs, (1) silver tabs spot-welded or hot-forged to silver expanded metal grids cut to size, and (2) silver expanded metal grid in which a solid silver tab is an integral part of the grid. A KOH soak test was performed, in compliance with the statement of work, in which two electrode current collector grids of the first design described above were completely

submerged in 35% KOH in a stainless steel vessel shown in Figure 10 and the vessel maintained at 150°C + 2°C for 168 hours. At the completion of the 168hour soak test, the current collector grids were removed from the sealed vessel, washed, dried, and inspected under a microscope for corrosion. No evidence of corrosion was noted. Figure 12 is a photograph of the current collector grids taken after the 168-hour soak test. A 30 ampere current (dc) was then passed through each grid for a period of one minute with one current lead connected to the end of the silver tab and the other current lead attached to the bottom of the silver grid. No evidence of resistance, corrosion or discoloration was detected. Finally an attempt was made to mechanically pull the tab away from the grid at the welded joint by holding the grid in a vise and manually pulling the tab. The tab could not be pulled loose from the grid indicating satisfactory weld strength. Assemblies were also tested to determine the force required to pull the tab away from the collector. It was determined that when 10 pounds force was applied, the Exmet grid pulled apart. The welded joint between tab and grid was unaffected by the test showing that the weld is stronger than the grid material itself.

Because the second type is an integral part of the current collector-connector assembly, it was unnecessary to test this design for corrosion resistance. Current tests were conducted which indicated that the physical design is adequate for the proposed application and capable of operation continuously at 30 amperes.

2.3 Summary of Results and Conclusions

Several prototype multiplate 5 ampere-hour cells were fabricated throughout the past quarter. The cell design used was the modified groove-type, which was approved by the NASA/Lewis Project Officer early in this quarter. This design emphasizes the requirements of the work statement, such as ease of assembly, positive closures, parts reproducibility, adequate closures, and filling means. Cell assembly and detail parts drawings were completed on this modified groove-type multiplate cell design. One preliminary multiplate cell of this design completed 1165 cycles at 25°C on a 30-minute discharge and 30-minute charge test schedule.

SM-48461-Q2




Figure 12. Silver Electrode Current Collector Grids Following Exposure to 150°C for 168 Hours in 35% KOH

SM-48461-Q2

1783

Molded cell cases made of polyphenylene oxide (PPO) have been ordered for use in this program for both 100°C and 25°C temperature tests. The molded case approximates very closely the dimensions of the fabricated 5 AH multiplate cell design.

Final test data and analyses were obtained on the two candidate cell case and cover materials — PPO and Celcon — which were subjected to the 1000-hour KOH-high temperature soak tests. As a result of these tests, it was apparent that PPO can be used as the material for the multiplate cells to be built in Task III. Celcon can not withstand the 145°C specified in the statement of work. The mechanical properties of PPO remained unchanged as a result of the exposure.

Astroset Type 5-036-011 inorganic separators were fabricated and incorporated into test cells and prototype multiplate test cells during the quarter. Separator quality and uniformity have continually been improved as a result of strict quality control measures which have been implemented throughout this program.

Cycle testing of unit electrode test cells containing Astroset Type 5-036-011 inorganic separators was continued at 100°C and 25°C for the purpose of evaluating electrode formulations and configurations. Many electrode test cells successfully completed the required 140 cycles in compliance with the statement of work at 100°C and 25°C at a discharge current density of $20~\text{ma/cm}^2$. A new three-plate unit cell design is being cycle tested at room temperature and 100°C at discharge current densities of $20~\text{ma/cm}^2$ and $30~\text{ma/cm}^2$.

Based on the promising experimental test cell results obtained during the past quarter, the emphasis of the program has been shifted from component testing to multiplate cell fabrication, testing and evaluation. Although the component work will be continued at a reduced level of effort, multiplate cell work will be carried out based on the best components developed thus far. These cells will be constructed with PPO cases, and electrodes which have given satisfactory results. Astroset Type 5-036-011 inorganic separators will be used in the construction of cells.

SM-48461-Q2 33

3.0 WORK PLANNED

3.1 TASK I - Design of a Multiplate 5 AH Cell

- 3,1,1 Modify terminal base for tab attachment and complete drawings.
- 3.1.2 Modify separator dimensions to fit frame grooves more deeply.
 - 3.1.3 Design and fabricate new separator die.

3.2 TASK II - Fabrication, Testing and Evaluation of Cell Components (Single Electrode Cell)

3.2.1 Electrodes

3.2.1.1 Fabricate electrodes, assemble single electrode cells and test them mainly at current densities higher than 20 ma/cm 2 at 25° C and 100° C, in order to establish the practical limit capable of reaching 140 cycles reliably and without undue capacity loss at 100° C.

3.2.1.2 Test single electrode cells at 25°C and 100°C for gassing rates on stand and on cycling.

3.2.2 Separators

Fabricate separators from Astroset Type 5-036-011 to new dimensions as required for component and cell testing.

3.2.3 Case

3.2.3.1 Assemble single electrode cell cases, cement and test for leakage.

\$3.2.3.2\$ Adapt cover and stainless steel tubing for $100^{\rm O}C$ operation and minimization of water evaporation.

3.2.4 Terminal

Work on terminal seal completed, but base to be modified: See next paragraph.

3.2.5 Connections

The base of the terminal was redesigned in order to simplify the tab attachment from plates to terminals during cell assembly.

Terminals with new bases are being fabricated and will be used on the new test cells.

3.2.6 Electrolyte

Study effects of 30, 35, 40, 45%, KOH concentration on cell cycle life and drain rate.

Four cells will be built and tested at various load regimes for 3 cycles, then cycled at the 1 hour-rate of discharge at 25°C for life.

3.2.7 Multiplate Cells

- 1. Order 100 PPO cell cases from molder for multiplate cells. The case was selected for its dimensions approximating our design very closely except for height. The cases will be cut down to the proper height and pressure-tested at 125°C and 30 psi.
- 2. Case-to-cover bond will be pressure tested to determine rupture pressure.
- 3. Multiplate cells will be built and tested at 25° and 100° C.

4.0 PERSONNEL

As of 30 January 1966, a total of 6270 engineering hours have been expended on this project. The personnel who worked on this program and the approximate percentage of their time devoted to this project are as follows:

Dr. C. Berger	No direct charge
F. C. Arrance	100%
A. Himy	50%
A. D. Taylor	50%
A. G. Rosa	100%
Q. H. McKenna	100%
R. K. Greve	20%
M. P. Kilgore	60%
J. D. Armantrout	20%

REFERENCES

- 1. "Program to Develop an Inorganic Separator for a High Temperature Silver-Zinc Battery," Contract NAS 3-7639, Report SM-48461-Q1, October (1965).
- 2. "Program to Develop an Inorganic Separator for a High Temperature Silver-Zinc Battery," Contract NAS-37639, Report SM-48461-M2 September (1965).

OFFICIAL DISTRIBUTION LIST FOR QUARTERLY AND FINAL REPORTS

National Aeronautics & Space Administration Washington, D. C. 20546

Attention: RNW/E. M. Cohn

FC/A. M. Greg Andrus

SL/J. R. Miles

National Aeronautics & Space Administration Goddard Space Flight Center Greenbelt, Maryland 20771

Attn: Thomas Hennigan, Code 632.2

Joseph Sherfey, Code 652

Paul Donnelly, Code 636.2

E. R. Stroup, Code 636.2

National Aeronautics & Space Administration Langley Research Center Instrument Research Division Hampton, Virginia 23365 Attn: John L. Patterson, MS-234

National Aeronautics & Space Administration Langley Research Center Langley Station Hampton, Virginia Attn: S. T. Peterson/Harry Ricker

National Aeronautics & Space Administration Lewis Research Center 21000 Brookpark Road Cleveland, Ohio 44135

Attn: Library, MS 3-7

N. D. Sanders, MS 302-1

J. E. Dilley, MS 500-309

R. L. Cummings, MS 500-201

B. Lubarsky, MS 500-201

H. J. Schwartz, MS 500-201

D. G. Soltis, MS 500-201

M. J. Saari, MS 500-202

J. J. Weber, MS 3-16

R. R. Miller, MS 500-202

Report Control, MS 5-5

National Aeronautics & Space Administration Scientific and Technical Information Facility P. O. Box 5700 Bethesda 14, Maryland Attn: NASA Representative(2+1 repro.) National Aeronautics & Space Administration George C. Marshall Space Flight Center

Huntsville, Alabama 35812 Attn: Philip Youngblood

Richard Boehme, Building 4487-BB

M-ASTR-EC

National Aeronautics & Space Administration Manned Spacecraft Center

Houston, Texas 77058

Attn: William R. Dusenbury,

Propulsion & Energy Systems Branch

Bldg. 16, Site 1

Attn: Robert Cohen,

Gemini Project Office

Attn: Richard Ferguson (EP-5)

James T. Kennedy (EE-5) Forrest E. Eastman (EE-4)

National Aeronautics & Space Administration Ames Research Center

Pioneer Project

Moffett Field, California 94035

Attn: James R. Swain

A. S. Hertzog

Attn: Jon Rubenzer

Biosatellite Project

National Aeronautics & Space Administration

Jet Propulsion Laboratory

4800 Oak Grove Drive

Pasadena, California 91103

Attn: Aiji Uchiyama

U. S. Army Engineer R&D Labs.

Fort Belvoir, Virginia 22060

Attn: Dr. Galen Frysinger, Electrical Power Branch SMOFB-EP

U. S. Army Engineer R&D Labs. Fort Monmouth, New Jersey

Attn: David Liden (Code SELRA/PS)

U. S. Army R&D Liaison Group (9851 DV)
APO 757
New York, New York
Attn: B. R. Stein

Commanding Officer
U. S. Army Electronics R&D Lab.
Fort Monmouth, New Jersey 07703
Attn: Power Sources Division

Research Office
Rand D. Directorate
Army Weapons Command
Rock Island, Illinois
Attn: G. Riensmith, Chief

U. S. Army Research Office Box CM, Duke Station Durham, North Carolina Attn: Paul Greer

U. S. Army Research Office Chief, Rand D. Department of the Army 3D442, The Pentagon Washington, D. C. 20546 Attn: Dr. Sidney J. Mangram

Army Materiel Command Research Division AMCRD-RSCM-T-7 Washington, D. C. Attn: John W. Crellin

U. S. Army TRECOM Fort Eustis, Virginia 23604 Attn: Leonard M. Barton (SMOFE-ASE)

U. S. Army Mobility Command Research Division Center Line, Michigan 48090 Attn: O. Renius (AMSMO-RR)

Office of the Deputy Commander AFSC for Aerospace Systems
U. S. A. F.
Los Angeles 45, California
Attn: W. J. Bennison

Flight Vehicle Power Branch Air Force Aero Propulsion Laboratory Wright-Patterson AFB, Ohio Attn: J. E. Cooper

A. F. Cambridge Research Lab. L. G. Hanscom Field Bedford, Massachusetts Attn: Francis X. Doherty

Rome Air Development Center, ESD Griffiss AFB, New York 13442 Attn: Frank J. Mollura (RASSM)

Headquarters, USAF (AFRDR-AS) Washington 25, D. C. Attn: MAJ G. Starkey

National Bureau of Standards Washington 25, D. C. Attn: Dr. W. J. Hamer

Office, DDR&E: USE & BSS
The Pentagon
Washington, D. C.
Attn: G. B. Wareham

U. S. Atomic Energy Commission Auxiliary Power Branch (SNAP) Division of Reactor Development Washington 25, D. C. Attn: LT COL George H. Ogburn, Jr.

Advanced Space Reactor Branch Division of Reactor Development U. S. Atomic Energy Commission Washington 25, D. C. Attn: LT COL John H. Anderson

Army Reactors, DRD U. S. Atomic Energy Commission Washington 25, D. C. Attn: Donald B. Hoatson

Institute for Defense Analyses R&E Support Division 400 Army-Navy Drive Arlington, Virginia 22202 Attn: Dr. George C. Szego

Office of Naval Research
Washington, D. C. 20360
Attn: Dr. Ralph Roberts, Code 429
Head, Power Branch

Naval Research Laboratory Washington, D. C. 20390 Attn: Dr. J. C. White, Code 6160

Office of Naval Research Department of the Navy Washington, D. C. 20360 Attn: H. W. Fox, Code 425

Bureau of Naval Weapons
Department of the Navy
Washington 25, D. C.
Attn: Milton Knight (Code RAAE-50)

Naval Ammunition Depot Crane, Indiana Attn: H. Shultz

Navl Ordanance Laboratory
Department of the Navy
Corona, California
Attn: William C. Spindler (Code 441)

Naval Ordnance Laboratory Department of the Navy Silver Spring, Maryland Attn: Philip B. Cole (Code WB)

Bureau of Ships Department of the Navy Washington 25, D. C. Attn: C. F. Viglotti (Code 660)

Power Information Center University of Pennsylvania Moore School Building 200 South 33rd Street Philadelphia 4, Pennsylvania

Office of Technical Services Department of Commerce Washington 25, D. C.

Arthur D. Little, Incorporated Cambridge, Massachusetts Attn: Library

Bell Laboratories
Murray Hill, New Jersey
Attn: U. B. Thomas/David A. Feder

The Boeing Company Seattle, Washington Attn: Dr. Theodore Beck

Burgess Battery Company Freeport, Illinois Attn: Dr. Howard J. Strauss'

Calvin College Grand Rapids, Michigan Attn: Prof. T. P. Dirkse

Delco Remy Division
General Motors Corporation
Anderson, Indiana
Attn: Dr. J. Lander

Eagle-Picher Company P. O. Box 290 Joplin, Missouri Attn: E. M. Morse

Electric Storage Battery Company Missile Battery Division Raleigh, North Carolina Attn: A. Chreitzberg

Electric Storage Battery Company Carl F. Norberg Research Center Yardley, Pennsylvania Attn: Dr. R. A. Schaefer

Electrochimica Corporation 1140 O'Brien Drive Menlo Park, California Attn: Dr. Morris Eisenberg

Electro-Optical Systems, Incorporated 300 North Halstead Pasadena, California Attn: E. Findl

Dr. Arthur Fleischer 466 South Center Street Orange, New Jersey

General Electric Company
Schenectady, New York
Attn: Dr. William Carson
Advanced Technology Lab.

General Electric Company Battery Products Section P. O. Box 114 Gainsville, Florida General Motors-Defense Research Labs. P. O. Box T Santa Barbara, California Attn: Dr. C. R. Russell

Globe-Union, Incorporated 900 East Keefe Avenue Milwaukee, Wisconsin Attn: Dr. Warren Towle

Gould-National Batteries, Incorporated Engineering and Research Center 2630 University Avenue, S. E. Minneapolis 14, Minnesota Attn: J. F. Donahue

Gulton Industries Alkaline Battery Division Metuchen, New Jersey Attn: Dr. Robert Shain

Hughes Research Laboratories Corporation Malibu, California Attn: T. M. Hahn

Inland Testing Laboratories
Dayton, Ohio
Attn: W. Ingling

ITT Federal Laboratories 500 Washington Avenue Nutley 10, New Jersey Attn: Dr. P. E. Lighty

Livingston Electronic Corporation Route 309 Montgomeryville, Pennsylvania Attn: William F. Meyers

Lockheed Missiles and Space Company Department 65-82 Palo Alto, California Attn: Larry E. Nelson

Mallory Battery Company 60 Elm Street North Terrytown, New York Attn: R. R. Clune

Midwest Research Institute 425 Volker Boulevard Kansas City 10, Missouri Attn: Dr. B. W. Beadle North American Aviation, Incorporated 12214 Lakewood Boulevard Downey, California Attn: Burton M. Otzinger

P. R. Mallory & Company, Incorporated Northwest Industrial Park Burlington, Massachusetts Attn: Dr. R. Selim

Power Sources Division Whittaker Corporation P. O. Box 337 Newbury Park, California Attn: Mr. John Rhyne

Radio Corporation of America Astro Division Heightstown, New Jersey Attn: Seymour Winkler

Space Technology Laboratories, Incorporated One Space Park Redondo Beach, California Attn: Dr. A. Krausz

Southwest Research Institute 8500 Culebra Road San Antonio 6, Texas Attn: Dr. Jan Al

Texas Instruments, Incorporated 13500 North Central Expressway Dallas, Texas Attn: Dr. I. Trachtenberg

Sonotone Corporation Saw Mill River Road Elmsford, New York Attn: A. Mundel

Thomas A. Edison Research Laboratory McGraw Edison Company Watchung Avenue West Orange, New Jersey Attn: Dr. P. F. Grieger

Union Carbide Corporation Development Laboratory Library P. O. Box 6056 Cleveland, Ohio 44101 Attn: Miss C. M. Foecking Westinghouse Electric Corporation Research & Development Center Churchill Borough Pittsburgh, Pennsylvania Attn: Dr. A. Langer

Western Company Suite 802, RCA Building Washington, D. C. Attn: R. T. Fiske

Yardney Electric Corporation 40-50 Leonard Street New York, New York Attn: Dr. Paul Howard

Aerospace Corporation
Systems Design Division
2350 East El Segundo Boulevard
El Segundo, California
Attn: John G. Krisilas