

GPO PRICE \$ _____

CFSTI PRICE(S) \$ _____

NASA CR70561

Hard copy (HC) 3.00

Microfiche (MF) .65

ff 653 July 65

TRANSIENT AND STEADY PERFORMANCE OF AN
ION ROCKET THRUST AUGMENTOR

prepared for

NATIONAL AERONAUTICS AND SPACE ADMINISTRATION

GRANT N~~8~~ G-570

FACILITY FORM 802	N 67-17771	_____
	(PAGES)	(THRU)
	CR 70561	_____
	(NASA CR OR TMX OR AD NUMBER)	(CATEGORY)

FLUID DYNAMICS AND DIFFUSION LABORATORY
COLLEGE OF ENGINEERING
COLORADO STATE UNIVERSITY
FORT COLLINS, COLORADO

SUMMARY REPORT

TRANSIENT AND STEADY PERFORMANCE OF AN ION ROCKET
THRUST AUGMENTOR

prepared for

NATIONAL AERONAUTICS AND SPACE ADMINISTRATION

December, 1964

GRANT ~~NAG~~-570

Technical Management
NASA Lewis Research Center
Cleveland, Ohio
Electric Propulsion Office
John Ferrante

NASA Offices and Research Centers
Only

TRANSIENT AND STEADY PERFORMANCE OF AN ION ROCKET THRUST AUGMENTOR

SUMMARY

The grant for the year 1964 included the design, construction and operation of a vacuum facility to do research on ion propulsion units. A cesium contact ion source with an electrostatic accelerator was also designed, constructed and put in operation. A thrust augmentor system is incorporated in the accelerator system. Preliminary measurements of the ion propulsion system in operation have been made.

A theoretical study of the acceleration of ions due to counter-current electron flow and secondary electron emission at the ion emitter has been made. The assumed model and solution indicates an increase in ion beam power is possible. However, the solution failed to give increases in ion beam power, equivalent to those observed experimentally.

A literature survey of the emission of secondary electrons has been prepared. Both the theoretical and experimental data reported on secondary electron emission at metal surfaces have been reviewed. An experimental program is underway to evaluate the secondary electron emission from porous tungsten ionizers.

INTRODUCTION

The present research program is directed toward understanding and improving the present state of the art of electrostatically accelerating ions. Present ion accelerator systems are limited by space charge effects. Maximum efficiency of an ion rocket would be obtained if it could be operated ion-limited rather than space-charge-limited. In other words, at present it is not always possible to accelerate all ions produced. A possible technique for overcoming the space charge limiting condition is to introduce electrons into the accelerator system. A single set of crude data was reported, ref. 1, which did indeed suggest that electrons can greatly improve the acceleration of ions.

The first phases of the research program at CSU are reported in this paper. An experimental facility was designed, built and put into operation during the first year for the grant. A cesium contact ion rocket with provisions for the injection of electrons was also operated on a trial basis. Further work on the development of a practical rocket for the experimental study is now in progress.

A theoretical model to explain the acceleration of ions due to the counter flow of electrons is also being sought. Previous study, ref. 2, failed to indicate increases of the order experimentally observed. Thus a theoretical model based on the emission of secondary electrons from the ionizer surface was investigated during the first years' grant. The result of this study still does not give power increases as great as those observed. Further evaluation of the theoretical analysis will be necessary in order to explain the results. Apparently the use of a non-interacting steady state ion-electron flow model may be too simple for the problem.

Work is also underway to evaluate the production of secondary electrons at the ionizer. The evaluation of secondary electron emission from a porous tungsten, cesium coated ionizer is now beginning. A general literature review of secondary electron emission is included as a part of this report.

I. Vacuum Facility

The 4 foot diameter by 15 foot long, vacuum chamber built during the present grant period is shown in figures 1. The chamber is now in routine operation. Under ideal conditions the chamber can be evacuated to less than 3×10^{-7} torr in approximately 1 1/2 hours starting at atmospheric pressure. With an ion engine in operation and probes actuated through the vacuum seals, the operating pressure is usually in the 10^{-6} torr range. The operations manual for the chamber is included as appendix A of this report.

II. Cesium Contact Ion Propulsion System

As outlined in the interim report, ref. 3, a porous tungsten-cesium contact ion propulsion system was designed for the experimental study. Figure 2 is a photograph of the completed system. The complete system is mounted with ceramic insulators on a brass plate. The brass plate is in turn mounted on two rails with small ceramic insulators. The brass mounting plate is, thus, insulated both from the voltages applied to the system and also from ground potential. In this way the breakdown of accelerator voltages to ground potential requires the failure of two insulators. The porous tungsten ionizers were shown in ref. 3. Evaluation of the properties of the ionizer is still in progress. First attempts to measure the volume flow rate through the ionizers gave unrealistic values for the porosity. These measurements are being repeated with improved measuring instruments.

Limited data on the operation of the ion system has been obtained in the preliminary tests. Figure 3 is a typical set of data plotted as cesium ion current density versus cesium reservoir temperature curve. The ionizer temperature was approximately 1660°F for the data shown.

As may be seen in figure 3 a condition of space-charge-limited flow was obtained for the + 1K, -2K volt condition. Figure 4 compares the ion current density obtained for the low temperature operating conditions with data reported by Kuskevics and Thompson, ref. 4, for similar ionizers. The extrapolated agreement indicates that the porous tungsten ionizers are operating as expected.

The major difficulty encountered in operating the ion system has been the development of the ionizer heater. First attempts used tantalum heater wires imbedded in a ceramic material, Rokite A which is a sprayed alumina coating. Difficulty was encountered in making connections to the tantalum wire. Secondly, the ceramic did not adhere to the ionizer block after several thermal cycles. The tantalum wire became brittle after it was heated and could not be further worked. The tantalum heater wire was replaced in later versions by tungsten - 26 per cent rhenium wire. The 73 W-26 Re wire can be silver soldered to connections and remains ductile after repeated thermal cycles. The ionizer heaters are now swaged in a 0.06 inch diameter metal sheath. Small ceramic (MgO) insulators are placed in the metal sheath and a 0.013 inch diameter 73 W-26 Re wire is threaded down the middle of the sheathed insulators. Both tantalum and stainless steel have been used as sheath material. Tantalum sheathes became very brittle. The stainless steel melts at temperatures slightly greater than 2000°F. Tungsten - Rhenium sheath material will be employed for future heaters, however, this material costs approximately \$10 per inch which means that approximately \$120 per heater will be invested.

The insulator material, MgO, for the heater will hold a potential difference of only 30 volts at 2000°F. Thus, it is necessary to make the heaters of low resistance (1 ohm or less) to prevent arcing from the heater wire to the ionizer block which leads to failure. The heaters have been operated at 10 amps without difficulty, as long as the voltage does not exceed approximately 30 volts.

The most important point in improving the ionizer heater was the radiation shielding. Without shielding, two hundred watts were required to reach temperatures of only 1250°F at the emitter. By adding a tantalum radiation shield around the heater and ionizer block, the power required to reach 1250°F was reduced by a factor of 3. The radiation shield was made of 0.005 inch thick tantalum sheet. The front of the sheet formed the focusing electrode of the emitter. A second improvement in radiation shielding was the addition of a ceramic powder to the space between the heater and the radiation shield. Figure 5 shows the actual measured improvement obtained by the radiation shielding.

III. Thrust Augmentor

The thrust augmentor tested in the initial experimental studies is shown in the photograph of figure 6. It is a 0.01 inch diameter thoriated-tungsten wire which was used to produce electrons in the accelerator region. As the study progresses the thoriated-tungsten wire will be replaced with a pure tungsten wire, so a better controlled supply of electrons will be available.

The initial run of the electron emission thrust augmentor was limited by malfunction of the cesium reservoir heater. The reservoir could be heated to only 400°F , thus for most of the practical measurements the system was ion limited rather than space charge limited. Figure 7 shows some of the metered data taken during the initial run. Figure 7a is a block diagram of the electrical hook-up of the system. In figure 7a the current density is plotted as a function of cesium reservoir temperature.

Figure 7c shows the effect of varying the electron emission wire voltage without emitting electrons. Figure 7d shows the effect of varying the electron emission wire voltage while maintaining a constant emission between 8.6 and 9.0 milliamps of electrons. The limited reservoir temperature makes it impossible to draw definite conclusion from this preliminary data.

A theoretical analysis of a simple model of the thrust augmentor was made for the research grant. This analysis is presented as Appendix B of this report. The results of this analysis suggest that an adequate model to explain the physical observations is still lacking. Further development of the model will await more experimental measurements.

IV. Instrumentation

A group of three instruments have been developed to analyze the ion beam; a) Hot Wire Calorimeter, b) Ion Energy Analyzer, and c) Floating Emission Probe. Because of the limited operation of the ion system to date, no actual ion beam measurements have been recorded with the instruments.

A. Hot Wire Calorimeter. - Construction of the hot wire calorimeter was outlined in ref. 3. Figure 8 shows the actual probe mounted in the vacuum chamber. The sensing element is a platinum - iridium wire, 0.0004 inches in diameter and approximately 0.10 inches long. The sensing element is roughly half the length of the wires used in the original development of the calorimeter, ref. 5. The wire was shortened to reduce the radiation error encountered with the longer wires. The short wire and cooling directly at the support tips greatly reduce the background errors encountered in the original probe designs of ref. 5. The sensitivity of the wire, as determined from a calibration curve of R versus I^2 for the wire in the vacuum, as shown in figure 9, is roughly half that of the wire used in ref. 5. It remains to determine if this lesser sensitivity will be adequate for the present ion system.

The water cooled hot wire calorimeter is remotely actuated by the actuator shown on top of the vacuum chamber in figure 8. An uncooled hot wire calorimeter probe is also used in the measurements. The uncooled calorimeter is mounted to a rotating arm contained in the same mounting flange with the ion system. This uncooled calorimeter can be used to

survey the ion beam at distances from roughly 1 inch from the ionizer to distances up to 15 inches along the beam. This particular acutator system will be employed with the velocity analyzer and the floating emission probe.

B. Ion Energy Analyzer. - A energy analyzer, simular to that reported by Sellen, ref. 6, has been built for analysis of the present ion beam. A photograph of the analyzer is shown in figure 10. The electronic control of the two curved plates is still being developed. An attempt is being made to utilize the high voltage power supplies used to accelerate the ions to also supply the voltage to the analyzer plates.

C. Floating Emission Probe. - A floating emission probe built according to the specification of ref. 7 has also been constructed. Figure 11 is a photograph of this probe. The case of the probe was made of brass instead of stainless steel. Since the probe will be operated very close to the ion system it is expected that sputtered atom of the case material may get back to the ionizer. Thus, a metal such as brass or copper is preferred to stainless steel, since stainless steel materials would not necessarily melt when it deposited on the ionizer.

V. Secondary Electron Emission Study

A. Literature Survey. - A literature survey of both experimental and theoretical studies of secondary electron emission is given as Appendix C of this report.

B. Experimental Study. - A electron collector has been built to study the secondary emission from the porous tungsten ionizers. Figure 12 is a photograph of the collector. This collector is designed to evaluate the angular distribution of the secondary electrons. Provisions are also made to study the secondaries due to primary electrons striking at angles of incidence to the ionizer. The bell jar assembly where the secondary electron experiments are to be made is an integral part of the vacuum chamber.

CONCLUSIONS

The general research facility and instrumentation for the study of an ion rocket thrust augmentor was completed during the first year of the grant. The ion rocket system has been operated and preliminary data recorded. The preliminary operation of the ion system has led to normally expected difficulties, which are being solved at the present time.

REFERENCES

1. Sandborn, V. A. and Baldwin, L. V.; Hot Wire Calorimeter Study of Ion Production and Acceleration. AIAA Journal Vol. 2, No. 4, 1964.
2. Muller-Lubeck, K.; Uber Die Ambipolare Raumladungsstromung Bei Ebenen Elektroden. Lectschrift Fur Angewandte Physik, III. Band Heft II. -1951. See also Langmurs, I. ; The interaction of electrons and positive ion space charges in cathode sheaths. Physic, Rev. 33, 954 (1919).
3. Transient and Steady Performance of an Ion Rocket Thrust Augmentor. Interim Report, June, 1964 to NASA from Fluid Dynamics and Diffusion Laboratory, College of Engineering, Colorado State University, Fort Collins, Colorado.
4. Kuskevics, G. and Thompson, B. L.; Comparison of Commercial, Spherical Powder, and Wire Bundle Tungsten Ionizers. AIAA Journal Vol. 2, No. 2, 1964.
5. Baldwin, L. V. and Sandborn, V. A.; Hot-Wire Calorimetry: Theory and Application to Ion Rocket Research. NASA Technical Report R-98, 1961.
6. Sellen, J. M. and Shelton, H.; Transient and Steady State Behavior in Cesium Ion Beams. Electrostatic Propulsion, Vol. 5 Progress in Astronautics and Rocketry, Academic Press, New York, 1961.
7. Design, Development, and Fabrication of a Floating Embsive Probe for Ion Beam Diagnostics. Space Technology Laboratories, Inc. Report 9240-0186, 1963.




Figure 1. - CSU-NASA Ion Research Vacuum Facility





Figure 2. - Cesium Contact Ion Propulsion System




FIG. 3.- ION CURRENT DENSITY AS A FUNCTION OF CESIUM RESEVOIR TEMPERATURE. (IONIZER TEMPERATURE 1660 $^{\circ}\text{F}$)




FIG. 4.- COMPARISON OF MEASURED ION CURRENT DENSITY WITH PREVIOUS REPORTED DATA.




FIG. 5.- EFFECT OF RADIATION SHIELDING AND POWDER ON POWER REQUIRED TO HEAT THE IONIZER.




Figure 6. - Electron Emission Wire Across
the Ionizer Face.







FIG. 7. - OPERATION OF ION ACCELERATOR SYSTEM WITH AN ELECTRON EMITTER.



(C) CURRENT DENSITY AS A FUNCTION OF ELECTRON
EMITTER VOLTAGE (NO FORCED EMISSION)



(d) CURRENT DENSITY AS A FUNCTION OF EMITER
VOLTAGE WITH ELECTRON EMISSION
(8.5 TO 9.0 ma EMISSION)




Figure 3. - Hot Wire Calorimeter Probe Mounted
in the Vacuum Chamber.





FIG.9 CALIBRATION CURVE FOR A HOT WIRE CALORIMETER



Secondary Electron Collector
Figure 10. - ~~Ion Velocity Analyzer~~.





Figure 11. - Floating Emission Probe.




Ion Velocity Analyzer
Figure 12. - ~~Secondary Electron Collector~~.

FLUID MECHANICS AND DIFFUSION LABORATORY
COLORADO STATE UNIVERSITY
Fort Collins , Colorado

CSU HIGH VACUUM FACILITY
Manual of Operation and Schematics


August 1964



**FLUID DYNAMICS AND DIFFUSION
LABORATORY CSU FT. COLLINS**

PROJECT:	CSU HIGH VACUUM FACILITY	PROJECT NO.	1509
TITLE:	WATER, NITROGEN & AIR PRESSURE INSTALLATION		
DESIGN BY:	H. AKARI	DRAWN BY:	H. AKARI
DATE:	JULY 1964	DATE:	AUGUST 1964
		SCHEMATIC NO.	

PANEL NUMBERS



BEFORE OPERATION

Before operation of the facility all the switches and indicators have to be set according to the following description:

PANEL I

All indicators, off

Interlock lights and switches, off

PANEL II

"FORE PUMP LINE VALVE" in "AUTO"

"DIFF PUMP HEATER" in "OFF"

"BELL JAR VALVE" in "CLOSED"

"BLOWER" in "AUTO"

"CONTROL PANEL POWER" in "OFF"

All indicators are off.

"FORE PUMP LINE VACUUM" meter: High Pressure

"BELL JAR VACUUM" meter indicating: High Pressure

NRC PANEL

Power switch in "OFF"

"POWER" indicator off

"METER SELECTOR" in "TC-2"

For adjustment and calibration of the NCR panel see NCR-Manual.

PANELS III, IV, AND VIII

"AC" switch in "OFF"

"AC INPUT" indicator off

For operation of these panels, see "High voltage supplies".

VACUUM, AIR and NITROGEN VALVES

Before starting the pump-down it is necessary to check if the valves for vacuum and cooling supplies are in the proper position. The following table may help for the check out of all valves:

<u>VALVE</u>	<u>LOCATION</u>
ISOLATION VACUUM VALVE , open	1. Tower on the tank
PURGING VALVE, closed	2. Tower on the tank
EXHAUST PIPE, closed	2. Tower on the tank
BAFFLE VALVE, open	West side of the tank
BELL JAR AIR PRESS VALVE, closed	Bottom of Bell Jar
AIR LINE VALVE, open	Left side of the console
MAIN VALVE (NITROGEN), closed	Outside of the building
FILLING VALVE, closed	Outside of the building
MAIN LINE WATER VALVE, open	Left side of the console

OPERATION (Pumping-down)

- 1) The first thing to do before the operation of the vacuum facility is to set the water valves properly for the cooling of the pumps. The sequence of setting the valves is as follows:

<u>VALVE</u>	<u>LOCATION</u>
Close the "DIFF PUMP INPUT VALVE"	Downstairs
Close the "DIFF PUMP OUTLET COOLING VALVE"	"
WARNING: If the next <u>two valves</u> are not open the water line may blow out!	
Open the "Drain Cock" of the "DIFF. PUMP OUTLET COOLING VALVE"	Downstairs
Open the "POP OFF VALVE"	"

OPERATION (Pumping-down)LOCATION cont'd"

Open the "DIFF PUMP HEATER WATER DRAIN VALVE" to drain water, when this line is empty close the valve. Downstairs

Open the "BLOWER INLET VALVE" Downstairs

Open the "MECHANICAL PUMP INLET VALVE" only 1-1/2 turns Downstairs

Permanent open have to be the "DIFF PUMP WATER LINE VALVE" and the "DIFF PUMP MAIN LINE DRAIN VALVE". Downstairs

2) CONNECTION OF THE AC LINES

Switch on the "110 MAIN DISCONNECT" switch, to supply power to the console and all AC outlets. Downstairs on the south wall of the building.

Switch on the "440 MAIN DISCONNECT" switch, to supply power to the diffusion pump heaters, roughing pump and blower. Downstairs on the south wall of the building.

Switch on the "110 CONSOLE SWITCH" (red) to supply power to the panels I, III, IV, and VIII. On the left side of the console.

Switch on the "440 CONSOLE SWITCH" to supply power to the pumps and blower. On the left side of the console.

OVERLOAD OF AC LINES

If some of the AC lines are accidentally overloaded, the "CIRCUIT BREAKER LOAD CENTER" open that circuit. The breakers are: On the left side of the console.

1 "Control panel plug mold front" under the console

4-5 "30 Amps for panels II and V"

OPERATION (Pumping-down) cont'd:LOCATION cont'd:

- 13 "Control panel plug mold back
(Back of the console)
- 14 "Plug mold south end", for all the south
plug molds of the facility.
- 15 "Plug mold north end" for all the north
plug molds of the facility.

Indicators on:

- 3) Switch on "CONTROL PANEL POWER". It
switches on the power supplies of the instruments "CONTROL PANEL ON"
in the panels
- 4) Switch in NRC-panel, the "METER SELECTOR" to
"TC-2" position, "FULL SCALE mmHG" to " 10^{-3} "
- 5) Switch "ON" the NRC power switch NRC "POWER", "NRC ON"
- 6) Open "AIR LINE VALVE" for air pressure
The "AIR PRESSURE GAUGE" has to indicate
between 70 and 80 psi.
- 7) Open "MAIN LINE WATER VALVE" and adjust
valves to obtain at least: in Panel 6 for "DIFF
PUMP LINER": 5 Gal/min and for the "ROUGHING
PUMP": 2 Gal/min.
- 8) The temperature of the "DIFF PUMP LINER"
has to be less than 100° F. Panel 6.
- 9) Depress "PUMP DOWN OVERRIDE" until valve is
open and then depress "FOREPUMP START". Be
sure that the mechanical pump (Roughing pump) turns
counter clock wise looking at the pump west to east.
This pump is downstairs.
"OVERRIDE ON"
"ROUGHING PUMP ON"
"FOREPUMP VALVE
OPEN"
- 10) Set the upper and lower limits of the "FORE
PUMP LINE VACUUM" meter.

OVERLOAD OF AC LINES cont'd:

Indicators on: cont'd:

- 11) After a few minutes the blower will be automatically started. This usually takes 10 minutes when starting from atmospheric pressure in tank.
"BLOWER MOTOR"
- 12) After a certain vacuum is reached, the "OVERRIDE ON" indicator will be off. The level where the "OVERRIDE ON" indicator turns off, depends on the upper limit set in the "FORE PUMP LINE VACUUM" meter.
- 13) When the "FORE PUMP LINE VACUUM" meter indicates the upper limit, the diffusion pump can be started but first it is necessary to follow the next steps in order to operate the nitrogen's cooling system.
"WATER TEMP."
- 14) Open the "BAFFLE VALVE" and fill the baffle of the Diffusion Pump with liquid nitrogen. This can be obtained from the liquid nitrogen main tank outside of the building by opening the "FILLING VALVE".
- 15) The facility has to be operated for a longer time with the roughing pump and blower. The baffle has to be refilled continuously until the exhaust line of the baffle is completely frosted and the pressure in the facility goes down to about 3×10^{-4} mmHg.
- 16) Turn on the "DIFF PUMP HEATER" switch to "AUTO".
"DIFF PUMP HEATER ON"

- 17) When the pressure is about 1.2×10^{-6}
open the nitrogen line.
- 18) Close the "BAFFLE VALVE"
- 19) To operate the nitrogen line, open the
"MAIN VALVE", outside of the building
very slowly to approximately $1/2$ turn.
If too much nitrogen goes out in the "EXHAUST
PIPE" turn the "MAIN VALVE" back to about
 $1/4$ turn. This operation of opening more or
less the "MAIN VALVE" has to be made many
times during the operation of the facility to
get the proper flow of nitrogen.

CLOSEDOWN OPERATION

Before increasing the pressure in the tank, it is very important to disconnect all the devices in the experiment that can be damaged by the higher pressures. It is also very important to be careful with the operation of the NRC-panel when the pressure in the facility increases.

LOCATION

- 1) Turn the "DIFF PUMP HEATER" switch to "OFF" Panel II
- 2) Open the "DIFF PUMP INPUT COOLING VALVE"
very slowly avoiding too much cold water flowing
in the lowest cooling circuit. At the same time
steam will flow out from the "POP OFF VALVE"
and the "Drain cock" of the "DIFF PUMP OUTLET
COOLING VALVE". When too much cold water
flows in the lowest cooling circuit, the high temper-
ature of the lines will create steam (bubbles) and the
operator can realize their presence by the noise it
produces.

CLOSEDOWN OPERATION cont'd:LOCATION cont'd:

After 15 or 20 minutes water will flow out from the "POP OFF VALVE" and the "Drain cock of the "DIFF PUMP OUTLET COOLING VALVE", then

- 3) Close the "POP OFF VALVE" and the "Drain cock" of the "DIFF PUMP OUTLET COOLING VALVE", and at the same time open slowly the "DIFF PUMP OUTLET COOLING VALVE".

It takes approximately 2 hours until the temperature of the diffusion pump's heaters drops to about 200°F.


- | | |
|--|--------------------------|
| 4) Close the "NITROGEN MAIN VALVE". | Outside of the building |
| 5) Depress "STOP" in panel II, to turn off the mechanical pump and blower. | Panel II |
| 6) Close the "MAIN LINE WATER VALVE" | Left side of the console |
| 7) Close the "AIR LINE VALVE" | Left side of the console |




After following the above instructions it is possible to switch off the power in all the panels and equipments. It is strongly recommended to switch off the "110 CONSOLE SWITCH" (red) before touching or coming close to the high voltage connections of the facility. This switch disconnects the high voltage power supplies.

PURGING



To let air into the tank open the "EXHAUST PIPE"	2. Tower on the tank
Open the "PURGING VALVE" about 4 or 5 turns	2. Tower on the tank
and after 15 minutes open it completely.	

Open the "FORELINE PURGE VALVE"	Left side of the console.
---------------------------------	---------------------------






PROJECT: CSU VACUUM FACILITY	PROJECT NO 1509
TITLE: CONSOLE INSTRUMENT PANELS V, VI & VII	
DESIGN BY: STAFF	DRAWN BY: H. AKARI
DATE: JULY, 1964	DATE: AUGUST, 1964
SCHEMATIC NO.	
HV COMMON	
CURRENT METER	
DESIGNED: JIM CLINE	
LOCATION: PANEL VII	



FLUID DYNAMICS AND DIFFUSION LABORATORY C.S.U. FT. COLLINS		PROJECT NO. 1509
PROJECT: C.S.U. HIGH VACUUM FACILITY		
TITLE METER AMPLIFIER AND POWER SUPPLY		
DESIGN BY: C. FINN	DRAWN BY: H. AKARI	
DATE: 8/12/64	DATE: 8/31/64	
		SCHEMATIC NO.



NOTES:
 1 -- ONLY FOR THE 2KV P.S.
 2 -- ONLY FOR THE 5KV P.S.

FLUID DYNAMICS AND DIFFUSION LABORATORY CSU FT. COLLINS	
PROJECT	PROJECT NO
CSU HIGH VACUUM FACILITY	1509
TITLE HIGH VOLTAGE POWER SUPPLIES	
DESIGN BY SCINTILLONICS, INC.	DRAWN BY H. ADARI
DATE JUNE 1964	DATE SEPT. 1964
SCHEMATIC NO	

HIGH VOLTAGE POWER SUPPLIES COMPONENTS

<u>Component</u>	<u>2 KV P.S.</u>	<u>5 KV P.S.</u>
C ₁	2 μ F	1.25 μ F
C ₂	2 μ F	1.25 μ F
R1	1.8 M Ω	9 M Ω
R2	0.444 Ω	1.11 Ω
R3	1 K Ω	3.3 K Ω
R4	270 Ω	680 Ω
R5	120 Ω	270 Ω
R6	68 Ω	150 Ω
R7	47 Ω	100 Ω
R8	33 Ω	68 Ω
R9	27 Ω	47 Ω
R10	18 Ω	39 Ω
R11	15 Ω	27 Ω
R12	128 Ω	265 Ω
R13	1 K Ω	200-1000 Ω
R14	0	17 K Ω
R15	42 K Ω	100 K Ω
R16	0	22 K Ω
R17	42 K Ω	100 K Ω
R18	0	22 K Ω
R19	42 K Ω	100 K Ω
R20	0	22 K Ω
R21	42 K Ω	100 K Ω
R22	0	22 K Ω
R23	42 K Ω	100 K Ω
R24	0	22 K Ω
R25	42 K Ω	100 K Ω
R26	0	22 K Ω
R27	42 K Ω	100 K Ω
R28	0	22 K Ω
R29	42 K Ω	100 K Ω
R30	0	22 K Ω
R31	42 K Ω	100 K Ω
R32	0	22 K Ω
R33	42 K Ω	100 K Ω

