

ni

**UNION
CARBIDE**

SECOND QUARTERLY REPORT

SECONDARY ZINC-OXYGEN CELL FOR SPACECRAFT
APPLICATIONS

(23 SEPT., 1966 - 23 DEC., 1966)

CONTRACT NO. NAS-5-10247
for
GODDARD SPACE FLIGHT CENTER
GREENBELT, MARYLAND

FACILITY FORM 802	N67-39070	
	(ACCESSION NUMBER)	(THRU)
	27	1
	(PAGES)	(CODE)
	C-89311	03
	(NASA CR OR TMX OR AD NUMBER)	(CATEGORY)

Prepared by

UNION CARBIDE CORPORATION
CONSUMER PRODUCTS DIVISION
RESEARCH LABORATORY - PARMA, OHIO

SECOND QUARTERLY REPORT
SECONDARY ZINC-OXYGEN CELL FOR SPACECRAFT
APPLICATIONS

(23 SEPT., 1966 - 23 Dec., 1966)

CONTRACT NO.: NAS-5-10247

for

GODDARD SPACE FLIGHT CENTER
GREENBELT, MARYLAND

APPROVED BY:



R. A. Powers, Director

CONSUMER PRODUCTS DIVISION
RESEARCH LABORATORY
PARMA, OHIO

ABSTRACT

The test program to date has shown that the zinc-oxygen system is rechargeable with good voltage regulation over a range of cycle regimes including two-hour discharge/two-hour charge, two-hour discharge/six hour charge, and twenty-four hour discharge/twenty-four hour charge. In the two-hour discharge/two hour charge cycle, over 50 cycles have been obtained above 1.0 volt terminal discharge voltage at a zinc depth of 14 percent with 10 ampere-hour cells. Deeper zinc discharge depth to 28 percent of theoretical has been demonstrated with the twenty-four hour discharge/twenty-four hour charge cycle.

Use of a membrane type C-3 separator produced by Borden Chemical Company under contract for NASA was a factor in achieving the aforementioned cycle life on the two-hour discharge/two-hour charge regime, even though the cell was cycled with abusive overcharge and only a single layer of C-3 separator was used. A re-design of the unit test cell so as to seal the zinc electrode behind the C-3 film separator, in a chamber inaccessible to oxygen bubbles, effectively prevents oxygen from "chemically shorting" the cell. The cells are operated in a "flooded condition" with a nickel charging electrode being used to prevent oxidation of carbon catalyst in the "fixed-zone" oxygen electrode. The use of more than one layer of C-3 separator in conjunction with the mechanical cushion non-woven separator on either side of the C-3 is expected to lead to cell cycle life several times beyond that obtained to date.

While the major effort directed toward system optimization is being conducted at room temperature (25°C) cycling performance evaluations at both 0°C and 40°C have been initiated and will be continued. As of this time the cells have undergone 4 two-hour discharge/two-hour charge cycles at 0°C, and 9 cycles at 40°C at a discharge depth of 14 percent.

TABLE OF CONTENTS

	<u>Page No.</u>
ABSTRACT	ii
INTRODUCTION	1
DISCUSSION	1
A. Experimental Unit Cell Construction	1
B. Description of Electrodes	4
1. Oxygen Electrode	4
2. Rechargeable Zinc Electrode	4
C. Description of Membrane Separator	5
D. Rechargeable Unit Cell Performance	5
1. Performance at 25°C	5
2. Performance at 0°C	6
3. Performance at 40°C	6
4. Comparison of 0°, 25°, and 40°C Performance	11
NEW TECHNOLOGY	11
PROGRAM FOR NEXT REPORTING INTERVAL	11
CONCLUSIONS AND RECOMMENDATIONS	11
BIBLIOGRAPHY	33

LIST OF ILLUSTRATIONS

Figure		Page
1	Cutaway and Cross Section Views of Experimental Zinc-Oxygen Rechargeable Unit Cell.	3
2	Discharge of Rechargeable Zinc-Oxygen Unit Cell for first 50 cycles on 2 Hr Discharge/2 Hr Charge Regime at 25°C.	7
3	Terminal Discharge Voltage of Rechargeable Zinc-Oxygen Unit Cell on 2 Hr Discharge/ 2 Hr Charge at 25°C.	10
4 - 9	1st, 10th, 20th, 30th, 40th, and 50th Discharges of Rechargeable ZnO ₂ Unit Cell on 2 Hr Discharge/2 Hr Charge at 25°C.	13 - 18
10 - 12	1st, 8th, and 14th Discharge of Rechargeable Zn-O ₂ Unit Cell on 24 Hr Discharge/24 Hr Charge at 25°C.	19 - 21
13	Rechargeable Zinc Oxygen Cell Cycling 2 Hr Discharge/ 2 Hr Charge.	22
14	Rechargeable Zinc-Oxygen Cell Cycling 24 Hr Discharge/ 24 Hr Charge.	23
15 - 16	1st and 4th Discharge of Rechargeable Zn-O ₂ Unit Cell on 2 Hr Discharge/2 Hr Charge at 0°C.	24 - 25
17 - 19	1st, 5th, and 9th Discharge of Rechargeable Zn-O ₂ Unit Cell on 2 Hr Discharge/2 Hr Charge at 40°C.	26 - 28
20 - 23	Comparison of Unit Cell Performance at 0°, 25°, and 40°C on 1st, 2nd, 3rd, and 4th Discharges	29 - 32

LIST OF TABLES

	<u>Page No.</u>
Table I Components of Experimental Unit Cell	2
Table II Performance Analysis of Rechargeable Zinc-Oxygen Unit Cell - 2 Hr Discharge/2 Hr Charge (Plus 50% overcharge)	8-9

INTRODUCTION

Work conducted to date has demonstrated the feasibility of recharging the zinc-oxygen battery system. The technical approach used was based upon Union Carbide's background experience in fuel cells, Air Cells, and rechargeable battery system technology.

The testing of unit cells has proved that cycle regimes of 2 hours discharge/ 2 hours charge, 2 hours discharge/6 hours charge, 24 hours discharge/24 hours charge are practical with good discharge voltage regulation. In the case of the 2 hour discharge/2 hour charge, over 50 cycles have been obtained above the 1.0V terminal discharge voltage at a zinc depth of 14 percent of the theoretical 10 ampere hours (12.1 grams of zinc). Deeper discharge depths to 28 percent of the theoretical zinc capacity have been attained on 24 hour discharge/24 hour charge test regime.

A major contributor toward achieving the aforementioned cycle life was the use of a membrane type C-3 separator produced by Borden Chemical Company under contract for NASA. This separator effectively isolates soluble zincate in the neighborhood of the zinc electrode so that zinc treeing is minimized. Even greater improvements in cycle life are expected through the use of multiple layers of this separator.

DISCUSSION

A. Experimental Unit Cell Construction


The construction of the experimental unit cell used to investigate the zinc oxygen system is that shown in Figure 1. A detailed description of cell components is given in Table I. The cell is built by enclosing the oxygen cathode within a cast "Lucite" frame (L) patterned after the cell assembly techniques that have been developed over a period of years in the company's fuel cell work. An oxygen gas inlet and outlet are provided shown as (J) and (K). These ports communicate to the region of the porous nickel back side of the oxygen electrode interface between (H) and (G). A polypropylene screen separator (F) is used to

separate the catalyzed surface of the oxygen cathode from the nickel screen charging electrode (E). A similar polypropylene screen (D) separates the other side of the charging electrode from the separator (C) of the zinc electrode. This separator is a membrane film (C-3) produced by the Borden Chemical Company under contract for NASA (1,2). The zinc electrode (B) which completes the cell is enclosed in a basket of expanded silver metal that is spot welded to a silver sheet collector (A). The C-3 film separator is sealed to the "Lucite" frame in such a manner that the chamber holding the zinc electrode is inaccessible to oxygen bubbles that are formed at the charging electrode during cell charge. In this manner "chemical shorting" is effectively prevented. The test cells are operated in flooded condition during both discharge and charge. Oxidation of carbon catalyzed layer on the surface of the oxygen cathode is prevented during charging through the use of the nickel screen charging electrode.

TABLE I
COMPONENTS OF EXPERIMENTAL UNIT CELL

	Dimensions	Weight (g)
"Fixed-Zone" Oxygen Electrode ^(a)	3" x 3" x 0.022"	10.0
Polypropylene Screen ^(b)	3" x 3" x 0.030"	1.5
Expanded Nickel Metal ^(c) Charging Electrode	3" x 3" x 0.020"	2.6
Polypropylene Screen ^(b)	3" x 3" x 0.030"	1.5
C-3 Membrane Separator (dry) ^(d)	3" x 3" x 0.0015"	0.3
Zinc Electrode ^(a)	3" x 3" x 0.100"	12.2
Electrolyte (44% KOH + 2% ZnO dissolved therein)		25.0
Oxygen Source ^(e)	oxygen cylinder	
<hr/>		
(a) UCC Type 2 electrode		
(b) Lamport		
(c) Exmet		
(d) Borden		
(e) Linde		

FIGURE 1
CUTAWAY AND CROSS SECTION VIEWS OF EXPERIMENTAL ZINC-OXYGEN
RECHARGEABLE UNIT CELL



- A Silver sheet anode collector
- B Zinc anode restrained in a silver screen envelope
- C Separator
- D Polypropylene screen
- E Nickel Screen (Charging Electrode)
- F Polypropylene screen
- G "Fixed-Zone" oxygen electrode
- H Nickel screen cathode collector
- J Gas inlet
- K Gas Outlet
- L "Lucite" backing plates

B. Description of Electrodes

1. Oxygen Electrode

The oxygen electrode employed is the thin "fixed-zone" type that is based upon the use of an active carbon layer on one side of a thin but strong porous metal backing. This electrode was developed by Union Carbide over a period of time as an electrode combining high-rate capability with low cost (3-5). When oxygen is evolved electrochemically from a carbon-metal duplex electrode, the carbon is oxidized to form soluble quinone type compounds, it then loses its hydrophobic characteristics and the electrode becomes susceptible to flooding. A feature in the present cell is the use of a separate nickel charging electrode which is in the circuit during charging in the place of the oxygen electrode and upon which the oxygen is evolved. In this manner oxidation of the carbon catalyzed layer on the oxygen cathode is avoided during charging. Thus the reversible oxygen electrode is truly the combination of oxygen fuel cell electrode and a separate nickel screen charging electrode.

Work to date has shown that the use of a separate nickel screen charging electrode which is used exclusively for oxygen evolution in the charging mode prevents the degradation of the oxygen cathode and renders the rechargeable zinc-oxygen system feasible.

In practice the nickel screen is placed between the zinc anode and the oxygen cathode and is separated from each by a polypropylene separator. During charge, the oxygen cathode is removed from the circuit and oxygen is evolved only from the nickel screen charging electrode, while oxidized zinc is being reduced at the zinc electrode. During discharge the oxygen cathode is connected to the circuit with the zinc anode in normal fashion and the charging electrode is removed from the circuit.

2. Rechargeable Zinc Electrodes

The zinc electrode, as previously developed at Union Carbide, is made by folding an expanded silver sheet in envelope fashion so as to enclose the active zinc material. This unit is next pressed and spot-welded to a silver

backing sheet. Finally it is sealed into the plastic cell frame in such a way that the active zinc is protected by a C-3 membrane separator from oxygen evolved at the charging electrode.

C. Description of Membrane Separator

Use of a membrane type (C-3) separator produced by Borden Chemical Company under contract for NASA has contributed substantially to improved cycle life. Even when only a single layer of C-3 separator* film was used, 50 cycles of 2 hour discharge/2 hour charge were obtained above a terminal discharge voltage of 1.0 volts. This performance was obtained although an abusive 50 percent overcharge was used in the cycling regime and cell operation was essentially unattended. The use of multiple layers of C-3 separators in conjunction with a protective non-woven cushion separator on either side of C-3 is expected to substantially extend cycle life beyond 50 cycles.

The C-3 Borden film is reported to be a composition of 30 percent poly(vinyl methyl ether/maleic anhydride) in a methyl cellulose base. Such a separator has a closely controlled pore size which helps prevent the growth of zinc dendrites through the separator. This separator is further stated to be particularly resistant to oxidation, an important advantage in a zinc-oxygen rechargeable cell. The C-3 membrane effectively separates the anolyte from the catholyte thereby improving the cycle life of the cell. Soluble zincate is thus kept in the anolyte in the vicinity of the zinc electrode, so that conditions for forming of zinc trees through the separator are minimized. This film type separator of controlled pore size further minimizes the possibility of oxygen bubbles formed during charging from reaching the zinc electrode and thereby "chemically shorting" the cell.

D. Rechargeable Unit Cell Performance

1. Performance at 25°C

Unit cell performance is being evaluated on both the 2 hour discharge/

* electrolyte wet thickness = 0.0023"

2 hour charge and the 24 hour discharge/24 hour charge cycle modes. Fifty 2 hour discharge/2 hour charge cycles have been obtained above a terminal discharge voltage of 1.0 volt at 14 percent zinc depth based upon the theoretical ampere-hour equivalents of actual weight of zinc used. This performance was obtained under abusive conditions of 50 percent overcharge while the cell operated unattended with only a single layer of C-3 separator. Cycle life improvement to several hundred cycles is anticipated when multiple layers of C-3 separator are used in conjunction with a balanced charge-discharge cycle mode.

Figure 2 presents the discharge curves obtained over the first 50 abuse cycles during the operation of this cell. Table II summarizes cell performance for these 50 cycles.

Figure 3 is a graph of the cell voltage at the end of each 2 hour discharge over the same 50 cycle period.

Figures 4 through 9 present the 1st, 10th, 20th, 30th, 40th, and 50th two hour discharge on a large scale.

The unit cell operation at 25°C on the 24 hour discharge/24 hour charge cycle mode is presented in Figures 10 through 12, respectively, for the 1st, 8th, and 14th twenty-four hour discharge.

Figures 13 and 14 show the charge curves as well as the discharge curves for cells operating at 25°C at each of the 2 hour discharge/2 hour charge and 24 hour discharge/24 hour charge regimes. Both O₂ to Zn as well as Ni (charging electrode) to Zn potentials are plotted.

2. Performance at 0°C

Cell performance at 0°C on the 2 hour discharge/2 hour charge cycle has been initiated. Discharge curves for the 1st and 4th cycles are presented in Figures 15 and 16.

3. Performance at 40°C

Unit cell performance at 40°C has been conducted on the 2 hour discharge/2 hour charge cycle through 9 cycles thus far. The discharge curves obtained on the 1st, 5th and 9th cycles are presented in Figure 17 through 19.

FIGURE 2

DISCHARGE OF RECHARGEABLE ZINC-OXYGEN UNIT CELL FOR FIRST 50 CYCLES ON
2 HOUR DISCHARGE/2 HOUR CHARGE REGIME AT 25°C




TABLE II

PERFORMANCE ANALYSIS OF RECHARGEABLE ZINC-OXYGEN UNIT CELL
2 Hour Discharge - 2 Hour Charge (Plus 50% overcharge)
25°C

Discharge Number	Avg. Voltage (Volts)	Ave. Current (amperes)	Avg. Apparent Current Density ma/cm ²	Amp-Hrs Delivered
1	1.21	0.69	11.9	1.38
2	1.23	0.70	12.0	1.40
3	1.22	0.70	12.0	1.40
4	1.20	0.69	11.8	1.38
5	1.18	0.67	11.5	1.34
6	1.17	0.67	11.5	1.34
7	1.18	0.67	11.5	1.34
8	1.18	0.67	11.5	1.34
9	1.17	0.67	11.5	1.34
10	1.16	0.66	11.4	1.32
11	1.15	0.66	11.4	1.32
12	1.14	0.65	11.2	1.30
13	1.16	0.66	11.4	1.32
14	1.15	0.66	11.4	1.32
15	1.14	0.65	11.2	1.30
16	1.15	0.66	11.4	1.32
17	1.16	0.66	11.4	1.32
18	1.14	0.65	11.2	1.30
19	1.14	0.65	11.2	1.30
20	1.14	0.65	11.2	1.30
21	1.15	0.66	11.4	1.32
22	1.14	0.65	11.2	1.30
23	1.12	0.64	11.0	1.28
24	1.14	0.65	11.2	1.30
25	1.15	0.66	11.4	1.32



Continued

TABLE II-- Concluded

Discharge Number	Avg. Voltage (Volts)	Avg. Current (amperes)	Avg. Apparent Current Density ma/cm ²	Amp-Hrs Delivered
26	1.13	0.65	11.2	1.30
27	1.13	0.65	11.2	1.30
28	1.13	0.65	11.2	1.30
29	1.14	0.65	11.2	1.30
30	1.14	0.65	11.2	1.30
31	1.12	0.64	11.0	1.28
32	1.12	0.64	11.0	1.28
33	1.12	0.64	11.0	1.28
34	1.12	0.64	11.0	1.28
35	1.12	0.64	11.0	1.28
36	1.12	0.64	11.0	1.28
37	1.14	0.65	11.2	1.30
38	1.12	0.64	11.0	1.28
39	1.11	0.63	10.8	1.26
40	1.09	0.62	10.7	1.24
41	1.10	0.63	10.8	1.26
42	1.08	0.61	10.5	1.22
43	1.10	0.63	10.8	1.26
44	1.03	0.59	10.2	1.18
45	1.06	0.61	10.5	1.22
46	1.07	0.61	10.5	1.22
47	1.05	0.60	10.3	1.20
48	1.04	0.59	10.2	1.18
49	1.03	0.59	10.2	1.18
50	1.02	0.58	10.0	1.16

FIGURE 3

TERMINAL DISCHARGE VOLTAGE OF RECHARGEABLE ZINC-OXYGEN UNIT CELL
2 HOUR DISCHARGE / 2 HOUR CHARGE (Plus 50% Overcharge)
25°C



4. Comparison of 0°, 25°, and 40°C Performance

Comparison of unit cell performance on 2 hour discharge/2 hour charge cycle for the first four cycles at the three temperatures tested, 0°, 25°, and 40°C are shown in Figures 20 through 23. Examination of these figures reveals that discharge occurs at a higher voltage level at the higher temperature.

NEW TECHNOLOGY

There are no new technological advances falling within the scope of this contract to be reported at this time.

PROGRAM FOR NEXT REPORTING INTERVAL

Efforts will be concentrated on extending the cycle life of the present zinc-oxygen cell. Further modification of the unit test cell together with the use of multiple layers of Borden film type separator (C-3) will be explored. The use of a mechanical cushioning non-woven separator on either side of the C-3 films will be examined in an effort to protect the C-3 separator from mechanical puncture either from the zinc side or from the charging electrode side. Such improved cells are expected to provide even greater cycle life, substantially extending the present 50 cycles obtained on the 2 hour discharge/2 hour charge regime. Test cell evaluations of the improved cells constructed in accordance with the above will be evaluated over the 0° to 40°C temperature range of interest to NASA.

Cell tests will be conducted at 0°, 25°, and 40°C on both the 2 hour discharge/2 hour charge and 24 hour discharge/24 hour charge test regimes. The overall anticipated effort for the next reporting period will be concerned with further unit cell optimization. This will include emphasis upon (a) increasing cell cycle life, (b) optimizing cell design and minimizing required cell components from a weight and volume standpoint, and (c) increasing the depth of cell discharge.

CONCLUSIONS AND RECOMMENDATIONS


Work conducted during the present quarter has shown that the development of a rechargeable zinc-oxygen system operating with good voltage regulation for at least 50 cycles is possible. The best results were obtained with a film type

separator (C-3) made by the Borden Chemical Company under contract for NASA. This cycle life was obtained on a 2 hour discharge/2 hour charge regime at 25°C in a cell containing only a single layer of C-3 separator and which was operated at a 50 percent abusive overcharge. It is recommended that the use of multiple layers of C-3 separator in cells operating with a balanced charge-discharge test be explored. It is reasonable to expect further extensions of cycle life may result from such changes. It is recommended that such improved cells be cycled at the three temperatures of 0°, 25°, and 40°C on both the 2 hour discharge/2 hour charge and 24 hour discharge/24 hour charge test regimes in order to more completely bracket the temperature range and test regimes of interest to NASA.

Cell discharge conducted during the present quarter was taken to the 14 percent zinc depth based on the theoretical equivalent of the actual weight of zinc used in the case of the 2 hour discharge/2 hour charge regime, and to the 28 percent zinc depth in the case of the 24 hour discharge/24 hour charge regime. It is recommended deeper discharges up to the 50 percent depth be investigated during the next quarter.

FIGURE 4

1ST DISCHARGE OF RECHARGEABLE Zn-O₂ UNIT CELL



C-3310

FIGURE 5





FIGURE 6

20TH DISCHARGE OF RECHARGEABLE Zn-O₂ UNIT CELL



C-3314

FIGURE 7

30TH DISCHARGE OF RECHARGEABLE Zn-O₂ UNIT CELL




FIGURE 8

40TH DISCHARGE OF RECHARGEABLE Zn-O₂ UNIT CELL




FIGURE 9

50TH DISCHARGE OF RECHARGEABLE Zn-O₂ UNIT CELL




FIGURE 10

1ST DISCHARGE OF RECHARGEABLE Zn-O₂ UNIT CELL




FIGURE 11

8TH DISCHARGE OF RECHARGEABLE Zn-O₂ UNIT CELL




FIGURE 12

14TH DISCHARGE OF RECHARGEABLE Zn-O₂ UNIT CELL





FIGURE 13
RECHARGEABLE ZINC OXYGEN CELL
CYCLING 2 HOUR DISCHARGE/ 2 HOUR CHARGE



C-3454

FIGURE 14
RECHARGEABLE ZINC-OXYGEN CELL
CYCLING 24 HOUR DISCHARGE/24 HOUR CHARGE





FIGURE 15

1ST DISCHARGE RECHARGEABLE Zn-O₂ UNIT CELL



C-3330

FIGURE 16

4TH DISCHARGE OF RECHARGEABLE Zn-O₂ UNIT CELL




FIGURE 17

1ST DISCHARGE OF RECHARGEABLE Zn-O₂ UNIT CELL





FIGURE 18


5TH DISCHARGE OF RECHARGEABLE Zn-O₂ UNIT CELL



C-3327

FIGURE 19


9TH DISCHARGE OF RECHARGEABLE Zn-O₂ UNIT CELL



C-3329

FIGURE 20

COMPARISON OF UNIT CELL PERFORMANCE AT 0°, 25°, and 40°C
FIRST DISCHARGE



C-3332

FIGURE 21
COMPARISON OF UNIT CELL PERFORMANCE AT 0°, 25°, and 40°C
SECOND DISCHARGE




FIGURE 22
COMPARISON OF UNIT CELL PERFORMANCE AT 0°, 25°, and 40°C
THIRD DISCHARGE





FIGURE 23

COMPARISON OF UNIT CELL PERFORMANCE AT 0°, 25°, and 40°C
FOURTH DISCHARGE



C-3320

BIBLIOGRAPHY

1. H. L. Pfluger and H. H. Hoyt, "Improved Separators for Silver Oxide-Zinc and Silver Oxide-Cadmium Cells for Spacecraft Application," Final Report prepared for Goddard Space Flight Center, Contract NAS 5-3467, November 1964.
2. H. L. Pfluger and H. H. Hoyt, "Improved Separators for Silver Oxide-Zinc and Silver Oxide-Cadmium Cells for Spacecraft Application, Final Report prepared for Goddard Space Flight Center, Contract NAS 5-9107, November 1965.
3. K. V. Kordes, "Fuel Cells with Carbon Electrodes," paper presented at Fuel Cell Conference, Committee for Energy Conversion, Delegation Generale a la Recherche Scientifique et Technique, Paris, February 23-25, 1965.
4. K. V. Kordes, "Progress of the Carbon Electrode Fuel Cell," paper presented at 19th Annual Power Sources Conference, Atlantic City, N. J., May 18-20, 1965.
5. K. V. Kordes, "Carbon-Air Electrodes for Low Temperature Fuel Cells," Fuel Cell Symposium, American Chemical Society Meeting, Atlantic City, N. J., September 12-17, 1965.

NASA/Goddard Space Flight Center

OFFICIAL DISTRIBUTION LIST
FOR BATTERY REPORTS

May 1, 1967

National Aeronautics & Space Admin.
Scientific and Technical Information
Facility
College Park, Maryland 20740
Attn: NASA Representative
Send 2 copies plus 1 reproducible

National Aeronautics & Space Admin.
Washington, D. C. 20546
Attn: RNW/E.M. Cohn

National Aeronautics & Space Admin.
Washington, D. C. 20546
Attn: FC/A. M. Greg Andrus

National Aeronautics & Space Admin.
Goddard Space Flight Center
Greenbelt, Maryland 20771
Attn: Gerald Halpert, Code 735

National Aeronautics & Space Admin.
Goddard Space Flight Center
Greenbelt, Maryland 20771
Attn: Thomas Hennigan, Code 716.2
Send 3 copies

National Aeronautics & Space Admin.
Goddard Space Flight Center
Greenbelt, Maryland 20771
Attn: Joseph Sherfey, Code 735

National Aeronautics & Space Admin.
Langley Research Center
Instrument Research Division
Hampton, Virginia 23365
Attn: John L. Patterson, MS-234

National Aeronautics & Space Admin.
Langley Research Center
Instrument Research Division
Hampton, Virginia 23365
Attn: M. B. Seyffert, MS 112

National Aeronautics & Space Admin.
Lewis Research Center
21000 Brookpark Road
Cleveland, Ohio 44135
Attn: N. D. Sanders, MS 302-1

National Aeronautics & Space Admin.
Lewis Research Center
21000 Brookpark Road
Cleveland, Ohio 44135
Attn: M. J. Saari, MS 500-202

National Aeronautics & Space Admin.
Lewis Research Center
21000 Brookpark Road
Cleveland, Ohio 44135
Attn: R. R. Miller, MS 500-202

National Aeronautics & Space Admin.
Geo. C. Marshall Space Flight Center
Huntsville, Alabama 35812
Attn: Philip Youngblood

National Aeronautics & Space Admin.
Geo. C. Marshall Space Flight Center
Huntsville, Alabama 35812
Attn: Richard Boehme
Bldg. 4487-BB

National Aeronautics & Space Admin.
Manned Spacecraft Center
Houston, Texas 77058
Attn: William R. Dusenbury
Propulsion & Energy Systems Branch
Bldg. 16, Site 1

National Aeronautics & Space Admin.
Manned Spacecraft Center
Houston, Texas 77058
Attn: Richard Ferguson (EP-5)

National Aeronautics & Space Admin.
Manned Spacecraft Center
Houston, Texas 77058
Attn: Mr. Barry Trout

National Aeronautics & Space Admin.
Manned Spacecraft Center
Houston, Texas 77058
Attn: Forrest E. Eastman (EE-4)

National Aeronautics & Space Admin.
Washington, D. C. 20546
Attn: Office of Technology
Utilization

National Aeronautics & Space Admin.
Ames Research Center
Pioneer Project
Moffett Field, California 94035
Attn: Arthur Wilbur/ A. S. Hertzog

National Aeronautics & Space Admin.
Ames Research Center
Moffett Field, California 94035
Attn: Jon Rubenzer
Biosatellite Project

National Aeronautics & Space Admin.
Electronics Research Center
575 Technology Square
Cambridge, Mass. 02139
Attn: Dr. Sol Gilman

Jet Propulsion Laboratory
4800 Oak Grove Drive
Pasadena, California 91103
Attn: Mr. Aiji Uchiyama

Department of the Army

U. S. Army Engineer R & D Labs.
Fort Belvoir, Virginia 22060
Electrical Power Branch
Energy Conversion Research Lab.

Commanding General
U. S. Army Weapons Command
Attn: AMSWE-RDR, Mr. G. Reinsmith
Rock Island Arsenal
Rock Island, Illinois 61201

U. S. Army Natick Laboratories
Clothing and Organic Materials Div.,
Natick, Massachusetts 01760
Attn: G. A. Spano

Commanding Officer
U. S. Army Electronics R & D Labs
Power Sources Division
Fort Monmouth, New Jersey 07003
Attn: Code SELRA/PS

Harry Diamond Laboratories
Room 300, Building 92
Conn. Ave. & Van Ness Street, N. W.
Washington, D. C. 20438
Attn: Nathan Kaplan

Department of the Navy

Office of Naval Research
Washington, D. C. 20360
Attn: Head, Power Branch, Code 429

Naval Research Laboratory
Washington, D. C. 20390
Attn: Dr. J. C. White, Code 6160

U. S. Navy
Special Projects Division
Marine Engineering Laboratory
Annapolis, Maryland 21402
Attn: J. H. Harrison

Naval Air Systems Command
Department of the Navy
Washington, D. C. 20360
Attn: Milton Knight (Code AIR-340C)

Commanding Officer
(Code QEWE, E. Bruess/H. Schultz)
U. S. Naval Ammunition Depot
Crane, Indiana 47522

Naval Ordnance Laboratory
Department of the Navy
Corona, California 91720
Attn: William C. Spindler (Code 441)

Naval Ordnance Laboratory
Silver Spring, Maryland 20910
Attn: Philip B. Cole (Code 232)

Commander, Naval Ship Sys. Command
Department of the Navy
Washington, D. C. 20360
Attn: C. F. Viglotti (Code 66605)

Commander, Naval Ship Sys. Command
Department of the Navy
Washington, D. C. 20360
Attn: Bernard B. Rosenbaum
(Code 03422)

Department of the Air Force

Flight Vehicle Power Branch
Aero Propulsion Laboratory
Wright-Patterson AFB, Ohio 45433
Attn: James E. Cooper

AF Cambridge Research Lab.
Attn: CRE
L. G. Hanscom Field
Bedford, Massachusetts 01731
Attn: Francis X. Doherty
Edward Raskind (Wing F)

Rome Air Development Center, ESD
Attn: Frank J. Mollura (RASSM)
Griffis AFB, New York 13442

Other Government Agencies

National Bureau of Standards
Washington, D. C. 20234
Attn: Dr. W. J. Hamer

National Bureau of Standards
Washington, D. C. 20234
Attn: Dr. A. Brenner

Office, Sea Warfare System
The Pentagon
Washington, D. C. 20310
Attn: G. B. Wareham

Mr. Donald A. Hoatson
Army Reactors, DRD
U. S. Atomic Energy Commission
Washington, D. C. 20545

Bureau of Mines
4800 Forbest Avenue
Pittsburgh, Pennsylvania 15213
Attn: Dr. Irving Wender

Private Organizations

Aerojet-General Corporation
Chemical Products Division
Azusa, California 91702
Attn: William H. Johnson

Aeronutronic Division of Philco Corp.
Technical Information Services
Ford Road
Newport Beach, California 92663

Aerospace Corporation
P. O. Box 95085
Los Angeles, California 90045
Attn: Library Acquisition Group

Allis-Chalmers Mfg. Co.
1100 South 70th Street
Milwaukee, Wisconsin 53201
Attn: Dr. P. Joyner

A. M. F.
Attn: Dr. Lloyd H. Shaffer
689 Hope Street
Springdale, Connecticut 06879

American University
Mass. & Nebraska Avenue, N. W.
Washington, D. C. 20016
Attn: Dr. R. T. Foley
Chemistry Department

Arthur D. Little, Inc.
Acorn Park
Cambridge, Massachusetts 02140
Attn: Dr. Ellery W. Stone

Atomics International Division
North American Aviation, Inc.
8900 De Sota Avenue
Canoga Park, California 91304
Attn: Dr. H. L. Recht

Battelle Memorial Institute
505 King Avenue
Columbus, Ohio 43201
Attn: Dr. C. L. Faust

Bell Laboratories
Murray Hill, New Jersey 07971
Attn: U. B. Thomas

Bell Telephone Laboratories, Inc.
Whippany, N. J. 07981
Attn: D. O. Feder, Room 3B-294

The Boeing Company
P. O. Box 3868
Seattle, Washington 98124
Attn: Sid Gross, MS 85-86

Borden Chemical Company
Central Research Lab.
P. O. Box 9524
Philadelphia, Pennsylvania 19124

Burgess Battery Company
Foot of Exchange Street
Freeport, Illinois 61033
Attn: Dr. Howard J. Strauss

C & D Batteries
Division of Electric Autolite Co.
Conshohocken, Pennsylvania 19428
Attn: Dr. Eugene Willihnganz

Calvin College
Grand Rapid, Michigan 49506
Attn: Prof. T. P. Dirkse

Catalyst Research Corporation
6101 Falls Road
Baltimore, Maryland 21209
Attn: H. Goldsmith

ChemCell Inc.
150 Dey Road
Wayne, New Jersey 07470
Attn: Peter D. Richman

G. & W. H. Corson, Inc.
Plymouth Meeting
Pennsylvania 19462
Attn: Dr. L. J. Minnick

Cubic Corporation
9233 Balboa Avenue
San Diego, California 92123
Attn: Librarian
Mrs. Judy Kalak

Delco Remy Division
General Motors Corporation
2401 Columbus Avenue
Anderson, Indiana 46011
Attn: Dr. J. J. Lander

Douglas Aircraft Company, Inc.
Astropower Laboratory
2121 Campus Drive
Newport Beach, California 92663
Attn: Dr. George Moe

Dynatech Corporation
17 Tudor Street
Cambridge, Massachusetts 02139
Attn: R. L. Wentworth

E. I. duPont de Nemours & Co.
Explosives Department
Repauno Development Laboratory
Gibbstown, New Jersey 08027
Attn: Mr. R. W. Prugh
(Contract NASw-1233)

Eagle-Picher Company
Post Office Box 47
Joplin, Missouri 64801
Attn: E. P. Broglio

Electric Storage Battery Co.
Missile Battery Division
2510 Louisburg Rd.
Raleigh, North Carolina 27604
Attn: A. Chreitzberg

Electric Storage Battery Co.
Carl F. Norberg Research Center
19 West College Avenue
Yardley, Pennsylvania 19067
Attn: Dr. R. A. Schaefer

Electrochimica Corporation
1140 O'Brien Drive
Menlo Park, California 94025
Attn: Dr. Morris Eisenberg

Electro-Optical Systems, Inc.
300 North Halstead
Pasadena, California 91107
Attn: Martin Klein

Emhart Corp.
Box 1620
Hartford, Connecticut 06102
Attn: Dr. W. P. Cadogan

Engelhard Industries, Inc.
497 DeLancy Street
Newark, New Jersey 07105
Attn: Dr. J. G. Cohn

Dr. Arthur Fleischer
466 South Center Street
Orange, New Jersey 07050

General Electric Company
Schenectady, New York 12301
Attn: Dr. R. C. Osthoff/Dr. W. Carson
Advanced Technology Lab.

General Electric Company
Missile & Space Division
Spacecraft Department
P. O. Box 8555
Philadelphia, Pennsylvania 19101
Attn: E. W. Kipp, Room U-2307

General Electric Company
Battery Products Section
P. O. Box 114
Gainesville, Florida 32601
Attn: W. H. Roberts

General Electric Company
Research and Development Center
P. O. Box 8
Schenectady, New York 12301
Attn: Dr. H. Liebhafsky

General Motors-Defense Research Labs.
6767 Hollister Street
Santa Barbara, California 93105
Attn: Dr. J. S. Smatko/Dr. C. R. Russell

Globe-Union, Incorporated
P. O. Box 591
Milwaukee, Wisconsin 53201
Attn: Mr. J. D. Onderdonk
V. P. Marketing

Gould-National Batteries, Inc.
Engineering & Research Center
(Dr. D. Douglas)
2630 University Avenue, S. E.
Minneapolis, Minnesota 55418

Gulton Industries
Alkaline Battery Division
212 Durham Avenue
Metuchen, New Jersey 08840
Attn: Dr. Robert Shair

Gulton Industries
Alkaline Battery Division
212 Durham Avenue
Metuchen, New Jersey 08840
Attn: H. N. Seiger
Contract NAS W-12, 300 only

Hughes Aircraft Corporation
Centinda Ave., & Teale Street
Culver City, California 90230
Attn: T. V. Carvey

Hughes Aircraft Corporation
Bldg. 366, M. S. 524
El Segundo, California 90245
Attn: P. C. Ricks

IIT Research Institute
10 West 35th Street
Chicago, Illinois 60616
Attn: Dr. H. T. Francis

Institute for Defense Analyses
R & E Support Division
400 Army-Navy Drive
Arlington, Virginia 22202
Attn: Mr. R. Hamilton

Institute for Defense Analyses
R&E Support Division
400 Army-Navy Drive
Arlington, Virginia 22202
Attn: Dr. G. Szego

Idaho State University
Department of Chemistry
Pocatello, Idaho 83201
Attn: Dr. G. Myron Arcand

Institute of Gas Technology
State and 34th Street
Chicago, Illinois 60616
Attn: B. S. Baker

International Nickel Co.
1000-16th Street, N. W.
Washington, D. C. 20036
Attn: Wm. C. Mearns

Johns Hopkins University
Applied Physics Laboratory
8621 Georgia Avenue
Silver Spring, Maryland 20910
Attn: Richard E. Evans

Johns Hopkins University
Applied Physics Laboratory
8621 Georgia Avenue
Silver Spring, Maryland 20910
Attn: Mr. Louis Wilson

Leesona Moos Laboratories
Lake Success Park, Community Drive
Great Nick, New York 11021
Attn: Dr. H. Oswin

Livingston Electronic Corporation
Route 309
Montgomeryville, Pa. 18936
Attn: William F. Meyers

Lockheed Missiles & Space Company
Technical Information Center
3251 Hanover Street
Palo Alto, California 93404

Mallory Battery Company
Broadway & Sunnyside Lane
North Tarrytown, New York 10591
Attn: R. R. Clune

P. R. Mallory & Co., Inc.
Northwest Industrial Park
Burlington, Massachusetts 01803
Attn: Dr. Per Bro

P. R. Mallory & Co., Inc.
3029 E. Washington Street
Indianapolis, Indiana 46206
Attn: Technical Librarian

Martin Company
Denver Division
(P1001, Mr. R. C. Wildman)
Mail No. P-6700-1
Denver, Colorado 80201

Martin Company
Electronics Research Department
P. O. Box No. 179
Denver, Colorado 80201
Attn: William B. Collins, MS 1620

Mauchly Systems, Inc.
Fort Washington Industrial Park
Fort Washington, Pennsylvania
Attn: John H. Waite

Melpar
Technical Information Center
7700 Arlington Blvd.
Falls Church, Virginia 22046

Metals and Controls Division
Texas Instruments, Inc.
34 Forrest Street
Attleboro, Massachusetts 02703
Attn: Dr. E. M. Joe

Midwest Research Institute
425 Volker Boulevard
Kansas City, Missouri 64110
Attn: Physical Science Laboratory

Monsanto Research Corporation
Everett, Massachusetts 02149
Attn: Dr. J. O. Smith

North American Aviation Co.
S & ID Division
Downey, California 90241
Attn: Dr. James Nash

Oklahoma State University
Stillwater, Oklahoma 74075
Attn: Prof. William L. Hughes
School of Electrical Engineering

Paul Howard Associates Inc.
Centerville, Maryland 21617

Power Information Center
University of Pennsylvania
3401 Market St., Rm. 2107
Philadelphia, Pennsylvania 19104

Power Sources Division
Whittaker Corporation
9601 Canoga Avenue
Chatsworth, California 91311
Attn: Dr. M. Shaw

Prime Battery Corp.
15600 Cornet Street
Santa Fe Springs, California 90670
Attn: David Roller

RAI Research Corp.
36-40 37th Street
Long Island City, N. Y. 11101

Radio Corporation of America
Astro Corporation
P. O. Box 800
Hightstown, New Jersey 08540
Attn: Seymour Winkler

Radio Corporation of America
AED
P. O. Box 800
Princeton, New Jersey 08540
Attn: I. Schulman

Radio Corporation of America
415 South Fifth Street
Harrison, New Jersey 07029
Attn: Dr. G. S. Lozier
Bldg.-18-2

Southwest Research Institute
8500 Culebra Road
San Antonio, Texas 78206
Attn: Library

Sonotone Corporation
Saw Mill River Road
Elmsford, New York 10523
Attn: A. Mundel

Texas Instruments, Inc.
P. O. Box 5936
Dallas, Texas 75222
Attn: Dr. Isaac Trachtenberg

TRW Systems, Inc.
One Space Park
Redondo Beach, California 90278
Attn: Dr. A. Krausz, Bldg. 60,
Rm. 147

TRW Systems, Inc.
One Space Park
Redondo Beach, California 90278
Attn: Dr. Herbert P. Silverman

TRW, Inc.
23555 Euclid Avenue
Cleveland, Ohio 44117
Attn: Librarian

Tyco Laboratories, Inc.
Bear Hill
Hickory Drive
Waltham, Massachusetts 02154
Attn: Dr. A. C. Makrides

Unified Sciences Associates, Inc.
826 S. Arroyo Parkway
Pasadena, California 91105
Attn: Dr. S. Naiditch

Union Carbide Corporation
Development Laboratory Library
P. O. Box 6056
Cleveland, Ohio 44101

Electromite Corporation
Attn: R. H. Sparks
General Manager
562 Meyer Lane
Redondo Beach, California 90278

Union Carbide Corporation
Consumer Products Division
P. O. Box 6116
Cleveland, Ohio 44101
Attn: Dr. Robert Powers

University of Pennsylvania
Electrochemistry Laboratory
Philadelphia, Pennsylvania 19104
Attn: Prof. John O'M. Bockris

Westinghouse Electric Corporation
Research and Development Center
Churchill Borough
Pittsburgh, Pennsylvania 15235

Whittaker Corporation
3850 Olive Street
Denver, Colorado 80237
Attn: J. W. Reiter

Whittaker Corporation
Narmco R & D Division
3540 Aero Court
San Diego, California 92123
Attn: Dr. M. Shaw

Yardney Electric Corporation
40 Leonard Street
New York, New York 10013
Attn: Dr. Geo. Dalin