

BUREAU OF MINES
Pittsburgh Coal Research Center
Pittsburgh, Pennsylvania 15213

DEVELOPMENT OF AN IMPROVED OXYGEN ELECTRODE FOR USE
IN ALKALINE H₂-O₂ FUEL CELLS

Q-6

Report for Period

October 1-December 31, 1967

GPO PRICE \$ _____

CFSTI PRICE(S) \$ _____

Hard copy (HC) 3.00

Microfiche (MF) 65

ff 653 July 65

Contract NASA W-12,300

National Aeronautics and Space Administration
NASA Headquarters, Washington, D.C. 20546

68-15859

(THRU) 1

(COPIES) 10

(CATEGORY) 10

(ACCESSION NUMBER) 23

(PAGES) 492

(NASA CR OR TMX OR AD NUMBER) 582

FACILITY FORM 602

DEVELOPMENT OF AN IMPROVED OXYGEN ELECTRODE FOR USE
IN ALKALINE H_2-O_2 FUEL CELLS

The objective of this project is the synthesis of interstitial compounds for increasing the efficiency of the oxygen electrode in alkaline H_2-O_2 fuel cells. The work is being carried out for the National Aeronautics and Space Administration with Mr. E. M. Cohn as technical monitor. Principal investigators are Sayeed Akhtar, C.T. Grein, R.C. Diehl, W.H. Ryback, and D. Bienstock.

Bureau of Mines
Pittsburgh Coal Research Center

Quarterly Report for the period ending December 31, 1967

Development of An Improved Oxygen Electrode for Use
in Alkaline H₂-O₂ Fuel Cells

Summary

A total of 26 preparations were synthesized and shipped to Tyco Laboratories in this quarter. Apparatus for testing activity of cathode catalysts in the reduction of oxygen is in operation now. Selected preparations from amongst the materials synthesized so far are being induced by different methods and their activities tested. Results of different induction experiments on reduced 3Ni-1Au are presented. None of the induction methods tried so far has led to an improved catalyst.

Introduction

The object of this project is to develop catalysts for the cathodic reduction of oxygen in alkaline H₂-O₂ fuel cells. The work is being conducted in cooperation with Tyco Laboratories Inc., and the materials under investigation are the interstitial compounds of the transition metals, singly and in combinations, with carbon, nitrogen, and boron. Samples of the preparations are also sent to other firms designated by the Technical Monitor of N.A.S.A. This report deals primarily with the preparation of these compounds; information on the efficacy of the preparations in laboratory tests may be obtained from the reports of Tyco Laboratories, Inc., Waltham, Massachusetts.

Experimental

A. Preparation of Reduced Mixed Metals, Their Carbides, and Nitrocarbides

As described earlier (1), the following sequence of steps are involved:

Mixtures of salts of transition metals in solution



NaOH, 80°-90°C

Coprecipitated hydroxides



H₂, 250° or 275°C, ~ 85 hrs.

Reduced mixed metals



CO, 250°-260°C, 100 hrs.

Carbides



NH₃, 260°C, 48 hrs.

Nitrocarbide

Since platinum does not precipitate as hydroxide from a solution of its salt by the addition of NaOH, it was precipitated as Pt-black by reduction with alkaline sodium formate. The procedural details for the foregoing sequence of steps has been described earlier (2).

The mixed metals hydroxides that were reduced, carbided, and nitrocarbided during this quarter are listed in tables 1, 2, and 3, respectively.

TABLE 1.- Reduction of mixed metals hydroxides

Reducing gas: H_2
 Space velocity: $1,000 \text{ hr}^{-1}$
 Time: $\sim 85 \text{ hrs.}$

Run No.	Temperature of reduction, $^{\circ}C$	Composition of reduced material
80R ^{1/}	250	3Ni-1Pt
81R	"	1Ni-1Pt
82R	"	1Ni-3Pt
84R	275	3Ni-1Ag
85R	250	1Ag-1Pd
86R	"	3Ag-1Pd
87R	275	4Cr-1Mo
88R	250	1Au-3Pd
89R	"	1Au-1Pd
90R	"	3Au-1Pd

^{1/} The letter R stands for reduced material.

TABLE 2.- Preparation of carbides

Carbiding gas: CO Space velocity: 1,000 hr ⁻¹					
Run No.	Charge ^{1/}	Duration of carbiding, hrs.	Temp., °C	Chemical analysis, weight-percent	
				Total C	Free C
80C ^{2/}	3Ni-1Pt	4 105	160-260 260	5.96	3.40
81C	1Ni-1Pt	5 100	160-260 260	3.66	2.57
82C	1Ni-3Pt	4 105	160-260 260	1.21	0.97
84C	3Ni-1Ag	4 103	160-260 260	5.75	0.35
85C	1Ag-1Pd	5 104	160-260 260	0.29	0.10
86C	3Ag-1Pd	4 105	160-260 260	0.5	0.23
87C	4Cr-1Mo	5 103	160-260 260		
88C	1Au-3Pd	4 104	160-260 260		

^{1/} Reduced coprecipitated hydroxides.^{2/} The letter C stands for carbide.

TABLE 3.- Preparation of nitrocarbides

Nitriding gas: NH_3
 Space velocity: $1,000 \text{ hr}^{-1}$
 Time, hours: 48
 Temperature: 260°C

Run No.	Charge	Chemical analysis, weight percent		
		Total C	Free C	N
58NC ^{1/}	80C (carbided 3Ni-1Pt)	5.36	3.57	0.47
59NC	81C ^{2/} (carbided 1Ni-1Pt)	3.57	2.86	0.26
60NC	82C (carbided 1Ni-3Pt)	1.11	0.88	0.24
61NC	84C (carbided 3Ni-1Ag)	5.42	0.34	0.57
62NC	85C (carbided 1Ag-1Pd)			
63NC	86C (carbided 3Ag-1Pd)			
64NC	88C ^{2/} (carbided 1Au-3Pd)			

^{1/} The letters NC stand for nitrocarbide.

^{2/} Space velocity: $1,500 \text{ hr}^{-1}$.

X-ray analysis of the preparations 80C-84C gives evidence for the formation of nickel carbide only. It may further be noted from Table 2 that, under identical conditions of preparation, a far larger proportion of free carbon was found in the carbided 3Ni-1Pt than in the carbided 3Ni-1Ag. Since the total carbon was about the same in the two preparations, the carbidic carbon must be less in the carbided 3Ni-1Pt than in the carbided 3Ni-1Ag. Pt, it seems, tends to catalyze the decomposition of nickel carbide.


In confirmation of x-ray evidence, chemical analysis appears to indicate only negligible, if any, carbide formation in the cases of 1Ag-1Pd and 3Ag-1Pd.

B. Electrochemical Test Cell

a) Techniques

During the quarter, an apparatus was assembled to permit the electrochemical testing of the catalytic materials (figure 1). This apparatus was patterned after the floating electrode cell (3) described by Tyco Laboratories, Inc. We wish to acknowledge our sincere appreciation to the staff of Tyco Laboratories for their help in this area.

The cell is a double oxygen half-cell,



with the electrode under test consuming oxygen by the reverse reaction and a counter electrode employing the forward reaction. With the test electrode grounded, current required to maintain the counter electrode at a given potential may be determined, and, by repeated measurement, the current-voltage performance curve of the test material traced.

Since the applied potential difference associated with a given current will be decreased due to the internal resistance, R_c , of the cell, the current-potential curve, as measured, is not comparable to measurements made in a different cell. Therefore, the correction factor,

$$\Delta E = I R_c$$

is customarily added to the applied potential to allow comparison of the results of different workers. The resistance of the cell was




Figure 1- Apparatus for electrochemical testing of fuel-cell electrodes.

determined here by a relaxation technique. A known current was applied to the cell, then suddenly interrupted. The transient potential change was measured on an oscilloscope, with the instantaneous response attributed to resistive loss and the rest to capacitive decay. Then

$$\Delta E_{\text{Inst.}} / I_{\text{App.}} = R_c.$$

The reference electrode used was a hydrogen electrode of a type proposed by Giner (4). A pair of inert electrodes are immersed in the electrolyte and connected to a potential source to maintain a potential sufficient for the electrolysis of water. Once a steady state has been reached the negative electrode remains at a potential within about 30 mv of the hydrogen zero potential. The small correction required may be measured at the start or conclusion of an experiment by comparison with a truly reversible hydrogen electrode. A reference electrode of this type, operating at the potential of hydrogen evolution, is called a dynamic hydrogen electrode, or D.H.E. The D.H.E. is useful over an extreme range of pH and temperature, and lacks the elaborate equipment needed to operate a reversible hydrogen electrode for an extended period.

b) Physical Description

The physical construction of the test cell is shown in figure 2. The vessel is a 500 ml. commercial resin kettle, containing the electrolyte, 400 ml. of 35% KOH solution. The vessel is immersed in a bath of white oil thermostated at $75^{\circ} \pm 0.1^{\circ}\text{C}$. A four-hole cover provides entry for the electrical leads and for a supply of oxygen, which has been saturated with water vapor at $58^{\circ} \pm 0.1^{\circ}\text{C}$. Due to the corrosive nature of the electrolyte, all glass-to-glass contact is avoided by the use of teflon gaskets and plugs.

The support for the working electrode also serves as an isolated chamber for the D.H.E. The D.H.E. electrodes, a commercial formulation of platinum black on nickel screen bonded to platinum wire, are arranged so that oxygen generated at the positive electrode will not readily diffuse downward to the hydrogen electrode. Contact with the bulk electrolyte is through a Luggin capillary.

The counter electrode is simply a smooth platinum ring, as shown. This electrode supports the current required to maintain the working electrode at a fixed potential.




Figure 2.— Floating electrode assembly—electrochemical test cell for finely divided catalytic materials.

Electrodes to be tested are made by bonding finely-divided catalyst onto nickel screen. A standard amount, 250 mg in our experiments, of the finely-divided catalyst is kneaded with a few drops of water and a known volume of a 30% suspension of teflon. The dough-like kneaded mass is spread uniformly on an area at approximately 3 to 4 sq cm of a tightly stretched 100-mesh screen of 0.002-inch diameter nickel wire. The impregnated screen is dried for 15 minutes at 100°C and then sintered in a stream of N₂ for 5 minutes at 275°C. It is allowed to cool to room temperature in N₂ and then cut into circular discs of 1 sq cm with a sharp cork borer. The catalyst loading for each disc is calculated from the weight of the finished disc, the weight of a square centimeter of the blank screen, and the weight of sintered mass obtained from a unit volume of the teflon suspension in a separate experiment.

The disc thus obtained rests on a platinum ring on the working electrode support. A spring of platinum wire presses on the disc, to hold it in place and serve as an electrical contact. The disc is positioned just at the surface of the electrolyte but not immersed, so that electrolyte, oxygen, and catalyst are in intimate contact within the pores of the disc.

c) Circuit Description

The electrical circuitry is diagramed in figure 3. Current for the D.H.E. is furnished by a 45 volt battery, through a suitable resistance, to give a current density of 1 ma/cm² at the electrode. Provision is also made for operating the D.H.E. at 10 ma/cm². A high initial current density decreases the time required for the D.H.E. to stabilize.

For measurement of current-potential curves, the D.H.E. reference (negative) electrode and the working and counter electrodes are connected to the corresponding outputs of a potentiostat through a pair of double-pole double-throw switches. (Potentiostat requirements are rather high; the unit must be capable of handling 1.5 amps current at 1.5 volts. A commercial unit, designed primarily for electrodeposition experiments, was employed.) A ramp-step type digital voltmeter, with an input impedance of 10⁶ ohms, is connected between working and reference electrodes, and an internal galvanometer on the potentiostat indicates the output current.




Figure 3.— Electrical circuit-electrochemical test cell for finely divided catalytic materials.

The opposite poles of the two main DPDT switches connect the cell to the resistance-measuring circuit. A 90 volt battery, connected through a series of resistances, furnishes a variable current between the working and counter electrodes, which is measured on an external ammeter. The voltage thus induced, relative to the D.H.E., is applied to the vertical input of a D.C. oscilloscope. When the mercury relay is tripped, current is interrupted abruptly. The instantaneous potential drop, discussed above, is measured from the oscilloscope trace. To increase sensitivity, the oscilloscope vertical amplifier is set for maximum gain, and a small battery and potentiometer are used to oppose the voltage applied to the cell and keep the oscilloscope trace on scale.

d) Operation

In practice, the following procedure is used:

Electrolyte solution, 35% KOH by weight, is prepared fresh before use from reagent grade KOH and distilled, deionized water treated to remove biological reducing agents. The newly prepared electrode disc is placed on the support and brought into surface contact with the electrolyte at 75°C. A slight stream of oxygen is passed over the electrolyte. The cell requires several hours to come to its resting potential; during this time, the D.H.E. is standardized.

The D.H.E. is initially operated at 10 ma/cm² current density for two minutes, to clear the electrode surfaces, then at 1 ma/cm². The potential of two identical reversible hydrogen electrodes is compared, to assure consistency, and one of the reversible electrodes is then compared to the D.H.E. The potential of the D.H.E. was found to stabilize within 10 minutes at the lower current density and remain constant, within ± 1 mv, over a 6-hour period.

Once a stable resting potential is reached, a potential sweep is begun, starting at the rest potential and proceeding to zero. Current readings are taken at 25 and 50 mv intervals. The time required for the current to stabilize at the first point is noted, and all successive current readings are taken after equal stabilization periods. Upon completion of the downward sweep, a sweep upward to the rest potential is made.

Upon completion of the potential sweeps, the cell internal resistance is measured. A current is applied to the cell, and its value is adjusted to a convenient value (usually 25 ma). The potential of the bias circuit is adjusted so that the trace appears on scale at highest gain. The current is interrupted, and the transient recorded with an oscillograph camera for more leisurely evaluation. Average resistance for the teflon-bound discs is 0.7-0.8 ohm.

Graphically presented results include both IR-corrected and uncorrected curves.

e) Calibration

To evaluate the effectiveness of the apparatus, two samples of American Cyanamid Type AB-4 fuel cell electrode material were tested by the above procedure. AB-4 is a platinum black on nickel screen, but teflon is not employed as a binder. The test results are shown in table 4. The two samples gave identical values in the range indicated. The values obtained are in good agreement with other studies of commercial platinum electrodes in this system (5).

TABLE 4.- Performance of American Cyanamid
type AB-4 electrode

<u>I, ma/cm^2</u>	<u>E, (IR-free) mv (vs. hydrogen zero)</u>
8	975
22	950
55	925
90	900

f) Activity Tests on 74R (3Ni-1Au) and 74C (3Ni-1Au, carbided)

A series of tests were performed on 74R and 74C, as such and modified by various methods of pretreatment. The results are presented in Figures 4-9. For secondary reasons, the internal resistance of the cell could not be determined in certain cases; hence, some of the curves are not corrected for IR drop.

Figures 4 and 5 were obtained with 3Ni-1Au when the loadings were different, whereas figures 6 and 7 were obtained with the same material after samples of it were treated with petroleum ether for different lengths of time. In one case, the material was left exposed to air for 24 hours after removal of petroleum ether. Each of the materials was then fabricated into two electrodes, one of which was tested immediately after preparation and the other 24 hours later. It will be seen that, in all cases, the activity of 3Ni-1Au was adversely affected by these treatments.

As is known, with a very few exceptions, finely divided reduced transition metals and their carbides are very sensitive to atmospheric oxidation, which leads to serious loss of their catalytic activity. The purpose of these pretreatments was an attempt to reduce their extraordinary reactivity with oxygen by covering the surface with a thin layer of oxide film by slow access of oxygen.

However, as has been pointed out, the activity of the material so treated was found to be far lower than that of the untreated 3Ni-1Au. Exposure to H₂S vapors poisoned both reduced 3Ni-1Au (fig. 8) and carbided 3Ni-1Au (fig. 9).

Work Plan

Further treatment of the preparations to prevent their oxidation and thus conserve their catalytic activity will be continued. A selected number of the materials which, on the basis of the earlier screening by Tyco Laboratories, appeared to offer better promise will be more intensively investigated. The few remaining preparations agreed upon with the technical monitor of N.A.S.A. will be completed.

References

- (1) Quarterly Report to N.A.S.A. for the quarter ended September 30, 1967, Q-5, Development of an Improved Oxygen Electrode for Use in Alkaline H₂-O₂ Fuel Cells, Bureau of Mines, Pittsburgh Coal Research Center, Pittsburgh, Pa.
- (2) Quarterly Report to N.A.S.A. for the quarter ended June 30, 1967, Q-4, Development of an Improved Oxygen Electrode for Use in Alkaline H₂-O₂ Fuel Cells, Bureau of Mines, Pittsburgh Coal Research Center, Pittsburgh, Pa.
- (3) Report to N.A.S.A. for the Period ending January 31, 1966, Development of Cathodic Electrocatalysts for Use in Low Temperature H₂/O₂ Fuel Cells with an Alkaline Electrolyte, Tyco Laboratories, Inc., Bear Hill, Waltham, Mass., pp. 18-21.
- (4) Giner, J., A Practical Reference Electrode. J. Electrochem. Soc., v. 111, No. 3, 1964, pp. 376-377.
- (5) Quarterly Report to N.A.S.A. for the period ending June 30, 1966, Q-4, Development of Cathodic Electrocatalysts for Use in Low Temperature H₂/O₂ Fuel Cells with an Alkaline Electrolyte, Tyco Laboratories, Inc., Bear Hill, Waltham, Mass., p. 67.




Figure 4.—i-E curve for 3Ni-1Au in the reduction of O₂.




Figure 5.—i-E curve for 3Ni-1Au in the reduction of O₂.




Figure 6.— i — E curve for 3Ni —1Au, treated with pet. ether for 135 hours.




Figure 7.—i-E curve for 3Ni-1Au, treating with pet ether.




Figure 8.— i-E curve for 3 Ni-1Au treated with H₂S.




Figure 9.— i - E curve for 3Ni-1Au, carbided.

APPENDIX I

Samples shipped to Tyco Laboratories this quarter -----	26
Samples shipped to Tyco Laboratories to date -----	205
Samples shipped to non-cost users this quarter -----	none
Samples shipped to non-cost users to date -----	337

OFFICIAL DISTRIBUTION LIST

NASA and JPL

National Aeronautics & Space Admin.
Scientific and Technical Information
Facility
College Park, Maryland 20740
Attn: NASA Representative
Send 2 copies + 1 reproducible

National Aeronautics & Space Admin.
Washington, D.C. 20546
Attn: RNW/E.M. Cohn

National Aeronautics & Space Admin.
Washington, D.C. 20546
Attn: MAT/G.F. Esenwein

National Aeronautics & Space Admin.
Washington, D.C. 20546
Attn: FC/A.M. Greg Andrus

National Aeronautics & Space Admin.
Washington, D.C. 20546
Attn: MLT/T. Albert

National Aeronautics & Space Admin.
Goddard Space Flight Center
Greenbelt, Maryland 20771
Attn: Thomas Hennigan, Code 716.2

National Aeronautics & Space Admin.
Langley Research Center
Langley Station
Hampton, Virginia 23365
Attn: John Patterson

National Aeronautics & Space Admin.
Lewis Research Center
21000 Brookpark Road
Cleveland, Ohio 44135
Attn: Mr. Robert Miller

National Aeronautics & Space Admin.
Washington, D.C. 20546
Attn: Office of Technology Utilization

National Aeronautics & Space Admin.
Lewis Research Center
21000 Brookpark Road
Cleveland, Ohio 44135
Attn: M.J. Saari
MS 500-202

National Aeronautics & Space Admin.
Lewis Research Center
21000 Brookpark Road
Cleveland, Ohio 44135
Attn: Mr. N.D. Sanders

National Aeronautics & Space Admin.
Marshall Space Flight Center
Huntsville, Alabama 35812
Attn: Mr. Richard Boehme
R-ASTR-E

National Aeronautics & Space Admin.
Marshall Space Flight Center
Huntsville, Alabama 35812
Attn: Mr. Charles Graff
R-ASTR-EAP

National Aeronautics & Space Admin.
Ames Research Center
Pioneer Project
Moffett Field, California 94035
Attn: Mr. John Rubenzer

National Aeronautics & Space Admin.
Manned Spacecraft Center
Houston, Texas 77001
Attn: Mr. William R. Dusenbury

National Aeronautics & Space Admin.
Manned Spacecraft Center
Houston, Texas 77001
Attn: Mr. Hoyt McBryar
EP-5, Building 16

National Aeronautics & Space Admin.
Manned Spacecraft Center
Houston, Texas 77001
Attn: Mr. Forrest Eastman

National Aeronautics & Space Admin.
Electronics Research Center
575 Technology Square
Cambridge, Mass. 02139
Attn: Dr. Sol Gilman

Jet Propulsion Laboratory
4800 Oak Grove Drive
Pasadena, California 91103
Attn: Mr. Aiji Uchiyama

Department of the Army

U.S. Army Engineer R&D Labs.
Fort Belvoir, Virginia 22060
Attn: Energy Conversion Research Lab.

Commanding General
U.S. Army Electronics R&D Labs.
Attn: Code AMSEL-KL-P
Fort Monmouth, New Jersey 07703

Harry Diamond Labs.
Room 300, Building 92
Conn. Ave & Van Ness St., N.W.
Washington, D.C. 20438
Attn: Mr. Nathan Kaplan

U.S. Army Natick Laboratories
Clothing & Organic Materials Div.
Natick, Mass. 01760
Attn: Leo A. Spano

Department of the Navy

Office of Naval Research
Department of the Navy
Washington, D.C. 20300
Attn: Dr. Ralph Roberts/H.W. Fox

U.S. Naval Research Laboratory
Washington, D.C. 20390
Attn: Dr. J.C. White
Code 6160

Commander, Naval Ship System Command
Department of the Navy
Washington, D.C. 20350
Attn: Mr. Bernard B. Rosenbaum

Commander, Naval Ship System Command
Department of the Navy
Washington, D.C. 20350
Attn: Mr. C.F. Viglotti

Naval Ordnance Laboratory
Department of the Navy
Corona, California 91720
Attn: Mr. William C. Spindler
Code 441

Naval Ordnance Laboratory
Silver Spring, Maryland 20910
Attn: Mr. Philip B. Cole
Code 232

U.S. Navy Marine Engineering Lab.
Special Projects Division
Annapolis, Maryland 21402
Attn: J.H. Harrison

Department of the Air Force

Wright-Patterson AFB
Aeronautical Systems Division
Dayton, Ohio 45433
Attn: James E. Cooper, AP1P-2

AF Cambridge Research Lab.
Attn: CRE
L.G. Hanscom Field
Bedford, Mass. 01731
Attn: Francis X. Doherty
Edward Raskind (Wing F)

Rome Air Development Center
Griffiss AFB, New York 13442
Attn: Mr. Frank J. Mollure
(RASSM)

Other Government Agencies

Mr. Donald A. Hoatson
Army Reactor, DRD
U.S. Atomic Energy Commission
Washington, D.C. 20545

Office, DDR&E: Sea Warfare Systems
The Pentagon
Washington, D.C. 20301
Attn: G.B. Wareham

Mr. D. Bienstock
Bureau of Mines
4800 Forbes Avenue
Pittsburgh, Pa. 15213

Mr. John S. Tosh
Bureau of Mines
Interior Building
Washington, D.C. 20240

Private Organizations

Aeronutronic Division of Philco Corp.
Technical Information Services
Ford Road
Newport, California 92663

Allis-Chalmers Mfg. Co.
1100 S. 70th St.
Milwaukee, Wisconsin 53214
Attn: John W. McNeil
Mgr., Marketing Res. Div.
#3349

Allis-Chalmers Mfg. Co.
1100 S. 70th St.
Milwaukee, Wisconsin 53214
Attn: Dr. D. Pouli

Allison Division of General Motors
Indianapolis, Indiana 46206
Attn: Dr. Robert E. Henderson

American Cyanamid Company
1937 W. Main Street
Stamford, Connecticut 06901
Attn: Dr. R.G. Haldeman

American Oil Company
2500 New York Avenue
Whiting, Indiana 46394
Attn: Dr. R. J. Flannery

American Machine & Foundry
689 Hope Street
Springdale, Connecticut 06879
Attn: Dr. L.H. Shaffer
Research Division

Arthur D. Little, Inc.
Acorn Park
Cambridge, Mass. 02140
Attn: Dr. Ellery W. Stone

Aerospace Corp.
P.O. Box 95085
Los Angeles, California 90045
Attn: Tech. Library Acquisitions Group

Atomics International Division
North American Aviation, Inc.
8900 De Soto Avenue
Canoga Park, California 91304
Attn: Dr. H.L. Recht

Battelle Memorial Institute
505 King Ave.
Columbus, Ohio 43201
Attn: Dr. C.L. Faust

Bell Telephone Laboratories, Inc.
Murray Hill, New Jersey 07971
Attn: U.B. Thomas

Catalyst Research Corp.
6101 Falls Road
Baltimore, Maryland 21209
Attn: Mr. James R. Moser

ChemCell Inc.
150 Dey Road
Wayne, New Jersey 07470
Attn: Peter D. Richman

Clevite Corporation
Mechanical Research Division
540 East 105th Street
Cleveland, Ohio 44108
Attn: D.J. Berger

G. & W.H. Corson, Inc.
Plymouth Meeting
Pennsylvania 19462
Attn: Dr. L.J. Minnick

Douglas Aircraft Company, Inc.
Astropower Laboratory
2121 Campus Drive
Newport Beach, California 92663
Attn: Dr. Carl Berger

Electrochimica Corp.
1140 O'Brien Drive
Menlo Park, California 94025
Attn: Dr. Morris Eisenberg

Electro-Optical Systems, Inc.
300 North Halstead Street
Pasadena, California 91107
Attn: Martin Klien

Engelhard Industries, Inc.
497 Delancy Street
Newark, New Jersey 07105
Attn: Dr. J.G. Cohn

Esso Research and Engineering Co.
Government Division
P.O. Box 8
Linden, New Jersey 07036
Attn: Dr. C.E. Heath

The Franklin Institute
Philadelphia, Penna. 19103
Attn: Mr. Robert Goodman

Garrett Corporation
1625 Eye St., N.W.
Washington, D.C. 20013
Attn: Mr. Bowler

General Dynamics/Convair
P.O. Box 1138
San Diego, Calif. 92112
Attn: Mr. R.P. Mikkelsen
Electrical Systems Dept. 988-7

Dynatech Corp.
17 Tudor Street
Cambridge, Mass. 02139

General Electric Company
Direct Energy Conversion Operation
930 Western Ave.
Lynn, Massachusetts 01901
Attn: E.L. Weissman

General Electric Company
Research & Development Center
P.O. Box 8
Schenectady, New York 12301
Attn: Dr. H. Liebhafsky

General Electric Company
777-14th St., N.W.
Washington, D.C. 20005
Attn: Philip C. Hargraves

General Motors Corp.
Box T
Santa Barbara, California 93102
Attn: Dr. C.R. Russell

Globe-Union, Inc.
P.O. Box 591
Milwaukee, Wisconsin 53201
Attn: J.D. Onderdonk,
V.P., Marketing

Galton Industries, Inc.
212 Durham Ave.
Metuchen, New Jersey 08840
Attn: Dr. Harvey N. Seiger
Director of Research

Ionics, Incorporated
65 Grove Street
Watertown, Massachusetts 02172
Attn: Dr. Werner Glass

Institute for Defense Analyses
Research & Engineering Support Div.
400 Army Navy Drive
Arlington, Virginia 22202
Attn: Dr. George C. Szego

Institute for Defense Analyses
Research & Engineering Support Div.
400 Army Navy Drive
Arlington, Virginia 22202
Attn: Dr. R. Briceland

Institute of Gas Technology
State and 34th Streets
Chicago, Illinois 60616
Attn: Dr. B.S. Baker

Johns Hopkins University
Applied Physics Laboratory
8621 Georgia Avenue
Silver Spring, Maryland
Attn: Richard Cole

Johns-Manville R&E Center
P.O. Box 159
Manville, New Jersey 08835
Attn: J.S. Parkinson

Leesona Moos Laboratories
Lake Success Park
Community Drive
Great Neck, New York 11021
Attn: Dr. A. Moos

Livingston Electronic Corp.
Route 309
Montgomeryville, Pa. 18936
Attn: William F. Meyers

Lockheed Missiles & Space Co.
Technical Information Center
3251 Hanover Street
Palo Alto, California 93404

LTV Research Center
P.O. Box 5907
Dallas, Texas 75222
Attn: Madison Reed

McDonnell Aircraft Corporation
Attn: Project Gemini Office
P.O. Box 516
St. Louis, Missouri 63166

Midwest Research Institute
425 Volker Boulevard
Kansas City, Missouri 64110
Attn: Physical Science Library

Monsanto Research Corporation
Boston Laboratories
Everett, Massachusetts 02149
Attn: Dr. J.O. Smith

Monsanto Research Corporation
Dayton Laboratory
Dayton, Ohio 45407
Attn: Librarian

North American Aviation Co.
S&ID Division
Downey, California 90241
Attn: Dr. James Nash

Oklahoma State University
Stillwater, Oklahoma 74075
Attn: Prof. William L. Hughes
School of Electrical Engineering

Power Information Center
University of Pennsylvania
Moore School Building
200 South 33rd Street
Philadelphia, Pennsylvania 19104

Radio Corporation of America
Astro Division
P.O. Box 800
Hightstown, New Jersey 08540
Attn: Dr. Seymour Winkler

Rocketdyne
6633 Canoga Avenue
Canoga Park, California 91304
Attn: Library, Dept. 086-306-Zone 2

Speer Carbon Company
Research & Development Laboratories
Packard Road at 47th Street
Niagara Falls, New York 14304
Attn: W.E. Parker

Stanford Research Institute
820 Mission Street
So. Pasadena, California 91108
Attn: Dr. Fritz Kalhammer

Texas Instruments, Inc.
P.O. Box 5936
Dallas, Texas 75222
Attn: Mr. Issac Trachtenberg

TRW, Inc.
23555 Euclid Avenue
Cleveland, Ohio 44115
Attn: Dr. R.A. Wynveen

TRW Systems
One Space Park
Redondo Beach, Calif. 90278
Attn: Dr. A. Krausz

Tyco Laboratories, Inc.
Bear Hill
Hickory Drive
Waltham, Massachusetts 02154
Attn: Dr. A.C. Makrides

Tyco Laboratories, Inc.
Bear Hill
Hickory Drive
Waltham, Massachusetts 02154
Attn: Dr. John Parry

Unified Science Associates, Inc.
826 S. Arroyo Parkway
Pasadena, California 91105
Attn: Dr. Sam Naiditch

Union Carbide Corporation
Electronics Division
P.O. Box 6116
Cleveland, Ohio 44101
Attn: Dr. George E. Evans

United Aircraft Corporation
400 Main Street
East Hartford, Connecticut 06108
Attn: Library

University of Pennsylvania
Electrochemistry Laboratory
Philadelphia, Pennsylvania 19104
Attn: Prof. John O'M. Bockris

University of Pennsylvania
Institute for Direct Energy Conversion
260 Towne Building
Philadelphia, Penna. 19104
Attn: Dr. Manfred Altman

Western Reserve University
Department of Chemistry
Cleveland, Ohio 44101
Attn: Prof. Ernest Yeager

Westinghouse Electric Corp.
Research & Development Center
Churchill Borough
Pittsburgh, Penna. 15235
Attn: Dr. A. Langer

Whittaker Corporation
Narmco R&D Division
3540 Aero Court
San Diego, Calif. 92123
Attn: Dr. M. Shaw

Yardney Electric Corp.
40 Leonard Street
New York, New York 10013
Attn: Dr. George Dalin

Zaromb Research Corp.
376 Monroe Street
Passaic, New York 07055

Olin Matheson Chemical Corp.
275 Winchester Avenue
New Haven, Connecticut 06504
Attn: Dr. R. E. Maizell

Mr. Harold Hirsch
R & D Center, Rm. 249MB
General Electric
P.O. Box 8
Schenectady, New York 12301

Dr. Carl Berger
Electrochemical & Water Desalination Tech.
13401 Kootenay Drive
Santa Ana, California 92705