

AVSSD-0323-67-CR
Revision 1

STERILIZATION ASSEMBLY DEVELOPMENT LABORATORY
"CMTM BIOLOGICAL MONITORING PLAN"

PHASE II


10 October 1967
Task 7
JPL CONTRACT 951624

THIS WORK WAS PERFORMED FOR THE JET PROPULSION
LABORATORY, CALIFORNIA INSTITUTE OF TECHNOLOGY,
SPONSORED BY THE NATIONAL AERONAUTICS AND SPACE
ADMINISTRATION UNDER CONTRACT NAS7-100.

Prepared by

AVCO CORPORATION
SPACE SYSTEMS DIVISION
Lowell, Massachusetts

for



JET PROPULSION LABORATORY
CALIFORNIA INSTITUTE OF TECHNOLOGY
PASADENA, CALIFORNIA

CFSTI PRICE(S) \$ _____

Hard copy (HC) 3.00

Microfiche (MF) _____

ff 653 July 65

FACILITY FORM 602

N68-22524
(ACCESSION NUMBER) (THRU)
94
(PAGES) (CODE)
05
(CATEGORY)
0794370
(NASA CR OR TMX OR AD NUMBER)

STERILIZATION ASSEMBLY DEVELOPMENT LABORATORY

CMTM BIOLOGICAL MONITORING PLAN

PHASE II

10 October 1967
Task 7
JPL CONTRACT 951624

PREPARED BY: *Paul A. Kales*
P. A. Kales
AVCO CORPORATION

APPROVED BY: *E. J. Lunney*
E. J. Lunney
AVCO CORPORATION

APPROVED BY: *Dr. E. A. Botan*
Dr. E. A. Botan
AVCO CORPORATION

APPROVED BY: *W. W. Paik*
W. W. Paik
JET PROPULSION LABORATORY

APPROVED BY: *G. H. Redmann*
G. H. Redmann
JET PROPULSION LABORATORY

JET PROPULSION LABORATORY
CALIFORNIA INSTITUTE OF TECHNOLOGY
PASADENA, CALIFORNIA

CHANGES

Page No.	Description	Date
AVSSD-0323-67-CR	Initial Issue	15 August 1967
AVSSD-0323-67-CR	Revision 1	10 October 1967

-NOTE-

This report contains information prepared by AVCO Corporation, Space Systems Division, under JPL subcontract. Its content is not necessarily endorsed by the Jet Propulsion Laboratory, California Institute of Technology, or the National Aeronautics and Space Administration

A B S T R A C T

This report defines the locations for the bioassay coupons to be attached to the surfaces of the CMM sub-system assemblies for removal during assembly operations. Included are coupon removal schedules, the designation of coupons to be assayed, and modifications which can be applied to the schedule for conducting related studies.

TABLE OF CONTENTS

I	INTRODUCTION	1
II	COUPON IDENTIFICATION	3
III	COUPON PLACEMENT	5
IV	COUPON REMOVAL	7
V	POSSIBLE MODIFICATIONS	11
APPENDIX A.	DISPOSITION OF COUPONS ON CMTM SURFACES	13
APPENDIX B.	COUPON REMOVAL SCHEDULE	23
APPENDIX C.	POST QUARANTINE COUPON REMOVAL SCHEDULE	31
APPENDIX D.	DESCRIPTIONS OF SURFACE AREAS, ZONES AND COUPON QUANTITIES	35
APPENDIX E.	ILLUSTRATIONS OF COUPON LOCATIONS	61

ILLUSTRATIONS

FIGURE NO.		PAGE
1	Identification of Coupons	4
2	Zone Definition - Aeroshell Outside Surface	41
3	Zone Definition - Aeroshell Inner Surface	42
4	Zone Definition - Aeroshell - Attitude Control System	43
5	Zone Definition - Impact Limiter	49
6	Zone Definition - De-orbit Motor	52
7	Coupon Locations - Aeroshell - Top View	63
8	Coupon Locations - Aeroshell - Side View	64
9	Coupon Locations - Aeroshell - Support Ring	65
10	Coupon Locations - Aeroshell - Support Ring (cont.)	66
11	Coupon Locations - Aeroshell - Under Side	67
12	Coupon Locations - Aeroshell - Inside Surface Cylindrical Section	68
13	Coupon Locations - Aeroshell - Fuel Tank Brackets	69
14	Coupon Locations - Marmon Clamp	70
15	Coupon Locations - Canister	71
16	Coupon Locations - Dummy Chassis	72
17	Coupon Locations - Live Chassis	73
18	Coupon Locations - Impact Limiter	74
19	Coupon Locations - De-orbit Motor	75
20	Coupon Locations - De-orbit Motor - Clamp	76
21	Coupon Locations - De-orbit Motor Harness	77
22	Coupon Locations - Parachute Canister	78
23	Coupon Locations - Antenna	79

ILLUSTRATIONS (Concl'd)

FIGURE NO.		PAGE
24	Coupon Locations - Payload Chassis - Outside Surface	80
25	Coupon Locations - Payload - Bottom View	81
26	Coupon Locations - Payload - Top View	82
27	Coupon Locations - Umbilical Plate	83
28	Coupon Locations - Umbilical Flange	84
29	Coupon Locations - Bay 8 Umbilical Harness	85

I. INTRODUCTION

This report defines coupon locations and the removal schedule to be applied to the Capsule Mechanical Training Model (CMIM) for the evaluation of surface microbial burden during assembly operations. The discussion makes reference to the SADL assembly operation, which presumes an ETO exposure prior to admission into the Sterile Assembly Development Laboratory (SADL). It is also presumed that the system will be built according to the prescribed SADL operations procedure. However, provisions have been made to accommodate variations to the plan, including assembly in a high bay area, assembly under a laminar flow tent, and a quarantine period for the CMIM after the buildup.

Acknowledgement must be made to Keith Bateman for preparation of the drawings in Appendix E.


II. COUPON IDENTIFICATION.

This design calls for 1390 coupons to be used. Many of these will be decoys, which will not be assayed. This is discussed in section IV.

A five character code will be used for identifying each coupon, and it will also identify the subsystem assembly and location. The first character will be a letter identifying the subsystem assembly to which the coupon is attached. The letter A will indicate that the coupon will be attached to part of the aeroshell, B to the band assembly clamp, C to the sterilization canister, D to part of the seven dummy chassis or live data encoder, I to the impact limiter, M to the deorbit motor, P to the parachute canister, R to the relay link antenna, S to the payload structure, and U to the umbilical chord assembly.

The next two characters will be a two digit number identifying the zone. The final two digit number will identify the coupon number within the zone. As an example, coupon number A04-07 is the seventh coupon of the fourth zone of the aeroshell assembly.

Figure 1. Identification of Coupons



Zones 1 and 2 of the aeroshell are the only zones which have more than 100 coupon assignments. An X as the second character will indicate a coupon number between 100 and 199, and a Y will indicate a coupon between 200 and 299. As examples, the first coupon of zone 1 of the aeroshell assembly will be identified as A01-01, the one hundredth will be identified AX1-00, and the two hundredth will be AY1-00.

III. COUPON PLACEMENT.

A Task 7 requirement was to identify coupon locations on the CMM subsystem assembly surfaces. The locations for 1390 coupons are identified by crosses marked on the hardware surfaces. Coupon identification numbers are also marked on the hardware surfaces at the proper locations.

It is expected that the coupons will be placed approximately within two inches of the location marks. They should be placed in a manner which will preclude their impeding the assemblers, which will minimize the chance of their falling off during transportation and assembly, and which will facilitate application and removal at the proper time.

Appendix D describes and identifies the zones and lists the number of coupons to be used in each. The number of coupons to be used in each zone can also be taken from Appendix A. Appendix E contains subsystem assembly drawings which illustrate the locations for the coupons.

The time at which the coupons are to be attached will be specified along with the instructions for each assembly plan. The next section deals with the time at which the coupons are to be removed.

IV. COUPON REMOVAL.

There will be nine removal periods during the SADL assembly operations.

1. Post FA, as the parts arrive into the SADL from the ETO chamber, just prior to the buildup.
2. After the eight chassis are assembled to the payload assembly and the appropriate Quality Assurance checks are completed.
3. After the impact limiter is lowered onto the payload structure assembly.
4. After the aeroshell is assembled onto the payload structure assembly.
5. After the parachute canister is assembled onto the payload structure.
6. After the deorbit motor is assembled to the payload structure assembly.
7. After the assembly of the relay antenna. At this point the CMM is built.

8. After the CMTM is lowered into the sterilization canister bottom and the umbilical cord is being pulled through its port and connected to its plate.

9. After the systems test, just prior to mating the sterilization canister cover.

At each of these nine operations, the coupons designated for removal and assay are to be taken off first. These coupons must remain identified, and the date and time of removal must be recorded. The schedule in Appendix B lists the coupons to be removed for assay during each of the nine operations. If a coupon designated for removal is lost, accidentally falls off, or for some other reason cannot be used for an assay, the nearest dummy coupon can be substituted. Appendix A identifies which are the dummy coupons.

In addition to providing substitutes when a coupon designated for an assay cannot be used, the dummy coupons also serve as decoys for the assemblers to reduce bias when the CMTM hardware is being handled. These however must be taken off from zones before they are to be occluded by the next assembly operation. Their removal, which can be a more careless one, should take place after the coupons destined for assays are removed, identi-

fied and dated. Appendix B lists the zones from which all the (dummy) coupons are to be removed during each operation.

Use the drawings of Appendix E to help locate the coupons.

V. POSSIBLE MODIFICATIONS.

A. High Bay and Laminar Flow Tent Assemblies.

For a normal SADL assembly operation, there will be a total of 500 coupons to be assayed. There are also plans for a series of buildups outside the SADL. These will not be preceded by the FA test or by the ETO treatment. Also, the CMM will not be assembled into the sterilization canister. Hence, application of the schedules of Appendix B will lead to less than 500 assayed coupons.

B. CMM Quarantine Period.

During some buildups a quarantine period will be required after the CMM is built. In these cases, additional coupons will be removed for assay. The removal schedule for the quarantine period termination appears in Appendix C.

When a quarantine period is to take place, there will be no dummy coupon removal at Estimation Point 7. The dummy coupons scheduled for removal at Estimation Point 7 will be removed after the quarantine period instead.

The date and time of the quarantine period must be recorded when the coupons to be assayed are removed. The coupons to be assayed should be removed before the dummy coupons are removed.

The coupons scheduled to be removed for assay after the quarantine period in Appendix C will be dummy coupons during assembly operations for which there will be no quarantine period.

C. Dummy Coupons.

At the risk of minimizing or of eliminating the bias protection, some of the dummy coupons may be eliminated from the placement schedule. Budgetary considerations may make it necessary to attach only those coupons which are to be assayed or to merely reduce the quantity of dummy coupons. Appendix A will be helpful in revising the coupon attachment schedule.

APPENDIX A
DISPOSITION OF COUPONS
ON THE CMIM SURFACES

CMTM STERILIZATION PROGRAM

DISPOSITION OF COUPONS

Page 1 of 7

CODE: 1 = To be removed during assembly Estimation Point 1, and assayed.

d = Dummy coupon, to be removed but not assayed.

Qd = To be removed after the quarantine period, and assayed. To be a dummy coupon if there is no quarantine period.

A01-01	d	A01-29	7	A01-57	9	A01-85	d	AX1-13	d	AX1-41	d	AX1-69	9	AX1-97	Qd
02	7	30	Qd	58	9	86	Qd	14	9	42	d	70	d	98	d
03	Qd	31	3	59	9	87	7	15	d	43	5	71	1	99	3
04	d	32	7	60	Qd	88	3	16	d	44	d	72	d	AY1-00	d
05	5	33	Qd	61	9	89	d	17	d	45	d	73	3	01	9
06	d	34	d	62	7	90	9	18	3	46	d	74	d	02	d
07	5	35	9	63	3	91	d	19	9	47	d	75	7	03	Qd
08	d	36	5	64	d	92	d	20	9	48	d	76	Qd	04	7
09	9	37	d	65	d	93	5	21	d	49	3	77	d	05	9
10	3	38	d	66	d	94	d	22	d	50	d	78	9	06	d
11	5	39	d	67	d	95	3	23	Qd	51	d	79	d	07	5
12	3	40	d	68	d	96	d	24	3	52	d	80	d	08	3
13	d	41	9	69	d	97	5	25	7	53	3	81	5	09	d
14	d	42	d	70	d	98	7	26	7	54	d	82	d	10	d
15	d	43	5	71	d	99	Qd	27	Qd	55	1	83	d	A02-01	d
16	d	44	d	72	9	AX1-00	d	28	9	56	7	84	d	02	7
17	1	45	3	73	d	01	d	29	d	57	5	85	9	03	Qd
18	d	46	d	74	d	02	d	30	d	58	Qd	86	d	04	d
19	d	47	d	75	7	03	d	31	5	59	d	87	7	05	7
20	9	48	d	76	Qd	04	d	32	9	60	d	88	Qd	06	Qd
21	d	49	5	77	d	05	d	33	d	61	5	89	d	07	d
22	d	50	d	78	d	06	d	34	d	62	d	90	d	08	9
23	5	51	7	79	d	07	d	35	1	63	d	91	d	09	9
24	d	52	Qd	80	3	08	d	36	d	64	d	92	9	10	9
25	5	53	d	81	d	09	5	37	9	65	d	93	d	11	d
26	9	54	d	82	d	10	d	38	d	66	d	94	d	12	9
27	7	55	9	83	d	11	3	39	d	67	d	95	1	13	7
28	Qd	56	d	84	d	12	d	40	3	68	d	96	7	14	Qd

CMM STERILIZATION PROGRAM

DISPOSITION OF COUPONS

CODE: 1 = To be removed during Estimation Point
 1, and assayed.
 d = Dummy coupon, to be removed but not assayed.
 Qd = To be removed after the quarantine period,
 and assayed. To be a dummy coupon if there
 is no quarantine period.

Page 2 of 7

A02-15	A02-43	A02-71	A02-99	A03-19	A04-17	A05-13	A06-11
16 ³	44 ^d	72 ⁵	AX2-00 ^d	20 ^d	18 ^d	14 ^d	12 ^d
17 ^d	45 ^d	73 ⁷	01 ^d	21 ^d	19 ⁶	15 ^d	13 ^d
18 ^d	46 ^d	74 ³	02 ^d	22 ^d	20 ^d	16 ^{Qd}	14 ^d
19 ^d	47 ^d	75 ^{Qd}	03 ^d	23 ^d	21 ^d	17 ⁷	15 ⁵
20 ⁷	48 ^d	76 ⁵	04 ³	24 ^d	22 ^d	18 ⁷	16 ^d
21 ^{Qd}	49 ^d	77 ³	05 ^d	25 ⁵	23 ⁶	19 ^{Qd}	17 ^d
22 ^d	50 ^d	78 ^d	06 ⁵	26 ^d	24 ^d	20 ^d	18 ^d
23 ⁷	51 ^d	79 ^d	07 ¹	27 ⁴	25 ⁵	21 ^d	19 ^d
24 ^{Qd}	52 ^d	80 ⁹	08 ^d	28 ^d	26 ^d	22 ^d	20 ^d
25 ^d	53 ³	81 ^d	A03-01 ^d	29 ^{Qd}	27 ^d	23 ^d	21 ^{Qd}
26 ⁵	54 ⁹	82 ^d	02 ³	30 ⁷	28 ⁵	24 ^d	22 ⁶
27 ⁷	55 ⁵	83 ^d	03 ⁷	A04-01 ^d	29 ¹	25 ^d	23 ⁷
28 ³	56 ^d	84 ^d	04 ⁶	02 ^d	30 ^d	26 ⁴	24 ³
29 ^{Qd}	57 ^d	85 ^d	05 ^{Qd}	03 ^d	31 ^d	27 ^d	25 ⁵
30 ^d	58 ⁹	86 ^d	06 ^d	04 ³	32 ^d	28 ³	26 ⁴
31 ^d	59 ⁹	87 ^d	07 ^d	05 ^d	A05-01 ^d	29 ^d	27 ⁶
32 ^d	60 ^d	88 ^d	08 ^d	06 ^d	02 ^d	30 ^d	28 ^d
33 ^d	61 ⁵	89 ⁵	09 ^d	07 ⁷	03 ^d	A06-01 ^d	29 ⁴
34 ^d	62 ^d	90 ⁷	10 ^d	08 ^{Qd}	04 ⁶	02 ^d	30 ^d
35 ¹	63 ⁷	91 ^{Qd}	11 ⁴	09 ^d	05 ⁴	03 ^d	A07-01 ^d
36 ^d	64 ^{Qd}	92 ³	12 ⁵	10 ^d	06 ^d	04 ^d	02 ^d
37 ^d	65 ^d	93 ^d	13 ^d	11 ⁴	07 ⁵	05 ^d	03 ¹
38 ^d	66 ^d	94 ^d	14 ^d	12 ^d	08 ^d	06 ^d	A09-01 ³
39 ^d	67 ⁵	95 ^d	15 ⁴	13 ^d	09 ^d	07 ^d	02 ^d
40 ^d	68 ^d	96 ⁹	16 ^d	14 ^d	10 ^d	08 ^d	03 ^d
41 ⁹	69 ^d	97 ⁵	17 ¹	15 ^{Qd}	11 ⁵	09 ⁵	A10-01 ⁷
42 ³	70 ^d	98 ^d	18 ^d	16 ⁷	12 ^d	10 ^d	02 ^{Qd}

CMM STERILIZATION PROGRAM

DISPOSITION OF COUPONS

Page 3 of 7

CODE: .1 = To be removed during Estimation Point
1, and assayed.

d = Dummy coupon, to be removed but not assayed.
Qd = To be removed, after the quarantine period
and assayed. To be a dummy coupon if there
is no quarantine period.

A10-03 ^u	A10-31 ^d	A10-59 ^s	A10-87 ^d	A11-25 ^d	A11-53 ^{Qd}	A11-81 ^d	A13-09 ^d
04 ^d	32 ^d	60 ^d	88 ^s	26 ^d	54 ^d	82 ^s	10 ^d
05 ^d	33 ^d	61 ^d	89 ^d	27 ^d	55 ^d	83 ^d	11 ^d
06 ^d	34 ^d	62 ^s	90 ^d	28 ^d	56 ^d	84 ^d	12 ^d
07 ^d	35 ^s	63 ^d	A11-01 ^{Qd}	29 ^d	57 ^r	85 ^d	A16-01 ^d
08 ^u	36 ^d	64 ^d	02 ^r	30 ^d	58 ^{Qd}	86 ^r	02 ^d
09 ^d	37 ^d	65 ^r	03 ^s	31 ^s	59 ^d	87 ^{Qd}	03 ^s
10 ^d	38 ^d	66 ^{Qd}	04 ^d	32 ^d	60 ^d	88 ^s	04 ^d
11 ^d	39 ^d	67 ^d	05 ^d	33 ^d	61 ^r	89 ^s	05 ^d
12 ^d	40 ^d	68 ^d	06 ^s	34 ^d	62 ^d	90 ^s	06 ^d
13 ^d	41 ^s	69 ^r	07 ^s	35 ^d	63 ^r	A12-01 ^d	07 ^d
14 ^d	42 ^r	70 ^{Qd}	08 ^s	36 ^s	64 ^{Qd}	02 ^s	08 ^d
15 ^r	43 ^{Qd}	71 ^r	09 ^d	37 ^s	65 ^d	03 ^d	09 ^r
16 ^d	44 ^s	72 ^{Qd}	10 ^s	38 ^d	66 ^d	04 ^s	10 ^{Qd}
17 ^d	45 ¹	73 ^d	11 ^d	39 ^d	67 ^d	05 ^r	B01-01 ^d
18 ^d	46 ^d	74 ^r	12 ^d	40 ^d	68 ^d	06 ^{Qd}	02 ^d
19 ^d	47 ^d	75 ^{Qd}	13 ¹	41 ^d	69 ^{Qd}	07 ^{Qd}	03 ^s
20 ^{Qd}	48 ^d	76 ^d	14 ^d	42 ^d	70 ^r	08 ^r	04 ^d
21 ^r	49 ^d	77 ^d	15 ^{Qd}	43 ¹	71 ^s	09 ^d	05 ^{Qd}
22 ^r	50 ^d	78 ^{Qd}	16 ^r	44 ^d	72 ^d	10 ^d	06 ^r
23 ^{Qd}	51 ^s	79 ^r	17 ^s	45 ^d	73 ^d	A13-01 ¹	07 ⁴
24 ^d	52 ^s	80 ^r	18 ^r	46 ^d	74 ^d	02 ^r	08 ^d
25 ^d	53 ^d	81 ^{Qd}	19 ^{Qd}	47 ^d	75 ^d	03 ^s	09 ⁶
26 ^u	54 ^d	82 ^d	20 ^d	48 ^s	76 ^r	04 ^{Qd}	10 ^s
27 ^d	55 ¹	83 ^d	21 ^d	49 ^r	77 ^{Qd}	05 ^d	11 ^d
28 ^d	56 ^s	84 ^s	22 ^s	50 ^{Qd}	78 ^d	06 ^s	12 ^s
29 ^d	57 ¹	85 ^d	23 ^d	51 ^d	79 ^r	07 ^d	13 ^d
30 ^d	58 ^d	86 ^d	24 ^d	52 ^r	80 ^{Qd}	08 ^d	14 ^d

CMIM STERILIZATION PROGRAM

DISPOSITION OF COUPONS

CODE

1 = To be removed during Estimation Point
1, and assayed.
d = Dummy coupon, to be removed but not assayed
Qd = To be removed after the quarantine period,
and assayed. To be a dummy coupon if there
is no quarantine period.

Page 4 of 7

01-15	d	C02-13	d	C04-17	d	C05-15	d	D01-13	5	D01-41	d	D01-69	d	D02-13	5
16	d	14	d	18	d	16	d	14	d	42	d	70	d	14	d
17	d	15	d	19	d	17	d	15	d	43	d	71	d	15	d
18	4	16	d	20	d	18	d	16	5	44	d	72	d	16	5
19	6	17	d	21	d	19	d	17	d	45	2	73	d	17	Qd
20	5	18	d	22	d	20	d	18	d	46	5	74	d	18	5
B02-01	d	19	d	23	d	21	d	19	d	47	d	75	2	19	5
02	3	20	d	24	d	22	d	20	3	48	d	76	d	20	Qd
03	3	21	d	25	d	23	d	21	d	49	d	77	2	21	Qd
04	3	22	d	26	d	24	d	22	d	50	2	78	d	22	7
B03-01	d	23	d	27	d	25	d	23	3	51	d	79	d	23	Qd
02	4	24	d	28	d	26	d	24	d	52	d	80	d	24	5
C01-01	8	C04-01	d	29	d	27	d	25	d	53	d	81	d	25	7
02	7	02	d	30	d	28	d	26	d	54	d	82	d	26	Qd
03	5	03	d	C05-01	d	29	d	27	d	55	d	83	d	27	5
04	8	04	d	02	d	30	d	28	d	56	d	84	d	28	3
C02-01	d	05	d	03	d	D01-01	Qd	29	d	57	d	D02-01	Qd	29	7
02	d	06	d	04	d	02	7	30	7	58	d	02	7	30	5
03	d	07	d	05	d	03	7	31	Qd	59	6	03	Qd	31	7
04	d	08	d	06	d	04	Qd	32	3	60	Qd	04	3	32	5
05	d	09	d	07	d	05	d	33	d	61	7	05	3	33	d
06	d	10	d	08	d	06	d	34	d	62	7	06	7	34	5
07	d	11	d	09	d	07	d	35	d	63	Qd	07	Qd	35	d
08	d	12	d	10	d	08	5	36	4	64	6	08	3	36	Qd
09	d	13	d	11	d	09	d	37	d	65	d	09	7	37	7
10	d	14	d	12	d	10	d	38	d	66	d	10	5	38	5
11	d	15	d	13	d	11	3	39	3	67	5	11	Qd	39	d
12	d	16	d	14	d	12	d	40	d	68	d	12	Qd	40	5

CMIM STERILIZATION PROGRAM

DISPOSITION OF COUPONS

CODE: .1 = To be removed during Estimation Point
1, and assayed.

d = Dummy coupon, to be removed but not assayed.

Qd = To be removed, after the quarantine period,
and assayed. To be a dummy coupon if there
is no quarantine period.

Page 5 of 7

DO2-41	3	DO2-69	3	DO4-27	d	DO4-55	d	DO7-01	1	IO2-03	d	IO3-01	d	IO3-29	1
42	7	70	3	28	d	56	d	02	5	04	3	02	3	30	d
43	3	DO4-01	d	29	d	57	d	03	7	05	d	03	d	MO1-01	1
44	d	02	d	30	d	58	d	04	3	06	d	04	d	02	d
45	Qd	03	d	31	d	59	d	05	7	07	3	05	d	03	d
46	3	04	d	32	d	60	d	06	5	08	d	06	d	MO2-01	1
47	Qd	05	d	33	1	61	d	07	5	09	d	07	3	02	d
48	d	06	d	34	d	62		08	3	10	3	08	d	03	d
49	3	07	d	35	d	63	d	09	3	11	d	09	d	04	7
50	7	08	d	36	d	64	1	10	3	12	d	10	d	05	Qd
51	Qd	09	d	37	d	65	d	DO9-01	d	13	3	11	d	06	d
52	3	10	d	38	d	66	d	02	1	14	3	12	d	MO3-01	d
53	1	11	d	39	d	67	d	03	d	15	d	13	d	02	Qd
54	7	12	d	40	d	68	d	04	d	16	d	14	d	03	7
55	1	13	d	41	1	69	d	05	d	17	d	15	d	MO4-01	7
56	d	14	d	42	d	70	d	06	d	18	d	16	d	02	Qd
57	3	15	d	43	d	DO6-01	5	07	1	19	1	17	d	03	7
58	Qd	16	d	44	d	02	d	08	d	20	d	18	d	04	Qd
59	d	17	d	45	d	03	2	09	d	21	d	19	d	05	7
60	7	18	d	46	d	04	d	10	d	22	d	20	d	06	d
61	3	19	d	47	d	05	6	IO1-01	d	23	d	21	d	07	7
62	7	20	d	48	d	06	d	02	d	24	d	22	d	08	Qd
63	3	21	1	49	d	07	5	03	1	25	3	23	3	09	7
64	1	22	d	50	d	08	6	04	d	26	d	24	d	10	Qd
65	3	23	d	51	d	09	7	05	3	27	3	25	d	MO5-01	7
66	3	24	d	52	d	10	3	06	d	28	d	26	d	02	Qd
67	3	25	d	53	1	11	4	IO2-01	d	29	d	27	d		
68	5	26	d	54	d	12	Qd	02	d	30	d	28	d		

CMM STERILIZATION PROGRAM

DISPOSITION OF COUPONS

Page 6 Of 7

CODE: 3.1 = To be removed during Estimation Point 1, and assayed.

d = Dummy coupon, to be removed but not assayed.
Qd = To be removed, after the quarantine period and assayed. To be a dummy coupon if there is no quarantine period.

PO2-01 d	PO3-09 d	RO3-12 d	S02-17 d	S02-45 d	S04-07 d	S06-05 d	S08-19 d
02 d	10 d	13 d	18 d	46 Qd	08 d	06 d	20 d
03 d	11 d	14 Qd	19 d	47 d	09 d	S07-01 d	21 d
04 d	12 d	15 d	20 d	48 d	10 d	02 d	22 d
05 d	13 d	S01-01 d	21 d	49 d	11 d	03 d	23 d
06 d	14 d	02 d	22 d	50 Qd	12 d	04 d	24 d
07 d	15 d	03 d	23 d	51 d	13 Qd	05 d	25 d
08 d	16 d	04 d	24 d	52 d	14 d	06 d	26 d
09 d	RO1-01 d	05 d	25 d	53 d	S05-01 d	07 d	27 d
10 d	02 d	06 d	26 d	54 d	02 d	08 d	28 d
11 d	03 Qd	07 d	27 d	55 d	03 d	S08-01 d	29 d
12 d	RO2-01 d	08 d	28 d	56 d	04 d	02 d	30 d
13 d	02 d	S02-01 d	29 d	57 d	05 d	03 d	31 d
14 d	03 Qd	02 d	30 d	58 d	06 d	04 d	32 d
15 d	04 Qd	03 d	31 Qd	59 d	07 d	05 d	33 d
16 d	05 Qd	04 d	32 d	60 d	08 d	06 d	34 d
17 d	06 d	05 d	33 d	61 d	09 d	07 d	35 d
18 d	RO3-01 d	06 d	34 d	62 Qd	10 d	08 d	36 d
PO3-01 d	02 Qd	07 d	35 d	63 d	11 d	09 d	37 d
02 d	03 d	08 d	36 d	64 d	12 d	10 d	38 d
03 d	04 d	09 d	37 d	S03-01 d	13 d	11 d	39 d
04 d	05 d	10 d	38 d	02 d	14 Qd	12 d	40 d
05 d	06 Qd	11 d	39 d	S04-01 d	15 d	13 d	41 d
06 d	07 d	12 d	40 Qd	02 d	16 d	14 d	42 d
07 d	08 d	13 d	41 d	03 d	S06-01 d	15 d	43 d
08 d	09 Qd	14 d	42 d	04 d	02 d	16 d	44 d
	10 d	15 d	43 d	05 d	03 d	17 d	45 d
	11 d	16 Qd	44 d	06 d	04 d	18 d	46 d

CMM STERILIZATION PROGRAM

DISPOSITION OF COUPONS CODE: .1 = To be removed during Estimation Point
1, and assayed.

Page 7 Of 7

d = Dummy coupon, to be removed but not assayed.
Qd = To be removed, after the quarantine period
and assayed. To be a dummy coupon if there
is no quarantine period.

S03-47	U01-15	d					
48	16	d					
S11-01	17	d					
02	18	3					
03	19	d					
04	20	d					
05	21	d					
06	U02-01	3					
S12-01	02	3					
02	03	d					
03	04	d					
04	05	d					
05	06	d					
06	U03-01	3					
U01-01	02	d					
02	03	d					
03	04	3					
04	05	1					
05	06	d					
06	07	d					
07	08	d					
08	09	3					
09							
10							
11							
12							
13							
14							

APPENDIX B

COUPON REMOVAL SCHEDULE

CMTM STERILIZATION PROGRAM

SADL ASSEMBLY OPERATION COUPON REMOVAL SCHEDULE

ESTIMATION POINT 1. DATE: _____, 19____. TIME: _____.

(Section 1.0, Oper. 5)

To Be Removed For Assay:

A01-17	A10-45	DO4-53	P03-13	S08-23
AX1-35	A10-55	DO4-41	R03-03	S08-29
AX1-55	A10-57	DO4-59	S01-01	S08-33
AX1-71	A11-13	DO4-64	S01-05	S08-39
AX1-95	A11-43	DO7-01	S01-08	S08-45
A02-35	A11-61	DO9-02	S02-33	S08-47
A02-99	A13-01	DO9-07	S02-55	S12-01
AX2-07	DO2-53	IO1-03	S04-11	S12-03
A03-17	DO2-55	IO2-19	S08-01	S12-05
A04-29	DO4-17	IO3-29	S08-05	U01-01
A07-03	DO4-21	M01-01	S08-10	U01-07
A10-15	DO4-33	M02-01	S08-18	U03-05

All Coupons Are To Be Removed From The Following Zones:

A07	(2)
DO4	(63)
DO9	(8)
M01	(2)
S01	(5)
S08	(38)
S12	(3)

ESTIMATION POINT 2.

(Section 1.0 Oper. 90) DATE: _____, 19____. TIME: _____.

To Be Removed For Assay:

DO1-45
DO1-50
DO1-75
DO1-77
DO6-03
SO6-05

CMIM STERILIZATION PROGRAM

SADL ASSEMBLY OPERATION COUPON REMOVAL SCHEDULE.

Page 2 of 5

ESTIMATION POINT 3.
(Sec. 2.0, Oper. 50)

Date: _____, 19____.

TIME: _____

To Be Removed For Assay:

A01-10	A02-77	B02-02	D02-67	S02-49
A01-12	A02-92	B02-03	D02-69	S02-54
A01-31	AX2-04	B02-04	D02-70	S02-56
A01-45	A03-02	D01-11	D06-10	
A01-63	A04-04	D01-20	D07-04	S02-60
A01-80	A05-28	D01-23	D07-08	S03-02
A01-88	A06-24	D01-32	D07-09	S04-08
A01-95	A09-01	D01-39	D07-10	S04-09
AX1-11	A10-51	D02-04	I01-05	S04-10
AX1-18	A10-52	D02-05	I02-04	S05-04
AX1-24	A10-56	D02-08	I02-07	S05-05
AX1-40	A10-84	D02-28	I02-10	S05-08
AX1-49	A10-88	D02-41	I02-13	S07-02
AX1-53	A11-03	D02-43	I02-14	S11-04
AX1-73	A11-10	D02-46	I02-25	S11-06
AX1-99	A11-22	D02-49	I02-27	U01-05
AY1-08	A11-31	D02-52	I03-02	U01-12
A02-16	A11-36	D02-57	I03-07	U02-02
A02-28	A12-02	D02-61	I03-23	U03-01
A02-42	A13-06	D02-63	S02-12	U03-04
A02-53	B01-03	D02-65	S02-20	U03-09
A02-74	B01-10	D02-66	S02-38	

ALL COUPONS ARE TO BE REMOVED FROM THE FOLLOWING ZONES:

A09 (2)
B02 (1)
I01 (4)
I02 (22)
I03 (26)
S11 (4)
U03 (5)

ESTIMATION POINT 4
(Sec. 3.0, Oper. 90)

Date: _____, 19____.

TIME: _____

A03-11	A05-05	B01-07	D01-36	D06-11
A03-15	A05-26	B01-18	D01-71	S06-01
A03-27	A06-26	B03-02	D01-82	S06-04
A04-11	A06-29			S07-04
A04-17				

ALL COUPONS ARE TO BE REMOVED FROM ZONE S06 (3 COUPONS).

CMM STERILIZATION PROGRAM

July, 1967

SADL ASSEMBLY OPERATION COUPON REMOVAL SCHEDULE.

Page 3 of 5

ESTIMATION POINT 5.
(Sec. 4.0, Oper. 80)

Date: _____, 19____.

TIME: _____

To Be Removed For Assay:

A01-05	A02-76	A11-06	D02-10	P02-12
A01-07	A02-89	A11-07	D02-13	P02-15
A01-11	A02-97	A11-08	D02-16	P02-18
A01-23	AX2-06	A11-17	D02-18	P03-02
A01-25	A03-12	A11-37	D02-19	P03-05
A01-36	A03-25	A11-48	D02-24	P03-06
A01-43	A04-25	A11-71	D02-27	P03-08
A01-49	A04-28	A11-82	D02-30	P03-11
A01-93	A05-07	A11-88	D02-32	P03-14
A01-97	A05-11	A11-89	D02-34	P03-15
AX1-09	A06-09	A11-90	D02-38	S02-10
AX1-31	A06-15	A12-04	D02-40	S02-32
AX1-43	A06-25	A13-03	D02-68	S02-37
AX1-57	A10-03	A16-03	D06-01	S02-43
AX1-61	A10-08	B01-12	D06-07	S02-47
AX1-81	A10-26	B01-20	D07-02	S02-64
AY1-07	A10-35	C01-03	D07-02	S03-01
A02-26	A10-41	D01-08	P02-03	S04-01
A02-55	A10-44	D01-13	P02-08	S04-03
A02-61	A10-59	D01-16	P02-10	S04-04
A02-67	A10-62	D01-67	P02-11	S05-06
A02-72				S05-09
				S07-05

ALL COUPONS ARE TO BE REMOVED FROM THE FOLLOWING ZONES:

P02 (11)
P03 (8)
S07 (4)

ESTIMATION POINT 6
(Sec. 5.0, Oper. 60)

Date: _____, 19____.

TIME: _____

To Be Removed For Assay:

A03-04	A06-22	B03-01	D01-59
A04-19	A06-27	D01-15	D01-64
A04-23	B01-09	D01-26	D06-05
A05-04	B01-19	D01-46	D06-08

CMIM STERILIZATION PROGRAM

July 1967

SADL ASSEMBLY OPERATION COUPON REMOVAL SCHEDULE

ESTIMATION POINT 7
(Sec. 6.0 Oper. 30)

Date: _____, 19____. TIME: _____

A01-02	A02-27	A11-16	D01-62	M03-03
A01-27	A02-63	A11-18	D02-02	M04-01
A01-29	A02-73	A11-49	D02-06	M04-03
A01-32	A02-90	A11-52	D02-09	M04-05
A01-51	A03-03	A11-57	D02-14	M04-07
A01-62	A03-30	A11-63	D02-15	M04-09
A01-75	A04-07	A11-70	D02-22	M05-01
A01-87	A04-16	A11-76	D02-25	R01-02
A01-98	A05-17	A11-79	D02-29	
AX1-25	A05-18	A11-86	D02-31	R02-01
Ax1-26	A06-23	A12-05	D02-37	R02-02
AX1-56	A10-01	A12-08	D02-42	R02-06
AX1-75	A10-21	A13-02	D02-50	R03-04
AX1-87	A10-22	A16-09	D02-54	R03-05
AX1-96	A10-42	B01-06	D02-60	R03-08
AY1-04	A10-65	D01-02	D02-62	R03-15
A02-02	A10-69	D01-03	D06-09	S02-15
A02-05	A10-71	D01-30	D07-03	S02-30
A02-13	A10-74	D01-42	D07-05	S02-39
A02-20	A10-79	D01-61	M02-04	S02-48
A02-23	A10-80			S02-51
	A11-02			S02-63
				S04-14
				S05-13

ALL COUPONS ARE TO BE REMOVED FROM THE FOLLOWING ZONES:

A03-	(20)	M02	(4)
A04	(22)	M03	(2)
A05	(22)	M04	(5)
A06	(21)	M05	(1)
A10	(63)	R01	(2)
A11	(60)	R02	(3)
A12	(6)	S02	(43)
A13	(8)	S04	(6)
A16	(8)	S05	(10)
B01	(11)	R03-	(10)
D01	(57)		
D02	(23)		
D06	(4)		

CMM STERILIZATION PROGRAM

July 1967

SADL ASSEMBLY OPERATION COUPON REMOVAL SCHEDULE

ESTIMATION POINT 8
 (Sec. 8.0, Oper. 20)

Date: _____, 19____. TIME: _____

To Be Removed For Assay:

CO1-01	U01-03	U01-14
CO1-04	U01-04	U01-18
		U02-01

ALL COUPONS ARE TO BE REMOVED FROM THE FOLLOWING ZONES:

U01	(13)
U02	(4)
CO1	(1)

ESTIMATION POINT 9.
 (Sec. 9.0, Oper. 10)

Date: _____, 19____. TIME: _____

To Be Removed For Assay:

A01-09	AX1-28	A02-58	C02-24	C05-06
A01-20	AX1-32	A02-59	C04-06	C05-10
A01-26	AX1-37	A02-80	C04-07	C05-11
A01-35	AX1-69	A02-96	C04-10	C05-13
A01-41	AX1-78	C02-02	C04-12	C05-18
A01-55	AX1-85	C02-03	C04-03	C05-21
A01-57	AX1-92	C02-04	C04-15	C05-24
A01-58	AX1-01	C02-06	C04-18	C05-28
A01-59	AX1-05	C02-09	C04-22	
A01-61	A02-08	C02-10	C04-25	
A01-72	A02-09	C02-11	C04-27	
A01-90	A02-10	C02-12	C04-29	
AX1-14	A02-12	C02-18	C04-30	
AX1-19	A02-41	C02-19	C05-01	
AX1-20	A02-54	C02-23	C05-04	

ALL COUPONS ARE TO BE REMOVED FROM THE FOLLOWING ZONES:

A01, AX1, A01	(131)
A02, AX2	(69)
C02	(12)
C04	(18)
C05	(20)

APPENDIX C

POST QUARANTINE COUPON REMOVAL SCHEDULE

POST QUARANTINE COUPON REMOVAL SCHEDULE

Date: _____, 19____. TIME: _____

AFTER THE QUARANTINE PERIOD, THE FOLLOWING COUPONS ARE TO BE REMOVED FOR ASSAY:

A01-03	A02-29	A11-01	D01-63	M04-02
A01-28	A02-64	A11-15	D02-01	M04-04
A01-30	A02-75	A11-19	D02-03	M04-06
A01-33	A02-91	A11-50	D02-07	M04-08
A01-52	A03-05	A11-53	D02-11	M04-10
A01-60	A03-29	A11-58	D02-12	M05-02
A01-76	A04-08	A11-64	D02-17	R01-03
A01-86	A04-15	A11-69	D02-20	R02-03
A01-99	A05-16	A11-77	D02-21	R02-04
AX1-23	A05-19	A11-80	D02-23	R02-05
AX1-27	A06-21	A11-87	D02-26	R03-02
AX1-58	A10-02	A12-06	D02-36	R03-06
AX1-76	A10-20	A12-07	D02-45	R03-09
AX1-88	A10-23	A13-04	D02-47	R03-14
AX1-97	A10-43	A16-10	D02-51	S02-16
AY1-03	A10-66	B01-05	D02-56	S02-31
A02-03	A10-70	D01-01	D02-58	S02-40
A02-06	A10-72	D01-04	D02-64	S02-46
A02-14	A10-75	D01-31	D02-12	S02-50
A02-21	A10-78	D01-43	M02-05	S02-62
A02-24	A10-81	D01-60	M03-02	S04-13
				S05-14

APPENDIX D

DESCRIPTIONS OF SURFACE AREAS,
ZONES, AND COUPON QUANTITIES.

CMM STERILIZATION PROGRAM

DEFINITION OF ZONES AND COUPON QUANTITIES

CLASSIFICATION OF ZONES:

- A-1. Heavy burden, initially handled area.
 - A-2. Heavy burden, area handled in previous assembly stage.
 - A-3. Heavy burden, area handled two assembly stages earlier.
 - A-M. Heavy burden, area handled M-1 assembly stages earlier.

 - B. Moderate burden, direct fallout, horizontal upward flat surface, ridges, flanges.
 - C. Light burden, indirect fallout, vertical or slanted surfaces.
 - D. Very light burden, downward or inside surfaces.
 - M. Mates Surfaces.
 - O. Occluded Surfaces.
 - I. Inaccessible surfaces, not occluded or mated.
-

NOTE:

- 1. The numbers of dummy coupons, which are to be removed but not assayed, appear in parentheses.
- 2. An asterisk (*) indicates where a zone is handled just prior to the corresponding estimation point.
- 3. Surface **area** values which were estimated without measurements are denoted by the letter E.
- 4. Definitions of estimation points appear in Section II B of the text.

CMIM STERILIZATION PROGRAM

DEFINITIONS OF ZONES AND COUPON QUANTITIES
(See explanatory notes on Page 1 of this Appendix)

Part	Zone	Surface Area (In. ²)	Description of Area	Quantity of coupons to be removed and zone classification at each estimation point.									Total Coupon Quantity
				1	2	3	4	5	6	7	8	9	
Aeroshell	A01	25,345	Outside surface including the apex and conic section (Frustum)	5	0	17	0	17	0	16	0	24 (131)	210
				D	C	C	C	C	C	C	C	C	
Aeroshell	A02	12,700	Outside surface cylindrical section. Subject to less fallout than zone 1, but there is a higher probability of human contamination, e.g., from coughing, sneezing, and accidental handling	3	0	8	0	9	0	9	0	10 (69)	108
				D	C	C	C	C	C	C	C	C	
Aeroshell	A03	406.	Internal support ring cylinder, outside surface, $y \pm 45^\circ$ sector.	1	0	1	3	2	1	2	0	0 (20)	30
				D	D	D	A-1	A-2	A-3	A-4	0	0	
Aeroshell	A04	406.	Internal support ring cylinder outside surface $X \pm 45^\circ$ sector.	1	0	1	2	2	2	2	0	0 (22)	32
				D	D	D	A-1	A-2	A-3	A-4	0	0	
Aeroshell	A05	406.	Internal support cylinder outside surface, $-y \pm 45^\circ$ sector.	0	0	1	2	2	1	2	0	0 (22)	30
				D	D	D	A-1	A-2	A-3	A-4	0	0	
Aeroshell	A06	406.	Internal support ring cylinder outside surface, $-X \pm 45^\circ$ sector.	0	0	1	2	3	2	1	0	0 (21)	30
				D	D	D	A-1	A-2	A-3	A-4	0	0	

CMIM STERILIZATION PROGRAM

DEFINITIONS OF ZONES AND COUPON QUANTITIES
(See explanatory notes on Page 1 of this Appendix)


Part	Zone	Surface Area (In. ²)	Description of Area	Quantity of coupons to be removed and zone classification at each estimation point.									Total Coupon Quantity	
				1	2	3	4	5	6	7	8	9		
Aeroshell	A07	4084	Internal support ring cylinder inside surface (360°) and inside of flange, plus portion of inner surface of shell bounded by the cylinder	1 (2) D	0 D	0 D	0 0	0 0	0 0	0 0	0 0	0 0	0 0	3
Aeroshell	A08	373	Internal support ring flange top and edge, plus connectors and brackets.	0 D	0 D	0 D	0 * 0	0 0	0 0	0 0	0 0	0 0	0 0	0
Aeroshell	A09	287	Internal support ring flange bottom.	0 D	0 D	1 (2) D	0 M	0 M	0 M	0 M	0 M	0 M	0 M	3
Aeroshell	A10	20,000	Inside surface of shell, excluding portion bounded by internal support ring cylinder at the apex of the shell.	4 D	0 D	5 D	0 D	8 D	0 D	10 D	0 D	0 D	0 D	90
Aeroshell	A11	16,960	Inside surface of shell, cylindrical section, plus bottom of aeroshell.	3 D	0 D	5 D	0 C	11 C	0 C	11 C	0 C	0 C	0 C	90
Aeroshell	A12	1378	Both shells around attitude control tanks including the support brackets and electrical connectors.	0 D	0 D	1 D	0 D	1 D	0 D	2 D	0 D	0 D	0 D	10

CMM STERILIZATION PROGRAM

DEFINITIONS OF ZONES AND COUPON QUANTITIES
(See explanatory notes on Page 1 of this Appendix)

Part	Zone	Surface Area (In. ²)	Description of Area	Quantity of coupons to be removed and zone classification at each estimation point.									Total Coupon Quantity	
				1	2	3	4	5	6	7	8	9		
Aeroshell	A13	1464	Two spherical altitude con- trol tanks.	1 D	0 D	1 D	0 D	1 D	0 D	0 D	1 D (8)	0 0	0 0	12
Aeroshell	A14	3000 ^E	Mated and fayed surface areas (total) (X 2)	0 M	0 M	0 M	0 M	0 M	0 M	0 M	0 M	0 M	0 M	0
Aeroshell	A15	1625 ^E (a) X (b) = 1625 inches ²	(a) Total number of rivets = 3620. (b) Total mated surface contact area per rivet (X2) = 0.45 (average).	0 M	0 M	0 M	0 M	0 M	0 M	0 M	0 M	0 M	0 M	0
Aeroshell	A16	190 ^E	Cabling and Piping.	0 D	0 D	0 D	0 C	1 C	0 C	0 C	1 C (8)	0 0	0 0	10


AEROSHELL



OUTSIDE SURFACE

FIGURE 2 ZONE DEFINITION - AEROSHELL OUTSIDE SURFACE


AEROSHELL (INSIDE VIEW)



* ZONES 3, 4, 5, 6 outside surface of inner ring as pictured

FIGURE 3 ZONE DEFINITION - AEROSHELL INNER SURFACE

AEROSHELL (ATTITUDE CONTROL SYSTEM)



2 BOTTLES AT X' -X AXIS AS PICTURED

FIGURE 4 ZONE DEFINITION - AEROSHELL - ATTITUDE CONTROL SYSTEM

CMM STERILIZATION PROGRAM

DEFINITIONS OF ZONES AND COUPON QUANTITIES
(See explanatory notes on Page 1 of this Appendix)

Part	Zone	Surface Area (In. ²)	Description of Area	Quantity of coupons to be removed and zone classification at each estimation point.									Total Coupon Quantity	
				1	2	3	4	5	6	7	8	9		
Clamp	B01	810.	Outside and edges of clamp.	0 D	0 D	2 D	2 * A-1	2 A-2	2 A-3	1 (11) A-4	0	0	20	
Clamp	B02	462.	Inside and Backface.	0 D	0 D	3 (1) D	0 0*	0	0	0	0	0	0	4
Clamp	B03	68. ^E	Support clips turnbuckle, nut & swivel bolts.	0 D	0 D	0 D	1 * A-1	0 A-2	1 A-3	0 A-4	0	0	2	
Clamp	B04	540. ^E	Occluded areas behind sup- port band.	0 0	0 0	0 0	0 0	0 0	0 0	0 0	0 0	0 0	0	

CMM STERILIZATION PROGRAM

DEFINITIONS OF ZONES AND COUPON QUANTITIES
(See explanatory notes on Page 1 of this Appendix)

Part	Zone	Surface Area (In. ²)	Description of Area	Quantity of coupons to be removed and zone classification at each estimation point.									Total Coupon Quantity
				1	2	3	4	5	6	7	8	9	
Sterili- zation Canister	C01	E 150.	Interior of umbilical port	0 D	0 D	0 D	0 D	1 D	0 D	0 D	(1) * A-1	0 0	4
Sterili- zation Canister	C02	E 40,000	Interior of top of canis- ter.	0 0	0 0	0 0	0 0	0 0	0 0	0 0	0 D	12 D (12)	24
Sterili- zation Canister	C03	E 30,000.	Interior of bottom of canister. (This is ex- posed to at- mosphere for a very short time only).	0 0	0 0	0 0	0 0	0 0	0 0	0 0	0 0	0 0	0
Sterili- zation Canister	C04	2800	Mating flange of top of canister.	0 M	0 M	0 M	0 M	0 M	0 M	0 M	0 D	12 D (18)	30
Sterili- zation Canister	C05	2800.	Mating flange of bottom of canister (al- though this faces upward horizontally, it is exposed to the atmos- phere for a very short time only).	0 M	0 M	0 M	0 M	0 M	0 M	0 M	0 C	10 C/O (20)	30

CMM STERILIZATION PROGRAM

DEFINITIONS OF ZONES AND COUPON QUANTITIES
(See explanatory notes on Page 1 of this Appendix)

Part	Zone	Surface Area (In. ²)	Description of Area	Quantity of coupons to be removed and zone classification at each estimation point.									Total Coupon Quantity
				1	2	3	4	5	6	7	8	9	
Dummy Chassis & Data Encoder	D01	392.	Handled areas on panels of the 7 dummy chassis 2 x 7 x (7 x 4) = 392 Sq. inches	0	4	5	3	4	5	6	0	0	84
				D	* A-1	A-2	A-3	A-4	A-5	A-6	0	0	
										(57)			
Dummy Chassis & Data Encoder	D02	2180	Unhandled por- tion of the front panels of the 7 dum- my chassis and edges of exposed panels	2	0	17	0	13	0	15	0	0	70
				D	C	C	C	C	C	C	0	0	
										(23)			
Dummy Chassis & Data Encoder	D03	320	Portions of the 7 dummy chassis which mate onto the payload assem- bly.	0	0	0	0	0	0	0	0	0	0
				D	M	M	M	M	M	M	M	M	
Dummy Chassis & Data Encoder	D04	30,340 ^E	Internal sur- face areas of the 7 dummy chassis, inc- luding all wiring, elec- trical compo- nents, circuit boards, etc.	7 (63)	0	0	0	0	0	0	0	0	70
				D	0	0	0	0	0	0	0	0	
Dummy Chassis & Data Encoder	D05	819 ^E	(a) Total no. of rivets=1820 (b) Average surface area =0.45. (c)(a)x(b) = 819.	0	0	0	0	0	0	0	0	0	0
				M	M	M	M	M	M	M	M	M	

CMIM STERILIZATION PROGRAM

DEFINITIONS OF ZONES AND COUPON QUANTITIES
(See explanatory notes on Page 1 of this Appendix)

Part	Zone	Surface Area (In. ²)	Description of Area	Quantity of coupons to be removed and zone classification at each estimation point.									Total Coupon Quantity
				1	2	3	4	5	6	7	8	9	
Dummy Chassis & Data Encoder	D06	56.	Handled areas on the front panel of the data encoder. 2x(7x4)=56 sq."	0	1	1	1	2	2	1	0	0	
				D	*					(4)			
					A-1	A-2	A-3	A-4	A-5	A-6	0	0	
Dummy Chassis & Data Encoder	D07	310.	Unhandled por- tion of the front panel of the data enco- der.	1	0	4	0	3	0	2	0	0	10
				D	C	C	C	C	C	C	0	0	
Dummy Chassis & Data Encoder	D08	46.	Portion of the data encoder case which mates onto the payload assem- bly.	0	0	0	0	0	0	0	0	0	0
				D	M	M	M	M	M	M	M	M	
Dummy Chassis & Data Encoder	D09	4791 ^E	Internal sur- face areas of the data enco- der, including all wiring, electrical components, circuit boards etc.	2	0	0	0	0	0	0	0	0	10
				(8)									
				D	0	0	0	0	0	0	0	0	
Dummy Chassis & Data Encoder	D10	117 ^E	(a) Total No. of rivets=260. (b) Average surface area= 0.45. (c) (a)x(b)= 117.	0	0	0	0	0	0	0	0	0	
				M	M	M	M	M	M	M	M	M	

CMM STERILIZATION PROGRAM

DEFINITIONS OF ZONES AND COUPON QUANTITIES
(See explanatory notes on Page 1 of this Appendix)

Part	Zone	Surface Area (In. ²)	Description of Area	Quantity of coupons to be removed and zone classification at each estimation point.									Total Coupon Quantity
				1	2	3	4	5	6	7	8	9	
Impact Limiter	I01	622.	Surface on top of Impact Li- miter whose border is hor- izontal circle of radius=13.4"	1	0	1 (4)	0	0	0	0	0	0	6
				D	B	B	0	0	0	0	0	0	
Impact Limiter	I02	1308.	Three surfaces containing lift hooks. These are bor- dered by the horizontal cir- cles of radii, 13.4" & 22.5" and by arcs ± 30° of the centerline of hooks.	1	0	7 (22)	0	0	0	0	0	0	30
				D	D	* A-1	0	0	0	0	0	0	
Impact Limiter	I03	1282.	Three surfaces on upper half of Impact Li- miter bordered on top and bot- tom by circles of radii 13.4" & 22.5", resp- ectively, and not included in zone I02.	1	0	3 (26)	0	0	0	0	0	0	30
				D	C	C	0	0	0	0	0	0	
Impact Limiter	I04	2565.	Surface of Im- pact Limiter on bottom half of sphere whose borders are horizontal cir- cles of radii 22.5" & 13.4". This surface is occluded by chassis.	0	0	0	0	0	0	0	0	0	0
				D	D	0	0	0	0	0	0	0	
Impact Limiter	I05	622.	Surface on bot- tom of Impact Limiter whose border is a horizontal cir- cle of radius 13.4".	0	0	0	0	0	0	0	0	0	0
				D	D	I	I	0	0	0	0	0	

IMPACT LIMITER




FIGURE 5 ZONE DEFINITION - IMPACT LIMITER

CMM STERILIZATION PROGRAM

DEFINITIONS OF ZONES AND COUPON QUANTITIES
(See explanatory notes on Page 1 of this Appendix)

Part	Zone	Surface Area (In. ²)	Description of Area	Quantity of coupons to be removed and zone classification at each estimation point.									Total Coupon Quantity
				1	2	3	4	5	6	7	8	9	
Deorbit Motor	MO1	306.	Top of motor above clamp lo- cation, (This becomes occlud- ed immediately after assembly). Plus mated sur- face.	1 (2) D	0 C	0 C	0 C	0 C	0 0	0 0	0 0	0 0	3
Deorbit Motor	MO2	1253.	Side surface of motor beneath clamp location.	1 D	0 D	0 D	0 D	0 D	0 D	1 (4) D	0 0	0 0	6
Deorbit Motor	MO3	1574.	Bottom of motor and internal shell area and inside tank.	0 D	0 D	0 D	0 D	0 D	0 D	1 (2) D	0 0	0 0	3
Deorbit Motor	MO4	E. 500.	Cabling. (Not including the connectors).	0 D	0 D	0 D	0 D	0 D	0 B	5 (5) B	0 0	0 0	10
Deorbit Motor	MO5	E 25.	Cabling Connec- tors.	0 D	0 D	0 D	0 D	0 D	0 B	1 (1) B	0 *	0 0	2

CMIM STERILIZATION PROGRAM

DEFINITIONS OF ZONES AND COUPON QUANTITIES
 (See explanatory notes on Page 1 of this Appendix)

Part	Zone	Surface Area (In. ²)	Description of Area	Quantity of coupons to be removed and zone classification at each estimation point.									Total Coupon Quantity	
				1	2	3	4	5	6	7	8	9		
Motor Clamp Assembly	001	56.0	Outside and edges.	0	0	0	0	0	0	0*	0	0	0	0
				D	D	D	D	D	I	I	0	0		
Motor Clamp Assembly	002	54.0	Inside (occlu- ded).	0	0	0	0	0	0	0	0	0	0	0
				D	D	D	D	D	0	0	0	0		
Motor Clamp Assembly	003	2.0 ^E	Screws, etc.	0	0	0	0	0	0	0*	0	0	0	0
				I	I	I	I	I	0	0	0	0		

DE-ORBIT MOTOR

XXXXX
XXXXX
XXXXX




FIGURE 6 ZONE DEFINITION - DE-ORBIT MOTOR

CMIM STERILIZATION PROGRAM

DEFINITIONS OF ZONES AND COUPON QUANTITIES
(See explanatory notes on Page 1 of this Appendix)

Part	Zone	Surface Area (In. ²)	Description of Area	Quantity of coupons to be removed and zone classification at each estimation point.									Total Coupon Quantity	
				1	2	3	4	5	6	7	8	9		
Parachute Canister	P01	176.	Top surface.	0 D	0 B	0 B	0 B	0 I	0 I	0 I	0 O	0 O	0	
Parachute Canister	P02	240.	Bottom Surface	0 D	0 D	0 D	0 D	7 (11) A-1 *	0	0	0	0	0	18
Parachute Canister	P03	760	Cylindrical Side surface (possibly a light contact area).	1 D	0 C	0 C	0 C	7 (8) B	0 I	0 I	0 O	0 O	16	
Parachute Canister	P04	21.	Top flange.	0 D	0 B	0 B	0 B	0 I	0 I	0 I	0 O	0 O	0	
Parachute Canister	P05	89.	Bottom flange	0 D	0 D	0 D	0 D	0 * M	0 M	0 M	0 M	0 M	0	

CMM STERILIZATION PROGRAM

DEFINITIONS OF ZONES AND COUPON QUANTITIES
(See explanatory notes on Page 1 of this Appendix)

Part	Zone	Surface Area (In. ²)	Description of Area	Quantity of coupons to be removed and zone classification at each estimation point.									Total Coupon Quantity
				1	2	3	4	5	6	7	8	9	
Antenna Relay	R01	19. ^E	Top Surface (Except portion mated to pay- load)	0	0	0	0	0	0	1	0	0	3
				D	B	B	B	B	B	B	B	0	
Antenna Relay	R02	254.	Bottom Surface	0	0	0	0	0	0	3	0	0	6
				D	D	D	D	D	D	(3)* A-1	0	0	
Antenna Relay	R03	550	Cylindrical side wall surface.	1	0	0	0	0	0	4	0	0	15
				D	D	D	D	D	D	(10) A-1*	0	0	
Antenna Relay	R04	264. ^E	Top surface mated to the payload assem- bly.	0	0	0	0	0	0	0	0	0	0
				D	D	D	D	D	D	* M	M	M	

CMIM STERILIZATION PROGRAM

DEFINITIONS OF ZONES AND COUPON QUANTITIES
(See explanatory notes on Page 1 of this Appendix)

Part	Zone	Surface Area (In. ²)	Description of Area	Quantity of coupons to be removed and zone classification at each estimation point.									Total Coupon Quantity	
				1	2	3	4	5	6	7	8	9		
Payload Assembly	S01	366.	Portion of the columns which become mated when the chassis and the data encoder are mated.	3 (5) D	0 M	8								
Payload Assy.	S02	7022.	All the type C areas which remain exposed after the completion of the CMIM assembly. This includes the cylindrical side wall and bottom flange, the struts (inside and out), the side walls (both sides) in the mid-support section, the upper shelves (top sides) above the bays, the portions of the columns between bays which are not mated, and the exposed areas of all brackets.	2 D	0 C	7 C	0 C	6 C	0 C	6 C	0 C	0 C	0 C	64
Payload Assy.	S03	264. ^E	The bottom area directly under the bays which becomes mated by the assembly of the antenna relay.	0 D	0 D	1 D	0 D	1 D	0 D	0 D	0 M	0 M	0 M	2

CMUM STERILIZATION PROGRAM

DEFINITIONS OF ZONES AND COUPON QUANTITIES
(See explanatory notes on Page 1 of this Appendix)

Part	Zone	Surface Area (In. ²)	Description of Area	Quantity of coupons to be removed and zone classification at each estimation point.									Total Coupon Quantity
				1	2	3	4	5	6	7	8	9	
Payload Assy.	S04	1236.	The bottom area directly under the bays minus zone S03.	1	0	3	0	3	0	6	0	0	14
				D	D	D	D	D	D	D	0	0	
Payload Assy.	S05	1635.	The de-orbit motor mount surface area excluding those portions which are occluded by the para- chute canister and the motor, i.e. the shelf and internal areas.	0	0	3	0	2	0	1	0	0	16
				D	D	D	D	D	D	D	0	0	
										(10)			
Payload Assy.	S06	12.	ID of shelf which becomes occluded by the parachute can- ister. This surface is con- tacted during assembly of the data encoder to bay 8.	0	1	0	2	0	0	0	0	0	6
				D	*		(3)	0	0	0	0	0	
					A-1	A-2	A-3						
Payload Assy.	S07	128.	ID of motor mount which be- comes occluded by the assembly of the motor. This is contac- ted during the assembly of the data encoder to bay 8.	0	1	1	1	1	0	0	0	0	8
				D	*		(4)	0	0	0	0	0	
					A-1	A-2	A-3	A-4	0	0	0	0	

CMMM STERILIZATION PROGRAM

DEFINITIONS OF ZONES AND COUPON QUANTITIES
(See explanatory notes on Page 1 of this Appendix)

Part	Zone	Surface Area (In. ²)	Description of Area	Quantity of coupons to be removed and zone classification at each estimation point.									Total Coupon Quantity
				1	2	3	4	5	6	7	8	9	
Payload Assy.	S08	5798.	The areas in- side the bays which become occluded by the assembly of the dummy chassis & data encoder.	10 (38) D	0 0	0 0	0 0	0 0	0 0	0 0	0 0	0 0	48
Payload Assy.	S09	14.	Bottom surface of the motor mount, which becomes entire- ly mated by the assembly of the motor.	0 D	0 D	0 D	0 D	0 D	0 M	0 M	0 M	0 M	0
Payload Assy.	S10	7180.	All the inter- nal portions which are in- accessible and become occlud- ed by the mat- ing of the parachute ca- nister.	0 D	0 I	0 I	0 I	0 0	0 Q	0 Q	0 0	0 0	0
Payload Assy.	S11	922.	The top flange which mates to the aeroshell and becomes mated after the aeroshell assembly.	0 D	0 B	2 B (4)	0 M	0 M	0 M	0 M	0 M	0 M	0
Payload Assy.	S12	2610	Portion which mates to the Impact Limiter, including the bowl surface and the rubber receivers.	3 (3) D	0 C	0 0	0 0	0 0	0 0	0 0	0 0	0 0	6

CMM STERILIZATION PROGRAM

DEFINITIONS OF ZONES AND COUPON QUANTITIES
 (See explanatory notes on Page 1 of this Appendix)

Part	Zone	Surface Area (In. ²)	Description of Area	Quantity of coupons to be removed and zone classification at each estimation point.									Total Coupon Quantity
				1	2	3	4	5	6	7	8	9	
Payload Assy	S13	1500 ^E	All perman- ently mated surfaces.	0 M	0 M	0 M	0 M	0 M	0 M	0 M	0 M	0 M	0
Payload Assy	S14	900 ^E	(a) Number of rivets=2000. (b) Average area=0.45. (a)x(b)=900 ^E .	0 M	0 M	0 M	0 M	0 M	0 M	0 M	0 M	0 M	0

CMIM STERILIZATION PROGRAM

DEFINITIONS OF ZONES AND COUPON QUANTITIES
(See explanatory notes on Page 1 of this Appendix)

Part	Zone	Surface Area (In. ²)	Description of Area	Quantity of coupons to be removed and zone classification at each estimation point.									Total Coupon Quantity	
				1	2	3	4	5	6	7	8	9		
Umbilical	U01	255.	Connector plate.	2	0	2	0	0	0	0	0	4	0	21
												(13)		
				D	D	D	D	D	D	D	D	* A-1	0	
Umbilical	U02	116 ^E	Cabling at the connector plate area (i.e. the 5 connectors).	0	0	1	0	0	0	0	0	1	0	6
				D	B	B	B	B	B	B	B	(4)	0	
												* A-1	0	
Umbilical	U03	795 ^E .	Cabling.	1	0	3	0	0	0	0	0	0	0	9
				D	B	(5) B	B	B	B	B	B	B	0	
Umbilical	U04	20 ^E	Connector at Data Encoder.	0	0	0	0	0	0	0	0	0	0	0
				D	*I	I	I	0	0	0	0	0	0	
Total All Subassem- blies	75	249,346.	CMIM and Canis- ter. (Including only the inside of the Canister).	60	7	108	19	109	16	106	7	68	68	500
			Total dummy coupons:	121	0	64	3	23	0	411	18	250	250	890
			Total coupons:	181	7	172	22	132	16	517	25	318	318	1390


APPENDIX E

ILLUSTRATIONS OF COUPON LOCATIONS

FIGURE 7 AEROSHELL
(TOP VIEW)

"COUPON DISTRIBUTION"

NO.5 A01-01 TO A01-99
AXI-00 TO AXI-99
AYI-00 TO AYI-10




OUTSIDE SURFACE (FRUSTRUM WITH
CONICAL APEX)

FIGURE 9 AEROSHELL
(SUPPORT RING, INSIDE)

SIDE VIEW

"COUPON DISTRIBUTION"
 Nos A03-01 TO A09-30
 A04-01 TO A04-32
 A05-01 TO A05-30
 A06-01 TO A06-30



*FIGURE 10 AEROSHELL
(SUPPORT RING, INSIDE)*

SIDE VIEW

*'CAMPON DISTRIBUTION'
Nos A07-01 TO A07-03
A09-01 TO A09-03*

*CONICAL SECTION FLAT PATTERN
90° DIMENSIONS*




FIGURE 11 AEROSHELL

(UNDER SIDE VIEW)
 "COUPON DISTRIBUTION"
 NOS A10-01 TO A10-90
 A16-01 TO A16-03
 A16-06 TO A16-08

INSIDE SURFACE (FRUSTRUM
 WITH CONICAL APEX)




FIGURE 12

AEROSHELL

(SIDE VIEW EXTENDED)

"COUPON DISTRIBUTION"

NO. 8 A11-01 TO A11-90

A16-01 TO A16-05

A16-09 TO A16-10

INSIDE SURFACE CYLINDRICAL SECTION




FIGURE 13 AEROSHELL - INSIDE -
 (ATTITUDE CONTROL FUEL
 TANK BRACKETS)






FIGURE 14 MARMON CLAMP
(FLAT PATTERN)

"COUPON DISTRIBUTION"
Nos B01-01 TO B01-20
B02-01 TO B02-04
B03-01 TO B03-02


FRONT VIEW #1



BACK VIEW #1



FRONT VIEW #2



BACK VIEW #2




FIGURE 15 CANISTER

"COUPON DISTRIBUTION" (TOP & BOTTOM HALVES)

NO'S CO2-01 TO CO2-24
 CO4-01 TO CO4-30
 CO5-01 TO CO5-30





FIGURE 16 DUMMY CHASSIS


"COUPON DISTRIBUTION"
 NOS D01-01 TO D01-84
 D02-01 TO D02-70
 D04-01 TO D04-70

BAY 1


(TOP)



NOTE:
 CHASSIS NOS 1 THRU 7 ARE NUMBERED
 CONSECUTIVELY AS PER DRAWINGS.
 EACH COUPON POSITION (+) IS THE
 SAME THRU OUT, IN STEPS OF
 10°/12



(INSIDE SURFACES)



FRONT
VIEW

(OUTSIDE SURFACES)




FIGURE 17 LIVE CHASSIS

"COUPON DISTRIBUTION"
 NOS 206-01 TO 206-12
 207-01 TO 207-10
 209-01 TO 209-10

BAY 8




FIGURE 18
IMPACT LIMITER
 (TOP VIEW)

"COUPON DISTRIBUTION"
 NOS I01-01 TO I01-06
 I02-01 TO I02-30
 I03-01 TO I03-50

OUTSIDE SURFACE
 (TOP HALF)





FIGURE 19 DE-ORBIT MOTOR

TOP SIDE VIEW
 "COUPON DISTRIBUTION"
 NOS M01-01 TO M01-03
 M02-01 TO M02-06



OUTSIDE SURFACE
 TOP & SIDE


FIGURE 20 DE-ORBIT MOTOR

CLAMP & MOTOR BOTTOM

4 COPIES DISTRIBUTION
 NOS 001-01 TO 001-04
 M03-01 TO M03-03

CLAMPS
 SIDE VIEW

BOTH HALVES FLAT PATTERN



DE-ORBIT MOTOR
 BOTTOM FRUSTRUM
 INSIDE FLAT PATTERN




FIGURE 21 DE-ORBIT MOTOR CABLE HARNESS

COUPON DISTRIBUTION
NO'S M04-01 TO M04-10
M05-01 TO M05-02
U02-06




FIGURE 22 PARACHUTE CANISTER
2 VIEWS

"COUPON DISTRIBUTION"
 NO3 P02-01 TO P02-18
 P03-01 TO P03-16




FIGURE 23 ANTENNA

(TRI-VIEW)
 "COUPON DISTRIBUTION"
 NOS R01-01 TO R01-03
 R02-01 TO R02-06
 R03-01 TO R03-15





FIGURE 24
PAYLOAD CHASSIS
 "COUPON DISTRIBUTION"
 NOS S01-01 TO S01-08
 S02-01 TO S02-64
 S08-01 TO S08-46

OUTSIDE SURFACE PAYLOAD
 FLAT PATTERN



STAINLESS STEEL,
 NUT PLATE (8) PCE

X AXIS

-X AXIS

FIGURE 25

PAYLOAD

(BOTTOM VIEW
LOOKING UP)

"COUPON DISTRIBUTION"

- NO 5 S03-01 TO S03-2
- S04-01 TO S04-2
- S05-01 TO S05-16
- S07-01 TO S07-8




FIGURE 26 PAYLOAD

(TOP VIEW
LOOKING DOWN)

COUPON DISTRIBUTION

- NO# S06-01 TO S06-06
- S11-01 TO S11-06
- S12-01 TO S12-06




FIGURE 27 UMBILICAL PLATE

"COUPON DISTRIBUTION"
NO'S U01-01 TO U01-21




FIGURE 28 UMBILICAL FLANGE CONNECTION

"COUPON DISTRIBUTION"
NOS COI-01 TO COI-04




FIGURE 29
BAY 8 UMBILICAL HARNESS

"COUPON DISTRIBUTION"
NO'S U02-01 TO U02-05
U03-01 TO U03-09

