



N6822981


NTIS

One Source. One Search. One Solution.

TECHNICAL REPORT C-1 ENGINE DEVELOPMENT BIPROPELLANT VALVE IMPROVEMENT PROGRAM

GEORGE C. MARSHALL SPACE FLIGHT CENTER


AUG 1967



U.S. Department of Commerce
National Technical Information Service



One Source. One Search. One Solution.

NTIS



**Providing Permanent, Easy Access
to U.S. Government Information**

The National Technical Information Service is the Nation's largest repository and disseminator of government-initiated scientific, technical, engineering, and related business information. The NTIS collection includes almost 3 million information products in a variety of formats: electronic download, online access, DVD, CD-ROM, magnetic tape, diskette, multimedia, microfiche and paper.



Search the NTIS Database from 1990 forward

More than 600,000 government research information products have been added to the NTIS collection since 1990. All bibliographic entries for those products are searchable on the NTIS Web site at www.ntis.gov.

Download Publications (1997 - Present)

NTIS provides the full text of many reports received since 1997 as downloadable PDF files. When an agency stops maintaining a report on its Web site, NTIS still offers a downloadable version. There is a fee for each download of most publications.

For more information visit our website:

www.ntis.gov



U.S. DEPARTMENT OF COMMERCE
Technology Administration
National Technical Information Service
Springfield, VA 22161

Thiokol CHEMICAL CORPORATION

C-1 ENGINE FINAL REPORT


Prepared for George C. Marshall Space Flight Center
Under Contract NAS8-15486

TECHNICAL REPORT C-1 ENGINE DEVELOPMENT
BIPROPELLANT VALVE IMPROVEMENT PROGRAM

Addendum No. 1
To Final Report RMD 6203

31 August 1967

● REACTION MOTORS DIVISION
DENVER, NEW JERSEY



C-1 ENGINE PROGRAM
PHASE II DEVELOPMENT

Technical Report Bipropellant Valve
Improvement Program

Addendum No. 1

To Final Report RMD 6203-F1

Approved by:


L. M. Bachman
C-1 Program Manager

1a

CONTENTS

		Page
1.0	INTRODUCTION	1-1
1.1	PURPOSE	1-1
1.2	CONTRACTUAL COVERAGE	1-1
1.3	BACKGROUND	1-1
2.0	SUMMARY	2-1
APPENDIX	Moog Evaluation Test Report No. MR 1216	

ILLUSTRATIONS

Figure		Page
2.0-1	Flat Spring Flapper-Button Motion Restrictors	2-2
2.0-2	Design Sketch of Flat Spring Installation	2-3
2.0-3	Teflon Seat After Test S/N 45 Valve	2-4
Table		
2.0-I	Vibration Testing Matrix	2-5
2.0-II	Vibration Spectra	2-6

1.0 INTRODUCTION

1.1 PURPOSE

This report describes the program conducted to improve the vibration characteristics of the bipropellant valve used on the C-1 Engine and presents the test data obtained during this evaluation. The content of this document forms a part of Thiokol-RMD Report 6203-F1. The program reported herein completes the development work on the bipropellant valve for the C-1 Engine.

1.2 CONTRACTUAL COVERAGE

The bipropellant valve improvement program was conducted for the George C. Marshall Space Flight Center under NASA Contract NAS8-15486.

1.3 BACKGROUND

The bipropellant valve (Thiokol-RMD Part No. 316305-300) qualified as part of the C-1 Engine demonstrated marginal vibration characteristic when subjected to the unpressurized vibration test. The marginal condition was evidenced by excessive seal leakage after being exposed to the vibration environment. The leakage resulted from excessive relative motion between the flapper button and seat. At extreme vibration levels this motion generated hairlike teflon particles and chips which interfered with reliable sealing. A detailed discussion of this condition is contained in Thiokol-RMD Report No. 6203-F1, Sections 4.4 and 14.0, and in Thiokol-RMD Report No. 6203-Q2. To extend the vibration capability of the bipropellant valve, a design improvement and vibration evaluation program was conducted. The initial progress of this program was reported in Thiokol-RMD Report 6203-F1.


Appended to this document is a copy of the Moog Inc. Evaluation Test Report No. MR 1216 which contains a discussion of the design improvement program and the test data obtained during this program.

2.0 SUMMARY

Two bipropellant valve test specimens were modified by the addition of a flat spring motion restrictor to each flapper-button as shown in Figures 2.0-1 and 2.0-2. The test specimens successfully completed all the unpressurized vibration tests and the performance tests without malfunction. The vibration testing was conducted with the valve assembled to a Thiokol-RMD thrust chamber assembly (Part No. 317555). The vibration input was controlled at the thrust chamber test fixture mounting surface. Tables 2.0-I and 2.0-II describe the specified vibration envelopes which were utilized for these tests. Further detail regarding test parameters and recorded data is contained in Appendix A of this report.

The first test specimen, S/N 45, was subjected to 50,000 cycles after completing all vibration testing. The valve sealing elements (nozzles) were removed following these tests for visual examination. As shown in Figure 2.0-3, the teflon seat revealed negligible wear and no evidence of hairlike particles or chips. The second test specimen, S/N 112, was also disassembled following vibration testing and again visual inspection revealed a completely satisfactory condition.

The design change incorporating the flat spring motion restrictor to each flapper button has been made in the bipropellant valve assembly identified as Thiokol-RMD Part No. 316305-400. As shown in Figures 2.0-1 and 2.0-2, the flat spring is retained in the valve body by a small button head screw which is heli-arc spot welded to spring and body to lock in position. The other end of the spring is retained by an interference fit with the small diameter shaft end of the flapper button which is pressed into the valve body. The two sample test specimens were assembled in this manner and showed no signs of loosening or structural failure during the vibration tests. This revised design feature has greatly improved the vibration characteristics of the bipropellant valve when exposed to the unpressurized vibration levels which is the most severe environment. The valve assembly can now meet or exceed the specified unpressurized vibration requirements and can satisfactorily pass all functional tests following the vibration tests. Three bipropellant valve assemblies of the improved design will be delivered to the Marshall Space Flight Center for further evaluation.



Reproduced from
best available copy. 

Figure 2.0-1. Flat Spring Flapper-Button Motion Restrictors






Figure 2.0-2. Design Sketch of Flat Spring Installation



Oxidizer Nozzle

Reproduced from
best available copy. 



Fuel Nozzle



Figure 2.0-3. Teflon Seat After Test S/N 45 Valve

TABLE 2.0-I
VIBRATION TESTING MATRIX

Configuration	Sequence	Non-Operating				Operating			
		Pressurized		Un Pressurized		Pressurized		Random	
		Sine Spectrum-Time	Random Spectrum-Time	Sine Spectrum-Time	Random Spectrum-Time	Sine Spectrum-Time	Random Spectrum-Time	Sine Spectrum-Time	Random Spectrum-Time
Bipropellant Valve Engine	A	--	--	1	54 min	2	36 min	--	--
	B	1	54	1	27	2	24	--	--
	C	--	--	5	54	6	15	3	54
	D	--	--	5	54	7	15	3	54
Quadredundant Valve Engine	A	1	54	--	--	--	--	3	54
	B	--	--	5	54	6	15	3	54
	C	--	--	5	54	7	15	3	54
	D	--	--	--	--	--	--	3	54

Note: Refer Table 2.0-II for Spectra Definition

TABLE 2. 0-II
REACTOR MOTOR SPECIFICS



APPENDIX A

EVALUATION TEST REPORT
FOR THE
ADVANCED DESIGN OF THE
MOOG MODEL 52X147C BIPROPELLANT VALVE

MOOG INC.
Report No. MR 1216

Final Report RMD 6203-F1
Addendum No. 1

EVALUATION TEST REPORT
FOR THE
ADVANCED DESIGN OF THE
MOOG MODEL 52X147C BIPROPELLANT VALVE

MOOG INC.
Report No. MR 1216

Reproduced from
best available copy.

Prepared by: Gordon B. LeRoy
Gordon B. LeRoy
Sr. Reliability Engineer

Reviewed by: Carl W. Naab
Carl W. Naab
Project Engineer

Approved by: David P. Elmer
David P. Elmer
Manager, Reliability
Engineering

Date: June 28, 1967

TABLE OF CONTENTS

	<u>Page</u>
1.0 INTRODUCTION	1
2.0 SUMMARY	2
3.0 TEST SPECIMENS	3
4.0 TEST OUTLINE	4
5.0 TEST METHODS	14
5.1 Vibration System and Fixturing	14
5.2 Instrumentation	14
5.2.1 Visual	14
5.2.2 Coil Voltage	15
5.3 Vibration Levels	16
6.0 TEST DATA	25

FIGURES

	<u>Page</u>
1. Model 52-147, S/N 238, Axis A, 4/20/67; 10 g input to valve. Accelerometer located on oxidizer inlet in input direction	42
2. Model 52-147, S/N 238, Axis A, 4/20/67; 10 g input to valve. Back emf vs frequency	43
3. Model 52-147, S/N 238, Axis B, 4/20/67; 10 g input to valve. Accelerometer located on side of oxidizer inlet in input direction.	44
4. Model 52-147, S/N 238, Axis B, 4/20/67; 10 g input to valve. Back emf vs frequency	45
5. Model 52-147, S/N 238, Axis C, 4/20/67; 10 g input to valve. Accelerometer located on oxidizer inlet in input direction.	46
6. Model 52-147, S/N 238, Axis C, 4/20/67; 10 g input to valve. Back emf vs frequency	47
Model 52-147, Torque Motor Study, Axis A, 4/25/67; 10 g and 20 g input. Accelerometer located on top pole-piece in input direction	48
8. Model 52-147, Torque Motor Study, Axis B, 4/25/67; 10 g and 20 g input. Accelerometer located on magnet in input direction	49
9. Model 52-146, Axis C, 5/26/67. Wire armature motion restrictors on free end of armature, 27.7 g rms input	53
10. Model 52-146, Axis A, 5/26/67. Wire armature motion restrictors on free end of armature, 27.7 g rms input	54
11. Model 52-146, Axis B, 5/26/67. Wire armature motion restrictors on free end of armature, 27.7 g rms input	55

Reproduced from
best available copy.



FIGURES (cont'd.)

	<u>Page</u>
12. Model 52-147, Axis A, 6/7/67. Wire armature motion restrictors on free end of armature, 27.7 g rms input	56
13. Model 52-147, S/N 204, Axis B, 6/7/67. Wire armature motion restrictors on free end of armature, 27.7 g rms input	57
14. Model 52-147, S/N 204, Axis C, 6/6/67. Wire armature motion restrictors on free end of armature, 27.7 g rms input	58
15. Model 52X147C, Body, S/N 45, Axis C, 7/25/67. Flapper button motion restrictors, flat spring, 27.7 g rms	67
16. Model 52X147C, Body, S/N 45, Axis A, 7/25/67. Flapper button motion restrictors, flat spring, 27.7 g rms input	69
17. Model 52X147C, Body, S/N 112, Axis C, 8/12/67. Flapper button motion restrictors, flat spring, 27.7 g rms input	85
18. Model 52X147C, Body, S/N 112, Axis A, 8/12/67. Flapper button motion restrictors, flat spring, 27.7 g rms input	87
19. Model 52X147C, Body, S/N 112, Axis B, 8/12/67. Flapper button motion restrictors, flat spring, 27.7 g rms input	89

Reproduced from
best available copy.



PHOTOGRAPHS

	<u>Page</u>
1. Model 52-147B, S/N 238; Test Setup Utilized to Determine Valve Mounting Frequencies	17
2. Model 52-147B, S/N 238; Test Setup Utilized to Determine Valve Mounting Frequencies	18
Model 52-147B, S/N 238; Test Setup Utilized to Determine Natural Frequency of Armature-Flexure Sleeve Assembly	19
4. Model 52-147B Torque Motor Test Setup Utilized to Determine Natural Frequency of Torque Motor	20
5. Model 52-147 "Wire" Armature Motion Restrictors	21
6. Model 52-147 "Flat Spring" Flapper-Button Motion Restrictors	22
7. Model 52-147, S/N 45; Oxidizer Nozzle and Fuel Nozzle	23
8. Model 52-147, S/N 45; Fuel Button	24

REFERENCES

1. "Valve, Bipropellant, Electrical, Torque Operated, Pulse Modulated," Thiokol Chemical Corporation, Reaction Motors Division, Denville, New Jersey, Specification Document EC20517, Revision L, dated January 10, 1967.
2. "Qualification Test Procedure for Valve, Bipropellant, Electrical, Torque Motor Operated, Pulse Modulated, Moog Model 52-147B, Moog Inc., East Aurora, New York, Report Number MR 1144, Revision B.

Reproduced from
best available copy. 

1.0 INTRODUCTION

The bipropellant valves, presently being built for Reaction Motors Division of Thiokol Chemical Corp., do not meet the internal leakage performance requirements of RMD Specification EC 20517 Revision K after exposure to the vibration environment specified in paragraph 4.7.18. Moog was informed in late April that the bipropellant valve must be modified to incorporate the necessary design changes to insure passage of all performance requirements after exposure to vibration testing.

This report documents test data obtained during vibration evaluation of the existing valve design and of the various design concepts developed to eliminate the vibration problem. The purpose of these tests was to obtain information on the resonance behavior of the valve body and the torque motor armature-flexure sleeve assembly and the effect of certain modifications on this behavior.

The tests presented in this report were conducted in the Moog Reliability Engineering Laboratory during the period of April 20 through August 11, 1967, and were authorized by Moog Job Order Number 1766723.

Reproduced from
best available copy. 

2.0 SUMMARY

Two test specimens, modified by the addition of a flat spring motion restrictor to each flapper-button, completed all vibration and performance tests without malfunction. Vibration testing was conducted with the valve mounted on the RMD thrust chamber (P/N 317555), in accordance with paragraphs 5.2.2 and 5.2.3 of Moog Report No. MR 1144, Rev. B. The vibration input was controlled at the thrust chamber test fixture mounting surface. The test specimens were unpressurized during vibration.

The first specimen tested, Body S/N 45, was subjected to 50,000 cycles after completing all vibration testing. The nozzles were then removed from this specimen and visual examination of the teflon seat revealed negligible teflon wear. (See illustration 8 of this report). The second specimen, Body S/N 112, was disassembled following vibration testing and visual inspection again revealed negligible teflon wear.

The test specimens utilized for this evaluation are identical to the Model 52-147B configuration with the exception of the addition of the button motion restrictors. Review of the performance data recorded for these two specimens (see section 6.0) indicates that the modified valve configuration meets all the specification performance requirements.

3.0 TEST SPECIMENS

The following bipropellant valves were tested:

- a. Model 52-147B, S/N 238, unmodified except motor cap removed and body slotted to permit observation of armature and flapper button.
- b. Model 52-147B Torque Motor consisting of bottom and top polepieces, magnets, and four screws.
- c. Model 52-147B, S/N 238, modified by jamming armature with wood. Same as item (a).
- d. Model 52-147B modified by removing both polepieces and magnets.
- e. Model 52-147B, S/N 238, same as item (a), modified by the addition of armature motion restrictors. Wire restraint.
- f. Model 52-147B, S/N 238, same as item (a), modified by the addition of armature motion restrictors. Set screw restraint.
- g. Model 52-146, modified by the addition of wire armature motion restrictors on free end of armature.
- h. Model 52-147 S/N 204, modified by the addition of wire armature motion restrictors on free end of armature.
- i. Model 52-147, modified by the addition of wire armature motion restrictors on both ends of armature.
- j. Model 52-147, modified by the addition of a flapper-button motion restrictor. Flat spring. The nozzle assembly was not installed in this valve.
- k. Model 52-147, S/N 45 modified by the addition of a flapper-button motion restrictor. Flat spring.
- l. Model 52-147, S/N 112 modified by the addition of a flapper-button motion restrictor. Flat spring.

4.0 TEST OUTLINE

An outline of the tests performed is presented in Table I. This outline presents a tabulation of test procedures and results reported in chronological order. Test specimen configuration is identified in accordance with the itemized description presented in paragraph 3.0.

Reproduced from
best available copy. 

TABLE I

MODEL 52-147 ADVANCED DESIGN STUDY PROGRAM

Date	Specimen Configuration	Test	Results
4/20/67	A	Sinusoidal sweep, 290 - 2000 Hz, 10 g peak input at valve mounting surface valve de-energized. Simultaneously made X-Y plot of body acceleration vs. frequency and of coil voltage generated by armature vs. frequency.	<p>1. Axis A: see body acceleration plot #1 and coil voltage plot #2. Vibration sweep time: 9 min 48 sec.</p> <p>2. Axis B: see body acceleration plot #3 and coil voltage plot #4. Vibration sweep time: 9 min. 48 sec.</p> <p>3. Axis C: see body acceleration plot #5 and coil voltage #6. Vibration sweep time: 9 min. 48 sec.</p>
4/21/67	A	Sinusoidal resonance search, 290 - 2000 Hz, 20 g peak input at valve mounting surface, valve de-energized	<p>1. Axis B:</p> <p>a. observed end of button 1250 Hz - .007" D. A. vertical</p> <p>b. observed end of button stops, 1290 Hz - .0005 in. D. A. vertical, .0005 in. D. A. horizontal</p> <p>c. observed "latched" end of armature 1320 Hz - .0007 in. D. A. vertical</p> <p>d. observed free end of armature 1273 Hz - .004 in. D. A. vertical</p> <p>Note: armature out of phase with both bottom & top polepieces.</p>

MR 1216

TABLE I

MODEL 52-147 ADVANCED DESIGN STUDY PROGRAM

Date	Specimen Configuration	Test	Results
4/25/67	B	Sinusoidal sweep 290 - 2000 Hz, 10 g and 20 g input at the torque motor mounting surface	1. Axis A: see torque motor acceleration plot #7 2. Axis B: see torque motor acceleration plot #8
4/27/67	C	Sinusoidal resonance search 290 - 2000 Hz, 20 g peak input at valve mounting surface, valve de-energized.	1. Axis B: a. observed end of button 1278 Hz - .0002 in. D. A. vertical; 1348 Hz - .0007 in. D. A. vertical b. observed free end of armature - 1186 Hz - .0008 in. D. A. vertical; 1388 Hz - .0006 in. D. A. vertical Note: upper polepiece and armature are in phase, lower polepiece and armature are in phase
5/1/67	D	Sinusoidal resonance search, 100 - 2000 Hz 1. 1.0 g peak input at valve mounting surface	1. Axis A: observed long end of armature 496 Hz - .005 in. D. A. vertical 2. Axis B: observed long end of armature 801 Hz - .002 in. D. A. vertical 3. Axis C: observed long end of armature 240 Hz - .0006 in. D. A. vertical 500 Hz - .0005 in. D. A. vertical

TABLE I

MODEL 52-147 ADVANCED DESIGN STUDY PROGRAM

Date	Specimen Configuration	Test	Results
		2. 3.0 g peak input at valve mounting surface	1. Axis A: observed long end of armature. Negligible movement throughout 600 - 2000 Hz bandwidth
			2. Axis C: observed long end of armature. Negligible movement throughout 600 - 2000 Hz bandwidth
		3. 5.0 g peak input at valve mounting surface	1. Axis C: observed long end of armature 800 Hz - .0002 in. D.A. vertical 900 Hz - .0002 in D.A. vertical 1900 Hz - .0002 in. D.A. vertical
5/5/67	E	Sinusoidal resonance search. 2.90 - 2000 Hz, 22 g peak input at valve mounting surface, valve de-energized. Wires attached to both ends of armature. Posts mounted to bottom polepiece.	1. Axis B: a. observed end of button. Data considered invalid because one of the wires on the free end of the armature was found broken after search. b. observed free end of armature. Data considered invalid because one wire was found to have lost its preload after the search.

TABLE 1

MODEL 52-147 ADVANCED DESIGN STUDY PROGRAM

Date	Specimen Configuration	Test	Results
5/9/67	E	Continue resonance search as conducted on 5/5/67. A new technique of securing the wire to its post was evaluated.	<p>1. Axis B: observed end of button 1260 Hz - .0023 in. D. A. vertical</p> <p>2. Axis A: observed end of button. Negligible movement throughout 290 - 2000 Hz bandwidth</p> <p>3. Axis C: observed end of button. Negligible movement throughout 290 - 2000 Hz bandwidth</p> <p>Note: One of the wires was found broken after the third axis of vibration. Validity of data is questionable.</p>
5/11/67	E	Continue resonance search as conducted on 5/5/67. A second new method of securing the wire to its post was evaluated.	<p>1. Axis B: observed end of button. 1249 Hz - .0005 in. D. A. vertical 2000 Hz - .0012 in. D. A. vertical</p> <p>Note: The inboard wire on the short end of the armature was found broken after search.</p>
5/18/67	E	Continue resonance search as conducted on 5/5/67. A third method of securing the wire to its post was evaluated.	<p>1. Axis B: Observed end of button 1792 - 1820 - .003 in. D. A. vertical 1865 - .006 in. D. A. vertical</p> <p>Note: The outboard wire on the free end of armature was found broken after search. Validity of data is questionable.</p>

TABLE 1

MODEL 52-147 ADVANCED DESIGN STUDY PROGRAM

Date	Specimen Configuration	Test	Results
5/19/67	F	Sinusoidal resonance search, 290 - 2000 Hz. 22 g peak input at valve mounting surface, valve de-energized. Set screw restraint at free end of armature only. Post mounted on top polepiece.	<p>1. Axis B:</p> <p>a. observe end of button: 1300 Hz - .0003 in. D.A. vertical; 1914 - 1960 Hz - .0025 in. D.A. vertical</p> <p>b. observe end of post: 1248 Hz - .0005 in. D.A. vertical; 1898 to 2000 - .001 in. D.A. vertical</p> <p>c. observe top polepiece: 1290 Hz - .0005 in. D.A. vertical; 1825 - 1990 - .001 in. D.A. vertical.</p> <p>d. observe bottom polepiece. Negligible movement throughout bandwidth.</p>
5/23/67	E	Sinusoidal resonance search, 290 - 2000 Hz. 22 g peak input at valve mounting surface, valve de-energized. Wires attached to free end of armature only. Post mounted to bottom polepiece. A new post design was evaluated.	<p>1. Axis B:</p> <p>a. observe end of button: 1236 - 1300 Hz - .0005 in. D.A. vertical; 2000 - .002 in. D.A. vertical</p> <p>b. observe end of post: 1200 Hz - .0005 in. D.A. vertical; 1850 - 2000 Hz - .0005 in. D.A. vertical</p> <p>2. Axis A: observe end of button 1280 Hz - .001 in. D.A. vertical</p> <p>3. Axis C: observe end of button: 1560 - 1650 Hz - .0002 in. D.A. vertical</p>

TABLE I

MODEL 52-147 ADVANCED DESIGN STUDY PROGRAM

Date	Specimen Configuration	Test	Results
5/24/67	F	<p>Sinusoidal resonance search, 299 - 2000 Hz, 22 g peak input at valve mounting surface, valve de-energized. Set screw restraint at free end of armature only. Posts mounted on bottom potpiece.</p>	<p>1. Axis B: a. observe end of button: 1289 to 1321 Hz - .005 in. D. A. vertical. b. observe set screw post 1050 Hz - .0005 in. D. A. vertical. c. observe free end of armature 1279 - 1401 Hz - .002 in. D. A. vertical.</p>
5/26/67	G	<p>Sinusoidal and random vibration testing were conducted in accordance with Moog Report Number MR 1144, Rev. B, paragraphs 5.2.2 and 5.2.3. The valve was installed on the RMD thrust chamber and was unpressurized throughout vibration. The sequence of testing was: sinusoidal - axes C, A, B; random - axes C, A, B.</p>	<p>See tabulated data sheets for initial, inter-val, and final performance test results. Inspection of the nozzles after vibration revealed severe teflon wear. Visual inspection of the manifold to body mating surfaces revealed relative motion between the two components. Such motion would produce movement between the nozzle and its mating button resulting in teflon wear. Testing was, therefore, considered invalid.</p>
6/3/67	H	<p>Vibration testing same as testing conducted on 5/26/67. See above. After vibration, the valve was cycled 50,000 times before disassembly and subsequent visual inspection of the buttons and nozzles</p>	<p>See tabulated data sheets for initial, inter-val, and final performance test results. Inspection of the nozzles after vibration revealed excessive teflon wear.</p>

TABLE I
MODEL 52-147 ADVANCED DESIGN STUDY PROGRAM

Date	Specimen Configuration	Test	Results
6/22/67	J	Sinusoidal resonance search, 290-2000 Hz Valve energized closed with 16 volts	<ol style="list-style-type: none"> <li data-bbox="512 957 538 1676">1. 22 g peak input at valve mounting surface Axis B - observed end of button 1400 Hz -.003" D.A. horizontal 1690 Hz -.005" D.A. horizontal <li data-bbox="538 957 564 1676">2. 30 g peak input at valve mounting surface Axis B - observed end of button 1400 Hz -.005" D.A. horizontal
6/23/67	J	Sinusoidal resonance search, 290-2000 Hz, valve de-energized.	<ol style="list-style-type: none"> <li data-bbox="598 957 624 1676">1. 30 g peak input at valve mounting surface Axis B - observed end of button 1450 Hz -.002" D.A. vertical .002" D.A. horizontal <li data-bbox="624 957 651 1676">2. 40 g peak input at valve mounting surface Axis B - observed end of button 1370 Hz -.003" D.A. vertical 1200 Hz -.001" D.A. vertical <li data-bbox="651 957 677 1676">3. 50 g peak input at valve mounting surface Axis B - observed end of button 1200 Hz -.002" D.A. elliptical 1300 - 1380 Hz -.001" D.A. elliptical 1500 - 1550 Hz -.001" D.A. elliptical

TABLE I
 MODEL 52-147 ADVANCED DESIGN STUDY PROGRAM

Date	Specimen Configuration	Test	Results
6/28/67	I	Sinusoidal resonance search 290-2000 Hz, valve de-energized	
		1. 22 g peak input at valve mounting surface	1. Axis B - observed end of button 1200 - .0002" D.A. vertical
		2. 30 g peak input at valve mounting surface	1. Axis B - observed end of button 1230 Hz - .0015" D.A. vertical 1700 Hz - .002" D.A. vertical
		3. 40 g peak input at valve mounting surface	1. Axis B - observed end of button 1260 Hz - .002" D.A. vertical 1870 Hz - .002" D.A. vertical
		4. 50 g peak input at valve mounting surface	1. Axis B - observed end of button 1230 - .006" D.A. vertical 1470 - .006" D.A. vertical

TABLE I

MODEL 52-147 ADVANCED DESIGN STUDY PROGRAM

Date	Specimen Configuration	Test	Results
7/25/67	K	<p>Sinusoidal and random vibration testing were conducted in accordance with Moog Report No. MR. 1144 Rev. B paragraphs 5.2.2 and 5.2.3. The valve was installed on the RMD thrust chamber and was unpressurized throughout vibration. The sequence of testing was:</p> <ul style="list-style-type: none"> sinusoidal axes C, A, B random axes C, A, B 	<p>See tabulated data sheets for initial, interval, and final performance test results.</p> <p>No internal leakage was recorded.</p> <p>Inspection of the nozzles after vibration and life showed negligible wear of the teflon</p>
		<p>All functional checks were conducted at a reduced pressure level because of an external leak at the manifold to body weld interface</p>	

5.0 TEST METHODS

5.1 Vibration System and Fixturing

All tests were performed using a Unholtz-Dickie Model 200 shaker driven by a 10 KVA amplifier. Vibration control was by a B & K 1018 controller, with an Endevco 2221C accelerometer filtered by a Spectral Dynamics SD101A Tracking Filter, bandwidth 20/100 Hz with 280 Hz crossover frequency. An Unholtz-Dickie 610R Dial-A-Gain accelerometer amplifier was also used.

The bipropellant valve was mounted to the shaker by means of a nearly cubical aluminum test fixture (Moog No. T12184-2), approximately 5 in. long x 5 in. wide x 5 in. deep. Valve mounting holes were provided on two edges of this block to permit mounting the valve in the three major mutually perpendicular axes. Acceleration was controlled from the top surface of this fixture.

5.2 Instrumentation

Two methods of detecting and measuring resonances were employed in the course of this test.

5.2.1 Visual

Reproduced from
best available copy. 

A Gaertner microscope with reticle graduated in .001 in. divisions was employed, primarily to observe motion of the end of the armature between the polepieces. A Chadwick-Helmuth Slip-Sync Stroboscope was used to illuminate the valve.

In general, motion of about .0002 inches double amplitude are discernable by this method.

5. 2. 2 Coil Voltage

Motion of the armature induced by applied vibration results in an e. m. f. being generated in the torque motor coils. This fact was used to detect resonances by making an automatic X-Y plot of coil voltage vs. vibration frequency. The valve coil was connected to a Moseley 60D Log Converter and an Electro-Instruments 400 X-Y plotter. Frequency signal was provided by the B & K 1018 Controller.

This method of detecting torque motor resonances appears to be quite sensitive, especially compared with the visual method described above. Limitations which should be observed in interpretation of these plots center around the hazards of comparing the amplitude of the voltage at various resonant frequencies. Voltage amplitude is dependent on, in part:

1. Relative velocity of the armature and polepiece
2. Angle at which lines of flux are cut
3. Mode of resonance (related to (2) above)

Reproduced from
best available copy. 

It can be seen that a thorough knowledge of the dynamic behavior of the torque motor under vibration would be required to interpret the significance of the amplitudes recorded.

5.3 Vibration Levels

Select test specimens were subjected to the vibration levels specified below while installed on the RMD thrust chamber (P/N 317555). These levels are in accordance with Moog Report No. MR 1144 Rev. B.

a. Sinusoidal Vibration


1. valve unpressurized
2. sweep rate - 2 octave/min. per axis
3. level:

5 - 58 cps	0.031 inch D.A.
58 - 150 cps	5.4 g peak
150 - 295 cps	0.0049 inch D.A.
295 - 2000 cps	21.8 g peak


b. Random Vibration

1. valve unpressurized
2. 8 minutes/axis
3. level


10 - 110 cps	0.055 g^2/cps at 10 cps increasing 3 db/octave to 0.62 g^2/cps at 110 cps
110 - 1000 cps	flat at 0.62 g^2/cps
1000 - 2000 cps	decreasing linearly on log-log coordinates from 0.62 g^2/cps at 1000 cps to 0.055 g^2/cps at 2000 cps




Reproduced from
best available copy. 



Model 52-147B - S/N 238
Test Set-Up Utilized To Determine
Valve Mounting Frequencies




Model 52-147B - S/N 238
Test Set-Up Utilized To Determine
Valve Mounting Frequencies





AXIS B

Reproduced from
best available copy.





AXIS C

Model 52-147B - S/N 238
Test Set-Up Utilized To Determine
Natural Frequency of Armature-Flexure Sleeve Assembly




Reproduced from
best available copy. 


Model 52-147B - Torque Motor
Test Set-Up Utilized To Determine
Natural Frequency of Torque Motor




Model 52-147
"Wire" Armature Motion Restrictors




Model 52-147
"Flat Spring" Flapper-Button
Motion Restrictors



Model 52-147
S/N 45 Oxidizer Nozzle
10X



Model 52-147
S/N 45 Fuel Nozzle
10X



Model 52-147
S/N 45 Fuel Button
15X

6.0 TEST DATA

Included in this section are the results of all performance and interval performance tests and all vibration X-Y plots generated during the Evaluation Test Program.

INITIAL PERFORMANCE

Model Number 52-147
Serial Number 204
Date 6/3/67

Specimen Designation Letter B
Tested By: _____
On Time _____ Cycles _____

Test	Proc. Par. No.	Conditions & Measurements	Limits	Test Results																									
MR 1144																													
Electrical Resistance a. Coil Resistance	5. 1. 3. 1	Measure and Record Ambient temperature		F																									
		Primary coil resistance		AB ohms																									
		Secondary coil resistance		CD ohms																									
Response Time	5. 1. 5	Measure opening and closing response from oscillograms. Inlet pressure at 310 psig for primary coil, at 360 psig for secondary coil.	primary open 9msec close 5 msec																										
		Primary coil-0. 80 amperes	secondary open 8. 0 msec. open 50 msec close 2. 7 msec.																										
		Secondary coil-0. 44 amperes	close 5msec open 48 msec. close 2. 3 msec.																										
		Primary and Secondary as above,	open 6. 3 msec. close 3. 0 msec.																										
Flow Test	5. 1. 6	Measure flow and pressure drop with inlet of 310 psig.																											
		<table border="1"> <thead> <tr> <th>Press Drop</th> <th>Fuel</th> <th>Oxidizer</th> </tr> </thead> <tbody> <tr> <td>15</td> <td>. 1085</td> <td>. 1332</td> </tr> <tr> <td>20</td> <td>. 1279</td> <td>. 1606</td> </tr> <tr> <td>25</td> <td>. 1433</td> <td>. 1811</td> </tr> <tr> <td>30</td> <td>. 1586</td> <td>. 1987</td> </tr> <tr> <td>35</td> <td>. 1672</td> <td>. 2163</td> </tr> <tr> <td>40</td> <td>. 1974</td> <td>. 2311</td> </tr> <tr> <td></td> <td>0. 144</td> <td>0. 179</td> </tr> <tr> <td></td> <td>25. 0</td> <td>24. 75</td> </tr> </tbody> </table>	Press Drop	Fuel	Oxidizer	15	. 1085	. 1332	20	. 1279	. 1606	25	. 1433	. 1811	30	. 1586	. 1987	35	. 1672	. 2163	40	. 1974	. 2311		0. 144	0. 179		25. 0	24. 75
Press Drop	Fuel	Oxidizer																											
15	. 1085	. 1332																											
20	. 1279	. 1606																											
25	. 1433	. 1811																											
30	. 1586	. 1987																											
35	. 1672	. 2163																											
40	. 1974	. 2311																											
	0. 144	0. 179																											
	25. 0	24. 75																											
Functional Test	5. 1. 7. 1	Inlet pressure at 360psig. Measure minimum voltage required to open valve 10 consecutive times at 0.25 cps.	<20volts	<table border="1"> <thead> <tr> <th></th> <th>Volts</th> <th>Amps</th> </tr> </thead> <tbody> <tr> <td>Pri</td> <td>7. 75</td> <td>. 48</td> </tr> <tr> <td>Sec</td> <td>12. 5</td> <td>. 39</td> </tr> <tr> <td>Both</td> <td>4. 65</td> <td>. 30</td> </tr> </tbody> </table>		Volts	Amps	Pri	7. 75	. 48	Sec	12. 5	. 39	Both	4. 65	. 30													
					Volts	Amps																							
Pri	7. 75	. 48																											
Sec	12. 5	. 39																											
Both	4. 65	. 30																											
Pull-in Voltage																													

INITIAL PERFORMANCE

Model Number 52-147
 Serial Number 204
 Date 6/3/67

Specimen Designation Letter _____
 Tested By _____
 On Time _____ Cycles _____

Test	Proc Par. No. MR 1144	Conditions & Measurements	Limits	Test Results
Drop-out Voltage	5.1.7.2	Inlet pressure at 166 psig Measure maximum voltage at which valve closes	>1.0 volts	Volts Amps <hr/> Pri 2.50 .152 Sec 4.13 .14 Both 1.51 .10
External Leakage	5.1.8	Apply 360 psig helium pressure to the oxidizer inlet with both return ports blocked. Energize valve to allow helium to enter all oxidizer chambers. Block fuel inlet and measure external leakage Open fuel inlet and measure external leakage Apply 360 psig helium press- ure to fuel inlet with both re- turn ports blocked. Energize valve to allow helium to enter all fuel chambers. Block oxi- dizer inlet and measure external leakage. Open oxidizer inlet and mea- sure external leakage.	$<10^{-4}$ cc/ sec.	Freon Immersion <u>no leakage</u>

INITIAL PERFORMANCE

Model Number 52-147
Serial Number 204
Date 6/3/67

Specimen Designation Letter _____
Tested By: _____
On Time _____ Cycles _____

Test	Proc. Par. No.	Conditions & Measurements	Limits	Test Results
	MR 1144			
Internal Leakage	5. I, 9	Measure outlet port leakage with inlet pressures of 50 and 360 psig Fuel Oxidizer		50 360 Psig Psig
				none none none none
		Cycle valve 100 times and repeat above tests, Fuel Oxidizer		100 none none none none
Reverse Seat Leak		Apply 20 psig to outlet ports Measure leakage at the inlet port	30 cc/ hr.	Fuel none Oxidizer none

POST SINUSOIDAL VIBRATION PERFORMANCE

Model Number 52-147
Serial Number 204
Date 6/5/67

Specimen Designation Letter _____
Tested By: _____
On Time _____ Cycles _____

Test	Proc. Par. No.	Conditions & Measurements	Limits	Test Results
	MR 1144			
Internal Leakage	5.1.9	Measure outlet port leakage with inlet pressures of 50 and 360 psig. Fuel Oxidizer		50 360 Psig Psig
				none none none none
		Cycle valve 100 times and repeat above tests. Fuel Oxidizer		none none none none
Reverse Seat Leak		Apply 20 psig to outlet ports Measure leakage at the inlet port	30 cc/ hr.	Fuel none Oxidizer none

POST AXIS A RANDOM VIBRATION PERFORMANCE

Model Number 52-147
Serial Number 204
Date 6/1/67

Specimen Designation Letter _____
Tested By: _____
On Time _____ Cycles _____

Test	Proc. Par. No.	Conditions & Measurements	Limits	Test Results
	MR 1144			
Internal Leakage	5.1.9	Measure outlet port leakage with inlet pressures of 50 and 360 psig. Fuel Oxidizer		50 360 Psig Psig
				none none none none
		Cycle valve 100 times and repeat above tests. Fuel Oxidizer		none none none none
Reverse Seat Leak		Apply 20 psig to outlet ports Measure leakage at the inlet port	30 cc/ hr.	Fuel none Oxidizer none

POST AXIS A RANDOM VIBRATION PERFORMANCE

Model Number 52-147
 Serial Number 204
 Date 6/7/67

Specimen Designation Letter _____
 Tested By: _____
 On Time _____ Cycles _____

Test	Proc. Par. No.	Conditions & Measurements	Limits	Test Results	
Functional Test	MR 1144			Volts	Amps
Pull-in Voltage	5. 1. 7. 1	Inlet pressure at 360 psig Measure minimum voltage required to open valve 10 consecutive times at 0.25 cps	< 20 volts	Pri 6.98 Sec 13.5 Both 1.19	.429 .409 .264
Drop-out Voltage	5. 1. 7. 2	Inlet pressure at 166 psig Measure maximum voltage at which valve closes	> 1.0 volts	Pri 2.66 Sec 4.14 Both 1.65	.163 .129 .102

POST AXIS B RANDOM VIBRATION PERFORMANCE

Model Number 52-147
Serial Number 204
Date 6/7/67

Specimen Designation Letter _____
Tested By: _____
On Time _____ Cycles _____

Test	Proc. Par. No.	Conditions & Measurements	Limits	Test Results
	MR 1144			
Internal Leakage	5.1.9	Measure outlet port leakage with inlet pressures of 50 and 360 psig. Fuel Oxidizer		50 360 Psig Psig
				none none
				none none
		Cycle valve 100 times and repeat above tests. Fuel Oxidizer		5.0 cc/hr. none 6.0 cc/hr. none
Reverse Seat Leak		Apply 20 psig to outlet ports Measure leakage at the inlet port	30 cc/ hr.	Fuel none Oxidizer none

POST AXIS B RANDOM VIBRATION PERFORMANCE

Model Number 52-147
 Serial Number 204
 Date 6/7/67

Specimen Designation Letter _____
 Tested By: _____
 On Time _____ Cycles _____

Test	Proc. Par. No.	Conditions & Measurements	Limits	Test Results	
	MR 1144				
Functional Test				Volts	Amps
Full-in Voltage	5. 1. 7. 1	Inlet pressure at 360 psig Measure minimum voltage required to open valve 10 consecutive times at 0.25 cps	< 20 volts	Pri <u>7.25</u>	<u>.449</u>
				Sec <u>14.0</u>	<u>.431</u>
				Both <u>4.55</u>	<u>.288</u>
Drop-out Voltage	5. 1. 7. 2	Inlet pressure at 166 psig Measure maximum voltage at which valve closes	> 1.0 volts	Pri <u>2.47</u>	<u>.150</u>
				Sec <u>4.05</u>	<u>.128</u>
				Both <u>1.54</u>	<u>.095</u>

POST AXIS C RANDOM VIBRATION PERFORMANCE

Model Number 52-147 Specimen Designation Letter _____
 Serial Number 204 Tested By: _____
 Date 6/3/67 On Time _____ Cycles _____

Test	Proc. Par. No. MR 1144	Conditions & Measurements	Limits	Test Results
Internal Leakage	5.1.9	Measure outlet port leakage with inlet pressures of 50 and 360 psig.		50 360
				Psig Psig
		Fuel		<u>none</u> <u>none</u>
		Oxidizer		<u>none</u> <u>none</u>
		Cycle valve 100 times and repeat above tests.		
		Fuel		<u>none</u> <u>none</u>
		Oxidizer		<u>none</u> <u>none</u>
Reverse Seat Leak		Apply 20 psig to outlet ports Measure leakage at the inlet port	30 cc/ hr.	Fuel <u>none</u> Oxidizer <u>none</u>

POST AXIS C RANDOM VIBRATION PERFORMANCE

Model Number 52-147
 Serial Number 204
 Date 1

Specimen Designation Letter _____
 Tested By: _____
 On Time _____ Cycles _____

Test	Proc. Par. No. MR 1144	Conditions & Measurements	Limits	Test Results	
				Volts	Amps
Functional Test					
Pull-in Voltage	5. 1. 7. 1	Inlet pressure at 360 psig Measure minimum voltage required to open valve 10 consecutive times at 0.25 cps	< 20 volts	Pri 6.6 Sec 13.1 Both 4.1	.43 .41 .27
Drop-out Voltage	5. 1. 7. 2	Inlet pressure at 166 psig Measure maximum voltage at which valve closes	> 1.0 volts	Pri 2.62 Sec 4.16 Both 1.61	.17 .14 .101

VIBRATION POST SINUSOIDAL & RANDOM PERFORMANCE

Model Number 52-147
 Serial Number 204
 Date 6/8/67

Specimen Designation Letter _____
 Tested By: _____
 On Time _____ Cycles _____

Test	Proc. Par. No. MR 1144	Conditions & Measurements	Limits	Test Results																													
Electrical Resistance a. Coil Resistance	5.1.3.1	Measure and Record Ambient temperature Primary coil resistance Secondary coil resistance		<table border="1"> <tr> <td>AB</td> <td>-</td> <td>ohms</td> </tr> <tr> <td>CD</td> <td>-</td> <td>ohms</td> </tr> </table>	AB	-	ohms	CD	-	ohms																							
AB	-	ohms																															
CD	-	ohms																															
Response Time	5.1.5	Measure opening and closing response from oscillograms. Inlet pressure at 310 psig for primary coil, at 360 psig for secondary coil. Primary coil -0.80 amperes Secondary coil -0.44 a amperes Primary and Secondary as above	primary open 9 msec close 5 msec secondary open open 50 msec close close 5 msec open close open close	<table border="1"> <tr> <td>8.4</td> <td>msec.</td> </tr> <tr> <td>3.0</td> <td>msec.</td> </tr> <tr> <td>96.0</td> <td>msec.</td> </tr> <tr> <td>3.2</td> <td>msec.</td> </tr> <tr> <td>7.0</td> <td>msec.</td> </tr> <tr> <td>3.4</td> <td>msec.</td> </tr> </table>	8.4	msec.	3.0	msec.	96.0	msec.	3.2	msec.	7.0	msec.	3.4	msec.																	
8.4	msec.																																
3.0	msec.																																
96.0	msec.																																
3.2	msec.																																
7.0	msec.																																
3.4	msec.																																
Flow Test	5.1.6	Measure flow and pressure drop with inlet of 310 psig <table border="1"> <thead> <tr> <th rowspan="2">Press Drop</th> <th colspan="2">Flow-lb/sec</th> </tr> <tr> <th>Fuel</th> <th>Oxidizer</th> </tr> </thead> <tbody> <tr> <td>15</td> <td>.1089</td> <td>.1336</td> </tr> <tr> <td>20</td> <td>.1277</td> <td>.1600</td> </tr> <tr> <td>25</td> <td>.1441</td> <td>.1818</td> </tr> <tr> <td>30</td> <td>.1590</td> <td>.1990</td> </tr> <tr> <td>35</td> <td>.1671</td> <td>.2160</td> </tr> <tr> <td>40</td> <td>.1980</td> <td>.2314</td> </tr> <tr> <td></td> <td>0.144</td> <td>0.179</td> </tr> <tr> <td></td> <td>25.0</td> <td>26.75</td> </tr> </tbody> </table>	Press Drop	Flow-lb/sec		Fuel	Oxidizer	15	.1089	.1336	20	.1277	.1600	25	.1441	.1818	30	.1590	.1990	35	.1671	.2160	40	.1980	.2314		0.144	0.179		25.0	26.75		
Press Drop	Flow-lb/sec																																
	Fuel	Oxidizer																															
15	.1089	.1336																															
20	.1277	.1600																															
25	.1441	.1818																															
30	.1590	.1990																															
35	.1671	.2160																															
40	.1980	.2314																															
	0.144	0.179																															
	25.0	26.75																															
Functional Test Pull-In Voltage	5.1.7.1	Inlet pressure at 360 psig. Measure minimum voltage required to open valve 10 consecutive times at 0.25 cps.	< 20 volts	<table border="1"> <thead> <tr> <th></th> <th>Volts</th> <th>Amps</th> </tr> </thead> <tbody> <tr> <td>Pri</td> <td>7.25</td> <td>.449</td> </tr> <tr> <td>Sec</td> <td>14.0</td> <td>.431</td> </tr> <tr> <td>Both</td> <td>4.53</td> <td>.288</td> </tr> </tbody> </table>		Volts	Amps	Pri	7.25	.449	Sec	14.0	.431	Both	4.53	.288																	
	Volts	Amps																															
Pri	7.25	.449																															
Sec	14.0	.431																															
Both	4.53	.288																															

VIBRATION POST SINUSOIDAL & RANDOM PERFORMANCE

Model Number 52-147
Serial Number 204
Date 6/8/67

Specimen Designation Letter _____
Tested By: _____
On Time _____ Cycles _____

Test	Proc. Par. No.	Conditions & Measurements	Limits	Test Results
Drop-out Voltage	5.1.7.2	Inlet pressure at 166 psig Measure maximum voltage at which valve closes.	> 1.0 volts	Volts Amps
				Pri 2.47 .150
				Sec 4.05 .128
				Both 1.54 .095
External Leakage	5.1.8	Apply 360 psig helium pressure to the oxidizer inlet with both return ports blocked. Energize valve to allow helium to enter all oxidizer chambers. Block fuel inlet and measure external leakage	<10 ⁻⁴ cc/sec.	Freon Immersion No Leakage
				Open fuel inlet and measure external leakage
				Apply 360 psig helium pressure to fuel inlet with both return ports blocked. Energize valve to allow helium to enter all fuel chambers. Block oxidizer inlet and measure external leakage.
				Open oxidizer inlet and measure external leakage.

VIBRATION POST SINUSOIDAL & RANDOM PERFORMANCE

Model Number 52-147
Serial Number 204
Date 6/8/67

Specimen Designation Letter _____
Tested By: _____
On Time _____ Cycles _____

Test	Proc. Par. No.	Conditions & Measurements	Limits	Test Results
	MR 1144			
Internal Leakage	5.1.9	Measure outlet port leakage with inlet pressures of 50 and 360 psig. Fuel Oxidizer		50 360
				Psig Psig
				none none
				none none
		Cycle valve 100 times and repeat above tests.		
		Fuel	5 cc/hr.	none
		Oxidizer	6 cc/hr	none
Reverse Seat Leak		Apply 20 psig to outlet ports Measure leakage at the inlet port	30 cc/ hr.	Fuel none Oxidizer none

POST 50,000-CYCLE PERFORMANCE

Model Number 52-147
Serial Number 204
Date 6/8/67

Specimen Designation Letter _____
Tested By: _____
On Time _____ Cycles _____

Test	Proc. Par. No.	Conditions & Measurements	Limits	Test Results												
Electrical Resistance																
		Measure and Record Ambient temperature		-												
a/ Coil Resistance	5. 1. 3. 1	Primary coil resistance		AB - ohms												
		Secondary coil resistance		CD - ohms												
Response Time																
	5. 1. 5	Measure opening and closing response from oscillograms. Inlet pressure at 310 psig for primary coil, at 360 psig for secondary coil.	primary open 9 msec close 5 msec													
		Primary coil-0. 80 amperes	secondary open 8. 0 msec. open 50 msec close 3. 2 msec.													
		Secondary coil-0. 44 amperes	close 5 msec open 84. 0 msec. at 340 psi close 2. 8 msec.													
		Primary and Secondary as above.	open 6. 6 msec. close 3. 3 msec.													
Flow Test																
	5. 1. 6	Measure flow and pressure drop with inlet of 310 psig.														
		Press Flow -lb./sec.														
		Drop Fuel Oxidizer														
		15	. 1105	. 1344												
		20	. 1283	. 1610												
		25	. 1441	. 1797												
		30	. 1583	. 1978												
		35	. 1729	. 2128												
		40	. 1852	. 2284												
			0. 144	0. 179												
			25. 0	24. 75												
Functional Test																
Pull-in Voltage	5. 1. 7. 1	Inlet pressure at 360psig. Measure minimum voltage required to open valve 10 consecutive times at 0.25 cps.	<20volts													
				<table border="1"> <thead> <tr> <th></th> <th>Volts</th> <th>Amps</th> </tr> </thead> <tbody> <tr> <td>Pri</td> <td>7. 98</td> <td>. 496</td> </tr> <tr> <td>Sec</td> <td>12. 70</td> <td>. 402</td> </tr> <tr> <td>Both</td> <td>5. 00</td> <td>. 316</td> </tr> </tbody> </table>		Volts	Amps	Pri	7. 98	. 496	Sec	12. 70	. 402	Both	5. 00	. 316
	Volts	Amps														
Pri	7. 98	. 496														
Sec	12. 70	. 402														
Both	5. 00	. 316														

Reproduced from best available copy.

POST 50,000 CYCLES PERFORMANCE

Model Number 52-147
 Serial Number _____
 Date _____

Specimen Designation Letter _____
 Tested By _____
 On Time _____ Cycles _____

Test	Proc. Par. No.	Conditions & Measurements	Limits	Test Results					
Drop-out Voltage	5.1.7.2	Inlet pressure at 160 psig Measure maximum voltage at which valve closes	1.0 volts	Volts Amps					
				<table border="1"> <tr> <td>Pri</td> <td>2.09</td> <td>.131</td> </tr> <tr> <td>Sec</td> <td>3.22</td> <td>.105</td> </tr> <tr> <td>Both</td> <td>1.24</td> <td>.077</td> </tr> </table>	Pri	2.09	.131	Sec	3.22
Pri	2.09	.131							
Sec	3.22	.105							
Both	1.24	.077							
External Leakage	5.1.8	Apply 360 psig helium pressure to the oxidizer inlet with both return ports blocked. Energize valve to allow helium to enter all oxidizer chambers. Block fuel inlet and measure external leakage	$<10^{-4}$ cc/sec.	Freon Immersion No Leakage					
		Open fuel inlet and measure external leakage							
		Apply 360 psig helium pressure to fuel inlet with both return ports blocked. Energize valve to allow helium to enter all fuel chambers. Block oxidizer inlet and measure external leakage.							
		Open oxidizer inlet and measure external leakage.	$<10^{-4}$ cc/sec.						

POST 50,000 CYCLES PERFORMANCE

Model Number 52-147
Serial Number _____
Date _____

Specimen Designation Letter _____
Tested By: _____
On Time _____ Cycles _____

Test	Proc. Par. No.	Conditions & Measurements	Limits	Test Results
	MR 1144			
Internal Leakage	5.1.9	Measure outlet port leakage with inlet pressures of 50 and 360 psig. Fuel Oxidizer		50 360 Psig Psig
				<u>26 cc/hr.</u> <u>7.2 cc/hr.</u> <u>22 cc/hr.</u> <u>55.2 cc/hr.</u>
		Cycle valve 100 times and repeat above tests. Fuel Oxidizer		<u>4 cc/hr.</u> <u>5 cc/hr.</u> <u>12 cc/hr.</u> <u>41 cc/hr.</u>
Reverse Seat Leak		Apply 20 psig to outlet ports Measure leakage at the inlet port:	30 cc/ hr.	Fuel <u>2.0 cc/hr.</u> Oxidizer <u>6.0 cc/hr.</u>




Figure 1




Figure 2




Figure 3




Figure 4




Figure 5




Figure 6




Figure 7

(10)

B. P. P. 12
4-25-67




Figure 8

INITIAL PERFORMANCE

Model Number 52-146
Serial Number _____
Date 5/26/67

Specimen Designation Letter _____
Tested By: _____
On Time _____ Cycles _____

Test	Proc. Par. No. MR 1144	Conditions & Measurements	Limits	Test Results
Internal Leakage	5. 1. 9	Measure outlet port leakage with inlet pressures of 50 and 360 psig. Fuel Oxidizer		50 360 Psig Psig
				none none none none
		Cycle valve 100 times and repeat above tests.		
		Fuel Oxidizer		none none none none
Reverse Seat Leak		Apply 20 psig to outlet port, Measure leakage at the inlet port	30 cc/ hr.	Fuel none Oxidizer none

POST SINUSOIDAL VIBRATION PERFORMANCE

Model Number 52-146
 Serial Number _____
 Date 5/26/67

Specimen Designation Letter _____
 Tested By: _____
 On Time _____ Cycles _____

Test	Proc. Par. No.	Conditions & Measurements	Limits	Test Results
	MR 1144			
Internal Leakage	5. 1. 9	Measure outlet port leakage with inlet pressures of 50 and 360 psig. Fuel Oxidizer		50 360 Psig Psig
				none none none none
		Cycle valve 100 times and repeat above tests. Fuel Oxidizer		none none none none
Reverse Seat Leak		Apply 20 psig to outlet ports Measure leakage at the inlet port	30 cc/ hr.	Fuel none Oxidizer none

POST RANDOM VIBRATION PERFORMANCE

Model Number 52-146
 Serial Number _____
 Date 5/26/67

Specimen Designation Letter _____
 Tested By: _____
 On Time _____ Cycles _____

Test	Proc. Par. No.	Conditions & Measurements	Limits	Test Results
	MR 1144			
Internal Leakage	5.1.9	Measure outlet port leakage with inlet pressures of 50 and 360 psig. Fuel Oxidizer,	50	360
			Psig	Psig
			none	none
			none	none
		Cycle valve 100 times and repeat above tests.		
		Fuel	35 cc/hr.	none
		Oxidizer	none	none
Reverse Seat Leak		Apply 20 psig to outlet ports Measure leakage at the inlet port	30 cc/hr.	Fuel _____ Oxidizer _____
				none none

Model 52-146
Axis A 5/20/67
27.7 g rms input
Wire armature motion
restrictors of free end
of armature




Figure 10

Model 52-146
Axis B 5/26/67
27.7 g rms input
Wire armature motion
restrictors on free end
of armature




Figure 11

Model 52-147
Axis A 6/7/67
27.7 g rms input
Wire armature motion
restrictors on free end
of armature

Reproduced from
best available copy.




Figure 12

Model 52-147 S/N 204
Axis B (1/7/67)
27.7 g rms input
Wire armature motion
restrictors on free end
of armature




Figure 13

Reproduced from
best available copy.

Model 52-147 S/N 204
Axis C 6/6/67
27.7 g rms input
Wire armature motion
restrictors on free end
of armature




Figure 14

INITIAL PERFORMANCE

Model Number 52-147
 Serial Number 45
 Date 7/19/67

Specimen Designation Letter _____
 Tested By: _____
 On Time _____ Cycles _____

Test	Proc. Par. No.	Conditions & Measurements	Limits	Test Results
Electrical Resistance	5.1.3.1	Measure and Record Ambient temperature		- °F
Coil Resistance		Primary coil resistance	AB	- ohms
		Secondary coil resistance	CD	- ohms
Response Time	5.1.5	Measure opening and closing response from oscillograms. Inlet pressure at 200 psig for primary coil, at 200 psig for secondary coil.	primary open 9 msec close 5 msec	
		Primary coil-0.80 amperes	secondary open	<u>4.2 msec.</u>
		Secondary coil-0.44 amperes	open 50 msec close	<u>3.0 msec.</u>
		Primary and Secondary as above.	close 5msec open	<u>7.4 msec.</u>
			close	<u>2.6 msec.</u>
			open	<u>4.9 msec.</u>
			close	<u>2.8 msec.</u>
Flow Test	5.1.6	Measure flow and pressure drop with inlet of 310 psig.		
		Press Drop	Flow - lb./sec. Fuel Oxidizer	
		15	.1039 .1097	
		20	.1175 .1306	
		25	.1350 .1471	
		30	.1480 .1607	
		35	.1606 .1748	
		40	.1727 .1865	
			0.144 0.179	
Functional Test		28.25 36.50		
Full-in Voltage	5.1.7.1	Inlet pressure at 200 psig. Measure minimum voltage required to open valve 10 consecutive times at 0.25 cps	<20 volts	
			Pri	<u>3.82</u> <u>.249</u>
			Sec	<u>5.79</u> <u>.194</u>
			Both	<u>3.10</u> <u>.203</u>

INITIAL PERFORMANCE

Model Number 52-147
 Serial Number 45
 Date 7/19/67

Specimen Designation Letter _____
 Tested By _____
 On Time _____ Cycles _____

Test	Proc. Par. No.	Conditions & Measurements	Limits	Test Results
Drop-out Voltage	5. 1. 7. 2	Inlet pressure at 166 psig Measure maximum voltage at which valve closes	1. 0volts	Volts Amps
				Pri 1.43 .087
				Sec 2.29 .071
				Both .84 .054
External Leakage	5. 1. 8	Apply 360 psig helium pressure to the oxidizer inlet with both return ports blocked. Energize valve to allow helium to enter all oxidizer chambers. Block fuel inlet and measure external leakage. Open fuel inlet and measure external leakage Apply 360 psig helium pressure to fuel inlet with both return ports blocked. Energize valve to allow helium to enter all fuel chambers. Block oxidizer inlet and measure external leakage. Open oxidizer inlet and measure external leakage.	<10 ⁻⁴ cc/sec.	Freon Immersion <u>no leakage</u>

Reproduced from best available copy.

INITIAL PERFORMANCE

Model Number 52-147
 Serial Number 45
 Date 7/19/67

Specimen Designation Letter _____
 Tested By _____
 On Time _____ Cycles _____

Test	Proc. Par. No. MR 1144	Conditions & Measurements	Limits	Test Results
Internal Leakage	5.1.9	Measure outlet port leakage with inlet pressures of 50 and 360 psig. Fuel Oxidizer		50 360 Psig Psig
				<u>none</u> <u>none</u> <u>none</u> <u>none</u>
		Cycle valve 100 times and repeat above tests Fuel Oxidizer		<u>none</u> <u>none</u> <u>none</u> <u>none</u>
Reverse Seat Leak		Apply 20 psig to outlet ports Measure leakage at the inlet port	30 cc/ hr.	Fuel <u>none</u> Oxidizer <u>none</u>

Reproduced from
 best available copy.

POST AXIS C SINUSOIDAL VIBRATION PERFORMANCE

Model Number 52-147
 Serial Number 45
 Date 7/19/67

Specimen Designation Letter _____
 Tested By _____
 On Time _____ Cycles _____

Test	Proc. Par. No.	Conditions & Measurements	Limits	Test Results
	MR 1144			
Internal Leakage	5.1.9	Measure outlet port leakage with inlet pressures of 50 and 360 psig.	50	360
			Psig	Psig
		Fuel	none	none
		Oxidizer	none	none
		Cycle valve 100 times and repeat above tests.		
		Fuel	none	none
		Oxidizer	none	none
Reverse Seat Leak		Apply 20 psig to outlet ports. Measure leakage at the inlet port	30 cc/hr.	Fuel <u>none</u> Oxidizer <u>none</u>

POST AXIS A SINUSOIDAL VIBRATION PERFORMANCE

Model Number 52-147
 Serial Number 45
 Date 7/20/67

Specimen Designation Letter _____
 Tested By: _____
 On Time _____ Cycles _____

Test	Proc. Par. No.	Conditions & Measurements	Limits	Test Results
	MR 1144			
Internal Leakage	5.1.9	Measure outlet port leakage with inlet pressures of 50 and 360 psig.		
		Fuel	50 Psig	360 Psig
		Oxidizer	none	none
		Cycle valve 100 times and repeat above tests.		
		Fuel	none	none
		Oxidizer	none	none
Reverse Seat Leak		Apply 20 psig to outlet ports Measure leakage at the inlet port	30 cc/ hr.	Fuel <u>none</u> Oxidizer <u>none</u>

POST SINUSOIDAL VIBRATION PERFORMANCE

Model Number 52-147
 Serial Number 45
 Date 7/20/67

Specimen Designation Letter _____
 Tested By: _____
 On Time _____ Cycles _____

Test	Proc. Par. No.	Conditions & Measurements	Limits	Test Results																		
Electrical Resistance		Measure and Record Ambient temperature		-																		
a. Coil Resistance	5.1.3.1	Primary coil resistance Secondary coil resistance		AB - ohms CD - ohms																		
Response Time	5.1.5	Measure opening and closing response from oscillograms. Inlet pressure at 200 psig for primary coil, at 200 psig for secondary coil. Primary coil - 0.80 amperes Secondary coil - 0.44 amperes Primary and Secondary as above.	primary open 9 msec close 5 msec secondary open open 50 msec close close 5 msec open	4.2 msec. 2.8 msec. 6.3 msec. 1.3 msec. 4.1 msec. 3.0 msec.																		
Flow Test	5.1.6	Measure flow and pressure drop with inlet of 310 psig																				
		<table border="1"> <thead> <tr> <th>Press Drop</th> <th>Flow-lb/sec Fuel Oxidizer</th> </tr> </thead> <tbody> <tr><td>15</td><td>.1017 .1113</td></tr> <tr><td>20</td><td>.1193 .1309</td></tr> <tr><td>25</td><td>.1339 .1462</td></tr> <tr><td>30</td><td>.1469 .1607</td></tr> <tr><td>35</td><td>.1586 .1751</td></tr> <tr><td>40</td><td>.1686 .1871</td></tr> <tr><td></td><td>0.144 0.179</td></tr> <tr><td></td><td>29.0 32.0</td></tr> </tbody> </table>	Press Drop	Flow-lb/sec Fuel Oxidizer	15	.1017 .1113	20	.1193 .1309	25	.1339 .1462	30	.1469 .1607	35	.1586 .1751	40	.1686 .1871		0.144 0.179		29.0 32.0		
Press Drop	Flow-lb/sec Fuel Oxidizer																					
15	.1017 .1113																					
20	.1193 .1309																					
25	.1339 .1462																					
30	.1469 .1607																					
35	.1586 .1751																					
40	.1686 .1871																					
	0.144 0.179																					
	29.0 32.0																					
Functional Test																						
Pull-in Voltage	5.1.7.1	Inlet pressure at 200 psig Measure minimum voltage required to open valve 10 consecutive times at 0.25 cps.	< 20 volts	<table border="1"> <thead> <tr> <th></th> <th>Volts</th> <th>Amps</th> </tr> </thead> <tbody> <tr><td>Pri</td><td>3.50</td><td>.226</td></tr> <tr><td>Sec</td><td>5.77</td><td>.194</td></tr> <tr><td>Both</td><td>2.24</td><td>.148</td></tr> </tbody> </table>		Volts	Amps	Pri	3.50	.226	Sec	5.77	.194	Both	2.24	.148						
	Volts	Amps																				
Pri	3.50	.226																				
Sec	5.77	.194																				
Both	2.24	.148																				

POST SINUSOIDAL VIBRATION PERFORMANCE

Model Number 52-147
 Serial Number 45
 Date 7/20/69

Specimen Designation Letter _____
 Tested By: _____
 On Time _____ Cycles _____

Test	Proc. Par. No.	Conditions & Measurements	Limits	Test Results
Drip-out Voltage	5. 1. 7. 2	Inlet pressure at 166 psig Measure maximum voltage at which valve closes	1.0 volts	Volts
				Amps
				Pri 1.21 .075
				Sec 1.87 .062
External Leakage	5. 1. 8	Apply 360 psig helium pressure to the oxidizer inlet with both return ports blocked. Energize valve to allow helium to enter all oxidizer chambers. Block fuel inlet and measure external leakage	$<10^{-4}$ cc/sec.	Freon Immersion
				no leakage
				Open fuel inlet and measure external leakage
				Apply 360 psig helium pressure to fuel inlet with both return ports blocked. Energize valve to allow helium to enter all fuel chambers. Block oxidizer inlet and measure external leakage.
External Leakage	5. 1. 8	Open oxidizer inlet and measure external leakage.	$<10^{-4}$ cc/sec.	

Reproduced from best available copy.

POST SINUSOIDAL VIBRATION PERFORMANCE

Model Number 52-147

Specimen Designation Letter _____

Serial Number 45

Tested By: _____

Date 7/20/67

On Time _____ Cycles _____

Test	Prec. Par. No. MR 1144	Conditions & Measurements	Limits	Test Results
Internal Leakage	5. 1. 9 ^b	Measure outlet port leakage with inlet pressures of 50 and 360 psig. Fuel Oxidizer		50 360 Psig Psig
				<u>none</u> <u>none</u> <u>none</u> <u>none</u>
		Cycle valve 100 times and repeat above tests. Fuel Oxidizer		<u>none</u> <u>none</u> <u>none</u> <u>none</u>
Reverse Seat Leak		Apply 20 psig to outlet ports Measure leakage at the inlet port	30 cc/ hr.	Fuel <u>5</u> Oxidizer <u>5</u>

Model 52X147C Body S/N 45
Axis C 7/25/67
Flapper button motion restrictors
flat spring
27.7 g rms




Figure 15

POST AXIS C RANDOM VIBRATION PERFORMANCE

Model Number 52-147
 Serial Number 45
 Date 7/25/67

Specimen Designation Letter _____
 Tested By: _____
 On Time _____ Cycles _____

Test	Proc. Par. No.	Conditions & Measurements	Limits	Test Results
	MR 1144			
Internal Leakage	5.1.9	Measure outlet port leakage with inlet pressures of 50 and 360 psig. Fuel Oxidizer	50 Psig	360 Psig
			none	none
		Cycle valve 100 times and repeat above tests. Fuel Oxidizer	none	none
			none	none
Reverse Seat Leak		Apply 20 psig to outlet ports Measure leakage at the inlet port	30 cc/ hr.	Fuel <u>none</u> Oxidizer <u>none</u>

Reproduced from best available copy. 

Model 52X147C Body S/N 45
Axis A 7/25/67
Flapper button motion restrictors
flat spring
27.7 g rms input




Figure 16

POST AXIS A RANDOM VIBRATION PERFORMANCE

Model Number 52-147
 Serial Number 45
 Date 7/25/67

Specimen Designation Letter _____
 Tested By: _____
 On Time _____ Cycles _____

Test	Proc. Par. No.	Conditions & Measurements	Limits	Test Results
	<u>MR 1144</u>			
Internal Leakage	5.1.9	Measure outlet port leakage with inlet pressures of 50 and 360 psig. Fuel Oxidizer	50	360
			Psig	Psig
			none	none
			none	none
		Cycle valve 100 times and repeat above tests. Fuel Oxidizer		
			none	none
			none	none
Reverse Seat Leak		Apply 20 psig to outlet ports Measure leakage at the inlet port	30 cc/ hr.	Fuel <u>none</u> Oxidizer <u>none</u>

Reproduced from best available copy.

VIBRATION POST SINUSOIDAL & RANDOM PERFORMANCE

Model Number 52-147
 Serial Number 45
 Date 7/26/67

Specimen Designation Letter _____
 Tested By: _____
 On Time _____ Cycles _____

Test	Prov. Par. No. MR 1144	Conditions & Measurements	Limits	Test Results
Electrical Resistance		Measure and Record Ambient temperature		-
a. Coil Resistance	5.1.3.1	Primary coil resistance		AB - ohms
		Secondary coil resistance		CD - ohms
Response Time	5.1.5	Measure opening and closing response from oscillograms. Inlet pressure at 200 psig for primary coil, at 200 psig for secondary coil	primary open 9 msec close 5 msec	
		Primary coil - 0.80 amperes	secondary open	3.4 msec.
		Secondary coil - 0.44 amperes	open 50 msec close	4.9 msec.
		Primary and Secondary as above	close 5 msec open	5.0 msec.
			close	4.4 msec.
			open	3.2 msec.
			close	5.2 msec.
Flow Test	5.1.6	Measure flow and pressure drop with inlet of 310 psig.		
		Press Drop	Flow - lb/sec Fuel Oxidizer	
		15	.1040 .1142	
		20	.1200 .1320	
		25	.1340 .1470	
		30	.1470 .1605	
		35	.1580 .1718	
		40	.1690 .1813	
			0.144 0.179	
Functional Test			29.0 38.6	
Pull-in Voltage	5.1.7.1	Inlet pressure at 200 psig. Measure minimum voltage required to open valve 10 consecutive times at 0.25 cps.	<20 volts	
				Volts Amps
				Pri 3.35 .219
				Sec 4.87 .167
				Both 1.05 .070

VIBRATION POST SINUSOIDAL & RANDOM PERFORMANCE.

Model Number 52-147
 Serial Number 45
 Date 7/26/67

Specimen Designation Letter _____
 Tested By: _____
 On Time _____ Cycles _____

Test	Proc. Par. No.	Conditions & Measurements	Limits	Test Results												
	MR 1144															
Drop-out Voltage	5. 1. 7. 2	Inlet pressure at 166 psig Measure maximum voltage at which valve closes	51.0volts	<table border="1"> <thead> <tr> <th></th> <th>Volts</th> <th>Amps</th> </tr> </thead> <tbody> <tr> <td>Pri</td> <td>1.52</td> <td>.096</td> </tr> <tr> <td>Sec</td> <td>2.42</td> <td>.080</td> </tr> <tr> <td>Both</td> <td>.90</td> <td>.054</td> </tr> </tbody> </table>		Volts	Amps	Pri	1.52	.096	Sec	2.42	.080	Both	.90	.054
	Volts	Amps														
Pri	1.52	.096														
Sec	2.42	.080														
Both	.90	.054														
External Leakage	5. 1. 8	Apply 360 psig helium pressure to the oxidizer inlet with both return ports blocked. Energize valve to allow helium to enter all oxidizer chambers. Block fuel inlet and measure external leakage Open fuel inlet and measure external leakage Apply 360 psig helium pressure to fuel inlet with both return ports blocked. Energize valve to allow helium to enter all fuel chambers. Block oxidizer inlet and measure external leakage. Open oxidizer inlet and measure external leakage.	<10 ⁻⁴ cc/sec.	<p>Freon Immersion no leakage</p> <hr/> <hr/>												

VIBRATION POST SINUSOIDAL & RANDOM PERFORMANCE

Model Number 52-147
 Serial Number 45
 Date 7/26/67

Specimen Designation Letter _____
 Tested By: _____
 On Time _____ Cycles _____

Test	Proc. Par. No.	Conditions & Measurements	Limits	Test Results
	MR 1144			
Internal Leakage	5.1.9	Measure outlet port leakage with inlet pressures of 50 and 360 psig.		50 360
				Psig Psig
		Fuel		<u>none</u> <u>none</u>
		Oxidizer		<u>none</u> <u>none</u>
		Cycle valve 100 times and repeat above tests.		
		Fuel		<u>none</u> <u>none</u>
		Oxidizer		<u>none</u> <u>none</u>
Reverse Seat Leak		Apply 20 psig to outlet ports Measure leakage at the inlet port	30 cc/ hr.	Fuel <u>none</u> Oxidizer <u>none</u>

POST 50,000 CYCLE PERFORMANCE

Model Number 52-147
 Serial Number 45
 Date 7/26/67

Specimen Designation Letter _____
 Tested By _____
 On Time _____ Cycles _____

Test	Proc. Par. No.	Conditions & Measurements	Limits	Test Results
	MR 1144			
Electrical Resistance		Measure and Record Ambient temperature		- ° F
Coil Resistance	5.1.3.1	Primary coil resistance	AB	- ohms
		Secondary coil resistance	CD	- ohms
Response Time	5.1.5	Measure opening and closing response from oscillograms. Inlet pressure at 200 psig for primary coil, at 200 psig for secondary coil.	primary open 9 msec close 5 msec	
		Primary coil - 0.80 amperes	secondary open	4.1 msec.
		Secondary coil - 0.44 amperes	open 50 msec close	4.2 msec.
		Primary and Secondary as above	close 5 msec open	6.5 msec.
			close	3.9 msec.
			open	4.0 msec.
			close	5.0 msec.
Flow Test	5.1.6	Measure flow and pressure drop with inlet of 310 psig.		
		Press Drop	Flow - lb/sec Fuel Oxidizer	
		15	.0971 .1110	
		20	.1110 .1281	
		25	.1232 .1420	
		30	.1340 .1536	
		35	.1435 .1645	
		40	.1513 .1745	
			0.144 0.179	
		35.8	42.1	
Functional Test	5.1.7.1	Inlet pressure at 200 psig. Measure minimum voltage required to open valve 10 consecutive times at 0.25 cps	<20 volts	
Minimum Voltage				
			Pri	3.12 .201
			Sec	4.71 .161
			Both	1.32 .090

BOST 50,000 CYCLES PERFORMANCE

Model Number 52-147
 Serial Number 45
 Date 7/26/67

Specimen Designation Letter _____
 Tested By _____
 On Time _____ Cycles _____

Test	Proc. Par. No.	Conditions & Measurements	Limits	Test Results	
Drop-out Voltage	5.1.7.2	Inlet pressure at 166 psig Measure maximum voltage at which valve closes	>1.0volts	Volts	Amps
				Pri 1.59	.096
				Sec 2.50	.082
				Both .90	.057
External Leakage	5.1.8	Apply 360 psig helium pressure to the oxidizer inlet with both return ports blocked. Energize valve to allow helium to enter all oxidizer chambers. Block fuel inlet and measure external leakage. Open fuel inlet and measure external leakage Apply 360 psig helium pressure to fuel inlet with both return ports blocked. Energize valve to allow helium to enter all fuel chambers. Block oxidizer inlet and measure external leakage. Open oxidizer inlet and measure external leakage.	<10 ⁻⁴ cc/sec.	Freon Immersion <u>no leakage</u>	

POST 50,000 CYCLES PERFORMANCE

Model Number 52-147
 Serial Number 45
 Date 7/26/67

Specimen Designation Letter _____
 Tested By _____
 On Time _____ Cycles _____

Test	Proc. Par. No.	Conditions & Measurements	Limits	Test Results
Internal Leakage	5.1.9	Measure outlet port leakage with inlet pressures of 50 and 360 psig.	50	360
			Psig	Psig
		Fuel	none	none
		Oxidizer	none	none
		Cycle valve 100 times and repeat above tests.		
		Fuel	none	none
		Oxidizer	none	none
Reverse Seat Leak		Apply 20 psig to outlet ports. Measure leakage at the inlet port.	30 cc/hr.	Fuel <u>none</u> Oxidizer <u>none</u>

INITIAL PERFORMANCE

Model Number 52X147
 Serial Number 112
 Date 8/8/67

Specimen Designation Letter C
 Tested By _____
 On Time _____ Cycles _____

Test	Proc. Par. No.	Conditions & Measurements	Limits	Test Results
Electrical Resistance	5.1.3.1	Measure and Record Ambient temperature Primary coil resistance Secondary coil resistance.		— °F AB — ohms CD — ohms
Response Time	5.1.5	Measure opening and closing response from oscillograms. Inlet pressure at 310 psig for primary coil, at 360 psig for secondary coil. Primary coil - 0.80 amperes Secondary coil - 0.44 amperes Primary and Secondary as above.	primary open 9 msec close 5 msec secondary open open 50 msec close close 5 msec open close open close	6.2 msec. 1.6 msec. 1.2 msec. 1.2 msec. 5.0 msec. 2.2 msec.
Flow Test	5.1.6	Measure flow and pressure drop with inlet of 310 psig. Press. Flow - lb/sec Drop Fuel Oxidizer		
		15 .1086 .1191 20 .1276 .1413 25 .1435 .1581 30 .1580 .1740 35 .1719 .1887 40 .1823 .2022 0.144 0.179		
Functional Test	5.1.7.1	Inlet pressure at 360 psig. Measure minimum voltage required to open valve 10 consecutive times at 0.25 cps.	25.3 31.8 <20volts •	Volts Amps Pri 6.80 .391 Sec 10.30 .305 Both 3.70 .231

INITIAL PERFORMANCE

Model Number 52X147
 Serial Number 112
 Date 8/8/67

Specimen Designation Letter C
 Tested By:
 On Time _____ Cycles _____

Test	Proc. Par. No.	Conditions & Measurements	Limits	Test Results	
	MR 1144				
Drop-out Voltage	5.1.7.2	Inlet pressure at 166 psig Measure maximum voltage at which valve closes	>1.0volts	Volts	Amps
				Pri	1.37 .080
				Sec	1.97 .060
				Both	785 .049
External Leakage	5.1.8	Apply 360 psig helium pressure to the oxidizer inlet with both return ports blocked. Energize valve to allow helium to enter all oxidizer chambers. Block fuel inlet and measure external leakage	<10 ⁻⁴ cc/sec.		
		Open fuel inlet and measure external leakage			
		Apply 360 psig helium pressure to fuel inlet with both return ports blocked. Energize valve to allow helium to enter all fuel chambers. Block oxidizer inlet and measure external leakage.			
		Open oxidizer inlet and measure external leakage	<10 ⁻⁴ cc/sec.		

INITIAL PERFORMANCE

Model Number 52X147
 Serial Number 112
 Date 8/8/67

Specimen Designation Letter C
 Tested By _____
 On Time _____ Cycles _____

Test	Proc. Par. No. MR 1144	Conditions & Measurements	Limits	Test Results
Internal Leakage	5.1.9	Measure outlet port leakage with inlet pressures of 50 and 360 psig.		50 360
				Psig Psig
		Fuel		<u>none</u> <u>none</u>
		Oxidizer		<u>none</u> <u>none</u>
Reverse Seat Leak		Apply 20 psig to outlet ports Measure leakage at the inlet port.	30 cc/	Fuel <u>none</u>
			hr.	Oxidizer <u>15 cc/hr</u>

POST AXIS C SINUSOIDAL VIBRATION PERFORMANCE

Model Number 52X147
 Serial Number 112
 Date 8/10/67

Specimen Designation Letter C
 Tested By: _____
 On Time _____ Cycles _____

Test	Proc. Par. No. MR 1144	Conditions & Measurements	Limits	Test Results	
Internal Leakage	5.1.9	Measure outlet port leakage with inlet pressures of 50 and 360 psig. Fuel Oxidizer		50 Psig	360 Psig
				none	none
		Cycle valve 100 times and repeat above tests. Fuel Oxidizer		none	none
				none	none
Reverse Seat Leak		Apply 20 psig to outlet ports Measure leakage at the inlet port.	30 cc/hr.	Fuel	none
				Oxidizer	none

POST AXIS-A SINUSOIDAL VIBRATION PERFORMANCE

Model Number 52X147
 Serial Number 112
 Date 8/10/67

Specimen Designation Letter C
 Tested By: _____
 On Time _____ Cycles _____

Test	Proc. Par. No.	Conditions & Measurements	Limits	Test Results
Internal Leakage	5.1.9	Measure outlet port leakage with inlet pressures of 50 and 360 psig.	50	360
			Psig	Psig
		Fuel	none	none
		Oxidizer	none	none
		Cycle valve 100 times and repeat above tests.		
		Fuel	none	none
		Oxidizer	none	none
Reverse Seat Leak		Apply 20 psig to outlet ports Measure leakage at the inlet port.	30 cc/hr.	Fuel <u>none</u> Oxidizer <u>none</u>

POST SINUSOIDAL VIBRATION PERFORMANCE

Model Number 52X147
 Serial Number 112
 Date 8/11/67

Specimen Designation Letter C
 Tested By:
 On Time Cycles

Test	Proc. Par. No.	Conditions & Measurements	Limits	Test Results		
Drop-out Voltage	5.1.7.2	Inlet pressure at 166 psig Measure maximum voltage at which valve closes	>1.0volts	Volts	Amps	
				Pri	1.35	.081
				Sec	1.99	.064
				Both	.780	.050
External Leakage	5.1.8	Apply 360 psig helium pressure to the oxidizer inlet with both return ports blocked. Energize valve to allow helium to enter all oxidizer chambers. Block fuel inlet and measure external leakage. Open fuel inlet and measure external leakage. Apply 360 psig helium pressure to fuel inlet with both return ports blocked. Energize valve to allow helium to enter all fuel chambers. Block oxidizer inlet and measure external leakage. Open oxidizer inlet and measure external leakage.	<10 ⁻⁴ cc/sec.			


POST SINUSOIDAL VIBRATION PERFORMANCE

Model Number 52X147
 Serial Number 112
 Date 8/11/67

Specimen Designation Letter C
 Tested By: _____
 On Time _____ Cycles _____

Test	Proc. Par. No.	Conditions & Measurements	Limits	Test Results
	<u>MR 1144</u>			
Internal Leakage	5.1.9	Measure outlet port leakage with inlet pressures at 50 and 360 psig. Fuel Oxidizer		50 360 Psig Psig
				<u>none</u> <u>none</u> <u>none</u> <u>none</u>
		Cycle valve 100 times and repeat above tests. Fuel Oxidizer		<u>none</u> <u>none</u> <u>none</u> <u>none</u>
Reverse Seat Leak		Apply 20 psig to outlet ports Measure leakage at the inlet port	30 cc/ hr.	Fuel <u>none</u> Oxidizer <u>none</u>

Model 52X147C Body S/N 112 -
Axis C 8/12/67
Flapper button motion restrictors
flat spring
27.7 g rms input




POST AXIS C RANDOM VIBRATION PERFORMANCE

Model Number 52X147
 Serial Number 112
 Date 8/12/67

Specimen Designation Letter C
 Tested By: _____
 On Time _____ Cycles _____

Test	Proc. Par. No. MR 1144	Conditions & Measurements	Limits	Test Results
Internal Leakage	5.1.9	Measure outlet port leakage with inlet pressures of 50 and 360 psig. Fuel Oxidizer	50	360
			Psig	Psig
			none	none
			none	none
		Cycle valve 100 times and repeat above tests		
		Fuel	none	none
		Oxidizer	none	none
Reverse Seat Leak		Apply 20 psig to outlet ports Measure leakage at the inlet port.	30 cc/ hr.	Fuel none Oxidizer none

Model 52X147C Body S/N 112
Axis A 8/12/67
Flapper button motion restrictors
flat spring
27.7 g rms input



f
Figure 18

POST AXIS A RANDOM VIBRATION PERFORMANCE

Model Number 52X147
 Serial Number 112
 Date 8/12/67

Specimen Designation Letter C
 Tested By: _____
 On Time * _____ Cycles _____

Test	Proc. Par. No. MR 1144	Conditions & Measurements	Limits	Test Results	
Internal Leakage	5.1.9	Measure outlet port leakage with inlet pressures of 50 and 360 psig. Fuel Oxidizer		50 m Psig	360 Psig
				<u>none</u>	<u>none</u>
		Cycle valve 100 times and repeat above tests. Fuel Oxidizer		<u>none</u>	<u>none</u>
				<u>none</u>	<u>none</u>
Reverse Seat Leak		Apply 20 psig to outlet ports Measure leakage at the inlet port.	30 cc/ hr.	Fuel <u>none</u> Oxidizer <u>none</u>	

Model 52X147C Body S/N 112
Axis B 8/12/67
Flapper button motion restrictors
flat spring
27.7 g rms input




Figure 19

VIBRATION POST SINUSOIDAL & RANDOM PERFORMANCE

Model Number 52X147
 Serial Number 112
 Date 8/14/67

Specimen Designation Letter C
 Tested By: _____
 On Time _____ Cycles _____

Test	Proc. Par. No. MR 1144	Conditions & Measurements	Limits	Test Results																								
Electrical Resistance a. Coil Resistance	5.1.3.1	Measure and Record Ambient temperature Primary coil resistance Secondary coil resistance		— AB — ohms CD — ohms																								
Response Time	5.1.5	Measure opening and closing response from oscillograms. Inlet pressure at 310 psig for primary coil, at 360 psig for secondary coil.	primary open 9 msec close 5 msec																									
		Primary coil - 0.80 amperes Secondary coil - 0.44 amperes Primary and Secondary as above	secondary open open 50 msec close close 5 msec open	6.0 msec. 2.3 msec. 14.2 msec. 2.0 msec. 5.1 msec. 2.6 msec.																								
Flow Test	5.1.6	Measure flow and pressure drop with inlet of 310 psig.																										
		<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Press. Drop</th> <th>Flow - lb/sec. Fuel</th> <th>Oxidizer</th> </tr> </thead> <tbody> <tr><td>15</td><td>.1094</td><td>.1183</td></tr> <tr><td>20</td><td>.1258</td><td>.1393</td></tr> <tr><td>25</td><td>.1411</td><td>.1553</td></tr> <tr><td>30</td><td>.1549</td><td>.1706</td></tr> <tr><td>35</td><td>.1675</td><td>.1850</td></tr> <tr><td>40</td><td>.1792</td><td>.1980</td></tr> <tr><td></td><td>0.144</td><td>0.179</td></tr> </tbody> </table>	Press. Drop	Flow - lb/sec. Fuel	Oxidizer	15	.1094	.1183	20	.1258	.1393	25	.1411	.1553	30	.1549	.1706	35	.1675	.1850	40	.1792	.1980		0.144	0.179		
Press. Drop	Flow - lb/sec. Fuel	Oxidizer																										
15	.1094	.1183																										
20	.1258	.1393																										
25	.1411	.1553																										
30	.1549	.1706																										
35	.1675	.1850																										
40	.1792	.1980																										
	0.144	0.179																										
Functional Test Pull-in Voltage	5.1.7.1	Inlet pressure at 360 psig. Measure minimum voltage required to open valve 10 consecutive times at 0.25 cps.	<20 volts	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th></th> <th>Volts</th> <th>Amps</th> </tr> </thead> <tbody> <tr><td>Pri</td><td>6.33</td><td>.380</td></tr> <tr><td>Sec</td><td>9.66</td><td>.301</td></tr> <tr><td>Both</td><td>3.61</td><td>.232</td></tr> </tbody> </table>		Volts	Amps	Pri	6.33	.380	Sec	9.66	.301	Both	3.61	.232												
	Volts	Amps																										
Pri	6.33	.380																										
Sec	9.66	.301																										
Both	3.61	.232																										

VIBRATION POST SINUSOIDAL & RANDOM PERFORMANCE

Model Number 52X147
 Serial Number 112
 Date 8/14/67

Specimen Designation Letter C
 Tested By: _____
 On Time _____ Cycles _____

Test	Prot. Pac. No.	Conditions & Measurements	Limits	Test Results		
Drop-out Voltage	5. 1. 7. 2	Inlet pressure at 166 psig Measure maximum voltage at which valve closes	>1.0 volts	Volts	Amps	
				Pri	1.52	.087
				Sec	2.18	.069
				Both	.801	.051
External Leakage	5. 1. 8	Apply 360 psig helium pressure to the oxidizer inlet with both return ports blocked. Energize valve to allow helium to enter all oxidizer chambers. Block fuel inlet and measure external leakage. Open fuel inlet and measure external leakage Apply 360 psig helium pressure to fuel inlet with both return ports blocked. Energize valve to allow helium to enter all fuel chambers. Block oxidizer inlet and measure external leakage. Open oxidizer inlet and measure external leakage.	<10 ⁻⁴ cc/sec.			

VIBRATION POST SINUSOIDAL & RANDOM PERFORMANCE

Model Number 52X147
 Serial Number 112
 Date 8/14/67

Specimen Designation Letter C
 Tested By: _____
 On Time _____ Cycles _____

Test	Proc. Par. No. MR 1144	Conditions & Measurements	Limits *	Test Results
Internal Leakage	5.1.9	Measure outlet port leakage with inlet pressures of 50 and 360 psig. Fuel Oxidizer	50	360
			Psig	Psig
			none	none
			none	none
		Cycle valve 100 times and repeat above tests. Fuel Oxidizer		
			none	none
			none	none
Reverse Seat Leak		Apply 20 psig to outlet ports Measure leakage at the inlet port.	30 cc/ hr.	Fuel none Oxidizer none

ALL SALES ARE FINAL

NTIS strives to provide quality products, reliable service, and fast delivery. Please contact us for a replacement within 30 days if the item you receive is defective or if we have made an error in filling your order.

▲ **E-mail: customerservice@ntis.gov**
▲ **Phone: 1-888-584-8332 or (703)605-6050**

Reproduced by **NTIS**

National Technical Information Service
Springfield, VA 22161

This report was printed specifically for your order from nearly 3 million titles available in our collection.

For economy and efficiency, NTIS does not maintain stock of its vast collection of technical reports. Rather, most documents are custom reproduced for each order. Documents that are not in electronic format are reproduced from master archival copies and are the best possible reproductions available.

If you have questions concerning this document or any order you have placed with NTIS, please call our Customer Service Department at 1-888-584-8332 or (703) 605-6050.

About NTIS

NTIS collects scientific, technical, engineering, and related business information – then organizes, maintains, and disseminates that information in a variety of formats – including electronic download, online access, DVD, CD-ROM, magnetic tape, diskette, multimedia, microfiche and paper.

The NTIS collection of nearly 3 million titles includes reports describing research conducted or sponsored by federal agencies and their contractors; statistical and business information; U.S. military publications; multimedia training products; computer software and electronic databases developed by federal agencies; and technical reports prepared by research organizations worldwide.

For more information about NTIS, visit our Web site at <http://www.ntis.gov>.

NTIS

**Ensuring Permanent, Easy Access to
U.S. Government Information Assets**



U.S. DEPARTMENT OF COMMERCE
Technology Administration
National Technical Information Service
Springfield, VA 22161 (703) 605-6000



N6822981



BX

BIN: M6 04-16-07
INVOICE: 1640878
SHIPTO: 1*85776
PAYMENT: NONE