

N71-13523
CR-115797

T-71-09129

CASE FILE COPY

FINAL REPORT

WATT-HOUR METER

CONTRACT NO. NAS 5-11524



Prepared for

NATIONAL AERONAUTICS AND SPACE ADMINISTRATION
GODDARD SPACE FLIGHT CENTER
GREENBELT, MARYLAND

By

EMR-AEROSPACE SCIENCES
EMR DIVISION
WESTON INSTRUMENTS, INC.
COLLEGE PARK, MARYLAND

FINAL REPORT

WATT-HOUR METER

CONTRACT NO. NAS 5-11524

Prepared for

NATIONAL AERONAUTICS AND SPACE ADMINISTRATION
GODDARD SPACE FLIGHT CENTER
GREENBELT, MARYLAND

By

EMR-AEROSPACE SCIENCES
EMR DIVISION
WESTON INSTRUMENTS, INC.
COLLEGE PARK, MARYLAND

TABLE OF CONTENTS

CHARACTERISTICS	SECTION 1
OPERATING INSTRUCTIONS	SECTION 2
THEORY OF OPERATION	SECTION 3
ALIGNMENT PROCEDURES	SECTION 4
EQUIPMENT PHOTOGRAPHS	SECTION 5
PRINTED CIRCUIT CARDS	SECTION 6
SCHEMATICS	SECTION 7
WIRE LISTS	SECTION 8
PARTS LISTS	SECTION 9
TIMING TEST SHEETS	SECTION 10

SECTION 1

CHARACTERISTICS

SECTION 1

- 1.1 INTRODUCTION
- 1.2 SPECIFICATIONS

SECTION 1

CHARACTERISTICS

1.1 INTRODUCTION

The Watt-Hour Meter is a versatile and accurate instrument for measuring watt-hours and ampere-hours over a wide range of voltages and currents. The voltage and current inputs can be widely separated in voltage potential from each other and from earth ground with no degradation in measuring performance. In addition, accuracy is maintained over the frequency range from DC to 100 Hz.

The Watt-Hour Meter uses voltage-to-frequency conversion techniques in order to obtain a pulse rate which is proportional to the watt-hour and ampere-hour inputs. Four solid state counters in the instrument accumulate and store the positive and negative watt-hours and positive and negative ampere-hours. Each can be selected for display on a six-digit Nixie readout. The output of each counter is commutated into a single six-phase BCD output for printout. Relay contact closure outputs are also provided for each of the four outputs permitting the use of external counters. The voltage and current inputs are indicated on front panel meters.

1.2 SPECIFICATIONS

Watt-Hour Meter:

Voltage Ranges:	3, 30, 300 volts full scale. 3, 10, 30, 100, 300 volts full scale on front panel meter.
Current Ranges (External shunt):	100 millivolts shunt full scale. 5a, 50 millivolts with 100% over-ranging. 50a, 50 millivolts shunt with 100% over-ranging.
Readout, Storage, and Print Capacity:	9999.99 watt-hours positive and 9999.99 watt-hours negative (Six complete digits on Nixie readout).
Current Shunt Isolation:	The current shunt input is isolated so that the shunt can be placed at any potential from 5 volts above the positive voltage input to 5 volts below the negative voltage input.
Accuracy:	$\pm 1\%$

Ampere-Hour Meter:

Current Ranges (External shunt):	100 millivolts shunt full scale. 5a, 50 millivolts with 100% over-ranging. 50a, 50 millivolts shunt with 100% over-ranging.
Readout and Storage Capacity:	999.999 ampere-hours positive and 999.999 ampere-hours negative (Six complete digits on Nixie readout).
Accuracy:	$\pm 1\%$

Overall Instrument:

Overload Protection:	Ten times maximum rated inputs will not damage instrument.
Print-Out and Reset Capability:	
Logic and Level to Printer:	1248 Positive Logic, Logic "1" equals 15 volts, Logic "0" equals 0.2 volts.
Print Command:	Front panel or by remote contact closure. All four stored readings are then printed in sequence (on external printer). Bypass pro- visions are included on front panel which will inhibit printout of any of the four stored readings.
Print Command:	15 volt positive pulse.
Earth Ground Isolation:	All inputs are electrically isolated from earth ground.
Input Impedance:	10 Megohm common mode and 20 Megohm differential on voltage inputs. 1000 ohm on current input.
Frequency:	DC to 100 Hz.
Operating Temperature:	$+10^{\circ}\text{C}$ to $+35^{\circ}\text{C}$

SECTION 2

OPERATING INSTRUCTIONS

- 2.1 GENERAL
- 2.2 CONTROLS AND CONNECTORS
- 2.3 OPERATOR ADJUSTMENT

SECTION 2



SECTION 2

OPERATING INSTRUCTIONS

2.1 GENERAL

The following instructions explain the use of all front panel controls and all connectors on the instrument. Complete detail for the connectors is contained in Section 6 - Wire List.

2.2 CONTROLS AND CONNECTORS

RANGE SWITCHES - Set the VOLTAGE RANGE and CURRENT RANGE switches to the desired full-range scales.

VOLTAGE INPUT - Connect to either J4 on the rear of the instrument or to J2 on the front panel. Pin A of J4 is positive and pin B is negative input.

CURRENT INPUT - Connect leads from the 50 millivolt shunt to J3 on the rear or J1 on the front panel.

MONITORING COUNT - Rotate the SELECTOR SWITCH to monitor any of the four counters.

PRINTER OUTPUT - A printer may be driven from J5 on the rear. Six digits are provided, plus a code digit. The logic is 1248 BCD, Positive "1". The code digit reads as follows:

3 = Negative ampere-hours

2 = Positive ampere-hours

1 = Negative watt-hours

0 = Positive watt-hours

The four readings are printed out in sequence. However, any of the above readings can be bypassed with the SKIP toggle switches on the front panel.

PRINT COMMAND - The printout sequence of readings to the printer can be initiated by: (1) pushing the PRINT button on the front panel and (2) applying a REMOTE PRINT signal (contact closure between pins E and F of connector J6).

RESET - The four counters can be reset by: (1) pushing the RESET button on the front panel which resets only the counter selected on the SELECTOR SWITCH, (2) the REMOTE RESET signal (contact closure between pins G and H of connector J6) will reset all four counters.

PRINT & RESET - The external contact closure between pins C and D of connector J6 initiates the print sequence to the printer, after which all four counters are reset.

EXTERNAL COUNTERS - A 60 millisecond contact closure is provided for external counters for each of the four channels. The external counter must be capable of receiving three counts per second. The Watt-Hour Counter output pulse rate is always a 0.833 counts per second full scale or 3,000 counts per hour full scale regardless of the scale used. This feature takes advantage of the maximum count rate of the external counter. The Ampere-Hour Counter produces 2.7 counts per second or 10,000 counts per hour on both scales. These contact closure outputs are negative ampere-hours between pins C and D of J7, positive ampere-hours between pins C and D of J8, negative watt-hours between pins C and D of J9, and positive watt-hours between pins C and D of connector J10.

2.3 OPERATOR ADJUSTMENT

If counts are registering in either the (+) Watt Hour counter or (-) Watt Hour counter when no signal is applied, perform the following:

- a. Place short across J1 and J2 on the front panel.
- b. Place ampere range switch to 100 amps and voltage range switch to 300 volts.
- c. Connect one trace of a dual trace oscilloscope between gray test point board 11 and the floating ground test point. Connect other trace of oscilloscope between blue test board 11 and floating ground test point.
- d. Sync scope from the gray test point.

- e. Adjust drift adjust pot on front panel for no relative motion between the two traces on the oscilloscope.
- f. Disconnect test equipment. Return WHM to normal operation.

SECTION 3

THEORY OF OPERATION

- 3.1 INTRODUCTION
- 3.2 CURRENT BUFFER
- 3.3 VOLTAGE BUFFER
- 3.4 CURRENT INTEGRATOR
- 3.5 MULTIPLIER AND PULSE SUBTRACTOR
- 3.6 WATT-HOUR COUNTERS AND
AMPERE-HOUR COUNTERS
- 3.7 DRIVER CARD
- 3.8 CONTROL CIRCUIT

SECTION 3

SECTION 3

THEORY OF OPERATION

3.1 INTRODUCTION

The Watt-Hour Meter is basically a voltage-to-frequency conversion device, with a multiplier to provide watt-hours. A Nixie readout provides a convenient display and a control circuit adds the capability of completely remote operation. Referring to the Block Diagram shown in Figure 3-1 and the respective electrical schematics will supplement the following discussions.

3.2 CURRENT BUFFER

The Current Buffer shown on drawing 01-22-503 utilizes a chopper-stabilized operational amplifier to provide a voltage gain of 100. High accuracy is obtained since the chopper-stabilized amplifier exhibits extremely low drift and offset. Full scale input voltage of 100 millivolts produces an output voltage of 10 volts.

3.3 VOLTAGE BUFFER

The Voltage Buffer shown in drawing 01-22-703 features 10 Megohm input impedance, voltage ranging, 300 percent common mode voltage immunity, and overload protection. These characteristics are obtained by employing a good quality FET operational amplifier in the difference circuit arrangement. Full scale operating voltages are 3 volts output and 3, 30, and 300 volts input. The voltage range switch on the front panel selects the proper feedback resistors.

3.4 CURRENT INTEGRATOR

The Current Integrator shown in drawing 01-22-403 is a continuous integrating device with negligible reset time. The output of the Current Buffer is applied to pin 28 of the Current Integrator card. This voltage is applied directly to the input summing point of integrating amplifier A2 through resistors R1 and R3. The input from the Current Buffer is inverted by operational amplifier A1 and is also applied through resistors R10 and R11 to the input summing point of integrating amplifier A2 when field effect transistor Q1 is "ON". The integrating amplifier is followed by a +10 volt and -10volt threshold detector. The output of each threshold detector is passed through a one-shot circuit. The one-shot outputs are combined and toggle flip-flop (IC9). The flip-flop output controls the state of input field effect transistor Q1 which in turn controls the input polarity of the signal applied to integrating amplifier A2. The integrating sequence




FIG. 3-1 WATT HOUR METER
BLOCK DIAGRAM

therefore occurs as follows: Assuming a positive voltage applied to pin 28 and a Q1 "off" initial condition, the input voltage through R1 and R3 will cause the integrating amplifier to produce a negative linear ramp output. When the output of integrating amplifier A2 reaches -10 volts, a pulse will be produced by the -10 volt detector (Amplifier A4) which will toggle flip-flop IC9. The Q output of the IC9 flip-flop will turn "on" the Q1 field effect transistor switch. Since the current through the R10 and R11 resistors is of opposite polarity and is precisely twice the current through resistors R1 and R3, the output of the integrating amplifier will reverse in direction producing a positive linear ramp. The output of the integrating amplifier proceeds positively until +10 volts is reached and the +10 volt threshold detector generates a pulse which toggles flip-flop IC9. The "Q" output of the flip-flop turns "off" Q1 and the above sequence of events repeat. The integrating amplifier's positive and negative time constant is equal providing a continuous integration of the applied current input to the unit. With a negative input, the integrator operates the same as the above description except the Q1 "off" state results in a positive linear ramp being produced by the integrating amplifier. When this output voltage reaches +10 volts, the +10 volt threshold detector will produce a toggle pulse for the IC9 flip-flop. The threshold detector's output and state of the IC9 flip-flop therefore determines if a positive or negative ampere-hour count should be produced.

The count output circuitry, consisting of two flip-flops (IC6) and the six associated gates, serves to eliminate counting errors due to jitter by requiring a "set" count on either output flip-flop before a count is allowed to reach that output terminal.

The unijunction transistor Q5, along with Q4 and Q6, produce a pulse to unlatch the circuit in the event that the pulse from the flip-flop (IC9) does not switch Q1 and, as a result, the output of the integrating amplifier (A2) saturates above 10 volts. Such a latch-up condition must be corrected since it would completely disable the integrator.

The full scale input to the current integrator is 10 volts positive or negative. The full-scale output is 27 counts per second and the polarity of the input determines which output produces the pulses.

3.5 MULTIPLIER AND PULSE SUBTRACTOR

The Multiplier shown on drawing 01-22-603 takes voltages which represent input voltage (E) and input current (I) and produces an output pulse count which is proportional to the product of E and I. The circuit utilizes the relationship $EI = (1/4) [(E+I)^2 - (E-I)^2]$. Summing amplifier A1 produces (E+I) and difference amplifier A5 produces (E-I). Amplifiers A2 and A6, in conjunction with their 10 volt threshold detectors, produce a

2KHz triangular waveform oscillation when input E and I are zero. A positive or negative input voltage to amplifiers A2 and A6 reduce the voltage; thus, $(E + I)^2$ are generated. The pulse subtractor and a scaling of 1/4 complete the EI formula. Thus, E times I has been generated using circuits which can only add, subtract, and square.

A reversing, constant current source is important to the operation of the squaring circuit. It is generated as follows: the switching circuit Q1, Q2, and Q3 is switched by the latching circuit following the ± 10 volt detectors at which time it reverses the polarity of the constant current "k" applied to the summing point of amplifier A2. The circuit of Q4, Q5, and Q6 performs the same function for amplifier A6.

The Pulse Subtractor uses 47 pf capacitors to generate a short pulse of only 20 n second. This greatly reduces the possibility of coincidence of the two pulse trains being subtracted. A "set-set-count" output circuit is used to eliminate false counts due to jitter in the 2KHz oscillators.

3.6 WATT-HOUR COUNTERS AND AMPERE-HOUR COUNTERS

The operation of these two types of counters is so similar that only one description of operation is necessary. The counters are shown on drawings 01-22-203 and 01-22-303.

Inhibit circuit - The Counter must remain fixed during the time a reading is being transferred to the printer. If a count is transmitted from the "current integrator" or from the "multiplier" during this transfer interval, it is stored in a RS flip-flop until transfer of the reading to the printer is complete. Then the count is transferred on to the Counter and is counted. Transformer T2 converts the pulse to "earth ground" potential and directs the pulse into the inhibit circuit.

Ranging - After passing through the inhibit circuit, the count pulse is applied to the decade counters. The first stage of the Ampere-Hour Counter or any of the first three stages of the Watt-Hour Counters may be bypassed depending on the setting of the range switches. This properly scales the output.

Read - A "read" command is required to switch "on" all BCD output control gates before they can be sent to the Nixies or to the printer.

Count output for remote counter - The count output pulse train from each of the four decade Counters is provided to drive an external counter. A one-shot and a reed relay provide a 60 millisecond contact closure for driving the external counter.

3.7 DRIVER CARD

The Six Driver Cards, shown on drawing 01-22-103, receive binary-coded decimal readings from whichever counter is commanded to "read". The Nixie driver (SN7441N) drives the Nixie tube and the transistor drivers apply the 1248 BCD input to the printer.

3.8 CONTROL CIRCUIT

The Control Circuit, shown on drawing 01-22-503, receives commands from the front panel and from remote inputs. In turn, it generates and coordinates the commands which control the operation of the Watt-Hour Meter and the external printer.

When the PRINT button is pushed or a Remote Print Command signal is received, the Print RS Flip-Flop is switched to its "set" state. The "set" output pulse resets the Count to Four Counter (SN7473N) sending a "read" command to the Minus Ampere-Hour Counter Card. The "set" pulse also turns on the Astable Oscillator (Q4) which sends out a "print command" pulse and the first reading is printed. The Astable Oscillator pauses and then, simultaneously, steps the "Count to Four Counter" and sends out a "print command" pulse about every one-half second until the "Count to Four Counter" reaches zero (sequence is 0, 1, 2, 3, 0) at which time the "Count to Four Counter" resets the Print RS Flip-Flop.

If any of the SKIP toggle switches are on, the Count to Four Counter ripples ahead until it reaches a number where that toggle switch is not switched on.

When the RESET button is pushed, a DC reset signal is transmitted to the Counter selected by the SELECTOR switch.

When the Remote Reset signal is received, all four Counters are directly reset to zero.

When a Remote Print and Reset command is received, the print cycle is the same as when the PRINT button is pushed. In addition, the RESET flip-flop is set which causes all four counters to be reset after the print cycle is complete.

Transistor Q3 is part of a one-shot which produces a reset pulse width of 100 milliseconds. This pulse width is required to prevent the counter boards from transmitting a false count to the external counters at the time any of the four Counters are reset.

Transistors Q1 and Q2 establish the Print Flip-Flop and the Reset Flip-Flop in their reset mode when power is applied to the circuit. Otherwise, unwanted print command and reset pulses would be sent out by the Control Circuit.

SECTION 4

ALIGNMENT PROCEDURES

- 4.1 EQUIPMENT REQUIRED
- 4.2 CURRENT BUFFER
- 4.3 VOLTAGE BUFFER
- 4.4 CURRENT INTEGRATOR
- 4.5 MULTIPLIER

SECTION 4



SECTION 4.

ALIGNMENT PROCEDURES

4.1 EQUIPMENT REQUIRED

This section describes the alignment procedure for the Watt-Hour Meter. The following equipment is required to perform this alignment.

- a. Digital Voltmeter having at least 4 place readout and 0.01% accuracy.
- b. Frequency counter with 10 second period counting capability.
- c. Oscilloscope - dual trace.
- d. Precision voltage supply with 0.01% accuracy - voltage range from 1.0 millivolts to 0.1 volts.
- e. Precision voltage supply with 0.01% accuracy - voltage range from 0.3 volts to 300.0 volts.
- f. Stopwatch.
- g. Audio sine wave generator.
- h. RMS meter.
- i. Two resistance decade boxes.

4.2 CURRENT BUFFER

- a. Place a jumper across J1 on the front panel. Connect DVM between Red test point and black test point on Board 13 and adjust potentiometer R3 until DVM reads $0.000 \pm .002$ volts.
- b. Connect precision voltage supply to J1 and adjust supply to $+100.0 \pm .1$ millivolts. Adjust R4 so that the DVM reads -10.00 volts $\pm .01$ volts.

4.3 VOLTAGE BUFFER

- a. Place a jumper across J2 on the front panel. Connect DVM between Red test point and Black test point on board

l4 and adjust potentiometer R10 until DVM reads $0.000 \pm .002$ volts with the voltage range switch in the 3V position.

- b. Remove the jumper and apply $+3.000 \pm .001$ volts to J2. The DVM should read $-3.000 \pm .003$ volts. Change voltage range switch to 30 volt position and apply $+30.000 \pm .001$ volts to J2. The DVM should read $-3.000 \pm .003$ volts. Change the voltage range switch to 300 volt position and apply $+300.00 \pm .03$ volts to J2. The DVM should read $-1.000 \pm .003$ volts. If the preceding readings are not within tolerance, the following procedure 5.3 (c) must be followed.
- c. If the full scale output measured in (b) is out of tolerance, connect a sine wave generator between (+) input of J2 and Black test point on board l4 (Reference drawing 01-22-703). Set frequency to 100 cps and RMS voltage to 2 volts. Attach RMS meter in parallel with DVM between Red test point and black test point board l4. Remove the two resistors which are in series with the out-of-tolerance switch position i. e., remove R39 and R36 if the full scale output in the 3V position was out of tolerance. Attach Decade Boxes in place of the resistors removed. Adjust resistor values so that the output is within 0.1 per cent of the correct value and the RMS meter value is minimum. The ratio of resistance between the two feedback legs directly effects the common-mode rejection of the amplifier; therefore, the legs must be balanced for minimum RMS signal at the amplifier output. Replace the TBD resistors with resistors having the value determined by the decade resistor boxes.

4.4 CURRENT INTEGRATOR

The Current Buffer must be adjusted before these adjustments can be made.

Drift Adjustments

- a. Apply about 1.0 mv to J1 on front panel. Connect a DVM and oscilloscope between the red test point on board l2 and the floating ground test point. If the voltage at this point is going in the negative direction as observed on the oscilloscope, place a jumper across J1 and adjust trimpot R13 so that the voltage reading on the DVM does not change. If the voltage is going in the positive direction, wait until it reaches +10 volts at which time it will change direction and the above procedure can be performed.

- b. Again apply +1.0 mv to J1 on front panel and observe the oscilloscope. If the voltage at the red test point board 12 is going in the positive direction, place a jumper across J1 and adjust trimpot R5 so that the voltage reading on the DVM does not change.

NOTE: There is some interaction between R5 and R13 so go through steps (a) and (b) above several times or until there is no drift in either state of the current integrator.

± 10 Volt Threshold Detector Adjustments

- c. Place a 100 K Ω resistor between the red test point and green test point on board 12. Connect a DVM between the red test point board 12 and the black test point board 13. Connect an oscilloscope between the blue test point board 12 and the floating ground test point. Increase the voltage applied to J1 on the front panel to about +100 mv (until the DVM reads +10.00 volts). (NOTE: If DVM reads near -10 volts instead of +10 volts increase the voltage applied to J1 momentarily to clock IC9 and invert the input voltage to A2). Adjust R15 until the oscilloscope indicates that A3 is on the threshold of switching (between 4 volts and zero volts). Decrease the voltage applied to J1 and then increase it again to check that A3 does switch when the DVM reaches +10.00 volts.
- d. Repeat step (c) with a negative voltage applied to J1 and -10.00 volts on the DVM. Adjust trimpot R18 so that the -10 v detector A4 switches (indicated by the oscilloscope at the gray test point) at -10.00 volts on the DVM.
- e. Remove the 100 K Ω resistor connected between red and green test point.

Frequency Adjustment

- f. Apply +100 mv ± 0.1 mv to J1 on the front panel. Connect counter with 10 meg input impedance or higher between orange test point board 12 and the floating ground test point. If counter does not have high enough input impedance connect oscilloscope to orange test point and drive counter from trigger or gate output of scope. Adjust R1 to give a 10 or 100 period average of 36.00 \pm .005 m sec. (This corresponds to an output pulse rate of 27.77 counts per second.)

MULTIPLIER


- a. Place jumpers across the J1 and J2 input connectors located on the front panel.
- b. Set Drift Adjust pot. on front panel to approximately mid position.
- c. Connect counter and oscilloscope between the blue test point on board 11 and the floating ground test point. Adjust R12 to obtain a frequency output of 2000 ± 1 Hz. Adjust R14 until the signal observed on the oscilloscope is an exactly symmetrical square wave. Readjust R12 until the frequency output is $2000 \pm .2$ Hz.
- d. Connect counter and oscilloscope between the gray test point on board 11 and the floating ground test point. Adjust R35 to obtain a frequency output of 2000 ± 1 Hz. Adjust R37 until the signal observed on the oscilloscope is an exactly symmetrical square wave. Readjust R35 until the frequency output is $2000 \pm .2$ Hz.
- e. Remove jumpers from across J1 and J2 and apply $+3.000 \pm .001$ volts to J2 and $+100.0 \pm .1$ millivolts to J1. Set the voltage range switch to 3 volts. Adjust the frequency at the blue test point to 1,167 Hz using potentiometer R7 on board P11. Reverse polarity of signals to J1 and J2 and observe frequency at the blue test point. If the frequency is not $1,167 \pm 1$ Hz, R15 should be adjusted until the frequency with both polarities are equal. During this procedure, R7 may require readjustment to retain the 1,167 Hz frequency.
- f. The same procedure as (e) is used to adjust the frequency at the gray test point with the exception that the voltage must be of opposite polarity as the current input. R33 is used to set the 1,167 Hz frequency and R38 is used to set the balance.

SECTION 5


EQUIPMENT PHOTOGRAPHS

SECTION 5







RIGHT OBLIQUE




FRONT VIEW



TOP VIEW



BOTTOM VIEW




REAR VIEW


SECTION 6

PRINTED CIRCUIT CARDS

SECTION 6




DRIVER CARD ASSEMBLY
(REF) DWG. NO. 01-22-100




NOTE: Jumper wires between Pins 7 and 10 on IC's 7, 8, 9, 10, 11, 12, 13, 14, and 15 not shown, located on far side of board.

WATT HOUR COUNTER ASSEMBLY
(REF) DWG. NO. 01-22-200



AMPERE HOUR COUNTER ASSEMBLY
(REF) DWG. NO. 01-22-300




NOTE: Jumper wires located on Sheet 2


CURRENT TIME INTEGRATOR ASSEMBLY
(REF) DWG. NO. 01-22-400
(SHEET 1 of 2)

NOTE: The following Jumper Wires were not shown.


1. Jumper Wire, From: Connector Pin 6
To: Orange Test Point
2. Jumper Wire, From: C13
To: R19
3. Jumper Wire, From: C14
To: R15
4. Jumper Wire, From: A1 Pin D
To: Connector Pin 9
5. Jumper Wire, From: Connector Pin 7
To: Junction of C9 and C10
6. Jumper Wire, From: Connector Pin 7
To: A2 Pin D
7. Jumper Wire, From: Connector Pin 8
To: A2 Pin B
8. Jumper Wire, From: Connector Pin 8
To: A1 Pin B



CONTROL CIRCUIT - CURRENT BUFFER ASSEMBLY
(REF) DWG. NO. 01-22-500




JUMPER WIRES LOCATED ON SHEET 2



MULTIPLIER AND PULSE SUBTRACTOR ASSEMBLY
(REF) DWG. NO. 01-22-600
(SHEET 1 of 2)

NOTE: The following Jumper Wires were not shown.

1. Jumper Wire, From: A1 Pin 3
To: Connector Pin 10
2. Jumper Wire, From: R28
To: Connector Pin 9
3. Jumper Wire, From: A2 Pin B
To: Connector Pin 8
4. Jumper Wire, From: A6 Pin B
To: Connector Pin 8
5. Jumper Wire, From: Connector Pin 32
To: R13
6. Jumper Wire, From: Connector Pin 33
To: R14
7. Jumper Wire, From: Connector Pin 34
To: R46
8. Jumper Wire, From: Connector Pin 35
To: R12
9. Jumper Wire, From: Connector Pin 36
To: R36
10. Jumper Wire, From: Connector Pin 37
To: R37
11. Jumper Wire, From: Connector Pin 38
To: R47
12. Jumper Wire, From: Connector Pin 39
To: R35




VOLTAGE BUFFER - POWER SUPPLY ASSEMBLY
(REF) DWG. NO. 01-22-700

SECTION 7
SCHEMATICS

SECTION 7






01-22-103

REQD	PART NO.	ITEM	DESCRIPTION	SYM
LIST OF MATERIALS				
UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ON FRACTIONS DECIMALS ANGLES				
DRAWN BY <i>Al Elliott</i>		DATE <i>7-22-68</i>		
CHECKED <i>W R Wolf</i>		DATE <i>4-7-70</i>		
ENGINEER <i>M. L. Lyons</i>		DATE <i>7-12-63</i>		
APPROVED <i>[Signature]</i>		DATE <i>11-17-70</i>		
TREATMENT OR FINISH				
EMR-AEROSPACE SCIENCES DIVISION ELECTRO-MECHANICAL RESEARCH, INC. COLLEGE PARK, MARYLAND				
WATT HOUR METER				
DRIVER CARDS PI THRU PG				
LOGIC DIAGRAM				
CODE IDENT NO.	SIZE	01-22-103		
06141	C			
SCALE ~		SHEET		

REVISIONS			
SYM	DESCRIPTION	DATE	APPROVED
A	REVISED	11-26-69	11/01




NOTE:
1. ALL GATES - SN7400N UNLESS OTHERWISE SPECIFIED

01-22-203

A

REQD	PART NO.	ITEM	DESCRIPTION	SYM
LIST OF MATERIALS				
UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ON FRACTIONS DECIMALS ANGLES			EMR-AEROSPACE SCIENCES DIVISION ELECTRO-MECHANICAL RESEARCH, INC. COLLEGE PARK, MARYLAND	
DRAWN BY 10/18/68 CHECKED 4/7/70 ENGINEER 11/12/69 APPROVED 11-12-22 APPROVED			WATT HOUR METER WATT HOUR COUNTER CARDS P7 & P8 LOGIC DIAGRAM	
TREATMENT OR FINISH			CODE IDENT NO. 06141	SIZE D
NEXT ASSY 6341-9038 USED ON			01-22-203 A	
			SCALE ~	SHEET


REVISIONS			
SYM	DESCRIPTION	DATE	APPROVED
A	REVISED & REDRAWN	11-25-67	ROA





01-22-303
A

REQD	PART NO.	ITEM	DESCRIPTION	SYM
LIST OF MATERIALS				
UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ON FRACTIONS DECIMALS ANGLES			DRAWN BY <i>Ed Elliott</i> CHECKED <i>W R W</i> ENGINEER <i>M L</i> APPROVED <i>W R W</i> APPROVED <i>W R W</i>	
MATERIAL			DATE 7-16-68 4-7-70 7-18-68 11-17-70	
TREATMENT OR FINISH			EMR-AEROSPACE SCIENCES DIVISION ELECTRO-MECHANICAL RESEARCH, INC. COLLEGE PARK, MARYLAND WATT HOUR METER AMPERE HOUR COUNTER P9 & P10 LOGIC DIAGRAM	
NEXT ASSY			CODE IDENT NO. 06141 SIZE D SCALE ~	SHEET 1 OF 1

REVISIONS			
SYM	DESCRIPTION	DATE	APPROVED
A	REVISED AND UPDATED DWG	11/24/69	M.O.A.




REQD	PART NO.	ITEM	DESCRIPTION	SYM
LIST OF MATERIALS				
UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ON FRACTIONS DECIMALS ANGLES				
MATERIAL		DRWN BY M. BEDROSIAN	DATE 8-15-68	EMR-AEROSPACE SCIENCES DIVISION ELECTRO-MECHANICAL RESEARCH, INC. COLLEGE PARK, MARYLAND WATT HOUR METER CURRENT INTEGRATOR CARD P12 SCHEMATIC DIAGRAM
		CHECKED W.R. WOLF	DATE 4-1-70	
		ENGINEER M. Bedrosian	DATE 9-18-68	
		APPROVED W. Wolf	DATE 11-10-70	
TREATMENT OR FINISH				CODE IDENT NO. 06141 SIZE D 01-22-403 A SCALE SHEET
NEXT ASSY		USED ON		



CONTROL CIRCUIT

REVISIONS			
ITEM	DESCRIPTION	DATE	APPROVAL
A	REVISED & REDRAWN	11-28-03	RON

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ON FINISHES DIMENSIONS ANGLES		DRAWN BY CHECKED ENGINEER APPROVED APPROVED	DATE 11-15-70 11-15-70 11-15-70 11-15-70	LIST OF MATERIALS Electro-Mechanical Research, Inc. COLLEGE PARK, MARYLAND SCHEMATIC DIAGRAM WATT HOUR METER CURRENT BUFFER & CONTROL CIR CARD P13	PART NUMBER OR PART ID 6341-9038	CODE IDENT NO 06141	SIZE E	QTY 1	UNIT 101
---	--	---	--	--	-------------------------------------	------------------------	-----------	----------	-------------



REVISIONS			
SYM	DESCRIPTION	DATE	APPROVED
A	REVISED AND REDRAWN.	11-25-69	W O A


NOTE: UNLESS OTHERWISE SPECIFIED;
1. ALL GATES ARE SN7400N.
2. FLOATING GRD. IS ELECTRICALLY ISOLATED FROM EARTH GND.

01-22-603
A


- ① +15V
- ② +5V
- ③ FLOATING GRD.
- ④ -15V
- ⑦ ±15V COMM
- ⑧ SIGNAL COMM
- ⑨ I COMM
- ⑩ E COMM
- ②⑥ -24V

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ON FRACTIONS DECIMALS ANGLES	DRAWN BY <i>Rotowski</i> CHECKED <i>W R W</i> ENGINEER <i>W R W</i> APPROVED <i>W R W</i> APPROVED	DATE 11-25-69 4-7-70 11-13-70 11-17-70	EMR-AEROSPACE SCIENCES DIVISION ELECTRO-MECHANICAL RESEARCH, INC. COLLEGE PARK, MARYLAND SCHEMATIC DIAGRAM WATT HOUR METER MULTIPLIER & PULSE SUBTRACTOR CARD P11
TREATMENT OR FINISH	CODE IDENT NO. 06141	SIZE D	01-22-603 A
NEXT ASSY 6341-9038	USED ON	SCALE	SHEET 1 OF 1

REVISIONS			
SYM	DESCRIPTION	DATE	APPROVED
A	REVISED	12-1-69	K.O.N.



POWER SUPPLY



VOLTAGE BUFFER


01-22-703

A

REQD	PART NO.	ITEM	DESCRIPTION	SYM
LIST OF MATERIALS				
UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ON FRACTIONS DECIMALS ANGLES			DRAWN BY E. LOGAN CHECKED W. R. WIFE ENGINEER APPROVED APPROVED	
MATERIAL			DATE 8-23-68 4-7-70 9-10-68 11-17-70	
TREATMENT OR FINISH			EMR-AEROSPACE SCIENCES DIVISION ELECTRO-MECHANICAL RESEARCH, INC. COLLEGE PARK, MARYLAND WATT HOUR METER VOLTAGE BUFFER & POWER SUPPLY CARD P14 SCHEMATIC	
NEXT ASSY			CODE IDENT NO. 06141 SIZE D SCALE ~	
USED ON			01-22-703 A SHEET	

SECTION 8
WIRE LISTS

SECTION 8



KEY TO WIRE LISTS

P	Plug
J	Jack
TB	Terminal Board
T	Transformer
N	Nixie Tube
S	Switch

WIRE LIST
WATT-HOUR METER

FROM			TO	FROM			TO
Card 1	Pin	1	P10-7	Card 1	Pin	48	N1-9
		2	P9-7			49	P2-49
		3	P8-6			50	P2-50
		4	P7-6			51	P2-51
		5	P10-8				
		6	P9-8				
		7	P8-9				
		8	P7-9				
		9	P10-10				
		10	P9-10				
		11	P8-10				
		12	P7-10				
		13	P10-11				
		14	P9-11				
		15	P8-11				
		16	P7-11				
		35	J5-36				
		36	J5-12				
		37	J5-11				
		38	J5-37				
		39	N1-3				
		40	N1-4				
		41	N1-7				
		42	N1-14				
		43	N1-2				
		44	N1-12				
		45	N1-10				
		46	N1-13				
		47	N1-5				

WIRE LIST
WATT-HOUR METER

FROM			TO	FROM			TO
Card 2	Pin	1	P10-13	Card 2	Pin	48	N2-9
		2	P9-13			49	P3-49 (P1-49)
		3	P8-13			50	P3-50 (P1-50)
		4	P7-13			51	P3-51 (P1-51)
		5	P10-14				
		6	P9-14				
		7	P8-14				
		8	P7-14				
		9	P10-16				
		10	P9-16				
		11	P8-16				
		12	P7-16				
		13	P10-17				
		14	P9-17				
		15	P8-17				
		16	P7-17				
		35	J5-34				
		36	J5-10				
		37	J5-9				
		38	J5-35				
		39	N2-3				
		40	N2-4				
		41	N2-7				
		42	N2-14				
		43	N2-2				
		44	N2-12				
		45	N2-10				
		46	N2-13				
		47	N2-5				

WIRE LIST
WATT-HOUR METER

FROM			TO	FROM			TO
Card 3	Pin	1	P10-19	Card 3	Pin	48	N3-9
		2	P9-19			49	P4-49 (P2-49)
		3	P8-19			50	P4-50 (P2-50)
		4	P7-19			51	P4-51 (P2-51)
		5	P10-20				
		6	P9-20				
		7	P8-20				
		8	P7-20				
		9	P10-23				
		10	P9-23				
		11	P8-23				
		12	P7-23				
		13	P10-24				
		14	P9-24				
		15	P8-24				
		16	P7-24				
		35	J5-32				
		36	J5-8				
		37	J5-7				
		38	J5-33				
		39	N3-3				
		40	N3-4				
		41	N3-7				
		42	N3-14				
		43	N3-2				
		44	N3-12				
		45	N3-10				
		46	N3-13				
		47	N3-5				

WIRE LIST
WATT-HOUR METER

FROM		TO	FROM		TO
Card 4	Pin 1	P10-26	Card 4	Pin 48	N4-9
	2	P9-26		49	P5-49 (P3-49)
	3	P8-27		50	P5-50 (P3-50)
	4	P7-27		51	P5-51 (P3-51)
	5	P10-27			
	6	P9-27			
	7	P8-28			
	8	P7-28			
	9	P10-30			
	10	P9-30			
	11	P8-30			
	12	P7-30			
	13	P10-31			
	14	P9-31			
	15	P8-31			
	16	P7-31			
	35	J5-30			
	36	J5-6			
	37	J5-5			
	38	J5-31			
	39	N4-3			
	40	N4-4			
	41	N4-7			
	42	N4-14			
	43	N4-2			
	44	N4-12			
	45	N4-10			
	46	N4-13			
	47	N4-5			

WIRE LIST
WATT-HOUR METER

FROM		TO	FROM		TO
Card 5	Pin 1	P10-33	Card 5	Pin 48	N5-9
	2	P9-33		49	P6-49 (P4-49)
	3	P8-34		50	P6-50 (P4-50)
	4	P7-34		51	P6-51 (P4-51)
	5	P10-34			
	6	P9-34			
	7	P8-35			
	8	P7-35			
	9	P10-36			
	10	P9-36			
	11	P8-38			
	12	P7-38			
	13	P10-37			
	14	P9-37			
	15	P8-39			
	16	P7-39			
	35	J5-28			
	36	J5-4			
	37	J5-3			
	38	J5-29			
	39	N5-3			
	40	N5-4			
	41	N5-7			
	42	N5-14			
	43	N5-2			
	44	N5-12			
	45	N5-10			
	46	N5-13			
	47	N5-5			

WIRE LIST
WATT-HOUR METER

FROM			TO	FROM			TO
Card 6	Pin	1	P10-40	Card 6	Pin	48	N6-9
		2	P9-40			49	P13-49 (P5-49)
		3	P8-41			50	P7-50 (P5-50)
		4	P7-41			51	P7-51 (P5-51)
		5	P10-41				
		6	P9-41				
		7	P8-42				
		8	P7-42				
		9	P10-43				
		10	P9-43				
		11	P8-44				
		12	P7-44				
		13	P10-44				
		14	P9-44				
		15	P8-45				
		16	P7-45				
		35	J5-26				
		36	J5-2				
		37	J5-1				
		38	J5-27				
		39	N6-3				
		40	N6-4				
		41	N6-7				
		42	N6-14				
		43	N6-2				
		44	N6-12				
		45	N6-10				
		46	N6-13				
		47	N6-5				

WIRE LIST
WATT-HOUR METER

FROM		TO	FROM		TO
Card 7	Pin 2	J10-C	Card 7	Pin 44	P6-12
	3	J10-D		45	P6-16
	4	P8-4		46	P8-46
	5	P8-5		47	P8-47
	6	P8-6		48	P11-51
	8	P1-4		49	P8-49
	9	P1-8		50	P6-50
	10	P1-12			P8-50
	11	P1-16		51	P6-51
	12	P13-43			P8-51
	13	P2-4			
	14	P2-8			
	16	P2-12			
	17	P2-16			
	19	P3-4			
	20	P3-8			
	22	P13-18			
	23	P3-12			
	24	P3-16			
	27	P4-4			
	28	P4-8			
	30	P4-12			
	31	P4-16			
	34	P5-4			
	35	P5-8			
	38	P5-12			
	39	P5-16			
	41	P6-4			
	42	P6-8			

WIRE LIST
WATT-HOUR METER

FROM			TO	FROM			TO
Card 8	Pin	2	J9-C	Card 8	Pin	41	P6-3
		3	J9-D			42	P6-7
		4	P7-4			44	P6-11
			P9-4			45	P6-15
		5	P7-5			46	P7-46
			P14-23				P14-27
		6	P7-6			47	P7-47
			P14-29				P14-25
		8	P1-3			48	P11-50
		9	P1-7			49	P7-49
		10	P1-11				P9-2
		11	P1-15			50	P7-50
		12	P13-42				P9-50
		13	P2-3			51	P7-51
		14	P2-7				P9-51
		16	P2-11				
		17	P2-15				
		19	P3-3				
		20	P3-7				
		22	P13-17				
		23	P3-11				
		24	P3-15				
		27	P4-3				
		28	P4-7				
		30	P4-11				
		31	P4-15				
		34	P5-3				
		35	P5-7				
		38	P5-11				
		39	P5-15				

WIRE LIST
WATT-HOUR METER

FROM		TO	FROM		TO
Card 9	Pin 1	P12-6	Card 9	Pin 43	P6-10
	2	P8-49		44	P6-14
		P10-2		45	S9-A-10A
	4	P8-4		46	S9-A-100A
		P10-4		47	J8-C
	7	P1-2		48	J8-D
	8	P1-6		50	P8-50
	10	P1-10			P10-50
	11	P1-14		51	P8-51
	12	P13-34			P10-51
	13	P2-2			
	14	P2-6			
	16	P2-10			
	17	P2-14			
	19	P3-2			
	20	P3-6			
	22	P13-10			
	23	P3-10			
	24	P3-14			
	26	P4-2			
	27	P4-6			
	30	P4-10			
	31	P4-14			
	33	P5-2			
	34	P5-6			
	36	P5-10			
	37	P5-14			
	40	P6-2			
	41	P6-6			

WIRE LIST
WATT-HOUR METER

FROM		TO	FROM		TO
Card 10	Pin 1	P12-5	Card 10	Pin 43	P6-9
	2	P9-2 P11-2		44	P6-13
	4	P9-4 P13-55		45	P9-45
	7	P1-1		46	P9-46
	8	P1-5		47	J7-C
	10	P1-9		48	J7-D
	11	P1-13		50	P9-50 P13-50
	12	P13-32		51	P9-51 P13-51
	13	P2-1			
	14	P2-5			
	16	P2-9			
	17	P2-13			
	19	P3-1			
	20	P3-5			
	22	P13-9			
	23	P3-9			
	24	P3-13			
	26	P4-1			
	27	P4-5			
	30	P4-9			
	31	P4-13			
	33	P5-1			
	34	P5-5			
	36	P5-9			
	37	P5-13			
	40	P6-1			
	41	P6-5			

WIRE LIST
WATT-HOUR METER

FROM	TO	FROM	TO
Card 11 Pin 1	TB1-3, #22 wire	Card 12 Pin 1	TB1-3, #22 wire
2	P12-2, #18 wire	2	P11-2, #18 wire P14-40, #18 wire
3	P12-3, #18 wire	3	P11-3, #18 wire P14-2, #18 wire
4	TB1-1, #22 wire	4	TB1-1, #22 wire
26	P12-26	5	P10-1
29	P14-21	6	P9-1
30	P13-59	26	P11-26 P14-33
50	P8-48	28	P13-59
51	P7-48	7	TB1-3, #20 wire
7	TB1-2, #20 wire	8	P13-3, #26 wire
8	TB1-7	9	P13-3, #20 wire
9	P13-3		
10	P14-3		
32	R13 gray		
33	R13 purple		
34	R12 blue		
35	R12 green		
36	R36 yellow		
37	R36 white		
38	R35 brown		
39	R35 orange		

WIRE LIST
WATT-HOUR METER

FROM		TO	FROM		TO
Card 13	Pin 1	TB1-3, #22 wire	Card 13	Pin 32	P10-12
	2	J1 & J3, twisted shielded pair		34	P9-12
	3	P12-8, #26 wire		36	S8
		P12-9, #22 wire		38	J6-G
		P13-21, #26 wire		40	S8
		TB1-2, #18 wire		42	P8-12
	4	TB1-1, #22 wire		43	P7-12
	5	J5-23		45	S8
	6	J5-15		46	J6-C
	7	S3		47	J6-E
	8	S8		49	P6-49
	9	P10-22			P14-48
	10	P9-22		50	P10-50
	11	S8			P14-42
	12	S4		51	P10-51
	13	S8			P14-50
	14	J5-16		52	J5-40
	15	S5		53	J5-41
	16	S8		55	P10-4
	17	P8-22		56	J5-22
	18	P7-22		59	11-30
	19	S8			
	20	S6			
	21	J1 & J3, twisted shielded pair			
	25	S5			
	26	S6			
	28	S4			
	29	S3			
	30	S8			

WIRE LIST
WATT-HOUR METER

FROM	TO	FROM	TO
Card 14 Pin 1	TB1-3, #22 wire	Card 14 Pin 44	(Q1 Collector, #18 wire) (CR3, CR4 cathodes)
2	P12-3, #18 wire		
	TB1-2, #18 wire	46	Q1 Bar1
	TB3-2, #18 wire	47	J5-25
3	P13-3	48	P13-49
4	TB1-1, #22 wire	49	T1-3
5	M2 (Neg)	50	P13-51, C1, R13
17	S1-D		Gnd Lug
19	S1-D	51	R12
21	P11-29	52	C1, R13
23	P8-5	54	N1-1
24	S1-E	55	N2
25	P8-47	56	N3-1
26	S1-D	57	N4-1
27	P8-46	58	N5-1
28	S1-E	59	N6-1
29	P8-6	6	S1-A Shielded
30	S1-E	7	S1-A Shielded
31	T1-12	8	J2 & J4 Twisted Shielded Pair
33	P12-26	10	S1-A Shielded
34	T1-11	12	S1-B Shielded
36	T1-9	14	J2 & J4 Twisted Shielded Pair
38	Q2 Collector, #18 wire, C11	16	S1-B Shielded
39	Q2 Base, #18 wire	18	S1-B Shielded
40	Q2 Emitter, #18 wire, C12, C13		
42	J5-24 (Q1 Emitter, #18 wire) P13-50		

WIRE LIST
WATT-HOUR METER

CONNECTOR	FROM		TO	FUNCTION
J1 (Current input, front)	Pin	+	P13-2	Twisted Shielded Pair
		-	P13-21	
J2 (Voltage input, front)		+	P14-8	Twisted Shielded Pair
		-	P14-14	
J3 (Current input, rear)		+	P13-2	Twisted Shielded Pair
		-	P13-21	
J4 (Voltage input, rear)		+	P14-8	Twisted Shielded Pair
		-	P14-14	
J5 (External printer)		1	P6-37	A Bit
		2	P6-36	B Bit
		3	P5-37	A Bit
		4	P5-36	B Bit
		5	P4-37	A Bit
		6	P4-36	B Bit
		7	P3-37	A Bit
		8	P3-36	B Bit
		9	P2-37	A Bit
		10	P2-36	B Bit
		11	P1-37	A Bit
		12	P1-36	B Bit
		15	P13-6	A Bit
		16	P13-14	B Bit
		22	P13-56	Pos. Inhibit
		23	P13-5	Pos. Print Command
		24	P14-42	Neg. Reference
		25	P14-47	Pos. Reference

WIRE LIST
WATT-HOUR METER

CONNECTOR	FROM		TO	FUNCTION
J5 (External printer)	Pin	26	P6-35	C Bit
		27	P6-38	D Bit
		28	P5-35	C Bit
		29	P5-38	D Bit
		30	P4-35	C Bit
		31	P4-38	D Bit
		32	P3-35	C Bit
		33	P3-38	D Bit
		34	P2-35	C Bit
		35	P2-38	D Bit
		36	P1-35	C Bit
		37	P1-38	D Bit
		40	P13-52	C Bit
		41	P13-53	D Bit
		50	Gnd Lug	Ground
J6 (Remote Control)	A		Rectifier Bridge +	+115VDC Output 115VDC Return
	B		Rectifier Bridge -	+115VDC Output 115VDC Return
	C		P13-46	Print and Reset
	D		J6-F	Signal Return
	E		P13-47	Print
	F		J6-D, H	Signal Return
	G		P13-38	Reset
	H		J6-F Gnd Lug	Signal Return

NOTE: Digit number is same as card number; e.g., card P6 drives digit 6. P13 drives identification code digit.

WIRE LIST
WATT-HOUR METER

CONNECTOR	FROM		TO	FUNCTION
J7 (Minus Ampere-Hour Count Output)	Pin	C	P10-47	Count output
		D	P10-48	Count output
		E	J8-E	115 VAC
		F	J8-F	115 VAC Return
J8 (Plus Ampere-Hour Count Output)		C	P9-47	Count output
		D	P9-48	Count output
		E	J7-E	115 VAC
			J9-E	
		F	J7-F	115 VAC Return
J9 (Minus Watt-Hour Count Output)			J9-F	
		C	P8-2	Count output
		D	P8-3	Count output
		E	J8-E	115 VAC
			J10-E	
J10 (Plus Watt-Hour Count Output)		F	J8-F	115 VAC Return
			J10-F	
		C	P7-2	Count output
		D	P7-3	Count output
		E	J9-E	115 VAC
			Front Panel AC	fused AC
		F	J9-F	115 VAC
			Front Panel AC	fused AC

WIRE LIST
WATT-HOUR METER

SWITCH	FROM		TO	FUNCTION
S9 (Current Range)	Pin	S9-A-10A	P9-45	
		S9-A-100A	P9-46	
		S9-B-10A	S1-D - Wiper	
		S9-B-100A	S1-E - Wiper	
<p>NOTE: All switches and other chassis components not included in the Wire List are shown on the schematic diagrams.</p>				

SECTION 9
PARTS LISTS

SECTION 9



PARTS LIST

P.C. Card No. 1 to 6 (6 Driver Cards)

ITEM	REQ'D	DESCRIPTION	SYMBOL
1	30	Contact, Lower Tier, #60-7001-04-13 Varicon (Elco)	
2	29	Contact, Upper Tier, #60-7001-05-13 Varicon (Elco)	
3	1	Capacitor, 22 μ f, 15v, K22C15K, (Kemet)	C1
4	4	Resistor, 1.5K, 5%, 1/4 W	R1 thru R4
5	4	Resistor, 22K, 5%, 1/4 W	R5 thru R8
6	1	Integrated Ckt, SN7400N (TI)	IC 1
7	2	Integrated Ckt, SN7440N (TI)	IC 2, IC 3
8	1	Integrated Ckt, SN7441N (TI)	IC 4
9	4	Transistor 2N2222	Q1 thru Q4

PARTS LIST

P.C. Card No. 7 & 8 (2 Watt-Hour Counter Cards)

Page 1

ITEM	REQ'D	DESCRIPTION	SYMBOL
1	30	Contact, Lower Tier, #60-7001-04-13 Varicon (Elco)	
2	29	Contact, Upper Tier, #60-7001-05-13 Varicon (Elco)	
3	12	Integrated Ckt, SN7400N (TI)	IC 1 to 6, 16, 18 to 22
4	1	Integrated Ckt, SN7440N (TI)	IC17
5	9	Integrated Ckt, SN7490N (TI)	IC 7 to 15
6	1	Transformer, H-48 (UTC)	T1
7	1	Relay, MRR-1A, 6V 288 Ω , 41F4227 (Struthersdunn)	K1
8	1	Transistor, 2N2222 (Mot.)	Q1
9	1	Diode, UT236 (Unitrode)	CR1
10	1	Capacitor, 22 μ f, 15V, K22C15K, (Kemet) Dipped Silver Mica	C1
11	1	Capacitor, .001 μ f, CD19FD102J03 (CDE) Dipped Silver Mica	C2
12	1	Capacitor, 100 pf, CD15FD101J03 (CDE) Ceramic High K Monolythic	C3
13	1	Capacitor, .47 μ f, 25V 5C023474X0250B3 (Sprague)	C4
14	4	Resistor, 4.7K, 1/4 W, 5%	R1 thru R4
15	1	Resistor, 2K, 1/4 W, 5%	R11
16	1	Resistor, 24K, 1/4 W, 5%	R9
17	2	Resistor, 510 Ω , 1/4 W, 5%	R8, R10
18	1	Resistor, 430 Ω , 1/4 W, 5%	R7
19	2	Resistor, 2.7K, 1/4 W, 5%	R6, R13
20	2	Resistor, 2.2K, 1/4 W, 5%	R5, R14
21	1	Resistor, 10K, 1/4 W, 5%	R12

PARTS LIST

P. C. Card No. 7 & 8 (2 Watt-Hour Counter Cards)

Page 2

ITEM	REQ'D	DESCRIPTION	SYMBOL
22	1	Capacitor, 47 μ f, 10V CS13BF476K (KEMET)	C5
23	1	Capacitor, .02 μ f, 500V	C6
24	1	Capacitor, 3300 pf 500V SD19FD332J03 (CDE) Dipped Silver Mica	C7
25	4	Capacitor, .01 μ f, 100V (erie)	C8 thru C11
26	1	Resistor, 150 μ f, 1/4W, 5%	R15
27	10	Jumper Wires, Insulated, AWG. #24	

PARTS LIST

P.C. Card No. 9 & 10 (2 Amp-Hour Counter Cards)

Page 1

ITEM	REQ'D	DESCRIPTION	SYMBOL
1	30	Contact, Lower Tier, #60-7001-04-13 Varicon (Elco)	
2	29	Contact, Upper Tier, #60-7001-05-13 Varicon (Elco)	
3	11	Integrated Ckt, SN7400N (TI)	IC 1 to IC 6, IC 14 to IC 18
4	7	Integrated Ckt, SN7490N (TI)	IC 7 to IC 13
5	1	Transformer, H-48 (UTC)	T1
6	1	Relay, MRR-1A, 6V, 288 Ω , 41F4227 (Struthersdunn)	K1
7	1	Transistor, 2N2222 (Mot.)	Q1
8	1	Diode, UT 236 (Unitrode)	CR1
9	1	Capacitor, 22 μ f, 15V, K22C15K (Kemet) Dipper Silver Mica	C1
10	1	Capacitor, .001 μ f, CD19FD102J03 (CDE) Dipped Silver Mica	C2
11	1	Capacitor, 100pf, CD15FD101J03 (CDE)	C4
12	1	Capacitor, .47 μ f, 25V, Ceramic High K Monolythic 5C023474X0250B3 (Sprague)	C3
13	2	Resistor, 4.7 K, 1/4 W, 5%	R1, R2
14	1	Resistor, 2K, 1/4 W, 5%	R9
15	1	Resistor, 24K, 1/4 W, 5%	R11
16	2	Resistor, 510 Ω , 1/4 W, 5%	R8, R10
17	1	Resistor, 430 Ω , 1/4 W, 5%	R7
18	2	Resistor, 2.7K, 1/4 W, 5%	R4, R5
19	2	Resistor, 2.2K, 1/4 W, 5%	R3, R6
20	1	Resistor, 10K, 1/4W, 5%	R12
21	1	Resistor, 150, 1/4W, 5%	R13

PARTS LIST

P.C. Card No. 9 & 10 (2 Amp-Hour Counter Cards)

Page 2

ITEM	REQ'D	DESCRIPTION	SYMBOL
22	1	Capacitor, 47 μ f, 35V, CS13BF476K (KEMET)	C5
23	3	Capacitor, .02 μ f, 500V	C6, C7, C8
24	1	Jumper Wire, Insulated, AWG. #24	

PARTS LIST

P.C. Card No. 11 (Multiplier & Pulse Subtractor)

Page 1

ITEM	REQ'D	DESCRIPTION	SYMBOL
1	30	Contact, Lower Tier, #60-7001-04-13 Varicon (Elco)	
2	29	Contact, Upper Tier, #60-7001-05-13 Varicon (Elco)	
3	3	Integrated Ckt, SN7400N (TI)	IC 1, IC 2, IC 3
4	2	Integrated Ckt, SN7440N (TI)	IC 4, IC 6
5	1	Integrated Ckt, SN7473N (TI)	IC 5
6	6	Operational Amplifier, LM201, Nat. Sem.)	A1, A3, A4, A5, A7, A8
7	2	Operational Amplifier, Model 149A (Analog Devices)	A2, A6
8	4	Transistor 2N3677 (Crystalonics)	Q2, Q3, Q5, Q6
9	2	Transistor, 2N2907 (Mot.)	Q1, Q4
10	4	Diode, 1N4446 (GE)	CR1, CR2, CR5, CR6
11	4	Diode, 1N704A (IR)	CR3, CR4, CR7, CR8
12	2	Capacitor, 30pf, DN10ED300J03 (Elmenco)	C1, C4
13	2	Capacitor, .01 μ f CYFM Glass (Corning Glassworks)	C2, C5
14	2	Capacitor, 22 μ f, 35V, K22C35K (Kemet)	C7, C8
15	1	Capacitor, 22 μ f, 15V, K22C15K (Kemet)	C10
16	1	Capacitor, .022 μ f, 25V 3C023223X0250A3, Ceramic High K Monolythic (Sprague)	C9
17	2	Capacitor, 47pf, CD15ED470J03 (CDE), Dipped Silver Mica	C3, C6

PARTS LIST

P.C. Card No. 11 (Multiplier & Pulse Subtractor)

Page 2

ITEM	REQ'D	DESCRIPTION	SYMBOL
18	6	Trim Potentionmeter, 1K, Helipot Helitrim, 77PR	R7, R15, R33 R38
19	2	Resistor, RN60D, Metal Film, 1/4, 1%, 10.0K, (Electra)	R2, R26
20	3	Resistor, RN60D, Metal Film, 1/4W, 1%, 5.11K, (Electra)	R5, R27, R28
21	2	Resistor, RN60D, Metal Film, 1/4W, 1%, 18.2K, (Electra)	R8, R34
22	2	Resistor, RN60D, Metal Film, 1/4W, 1%, 16.2K (Electra)	R13 R36
23	2	Resistor, RN60D, Metal Film, 1/4W, 1%, 8.06K, (Electra)	R46, R47
24	4	Resistor, RN60D, Metal Film, 1/4W, 1%, 20.0K, (Electra)	R17, R19, R39 R43
25	4	Resistor, RN60D, Metal Film, 1/4W, 1%, 30.1K, (Electra)	R16, R20, R39 R43
26	2	Resistor, RN60D, Metal Film, 1/4W, 1%, 3.0K, (Electra)	R4, R24
27	8	Resistor, TBD, 1/4W, 5%, Comp.	R1, R3, R23, R25
28	2	Resistor, 15K, 1/4W, 5%, Comp.	R9, R30
29	2	Resistor, 20K, 1/4W, 5%, Comp.	R10, R31
30	2	Resistor, 680 , 1/4W, 5%, Comp.	R11, R32
31	2	Resistor, 2.2K, 1/4W, 5%, Comp.	R22, R45
32	2	Resistor, 2.7K, 1/4W, 5%, Comp.	R21, R44
33	10	PC Mounting Test Points YEL(2), BRN(1), GRN(1), RED(1), BLU(1), WH(1), ORG(1), BLK(1)	
34	4	Resistor, Value to be determined	R12, R14, R35 R37

PARTS LIST

P.C. Card No. 11 (Multiplier & Pulse Subtractor)

Page 3

ITEM	REQ'D	DESCRIPTION	SYMBOL
35	4	Resistor, 510, 1/4W, 5%, Comp.	R48 thru R51
36	2	Resistor, 5.1meg, 1/4W, 5%, Comp.	R18, R41, R52, R53
37	*	Pot. 4 Section Ganged 2 Section 1K 2 Section 500	R54-A thru D
38	*	Resistor, 50 Ω , 1/4W, 1%	R55, R57
39	*	Resistor, 100 Ω , 1/4W, 1%	R56, R58
40	12	Jumper Wires, Insulated, AWG. #24	

* Mounted on Chassis

PARTS LIST

P. C. Card No. 12 (Current Time Integrator)

Page 1

ITEM	REQ'D	DESCRIPTION	SYMBOL
1	30	Contact Lower Tier, #60-7001-04-13 Varicon (Elco)	
2	29	Contact Upper Tier, #60-7001-05-13 Varicon (Elco)	
3	5	Integrated Ckt, SN7400N (TI)	IC 1, IC 2, IC 3, IC 5, IC 8
4	2	Integrated Ckt, SN7473N (TI)	IC 6, IC 9
5	1	Integrated Ckt, SN7451N (TI)	IC 4
6	1	Integrated Ckt, SN7440N (TI)	IC 7
7	2	Operational Amplifier, LM201, (Nat. Sem.)	A3, A4
8	1	Operational Amplifier, Model 142A, (Analog Devices)	A1
9	1	Operational Amplifier, Model 211 (Analog Devices)	A2
10	3	Transistor, 2N2222 (Mot.)	Q3, Q4, Q6
11	1	Transistor, 2N2907 (Mot.)	Q2
12	1	Transistor, 2N3972 Siliconix	Q1
13	1	Transistor, 2N4852 (Mot.)	Q5
14	1	Diode, 1N4446 (GE)	CR1
15	2	Diode, 1N704A (IR)	CR2, CR3,
16	1	Capacitor, 22pf, Dipped Silver Mica, CD15CD220J03 (CDE)	C1
17	1	Capacitor, .22 μ f, MFP, MYLAR, 1 P22, (CDE)	C2
18	2	Capacitor, 47 μ f, 20V, K47J02KS (Kemet)	C3, C4
19	2	Capacitor, 22 μ f, 35V, K22C35K, (Kemet)	C9, C10

PARTS LIST

P.C. Card No. 12 (Current Time Integrator)

Page 2

ITEM	REQ'D	DESCRIPTION	SYMBOL
20	1	Capacitor, 22 μ f, 15V, K22C15K, (Kemet)	C5
21	2	Capacitor, .022 μ f, 25V, Ceramic Monolythic, 3C023223KO250A3, (Sprague)	C6, C7
22	4	Trim Potentiometer, 1K, Helipot Helitrim, 77PR	R1, R5, R15, R18
23	1	Trim Potentiometer, 50K, Helipot Helitrim, 77PR	R13
24	3	Resistor, RN60D, Metal Film, 1/4 W, 1%, 75.0K (Electra)	R2, R3, R4
25	1	Resistor, RN60D, Metal Film, 1/4 W, 1%, 36.5K, (Electra)	R10
26	2	Resistor, RN60D, Metal Film, 1/4 W, 1%, 20.0K (Electra)	R16, R17
27	2	Resistor, RN60D, Metal Film, 1/4 W, 1%, 30.1K (Electra)	R14, R19
28	1	Resistor, TBD, 1/4 W, 5%, Comp.	R11
29	1	Resistor, 100K, 1/4 W, 5%, Comp.	R6
30	1	Resistor, 12K, 1/4 W, 5%, Comp.	R7
31	2	Resistor, 8.2K, 1/4 W, 5%, Comp.	R8, R12
32	1	Resistor, 2.4K, 1/4 W, 5%, Comp.	R9
33	2	Resistor, 470 Ω , 1/4 W, 5%, Comp.	R20, R21
34	1	Resistor, 5.1K, 1/4 W, 5%, Comp.	R22
35	1	Resistor, 620K, 1/4 W, 5%, Comp.	R23
36	2	Resistor, 100 Ω , 1/4 W, 5%, Comp.	R24, R25
37	2	Resistor, 47 Ω , 1/4 W, 5%, Comp.	R26, R27
38	1	Resistor, 2K, 1/4 W, 5%, Comp.	R28
39	6	PC Mounting Test Points, Yel(1), Grn(1), Red(1), Blu(1), Gry(1), Org(1)	

PARTS LIST

P.C. Card No. 12 (Current Time Integrator)

Page 3

ITEM	REQ'D	DESCRIPTION	SYMBOL
40	2	Capacitor, 100pf, 500V, CD15Fd101J03 (CDE) Dipped Silver Mica	C13, C14
41	2	Capacitor, 180pf, 500V, CD7CD181G03 (CDE) Dipped Silver Mica	C11, C12
42	1	Capacitor, 390 μ f, 10V	C8
43	8	Jumper Wires, Insulated, AWG. #24	

PARTS LIST

P.C. Card No. 13 (Control Circuit & Current Buffer)

Page 1

ITEM	REQ'D	DESCRIPTION	SYMBOL
1	30	Contact, Lower Tier, #60-7001-04-13 Varicon (Elco)	
2	29	Contact, Upper Tier, #60-7001-05-13 Varicon (Elco)	
3	4	Integrated Ckt, SN7400N (TI)	IC6, IC10, IC11, IC12
4	7	Integrated Ckt, SN7440N (TI)	IC 1, IC2, IC3, IC4, IC5, IC7 IC8
5	1	Integrated Ckt, SN7473N (TI)	IC9
6	1	Operational Amplifier, Model 211 (Analog Devices)	A1
7	8	Transistor, 2N2222 (Mot.)	Q1 thru Q8
8	3	Diode, 1N4446 (GE)	CR7, CR8, CR9
9	2	Diode, 1N3595 (Fairchild)	CR1, CR2
10	2	Capacitor, 22 μ f, 15V, K22C15K, (Kemet)	C1, C10
11	2	Capacitor, 200pf, Dipped Silver Mica, CD15FD201J03 (CDE)	C2, C5
12	2	Capacitor, 10 μ f, 20V, K10J20KS (Kemet)	C3, C7
13	1	Capacitor, 6.8 μ f, 35V, K6R8J35KS (Kemet)	C4
14	1	Capacitor, .01 μ f, 25V, Ceramic High K Monolythic, 3C023103X0250A3 (Sprague)	C6
15	2	Capacitor, 22 μ f, 35V, K22C35K (Kemet)	C8, C9
16	1	Trim Potentiometer, 5K, Helipot Helitrim, 77PR	R4
17	1	Trim Potentiometer, 50K, Helipot Helitrim, 77PR	R3

PARTS LIST

P.C. Card No. 13 (Control Circuit & Current Buffer)

Page 2

ITEM	REQ'D	DESCRIPTION	SYMBOL
18	1	Resistor, RN60D, Metal Film, 1/4 W, 1%, 1.00K (Electra)	R1
19	1	Resistor, RN60D, Metal Film, 1/4 W, 1%, 97.6K (Electra)	R2
20	1	Resistor, TBD, 1/4 W, 5%, Comp.	R5
21	1	Resistor, TBD, 1/4 W, 5%, Comp.	R48
22	8	Resistor, 4.7K, 1/4 W, 5%, Comp.	R14, R15, R16, R45 R49, R50, R51, R52
23	1	Resistor, 12K, 1/4 W, 5%, Comp.	R44
24	3	Resistor, 24K, 1/4 W, 5%, Comp.	R17, R18, R29
25	1	Resistor, 680 Ω , 1/4 W, 5%, Comp.	R19
26	3	Resistor, 22K, 1/4 W, 5%, Comp.	R20, R42, R43
27	3	Resistor, 1K, 1/4 W, 5%, Comp.	R21, R25, R26
28	4	Resistor, 1.5K, 1/4 W, 5%, Comp.	R22, R46, R47, R53
29	1	Resistor, 2.4K, 1/4 W, 5%, Comp.	R23
30	3	Resistor, 470 Ω , 1/4 W, 5%, Comp.	R24, R27, R30
31	1	Resistor, 10K, 1/4 W, 5%, Comp.	R28
32	2	Resistor, 820 Ω , 1/4 W, 5%, Comp.	R31, R32
33	2	PC Mounting Test Point, (one Red, one Black)	
34	1	Capacitor, 30pf. 500V, CD15ED300J03 (CDE), Dipped Silver Mica	C13
35	2	Capacitor, .1 μ f, 500V erie	C11, C12

PARTS LIST

P. C. Card No. 14 (Power Supply & Voltage Buffer)

Page 1

ITEM	REQ'D	DESCRIPTION	SYMBOL
1	30	Contact, Lower Tier, #60-7001-04-13 Varicon (Elco)	
2	29	Contact, Upper Tier, #60-7001-04-13 Varicon (Elco)	
		POWER SUPPLY	
3	1	Integrated Ckt, SN7400N (TI)	IC1
4	*	Transistor, 2N4395 (RCA)	Q1, Q2
5	4	Diode, UT236 (Unitrode)	CR2, CR5, CR6 CR7
6	1	Diode, 1N2614 (GE)	CR1
7	1	Diode, U25217 (Unitrode)	CR8
8	1	Diode, 1N4733A (Mot.)	CR11
9	1	Diode, W704A (IR)	CR9
10	1	Diode, 1N4734 (Mot.)	CR10
11	4	Capacitor, 150 μ f, 30V, WF 150-30C3M (Tansitor)	C2, C3, C8, C9
12	4	Capacitor, 500 μ f, 10V, 390507G010Ej4 (Sprague)	C4, C5, C6, C7
13	1	Resistor, 820 Ω , 1/2W, 5%Comp.	R1
14	1	Resistor, 100 Ω , 1/4W, 5%Comp.	R2
15	1	Resistor, 20 Ω , 1/4W, 5%Comp.	R3
16	1	Resistor, 150 Ω , 1/4W, 5%Comp.	R4
17	1	Resistor, 820 Ω , 1/4W, 5%Comp.	R5
18	6	Resistor, 10K Ω , 1/4W, 5%Comp.	R6 thru R11
19	1	Heat Sink, 6401, Thermalloy	
20	*	Diode, 1N1201	CR3, CR4
21	*	Resistor, 820 Ω , 1/2W, 5%Comp.	R12
22	*	Resistor, 62K, 2W, 5% Comp.	R13
23	1	Diode, 1N914	CR13

* Mounted on Chassis

PARTS LIST

P.C. Card No. 14 (Power Supply & Voltage Buffer)

Page 2

ITEM	REQ'D	DESCRIPTION	SYMBOL
24	1	Resistor, 3.6K, 1/4W, 5%, Comp.	R14
25	*	Capacitor, 5000 f, 10V	C10
26	*	Capacitor, 2000 f, 25V	C11, C12, C13
27	2	Jumper Wires, Insulated, AWG. #24	

* Mounted on Chassis

PARTS LIST

P.C. Card No. 14 (Power Supply & Voltage Buffer)

Page 3

ITEM	REQ'D	DESCRIPTION	SYMBOL
		VOLTAGE BUFFER	
1	1	Operational Amplifier, Model 143A (Analog Devices)	A2
2	4	Diode, 1N3595 (Fairchild)	CR3 to CR6
3	1	Trimpot, 2K, 77PR2K (Beckman)	R10
4	2	Resistor, 100K, RN60D, Metal Film, 1/4 W, 1%	R7, R11
5	2	Resistor, 1M, RN60D, Metal Film, 1/4 W, 1%	R8, R12
6	1	Resistor, 30.1K, RN60D, Metal Film, 1/4 W, 1%	R49
7	4	Resistor, 10M, RN60D, Metal Film, 1W, 1%	R5, R6, R9, R13
8	5	Resistor, TBD, Carbon Comp., 1/4 W, 5%	R33 to R39
9	1	Resistor, 2K, RN60D, Metal Film, 1/4 W, 1%	R40
10	1	Resistor, 6.04K, RN60D, Metal Film, 1/4 W, 1%	R41
11	2	PC Mounting Test Points RED (1), BLK (1)	
12	1	Capacitor, 30Pf, 500V, CD15ED300J03 (CDE), Dipped Silver Mica	C14

PARTS LIST

Chassis

Page 1

ITEM	REQ'D	DESCRIPTION	SYMBOL
1	1	Line Cord, 17236-SV (Belden)	
2	2	Line Filter Choke, 7825 (Miller)	FL1, FL2
3	1	Fuseholder, 342001 (Littlefuse)	F2
4	1	Switch, Fuse, Pilot Light, FCB-F (Rowen)	S10, F1, L1
5	1	Transformer, BX5420 (Balt. Transformer Co.)	T1
6	1	Power Supply, NPS-300 (Philbrick)	
7	1	Bridge Rectifier (Semtech)	CR12-(14)
8	1	Capacitor, 150 μ f, 250V, TVL1540 (Sprague)	C1-(14)
9	1	Switch, Rotary, PA2022 (Centralab)	S1
10	2	Switch, Push Button, 3391-GL, (Arrow-Hart)	S2, S7
11	4	Switch, Toggle, MST105D (Alcoswitch)	S3, S4, S5, S6
12	1	Switch, Rotary, PA2011 (Centralab)	S8
13	1	Switch, Rotary, PA2002 (Centralab)	S9
14	2	Meter, Type 1622, 0-1 DCMA (Simpson)	M1, M2
15	14	Binding Post, 224BB (H.H.Smith)	P1 to P14
16	3	Connector, 00-7015-059-218-001 (Elco)	J1 to J3
17	1	Connector, MS3102A10 SL-4P	J4
18	1	Connector, 57-40500 (Amphenol)	J5
19	1	Connector, MS3102A 20-27	J6
20	4	Connector, MS3102A-14S-6S	J7 to J10
21	1	Bezel Ass'y., SFB34-S4-6 w/SK182 Socket, 6 Wide	

PARTS LIST

Chassis

Page 2

ITEM	REQ'D	DESCRIPTION	SYMBOL
22	5	Nixie Tubes, B5440, (Burroughs)	N1,N2, N3, N5, N6
23	1	Nixie Tube, B5441 (Burroughs)	N4
24	3	Knob, DS70-3-2 (Raytheon)	
25	2	Transistor, 2N4395 (RCA)	Q1, Q2-(14)
26	2	Diode, 1N1201	CR3, CR4-(14)
27	1	Resistor, 820 Ω , 1/2W, 5%, Comp.	R12-(14)
28	1	Resistor, 62K, 2W, 5%, Comp.	R13-(14)
29	1	Capacitor, 5000 μ f, 10V	C10-(14)
30	3	Capacitor, 2000 μ f, 25V	C11, C12, C13-(14)
31	1	Pot. 4Section Ganged, 2 Section 1K, 2Section 500 Ω	R54-A, B, C, D (11)
32	2	Resistor, 50 Ω , 1/4W, 1%	R55, R57
33	2	Resistor, 100 Ω , 1/4W, 1%	R56, R58
34	1	Resistor, 100K, 1%, Metal Film, RN55C	

PARTS LIST

Chassis

Page 3

ITEM	REQ'D	DESCRIPTION	SYMBOL
		ACCESSORIES	
1	1	Receptacle, 59 Contact 00-7015-217-001, Varicon (ECCO)	
2	1	Contact Lower Tier, 30 Contacts 02-030-135-5200, Varicon (ECCO)	
3	1	Contact Upper Tier, 29 Contacts 02-029-137-5200, Varicon (ECCO)	

SECTION 10

TIMING TEST SHEETS

WATT HOUR METER TIMING TESTS

The following tests check the accuracy, drift, and operation of the Watt-Hour Meter. The technique used to obtain an accurate time interval for a measurement is to apply V_{IN} and then apply I_{IN} simultaneously with starting the clock or stopwatch. Then I_{IN} is disconnected precisely at the end of the measurement period and the readings on the counters are recorded. Since the counters operate only when I_{IN} is connected, the measurement period can be fairly controlled by this means. The resulting measurements are more accurate than those obtained by trying to read the Nixie Display while it is counting.

<u>V_{IN}</u> (volts)	<u>I_{IN}</u> (mv)	<u>Time</u> (min)	<u>Volts</u> Range	<u>Amps</u> Range	<u>Nominal</u> Amp-Hr	<u>Actual</u> Amp-Hrs	<u>%</u> Error	<u>Nominal</u> Watt-Hr	<u>Actual</u> Watt-Hr	<u>%</u> Error
+3.000	+100.0	6	3v	100A	+10.000			+30.00	30.16	.53%
+3.000	-100.0	3	3v	100A	- 5.000	-4.996	.12%	- 15.00	-15.03	.2%
-3.000	-100.0	3	3v	100A	- 5.000	-4.998	.1%	+ 15.00	14.95	.33%
+.3000	+ 10.0	6	3v	100A	+ 1.000	1.000	0	+ .30	.31	3.3%
+30.00	+1.000	6	30v	100A	+ .100	.100	0	+ 3.00		
- 10.00	+100.0	6	30v	10A	+ 1.000	1.002	.2%	- 10.00	10.08	.8%
Short	Short	6	300v	100A	± zero			± zero		

WATT HOUR METER TIMING TESTS

The following tests check the accuracy, drift, and operation of the Watt-Hour Meter. The technique used to obtain an accurate time interval for a measurement is to apply V_{IN} and then apply I_{IN} simultaneously with starting the clock or stopwatch. Then I_{IN} is disconnected precisely at the end of the measurement period and the readings on the counters are recorded. Since the counters operate only when I_{IN} is connected, the measurement period can be fairly controlled by this means. The resulting measurements are more accurate than those obtained by trying to read the Nixie Display while it is counting.

<u>V_{IN}</u> (volts)	<u>I_{IN}</u> (mv)	<u>Time</u> (min)	<u>Volts</u> Range	<u>Amps</u> Range	<u>Nominal</u> Amp-Hr	<u>Actual</u> Amp-Hrs	<u>%</u> Error	<u>Nominal</u> Watt-Hr	<u>Actual</u> Watt-Hr	<u>%</u> Error
+3.000	+100.0	6	3v	100A	+10.000			+30.00		
+3.000	-100.0	3	3v	100A	- 5.000			- 15.00		
-3.000	-100.0	3	3v	100A	- 5.000			+ 15.00		
+ .3000	+ 10.0	6	3v	100A	+ 1.000			+ .30		
+30.00	+1.000	6	30v	100A	+ .100			+ 3.00		
- 10.00	+100.0	6	30v	10A	+ 1.000			- 10.00		
Short	Short	6	300v	100A	± zero			± zero		

WATT HOUR METER TIMING TESTS

The following tests check the accuracy, drift, and operation of the Watt-Hour Meter. The technique used to obtain an accurate time interval for a measurement is to apply V_{IN} and then apply I_{IN} simultaneously with starting the clock or stopwatch. Then I_{IN} is disconnected precisely at the end of the measurement period and the readings on the counters are recorded. Since the counters operate only when I_{IN} is connected, the measurement period can be fairly controlled by this means. The resulting measurements are more accurate than those obtained by trying to read the Nixie Display while it is counting.

<u>V_{IN}</u> (volts)	<u>I_{IN}</u> (mv)	<u>Time</u> (min)	<u>Volts</u> Range	<u>Amps</u> Range	<u>Nominal</u> Amp-Hr	<u>Actual</u> Amp-Hrs	<u>%</u> Error	<u>Nominal</u> Watt-Hr	<u>Actual</u> Watt-Hr	<u>%</u> Error
+3.000	+100.0	6	3v	100A	+10.000	_____	_____	+ 30.00	_____	_____
+3.000	-100.0	3	3v	100A	- 5.000	_____	_____	- 15.00	_____	_____
-3.000	-100.0	3	3v	100A	- 5.000	_____	_____	+ 15.00	_____	_____
+.3000	+ 10.0	6	3v	100A	+ 1.000	_____	_____	+ .30	_____	_____
+30.00	+1.000	6	30v	100A	+ .100	_____	_____	+ 3.00	_____	_____
- 10.00	+100.0	6	30v	10A	+ 1.000	_____	_____	- 10.00	_____	_____
Short	Short	6	300v	100A	± zero	_____	_____	± zero	_____	_____