Monitoring Delamination of Thermal Barrier Coatings by Near-Infrared and Upconversion Luminescence Imaging

J.I. Eldridge, NASA Glenn Research Center, R.E. Martin, Cleveland State University, J. Singh, D.E. Wolfe, Penn State University.

Previous work has demonstrated that TBC delamination can be monitored by incorporating a thin luminescent sublayer that produces greatly increased luminescence intensity from delaminated regions of the TBC. Initial efforts utilized visible-wavelength luminescence from either europium or erbium doped sublayers. This approach exhibited good sensitivity to delamination of electron-beam physical-vapor-deposited (EB-PVD) TBCs, but limited sensitivity to delamination of the more highly scattering plasma-sprayed TBCs due to stronger optical scattering and to interference by luminescence from rare-earth impurities. These difficulties have now been overcome by new strategies employing near-infrared (NIR) and upconversion luminescence imaging. NIR luminescence at 1550 nm was produced in an erbium plus ytterbium co-doped yttria-stabilized zirconia (YSZ) luminescent sublayer using 980-nm excitation. Compared to visible-wavelength luminescence, these NIR emission and excitation wavelengths are much more weakly scattered by the TBC and therefore show much improved depth-probing capabilities. In addition, two-photon upconversion luminescence excitation at 980 nm wavelength produces luminescence emission at 562 nm with near-zero fluorescence background and exceptional contrast for delamination indication. The ability to detect TBC delamination produced by Rockwell indentation and by furnace cycling is demonstrated for both EB-PVD and plasma-sprayed TBCs. The relative strengths of the NIR and upconversion luminescence methods for monitoring TBC delamination are discussed.



Monitoring Delamination of Thermal Barrier Coatings by Near-Infrared and Upconversion Luminescence Imaging

J.I. Eldridge NASA Glenn Research Center

R.E. Martin Cleveland State University

J. Singh and D.E. Wolfe Penn State University

ICMCTF San Diego, CA April 30, 2008

Objectives

- Improved TBC delamination monitoring using nearinfrared (NIR) & upconversion luminescence imaging.
 - Greater transmittance using longer wavelengths
 - Co-doping strategy reduces interference from impurity luminescence
 - Luminescent sublayer fully integrated into TBC
- Monitor delamination progression produced by furnace cycling.
- Evaluate delamination progression for both EB-PVD & plasma-sprayed TBCs.
- Show that added dopants do not reduce TBC life.





Motivation for erbium + ytterbium co-doping

- Er³⁺ produces strong NIR luminescence at 1550 nm where TBC is much more transparent.
- Yb³⁺ is a good absorber of 980 nm excitation and produces luminescence in Er³⁺ by energy transfer. Luminescence from Er³⁺ impurities in undoped overlayer are not effectively excited without Yb³⁺ co-dopant.

Detecting TBC Delamination by Reflectance-Enhanced Luminescence Er + Yb Co-Doped Sublayer 562 nm Er³⁺ emission (intensified 980 nm by high internal **562 nm Er³⁺** illumination **reflectivity**) emission upconversion **Undoped YSZ Er + Yb-doped YSZ** delamination NiPtAl bond coat **Rene N5 superalloy**

substrate

Motivation for erbium + ytterbium co-doping

- Er³⁺ produces strong NIR luminescence at 1550 nm where TBC is much more transparent.
- Yb³⁺ is a good absorber of 980 nm excitation and produces luminescence in Er³⁺ by energy transfer. Luminescence from Er³⁺ impurities in undoped overlayer are not effectively excited without Yb³⁺ co-dopant.
- Er³⁺ produces upconversion luminescence at 562 nm with near-zero background for strong delamination contrast.



Type of Luminescence	λ _{excitation} (nm)	λ _{emission} (nm)	T _{excitation}		T _{emission}		T _{excitation} *T _{emission}	
			PS	EB-PVD	PS	EB-PVD	PS	EB-PVD
Visible	514	562	1.8%	21.4%	5.4%	24.3%	0.10%	5.20%
NIR	980	1550	18.8%	37.4%	23.5%	42.6%	4.42%	15.9%
Upconversion	980	562	18.8%	37.4%	5.4%	24.3%	1.02%	9.09%

NIR and Upconversion Luminescence Imaging



EB-PVD TBCs

Er³⁺ Luminescence Imaging of Scratch-Induced Delamination for EB-PVD TBC with YSZ:Er(1%),Yb(3%) Base Layer

White light image





514 nm excitation 562 nm emission 1 sec Luminescence images



980 nm excitation 1550 nm emission 16 msec



980 nm excitation 562 nm emission 6 sec





Upconversion Luminescence Images During Interrupted Furnace Cycling for EB-PVD TBC with YSZ:Er(1%),Yb(3%) Base Layer



Log Upconversion Luminescence Images During Interrupted Furnace Cycling for EB-PVD TBC with YSZ:Er(1%),Yb(3%) Base Layer



Change in Luminescence Intensity with Furnace Cycling



Change in Luminescence Intensity with Furnace Cycling



Plasma-Sprayed TBCs

Partitioned Multilayer Coating Design



NIR & Upconversion Luminescence Imaging of YSZ:Eu,Yb *below* Metco PS-8YSZ Shows Tremendous Sensitivity to Attached Substrate



Line Scans Showing NIR & Upconversion Delamination Enhancement



NIR Luminescence Imaging Monitors Advancing Delamination Front During Interrupted Furnace Cycling of Plasma-Sprayed TBC with YSZ:Er(1%),Yb(3%) Base Layer



NIR Luminescence Imaging Monitors Advancing Delamination Front During Interrupted Furnace Cycling of Plasma-Sprayed TBC with YSZ:Er(1%),Yb(3%) Base Layer



Effect of YSZ:Er,Yb Base Layer Microstructure on Delamination Contrast

YSZ:Er, Yb base layer thickness

EB-PVD



Vertical boundaries of columnar microstructure does not impede downward light propagation (wave guide).

Substantial reduction of luminescence by attached substrate absorption.

Partitioned Multilayer Plasma-Spray/EB-PVD Hybrid



No scattering of downward propagating light in base layer. Many boundaries in overlayer to reflect light back into base layer.

Near-complete absorption of luminescence by attached NiCr layer.

Superb delamination contrast

Plasma-Sprayed



Splat microstructure of base layer is highly scattering. _

Less absorption of luminescence by attached substrate absorption since there is significant scattering within base layer.

Excellent delamination contrast

Modest delamination contrast

Summary

- NIR & upconversion luminescence imaging offer improved detection of TBC delamination progression.
 - Upconversion luminescence imaging
 - Enhanced contrast for discriminating between finer gradations of TBC delamination progression in EB-PVD TBCs.
 - NIR luminescence imaging
 - Superior penetration for detecting delamination in highly scattering plasma-sprayed TBCs.
 - Er³⁺ + Yb³⁺ co-doping strategy minimizes interference from
 Er³⁺ impurities above the luminescent sublayer.
- Integration of luminescent sublayer achieved (EB-PVD) without reducing TBC life. (in progress)