

October 1997


www.nasatech.com

Vol. 21 No. 10



TECH BRIEFS

THE DESIGN/ENGINEERING TECHNOLOGY DIGEST



Sensors/Imaging Special Focus

NASA's Software of the Year


Motion Control Tech Briefs

Laser Tech Briefs

Join the Solution Revolution


"As developers of high-performance DAQ applications, we chose LabVIEW because it provides the high-end tools needed for rapid development without restricting the use of 'C' for low-level needs."

*Jim Campbell, Cofounder,
Viewpoint Software Solutions*




"The dataflow style of the LabVIEW graphical language replaces the old style of sequential programming – now, complex concepts such as the timing and operation of parallel tasks can be clearly defined."

*Lynda Gruggett, President,
G Systems*



"LabVIEW software is easy to develop, debug, and maintain. It helps us concentrate on the application features without being caught up in fine details. This translates to on-time, on-budget projects and customer satisfaction."

*Niranjan Ravulapalli, Project Manager
VI Technology*



LabVIEW

Graphical Programming Software

It's not a secret anymore. There's a graphical programming revolution going on, and LabVIEW is leading it. Thousands of scientists, engineers, and technicians use LabVIEW to create complete instrumentation and data acquisition solutions in a fraction of the time it takes with other software. The simplicity of the graphical language and the speed of the graphical compiler have helped LabVIEW users develop millions of successful solutions.




U.S. Corporate Headquarters

Tel: (512) 794-0100 • Fax: (512) 794-8411

info@natinst.com • www.natinst.com

Worldwide network of direct offices and distributors.

© Copyright 1997 National Instruments Corporation. All rights reserved.
Product and company names listed are trademarks or trade names of their respective companies.



FREE PRODUCTIVITY STUDY


**Learn how you can start creating solutions.
Call (800) 433-3488
and ask for your FREE Productivity Study.**

For More Information Circle No. 500

Where Do I Find Handheld, Infrared Thermometers with Optional Laser Sight? **OMEGA... Of Course!**

NEW 

Laser Sight Model Configurations



Single Dot



Circle



OMEGAfaxSM

OMEGA's 24-Hour-a-Day,
On-Demand Publishing Service
DIAL 1-800-848-4271

For Sales and Service Call:

1-800-82-66342SM
1-800-TC-OMEGA

OS520 Series Starts at \$345.
Includes Soft Carrying Case, Wrist Strap,
Batteries, and Complete Operators Manual.
Laser Sight Extra.

 No. 501
or Request Document #1538,
OMEGAfaxSM Service

Starting At
\$345

U.S. and
Int'l.

omega.comTM

Ω OMEGA®


OMEGA ENGINEERING, INC., ONE OMEGA DRIVE, P.O. BOX 4047, STAMFORD, CT. 06907-0047
© COPYRIGHT 1997 OMEGA ENGINEERING, INC. ALL RIGHTS RESERVED.

ISO 9001
CERTIFIED
CORPORATE QUALITY

<http://www.omega.com>
e-mail: info@omega.com


In Stamford, CT

TO CONVERT REAL-TIME COMPUTER GRAPHICS TO VIDEO...



1280x1024
Computer
Display

*...and get the best possible image,
you will need the Model 9400JR or
Model 9700XL from Folsom Research.*



NTSC/PAL Monitor

You're looking at the two best autosync video scan converters available anywhere. Both can turn your high-resolution desktop workstation, PC or Mac presentations into broadcast-quality videos. The 9400JR is built for the same top performance and excellent picture quality as our top-of-the-line unit. It is the most affordable true broadcast-quality scan converter made. The 9700XL, built for absolute control and flexibility, is the most powerful scan converter made. Period.


**9400JR
Limited
Time Price
Reduction
\$5,900**

9400JR

Interlaced and
Non-Interlaced
Sources

85 KHz Input
(true autosync)

NTSC/PAL
True Broadcast
Quality





*To see all of the powerful
features, call for your free
demo today.*

9700XL

Free RS-232
Win95/NT 4.0
Control Software

100 KHz Input
(true autosync)

NTSC/PAL
True Broadcast
Quality




FolsomTM
RESEARCH

526 East Bidwell Street
Folsom, CA 95630-3119
Tel (916)983-1500
Fax (916)983-7236
Email: sales@folsom.com
<http://www.folsom.com>


CFD2000[®]

generating
real results...


Electronics



Industrial




Aerodynamics




Biomedical



Metallurgy



Automotive



Environmental



www.adaptive-research.com

sales@adaptive-research.com

Trying to solve real-world fluid flow and heat transfer problems?

The solution...CFD2000. The most powerful and cost-effective CFD/CAD software system available to engineers. Period. With CFD2000, you can analyze and improve your designs without the cost of real-world testing. This means a more cost-effective design cycle. CFD2000 helps you identify design flaws early, resulting in a better product and shorter time-to-

market. Adaptive Research is dedicated to building strong relationships with clients and ensuring their success by providing quality software and expert technical support. Adaptive Research has the solution for you...CFD2000.

adaptive.
RESEARCH
a Division of
Pacific-Sierra Research Corporation

2901 28th Street, Suite 300
Santa Monica, California 90405
(800) 326-5155

4960 Corporate Drive, Suite 100
Huntsville, Alabama 35805
(800) 321-2426



CALL FOR
FREE DEMO
CD OF
CFD2000

Exact Graphs for Exact Science

New!
SigmaPlot 4.0
for Windows


You've spent months gathering and analyzing data. Now you need to show off your work – clearly and precisely. You can use a spreadsheet or a data analysis program to make a graph. Many scientists have tried this route. Then they saw they could not create the exact graph that best represented their data. Scientists like you designed the solution: SigmaPlot.

DESIGNED WITH THE FLEXIBILITY YOU NEED

Customize every detail to create the exact SigmaPlot graph you want. Just a few mouse clicks s all it

"When it comes to choosing the program that will best meet the needs of the bulk or scientific and engineering users; it isn't close: it's SigmaPlot by a mile."

Dr. Barry Simon, Ph.D., Desktop Engineering Magazine, September 1996



takes to see one of over 100 curve fits added to your graph using the new SigmaPlot 4.0 Regression Wizard. Choose the error bar direction for every data point. Lay out multiple graphs on a page to see the trends in your data. Export to EPS, TIFF, JPEG and other graphic file formats to publish your results.

THE PROOF IS IN THE PLOTTING

Over 100,000 of your colleagues have already seen how SigmaPlot

graphs create a more compelling presentation of their research. SigmaPlot provides exact graphs for exact science.

To order:
SPSS Inc., 444 N. Michigan Avenue, Chicago, IL, 60611
+312.329.2400; fax: +312.329.3668
Distributors worldwide: <http://www.spss.com/order/>
A0057 YSPCNTB-0997

Call today at 1-800-841-0057


<http://www.spss.com/software/science/sigmaplot>

SIGMAPLOT
Exact Graphs for Exact Science

Fit thousands of equations to your data in seconds

Find the best model for your data in seconds

TableCurve 2D has 3,665 equations frequently encountered in science and engineering built right in. With a single mouse click, fit them all or just the ones you need – instantly! You can even enter your own specialty models to be fit and ranked along with the built-in equations. If no single function describes your data, choose from the three powerful non-parametric estimation features – Local Regression Estimation, Spline Fitting and Smooth Spline Estimation. TableCurve saves you precious time because it takes the endless trial and error out of data fitting.



Fit XY models to your data in seconds with TableCurve 2D (above). Use TableCurve 3D for XYZ surface fitting applications (left).

Visually discover the best equation to model your data

Once the fit is complete, TableCurve automatically displays fitted equations and corresponding graphs sorted by the statistical criteria you select. Graphically review fitted results as you scroll through the equation list to discover the model that meets your requirements for the ideal fit.

To order:
SPSS Inc., 444 N. Michigan Avenue, Chicago, IL, 60611
+312.329.2400; fax: +312.329.3668
Distributors worldwide: <http://www.spss.com/order/>
A0057 YSPCNTB-0997

Call today 1-800-841-0057

<http://www.spss.com/software/science/tcurve2>

**NEW 3D
VERSION
3.0**

Solve complex science and engineering problems faster


- Optimize product and process performance
- Quickly calibrate sensors
- Understand complex chemical kinetics
- Reduce empirical data to a simple equation
- Stabilize systems with dynamic feedback
- Any general curve fitting application!

"I was able to turn a two-week semi-accurate task into a two-hour precision task the minute I installed TableCurve."

Scott Slavick
Engineer and Researcher

TABLECurve

When Time is Slipping Away...



On orders entered by
5:00 p.m. central time

Rated #1 for...

- Availability of Product
- On-Time Delivery
- Overall Performance

...5 Years in a Row!

Call, write, fax or visit us on the
Internet for your **FREE CATALOG** today!

Digi-Key®

Digi-Key Corporation
701 Brooks Ave. South
Thief River Falls, MN 56701
Toll-Free: 1-800-344-4539 • Fax: 218-681-3380
Order Online www.digikey.com



Features

- 20 Guest Editorial
Small Business: Vital Link to NASA's Future
- 22 Application Briefs
- 70 NASA's Software of the Year

Briefs



26 Special Focus: Sensors/Imaging

- 26 Neural-Network Modules for High-Speed Image Processing
- 26 Reconstruction of Images From Circular-Scan Sensors
- 30 Advanced X-Ray Imaging Spectrometer
- 30 Digital Video System Images Damaged Gears During Operation
- 32 Image-Analysis System Tracks Objects
- 35 Swept-Frequency Fiber-Optic Readout From Multiple Sensors



40 Electronic Components and Circuits

- 40 GaAs-JFET-Based Multiplexers for Readout of VLWIR Detectors
- 42 Electronically Switchable Bragg Gratings (ESBGs)



46 Electronic Systems

- 46 Telerobot Control for Microsurgery
- 46 Hydrogen-Fire-Detector Calibration Unit



52 Physical Sciences

- 52 Better Cells for Multiple-Pass Absorption of Light in Gases
- 56 Optical Air Mass Flux Sensor for Aeroengine Monitoring and Control
- 58 Electrochemical Process for Treatment of Wastewater




62 Materials

- 62 Adhesively Bonded Strain Gauges for Temperatures up to 400 °C
- 64 Modified CVI Process for Making SiC/SiC Composites
- 65 Unsymmetrical Squaraine Dyes for Nonlinear Optics

Departments

- 14 Commercial Technology Team
- 16 NASA Patents
- 24 Commercialization Opportunities
- 36 Special Focus Products
- 107 New on Disk
- 108 New on the Market
- 110 New Literature
- 112 Advertisers Index



NASA's ground network stations have been re-engineered to reduce life cycle costs for the Space Shuttle. Real-time range safety data in the laboratory and at the launch site will be developed using Visual Test Systems (VTS) data acquisition systems from L3 Communications Telemetry & Instrumentation of San Diego, CA. The customized VTS station shown is one of five to be installed for NASA to keep close track of the shuttle's flight performance. For more information, see Application Briefs on page 22.


Photo courtesy of L3 Communications

Now: **NONLINEAR** that's **EASY**


EASY things you can do with **Nonlinear**
that you can't do with regular linear stress analysis




Out of plane bending - Use nonlinear analysis to determine whether this plate will shorten and fall out of its support. Linear analysis cannot predict geometry changes perpendicular to a load.




Permanent deformation - Algor's nonlinear analysis can predict the permanent deformation when the predicted stress exceeds the yield stress. Linear analysis can't do this.




Trajectory - Basic motion, such as the trajectory of this rotating football is easily done using Algor's nonlinear analysis. Linear analysis cannot predict motion.




Squashing - Squashing this rubber ball in a vice using linear analysis cannot predict the final shape like this nonlinear analysis.




Stress concentration - Linear stress analysis will misrepresent both the stress and the deformation of this corner due to minute changes in the geometry. Nonlinear analysis gets it right.




Local buckling - When failure is due to local buckling, the geometry fails at stresses much, much lower than the yield stress. Linear cannot detect local buckling.




Snap-through - Any time you have a snap-through effect, your part is in motion until it stops on the other side. You need nonlinear analysis to predict this effect.




Impact - Nonlinear dynamic response predicts the stress in an object when it goes into motion as a result of impact by another object. Linear analysis cannot analyze for impact and motion.



Bar link - Linear dynamic analysis cannot predict the forces and stresses due to periodic loading. Accupak/VE simulates the loading and stresses in one analysis.



3-D mechanism - When a moving object is a 3-D mechanism, high inertia forces can occur. You need Accupak/VE to predict the stresses caused by motion.



Contact impact - Kinematic motion and the stresses due to the shock of impact cannot be predicted by either linear stress analysis or kinematics analysis software. Accupak/VE does it in one shot.



Elastic large deformation - Nonlinear analysis predicts the stressed geometry when the deformation is significant, even if the material properties remain linear. Linear analysis fails at this.

Nonlinear Dynamic Analysis for Virtual Engineering that's:

1. As **EASY** as Linear Static Stress Analysis
2. At Linear Stress Pricing Levels
3. Fully Integrated with your CAD Station

Accupak/VE from Algor is the nonlinear dynamic analysis software that's as easy to use as regular linear stress analysis while providing advanced solution technology. Its ease-of-use, affordability, and compatibility with Pentium computers and mainstream CAD systems make Accupak/VE ideal for everyday engineering. Engineers can learn it quickly and easily with the help of Docutech-Technical Documentation On-line Information Resource.

Get your free Video and CD-ROM to see
Algor Software in action

Video includes 18 action packed minutes of real-world examples combined with Algor FEA demonstrations. See Accupak/VE in action. CD includes a complete version of Algor's website with detailed information and software you can try.



Visit Algor at:
WWW.ALGOR.COM

Products

Services

Download
Superdraw III

You have 4 ways to get your free demo video and CD-ROM:

- 1) Call: +1 (412) 967-2700
- 2) WWW.ALGOR.COM
- 3) E-mail to: info@algor.com
- 4) Complete this form and fax to:
+1 (412) 967-2781

Name _____ Company _____

Address _____

City _____ State/Prov. _____ Zip/Postal Code _____

Country _____ Telephone _____

Fax _____ E-mail _____

ALGOR
When the Engineering
Has to be Right

Algor, Inc.
150 Beta Drive, Pittsburgh, PA 15238-2932
USA

Phone: +1 (412) 967-2700
Fax: +1 (412) 967-2781
California: +1 (714) 564-0844
Europe (UK): +44 (1) (784) 442 246
E-mail: info@algor.com



68 Computer Software

- 68 The SPICE System
- 68 Program for Analyzing Flutter of Propfan Blades
- 68 Computer Program for Emulating MIL-STD-1750a Computer



72 Mechanics

- 72 Focus-Ring Mechanism Translates Lenses Without Rotation
- 74 Portable Computer Workstations for Engineering Teams
- 78 Model-Based Placement of Gearbox-Monitoring Accelerometers
- 80 Rolled-Up Ramp Deploys Itself on Command
- 81 Identifying Loose Joints in an Adaptive Truss Structure



84 Machinery/Automation

- 84 Heat Pump for Quick Warming of Automobile Passenger Space
- 84 Designing Electrically Powered Actuators for Aircraft
- 86 Force-Feedback Device for Microsurgery
- 87 Rotordynamic Seal and Bearing Tester



89 Manufacturing/Fabrication

- 89 Holographic Lithography With Phase Feedback
- 90 Soldering Parts Together at Precise Faying Surfaces
- 91 Soldering Stacked Integrated-Circuit Chips
- 92 Fabricating and Testing an Ultrathin Mirror



93 Mathematics and Information Sciences

- 93 Predicting Where Terminated Unpiloted Aircraft Will Land
- 94 Dynamic Routing for Networks With Random Connectivities



96 Life Sciences

- 96 Continuous Unidirectional Locking Orthotic Joint



98 Books and Reports

- 98 Factors That Affect Readings of Ultrasonic Bolt-Load Gauges
- 98 Adaptive Footpads With Pyrotechnically Anchored Tethers
- 99 High-Temperature Fatigue Testing of PMCs
- 99 More About a Laser-Speckle Surface-Strain Gauge
- 99 Macrosegregation and Nucleation in Undercooled Pb/Sn Alloys
- 100 Reconfigurable Pointing Control for Spaceborne High-Resolution Spectroscopic Instruments
- 100 Using Genetic Algorithms to Plan a Spacecraft Landing

Special Supplements



Laser Tech Briefs

Follows page 88 in selected editions only.

Motion Control Tech Briefs

Follows page 96 in selected editions only.

On the cover:

Advances in sensors — as well as image acquisition, processing, and analysis — are featured in this month's Special Focus, which begins on page 26. Among the Sensors/Imaging products described are these Hall Effect geartooth sensor modules from Cherry Electrical Products, Waukegan, IL, that are manufactured using a patent-pending process to individually tune each sensor.


Photo courtesy of Cherry Electrical Products


This document was prepared under the sponsorship of the National Aeronautics and Space Administration. Neither Associated Business Publications Co., Ltd. nor the United States Government nor any person acting on behalf of the United States Government assumes any liability resulting from the use of the information contained in this document, or warrants that such use will be free from privately owned rights. The U.S. Government does not endorse any commercial product, process, or activity identified in this publication.

Permissions: Authorization to photocopy items for internal or personal use, or the internal or personal use of specific clients, is granted by Associated Business Publications, provided that the flat fee of \$3.00 per copy be paid directly to the Copyright Clearance Center (21 Congress St., Salem, MA 01970). For those organizations that have been granted a photocopy license by CCC, a separate system of payment has been arranged. The fee code for users of the Transactional Reporting Service is: ISSN 0145-319X/94 \$3.00+.00



NASA Tech Briefs, ISSN 0145-319X, USPS 750-070, copyright © 1997 in U.S. is published monthly by Associated Business Publications Co., Ltd., 317 Madison Ave., New York, NY 10017-5391. The copyright information does not include the (U.S. rights to) individual tech briefs that are supplied by NASA. Editorial, sales, production, and circulation offices at 317 Madison Ave., New York, NY 10017-5391. Subscription for non-qualified subscribers in the U.S., Panama Canal Zone, and Puerto Rico, \$75.00 for 1 year; \$135 for 2 years; \$200.00 for 3 years. Single copies \$10.00. Foreign subscriptions one-year U.S. Funds \$195.00. Remit by check, draft, postal, express orders or VISA, MasterCard, and American Express. Other remittances at sender's risk. Address all communications for subscriptions or circulation to *NASA Tech Briefs*, 317 Madison Ave., New York, NY 10017-5391. Periodicals postage paid at New York, NY and additional mailing offices.

HOW DOES ONE SOFTWARE PROGRAM
BECOME THE 5-TO-1 FAVORITE?







BY ENABLING COMPANIES LIKE YOURS TO *{Introducing Mechanical Desktop® 2.0, how more design*




© Copyright 1997 Autodesk, Inc. Autodesk, Mechanical Desktop and the Autodesk logo are registered trademarks of Autodesk, Inc. "Design Your World" is a trademark of Autodesk, Inc. All other trademarks belong to their respective owners. Background names are registered Mechanical Desktop users. *Source: Daratech, Inc. Midrange modeler installed base year-end 1996.



PRODUCE DESIGNS LIKE THESE.

professionals are moving to 3D modeling.



Everyone wants a shorter product-to-market cycle. That's why tens of thousands of engineers have already made Mechanical Desktop the best selling PC-based 3D modeling software. And now there's Mechanical Desktop 2.0. It supports the way you naturally work. You're free to use 3D modeling or 2D drafting, whichever's needed. You have all the benefits of feature-based parametric solid modeling, NURBS surface modeling, assembly modeling, associative drafting, as well as DWG



Autodesk.



compatibility. And our Mechanical Applications Initiative (MAI) enables you to create a seamless design-through-manufacturing solution with finite-element analysis, sheet metal fabrication, kinematics, NC programming and more. Call for more information today. Or, simply ask your colleagues. 5-to-1 says they chose Mechanical Desktop.*

For a Free Demo CD, call 1-800-964-6432

Request Demo Pak #s467 or get information on education discounts. And visit www.autodesk.com/s467

CONVERT COMPUTER GRAPHICS



TO VIDEO



RGB/Videolink®

VIDEO SCAN CONVERTERS

Up to 1600 x 1280 pixel input
Analog output / NTSC, PAL, S-Video, CAV
Digital output / CCIR 601 Flicker filter
Autosync Video overlay Pan & Zoom
Simple external connections



SPECTRUM®

A visual communications company™

950 Marina Village Parkway Alameda, CA 94501
Tel: (510) 814-7000 Fax: (510) 814-7026



TECH BRIEFS

VBPA ABP

Published by **Associated Business Publications**
Chairman/Chief Executive Officer **Bill Schnirring**
Publisher **Joseph T. Pramberger**
Chief Editor **Linda L. Bell**
Editor, Market Focus Editions **Robert Clark**
Production Manager **Margery Koen**
Assistant Production Manager **John Iwaniciw**
Art Director **Lois Erlacher**
Production Artist **Christopher Coleman**
Circulation Manager **Hugh J. Dowling**
Assistant to Circulation Manager **Damiana Garcia**

BRIEFS & SUPPORTING LITERATURE: Written and produced for NASA by
Advanced Testing Technologies, Inc., Hauppauge, NY 11788

Technical/Managing Editor **Ted Selinsky**
Sr. Technical Analyst **Dr. Larry Grunberger**
Art Manager **Eric Starstrom**
Staff Writers/Editors **Dr. Theron Cole, George Watson,**
Howard Falk, Gail Pyke
Graphics **Robert Simons**
Editorial & Production **Joan Schmiemann, Caroline Weaver**
Becky D. Bentley

NASA:

NASA Tech Briefs are provided by the National Aeronautics and Space
Administration, Technology Transfer Division, Washington, DC:

Administrator **Daniel S. Goldin**
Director, Commercial Technology **Dr. Robert Norwood**
Publications Director **Carl Ray**

ASSOCIATED BUSINESS PUBLICATIONS

317 Madison Avenue, New York, NY 10017-5391
(212) 490-3999 FAX (212) 986-7864

Chairman/Chief Executive Officer **Bill Schnirring**
President/Chief Operating Officer **Domenic A. Mucchetti**
Executive Vice President **Joseph T. Pramberger**
Credit/Collection **Felecia Lahey**
Staff Accountant **Larry Duze**
Budget Analyst **Mark Stanovic**
Accounting Assistant **Alfredo Vasquez**
Exhibition Sales Manager **Wayne Pierce**
Exhibition Sales Representative **Joanna Lipton**
Human Resources Manager **Louder Del Valle**
MIS Manager **Ted Morawski**
Webmaster **Albert Sunseri**
Assistant MIS Manager **Pak Tong**
Network Administrator **Dmitry Master**
Office Manager **Sylvia Valentin**
Mailroom Operations **John Torres, Rose D'Addio**
Administrative Assistant **Christine Saluzzi**

NASA TECH BRIEFS ADVERTISING ACCOUNT EXECUTIVES

Headquarters (212) 490-3999
NY, NJ (Area Code 201), Eastern Canada **John Waddell**
at (212) 490-3999
PA, DE, NJ (Area Code 908, 609), VA, DC, MD, WV **Tara Morie**
at (610) 640-3118
Eastern MA, NH, ME, RI **Paul Gillespie** at (508) 429-8907
Bill Doucette at (508) 429-9861
Western MA, CT, VT **George Watts**
at (802) 824-5546
Southeast, South Central **Thomas E. Duffy**
at (770) 844-7996
OH, MI, IN, KY **Louise Clemens**
at (216) 397-7477
IL, WI, MO, IA, MN, ND, SD, NE, KS, Central Canada **Paul Tucker**
at (847) 397-7084
N. Calif., CO **Bill Hague**
at (408) 492-9292
WA, OR, ID, MT, WY, UT, Western Canada **Bill Madden; Bill Hague**
at (253) 858-7575
S. Calif., AZ, NM, NV (For NASA Tech Briefs) **Blake Dahlgren**
at (310) 288-0391
S. Calif., AZ, NM, NV (For Electronics and Laser Tech Briefs) **Richard Ayer**
Jane Hayward
at (714) 366-9089
TechDeck Postcard Sales **Janet Krebs**
at (847) 397-7084

How To Reach Us On Line

NASA Tech Briefs home page: <http://www.nasatech.com>

Letters to the editor: ntb_edit@mindspring.com

To find out about advertising opportunities:
ntb_advertise@mindspring.com

**There's a time and place to find out how
good your bearing manufacturer is.**

This isn't one of them.



Oil exploration is a twenty-four hour a day endurance test of man and machine.

When investments in the hundreds of millions are riding an angry sea, working the endless shift comes with the territory. So, at Torrington, we know you need the performance, quality, and commitment to keep you up and running under the most demanding conditions. As long as oil

exploration goes on, so will our dedication to your industry.

TORRINGTON
INGERSOLL-RAND

Progress Through Performance

www.torrington.com

NASA's R&D efforts produce a robust supply of promising technologies with applications in many industries. A key mechanism in identifying commercial applications for this technology is NASA's national network of commercial technology organizations. The network includes ten NASA field centers, six Regional Technology Transfer Centers (RTTCs), the National Technology Transfer Center (NTTC), business support organizations, and a full tie-in with the Federal Laboratory Consortium (FLC) for Technology Transfer. Call (206) 683-1005 for the FLC coordinator in your area.

NASA's Technology Sources

If you need further information about new technologies presented in *NASA Tech Briefs*, request the Technical Support Package (TSP) indicated at the end of the brief. If a TSP is not available, the Commercial Technology Office at the NASA field center that sponsored the research can provide you with additional information and, if applicable, refer you to the innovator(s). These centers are the source of all NASA-developed technology.

Ames Research Center

Selected technological strengths: Fluid Dynamics; Life Sciences; Earth and Atmospheric Sciences; Information, Communications, and Intelligent Systems; Human Factors.
Bruce Webbon
(415) 604-6646
bwebbon@mail.arc.nasa.gov

Dryden Flight Research Center

Selected technological strengths: Aerodynamics; Aeronautics; Flight Testing; Aeropropulsion; Flight Systems; Thermal Testing; Integrated Systems Test and Validation.
Lee Duke
(805) 258-3802
duke@louie.drrf.nasa.gov

Goddard Space Flight Center

Selected technological strengths: Earth and Planetary Science; Missions; LIDAR; Cryogenic Systems; Tracking; Telemetry; Command.
George Alcorn
(301) 286-5810
galcorn@gsfc.nasa.gov

Jet Propulsion Laboratory

Selected technological strengths: Near/Deep-Space Mission Engineering; Microspacecraft; Space Communications; Information Systems; Remote Sensing; Robotics.
Merle McKenzie
(818) 354-2577
merle.mckenzie@ccmail.jpl.nasa.gov

Johnson Space Center

Selected technological strengths: Artificial Intelligence and Human Computer Interface; Life Sciences; Human Space Flight Operations; Avionics; Sensors; Communications.
Hank Davis
(713) 483-0474
hdavis@gp101.jsc.nasa.gov

Kennedy Space Center

Selected technological strengths: Environmental Monitoring; Sensors; Corrosion Protection; Bio-Sciences; Process Modeling; Work Planning/Control; Meteorology.
Gale Allen
(407) 867-8035
galeallen-1@ksc.nasa.gov

Langley Research Center

Selected technological strengths: Aerodynamics; Flight Systems; Materials; Structures; Sensors; Measurements; Information Sciences.
Dr. Joseph S. Heyman
(804) 864-6006
j.s.heyman@larc.nasa.gov

Lewis Research Center

Selected technological strengths: Aeropropulsion; Communications; Energy Technology; High Temperature Materials Research.
Ann Heyward
(216) 433-3484
cto@lerc.nasa.gov

Marshall Space Flight Center

Selected technological strengths: Materials; Manufacturing; Nondestructive Evaluation; Biotechnology; Space Propulsion; Controls and Dynamics; Structures; Microgravity Processing.
Harry Craft
(205) 544-5419
harry.craft@msfc.nasa.gov

Stennis Space Center

Selected technological strengths: Propulsion Systems; Test/Monitoring; Remote Sensing; Nonintrusive Instrumentation.
Kirk Sharp
(601) 688-1929
ksharp@ssc.nasa.gov

NASA Program Offices

At NASA Headquarters there are seven major program offices that develop and oversee technology projects of potential interest to industry. The street address for these strategic business units is: NASA Headquarters, 300 E St. SW, Washington, DC 20546.

Carl Ray
Small Business Innovation Research Program (SBIR) & Small Business Technology Transfer Program (STTR)
(202) 358-4652
cray@mail.hq.nasa.gov

Gerald Johnson
Office of Aeronautics (Code R)
(202) 358-4711
g.johnson@aeromail.hq.nasa.gov

Bill Smith
Office of Space Sciences (Code S)
(202) 358-2473
wsmith@sm.ms.oss.hq.nasa.gov

Bert Hansen
Office of Microgravity Science Applications (Code U)
(202) 358-1958
bhansen@gm.olmsa.hq.nasa.gov

Granville Paules
Office of Mission to Planet Earth (Code Y)
(202) 358-0706
gpaules@mtpe.hq.nasa.gov

Dr. Robert Norwood
Office of Aeronautics and Space Transportation Technology (Code R)
(202) 358-2320
norwood@mail.hq.nasa.gov

Philip Hodge
Office of Space Flight (Code M)
(202) 358-1417
phodge@osfms1.hq.nasa.gov

NASA's Business Facilitators

NASA has established several organizations whose objectives are to establish joint sponsored research agreements and incubate small start-up companies with significant business promise.

Karen Robbins
American Technology Initiative
Menlo Park, CA
(415) 325-5353

Joe Boeddeker
Ames Technology Commercialization Center
San Jose, CA
(408) 557-6700

Wayne P. Zeman
Lewis Incubator for Technology
Cleveland, OH
(216) 586-3888

Dan Morrison
Mississippi Enterprise for Technology
Stennis Space Center, MS
(800) 746-4699

NASA-Sponsored Commercial Technology Organizations

These organizations were established to provide rapid access to NASA and other federal R&D and foster collaboration between public and private sector organizations. They also can direct you to the appropriate point of contact within the Federal Laboratory Consortium. To reach the Regional Technology Transfer Center nearest you, call (800) 472-6785.

Dr. David Moran
National Technology Transfer Center
(800) 678-6882

Dr. William Gasko
Center for Technology Commercialization
Massachusetts
Technology Park
(508) 870-0042

Gary Sera
Mid-Continent Technology Transfer Center
Texas A&M University
(409) 845-8762

Chris Coburn
Great Lakes Industrial Technology Transfer Center
Battelle Memorial Institute
(440) 734-0094

Ken Dozier
Far-West Technology Transfer Center
University of Southern California
(213) 743-2353

J. Ronald Thornton
Southern Technology Applications Center
University of Florida
(904) 462-3913

Lani S. Hummel
Mid-Atlantic Technology Applications Center
University of Pittsburgh
(412) 383-2500


NASA ON-LINE: Go to NASA's Commercial Technology Network (CTN) on the World Wide Web at <http://nctn.hq.nasa.gov> to search NASA technology resources, find commercialization opportunities, and learn about NASA's national network of programs, organizations, and services dedicated to technology transfer and commercialization.

If you are interested in information, applications, and services relating to satellite and aerial data for Earth resources, contact: Dr. Stan Morain, **Earth Analysis Center**, (505) 277-3622. For software developed with NASA funding, contact the **Computer Software Management and Information Center (COSMIC)** at phone: (706) 542-3265; Fax: (706) 542-4807; E-mail: <http://www.cosmic.uga.edu> or service@cosmic.uga.edu.

THE IDEA BEHIND OUR MODULAR DATA STORAGE SYSTEMS

AS EXPLAINED BY AN

IS manager



WHEN IT COMES TO storing data, modularity and flexibility are big ideas. So we design Kingston® storage enclosures for optimum growth and custom configuration. Of course, compatibility is critical, too.

www.kingston.com/storage

That's why we are implementing a certification program with all the major drive and controller manufacturers, including Adaptec®, CMD®, DPT®, Mylex®, Quantum®, and Seagate®. Want to make configuring custom storage systems as easy as child's play? Just call (800) 259-9370. Or visit our Web site at www.kingston.com/storage.



Kingston
TECHNOLOGY
STORAGE PRODUCTS DIVISION




Kingston Technology Company, 17980 Newhope Street, Fountain Valley, CA 92708, USA (714) 438-1850. Fax (714) 438-1847. © 1997 Kingston Technology Company. All rights reserved. All other trademarks and registered trademarks are the property of their respective owners. The manufacturer of the blocks illustrated in this ad in no way endorses or is affiliated with Kingston Storage Products.

For More Information Circle No. 505

LabVIEW®

What do you want to analyze today?



From image processing to mathematics, LabVIEW analysis add-ons improve your productivity.

LabVIEW Analysis Add-Ons

- IMAQ™ Vision for image processing
- Signal Processing Suite
- Fuzzy Logic Control Design Toolkit
- Wavelet and Filter Bank Design Toolkit
- Digital Filter Design Toolkit
- PID Toolkit
- G Math Toolkit for advanced mathematics and numerical analysis

Call today for a **FREE** Instrupedia™ evaluation package to see LabVIEW analysis in action.

(800) 433-3488
(U.S. and Canada)



U.S. Corporate Headquarters
Tel: (512) 794-0100 • Fax: (512) 794-8411
info@ni.com • www.ni.com
Worldwide network of direct offices and distributors.

© Copyright 1997 National Instruments Corporation. All rights reserved. Product and company names listed are trademarks or trade names of their respective companies.

PATENTS NASA

Over the past three decades, NASA has granted more than 1000 patent licenses in virtually every area of technology. The agency has a portfolio of 3000 patents and pending applications available now for license by businesses and individuals, including these recently patented inventions:

Scalable Wrap-Around Shuffle Exchange Network with Deflection Routing

(U.S. Patent No. 5,617,413)

Inventor: Steve P. Monacos,
Jet Propulsion Laboratory

Current optical communications networks typically operate at a single frequency in a ring or bus topology. As computational and communications demands increase, such networks are inadequate to handle future requirements. This invention is a communication network including plural crossbar nodes, first apparatus for connecting the nodes in a first layer of links, and second apparatus for connecting the nodes in a second layer of links independent of the first layer. The network may further include third and fourth apparatuses connected similarly. Each layer is connected to the other at each one of the nodes. Preferably each layer corresponds to one recirculating network topology that closes in on itself. In the preferred embodiment, the network topology of each of the layers is that of a cyclic shuffle exchange network wherein the first and second layers include first and second rings of the connecting links.

For More Information Circle No. 765

Lightweight Ceramic Compositions of Carbon, Silicon, Oxygen, and Boron

(U.S. Patent No. 5,618,766)

Inventors: Daniel B. Leiser, Ming-Ta Hsu, and Timothy S. Chen,
Ames Research Center

The researchers have produced a lightweight monolithic ceramic composition of carbon, silicon, oxygen, and boron that is able to retain its shape and strength when exposed to an oxidizing environment at 1200 °C, using a sol-gel method. The method comprises coating a carbon substrate with a sol that mixes silicon alkoxides and a borate ester, such as di- and tetrafunctional siloxanes and boron alkoxide, gelling the sol and heating the coated carbon substrate in an inert atmosphere to form the ceramic. Lightweight, highly oxidation-resistant ceramic tiles suitable for use in advanced space vehicle applications have been

made by impregnating a porous carbon preform with the sol, followed by gelation, drying, and pyrolysis.

For More Information Circle No. 766

Series Connected Converter for Control of Multi-Bus Spacecraft Power Utility

(U.S. Patent No. 5,623,398)

Inventors: Raymond F. Beach and
Andy Brush, Lewis Research Center

Spacecraft often use power from a solar array to charge a battery and supply loads through a regulating converter. Power from the battery is supplied to high- and low-voltage buses through separate converters processing all of the power to the buses. But processing full power generates substantial losses, taxing cooling systems and requiring cooling to be sized for relatively high peak loads. The present invention provides a power system using series-connected regulators employing a bypass loop around a DC-DC converter. The loop connects a hot input of the converter to a return output, preferably through an inductor. Part of the current from the source passes through the bypass loop to the power bus. The converter bucks or boosts the voltage from the source to maintain the desired voltage at the bus. Thus only part of the power is processed through the converter.

For More Information Circle No. 767


Three-Dimensional Co-Culture Process

(U.S. Patent No. 5,627,021)

Inventors: Thomas J. Goodwin and
David A. Wolf, Johnson Space Center

The process of the present invention co-cultures a variety of cells to produce tissue that has three-dimensionality and some of the characteristics of *in vivo* tissue. It forms and maintains three-dimensional tissue of such a size as to create a multicellular organoid differentiation model. The co-culturing process optimizes a group of culture environmental conditions, even as the culturing progresses, in a manner that greatly enhances the capability to form and maintain three-dimensional living tissue from either dissociated source cells or intact tissue resections.

For More Information Circle No. 769



SIMULINK® 2 and STATEFLOW™

Now—combine dynamic and event-driven simulation in a single, integrated environment



New Simulink features:

- Triggered and enabled subsystems for multimode operation
- State-of-the-art solvers for extreme accuracy
- Intuitive block diagram editor, signal labels, and a powerful new Scope block
- Automatic C code generation with Real-Time Workshop®
- Direct access to the MATLAB® 5 development environment, including tools for control system and DSP design, extensive graphics, and user definable data structures and objects


Available Now!

Call 508-647-7000


To find out more about Simulink 2, Stateflow, and Real-Time Workshop, call now and request KP171 to receive your special Simulink 2 edition of *MATLAB News & Notes*.

<http://www.mathworks.com/ntb>


For more information on our Connections OEM/VAR program, visit our Web site at <http://www.mathworks.com/oem>, or call us at 508-647-7253.



State-of-the-art solvers provide extremely accurate simulations—including event crossings.



Conditionally executed systems offer modeling and simulation of multiple control modes.



Simulink 2 is built on MATLAB 5, the industry standard for data analysis, algorithms, prototyping, and application development.



The MathWorks, Inc. • 24 Prime Park Way, Natick, MA 01760-1500 USA • tel: 508-647-7000 • fax: 508-647-7101 • e-mail: info@mathworks.com • <http://www.mathworks.com>

Employment opportunities <http://www.mathworks.com/newjobs.html> • MATLAB in Education: <http://education.mathworks.com>

Outside the U.S. and Canada, contact: Australia: + 61-2-9922-6311 • Benelux: + 31 (0) 182-53-7644 • Brazil: + 55-11-816-3144 • Czech Republic: + 42-2-68-44-174 • France: + 33 (0) 41-14-67-14 • Germany/Austria: + 49-241-470750
India: + 91-60-5-549338 • Israel: + 972-3-561-5151 • Italy: + 39-11-240-80-00 • Japan: + 81-3-5978-5410 • Korea: + 82-2-556-1257 • New Zealand: + 64-7-839-9102 • Poland: + 48-12-17-33-48 • Scandinavia: + 46-8-15-30-22
Singapore/Malaysia: + 65-842-4222 • South Africa: + 27-11-325-6238 • Spain/Portugal: + 34-(9)3-415-49-04 • Switzerland: + 41-31-954-2020 • Taiwan: + 886 (0) 2-505-0525 • United Kingdom: + 44-1223-423-200

© 1997 by The MathWorks, Inc. All rights reserved. MATLAB, Simulink, Handle Graphics, and Real-Time Workshop are registered trademarks, and Stateflow and Target Language Compiler are trademarks of The MathWorks, Inc. Other product or brand names are trademarks or registered trademarks of their respective holders.

For More Information Circle No. 508

There are a ton of reasons to use Vespel[®] just about anywhere.



The reasons to use Vespel[®] polyimide parts and shapes keep piling up. And not just because they stand up to heat, friction, pressure and aggressive environments – with minimal or no lubrication. Manufacturers are finding that Vespel[®] parts in a wide range of applications can really trim the bottom line. That's because the reliability and long life of Vespel[®] parts can make them the most cost-effective choice for general applications in the long term.

If your applications require parts that can withstand extreme temperatures (cryogenic to 550 F), Vespel[®] should be your first choice. Vespel[®] should also be considered for parts that rub together, if metal parts are too noisy, or if fluid flow needs to be controlled.

Superior performance and reliability aren't the only ways Vespel[®] can save you money. Often, you can consolidate two or more existing parts in one Vespel[®] piece.



Seal Rings.

In the assembly of automobile transmissions, and farm and construction equipment, Vespel® seal rings reduce costs by replacing expensive metal rings, which can fracture or deform during assembly. They also reduce warranty costs by producing a better seal.



Bushings.

In aircraft engine vanes, Vespel® bushings withstand high-frequency vibration dithering and offer excellent stability and lubricity at extreme temperatures. They also reduce assembly time.

Thrust Washers.

In construction equipment transmissions, Vespel® thrust washers reduce costs and manufacturing time by eliminating the need for secondary machining. Vespel® washers also withstand high pressure and exhibit minimal wear with limited or no lubrication.



Thrust Devices.

The automotive industry counts on Vespel® thrust devices because they reduce friction, extend component life and can be easily molded. What's more, the variety of Vespel® grades allows manufacturers to specify the properties they need most.



Insulators.

In plasma-arc cutting torches, Vespel® insulators provide superior strength and durability at high temperatures up to 550 F, lasting up to six times longer than fragile ceramic insulators.



Compressor Discus Valves.

Supermarkets are cooling foods more efficiently with discus compressors, featuring components made of Vespel®. Vespel® not only reduces energy and noise levels, but it also offers excellent wear resistance. The Vespel® part is expected to operate for 15 years without failure.



Stripper Fingers.

Thanks to its high temperature resistance, Vespel® parts are ideal for copier stripper fingers. The Vespel® fingers resist heat as well as toner buildup, allowing a greater number of copies without part changes.

And Vespel® parts can be direct-formed, which eliminates machining costs.

When you consider how cost-effective Vespel® parts can be in the long term, it's clear that we don't just make better bushings, bearings, washers and seals. We make better sense.

www.dupont.com/enggpolymer

IF YOU WANT TO GET TECHNICAL

For information, call 1-800-426-7246.
Or write: DuPont Vespel®
Product Information
Center, P.O. Box 1138,
Bloomfield Hills, MI
48303-1138.



Vespel®
Polyimide Parts and Shapes

For More Information Circle No. 529

by Carl Ray,
Small Business
Innovation Research/
Small Business Technology
Transfer (SBIR/STTR)
Executive



Small Business: Vital Link to NASA's Future

As the new millennium dawns, NASA faces challenges as well as opportunities that our parents and grandparents only dreamed about. Across the nation, NASA scientists and engineers are performing the research and development required to maintain United States leadership in civil aeronautics, aviation, and space exploration, and, at the same time, continuing our strong customer focus particularly with regard to developing and maintaining NASA-industry partnerships.

NASA achievements continue to inspire and encourage a new generation of innovators who will lead our nation through the next century. To accomplish our goals, NASA must generate greater yields on the investments made by the citizens of this nation; this requires continuous changes in the way NASA and its family of contractors do business. Many of these changes are underway. The primary objective of these changes has been to reduce the taxpayer dollars required to carry out NASA programs, but a secondary goal is to increase the opportunities for the small-business community to be part of the NASA effort by providing it with greater flexibility and facility in its innovation efforts, with less bureaucratic burden. The SBIR/STTR programs are one of NASA's vehicles to accomplish this objective.

NASA views the cadre of small businesses, including women- and minority-owned businesses, as a vital link to the agency's future. They are on the cutting edge of technology, and their bold and aggressive approaches to innovation clearly mirror NASA's spirit of doing business better, cheaper, and faster. We are very excited about the possibilities that these companies bring to the agency. The SBIR/STTR programs provide an avenue for small businesses to meet many of NASA's research and development needs.

The SBIR program was established by Congress in 1982 to provide small businesses with increased federal R&D opportunities. The STTR program, established within the SBIR legislation in 1994, is modeled after its parent program but

focuses on translating U.S. leadership in basic research and many areas of applied science into an economic advantage.

The SBIR/STTR programs are both designed to allow small businesses and research institutions to participate in the nation's annual multi-billion-dollar investment in R&D. The aim of an SBIR/STTR-funded project is to produce new technologies that have high commercial potential and will advance U.S. growth in productivity and international market competitiveness.

Starting with this issue of *NASA Tech Briefs* magazine, the NASA SBIR/STTR management embarks on an innovation of their own to share the excitement and opportunities of these two programs with the broader technical community.

In this and periodically in following issues, you will learn more about NASA's SBIR/STTR programs. There will be articles on program participation and events, but most importantly, briefs from successful small businesses describing aspects of their technical and commercial accomplishments resulting from their participation in these programs. Two such briefs appear in this issue:

"Electronically Switchable Bragg Gratings (ESBGs)" (page 42), reporting on work done by Foster-Miller Inc. and monitored for NASA's SBIR program by Marshall Space Flight Center, and "Optical Air Mass Flux Sensor for Aeroengine Monitoring and Control" (page 56), reporting on work done by Physical Sciences Inc. and monitored by Dryden Flight Research Center.

We are very excited about the NASA SBIR/STTR "success briefs" as an addition to this renowned technology digest and hope that you will share the excitement in reading them.

To learn how to apply for and win SBIR grants and contracts, attend the 1997 National Small Business Innovation Research Conferences, to be held in Washington, DC's Renaissance Hotel October 14-16 and Phoenix, AZ's Hyatt Regency October 27-29. For more information, call the SBIR Conference Center at (360) 683-5742; fax (360) 683-5391; on-line: www.zyn.com/sbir.

Small businesses are on the cutting edge of technology, and their bold and aggressive approaches to innovation clearly mirror NASA's spirit.

THE FIRST IN AIT BRINGS YOU THE MOST ADVANCED IN AIT.

STRIPING MODE

maximize performance by writing to multiple tapes simultaneously

MIRRORING MODE

write duplicate data to multiple tapes, for fault-tolerance or off-site storage



OFFLINE

COPY/VERIFY MODE

copy and verify tapes without tying up the host

INDEPENDENT MODE


write with one drive while you read with another

CASCADE MODE

write to the next tape without manual tape swapping

250 GB. 18 MB/s.

An increasingly storage-centric environment demands more performance and flexibility from a subsystem. Perhaps that's why Cybernetics 8mm tape solutions are at work day and night at thousands of Fortune 500 sites all over the world. As the first to introduce AIT, we've built the most advanced solutions around it: the CY-8000 with the Advanced SCSI Processor and our Multi-Host Libraries.




A 200,000 MTBF and a bit error specification of less than 1 in 10^{17} ensure top reliability and data integrity.

The CY-8000 is the 3.5" 8mm tape drive that's setting a new standard with 25 GB tape capacity and 3 MB/s, uncompressed. Add Ultra SCSI Data Compression to achieve up to 125 GB on each tape at speeds of 9 MB/s. With the Advanced SCSI Processor, two or more of these drives can work together in a powerful and flexible subsystem that gives you freedom to write data five different ways, depending on your application and site requirements. In addition to unmatched performance, you'll

like the intelligent design. A built-in head cleaner means you don't have to waste time and money on cleaning cartridges. Use of AME media ensures exceptional data integrity and tape life (over 30 years). You'll also appreciate Memory In Cassette, a 64k EEPROM that keeps a data log on each tape, making it a breeze to find files fast.

Move up to AIT with the leader in AIT - Cybernetics - and take advantage of the innovation, plug compatibility, experience, and support that you won't find anywhere else. Call today at (757) 833 - 9000 ext. 104




8mm AIT libraries can support up to six drives, 126 tapes, and 15.75 TB.

Alliant - Alpha Micro - Altos - Amdahl - Apollo - Aris - AT&T - Basic-4 - Bull - Concurrent - Convergent
Data General - Digital - Gould/Encore - Harris - Honeywell - HP - IBM PC/Compatible
IBM Midrange/Mainframe - ICL - Intergraph - Macintosh - McDonnell Douglas - Motorola - NCR - NeXT
Novell - Pertec - Prime - Pyramid - Sequent - Silicon Graphics - Stratus - Sun - Texas Instruments
Unisys - Ultimate - Wang - Windows NT

Application Briefs

Test Systems Help Reduce Shuttle Costs

Visual Test Systems (VTS)
L3 Communications
Telemetry & Instrumentation
San Diego, CA
619-674-5100
Fax: 619-674-5145



Customized VTS stations provide a real-time data stream of the space shuttle's flight performance.

AlliedSignal Technical Services Corp. has re-engineered NASA's ground network stations to reduce life cycle costs for the space shuttle. The upgrade includes five Windows NT-based Visual Test Systems (VTS), which will be used to develop real-time range safety data in the laboratory and at the launch site. Three systems will be installed at the Merritt Island Launch Annex in Florida; another will be installed at the Electronic Systems Test Laboratory at NASA's Johnson Space Center in Houston; and the fifth system will go to the Network Engineering Development Laboratory at NASA's Goddard Space Flight Center in Greenbelt, MD.

"The VTS met our hard requirements for a commercial off-the-shelf PC solution that made use of a database for parameter extraction," said Ed Richards, implementation group leader at AlliedSignal. The systems come with a Software Development Kit that lets NASA customize the system to its requirements. "We needed flexible and reliable telemetry processing capabilities to meet range safety requirements for the shuttle," Richards explained.

The VTS is a Windows-based real-time data acquisition system with an intuitive interface for configuring hardware boards, including decommutators, bit synchronizers, MIL-STD-1553 modules, analog input modules, and digital/analog output modules. Data is distributed from a server to multiple clients via a network-based environment. The VTS stations will acquire shuttle data, strip parameters, and reassemble them as a serial output range safety data stream. The real-time data stream will be delivered to NASA's Range Safety Officers to verify that the vehicle flight performance remains within the safety environment. Generally, the data will come from the shuttle's flight systems and computers, which gather data from the external fuel tank, solid rocket boosters, and main engines. "The whole idea is to maintain a clear picture of the shuttle's flight performance, starting with the ignition sequence, through powered flight," said Richards.

For More Information Circle No. 756

Software Helps Grab Comet by the Tail

MuSE (Multidimensional, User-oriented Synthetic Environment) software
MuSE Technologies
Albuquerque, NM
505-843-6873
<http://www.musetech.com>



NASA's Stardust mission involves sending a spacecraft the size of an office desk to loop around the sun twice, collecting interstellar dust before a rendezvous with the Wild-2 comet in 2004. The spacecraft will pass the comet at 35,000 miles per hour while it collects comet dust and other debris. The craft will return to Earth with photos and samples in 2006, arriving home as the first U.S. mission to robotically obtain samples in deep space for analysis on Earth.

Last year, NASA conducted a rehearsal — in a virtual environ-

ment — of the encounter of the Stardust spacecraft with the comet. During the mission simulation, MuSE integrated actual data from previous space probes and technical drawings of the proposed craft, allowing NASA engineers to "fly" as close as possible to the comet without leaving the ground. Precision is crucial since the spacecraft and the comet will pass at right angles, the craft moving at nine times the speed of a rifle bullet. Critical to the mission is getting close enough to collect significant material, while not being endangered by the comet's debris.

With the MuSE software, NASA scientists were able to simulate approaching the comet from different trajectories and attempt to get as close as possible. During the simulation, when the virtual spacecraft flew too close to the comet, mission planners could hear the sound of objects striking the craft and see the impact of each "fly by" from different vantage points. MuSE-developed instruments measured changes in particle density and simulated potential destabilization of the craft.

For More Information Circle No. 757



(Left to right) 1) The Stardust spacecraft is shown in initial orbit around Earth, with cross-sections displayed on the craft wall; 2) the craft has approached the comet as it moves away from the Sun, with the full encounter running on the side wall; 3) the spacecraft approaches the comet with its collector extended.

Take it from concept to final design.



Only Bentley's comprehensive mechanical engineering products do it all in a single system.

Here's where it all comes together. Now you can design, document and share your ideas all within a fully integrated environment.

Bentley has assembled a complete offering of mechanical engineering products. Products that cover every aspect of mechanical engineering design, streamlining every step of your workflow. Bentley's Single Engineering Model helps you move through the product cycle from conceptual design to manufacturing, through simulation, analysis, preproduction, engineering and manufacturing. When you make changes to your design, all components—including documentation—are updated automatically, virtually eliminating errors and omissions.

The Bentley Engineering Back Office™ range of products unites desktop engineering systems with enterprise IT and database systems for information sharing via the Internet. Best of all, our products are scalable to meet the demands of your projects—bringing together best-in-class applications into a single, powerful solution.

Go from concept to final design with Bentley. Call 1-800-BENTLEY for a free demo CD or visit www.bentley.com

MicroStation Modeler®: For creating complete models for design, analysis and manufacturing. Combines parametric, variational and feature-based solid, surface and assembly modeling methods. Especially productive for 2D and 3D models. Included free—MechanicalDetailer™ for integrated mechanical drafting and detailing, ADAMS/MS Motion™ for assembly simulation and COSMOS/M DESIGNER ONE™ for state-of-the-art FFE® (Fast Finite Element) analysis.

MicroStation® MasterPiece™: For spectacular visualization.

MicroStation® TeamMate™ 96: For document management.

COSMOS/M DESIGNER II™: For structural analysis.

ADAMS/MS Mechanisms™: For advanced assembly simulation.

ESPRIT/MS™: For manufacturing and sheet metal design.

MoldDesign™: For mold base design.

Engineering the future together

610-458-5000 • 800-BENTLEY • FAX: 610-458-1060 • www.bentley.com

MicroStation and MicroStation Modeler are registered trademarks; Engineering Back Office, MechanicalDetailer, MasterPiece, TeamMate, MoldDesign, "Engineering the future together," Bentley and the "B" Bentley logo are trademarks of Bentley Systems, Incorporated. COSMOS/M DESIGNER ONE, COSMOS/M DESIGNER II and FFE are trademarks of Structural Research & Analysis Corp. ESPRIT/MS is a trademark of DP Technology Corp. ADAMS/MS Motion and ADAMS/MS Mechanisms are trademarks of Mechanical Dynamics, Inc. © 1997 Bentley Systems, Incorporated





Commercialization Opportunities

Telerobot Control for Microsurgery

This system scales down the motion of a surgeon's hand to a very precise, smooth movement, which is critical in operations of the eye, brain, ear, and face and in the repair of fine blood vessels and nerves.

(See page 46.)

Hydrogen-Fire-Detector Calibration Unit

A microprocessor-controlled tabletop unit uses a krypton lamp for testing hydrogen-fire detectors. It eliminates the need to ignite hydrogen to run such tests and is therefore safer.

(See page 46.)

Better Cells for Multiple-Pass Absorption of Light in Gases

Improved cells offer better accuracy, are smaller, and cost less than earlier models. These cells are used to analyze gases via light absorption.

(See page 52.)

Electrochemical Process for Treatment of Wastewater

Three sequential subprocesses treat wastewater that contains various proportions of urine, laundry water, and bath water. Contaminants are reduced to 500 micrograms per liter, a level considered potable.

(See page 58.)

Modified CVI Process for Making SiC/SiC Composites

This process utilizes a sacrificial layer of SiC fiber preform that can be removed easily by scraping or tapping. The process eliminates a time-consuming, costlier grinding step.

(See page 64.)

Unsymmetrical Squaraine Dyes for Nonlinear Optics

Dyes have been invented that can be used in a variety of optical devices that exploit nonlinear optical properties to change frequency and/or polarization of light in useful ways. Second-harmonic generators, spatial light modulators, parametric oscillators, and some interferometers can benefit from this development.

(See page 65.)

Portable Computer Workstations for Engineering Teams

Ergonomic computer workstations have been designed to allow flexible office-seating arrangements among engineers or other workers in ways that promote the best levels of communication and collaboration.

(See page 74.)

Rolled-Up Ramp Deploys Itself on Command

A ramp originally designed for the Mars Pathfinder can be stowed as a compact cylinder and can be readily unfurled by its own spring force. The design can be adapted to serve as an emergency-exit ramp for buildings, land vehicles, and aircraft.

(See page 80.)

HITACHI

Versatile Eyes For Detail

KP-M SERIES

Black and White CCD Cameras

The Hitachi KP-M Series offers you a innovative selection of reliable, high performance, black and white cameras, one of which is ideal for your imaging application and budget. KP-M cameras are compact, lightweight, and fully functioned, with superb sensitivity and resolution. 2/3", 1/2", and 1/3" CCD sensors are available, as are right angle or separated head mounting construction. Built for exacting imaging applications, features include field or frame integration, external sync, electronic shutter, and asynchronous reset. All KP-M Series cameras can be provided in either EIA (525 lines/frame) or CCIR (625 lines/frame) format. Contact Hitachi for complete details on these and other models.



Request Your Free Demonstration

HITACHI

Hitachi Denshi America, Ltd.

• Atlanta 770-242-3636
• Chicago 630-250-8050

• Dallas 817-488-4528
• Los Angeles 310-328-6116

• New York 516-921-7200
• Canada 416-299-5900

TRUE
WORKSTATION
PERFORMANCE ...

... WITHOUT
THE RISC.



The Micron™ Powerdigm™

Workstation performance
you can really sink
your teeth into.



The Micron Powerdigm executes demanding business and technical tasks with command, and it's flexible enough to run popular PC programs.

Powerdigm supports 64 bit/66MHz PCI, dual monitors, dual Pentium II Processors, ultra-wide SCSI-3, and speedy 10/100 network adapters. And it features the revolutionary Samurai chipset designed and developed by Micron engineers. You'll see the results in graphic design, digital imaging, financial analysis, CAD and more.

Powerdigm is backed by our industry-leading Micron Power limited warranty and our unrivaled customer service and support. Ask about the Powerdigm today.

POWERDIGM XL

- Dual Intel 200MHz Pentium® Pro processors
- Samurai chipset
- 64MB EDO ECC RAM
- Number Nine Revolution 3D video card, 4MB WRAM
- 4GB Ultra Wide SCSI-3 hard drive
- 12/20X variable speed SCSI CD-ROM drive
- 19" Hitachi SuperScan CM751 (18" display) 26dp color monitor

\$4,899

Bus. lease \$167/mo.

POWERDIGM Xsu

- Dual Intel 300MHz Pentium II processors
- 64MB EDO ECC SDRAM
- Fire GL 1000 pro 8MB 66MHz PCI
- Open GL Professional 3D accelerators
- 4GB Ultra Wide SCSI-3 hard drive
- 12/20X variable speed SCSI CD-ROM drive
- 19" Hitachi SuperScan CM751 (18" display) 26dp color monitor

\$6,199

Bus. lease \$195/mo.

AVAILABLE POWERDIGM FEATURES & OPTIONS

- Supports IDE Ultra ATA and multiple Ultra Wide SCSI-3 hard drives
- Support for dual monitors
- DMI software and hardware management support
- Iomega Jaz SCSI drive with 1GB removable cartridge
- Wavetable stereo sound with speakers
- Microsoft® Intellimouse™
- Microsoft Windows NT® Workstation
- 5-year/3-year Micron Power™ limited warranty

Micron Sales Hours: Mon-Fri 9am-10pm, Sat 9am-5pm (MT) Technical Support Available 24 Hours A Day 7 Days A Week Tollfree from Mexico: 95-800-708-1755 Tollfree from Canada: 800-708-1755 • Tollfree from Puerto Rico: 800-708-1755 International Sales: 208-893-8970 International Fax: 208-893-7393



©1997 Micron Electronics, Inc. All rights reserved. Micron Electronics is not responsible for omissions or errors in typography or photography. All purchases are subject to availability. Prices and specifications may be changed without notice; prices do not include shipping and handling and any applicable taxes. 30-day money-back policy does not include return freight and original shipping/handling charges, applies only to Micron brand products and begins from date of shipment. All sales are subject to Micron Electronics' current terms and conditions of sale. Lease prices based on 36-month lease. The Intel Inside Logo and Pentium are registered trademarks and MMX is a trademark of Intel Corporation. Microsoft, Windows, Windows NT and the Windows logo are registered trademarks of Microsoft Corporation. All other service marks, trademarks and registered trademarks are the property of their respective companies.



888•669•0971
www.micronpc.com

For More Information Circle No. 511



Special Focus: Sensors/Imaging

Neural-Network Modules for High-Speed Image Processing

These modules would offer unprecedented computational power in small, low-power packages.

NASA's Jet Propulsion Laboratory, Pasadena, California

JPL has recently designed, fabricated, and demonstrated custom ICs for high-speed image processing. Derived from highly parallel computing architectures based on neural network models, these circuits are implemented with JPL-pioneered extremely low-power neuron and synapse circuit elements. Furthermore, their ultra-low power and high-speed characteristics are making it possible for the first time to integrate multiple chips in 3-dimensional (3-D) modules (sugarcube-sized chipstacks).

Denoted "neuromicroprocessing modules" (NPMs), these 3-D packaged devices would be capable of processing images at rates of the order of 10^{12} operations per second. The original NPMs are intended for military use for recognition of targets by comparison of features in infrared images with previously recorded images of known targets. Potential civilian applications for NPMs include artificial vision, speech recognition, and autonomous control for robots.


The NPMs offer unprecedented computing ability in small packages. They include novel high-speed analog circuits that can operate at temperatures from 77 to 350 K and consume little power. This combination of high computing speed, low power, and small size facilitates integration with other compact, low-power, high-speed circuitry with which NPMs would be required to interact.

A typical NPM would consist of 64 identical neuromicroprocessing chips and

would process the analog outputs (each containing 8 to 12 bits of information) from a 64×64 array of infrared photodetectors. Thus, for example, an NPM chip would include a 64×64 synaptic array plus a multistage crossbar switch, digital logic circuits, and input/output (I/O) pads (see figure). During each frame cycle, the image information embodied in the photodetector outputs would be compared with stored information on at least 64 known targets. The time needed for signals from the photodetectors to be processed by a 3-D neural network in an NPM would be about 200 ns; this would be short enough to enable processing of 1,000 image frames per second.

This work was done by Tuan Duong, Taher Daud, and Anil-kumar Thakoor of Caltech, and Chris

Sauders of Irvine Sensors Corp. for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Electronic Systems category, or circle no. 124 on the TSP Order Card in this issue to receive a copy by mail (\$5 charge). NPO-19881



A Typical NPM would be no larger than a sugar cube, yet it would contain integrated circuitry capable of processing the output of a 64×64 array of infrared photodetectors at a rate of 1,000 frames per second.

Reconstruction of Images From Circular-Scan Sensors

Images can be reconstructed faster than before.

NASA's Jet Propulsion Laboratory, Pasadena, California

An improved algorithm for reconstructing images from the outputs of circular-scan sensors has been devised. With relatively minor variations, the algorithm is applicable to data acquired by diverse circular-scan sensors (see Figure 1), including those of holographic synthetic-aperture radar (HSAR), x-

ray computer-aided tomography (CAT), magnetic-resonance imaging (MRI), positron-emission tomography (PET), and ultrasonic-reflectivity tomography (URT). It can even be applied to data acquired by sonar and seismic sensors.

One older algorithm of this type, known as the convolution back-projec-

tion algorithm, has been popular in computer-aided tomography because it offers superior image quality and ease of adaptation to fan-beam geometry. Another one, known as the direct Fourier algorithm, is highly efficient in computation, but it depends on the use of a Cartesian coordinate grid and,

Style and Purpose



RUGGED EXPANDABLE PORTABLE COMPUTERS

Dolch Rugged Portable Computers span the widest range of performance and expandability available anywhere in the industry. Designed to perform while surviving the harshest of environments, the PAC™, L-PAC™ and MegaPAC™ families offer multiple ISA/PCI expansion slots, configurable peripheral bays and a wide range of power supply and keyboard options. Dolch leads the industry with the only Pentium® II portable, ultra-bright anti-reflective flat-panel TFT screens and handsome functional style. Choose from the industry's broadest range of configurations to fit any application.

- ❑ **Add-In Card Expansion** from two ISA to five ISA/PCI or ten ISA/PCI, full length/full-height expansion slots.
- ❑ **Hi-Brightness Anti-Reflective** VGA, SVGA, XGA display screens in 10.4" and 12.1" sizes with RGB option.
- ❑ **Certified CPUs** from 486-100 to Pentium® 233 MMX to Pentium® Pro/Dual Pentium® Pro 200 to Pentium® II 266.
- ❑ **Waterproof Keyboard Option**, AC/DC and medical power supply options, special configurations and certification programs.



800.995.7580 — www.dolch.com

DOLCH COMPUTER SYSTEMS, INC. • 3178 LAURELVIEW COURT FREMONT, CA 94538 • TEL: 510 661 2220 • FAX 510.490.2360

For More Information Circle No. 512




Figure 1. Circular Scans with various sensors generate data that can be processed to reconstruct images of the scanned scenes. The algorithm described in the text can accommodate these and other sensors and variations of the basic circular scanning geometry.

therefore, its image quality depends on the interpolation subalgorithm used to transform the signal spectrum into the Cartesian coordinates. Moreover, the direct Fourier algorithm applies to parallel-beam CAT only.

The improved algorithm overcomes the limitations of the direct Fourier algo-

rithm and offers a computational efficiency between two and six times that of the convolution back-projection algorithm. Before images are formed, all computations are performed in polar coordinates. Polar-to-Cartesian transformation is finally applied to the reconstructed image for image display purpose. Based on the circular symmetry, this algorithm performs fast Fourier correlation in the azimuth dimension.

The reference functions used in the improved algorithm are the amplitude-weighted two-dimensional spectra of the point-target responses (PTRs). [A PTR can be regarded as an extended or "blurred" version of a conventional point-spread function (PSF). The PTR is the PSF-blurred-curved-line response obtained from a point target imaged by a wide-beam circular-scan system like HSAR.] A reference function is updated for each range bin to achieve exact focusing. By choosing proper weighting functions, this algorithm is capable of generating an ideal PSF like that predicted for Fraunhofer diffraction by a

circular aperture (see Figure 2). Further shaping of the PSF can be achieved by use of extra weighting. The high computational efficiency of this algorithm is attributable to the characteristics of the two-dimensional spectrum of the PTR.

This work was done by Michael Y. Jin of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) **free online** at www.nasatech.com under the Mathematics and Information Sciences category, or **circle no. 158** on the TSP Order Card in this issue to receive a copy by mail (\$5 charge).

In accordance with Public Law 96-517, the contractor has elected to retain title to this invention. Inquiries concerning rights for its commercial use should be addressed to

Technology Reporting Office
JPL

Mail Stop 122-116
4800 Oak Grove Drive
Pasadena, CA 91109
(818) 354-2240

Refer to NPO-19559, volume and number of this NASA Tech Briefs issue, and the page number.





Figure 2. This Image of a Point Target was generated by applying the improved algorithm in a computer simulation of HSAR or URT, using a pulse with a bandwidth of $0.133 \times$ its carrier frequency. The PSF in this image exactly follows that of Fraunhofer diffraction by a ring aperture.

Watlow Gordon Temperature Sensors Are Built To Take It.


(Whatever "It" May Be.)



"It" may be fast changes in pressure. Vibration. Or extreme temperature ranges. Whatever "it" may be, the sensor must work.

At Watlow Gordon, we design our sensors for reliability in all types of hostile applications.

We engineered the two-element exhaust gas temperature sensor to measure jet engine wear, power and fuel efficiency; each sensor junction rigorously tested for operation at temperatures from -54°C to 1105°C.



Or how about the rugged sensor construction required to handle the vibration and high temperatures of a 3000hp diesel engine, plus waterproofing to withstand hosedown. All of this in an open pit mining environment.

We offer fast prototyping. Our lab services are extensive, including metallurgical examination, microhardness testing and SPC. And we produce our own wire for the sensor assemblies in our ISO9002 registered wire factory.

When lives are at stake. When dollars could be lost. When the project must finish on time. You need the reliability of a Watlow Gordon sensor. Call us. We go to extremes in temperature sensing. 1-800-WATLOW2 (1-800-928-5692)



**WATLOW
GORDON**
www.watlow.com



Advanced X-Ray Imaging Spectrometer

Increases in sensitivity and resolution are made possible by development of improved detectors used in conjunction with a coded aperture.


NASA's Jet Propulsion Laboratory, Pasadena, California

An advanced x-ray imaging spectrometer (AXIS) with electronic readout features high sensitivity with high spatial and spectral resolution. Prior to this innovation, to perform x-ray imaging and x-ray spectroscopy, it has been necessary to use separate instruments, so that it has been difficult or impossible to associate x-ray spectra with x-ray image features. Furthermore, prior photographic-film and electronic x-ray-imaging instruments have yielded poor spatial resolution and required long exposure times (because of low sensitivity). Offering a capability for sensitive, high-resolution imaging with fine spectroscopy within each pixel, the AXIS opens new possibilities for x-ray observations in astrophysics, laboratory microscopy, industrial inspection, and medicine.

The image plane in the AXIS consists of electronic circuitry in a 1,024-by-1,024 array of pixels containing x-ray photodetectors and on-pixel readout circuits. The detector array is made from high-purity, deeply depleted silicon. The deeply-depleted characteristic results in high sensitivity to x rays at photon energies up through 40 keV. The use of high-purity silicon with on-pixel circuitry results in low leakage current and low noise, enabling fine spectroscopy at or near room temperature. In circuitry outside the image plane, the outputs of the on-pixel preamplifiers are further amplified, then digitized.

To achieve high spatial resolution for

imaging, it is necessary to modulate the incoming x rays. For this purpose, the x rays pass through coded aperture (see figure). The coded aperture is fabricated from gold using semiconductor-pro-



Coded Aperture spatially modulates the incident x rays. The aperture pattern is designed so that the resulting pattern of x-ray intensity on the image plane can be deconvolved to extract an image of the x-ray source.

cessing techniques. [Such use of coded apertures to produce spatial modulation for imaging was described previously in "Gamma-Ray Imager With High Spatial and Spectral Resolution" (NPO-19140), *NASA Tech Briefs*, Vol. 20, No. 2 (February 1996), page 49 and "Gamma-

Ray Imaging With Two-Dimensionally-Coded Apertures" (NPO-19331), *NASA Tech Briefs*, Vol. 20, No. 11 (November 1996), page 4a.] The digitized pixel outputs are sent to a computer. Using a deconvolution algorithm based on the known geometric relationships among the x-ray source, the coded aperture, and pixels, the computer reconstructs an image of the x-ray source from the digitized detector pixel outputs with a spectrum associated with each image pixel. The spatial resolution of the image can be increased (trading field of view) by increasing the distance, L , between the aperture plate and the image plane.

This work was done by John L. Callas and George A. Soli of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Physical Sciences category, or circle no. 188 on the TSP Order Card in this issue to receive a copy by mail (\$5 charge).

In accordance with Public Law 96-517, the contractor has elected to retain title to this invention. Inquiries concerning rights for its commercial use should be addressed to

Technology Reporting Office

JPL

Mail Stop 122-116
4800 Oak Grove Drive
Pasadena, CA 91109
(818) 354-2240

Refer to NPO-19663, volume and number of this NASA Tech Briefs issue, and the page number.



Digital Video System Images Damaged Gears During Operation

The progression of damage can be documented more quickly, thoroughly, and easily.

Lewis Research Center, Cleveland, Ohio

A high-speed digital video imaging system captures still images of individual teeth on gears meshing at high speed on a gear-test rig. Each gear-tooth image documents the progression of the wear, pitting, spalling, and fractures that lead to overall gear failure. Heretofore, images documenting gear failure were acquired only during post-test analysis and thus did not provide real-time study of the degradation that leads to failure. The high-speed digital imaging system is integrated with another system that measures vibrations and processes the mea-

surements to detect indications of damage. Analysis of the gear-tooth images coupled with vibrational data acquired at the same time should make it possible to better classify vibrational signatures according to types and degrees of damage and to improve understanding of the events that lead to failure.

The imaging system (see figure) includes a digital video camera aimed at passing gear teeth. The system is located in a darkened room. Illumination is provided by a fiber-optic-coupled stroboscope with a 5- μ s pulse duration,

which is brief enough to capture images without noticeable blur at typical gear speeds. A magnetic probe senses the rotation of the gear and generates a once-per-revolution pulse. A shaft-angle-encoder circuit divides the once-per-revolution pulses into pulses at smaller intervals corresponding to the passage of individual gear teeth in front of the camera. A frequency divider processes the gear-tooth-passage pulses into stroboscope-trigger pulses at intervals long enough to ensure that only one flash occurs during the camera

FOR EVERY SENSING CHALLENGE, THERE'S A SUNX SOLUTION

**EX-10 SUPER-SLIM
PHOTOELECTRIC SENSORS.**

Save space with self-contained output and direct PLC interface. A 500mm sensing range and a Waterproof IP67 enclosure combine for big-time performance in a 3.5mm thick unit.

**CX-20 COMPACT-SIZE
PHOTOELECTRIC SENSORS.**

Though 20% smaller than comparable units, the CX series offers a 10m sensing range and transparent object detection. Ideal for all presence-sensing applications.

**PM SERIES
LIMITED-DISTANCE, DIFFUSE
AND SLOT-TYPE
MICROPHOTO SENSORS.**

Self-contained unit detects dark pieces and microscopic objects. Operation is not influenced by background or object color.

**CY CYLINDRICAL
PHOTOELECTRONIC SENSORS.**

Small and compact, these Waterproof IP67 sensors are ideal for specular, opaque, translucent, and transparent object-detection applications.

GXL INDUCTIVE PROXIMITY SENSORS.

Built-in amplifier saves space. Provides reliable performance for counting and positioning applications.

**COMPACT SIZE
HIGH RELIABILITY
LONG-RANGE SENSING
COST-EFFECTIVE
EASY INSTALLATION**

FX-7 FIBER OPTIC SENSORS.

On/off push button tuning simplifies sensitivity setup. Resolution 8x higher than comparable models.

LA-511 LASER BEAM SENSOR.

Laser beam alignment is simple with on-board alignment monitor. Provides both analog and digital output. Class I type.

S-LINK SENSOR AND WIRE-SAVING LINK SYSTEM.


Operate up to 128 I/O devices on a 4-wire bus. Connects directly to all PLC brands.

Pioneer in Sensor Systems
SUNX


To learn more about these SUNX products,
please call **1-800-280-6933**
for free literature.

P.O. Box 65310 ■ 1207 Maple Street ■ West Des Moines, IA 50265 ■ 1-800-280-6933 ■ FAX (515) 225-0063

For More Information Circle No. 570



TYPICAL IMAGE SHOWING DAMAGED GEAR TEETH



The High-Speed Digital Video Imaging System captures still images of gears meshing at high speed. The system will aid studies of gear damage and the development of techniques for vibration monitoring to detect incipient damage. In comparison with film-based photographic imaging systems, this system provides for easier viewing and storage of data; it gives immediate visual feedback and there is no need for costly and time-consuming film processing.

integration time of 1/30 second.

The imaging system operates automatically, under control by a computer that runs special-purpose software. Each time the computer in the vibration-measuring system determines that vibrations have exceeded a threshold level, it signals the computer in the imaging system to begin a sequence of operations to acquire images of gear teeth. For each tooth, the camera is turned on for its integration time; during that time, at the instant when the designated tooth passes in front of the camera, the stroboscope is flashed to produce a single-exposure still image of the tooth. The images are stored in the frame-grabber memory. This process is repeated until images for all the gear teeth have been acquired, then they are transferred to a hard disk in the computer. The computer then resets, and

the system awaits the next signal from the vibration-measuring system.

This imaging system is potentially adaptable to numerous other applications in which there are requirements for automatic acquisition of images of moving objects or of events that manifest themselves only during rapid motion. Examples of potential uses include the following:

- Inspection during bottling processes to verify fill levels and capping;
- Detection of improperly mounted or missing electronic components or detection of missing automotive components during manufacturing operations;
- Detection of stamps and preliminary sorting in postal operations;
- In banking, tracking bundles of checks and detecting checks out of order, and/or identifying stacks of money short in their amounts;

- In printing, imaging the product to detect defects without shutting down for false alarms; and
- Inspecting power-generation and manufacturing machinery during operation to identify troubles that cannot be seen when the equipment is shut down.

This work was done by James J. Sims and Howard Broughton of Cortez III Service Corp. for Lewis Research Center. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Electronic Systems category, or circle no. 175 on the TSP Order Card in this issue to receive a copy by mail (\$5 charge).

Inquiries concerning rights for the commercial use of this invention should be addressed to NASA Lewis Research Center, Commercial Technology Office, Attn: Tech Brief Patent Status, Mail Stop 7-3, 21000 Brookpark Road, Cleveland, Ohio 44135. Refer to LEW-16345.

Image-Analysis System Tracks Objects


A tedious manual image-analysis process has been automated.

Lewis Research Center, Cleveland, Ohio

A personal-computer-based image-processing system digitizes video or film images and then performs various forms of motion analysis by tracking objects and/or features. The system

was designed specifically for analysis of the types of images found in micro-gravity combustion and fluid experiments; the object and/or features to be tracked can include flame fronts, parti-

cles, droplets, and fluid interfaces. Since this is not a real-time tracking system but a post-analysis tracking system, the image sequences to be analyzed have been previously recorded on a



Cole-Parmer® Instrument Company

Serving the Research &
Technical communities worldwide

When you order from Cole-Parmer you receive quality products along with complete Sales, Applications, and Customer Satisfaction service. . . . and much more! We now offer extended hours, a NEW Web site, and enhanced Applications Service.

The Cole-Parmer catalog gives you a selection of more than 32,000 products for Research, Industry, and Education. . .

. . . and it's FREE!

The Cole-Parmer catalog also serves as a convenient resource—it includes technical information, conversion tables, and chemical resistance charts.

Here's how to receive your FREE 1997-1998 Cole-Parmer catalog:

- Fax back the coupon at left
- Or call our literature hotline at (800) 443-3434
- Or e-mail us at catalog@coleparmer.com
- Or visit our NEW Web site at <http://www.coleparmer.com>

For More Information Circle No. 513



**Cole-Parmer®
Instrument Company**

625 East Bunker Court

Vernon Hills, Illinois 60061-1844

We cater to your original equipment manufacturer (OEM) requirements by offering custom design and private label on many of our products. Call (800) 323-4340, extension 9-6092 for more information on our OEM services.

Fax this coupon to us at (847) 549-7676 to receive your FREE 1997-1998 Cole-Parmer Catalog!

Name: _____

Title/Mail Stop: _____

Company: _____

Address: _____

City: _____

State: _____ Zip: _____

Phone: _____ Fax: _____

Still

The World's First Miniature Fiber Optic Spectrometer



**First in innovation.
First in performance.
First in affordability.**

**Low-cost Custom Systems
for UV, VIS and
Shortwave NIR Applications**

- High sensitivity
- Remarkable flexibility
- Modular hardware and software
- Unmatched applications support

**Our newest innovation is here!
Ask about the high-sensitivity
\$2000 spectrometer
for low light level applications!**



Ocean Optics, Inc.

Tel: (813) 733-2447

Fax: (813) 733-3962

E-Mail: info@OceanOptics.com

www.OceanOptics.com


Ocean Optics Europe

Tel: 31-313-651-978

Fax: 31-313-655-783

E-Mail: 73131.150@compuserve.com

For More Information Circle No. 420



The Computer Analyzes Image Data from any of several playback units, which it controls. Special-purpose software tracks moving objects and/or features in video or photographic image frames.

standard photographic movie film or video tape. Digital image input in the form of image files can be also accepted. The system automates what has previously been a tedious, time-consuming image-analysis process in which a technician or a scientist visually examined and manually took measurements directly from a displayed image, repeating this process until all the image frames were analyzed.

The system (see figure) consists of individual hardware components working under computer control to achieve a high degree of automation. The most important hardware components include 16-mm and 35-mm film transports, a high-resolution digital camera mounted on a *x-y-z* micropositioning stage, an S-VHS tape deck, a Hi8 tape deck, a video laserdisk, and a framegrabber. All of the image-input devices are remotely controlled by a computer. Software, called Tracker was developed to integrate the overall operation of the system, including device frame incrementation, grabbing of image frames, image processing of the object's neighborhood, locating the position of the object being tracked, and storing the coordinates to a file. This process is performed repeatedly and automatically until the last frame is reached. Several different tracking methods are sup-

ported, including threshold reduction, template matching, and a spline-based active contour model method. The types of data obtained from Tracker are positions, velocities, area measurements, centroids, object outlines and shapes, time sequences of line profiles, 3-d areas, intensity and color characteristics, and size measurements, all as a function of time. The data are presented in a format ready for graphing or further analysis via other packages.

Optionally, the system can be operated in a semiautomatic mode, in which the user manually locates an object by using a mouse to move a crosshair on the display. All other steps are performed as in the automatic mode.

This work was done by Robert B. Klimek and Ted W. Wright of Lewis Research Center and Robert S. Sielken of Trinity University. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Electronic Systems category, or circle no. 167 on the TSP Order Card in this issue to receive a copy by mail (\$5 charge).

Inquiries concerning rights for the commercial use of this invention should be addressed to NASA Lewis Research Center, Commercial Technology Office, Attn: Tech Brief Patent Status, Mail Stop 7-3, 21000 Brookpark Road, Cleveland, Ohio 44135. Refer to LEW-16420.

Swept-Frequency Fiber-Optic Readout From Multiple Sensors

Readouts from individual sensors are distinguished by frequency rather than by pulse-travel time.

NASA's Jet Propulsion Laboratory, Pasadena, California

A technique of frequency-domain reflectometry has been devised for obtaining readouts from multiple sensor transducers that (a) reflect light to degrees indicative of quantities that one seeks to measure and (b) are connected to, and located at various positions along, an optical fiber. In this technique, a beam of light that interrogates the sensors is amplitude-modulated at a radio frequency that is swept linearly. The beam is launched into the fiber from an input end, travels to the various transducers, and is reflected back to the input end (see figure). As explained in more detail below, the modulation in the light reflected back to the input end can be decomposed into frequency components — a separate frequency component associated with each transducer — and the amplitude of each component can be taken as an indication of the quantity sensed by the corresponding transducer.

This technique offers advantages over time-domain reflectometry as applied to such an array of sensors. In time-domain reflectometry, one would interrogate the transducers by use of a pulsed beam of light in order to distinguish the returns from the individual transducers in terms of their individual round-trip pulse-travel times. The pulses would have to be short enough and the sensors would have to be located far enough apart, consistent with the pulse duration, so that pulses returned from different sensors did not overlap. Thus, time-domain

reflectometry would entail restrictions on both the placement of transducers and on pulse durations. Shorter pulses contain less energy than do longer pulses and thus necessitate longer signal-averaging times to obtain adequate measurement sensitivity at low signal levels. Long averaging times are not acceptable in many systems in which real-time or near-real-time responses are required; for example, in process-control applications. In the present swept-frequency technique, the minimum acceptable distance between sensors is much less than in time-domain reflectometry. Moreover, the averaging time needed to achieve a given level of sensitivity is less than in time-domain reflectometry.

Suppose that the interrogating beam of light is amplitude-modulated by a sinusoid of swept angular frequency $\omega(t) = \omega_0 + \alpha t$, where t is time as measured from the beginning of the frequency sweep, ω_0 is the initial angular frequency, and α is the frequency-sweep rate. Suppose that the light reflected back to the input end of the optical fiber is fed to a photodetector, the output of the photodetector is mixed with a replica of the modulating sinusoid, and the output of the mixer is low-pass-filtered so as to retain only the difference-frequency mixer output. It can be shown that the resulting output signal is given by

$$S_{\text{out}}(t) = \sum_{n=1}^N B_n \cos[\tau_n(\omega_0 + \alpha t)]$$

where B_n is proportional to the amplitude of the reflection from the n th sensor and τ_n is the round-trip propagation time for the optical signal traveling from the input end to the n th sensor and back to the input end.

Thus, the output-signal component representing the reflection from the n th sensor is a sinusoid of amplitude B_n and frequency $\alpha\tau_n$. By taking the Fourier transform of $S_{\text{out}}(t)$, one can obtain its frequency spectrum and thereby extract the amplitude of the reflection from each sensor. Incidentally, the measured frequency of each component can be used to refine the estimate of the round-trip propagation delay for each sensor.


This work was done by George F. Lutes and Xiaotian S. Yao of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Electronic Systems category, or circle no. 192 on the TSP Order Card in this issue to receive a copy by mail (\$5 charge).

In accordance with Public Law 96-517, the contractor has elected to retain title to this invention. Inquiries concerning rights for its commercial use should be addressed to Technology Reporting Office

JPL

*Mail Stop 122-116
4800 Oak Grove Drive
Pasadena, CA 91109
(818) 354-2240*

Refer to NPO-19725, volume and number of this NASA Tech Briefs issue, and the page number.



The Propagation Delays of the Reflections from the various sensors along the optical fiber result in differences between the phase of swept-frequency modulating signal and the phases of the modulations in the reflections. These phase differences are accompanied by frequency differences that can be exploited to identify and measure reflections from individual sensors.



Sensors/Imaging



SICK Optic-Electronic, Eden Prairie, MN, offers a line of **inductive sensors** that includes inductive proximity, magnetic proximity, and magnetic cylinder sensors featuring noncontact operation. The inductive proximity sensors, designed to detect metallic objects, come in shielded and non-shielded versions with shielded maximum sensing ranges to 15 mm and non-shielded ranges to 60 mm. Housings in ABS plastic, brass, and stainless steel come in threaded cylinder, smooth barrel, or cubical shapes.

The magnetic proximity sensors, in brass or plastic housings, offer sensing distances to 70 mm and can detect magnetic objects through non-magnetizable materials. Magnetic cylinder sensors are designed for position sensing in pneumatic cylinders. Fully electronic, they detect any magnetic ring in the piston through aluminum, brass, or stainless steel housing walls.

For More Information Circle No. 736



The OG Series **photoelectric sensors** from efector, Exton, PA, feature automatic micro-processor setup in an 18-mm body size. The sensors are available with an infrared LED or laser diode light source. Infrared LED units are available as thru-beam pairs, as retroreflective sensors with polarizing filters, and as diffuse reflective models; laser models are available in three thru-beam versions, two retroreflective versions, and a diffuse reflective version.

The sensor bodies are molded as single units, including windows for LEDs and pushbuttons. They feature a variety of ranges and minimum target sizes and are available as three-wire DC units.

Installation and alignment of the sensors is achieved with a mounting bracket and right-angle mirror adapter.

For More Information Circle No. 733



The Series 200 wire-wound **RTD temperature sensors and transmitters** from Burns Engineering, Minnetonka, MN, is available with Windows-based software that allows the user to configure their own RTD assembly. The wire-wound design features a coil suspension construction technique in which the element is coil-wound with platinum wire to minimize stress.

Each coil is suspended in a high-purity ceramic insulator and surrounded by a ceramic powder for shock and vibration resistance without affecting the coil's ability to expand and contract. A proprietary method is used to form the metallurgical bond between the element leads and the internal sheath leads.

For More Information Circle No. 730



The CRX-3D microtomography **x-ray inspection system** from CR Technology, Laguna Niguel, CA, generates slice-by-slice 3D images of integrated circuits, components, hybrids, and other devices, bringing out hidden properties or defects. Faults detected include miswires, opens, shorts, and voids in flip chip, fine pitch, and BGA packages. The x-ray sources offer levels to 160 Kev and focal spot sizes less than 2 microns.

The system's holding fixture rotates the component through 360° while the imaging camera takes individual video frames. The software then uses the digitized images to reconstruct the interior of the component and allows the user to view it from multiple perspectives. The system comes with a tomographic indexing stage, image processing computer, and a 17" SVGA monitor.

For More Information Circle No. 726



DEA-Brown & Sharpe, North Kingstown, RI, offers the VENTO high-speed direct computer-control **horizontal-arm measuring machine** that performs dimensional inspection of thin-walled parts such as automobile parts and subassemblies; dimensional inspection of prismatic parts; automatic and manual verification of freeform surfaces; continuous scanning operations for die and mold copying; and marking-out operations.

It has a measuring range of: X-axis 3000 to 12,000 mm; Y-axis 1400 to 1600 mm; and Z-axis 2000 to 2400 mm. Dual opposing machines can work together to cover larger areas. The machine is available in console and runway configurations. It can be equipped with PC-DMIS™ for Windows geometric measurement software, and comes with various electronic touch trigger and analog probes, heads, and automatic probe changers.

For More Information Circle No. 729



The Schaevitz™ **LVIT-Z linear variable inductance transducer** from Lucas Control Systems, Hampton, VA, were designed for applications with limited space and can be configured for a variety of linear measurement applications. The transducer features accuracy of $\pm 0.5\%$ non-linearity over the full stroke.

It integrates the sensor with the conditioning electronics on the same board for unit-to-unit interchangeability.

The unit features DC in-DC out, ratiometric, unipolar or bipolar outputs, and a duty cycle output for direct interface with micro-processor controllers. Output can be scaled to 90% of the input voltage. The transducer can be configured and packaged to customer requirements.

For More Information Circle No. 735



Door Lock Switch



NEMA 4 Photoelectric



Capacitive Prox

For Your Particular Sensor Solution, Look To The World Leader In Sensor Technology.

Take the trial and error out of finding the right sensor. Omron offers you the widest selection, spends more

SmartFactory on R&D than anybody, and

supports you with application assistance that's second to none.

Look to us for:

- Sensor solutions from experienced application engineers
- Innovative products that solve tough problems
- Widest selection to meet each of your application needs
- On-site demos that let you test different solutions
- Products available worldwide to support manufacturing consistency
- Commitment to R & D that delivers a steady stream of new solutions
- For specifications on any Omron sensor, call *ControlFax* at 847.843.1963 and request directory document #50



Threaded Photoelectric



Linear Contact Sensor



RF ID Tags



Plug-in Enclosed Switch



Miniature Photoelectrics



2-Wire DC Prox Sensors



Displacement Sensor



RF ID Controller System



Compact Limit Switch



Metal Body Photoelectric



Teflon Capacitive Prox



Machine Vision System



Flat Capacitive Prox



Rotary Encoder



Interlock Switch



Miniature Inductive Prox



Inductive Ring Proxes



Fiber-optic Amplifier



Block Style Prox



Ultrasonic Displacement Sensor



Prox Detects All Metals

1-800-55-OMRON

ASK FOR OUR SENSOR GUIDEBOOK.
IT'S FREE.

OMRON
WE HAVE THE FUTURE IN CONTROL


For More Information Circle No. 514



Cambridge AccuSense, Shirley, MA, has announced the AVS-Universal Series **thermistor-based transducers** that measure ultra-low air velocities covering a range from 0-100 fpm full scale to 0-1000 fpm. The output is linear with velocity. The transducers feature a standard response time of about 100 ms, accuracy of $\pm 3\%$ of full scale at room temperature, and solid-state construction.

A bi-directional version provides a positive or negative reading, depending on airflow direction. The unit is powered by 12-24V DC or AC, with output choices of 0-5V, 0-10V, or 4-20mA. Mounting hardware is included, and the units are housed in black, anodized aluminum with a 12.5" stainless steel probe.

For More Information Circle No. 731



VisionBlox 2.1 **machine vision software** from Integral Vision, Farmington Hills, MI, features optical character verification and polar unwrap tools. The software is added into Microsoft's Visual Basic or Visual C++ programming environments, and allows users to

acquire and grab live images with only two lines of code. The 32-bit software can be paired with a PCI frame grabber for image processing.

The program includes a Read Tool that verifies properly printed text in an image and an Unwrap Tool that unwraps a donut-shaped region of an image so the software can perform character verification or recognition.

For More Information Circle No. 728



Cherry Electrical Products, Waukegan, IL, has introduced the HE-6150/6151/6152/6154 Hall Effect **gear-tooth sensor modules** that directly sense rotating ferrous gear-type targets such as power transmission gears and gear-based shaft encoders. They can sense a range of tooth sizes and airgaps, and are small enough to be used in space-constrained applications.

The modules deliver a digital output signal and do not require additional signal processing or external electronics. They are designed for installation with the major axis of the module perpendicular to the direction of target rotation. The HE-6154 can be mounted with any degree of rotation about its major axis; the other modules include provisions for mounting at the preferred angle.

For More Information Circle No. 732



Cognex Corp., Natick, MA, offers the Cognex 8000 Series™ **machine vision system** that features PatMax™ image analysis software. The 8000 Series hardware platforms plug directly into the PCI bus of standard Pentium MMX™ computers. The series includes products ranging from the 8100 basic

model to the 8400, which incorporates a digital signal processor.

The PatMax software locates and inspects objects, features, and wafer and die patterns that change the way machine vision systems work. It can detect if pieces of the image are missing or if there are extraneous pieces present. For semiconductor and electronics applications, the software can locate and align 300-mm semiconductor wafers before probing, metrology, inspection, and bonding.

For More Information Circle No. 727



Banner Engineering Corp., Minneapolis, MN, has introduced the Q45U Series **ultrasonic sensors** that are available in switched (digital) or analog versions. The 12-24V dc piezoelectric units feature microprocessor-controlled, pushbutton setup of sensing

limits from 100 to 1400 mm. A long-range model allows sensing from 25 to 390 mm.

LEDs continuously display programming and operating status, as well as the relative position of the target within the sensing window. Program storage cards allow window limit programs to be set and stored on circuit cards that slide into the units. The sensors can be wired directly to an external switch, controller, or computer to set window limits. Parallel microprocessors provide immunity to electrical and acoustic noise.

For More Information Circle No. 725



Gordon Products, Brookfield, CT, has introduced the Model PC150 and PCA150 flat pack **capacitive sensors** that generate a low-power capacitive field to detect any material with a dielectric constant higher than 1 (air). They feature a 5.75" square internal sensing element, which allows detection of low-density materials.

Both models are provided in a shielded housing for mounting on grounded metal surfaces.

The Model PC150 has both NPN and PNP, switched outputs, and is available in a normally open or normally closed configuration. The PCA150 has an analog output that delivers a linear DC voltage of 1-6 VDC that varies in proportion to target capacity. Both models feature operating voltage of 10-30 VDC with operating current of 12mA.

For More Information Circle No. 734



We've Taken Dynamic Measurements To An All-Time Low.

It takes a very sensitive accelerometer to measure something that hardly seems to be moving.

Fortunately Endevco accelerometers have the accuracy and resolution you need—even if you're working in the micro-g range or at 0 Hz.

We're the only supplier with a complete array of advanced sensing technologies. So you're assured a perfect solution to address your specific measurement requirements. Yet for all their sensitivity at low vibration levels and frequencies, these units need no special handling. We even have models for extreme temperatures from -55°C to $+288^{\circ}\text{C}$. So these sensors keep working when others would fail.

And for every Endevco accelerometer there's an ideal signal conditioner and low-noise cable to match—for a complete turnkey solution.

So don't lower your standards by using lesser accelerometers. Call Endevco today. It's the best way to get your project moving.



Request a free copy of our Short Form Catalog today to find the right Endevco solution for you. Call 1-800-983-6732 or e-mail freebie@endevco.com.



7754-1000 ISOTRON® Accelerometer.
This rugged sensor has the exceptional resolution to detect less than 1 micro-g and flat down to 0.05 Hz.



7290A Accelerometer.
Ideal for low-level accelerations from 2g to 100g full scale. Offers dc response, ruggedness to 10,000g's, amplified ($\pm 2\text{V}$) output and a wide temperature range.



752-500 ISOTRON® Accelerometer.
This tiny accelerometer offers outstanding sensitivity of 0.5 V/g and comes in a hermetic package that weighs just 10 grams.



4430A Signal Conditioner.
This versatile, high-precision amplifier may be computer controlled and offers programmable filters, current, voltage and gain adjustments.

CERTIFIED
ISO 9001



MEGGITT

30700 Rancho Viejo Road, San Juan Capistrano, CA 92675 USA
Phone (800) 982-6732 Fax (714) 661-7231

Visit our website at <http://www.endevco.com>

ENDEVCO





▶ GaAs-JFET-Based Multiplexers for Readout of VLWIR Detectors

A prototype circuit has functioned properly at a temperature of 4 K.

NASA's Jet Propulsion Laboratory, Pasadena, California


Integrated-circuit multiplexers based on gallium arsenide junction field-effect transistors (GaAs JFETs) are undergoing development for use in reading out signals from arrays of very-long-wavelength infrared (VLWIR) detectors. To minimize thermally induced electronic noise, electromagnetic interference, and microphonics in future infrared-sensing instruments, it will be necessary to eliminate long connecting wires between infrared detectors located on cold heads and readout circuits located in warmer compartments; to do this, one must place the readout circuits in immediate contact with the infrared detectors at the detector-operating temperatures, which are typically <10 K. To be suitable for VLWIR-detector applications, readout circuits must not only be capable of operating at low temperatures but must also feature low noise, moderately low input capacitances, very low input bias currents, and low power dissipation.

The selection of GaAs-JFET-based integrated circuits for these purposes was prompted by the following considerations:

- The performances of bipolar-silicon-transistor circuits and silicon-JFET circuits at such low temperatures are severely degraded by charge-carrier freezeout. Silicon metal oxide/semiconductor field-effect transistor (MOSFET) circuits can operate at temperatures of a few K, but at these temperatures, they exhibit excessive noise and other undesired characteristics.
- Discrete GaAs JFETs had previously been found to perform well at 4 K.

N-channel GaAs JFETs and associated circuit elements designed especially for cryogenic operation can be made immune to charge-carrier freezeout. The fabrication of these devices includes

the use of highly isotropic HF:H₂O₂:H₂O etchants in an etch-back technique for definition of gates and isolation of mesas. The isotropy of the etch eliminates sharp edges, thereby reducing edge electric fields, with consequent reductions in gate leakage currents.



This Abbreviated Schematic Diagram illustrates one of eight cells, plus common column circuitry common to all eight cells, of a prototype circuit for reading out an 8 × 1 array of VLWIR detectors.

A prototype GaAs-JFET-based integrated-circuit multiplexer for readout of an 8 × 1 linear array of VLWIR detectors was designed and fabricated. Each cell of this circuit (see figure) corresponds to one pixel and its VLWIR detector. In use, the pad marked "Q_n" would be connected to the VLWIR

detector. As the detector integrated photogenerated electric charge, the voltage on the detector would change, and this voltage (the input voltage) would be applied to the gate of the source-follower JFET. The common load transistor at the bottom of the column would be biased at gate potential V_{LN} to form a current source. When clock potential ϕ_{sel} went high, the pixel-selecting transistor in the affected pixel would turn on, connecting the pixel source-follower JFET to the current source via the common column bus; the resultant voltage on the bus would equal the input voltage plus a fixed offset voltage. The pixel would then be reset by use of fixed reset potential V_{RST} under control by clock potential ϕ_{RST} . The foregoing process would be repeated, clocking through each of the eight pixels in turn, to sequentially read out all eight detectors.

In a preliminary test at 4 K without any detectors attached, the prototype circuit functioned properly and satisfied the requirements for low noise, low input bias current (as a result of low gate leakage), and low power dissipation. The leakage current was found to be <1 fA. When the circuit was biased at a common load current of 10 μ A, the low-frequency noise was dominated by a component proportional to the reciprocal of frequency (1/f noise) and was of the order of 1 μ V/Hz^{1/2} at a frequency of 1 Hz.

This work was done by Thomas Cunningham and Mike Fitzsimmons of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Electronic Components and Circuits category, or circle no. 103 on the TSP Order Card in this issue to receive a copy by mail (\$5 charge).
NPO-20096

**6 billion miles
out. There's no
acceptable
failure rate.**

**That's why
Teledyne
Relays is here.**

*The Preeminent Supplier of
High Reliability Relays*



12525 Daphne Avenue, Hawthorne, CA 90250
1-800-896-8904 • FAX: 213-779-9161 • <http://www.teledynereleys.com>

A business unit of Teledyne Electronic Technologies and Allegheny Teledyne
An ISO 9001 company

For More Information Circle No. 517

Communications Satellites

Globalstar
Pan Am Sat
Asian Cellular Satellite (AcES)
Echo Star
Skynet IV
Global Positioning Satellite
Milstar

Earth Observation/ Weather Satellites

Advanced Earth Observation
Satellite (ADEOS)
Earth Observation Satellite (EOS)
Geostationary Operational
Environmental Satellite (GOES)

Deep Space Probes

Galileo
Voyager
Cassini
Mars Global Surveyor
Mars Pathfinder, Sojourner
Hubble

Launch Vehicles

Ariane IV
Delta IV
Titan

Manned Programs

Shuttle
Sky Lab
Space Station



▶ Electronically Switchable Bragg Gratings (ESBGs)

A new microdroplet liquid crystal/polymer composite material offers high efficiency, switchable holograms for laser beam steering, dynamic focus lenses, and control of fiber optic signals.

Foster-Miller, Inc., Waltham, MA

The use of holograms, Bragg gratings, and diffractive optical elements is extensive in photonic systems of all kinds, including displays, spectrographic instruments, optical interconnects, and optical fiber communications links. A new materials technology now permits high-quality Bragg holograms to be realized in an

electronically switchable form, transforming passive holograms into active switches. A wide variety of novel applications is emerging.

The new material, a holographic polymer/liquid crystal composite, was invented at the USAF Wright Laboratory by employees of Science Applications

International Corporation (SAIC), originally for the purpose of protecting pilots from laser beams. The Foster-Miller Photonics Division, under the support of a NASA SBIR program monitored by Marshall Space Flight Center (solicitation year 1993), has worked closely with SAIC and the Air Force to apply this material for a variety of commercially promising purposes, including switchable focus lenses and fiber optic switches and filters.

In the ESBG process shown in Figure 1, a volume hologram is recorded by polymerizing a photosensitive liquid solution of seven ingredients including liquid crystal, prepolymer, solvents, and photoinitiators by exposure to interfering blue-green laser beams. This results in a permanent, high-diffraction-efficiency photopolymer Bragg grating, whose microstructure is formed by alternating layers of spatially distributed ≈ 30 -nm liquid crystal droplets interspersed with pure polymer. Transmission gratings with periods of $0.4 \mu\text{m}$ or less can easily be recorded, resulting in large diffraction angles for visible/near-IR wavelengths. Initially, the liquid crystal directors inside each slightly elongated droplet are aligned along the long axis. By applying an electric field to the film, the liquid crystal directors can be rotated inside the droplets, varying their effective refractive index, until the polymer host index is exactly matched. Then the grating effectively vanishes, turning the Bragg diffraction off, and making the previous photopolymer hologram into a film of transparent plastic.



SOLUTIONS

We build instruments. But we're in the business of providing solutions. MKS builds the most accurate and reliable process gas measurement and control instrumentation in the world. But to our customers, our real products are the solutions our instruments bring to manufacturing processes. So we build products that are more repeatable, more accurate and offer the highest levels of performance. We focus on excellence around the process, from our research and development people who listen to your needs, to innovative engineering and design systems, to a solid worldwide engineering, sales and service network that helps you bring our products together to create a solution. Because when you're in the business of providing solutions, nothing less than the most complete solution will do. To find out more about MKS solutions, call us at 1-800-227-8766.

Six Shattuck Road, Andover, MA, USA 01810 Tel: (508) 975-2350 Fax: (508) 975-0093
e-mail: mks@mksinst.com <http://www.mksinst.com> ©1997 MKS Instruments, Inc. All rights reserved.




Figure 1. One-step Holographic Process to make ESBG.




Figure 2. Free-space ESBG Devices.

The result is an electronically switchable Bragg grating (ESBG). In practice, first-order 99-percent diffraction efficiencies can be switched to less than 0.3 percent, for an on/off ratio of 25 to 30 dB, and it appears likely that a 40-dB dynamic range will be achieved in the near future. The material has intrinsically low scattering and absorption, so it has been possible to stack four or more layers of ESBG film for multiple diffraction. In addition, the usual millisecond speeds of nematic liquid crystals in their bulk form become substantially faster due to encapsulation in microdroplets; 20- μ s switch-on times and 40- μ s off times have been recorded. However, electric fields to switch ESBG films must be larger than for simple liquid crystals, about 4 V/ μ m for films 5 to 20 μ m thick.

Figure 2 shows three basic applications. A switchable transmission hologram ESBG steers a laser beam through a fixed angle. A fiber optic switch version couples to laser signals in fibers. More complex holograms such as lenses can also be recorded and switched.

Lens applications are widely useful. ESBG holographic lenses show the strong chromatic dispersion characteristic of diffractive lenses. In this case, however, the focus property can be electronically controlled, promising a new basis for devices such as an imaging spectrometer with no moving parts. Another technology demonstrated by Foster-

Miller under SBIR sponsorship is an optical multilayer disk pickup head which uses ESBG films in the optical lens system to maintain a small

spot size regardless of the depth of the read-plane.

The most commercially promising applications may be in the fiber optic telecommunications industry. Increased demand due to Internet and other traffic has accelerated installation of multiwavelength networks conveying many high-bandwidth signals on one optical fiber. Better methods for selecting signals of different wavelengths, and for switching signals from one fiber to another, are needed. Because of the geometric flexibility of ESBGs, not only free-space beam steering and lenses but also waveguide and optical-fiber-based films have been demonstrated at Foster-Miller. For example, Figure 3 shows a fiber-coupled Bragg grating that can select to retain or drop one wavelength channel from a fiber transporting 8 or 16 such signals spaced very closely, 0.8 nm apart at the communications wavelength of 1550 nm. ESBG technology also appears to be very inexpensive to manufacture, an important factor in extending broadband fiber optics to the office building and the home.

This work was done by Dr. Lawrence Domash and coworkers at Foster-Miller, Inc., 195 Bear Hill Road, Waltham, MA, working in collaboration with Dr. Richard Sutherland and coworkers at Science Applications International, under an SBIR contract monitored by NASA's Marshall Space Flight Center. For more information, call (617) 684-4164.




Figure 3. Switchable Fiber-coupled Bragg Filter.

SL-GMS

SL-Graphical Modeling System

Create brilliant interfaces with this dynamic-graphics run-time engine embedded in your application

Builds, runs, and manages animated interfaces and connects them to your data sources for dynamic display and interactive control of fully visualized, real-time applications.

SL-GMS is continually evolving and improving to meet developers' increasingly complex needs. A pioneer in object-oriented design, SL now offers the power of State-Oriented programming to fundamentally simplify construction using a library of useful, pre-defined Screen-State Classes. The State Class library is a superb extension to MFC Framework and Visual C++ (or to any Motif GUI builder).



Nothing approaches the unprecedented performance and flexibility of SL-GMS in creating animated control and display screens for:

- * Process Control
- * Network Monitoring
- * Energy Management
- * Telecommunications
- * Command and Control
- * Traffic Management

Under Windows NT, SL-GMS is integrated with OLE as ActiveX.

SL-GMS provides PostScript and Raster printing modes. In addition it can be configured to generate HTML documents.

SL-GMS supports UNIX (X/Motif) on SUN, HP, IBM, MIPS, DEC (OpenVMS, VAX/Alpha, Digital UNIX), Windows NT (MFC, OLE, ActiveX), SCO, QNX®.

Basic license price is \$12,500. Significant discounts depending on quantity and OEM status of purchaser.

Call: 1-415/927-1724
http://www.sl.com

Since 1984

SL
Sherrill-Lubinski

SL Corporation
Suite 110 Hunt Plaza
240 Tamal Vista Blvd.
Corte Madera, CA 94925

© 1997 Sherrill-Lubinski Corporation
All trademarks and registered trademarks mentioned are property of their respective companies.




Are you power hungry, performance-ob
You're just our type.



Introducing the new expanded family of Compaq Professional Workstations. The 5000, 6000, and 8000 series are powerful Windows NT®-based systems that not only outperform industry-standard workstations but most UNIX systems as well.

Interested in faster time to market? Our innovative Highly Parallel System Architecture gives you advanced multiprocessing so you can utilize up to two Pentium® II processors or four Pentium processors. The dual PCI buses give you parallel access to peripheral devices and our dual memory controllers provide you with bandwidth that's up to four times faster (1.06GB/s) than competing Intel-based workstations. These industry-standard Compaq workstations are optimized to run premier engineering applications like Pro/ENGINEER, I-DEAS Master Series, Unigraphics, AutoCAD, AutoCAD LT, Works 97 and MicroStation. And your choices

◀ Bench '97 - Pro/ENGINEER (lower is better)



essed, and ego-driven?

stop there. We are forging new partnerships with leading CAE application vendors like Altair Engineering Inc., ANSYS Inc., Fluent Inc., The MathWorks Inc., Schwendler Corp., and Mechanical Dynamics Inc. It all comes down to this. You want power. You want performance. You want proof. We're going to give it all to you. Call your local Compaq Authorized Reseller and ask about our "try and buy" program or visit us at www.compaq.com.

COMPAQ

For More Information Circle No. 3



Telerobot Control for Microsurgery

Hand movements are repeated on a smaller scale, without tremor.

NASA's Jet Propulsion Laboratory, Pasadena, California

A telerobotic system for microsurgery has been designed to reproduce the motions of a surgeon's hand on a more precise scale and with smoother motion than previously possible. This system can be used for surgeries on the eye, brain, ear, and face and in the repair of fine blood vessels and nerves. The surgeon holds a handle attached to a master robot arm and moves it to specify the motions of a surgical instrument on the slave robot arm. The surgeon's hand motions are scaled down and filtered to enable precise surgical-instrument positioning without tremor (see figure).

The master arm measures the position

of the model-tool position in 6 degrees of freedom (DOF) and reflects forces with 3 DOF. It measures input position in increments of 0.001 in. (25.4 μm) in translation and 0.07° in rotation. The slave arm has 6 DOF and responds with movements in increments of 20 μm . The system provides several modes of control, and can be switched easily between modes.

The system includes the following subsystems:

- The mechanical subsystem, including motors, encoders, gear and cable drive mechanisms, and robot links and joints;

- The electrical subsystem, including controller terminal blocks, cables, safety electronic circuits, and amplifiers;
- The servocontrol subsystem, including a servocontrol circuit board, software, communication electronics, and shared memory software; and
- A software subsystem that resides partly in a UNIX host computer and partly in the servocontrol subsystem and that implements algorithms for the forward and inverse kinematics of the slave robot, algorithms for demonstration modes of control, and a graphical user interface.

This work was done by Timothy Ohm, Hari Das, Guillermo Rodriguez, Curtis Boswell, Paul Schenker, and Ed Barlow of Caltech; Eric Paljug of McKinsey & Co., Inc.; and Steve Charles of MDS, Inc., for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Electronic Systems category, or circle no. 107 on the TSP Order Card in this issue to receive a copy by mail (\$5 charge).


In accordance with Public Law 96-517, the contractor has elected to retain title to this invention. Inquiries concerning rights for its commercial use should be addressed to

Technology Reporting Office

JPL

Mail Stop 122-116
4800 Oak Grove Drive
Pasadena, CA 91109
(818) 354-2240

Refer to NPO-19823, volume and number of this NASA Tech Briefs issue, and the page number.



Small Movements of a Surgeon's Hand are scaled down to even smaller movements of a surgical tool at the tip of the slave robot arm. The system removes hand tremor from the control signal, so that only the desired movement is reproduced in miniature by the slave robot arm.

Hydrogen-Fire-Detector Calibration Unit

A tabletop unit contains an ultraviolet source and calibration circuits.

John F. Kennedy Space Center, Florida


A microprocessor-controlled, tabletop apparatus has been developed for use in testing ultraviolet-sensitive alarm circuits that detect hydrogen fires at various distances. The apparatus includes a krypton discharge lamp that emits

ultraviolet light of about the same intensity and in the same wavelength range (180 to 240 nm) as observed in hydrogen fires that were previously used to test the hydrogen-fire detectors. By eliminating the need to test with hydro-

gen fires, the apparatus obviously contributes to overall safety.

The apparatus includes a bracket that holds the hydrogen-fire detector to be tested in the required geometric relationship with respect to the krypton dis-

How to beat the squeeze in today's tight design environments.



AMP fine-pitch solutions are available for many applications.

High-density design is a cramped world. Our interconnect expertise can make life easier.

Because every design is unique, we'll show you all the options. We'll guide you through your choices – while watching system performance, manufacturability and cost.

We'll also offer choices in socketing, I/O, and board-to-board interconnects. From conventional (0.050" and 2mm centers), to sublime (redundant contact on board pads 0.015" wide, on 0.025" centers, with non-critical alignment).

We'll make sure you meet tight electrical characteristics and space limitations. And we provide technical information, literature, and 2D and 3D models of many product lines to shorten design time.

We'll show you how your system will fit successfully into production with packaging help, training and maintenance support.

We also can design and build sub-systems, or even fabricate your entire product. Call today to learn more.

AMP is a trademark.

Connecting
at a
HIGHER
level.™

Product Information Center: 1-800-522-6752 (fax 717-986-7575). AMP Incorporated, Harrisburg, PA 17105-3608. In Canada, call 905-470-4425. On the Internet: <http://www.amp.com>.

For More Information Circle No. 525

AMP

charge lamp. The main functional characteristic of the apparatus is that it provides ultraviolet light in the required spectral range at a stable, repeatable, and uniform intensity across the face of an ultraviolet-sensitive detector tube in the fire detector. The necessary uniformity of intensity is provided by reflective and diffusive optical elements associated with the lamp.

Repeatability and stability of intensity are provided via microprocessor control of the positions of adjustable optical elements and by electronic feedback control of the power supplied to the lamp.

The intensity feedback is obtained from an ultraviolet-sensitive photodetector near the lamp. A spinning chopper wheel modulates the light seen by the detector to enhance the performance of the feedback system. In response to the feedback signal, the microprocessor adjusts the power supplied to the lamp to maintain the intensity at a value selected by the technician.

Electronic control of the power supplied to the lamp can vary the intensity by a factor no larger than about 2, but a factor of about 100 is required for the complete range of tests to simulate the

signals from a standard hydrogen fire at distances from 10 to 64 feet (3 to 19 m). To provide the necessary increments of intensity over this large dynamic range, the apparatus is also equipped with a microprocessor-controlled iris and a microprocessor-controlled filter wheel that contains neutral-density filters of different densities.

After startup, a liquid-crystal display unit on the apparatus presents three options to the technician; (1) functionality check, (2) specification check, or (3) alarm-time-versus-distance measurement. The functionality check involves determining whether a power relay within the unit is operational, turning on the lamp, and determining whether the ultraviolet light supplied by an internal lamp can trigger the alarm function in the hydrogen-fire detector under test.

The specification check includes a calibration needed to determine whether a hydrogen-fire detector satisfies its performance requirements. During a specification check, the apparatus projects ultraviolet light at known intensities into the fire detector to determine whether the minimum- and maximum-sensitivity requirements are satisfied.

The alarm-time-versus-distance measurement is carried out by projecting ultraviolet light into the fire detector at an intensity representative of that of a standard hydrogen fire located well within the alarm distance of the detector. The time taken to alarm is then measured, and the detector is allowed to come out of an alarm state. The intensity of ultraviolet light is then dropped to correspond to a slightly larger distance, and the alarm time measured again. This process is repeated until the alarm time is greater than 30 seconds. This measurement provides a characterization of the performance of the fire detector versus the distance to a standard hydrogen fire.

This work was done by Gregory A. Hall and William E. Larson of Kennedy Space Center and Robert C. Youngquist, John S. Moerk, William D. Haskell, Robert B. Cox, Jimmy D. Polk, Stephen J. Stout, and James P. Strobel of I-NET, Inc. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Electronic Systems category, or circle no. 108 on the TSP Order card in this issue to receive a copy by mail (\$5 charge).

This invention has been patented by NASA (U.S. Patent No. 5,561,290). Inquiries concerning nonexclusive or exclusive license for its commercial development should be addressed to the Patent Counsel, Kennedy Space Center; (407) 867-2544. Refer to KSC-11722.

K-BEAM® Accelerometers.

**The most
affordable, highest
performing
Capacitive Silicon
Micromachined
Accelerometers
in the world.**

The expanded OEM line of K-BEAM accelerometers provides superior measurement of low frequency vibrations and slow motions with:

- Low cost (any quantity)
- High sensitivity
- Excellent zero stability
- True static response

K-BEAM applications:

- Robotics
- Platform Stabilization
- Transportation
- Aerospace Instrumentation
- Seismic Sensing

For more information
call our toll-free hotline
1-888-KISTLER
(547-8537)

ISO 9001 Quality System
See us at Sensors Expo
Booth #400

KISTLER

INSTRUMENT CORPORATION

75 John Glenn Drive • Amherst, NY 14228-2171
Phone: (716) 691-5100 • Fax: (716) 691-5226
email: kicsales@kistler.com • www.kistler.com

Call GMR
or visit our web site
for information
on how we can take
your career into the 21st Century.

Which Global Integrator Will Take Your Enterprise Into The 21st Century?

Software Engineering
Services

Groupware/Internet
Solutions

Contract
Manufacturing

Calendar Year 2000
Solutions & Services

Integrated
Telecommunications
Solutions (CTI)



Government
Contract Specialists:

— GSA Schedules:
70 A, B/C, 58

— GWAC
FEDSIM
Dept. of Justice
NASA SEWP II
— Agency Specific
Contracts

Integration &
Maintenance Provider

— Commercial
— Government
— Subcontracting

Acquisition, Operations,
Resource Services
Assistance Available

800-232-4671
www.gmri.com

We're Government Micro Resources, Inc. (GMR), but there's nothing micro about us.

Leading edge solutions, complete services, and best-of-breed products are hallmarks of our success. For fifteen years, GMR has been addressing customer's Information Technology needs. From laptop to mainframe and everything in between, around the beltway or around the world, GMR is the integrator with global vision.

Call us today for more information on how we can take your enterprise into the 21st Century.

GMR



Government Micro Resources, Inc.

Sunnyvale, CA • Norfolk, VA • Mannington, WV • San Antonio, TX • Denver, CO

7203 Gateway Court • Manassas, VA 20109

(703) 330-1199 • (703) 330-1722 Fax

For More Information Circle No. 516



NASA Langley - NAS1-97101
NASA Ames - NAS2-14352




SEWP II - NAS5-32898

GSA Schedule B/C - GS-35F-4566G
GSA Schedule A - GS-35F-0097D
GSA Schedule 58 - GS-35F-1083D



When making a
long term
commitment,
compatibility is
everything.



PETASITE MASS STORAGE LIBRARY

The flagship of the Sony Data Storage Tape Drive Family. This modular based tape library provides mass storage of data up to 3 Petabytes (3,000 Terabytes) in capacity. Like the entire storage family of products, this unit is designed to grow with your needs.

PetaServe™ Hierarchical Storage Management Software is also available from Sony to further support your data intensive requirements. Best of all, the PetaSite library is compatible with our full line of Sony Data Storage Drives.

SONY'S DATA STORAGE FAMILY

So, it's time to take the plunge. Tie the knot. Make the big commitment. In other words, choose a data storage system. But, have you really, truly considered the importance of compatibility? Well, Sony has. When we built our data storage family, we saw to it that every product had one thing in common. Compatibility with our PetaSite™ modular based mass storage library. Whether you choose from the DIR-1000 Series, the DTF™ half inch tape drive, or the new ADI-1150 digital data recorder, Sony is committed to your high performance data storage and data acquisition needs. In addition, Sony has mapped a planned migration path for each drive series. Because in any good relationship, growing together is essential. So before you make a decision you might soon regret, consider Sony. The first name in magnetic tape technology and the reputation to prove it. Call 1-800-635-SONY, ext. FAMILY.

High
Performance
Data
Acquisition

DIR-1000 SERIES

One of the world's fastest commercially available ID-1 ANSI format tape drives. This high end series just got better with the addition of the DIR-1000H, with transfer rates of up to 512 Mb per second and storage of 770 Gb per tape cassette. With over 7 years of field deployment and 700 units installed worldwide, this series has built a reputation for compatibility, reliability, and performance. It's also compatible with our PetaSite Mass Storage Library.



Archiving

Large Scale
Database
Backup

ADI-1150 DIGITAL DATA RECORDER

One of the newest members of the Sony family, this unit delivers a sustained data rate of 15 MB per second over SCSI-2 Fast and Wide interface, combined with a maximum capacity of up to 52 GB of uncompressed data per cassette. The ADI-1150's impressive performance and favorable cost/performance ratio makes it the perfect fit for applications that range between our DIR and DTF drives. Also compatible with the PetaSite Mass Storage Library.



Digital Image
Storage

DTF HALF INCH TAPE DRIVE

Our next generation DTF high performance computer peripheral tape drive is rich in family heritage, based on Sony's highly successful Digital Betacam® professional recording technology. The GY-2120 (pictured here) features a sustained transfer rate of 12 MB per second (up to 20 MB per second with compression) and storage capacity of up to 108 GB compressed on a single cassette. It has the ability to backup 100 GB of data in approximately an hour and a half, and is already setting the standard for high performance and reliability in a SCSI attached tape storage peripheral. It's also compatible with the PetaSite Mass Storage Library.



Automated Tape
Libraries for Mass
Storage

Remote Sensing



Better Cells for Multiple-Pass Absorption of Light in Gases

These cells overcome some of the limitations of older multiple-pass absorption cells.


Ames Research Center, Moffett Field, California

A new multiple-pass optical gas measurement cell has been developed that provides improved analytical accuracy and reduced size and cost, compared to older designs.


Optical sampling cells allow the

measurement of light absorption in samples of gas, using the Beer-Lambert relation. Single pass cells are not difficult to manufacture, but the light path is too short for practical use with weak gas concentrations

or with gases that have low absorption properties. In these situations, multiple-pass cells are used, providing for a longer path for the light to travel. However, accuracy of the light path is more difficult to control in





GENERAL OPTICAL SCHEME SHOWING INCOMING BEAM AND FIRST REFLECTION



OPTICAL SCHEME OF AN EIGHT-PASS CELL (Nonoptical Components Omitted For Clarity)

Multiple Passes of a Beam of Light through a cell are achieved by reflection between a spherical mirror and multiple pairs of suitably positioned and oriented flat mirrors. In comparison with older multiple-pass configurations, this one is less sensitive to misalignment and better able to accommodate a wide and/or divergent beam of light.

There's a world of difference waiting. The competition isn't.



**Nonlinear analysis.
Virtual manufacturing.
Product simulation.
Parallel processing.
Multiphysics.**

**The cutting edge
solutions you need
are here today.**

MARC, the world's leading supplier of advanced finite element analysis software, has become the analysis methodology of choice in aeronautics, automotive, biomechanics, consumer products.... In **your** industry.

Our products give you the ability to benefit from the use of new materials, to extract more performance from less weight at less cost, to see how your products will perform in the real world — before they're manufactured.

Powered by Sun Microsystems's Ultra™ Enterprise™ Servers, MARC gives you the **competitive advantage**.

Analysis for the new millennium.

Find out what the world's leading manufacturing companies have already discovered. Visit us at **www.MARC.com**. Or contact us directly at **800-548-4665**. Find out what MARC can do for you.



Order our free CD-ROM. See what the industry's talking about.

Order at the website or call MARC today!



MARC Analysis Research Corporation
260 Sheridan Avenue, Suite 309
Palo Alto, CA 94306

For More Information Circle No. 512



multiple-path cells. Traditional multiple-pass optical cells with analytical levels of accuracy are relatively large, and need a bright, well-collimated light source for best performance.

The new design developed at the NASA Ames Research Center overcomes several of the limitations inherent in older gas cells, by combining a single spherical lens and two or more flat mirrors to extend the length of the light path.

The left part of the figure illustrates the principles of operation of the new design. A beam, or bundle, of light, which can be divergent, enters the entrance hole, and is reflected by a spherical mirror of radius R and focusing on a top cover on plane P and approximately height R above the spherical mirror. Without additional mirrors, the light beam would thus be focused on the top cover of the device. However, the light is not allowed to strike plane P . Instead, pairs of flat mirrors (one to three pairs would be typical embodiments) are placed near the entrance, and are positioned and oriented to redirect the beam to the spherical mirror. The positions and orientations of the flat mirrors are chosen to

make the beam come to a focus between them, so that the central ray of the light beam is reflected back toward the center of the spherical mirror. The last flat mirror is arranged such that, after the final reflection from the spherical mirror, the light beam passes through an exit hole on the top cover. The exit hole is on the same plane as the entrance hole, but at a different azimuthal position on the top cover.

The right part of the figure illustrates the path followed by the central ray of the beam in an eight-pass cell based on this concept. The ray enters the cell (pass 1), and is reflected by the spherical mirror back toward the first of six flat mirrors (pass 2). Passes 3 through 7 are back and forth between the spherical mirror and the remaining five flat mirrors. After the last reflection from the spherical mirror, the ray leaves through the exit hole in the top cover (pass 8).

Unlike some older multiple-pass absorption cells, it is not necessary to use narrow, well-collimated beams of light with this design when only a few passes are necessary. This is due to the property of the combined spheri-

cal and flat mirrors' tendency to reduce stray light paths within the cell, thus reducing errors when calculating gas absorption values.

Another advantage of the new design arises from the need for accurate knowledge of the length of the optical path within the cell in order to compute the light absorption using the Beer-Lambert relation. The configuration of the mirrors in the new design makes it easier to manufacture cells with precisely known light-path lengths.

This work was done by Richard Pearson, Dana H. Lynch, and William D. Gunter of Ames Research Center. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Physical Sciences category, or circle no. 115 on the TSP Order card in this issue to receive a copy by mail (\$5 charge).

This invention has been patented by NASA (U.S. Patent No. 5,459,566). Inquiries concerning nonexclusive or exclusive license for its commercial development should be addressed to the Patent Counsel, Ames Research Center; (415) 604-5104. Refer to ARC-13384.

EXCELLENCE IN ANALYTICAL IMAGING SOFTWARE

"Counting and sizing 100 pinwindows, for example, would take about 5 minutes....With Image-Pro, we acquire the same data within 15 seconds."

Dean Neuberger, R&D Engineer, Sheldahl, Inc.

"We use Image-Pro to quantify and qualify pinwindows (small areas deficient in copper). Image-Pro has the capability to see these pinwindows, count, and measure them. With a particular intensity range (a.k.a. threshold) used on a grey-scale capture to see bright areas, we have been able to characterize our material for pinwindows and use that information for R&D and quality purposes."



Whether you analyze materials, quantify biological samples, evaluate fingerprints, or any other application where you need to acquire and analyze images, Image-Pro Plus will deliver reliable, repeatable results on the hardware of your choice at a price/performance breakthrough. Use the #1 selling software from the leader in imaging technology -Your colleagues are! Call Today.
+(31) 715-730-639 (Europe) • 800-992-4256 (USA)

**MEDIA
CYBERNETICS**
The Imaging Experts

Site License and Maintenance Pricing Available

8484 Georgia Avenue • Silver Spring, Maryland 20910 USA • 301-495-3305 • FAX 301-495-5964 •
<http://www.mediacy.com> ©1997 Media Cybernetics. "Image-Pro Plus" and the Media Cybernetics logo are registered trademarks of Media Cybernetics.

**Image-Pro
PLUS**
The Proven Solution

The World Standard in Real-Time Data Recorders.

In the world of real time data recording, there is no room for compromise because the incoming data is priceless. Decisions need to be made *instantaneously* as the recording takes place – in real time. Engineers doing aerospace telemetry, automotive testing, electrical power transmission or telecommunications analysis, have made the Astro-Med MT95K2 the world standard because of its recording power and reliability. For detailed information and engineering specifications call, fax, or E-mail Astro-Med today.

- No Delay... see full traces on monitor while recording
- On-Board Data Analysis as well as by host program
- Patented Twin Printhead Design... 300 dpi laser printer resolution for clear, crisp traces
- On-Board Signal Conditioning for voltage, temperature, pressure and strain recording
- Front Panel Floppy Drive for personal chart and system setups
- Data Capture...store up to 32 megabytes in RAM; 1 gigabyte to internal hard drive; stream to external 2 gigabyte drive via SCSI; archive to DAT or floppy drive
- 8 to 32 Waveform Channels... plus 32 events; DC to 20 kHz; chart speeds to 500 mm/sec
- Record digital data via ethernet, SCSI, GPIB, or parallel interfaces



Astro-Med, Inc.

Astro-Med Industrial Park, West Warwick, Rhode Island 02893 • Telephone: (401) 828-4000
Toll Free: 800-343-4039 • Fax: (401) 822-2430
E-mail: astro-med@astro-med.com
Web Site: <http://www.astro-med.com>

Astro-Med is System Certified to ISO 9001

Sales and Service Centers throughout the U.S., Canada and Europe. Dealers located throughout the world.



Optical Air Mass Flux Sensor for Aeroengine Monitoring and Control

A diode-laser-absorption sensor for simultaneous measurements of air density and velocity has achieved ± 2 -percent accuracy in an F-100 engine inlet.

Physical Sciences Inc., Andover, Massachusetts

Flight-qualifiable sensors for inlet air mass flux are desired for improved control of conventional aeroengine gas turbine power plants and variable-geometry, mixed-compression inlets of advanced flight vehicles. Optically based techniques are advantageous for inlet measurements, particularly

in compressible flows, because they do not disturb the flowfield downstream of the measurement location. Under support from the NASA Dryden Flight Research Center (solicitation year 1992), a sensor using fiber optic beam transport and ultra-low-noise detection has been developed to obtain

high-precision measurements of the O_2 density and Doppler shift, permitting rapid determination of the density-velocity product, or mass flow into the engine.

In the basic sensor configuration, a room-temperature diode laser, operating near 763 nm, is fiber-coupled and split into two signal and two reference channels. Fiber optic cables bring the signal channels to two launch modules, where the narrowband, tunable laser light is collimated and launched across the flow duct at opposing angles. The transmitted light is detected with a pair of Si photodetectors configured in a sensitive balanced detection system.

MUCH MORE THAN A PRETTY PICTURE (FRAME)

Our competitors say, "Oh, Cardinal's just a picture frame company!" Sure, we manufacture picture frames, but that's just *one* of the many markets where we shine. Just take a look at this 6-hole, multi-hollow extrusion piece...

MOST EXTRUDERS WOULDN'T EVEN QUOTE THE JOB ...

They claimed it was too difficult to *economically* manufacture due to its difficult shape, varying wall thicknesses, and extensive fabricating.

... BUT CARDINAL COULD, AND DID IT ALL!

Extruding the complex profile was the easy part. What kills our competition is their tremendous cost in tooling and the numerous set-ups ...

FABRICATED IN 10 MINUTES!

Our fully automated, multi-functional fabricating equipment allowed us to completely fabricate this component in one work cell in less than ten minutes!



THE BIG FINISH

Next we applied our standard decorative etch black anodize—one of over 20 anodizing colors available. We also offer over 60 stock powder coat finishes, five 2-step architectural hard coats, plus any custom match—all with the surface finish of your choice. And with our Image Graphics, your extrusions can look like *any* material!

ALL THIS FROM A SINGLE SOURCE ...

Extruding, fabricating, finishing—oh yea, and picture frames—it's all here at Cardinal, your single source for high-tech aluminum extrusions since 1946. Give us a call today.

1-800-EXTRUDE
Cardinal Aluminum Co.

6910 Preston Hwy. • P. O. Box 19987 • Louisville, KY • 40219-0987

1-800-EXTRUDE • Fax: (800) 969-6910




Figure 1. Example of Air Velocity Data.

Using the reference channels to account for common-mode laser amplitude noise, near shot-noise-limited absorption sensitivity is obtained, allowing the weak O_2 absorption lineshapes to be accurately recorded as the laser wavelength is rapidly swept across an isolated lineshape. The integral of this lineshape gives the O_2 density. The relative shift in frequency between the lineshapes recorded across the opposed paths gives a measure of the path-averaged gas velocity across the duct. The simultaneous measurements of density and velocity are combined with the known duct area to yield a measure of the integrated mass flux in the duct.

Extensive testing of the basic sensor in laboratory flows, full-scale aero-engine, and large-scale wind-tunnel test facilities has built a large, statisti-

verification & validation

integration & test

specification

software/hardware implementation

design



How effectively do your engineering teams relay designs?

Now, more than ever, with constraints of schedules and budgets clouding engineering projects, smoothing communications between design groups is crucial to the success of your project. Here's where the MATRIX_X[®] engineering productivity tools step in. The "design via simulation" environment has proven its value over the years in a variety of challenging programs. MATRIX_X's open architecture framework facilitates rapid integration in your design process, while leveraging your design investment.

Valuable feedback from the MATRIX_X worldwide user community, combined with Integrated Systems' commitment to engineering innovation and leadership, has driven the next generation of MATRIX_X tools. Key enhancements include standard user interfaces, seamless workgroup integration, software specification flexibility, and a quantum leap in automatic code generation technology.

Version 6.0 is on the blocks and ready to go! Make your "design hand-off" a winner with MATRIX_X call: 800.770.3338 or send email to: info@isi.com.

Team MATRIX_X... Keeping Your Projects on Track

MATRIX_X
THE POWER OF TEAMWORK



201 Moffett Park Drive • Sunnyvale, CA 94089 • 800.770.3338 • www.isi.com

© 1997 Integrated Systems, Inc. MATRIX_X is a registered trademark of Integrated Systems, Inc. All other trademarks belong to their respective companies.

For More Information Circle No. 542

cally significant database of the sensor's performance in several flow environments. On a full-scale Pratt & Whitney F-100 aeroengine test, performed in a ground test at the NASA Dryden Flight Research Center, mass flux measurements with a precision and absolute accuracy of 1 to 2 percent over the full range of engine operating conditions were demonstrated.

Figure 1 is an example comparison

of the diode laser's optical velocity measurement with a calibrated Pitot-static air probe. The range of velocities shown spans idle to full Mil-spec power conditions.

Commercial development of a version of this sensor for compressor stall/surge monitoring and possible control is being pursued with support from the AlliedSignal Engine Company. Additional support from NASA

Dryden is developing a flight version of the sensor for installation and testing in a NASA F-18 test vehicle.

This work was done by Physical Sciences Inc., 20 New England Business Center, Andover, MA 01810-1077, under a NASA SBIR contract monitored by Dryden Flight Research Center. For more information, contact Dr. Mark Allen, (508) 689-0003. DRC 096-07

Electrochemical Process for Treatment of Wastewater

The treated water is potable.

Lyndon B. Johnson Space Center, Houston, Texas

A prototype apparatus implements an electrochemical process for treatment of wastewater streams that contain various proportions of urine, laundry water, and bath water. The process comprises three sequential subprocesses; a batch electrolysis process followed by a batch electrodialysis process followed by a continuous-flow catalytic oxidation process (see figure). Each of the first two subprocesses removes a different group of contaminants and/or

passes on partially reacted contaminants to the next subprocess. The electrochemical energy produced in the electrolysis subprocess results in oxidation of organic contaminants except organic acids. The electrodialysis subprocess removes organic acids and ions. The catalytic oxidation subprocess removes most of the remaining contaminants.


At the beginning of the process, a batch of wastewater (2.3 L in the case of

the prototype apparatus) is transferred to a reservoir in the electrolysis section. The electrolysis subprocess takes 260 to 280 min and includes a foam-suppression preprocess: The wastewater is recirculated through the electrolysis section along one of two alternative paths depending on the time. Before electrolysis starts and during the first 30 min of electrolysis, water flows through a regenerable foam-suppression unit, then the electrolysis cell, and back to

Flat Panel Monitor **ARMS**TM

Call: 1.800.888.8458

Ergonomically position your flat panel monitors, laptops and keyboards wherever you need them—with Ergotron's **Adjustable Rotating Mounting Solutions**



Mobile Solutions



Wall Mount Solutions



Custom Mount Solutions



Laptop Mounting Solutions



ERGOTRON[®]

1.800.888.8458 <http://www.ergotron.com>


the reservoir. This path reduces the concentration of foam-forming contaminants to tolerable levels. After 30 min of electrolysis, the path changes to bypass the foam-suppression unit.

The polarity of the voltage applied to the electrolytic cell is reversed once per minute to counteract the buildup of polarized ions near the electrodes and increase the concentration of reactants at the surfaces of the electrodes. The liquid being processed is recirculated through the electrolytic cell at a constant rate of 1 L/min. An oxidation/reduction-potential sensor indicates the end point of the electrolysis, which is defined as the point at which energy-utilization efficiency decreases during electrolysis. A gas-conditioning unit absorbs water vapor and chlorine produced by the electrolysis process. The total concentration of carbon in organic compounds ["total organic carbon" (TOC) for short] and the pH of the processed liquid are more than halved by the electrolysis process. Remaining organic materials are converted to low-molecular-weight organic acids that can be separated efficiently by electro-dialysis.

After electrolysis, the water is transferred to a reservoir in the electro-dialysis section. In the electro-dialysis sub-process, an electric field causes ions to migrate through membranes, thereby concentrating the contaminants into a brine while forming a deionized product water that is relatively free of contaminants. The statuses of the brine and the product water are monitored (to determine the end point for electro-dialysis) by use of electrical-conductivity meters. The brine is stored, while the deionized product water is moved on to catalytic oxidation.

In the catalytic oxidation subprocess, the TOC of the remaining contaminants is reduced to below 500 micrograms per liter — a level that satisfies NASA's specification for potable water. Oxidation byproducts (oxygen and carbon dioxide), are removed by a gas/liquid separator at the outlet of the catalytic oxidizer.

This work was done by James R. Akse of Umpqua Research Co. for Johnson Space Center. For further information, access the Technical Support Package (TSP) free online at www.nasa.gov under the Physical Sciences category, or circle no. 117 on the TSP Order card in this issue to receive a copy by mail (\$5 charge). MSC-22427



This **Electrochemical Water-Treatment Process** comprises three subprocesses, each of which plays an essential role in relation with the others.

DIAGNOSTICS/ACQUISITION SYSTEM

Up to 16 Real and Virtual Measurements

Data Evaluations ■ FFT ■ Diverse Sensors

NEW

Graphtec again reduces the weight, size and cost of data diagnostics and acquisition instrumentation. With the most portable and versatile system available anywhere.

The **WR9000** is available for 4, 8 or 16 channels. Multi-input amplifiers measure voltage, J/K/T thermocouples, or RMS level. Mix or match them with others to extend your inputs to bridge and frequency transducers. And use its math utilities and interchannel analysis capabilities to create *virtual channels* that greatly improve your real-time diagnostic capabilities.

Store sound, vibration and other dynamic phenomena for immediate FFT and correlation analysis.



Scroll through your data and define segments for instant calculation of area, max/min/rms values, standard deviation, and rise/fall times.

Use SMART triggering and available 16-

channel TTL logic to analyze transients, evaluate cyclical operations, summarize process variables, or interface with external controls. All in real time. With a system you can carry under your arm.

Use the **WR9000**'s file conversion software to merge your data on-the-spot with programs such as Microsoft Excel, Lotus 1-2-3 and DADISP.

Take advantage of a bright 8.9-inch EL display that is easy to read from any angle and under

any lighting condition. Use the A-4 thermal array chart for local printout. Use 512K of memory per channel, or reallocate to expand selected measurements. Standard 3.5" floppy drive or optional magneto-optical drive provides additional storage.

Control amplifier parameters and chart operation from a menu screen or GUI. Or by panel keys that you can reset even during operation.

The **WR9000**'s small footprint and low profile suit it ideally to field measurements.

And to portable use in the laboratory or on the factory floor. It measures less than 15" x 12" x 5" and weighs only 17.5 lbs (8-channel), and operates on AC or available 12 VDC.

Don't settle for tape recorders or multiple instruments. Make your evaluations and decisions on-the-spot. With the world's smallest and most versatile diagnostics and acquisition system.

Call (800) 854-8385 today for full information and to receive your copy of our new application brochure.

WESTERN GRAPHTEC, INC.

11 Vanderbilt ■ Irvine, CA 92718-2067

(714) 770-6010 ■ (800) 854-8385

FAX (714) 855-0895



Full-screen display

REPEAT

after me, "HP PROVIDES

SUPERIOR

GRAPHICS *across*

BOTH UNIX AND NT."

It has a nice ring to it, huh?

An unfamiliar ring, anyway. But no longer. With new, leading-edge graphics products like VISUALIZE FX, DirectModel and VISUALIZE PxFI, HP is delivering exceptional high-end graphics performance across UNIX® and NT. Couple that with our unparalleled application performance, and technical computing never sounded so good. Repeat, never sounded so good. Contact us at www.hp.com/go/technical





Adhesively Bonded Strain Gauges for Temperatures up to 400°C

Bonding conditions are consistent with chemical properties and temperature limitations of substrates.

Lewis Research Center, Cleveland, Ohio

Strain gauges with improved adhesive bonding have been developed for use in measuring creep and stress-relaxation effects associated with aging in PMR-15 polyimide resin at test temperatures up to and even somewhat above the maximum use temperature of 371 °C. Even near the upper limit of test temperatures, the improved adhesive bonding provides secure attachment to substrates of both PMR-15 composites and titanium alloy 6242.

The development of these strain gauges and the improved adhesive bonding were necessitated by the limitations of previously available strain gauges. The best previously available adhesively bonded strain gauges could not withstand prolonged exposure to temperatures above 232 °C and were recommended for no more than 150 hours of operation at 280 °C. The adhesive in those gauges had to be cured at temperatures up to 42 °C above the intended test temperatures; some substrate materials, including PMR-15 composites, cannot withstand this much heating above test temperatures.


The improved bonding of the present strain gauges is achieved by use of a procedure and materials compatible with the cure chemistry and with the processing requirements for the substrate material. The maximum bonding temperature does not exceed the intended test temperature or the maximum substrate-fabrication temperature. Also, unlike standard previously available adhesively bonded strain gauges, the present strain gauges are not backed with permanent organic supporting films that must be bonded to the substrates; the present gauges are manufactured with temporary supporting films, and the gauges themselves, rather than the supporting films, are adhesively bonded directly to the substrates.

In the case of a PMR-15 substrate, the improved bonding procedure is initiated after the cure and before the postcure stage of the substrate-fabrication process. The adhesive is a slurry

that is made by preparing a solution of poly(amic acid) in N-methyl-2-pyrrolidinone, then adding a partially reacted (imidized but not cross-linked) PMR-15 powder. The poly(amic acid) solution is used to obtain adequate flow and wetting of the substrate.

The gauge is cleaned by exposure to ultraviolet light and ozone. A first coat of adhesive is applied to the substrate and to the gauge face opposite the temporary supporting film, then this

Though the adhesive bonding system has been demonstrated on PMR-15 resin and titanium-alloy substrates, bonding to PMR-15 composites and to other polymeric and metal substrate materials should be possible. For bonding to other polymeric substrates, the adhesive system would be modified by replacing the poly(amic acid) and the PMR-15 powder with materials more similar to, and/or more compatible with, the substrate material.



A Strain Gauge Is Bonded to a substrate by pressing together adhesive-covered gauge and substrate surfaces, then heating the entire assembly to cure the adhesive and postcure the substrate. The adhesive is formulated to be compatible with the cure chemistry, processing requirements, and temperature limitation of the substrate.

first coat is dried by heating to temperatures up to 205 °C. A second coat of adhesive is applied, then the gauge and substrate are clamped together (see figure) and heated according to the normal postcure schedule of 205 °C for 10 minutes followed by 316 °C for two hours.


In a test of the gauges and improved bonding, a gauge remained bonded to a PMR-15 composite substrate and exhibited adequate resistance to creep after aging for a month at 316 °C. The present gauge/adhesive system has also been shown to withstand thermal cycling up to 364 °C and to withstand maximum temperatures up to 400 °C for short times.

This work was done by Gary D. Roberts, Kathy C. Chuang, and J. Michael Pereira of Lewis Research Center; Christopher Rabzak of NYMA, Inc.; and Douglas T. Jayne of Ohio Aerospace Institute. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Materials category, or circle no. 121 on the TSP Order card in this issue to receive a copy by mail (\$5 charge).


Inquiries concerning rights for the commercial use of this invention should be addressed to NASA Lewis Research Center, Commercial Technology Office, Attn: Tech Brief Patent Status, Mail Stop 7-3, 21000 Brookpark Road, Cleveland, Ohio 44135. Refer to LEW-16347.

Mechanical Simulation for Better Products™

Build



CAD or ACIS Parts and Assemblies



Functioning Working Model Subway Door Mechanism
Modeled by Sean Taffert, Vapor Canada Inc., Quebec, Canada


Build your "Working Model®" by putting together real physical components like motors, actuators, springs, and mechanical joints. No programming is required. You can design parts and assemblies in Working Model, or directly in your CAD environment.

Test


- Contact and friction forces
- Positional tracks and envelopes
- Loads on any part
- Will it work?
- Motor and actuator sizing
- Interference detection
- Forces on any joint or component
- Complete system animation
- Velocities, accelerations and energies



Will it work?



Positional tracks and envelopes




Loads on any part



Contact and friction forces

Refine



Range of Motion of Subway Door Mechanism
Acceptable range of motion derived after multiple iterations
with Working Model

Great designs are based on iteration. Working Model lets you iterate without limits. Our customers quickly perform multiple design iterations in Working Model, prior to building their first prototype.



Final product
functions as designed*

Working Model®


Working Model, Inc.
A Division of Knowledge Revolution
66 Bovet Road, Suite 200
San Mateo, CA 94402

* subway photo simulation
Working Model® is a trademark of
Knowledge Revolution.

For a demo or for your local dealer call 800-766-6615
Or contact us at www.workingmodel.com

For More Information Circle No. 523

Autodesk





Modified CVI Process for Making SiC/SiC Composites

Removable surface layers eliminate the need for time-consuming grinding-off of integral surface layers.

Lewis Research Center, Cleveland, Ohio

A modified chemical-vapor infiltration (CVI) process makes high-quality composites of silicon carbide fibers in silicon carbide matrices. In this process, one adds a sacrificial surface layer of SiC fiber preform that can later be removed easily, by scraping or tapping, when it becomes clogged

with infiltrate ("canned off," in CVI terminology).

In comparison with other CVI processes, this process is faster and costs less because unlike the other processes, this one does not involve time-consuming grinding-off of surface layers that have become clogged

with infiltrate. This process can be used for making parts that have variable thicknesses and complex, irregular shapes, as well as parts that have constant thicknesses and simple shapes. This process also ensures that the infiltrate consists only of silicon carbide, without the silicon that is

IF YOU THINK YOU CAN'T SEAL IT, YOU HAVEN'T TRIED

PNEUMA-SEAL®

Pneuma-Seal® is an inflatable gasket that is pressurized with air. It fills the gaps between surfaces, even hard-to-seal uneven surfaces. When deflated, Pneuma-Seal quickly retracts preventing interference when opening and closing a door or cover.

Use Pneuma-Seal as an effective barrier against pressure differentials and to seal out water, dust, gas, chemicals, noise and other contaminants.

Typical applications include:

Processing equipment: chemical, food, textile, pharmaceuticals, dryers, ovens and where **rapid sealing and unsealing** are required.

Pollution control: sound attenuation, hopper seals.

Laboratory facilities: test equipment, clean rooms.

Transportation: military vehicles, aircraft, shipboard, mass transit doors and hatches.

Construction: special purpose doors, flood protection.

Pneuma-Seal is particularly suitable for:

Large enclosures where it is uneconomical to machine the entire sealing surface.

Uneven fabrications where traditional compression gaskets or latches are ineffective.

Horizontal or vertical sliding doors or covers that would tend to drag on and abrade conventional seals.

Hinged doors where flush thresholds are required.

To obtain our complimentary designer's handbook, engineering assistance or to have a Presray representative contact you, please call, fax, E-mail or reach us on the Worldwide Web:

(914) 855-1220

Fax: (914) 855-1139

West Coast: (714) 751-2993


E-mail: info@presray.com

<http://www.presray.com>

PRESRAY

Presray Corporation

159 Charles Colman Blvd., Pawling, NY 12564



The Modified CVI Process resembles conventional forced-flow isothermal CVI in some respects, but costs less because it does not include a time-consuming grinding step.

sometimes found in SiC/SiC composites made by other processes.

The advantages of this process can be understood better by comparison with one of the other processes; namely, conventional forced-flow isothermal CVI, in which a porous (SiC-fiber) preform is held at con-




Out-of-the-BoxTM Paperless Recording

From
\$66
per channel

Replace your outdated strip-chart recorder with the new ChartScan/1400[™] and never buy expensive paper supplies again! Simply attach your voltage and thermocouple signals to the convenient input connectors, and run our included Out-of-the-Box[™] ChartView[™] software. You'll be viewing real-time data and saving it to your PC's disk drive within minutes, *without programming*.

Other features such as stand-alone operation (without a PC), modem support for remote applications, and 32 built-in alarms make the ChartScan/1400 paperless chart recorder an unbeatable value.

www.iotech.com/prchart.html



Features

- 16 to 128 channel capacity (from \$66 per channel)
- ChartView[™] software for immediate Out-of-the-Box[™] operation
- Measurement rates up to 147 channels/s
- 500V channel-to-channel isolation
- 32 programmable alarm outputs
- Excel[™] spreadsheet support
- Simple serial port connection to any PC
- IEEE 488 interface also available
- Modem-compatible for remote applications

Circle 401

ChartScan/1400, ChartView, & Out-of-the-Box are trademarks of iotech, Inc. All other trademarks are the property of their respective holders.

IOTECH WORLDWIDE SALES OFFICES:

Australia +61 3 9569 1366; Austria 43 (316) 30700; Belgium +32 2 466 81 99;
Canada Montreal (514) 697-3333, Ottawa (613) 596-9300, Toronto (905) 890-2010,
Vancouver (604) 988-2195; China +86 (10) 6232-9880; Denmark +45 45 82 7878;
Eastern Europe +43 1 54 515 38; Finland +358 9 476 1600; France +33 1 34 89 78 78;
Germany +49 711 9 02 97 0; Israel +972 3 649 8538; Italy +39 2 392 66561;
Japan +81 3 5688 6800; Korea +82 2 538 4001; Netherlands +31 79 360 00 18;
New Zealand +64 9309 2464; Singapore +65 482-5600; South Africa +27 (12) 660-2884;
Spain +34 1 570 2737; Sweden +46 13 31 0140; Switzerland +41 1 825 57 77;
Taiwan +886 2 501 7065; United Kingdom +44 01296 397676



the smart approach to instrumentation[™]

www.iotech.com



Toll-Free 1-888-727-4512

Contact us today for your FREE
Signal Conditioning Handbook,
1997 Catalog, & demo CD!





PCI/IEEE 488.2 Controller

IOtech's new Personal488/PCI™ IEEE 488.2 interface for PCs provides >1 Mbyte/s data transfer and plug-and-play convenience. Software support includes Windows® 95 and Windows™ NT drivers for most popular programming languages, as well as National Instruments® compatible Windows™ and LabVIEW® drivers. From \$495.

www.iotech.com/catalog/ieee/catperspci.html

CIRCLE 403


Dynamic Measurements with your Notebook PC

Directly attach ICP® accelerometers, microphones, or other dynamic signal inputs to our 1-MHz WaveBook™ portable measurement system. Then use our included WaveView™ software to view your signals in real-time and acquire data directly to your PC's disk. For analysis, use WaveView to export acquired signals to popular applications such as MATLAB™, DADiSP™, and Excel™, or develop your custom applications using our LabVIEW®, Snap-Master™, and DASyLab™ drivers.

WaveBook system features:

- 8 to 72 analog input channels
- 1M sample/sec A/D
- Multi-channel triggering
- Pre- & post-trigger sample rates
- Programmable 10-pole filtering
- Simultaneous sample & hold
- Direct ICP® input
- Thermocouple, RTD, strain-gage, isolation, & high-voltage inputs
- AC or 12V DC operable
- As low as \$190 per channel!

www.iotech.com/bghw5.html



Includes WaveView software for Out-of-the-Box™ set-up, acquisition, & real-time display without programming!



Circle 402



Call today
for your free
application notes
& software demo!




the smart approach to instrumentation

25971 Cannon Road
Cleveland, Ohio 44146
(440) 439-4091 • Fax (440) 439-4093
E-mail: sales@iotech.com
Internet: <http://www.iotech.com>

DaqBook, DaqViewXL, Personal488/PCI, WaveBook, WaveView, & Out-of-the-Box are trademarks of IOtech, Inc. All other trademarks or trade names are the property of their respective holders. Prices and specifications may change without notice.

Data Acq Software for Excel™



DaqViewXL™ is an add-in for Microsoft Excel™ that supports IOtech's parallel-port, ISA-bus, and PC-Card data acquisition systems. All setup and data acquisition—including real-time viewing of acquired data—occurs within Excel™. \$195.

www.iotech.com/bgsw3.html

CIRCLE 404

Expandable Notebook Data Acq




The 12- or 16-bit 100-kHz DaqBook® portable data acquisition systems for notebook and desktop PCs are expandable up to 256 analog inputs and 192 programmable digital I/O channels. The compact units offer five counter-timers, as well as 10 µs/channel scanning and gain switching over all channels. The DaqBooks are available with signal conditioning for thermocouple, RTD, strain gage, acceleration, high voltage and more. They include wide-ranging software support, and are operable via AC, DC, or battery power. From \$695.

www.iotech.com/bghw1.html

CIRCLE 405

Data Acquisition Software



DASyLab™ is a Windows-based, icon-driven data acquisition software package that provides effortless analysis, graphing, importing, configuration, user-interface, and operator-interface capabilities. It supports IOtech's parallel-port, ISA-bus, and PC-Card data acquisition systems. From \$495.

www.iotech.com/bgsw4.html

CIRCLE 406

stant temperature while reactant gases are forced through it. The infiltrating gases react to deposit silicon carbide in the pores. However, pores near the surface tend to become filled before those inside the preform. The canned-off surface pores greatly reduce the rate of infiltration to, and deposition in, the pores deeper in the preform. To promote further infiltration and deposition deep within the preform, the canned-off surface layer must be removed by diamond grinding (this subprocess is called "skin-ning" in the industry). The ground preform must be then returned to the CVI reactor for further infiltration.

One version of the modified CVI process (see figure) is similar to conventional forced-flow isothermal CVI in some respects. However, unlike in the conventional process, the upstream surface of the preform is first

covered with the sacrificial surface layer, which is typically made of either (a) the same material as that of the preform but without a protective fiber coating like that used in the preform or (b) any other high-temperature material that allows diffusion of the reactants and does not become bonded to the preform. The preform is then subjected to CVI. As CVI progresses, the differential pressure of reactant gases across the preform is monitored continuously; when the pressure has risen sufficiently to indicate that the sacrificial layer has become canned off, the preform is removed from the CVI reactor, the sacrificial layer is peeled or tapped off (this takes about two minutes at most), a new sacrificial layer is applied to the surface, and the preform is returned to the reactor for further infiltration.

The sacrificial layer also acts as a diffuser, helping to distribute the reactant gases more evenly. It also acts as a filter, screening out contaminants so that the material deposited in the pores is pure silicon carbide only.

This work was done by M. A. Kmetz, Paul Allard, Dave Wagner, and Chris Kogstrom of United Technologies Pratt & Whitney for Lewis Research Center. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Materials category, or circle no. 113 on the TSP Order card in this issue to receive a copy by mail (\$5 charge).

Inquiries concerning rights for the commercial use of this invention should be addressed to NASA Lewis Research Center, Commercial Technology Office, Attn: Tech Brief Patent Status, Mail Stop 7-3, 21000 Brookpark Road, Cleveland, Ohio 44135. Refer to LEW-15691.

Unsymmetrical Squaraine Dyes for Nonlinear Optics

Molecular structures are engineered to enhance second-order polarizabilities.

NASA's Jet Propulsion Laboratory, Pasadena, California

Dyes based on unsymmetrical squaraine molecules (see Figure 1) have been invented for use in a variety of optical devices that exploit nonlinear optical properties to change the frequency and/or polarization of light in useful ways. Examples of such devices include second-harmonic generators, spatial light modulators, parametric oscillators, and some interferometers.

The unsymmetrical squaraine molecular structures are engineered to obtain large values of first electronic hyperpolarizability (β); that is, the second-order polarizability that gives rise to the desired nonlinear optical response.

The molecular-engineering strategy is derived from some observations concerning two limiting charge-transfer resonance forms that occur in the molecules of interest. Each molecule can be characterized, in part, by a linear combination of these two forms. If one form completely dominates, the molecule is designated as being polyenelike; if the two forms contribute equally, the molecule is designated as being cyaninelike. It has been discovered that (a) it is necessary to obtain an optimal linear combination of the two forms in order to maximize β , and that (b) the value of β can be correlat-




Figure 1. This **General Structural Formula** is only one of nine such formulas that describe the numerous unsymmetrical squaraine dyes of the invention. Note the wide variety of compounds represented by variations in the groups R_1 through R_9 .

ed with the bond-length alternation (BLA), which is the difference between the lengths of adjacent carbon-carbon bonds. As one proceeds from a polyenelike limit ($BLA > 0.12 \text{ \AA}$) to a cyaninelike limit ($BLA = 0 \text{ \AA}$), β reaches a peak at $BLA \approx 0.04 \text{ \AA}$.

Past efforts to reach this peak from the polyene limit by adding electron donors or acceptors to decrease the magnitude of BLA have usually result-

ed in $BLA > 0.10 \text{ \AA}$ — far from the value needed to maximize β . The development of the present unsymmetrical squaraine dyes followed a different approach — starting from the cyanine limit of $BLA = 0$. Squaraine dyes are analogous to cyanine dyes in that like cyanine dyes, they are characterized by two degenerate resonance forms and sharp and intense visible or near-infrared absorption spectral




Figure 2. These Dyes Are Synthesized by condensing monosubstituted squaric acid precursors with neutral or ionic donors.

bands. However, unlike ionic cyanines, squaraines are neutral molecules that are suitable for measurement of electric-field-induced second-harmonic generation.

The unsymmetrical squaraine dyes of this invention are synthesized by condensing monosubstituted squaric acids with neutral or ionic donors. For example, in the synthesis illustrated in the upper part of Figure 2, the monosubstituted squaric acid precursors could be 1-(4-isopentyloxyphenyl)-2-hydroxycyclobutene-2,4-dione, and the neutral donor (D-H) could be 4-N,N-dibutylamino-3',5'-dihydroxystilbene. For another example, in the synthesis illustrated in the lower part of Figure 2, the monosubstituted squaric acid precursor could be 1-(4-methoxyphenyl)-2-hydroxycyclobutene-2,4-dione and the ionic donor (Htr-CH₃)⁺X⁻ could be N-butyllepidinium iodide.

Depending on specific applications, these dyes can be used alone (e.g., in crystalline and/or thin-film form) or can be incorporated into thin films, crystals, liquids, and/or gases in mixtures with other materials that are conventionally used in nonlinear optical devices. A particularly convenient and effective way of using a dye of this invention is to disperse the polar dye molecules in a polymeric binder. The polymer/dye mixture can be heated to a temperature at which the polymer becomes sufficiently soft so that upon application of an electric field, the polar molecules line up along the direction of the field. When the mixture cools, the polar molecules are locked into their field-aligned orientation, and so the electric field can be removed without loss of orientation.


This work was done by Seth R. Marder, Chin-Ti Chen, and Lap-Tak Cheng of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Materials category, or circle no. 142 on the TSP Order card in this issue to receive a copy by mail (\$5 charge).

In accordance with Public Law 96-517, the contractor has elected to retain title to this invention. Inquiries concerning rights for its commercial use should be addressed to:

*Technology Reporting Office
JPL*

*Mail Stop 122-116
4800 Oak Grove Drive
Pasadena, CA 91109
(818) 354-2240*

Refer to NPO-19398, volume and number of this NASA Tech Briefs issue, and the page number.



A smaller, lighter, and more powerful capacitor. EVANS


The Evans Capacitor Company
P. O. Box 14158
East Providence, RI 02914-0158
(401) 434-5600 Fax (401) 434-6908
www.evanscap.com

The new Evans Hybrid[®] is an electrolytic-electrochemical capacitor with incredible properties:

- As little as 1/10 the volume of aluminum electrolytics
- 1/2 the weight of aluminum electrolytics

In two design styles, a hermetic tantalum package and a polypropylene package, Evans Hybrids are excellent for avionics, power supplies, power filtering, communications, weapons systems, medical applications, auto auxiliary systems and many very special uses.

Hybrids are designed and manufactured by the Evans Capacitor Company, known for the Capattery[®], the world's leading electrochemical capacitor.



The Power of Green Is Now Affordable.

The power of YAG green now fits almost any budget with the introduction of the **DY** and **DYH Series** Nd:YAG lasers from Power Technology, Inc.

The single piece **DY Series** YAG lasers are available in powers of 1.0, 3.0, 5.0, 10.0, and 20.0 mW. The 532nm units require an input voltage of only 12VDC with a 3A maximum input current. Axial beam alignment and beam centering are standard on the **DY Series**.



DY Series Nd:YAG

LED indicators advise when the laser is on or in standby mode. The nonvolatile digital potentiometer to control laser drive current is optional.

The two piece **DYH Series** is available in powers of 50, 100, and 150mW and requires only 12VDC and 3.5A maximum input current.

Telescopes, beam expanders, and an optical bench mount are just a few of the options that are now available.

CW Starting At \$1,700



Address correspondence to: Box 191117
Plant location: 7925 Mabelvale Cutoff
E-mail: Sales@PowerTechnology.com

Little Rock, Arkansas 72219-1117
Mabelvale, Arkansas 72103-2213
Home Page Address:

501-568-1995
Fax 501-568-1994
www.PowerTechnology.com



Computer Software

❏ The SPICE System

The Navigation and Ancillary Information Facility (NAIF) at JPL has built a multimission, multidiscipline information system named SPICE, which is of use to scientists and engineers involved with mission evaluation, mission operations, observation planning, and science data analysis. SPICE has two principal components — a set of data file specifications and a collection of software used to write SPICE files and to read and utilize the data within SPICE files. The SPICE files, called “kernels,” contain a variety of space science geometry, including ephemerides and size, shape, and orientation for planets, satellites, comets, and asteroids; spacecraft trajectory; spacecraft orientation; and instrument viewing geometry. Also included in SPICE files is nongeometric information, such as sequence of events and electronic notebook. The software component of SPICE is the NAIF Toolkit. The principal component of this Toolkit is a large library of FORTRAN subroutines known as SPICELIB. Included in SPICELIB are subroutines used in both writing and reading SPICE kernel files, and higher-level routines used to process SPICE kernel data to compute a wide assortment of observation geometry, such as observer-target direction and range, sub latitude and longitude, lighting angles, and the like. Users integrate selected NAIF Toolkit routines into their own application programs to help accomplish whatever objectives are at hand. The kernel file structures and Toolkit software are designed with portability as a key attribute: the SPICE system will work on any computer that supports ANSI FORTRAN 77, and C language interfaces to the most used subroutines are being added. Flexibility is also a key attribute: the system architecture is easily extended to handle new requirements. A customer may choose to use a subset of the SPICE capabilities. SPICE defines the data standards for ancillary data to be archived within NASA's Planetary Data System. SPICE is used on most NASA planetary missions. It has been used to support a number of astrophysics and space physics applications, and has been suc-

cessfully demonstrated with Earth-observing spacecraft. SPICE is also used by terrestrial observatories.

This program was written by Charles Acton, Nathaniel Bachman, Kevin Gehringer, William Taber, and Boris Semenov of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Computer Software category, or circle no. 164 on the TSP Order card in this issue to receive a copy by mail (\$5 charge).
NPO-19984

⚙ Program for Analyzing Flutter of Propfan Blades

Stimulated by the interest in improvement of aircraft fuel efficiency, Lewis Research Center initiated an effort to develop refined analytical methods and associated computer codes for predicting flutter of propfans. The ASTROP2 computer program performs aeroelastic-stability analysis of rotating propfan blades. It uses strip theory to integrate aerodynamic forces calculated by use of a two-dimensional model of aerodynamics with a three-dimensional model of the structure.

The flutter analysis is performed by two separate subprograms. The first subprogram calculates the structural dynamics at the strips required for the analysis of aeroelasticity. The second subprogram uses the structural data from the first subprogram and calculates the aeroelastic stability. Each subprogram can be used and modified independently.

ASTROP2 is written in FORTRAN 77 and has been successfully compiled and run on a SUN 4 SLC workstation running SunOS 4.1.3_U1, an SGI IRIS INDIGO workstation running IRIX 6.2, and a SUN 4 IPC workstation running SunOS 5.4/Solaris 2.4. The program also functioned properly on a CRAY/Y-MP computer running UNICOS 8.0.4.1 with the CFT77 6.0.5.0 compiler. The standard distribution medium for ASTROP2 is a 4-mm digital audio tape in UNIX tar format. Alternate distribution media and formats are available on request. ASTROP2 was released in 1996.

This program was written by J. M.

Lucero of Lewis Research Center, T. S. Reddy of the University of Toledo, and G. V. Narayanan of Sverdrup, Inc. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Computer Software category, or circle no. 146 on the TSP Order card in this issue to receive a copy by mail (\$5 charge).

LEW-16407

❏ Computer Program for Emulating MIL-STD-1750a Computer

CPU_1750a is a software program that implements the MIL-STD-1750a Military Standard Sixteen-bit Computer Instruction Set Architecture. It emulates a MIL-STD-1750a compliant computer hardware system.

CPU_1750a provides a unified mechanism for integration with software that emulates peripheral hardware. It is used to implement a software emulation of a complete digital avionics system such that MIL-STD-1750a software may be developed and


COSMIC, NASA's Software Technology Transfer Center, has an inventory of over 800 software packages that originally were developed by NASA and its contractors for the U.S. space program. These packages have a wide range of applications other than space exploration and are used by industry, academic institutions, and other government agencies.

For further information about software available from COSMIC, or to receive a free diskette catalog, contact COSMIC at:


COSMIC
The University of Georgia
382 East Broad Street
Athens, GA 30602-4272
Phone: 706-542-3265
Fax: 706-542-4807
e-mail: service@cosmic.uga.edu
WWW:
<http://www.cosmic.uga.edu>

MATHEMATICA®

THE WORLD'S ONLY FULLY INTEGRATED ENVIRONMENT FOR TECHNICAL COMPUTING



Expand Your Command of the Mathematica System
1997 Mathematica Developer Conference
 October 27-29 • Champaign, Illinois
<http://www.wolfram.com/conf97/ntb>
 REGISTER TODAY!



In science, technology, engineering, finance, medicine, research, education—over a million professionals and students now rely on Mathematica to do their work.

For projects large and small, from initial concept to final report, Mathematica has defined the state of the art in technical computing for nearly a decade.

NUMERICAL COMPUTATION

World's most complete collection of mathematical functions • Unlimited numerical precision • Matrix and tensor operations • Ordinary and partial differential equations • Fourier transforms • Data manipulation, fitting, and statistics • Root finding • Optimization • Number theory

SYMBOLIC COMPUTATION

State-of-the-art computer algebra algorithms • Simplification • Polynomial factoring and manipulation • Symbolic integration • Algebraic and differential equation solving • Symbolic matrix operations • General list and string processing

ADVANCED LANGUAGE

Award-winning intuitive symbolic language • Procedural, functional, list-based, rule-based, and object-oriented programming • Uniform symbolic expression representation of all objects • Fully scalable from small to large programs

GRAPHICS AND SOUND

2D, 3D, contour, and density plots • General 3D object visualization • Animation • Sampled sound • High-level symbolic graphics description language • Resolution-independent PostScript output • Export and import of standard graphics formats

PROGRAMMABLE INTERFACE

Customizable palettes • Free-form 2D input • Complete math notation • 700+ math and other characters • Programmable notation rules

NOTEBOOK DOCUMENTS

Interactive documents with text, graphics, sound, and math • Publication-quality editable typeset formulas and tables • Full range of formatting options • Automatic optimization for screen and print • Export capabilities in TeX, HTML, and more • Fully programmable symbolic representation • Free *MathReader*

SYSTEM FEATURES

100% platform independent • Microsoft Windows, Macintosh, Unix/X • Unicode support • General MathLink® API • Distributed computing

APPLICATIONS LIBRARY

Over 30 products now available in data analysis, wavelets, time series, optics, astronomy, control systems, mechanical systems, structural mechanics, electrical engineering, finance, education, and more

FULL SERVICE

3000+ pages of award-winning on-line documentation • Three levels of technical support and consulting • 200+ books available • Volume discounts • Flexible academic site programs • Versions for students and teachers

Now Shipping
VERSION 3.0.1
 Released May 22, 1997



Information and purchases: <http://www.wolfram.com/v3/ntb>
 or call 1-800-416-8069 All Mathematica products are available for Microsoft Windows, Macintosh, and most Unix platforms.

Wolfram Research, Inc.: <http://www.wolfram.com>; info@wolfram.com; +1-217-398-0700
Wolfram Research Europe Ltd.: <http://www.wolfram.co.uk>; info@wolfram.co.uk; +44-(0)1993-883400
Wolfram Research Asia Ltd.: <http://www.wolfram.co.jp>; info@wolfram.co.jp; +81-(0)3-5276-0506
 © 1997 Wolfram Research, Inc. Mathematica and MathLink are registered trademarks of Wolfram Research, Inc. and are not associated with Mathematica Policy Research, Inc. or MathTech, Inc.

For More Information Circle No. 524

**WOLFRAM
 RESEARCH**

LEADERS IN ADVANCED COMPUTING

tested prior to the availability of hardware. The extensive visibility provided by CPU_1750a allows development and debugging to proceed more rapidly than is possible on many hardware-based development systems.

Powerful user interfaces can be quickly created. CPU_1750a provides read/write access to internal state (registers, memory, and page registers, and emulator control variables and functions) that is designed to be comparable with Tool Command Language (Tcl). Breakpoints and instruction trace are controlled via Tcl, and may in turn activate Tcl procedures upon activation.

CPU_1750a fully implements the MIL-STD-1750a instruction set. It passes all SEAFAC VSW V2.1 verification tests. CPU_1750a can be configured

with multiple personalities, which can be selected during runtime. Three personalities are currently available: MIL-STD-1750a, IBM GVSC, and IBM GVSC with breakpoints and instruction trace capability. Personalities are implemented so that performance of one personality is not dependent upon features implemented in another personality so that performance is always as high as possible.

CPU_1750a implements all mandatory and optional MIL-STD-1750a features, including: interval timers, expanded memory, memory block protect, startup ROM, and access lock/key.

CPU_1750a is written in C++. It executes over 400,000 instructions per second on a Sun SPARC 10/51.

This program was written by William K.

Reinholtz and Mohammad Shahabuddin of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Computer Software category, or circle no. 126 on the TSP Order card in this issue to receive a copy by mail (\$5 charge).

In accordance with Public Law 96-517, the contractor has elected to retain title to this invention. Inquiries concerning rights for its commercial use should be addressed to Technology Reporting Office

JPL

*Mail Stop 122-116
4800 Oak Grove Drive
Pasadena, CA 91109
(818) 354-2240*

Refer to NPO-19734, volume and number of this NASA Tech Briefs issue, and the page number.

NASA's Software of the Year


NASA's 1997 Software of the Year Awards will be presented on September 23 at a special Awards Reception during Technology 2007 to be held in Boston from September 22-24. Chosen by NASA's Inventions and Contributions Board, the awards are given to individuals who develop software that enhances NASA's missions and assists U.S. industry in maintaining world-class technology status.

1997 Winner:

Dynamics Algorithms for Real-Time Simulations (DARTS), developed by NASA's Jet Propulsion Laboratory, Pasadena, CA (Drs. Abhinandan Jain, Guillermo Rodriguez, and Guy K. Man)

The 1997 Software of the Year was used by JPL to keep the Pathfinder spacecraft on course as it cruised toward Mars. DARTS software has saved over \$10 million to date on NASA missions including Pathfinder, Galileo, and Cassini. It is a high-fidelity, flexible multibody dynamics simulator used for real-time hardware-in-the-loop design, integration, and testing of spacecraft flight software. DARTS allows the use of high-fidelity spacecraft dynamics models without sacrificing simulation speed, enabling more reliable flight-software design and testing, reduced development costs, and increased mission safety.

During Pathfinder's journey to Mars, the slightest variation in trajectory would have sent the spacecraft far afield



DARTS software helped keep Mars Pathfinder on course; it also has potential in the research and development of new drugs, catalysts, and polymers.

of its target. The flight plan included five midcourse corrections during which the spacecraft's thrusters would fire to refine its trajectory. NASA controllers ran commands through DARTS before sending signals to Pathfinder. This enabled them to verify that a command would have the desired result. During Pathfinder's seven-month flight, mission controllers made four midcourse corrections using DARTS. There was no need for a fifth: Pathfinder was still dead on target.

DARTS is based on a new form of mathematics called Spatial Operator Algebra (SOA), which also was invented by Drs. Jain, Rodriguez, and Man. SOA is a mathematical approach for modeling the dynamic behavior of complex, articulated collections of bodies interacting with each other in free-space or in contact with the environment.

DARTS was used to guide the Galileo spacecraft through its course around Jupiter's four largest moons, and it will be an important part of the Cassini mission to Saturn. SOA-based software also may help scientists uncover the structure and function of proteins and enzymes; of protein-folding mechanisms; and drug, catalyst, and polymer designs.

1997 Runners Up:

(in alphabetical order):

- **Micromechanics Analysis Code with Generalized Method of Cells (MAC/GMC)**, developed by NASA's Lewis Research Center, Cleveland, OH (headed by Dr. Steven M. Arnold) A comprehensive program for predicting a material's response to thermal and mechanical loads.
- **STructural Analysis RoutineS (STARS)**, developed by NASA's Dryden Flight Research Center, Edwards, CA (headed by Dr. Kajal K. Gupta) An analysis package of integrated finite element software developed for the solution of linear and nonlinear engineering problems.
- **Thickness-Independent Ultrasonic Imaging Software**, developed by NASA's Lewis Research Center, Cleveland, OH (headed by Dr. Don J. Roth) The software enhances materials characterization by ultrasonic imaging, eliminating the effects of sample-thickness variations.

High-Tech consoles under the symbol of the knight.

Cost-effective, flexible, ergonomic: individual standard solutions from our Dacobas furnishing range.


- **Cost-effective:** unrestricted access to cable shafts and built-in equipment eliminates downtimes during service operations. Fast assembly with patented quick-connect system.
- **Flexible:** modular structure permits a host of diverse furnishing design solutions. Upgrading, expansion and modification can be carried out at any time.
- **Ergonomic:** conformity with international standards including DIN 33402 (anthropometric dimensions), DIN 33414 (ergonomic design of control rooms) and DIN 66234 (VDU workstations).

dacobas®



elidos®

The future proof workstation system that combines ergonomics and economy. Height-adjustable surfaces, variable depths and depth-upgradable worktops suit the user's individual requirements.



miracel®

Universal application in all areas is guaranteed by the design of the Miracel 19" rack for electronics: a stable lightweight, cost-effective multiuse rack system.





Focus-Ring Mechanism Translates Lenses Without Rotation

The parts of the mechanism need not be highly precise.

NASA's Jet Propulsion Laboratory, Pasadena, California

The figure illustrates a camera lens barrel and a mechanism for translating the lens barrel along its optical axis. Unlike some other focusing mechanisms, this one does not rotate the lens barrel about the optical axis — an essential feature if the lenses and/or other optics in the barrel are asymmetric and are required to be kept in a specified alignment with respect to a line in the focal plane.


The lens barrel slides axially within a stationary camera barrel. The mechanism includes a focus ring that is approximately concentric with the barrels. The focus ring pivots about a fixed point

under the camera barrel, and the tilt of the ring can be varied by use of an adjustment screw atop the camera barrel. As the tilt of the ring changes, it pushes axially on (or allows itself to be pushed axially by) tabs on the lens barrel. These tabs are spring-loaded against similar but fixed tabs on the camera barrel. As the tabs on the lens barrel push against (or are pushed by) the spring load, the lens barrel translates along the axis.

The adjustment screw could be any of a variety of suitable screws with standard fine pitches, e.g., 32 threads per inch [pitch of 0.3125 in. (about 0.79 mm)]. Because the point of contact between

the ring and the lens barrel is halfway along the lever arm, the axial translation of the lens is half that of the adjustment screw. Thus, continuing the above example, one full turn of the screw translates the lens assembly about 0.016 in. (0.4 mm), while a partial turn of 10° translates the ring only about 0.00043 in. (0.011 mm).

The only motion-producing surfaces that need be machined to high precision are the outer-diameter surface of the lens barrel and the inner-diameter surface of the camera barrel; these surfaces are required to mate with each other in a smooth sliding fit with mini-



Rotation of the Adjustment Screw pivots the ring slightly, causing the ring to push on the tabs and thereby translate the lens barrel along the optical axis.

Easy does it!

"...I didn't need a single day of training!"

— Lukaš Kucera
Lekov

"The ease of use of Solid Edge is unprecedented."

— Raymond Wentink, TuMiC

"We overestimated the learning curve."


— Ralf Schwarz
Kaeser Kompressoren

"... we were able to get up and running with Solid Edge the easiest."

— Erik Schlusser
Watsco Components

"I was self-taught..."

— Scott Strickland
McDonnell Douglas
Aerospace



3 D S O L I D M O D E L I N G

If you need the competitive advantages of solid modeling design techniques but don't have the time to learn complicated CAD modeling procedures, you should investigate Solid Edge.™



INTERGRAPH
SOLID EDGE™

Solid Edge is the first industrial-strength solid modeling system with the ease-of-use advantage. It works like designers think – so you can spend more time designing and less time concentrating on how to get the CAD system to do what you want.

If you want to become a solid modeling expert in your spare time, join the thousands of mechanical design professionals who have moved to solids in record time with Solid Edge.

Call to get your **FREE** Solid Edge multimedia demonstration CD-ROM:

1-800-807-2200

Fax: 1-205-730-1053

E-mail: solidedge@ingr.com

Web: www.intergraph.com/solidedge




Intergraph and the Intergraph logo are registered trademarks and Solid Edge and the Solid Edge logo are trademarks of Intergraph Corporation. Microsoft and Windows are registered trademarks and Microsoft Office 97 Compatible is a trademark of Microsoft Corporation. Copyright 1997 Intergraph Corporation, Huntsville, AL 35894-0001. MC970519

INTERGRAPH
SOFTWARE SOLUTIONS

For More Information Circle No. 527

Take Control of Your Position!

**But don't do it alone,
let Data Technology help you
with one of our many
available encoders.**



**SM15 Advanced Small
Industrial Encoder**

- * Available in line counts up to 2000 PPR * Miniature shielded ball bearings * Fast operating speeds (200 kHz) * Shaft loading max: Radial 4.4 lbs., Axial 2.2 lbs. * Bearing life: 11.2×10^9 revolutions * Dual channel 90° phased with optional index pulse * Available with differential outputs * Line driver a standard * TTL & CMOS compatible



**SM23 Low Cost
Multipurpose Encoder**

- * Available in line counts up to 2500 * Precision surface mount technology * 200 kHz standard frequency inclusive of A, B and Z outputs * Face & servo mount standard * Shaft loading max: Radial 10 lbs., Axial 10 lbs. * TTL & CMOS compatible



**DT25 Industrial Sealed
Heavy Duty Encoder**

- * Available in line counts up to 5400 on the disc (up to 86,400 PPR with multiplier logic) * 200 kHz operating frequency * Bearing thrust max: 40 lbs. (156 N) * Radial force max: 35 lbs. (156 N) * TTL & CMOS compatible



**RS23 Instrument
Quality Encoder**

- * Available in line counts up to 2500 * Frequency response 200 kHz or 3000 RPM, whichever occurs first * Shaft loading max: Radial 10 lbs. (4.54 Kg) Axial 10 lbs. (4.54 Kg) * Bearing life: 2.8×10^9 revolutions * Differential line driver available * Drive capability is TTL & CMOS compatible

These are only a few of the many encoders we manufacture. We will work with you to provide you the encoder you need. We offer expedited service to ensure customer satisfaction.



DATA TECHNOLOGY, INC.
260 A Fordham Road
Wilmington, MA 01887
1-800-331-5797 Tel: (781) 935-8820
Fax: (781) 935-9656

**Data Technology -
Your encoder company
into the 21st century.**

mal radial play. The parts of the focusing mechanism can be fabricated without high precision. The adjustment screw and the spherical bearings on which the ends of the adjustment screw turns can be fabricated easily and inexpensively.

The mechanism can be upgraded in several ways. The adjustment screw could be modified to accept a motor drive so that the lens system could be focused under remote control. The adjustment screw could be made as a differential screw by machining it with dual threads, each having a slightly different pitch; this would greatly increase the resolution of the focus adjustment. Radial play could be eliminated by mounting the lens barrel on flexures configured to allow movement along the optical axis; in that case, it would no longer be necessary to enclose the lens barrel in a camera barrel.

This work was done by Richard E. Fleischer of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Mechanics category, or circle no. 156 on the TSP Order card in this issue to receive a copy by mail (\$5 charge). NPO-19711

Portable Computer Workstations for Engineering Teams

Units could be assembled in modular fashion to perform specific team engineering tasks.

*NASA's Jet Propulsion Laboratory,
Pasadena, California*

Figure 1 illustrates a proposed ergonomically designed unit of furniture that would house a personal computer workstation. The unit could be used alone but is meant to be assembled with other such units in modular fashion for use by an engineering design team. The unique configuration of the unit is chosen to




Figure 1. The Ergonomic Design of This Unit would provide for efficient utilization of space and adjustability for the user's comfort.

World's Fastest A/D Cards for PCI and ISA Bus

16 Bit A/D Cards at Ultra-Fast Speeds Up To 10 MSPS



New

CompuScope 1016

- ◆ 16 Bit Resolution
- ◆ 10 MSPS Sampling
- ◆ 5 MHz Bandwidth
- ◆ Very High Dynamic Range
- ◆ 85 dB SFDR
- ◆ Up to 8 Meg Memory


CompuScope 8500/PCI

- ◆ 500 MSPS Sampling A/D Card
- ◆ 8 Bit Resolution
- ◆ 100 MB/s Data Transfer Rate to PC Memory
- ◆ Up to 2 Meg Memory



Also Available:

- Up to 100 MSPS, 12 Bit A/D Card on ISA Bus
- Up to 250 MSPS, 2 GS/s, 8 Bit A/D Card on ISA Bus
- 16 Meg Memory
- Up to 16 Cards in one Industrial PC
- Drivers in DOS, QNX, Win 3.1, Win 95 and Win NT
- Support for HP VEE, LabVIEW, LabWindows CVI,...



GaGe

GAGE APPLIED SCIENCES INC.
1233 Shelburne Road, Suite 400
South Burlington, VT 05403

Call 1-800-567-GAGE

Ask for extension 3406

Tel: 1-800-567-4243 Fax: 1-800-780-8411 e-mail: prodinfo@gage-applied.com web site: <http://www.gage-applied.com>

From Outside the U.S. contact, Gage Applied Sciences Inc., 5610 Bois Franc, Montreal, QC, Canada, H4S 1A9 Tel: 514-337-6893 Fax: 514-337-9844

facilitate face-to-face verbal and visual communication and thereby promote collaboration among engineers on the team who specialize in different disciplines.

The main computer housing would be

placed on the shelf below the table to maximize the work space available to the user on the table. The shelf would be set back to provide room for the seated user. The height of the table could be

adjusted to suit the user, or to enable storage of the unit under a conference table or other piece of furniture.

The computer video output would be presented on a large, high-resolution, flat-screen display device, which would be mounted on an articulating arm that the user could adjust to position and orient the screen for comfort in viewing. The articulating arm could also be used to fold the screen out of the way for storage.

The peculiar nonrectangular shape of the table is chosen to please the eye and to promote creativity. Because of its bilateral symmetry, the table would be suitable for either a right- or a left-handed user. The unit would be light in weight and mounted on wheels for portability. Multiple units could readily be wheeled together in any of a large variety of cluster or line arrangements (see Figure 2) according to the number of collaborators and the preferred mode of interaction.

This work was done by Danette G. Klein and James Duke of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Mechanics category, or circle no. 129 on the TSP Order card in this issue to receive a copy by mail (\$5 charge). NPO-20010




Figure 2. These Are Only Two of many possible ways in which multiple units could be arranged to promote collaboration among multiple users.

Liability

Asset



Handling and Treatment of Metal Chips

Call on us

The SOLUTIONS

for your needs

are in our hand



For more details
please contact
Charlie Gaal at
Alesa Alusuisse Canada Ltd

245 Victoria, Suite 700
Westmount, Quebec, H3Z 2N1
Tel: (514) 937-9105
Fax: (514) 937-0473

What makes new Mathcad 7 the world's most innovative calculation software? Let's talk addition.



MORE POWER




EASIER TO USE




TOTALLY WIRED

How did simple addition make Mathcad 7 exponentially better? Consider what was added. Like increased power. A more refined interface. Easier equation editing. A richer programming environment. Greater access to deep technical content. And full Web integration — with Microsoft®


Internet Explorer built right in. All these additions let corporate workgroups increase productivity — so it's no wonder Mathcad continues to be the world's best-selling calculation software for technical professionals. Looks like the best just got better.



New MathConnex™ gives you the flexibility to combine components from several applications, such as Excel or MATLAB™, in a fully functional system. Feed the frequency output to a Mathcad plot or the gain curve to Axum®. Wire them together and show your entire model working in one window.



New symbolic keywords allow you to descriptively show the operations you perform. Convert an expression to a partial fraction and Mathcad's self-documenting nature explains what you're doing. As always, Mathcad's calculations are live: make a change and your answers are recalculated instantly.



Full support for OLE 2 including automation allows you to drag-and-drop Excel objects into Mathcad and make them functional components, or embed Mathcad objects in your spreadsheet.

To upgrade call **1-888-568-0951**. To order Mathcad 7, visit us at www.mathsoft.com/mathcad or see one of these fine retailers.

For corporate licensing, call **1-800-MATHCAD**.

SciTech
SOFTWARE FOR SCIENCE

COMPU
THE COMPUTER EXPERTS

COMPUTER CITY

ADEPT
SCIENTIFIC

MICRO CENTER
THE COMPUTER SUPERSTORE

EGGHEAD SOFTWARE

Includes
Microsoft
Internet
Explorer

Designed for
Microsoft
Windows NT
Windows 95

MathSoft, Inc., 101 Main Street, Cambridge, MA 02142 USA • Phone: 617-577-1017 • Fax: 617-577-8829 MathSoft International, Knighway House, Park Street, Bagshot, Surrey GU19 5AQ UK Tel: +44(0)1276 452299 • Fax: +44(0)1276 451224 • Mathcad 7 Professional and Mathcad 7 Standard are available for Windows 95 and Windows NT 3.51 and higher.





Imagine! Fast Morphology for about \$30



It's from Sumitomo, of course.

If your design calls for a rank value filter that quickly extracts minimum, maximum and median values in real time without breaking your budget, Sumitomo Metals has the answer. Our IP90C20 processes at 50 MHz so it's perfect for high-speed, high-density image data.

But we didn't stop there. Selecting the operating mode is easy, it has low power demand (CMOS process), uses a 5V single power source and has a 44-pin package for a wide variety of applications. All at an unbeatable price.

For detailed specs and more information on Sumitomo's family of reliable and inexpensive pipeline processors for image processing and machine vision, contact us now.



SUMITOMO METALS

1-800-392-4447

Park 80 West Plaza 1, 3rd Floor, Saddle Brook, NJ 07663

Phone: (201) 845-0980 Fax: (201) 845-5139

5201 Great America Parkway, Suite 320, Santa Clara, CA 95054

Phone: (408) 982-2503 Fax: (408) 982-2522

For More Information Circle No. 422


How To End Mass Confusion.

OEMs, be confused no more. The Setra Mass Monitor™ has it all. It's modular, easy to install and highly accurate. And unlike most load cells, it gives you direct digital output — no A/D converter required. That's because the Setra Mass Monitor uses our patented variable capacitance ceramic sensor technology.

No wonder *Designfax* gave the Setra Mass Monitor five stars.

And no wonder there are over 2,000 units in service today. So don't put up with mass confusion. Call Setra at 1-800-25-SETRA.

FAX: 1-508-264-0292



Mass Monitor

setra

The technology leader in precision weighing.


For More Information Circle No. 423

Model-Based Placement of Gearbox-Monitoring Accelerometers

Locations are ranked with respect to utility for measuring vibrations to diagnose faults.

Lewis Research Center, Cleveland, Ohio

A model-based methodology has been devised as a systematic means for selecting locations of accelerometers on a helicopter gearbox to measure vibrations indicative of cracked or pitted gear teeth, damaged bearings, and other gearbox faults. In the envisioned application, the outputs of the accelerometers would be fed to an onboard computer and processed to diagnose faults during flight. However, it is not practical to install and process the readings of a large number of accelerometers, each positioned on or near a gearbox component vulnerable to failure. The problem then becomes one of selecting locations for a limited number of accelerometers in such a way as to



A Helicopter Gearbox was instrumented with accelerometers at eight locations for experiments on monitoring vibrations to diagnose faults.

obtain the required diagnostic capability to some quantifiable degree. The methodology offers a solution that involves quantification of the significance of each accelerometer and its location in diagnosis.

Ideally, the significance of each accelerometer and its location could be determined empirically by comparing the results of diagnoses performed with and without the accelerometer. However, to be able to do this, one would need a comprehensive set of measurement data associated with all possible faults; in general, such a set of data is not available. The methodology provides a partial substitute for such an empirical assessment, on the basis of (a) relationships between component faults and accelerometer readings as expressed by an influence mathematical model obtained from (b) a lumped-masses-and-springs simplified mathematical model of the vibrational properties of the gearbox.

The influence model is used to compute the following three indices that represent the effectiveness of accelerometers for monitoring various gearbox components:

- The diagnosability index for each component is defined as a sum of coefficients of influence of that component on all the accelerometers, and is taken to be an indication of the ability to diagnose a fault in that component.
- The coverage index of an accelerometer is defined as a sum of coefficients of influence of all gearbox components on that accelerometer, and is taken as a measure of the "reach" or "coverage" of the accelerometer; that is, of the number of gearbox components that the accelerometer can monitor.
- The redundancy index of an accelerometer is a measure of the overlap of the sensory domain of that accelerometer with the sensory domains of other accelerometers; an accelerometer is deemed to be redundant if the components it covers are already covered, with greater coefficients of influence, by other accelerometers.

Accelerometers alone or in groups can be ranked according to the effects of the deletion of the specified accelerometers upon these indices. Those accelerometers, the deletion of which would result in the greatest losses in the values of these indices, are ranked highest to indicate their significance in diagnosis.

This model-based methodology was tested in experiments on an OH-58A main rotor gearbox. In the experiments, piezoelectric accelerometers were installed at eight locations on the gearbox (see figure) and used to measure vibrations in five tests that lasted for various numbers of days. During the tests, nine pitting failures and two cracking failures occurred. The outputs of the accelerometers were digitized and processed by diagnostic algorithms. The model-based methodology was applied and used to rank the individual accelerometers. These rankings were found to agree well with rankings obtained empirically.

This work was done by Vinay B. Jammu, Keming Wang, and Kourosh Danaei of The University of Massachusetts and David G. Lewicki of the Propulsion Directorate of the U.S. Army Research Laboratory for Lewis Research Center. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Mechanics category, or circle no. 123 on the TSP Order card in this issue to receive a copy by mail (\$5 charge).

Inquiries concerning rights for the commercial use of this invention should be addressed to NASA Lewis Research Center, Commercial Technology Office, Attn: Tech Brief Patent Status, Mail Stop 7-3, 21000 Brookpark Road, Cleveland, Ohio 44135. Refer to LEW-16452.

Paroscientific, Inc.

Digiquartz® Pressure Instrumentation

Features:

- **0.01% Accuracy**
- 1×10^{-8} Resolution
- Digital Output Signal
- Environmentally Rugged
- High Reliability & Stability
- ISO 9001 Quality System
- 5 Year Extended Warranty

Products:


- Barometers
- Transducers
- Transmitters
- Depth Sensors
- Portable Standards
- Fiber-Optic Systems
- Water Stage Sensors
- Meteorological Systems

4500 148th N.E., Redmond, WA 98052

Tel: (425) 883-8700 Fax: (425) 867-5407

Internet: <http://www.paroscientific.com>

For More Information Circle No. 424



Turcon® Variseal™ W

Longer Wearing Seals

- **Low friction Turcon®**
- **Temperatures to 575 °F**
- **Universal compatibility**
- **1/32" to 192" diameter**
- **Three spring loads to meet your exact force and torque requirements**

Call: 1-800-466-1727


The Turcon® Variseal™ W, a wear-resistant seal made from premium PTFE blended materials and energized by our patented *Slantcoil*® spring, provides you with a longer-lasting, tighter-sealing solution. Call for a free *Seal Selection Guide*.
Fax: 1-303-469-4874
web: www.variseal.com

ISO 9002

American Variseal


HOT! HOT! HOT!

PIXCI™-D



\$995 List Price (USA)

- Line Scan or Area Scan
- Single or Dual Channel
- Up to 20 Bit Camera Data
- External Trigger In/Out
- 32 bit PCI Bus Master
- 132MB/s Burst Transfers
- Image Sequence Storage to Motherboard Memory
- For Cohu, Dage, Dalsa, Hitachi, Kodak, Pulnix, Thomson, and others



WinNT, Win95, DOS Software for:

- Image Enhancement & Archival
- Image Analysis & Measurement
- Visual Inspection & Comparison
- Document Capture
- Machine Vision & Quality Control
- Particle Analysis, Counting & Tracking
- Cine-Loop Capture, Flow Analysis

Application Questions?

847-465-1818

<http://www.epixinc.com/epix>

EPIX®

EPIX, Incorporated
381 Lexington Drive
Buffalo Grove, IL 60089 USA
Tel - 847 465 1818
Fax - 847 465 1919
epix@epixinc.com

Rolled-Up Ramp Deploys Itself on Command



The ramp unfurls itself when pyrotechnic cutters are activated to release bindings.

NASA's Jet Propulsion Laboratory, Pasadena, California

The figure illustrates various aspects of a springy ramp that can be rolled tightly into a cylinder, which is then wrapped circumferentially with tie-down cables. On subsequent command, pyrotechnic devices can be activated to cut the tie-down cables, causing the ramp to deploy itself by unrolling under its own spring force. The ramp was designed to facilitate the egress of a small rover vehicle from the Mars *Pathfinder* spacecraft; modified versions of the ramp might be useful on Earth as compactly stowed, light-

weight, deployable emergency-exit ramps in buildings, land vehicles, and aircraft.

Lying lengthwise along the track are two stainless-steel tubular spring (STEM™, or equivalent) elements that can be pushed flat, against their springiness, for stowage. These elements provide the required strength, stiffness, and deployment force. Five crosswise aluminum alloy battens are attached to the STEM™ (or equivalent) elements. Thin stainless-steel tracks are located on the outboard side of



The Ramp Can Be Rolled into a cylinder for compact stowage until needed. On command, it unrolls itself under its own spring force.

each spring element; in the original spacecraft application, these are the surfaces along which the vehicle wheels are intended to roll. The tracks are attached to the STEM™ (or equivalent) and battens by screws and rivets, respectively. The tracks play a large role in reacting all inplane shear loads.

A lightweight aromatic polyamid/epoxy open-weave mesh covers the midspan of the ramp over most of its length. The mesh is attached to, and sandwiched between, the STEM™ (or equivalent) elements and tracks, and is pocketed for restraint at each batten. A cylindrical spool is attached to the outboard tip of each track and centered on the axis of the corresponding STEM™ (or equivalent) element. The spools assist during initiation of roll-up for stowage.

The inboard end of each STEM™ (or equivalent) element is fastened to a shim, which in turn, is attached to a mounting surface. Continuous strips of stainless-steel/nylon hybrid hook-and-pile material are attached to the outer sides of the top and bottom surfaces of the tracks. These strips resist peeling

with just enough force to reduce the speed of unrolling and to damp spurious unrolling movements, ensuring coordinated deployment movement like that of a carpet unrolling from a fixed end.

When stowed, the ramp is rolled up into a cylinder 7.62 cm in diameter and 42 cm long. Once the pyrotechnic devices are actuated, it takes the ramp about 1 second to unroll to its full length of 136 cm.

This work was done by Lee Sword, Howard Eisen, and Curtis Tucker of Caltech and Brian Spence, Keith Edwards, Jack Sanders, and Geoff Marks of Astro Aerospace for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Mechanics category, or circle no. 111 on the TSP Order card in this issue to receive a copy by mail (\$5 charge).

Inquiries concerning rights for the commercial use of this invention should be addressed to the Patent Counsel, NASA Resident Office-JPL; (818) 354-5179. Refer to NPO-19906.

Identifying Loose Joints in an Adaptive Truss Structure

Gaps are measured in a sequence of static force-vs.-displacement measurements.

NASA's Jet Propulsion Laboratory, Pasadena, California

A method of identification of loose joints in an adaptive truss structure is based on identification of nonlinear force-vs.-displacement behaviors in the structural members connected via the loose joints (see Figure 1). "Adaptive truss structure" as used here denotes a truss structure, at least some of the members of which are active (see Figure 2). An active member is one that contains an actuator that can apply a controllable force to the ends of the member and/or cause a controllable change in the length of the member.

Truss structures are made adaptive to provide active control for suppression of vibrations and/or to maintain precise geometric relationships among optical components mounted on the structures. Accurate knowledge of the stiffness characteristics of a structure is necessary for precise control. It is important to identify loose joints because looseness gives rise to large changes in stiffness. When either or both joint(s) at the end of a member is (are) loose and the state of the struc-

ture is such that the ends of the member lie within the looseness gap, then the member does not interact with the rest of the structure and thus does not contribute to the stiffness of the structure. The effect on the structure is equivalent to that of removing the member.





Figure 1. The Load-vs.-Displacement Curve for a member with a loose joint is nonlinear in that it exhibits zero stiffness within the looseness gap and nonzero stiffness on both sides of the gap.



Lowest Cost Data Acquisition

ADAC's new Value-Line has uncompromising design features and high quality components at prices below the low cost guys!

Just check out the specs:

Lowest Cost

5500MF

8 channels 12-bit A/D,
16 digital I/O, Counter/Timer

\$195

High Speed

5508LC

8 channels 12-bit A/D,
100KHz, DMA

\$245

Multi-Function DMA

5516DMA

16 channels 12-bit A/D,
DMA, 16 digital I/O

\$295

High Resolution

5500HR

16 channels 16-bit A/D,
DMA, 8 digital I/O

\$595

learn more:

voice 800-648-6589
fax 617-938-6553
web www.adac.com
email info@adac.com

ADAC

American Data Acquisition Corporation
70 Tower Office Park, Woburn, MA 01801




Figure 2. This **Adaptive Truss Structure** contains five active members. The black balls shown near the ends of four of the passive members indicate that the joints at those ends of those members are loose.

The method of identification of loose joints involves instrumenting the structure with displacement sensors and using some or all of the actuators that are already in the structure. First, some combination of actuators is used to stress the structure enough to close all gaps. With all gaps closed, the structure

can be expected to exhibit linear load-vs.-displacement characteristics.

Next, the applied loads are decreased by small amounts while the corresponding decrements in the displacements are measured. If there is a loose joint, then at some point in the unloading process, the gap in it will open. A nonlinearity in

the plot of load-vs.-displacement data obtained in this unloading process indicates that a gap has opened somewhere in the structure. When the unloading process is complete, the accumulated number of such nonlinearities indicates the total number of gaps that have opened and thus the number of loose joints.

Once the number of loose joints has been established, their locations and the sizes of the gaps in them are determined, one by one, in a recursive sequence of measurements and calculations. In this sequence, known displacements are applied via the active members and the displacements of the ends of the other members are measured and compared with displacements computed according to linear (no-gap) force-vs.-displacement relations to identify specific gap-opening nonlinearities in joints in which they occur.

This work was done by Robin J. Bruno of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Mechanics category, or circle no. 120 on the TSP Order card in this issue to receive a copy by mail (\$5 charge). NPO-19415

Non-Contact Infrared Thermometer With Laser Sighting

Palm Size



- Simple temperature measurement from -20°C to 300°C
- Laser sight pinpoints measured spots.
- Automatic-backlit LCD display at dark places by a brightness sensor
- Automatic power off for saving battery life
- Audible buzzer high alarm standard
- Emissivity adjustable from 0.30 to 1.90 in 0.01 steps

Handheld Infrared Thermometer

Model **IR-TA**

Measurement and Control System

CHINO

CHINO Works America Inc.

VICTORIA BUSINESS PARK 18005 SO. SAVARONA WAY, CARSON, CALIFORNIA 90746
TEL: 213-321-3943/45 FAX: 310-532-7195

CHINO CORPORATION

32-8, KUMANO-CHO, ITABASHI-KU, TOKYO 173, Japan
TEL: 03-3956-2171 FAX: 03-3956-0915

Mr. Sulu, I think you dropped something.


We admit the tri-corder is a pretty handy gadget. Unfortunately, you'll have to wait about 200 years to get one. Until then, consider the HP LogicDart. It's an advanced logic probe that not only performs basic logic monitoring, but also tests continuity, dc voltage, frequency, and does timing analysis. This eliminates the hassle of switching tools and keeps you focused on solving problems. Making it the perfect tool for first-level troubleshooting.

What's more, you can make all of these measurements from a single probe. So you don't have to fumble around hooking up different probes for different instruments. And the HP LogicDart's precise probe tip allows you to confidently probe fine-pitch surface mount circuitry.

But there's more to this 23rd-century tool than we can explain in 150 20th-century words. That's why we're offering a free brochure with key specifications and ten practical HP LogicDart applications.

To find out more about the HP LogicDart, visit our Web site or call HP DIRECT at 1-800-452-4844, Ext. 5215. At a price of only \$795*, anything else would be illogical.

<http://www.hp.com/info/LogicDart1>



DC voltage, frequency, logic activity and timing simultaneously.

Check up to 3 channels of logic timing.

Measure continuity, diode test, and resistance.

100 MSa/s sampling — up to 10 ns timing resolution.

* U.S. list price Faxback: 1-800-800-5281, Document 12687
©1997 Hewlett-Packard Co. TMPMO533/NASA

hp HEWLETT
PACKARD



Machinery/Automation

Heat Pump for Quick Warming of Automobile Passenger Space

The air-conditioner would be operated in reverse, drawing on exhaust heat.

NASA's Jet Propulsion Laboratory, Pasadena, California


A proposed system for quick heating of the passenger compartment in a cold automobile would exploit the vapor-compression cycle of an automotive air-conditioner. The system would likely cost and weigh less than do quick-heating systems based on storage and release of heat in phase-change materials. Unlike an electric heater, this system would not impose an excessive additional drain on the automobile battery.

The proposed system would consist mostly of an ordinary automotive air-conditioning system, with some additional switches, valves, and plumbing to enable operation in either the quick-heating mode or the traditional cooling mode. In the quick-heating mode, the vapor-compression cycle would be run in reverse: whereas the passenger-space heat exchanger serves as an evaporator that takes heat from the passenger space in the cooling mode, it would serve as a condenser that would deliver heat to the passenger space in the quick-heating mode (see figure).

The evaporator for the quick-heating mode would be an additional heat exchanger in direct or indirect contact with the exhaust pipe; this would make it possible to provide much more heat than could readily be extracted from cold ambient air. Even in the coldest weather, a typical cold idling engine produces ample low-grade exhaust condensation heat in the approximate temperature range of 70 to 110 °F (21 to 43 °C). The refrigerant fluid passing through the evaporator would absorb

some of this heat, and compression would raise the temperature of the fluid passing through the condenser to about 150 °F (66 °C). This fluid temperature is typical for an automotive heater.

the evaporator once the engine has warmed up. Alternatively, a more stable refrigerant could be used, such as CO₂, which has recently been demonstrated on automobile air-conditioning systems.



The Vapor-Compression Cycle of the air-conditioner would be exploited for traditional cooling or for quick heating, depending on valve and switch settings that would delineate flow paths.

One potential disadvantage of this system is that the chlorofluorocarbon refrigerant fluid of a typical automotive air-conditioner could decompose when exposed to very high exhaust temperatures. It is possible, however, to overcome this disadvantage by use of a thermal switch, such as a manifold, to divert the flow of exhaust from

This work was done by Jack A. Jones of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Machinery/Automation category, or circle no. 165 on the TSP Order Card in this issue to receive a copy by mail (\$5 charge). NPO-19868

Designing Electrically Powered Actuators for Aircraft

Flight controls will be operated by relatively lightweight power-by-wire systems.

Dryden Flight Research Center, Edwards, California

Under the Electrically Powered Actuation Design (EPAD) validation program and as part of a joint Air Force/Navy/NASA effort, Dryden Flight Research Center has begun test-

ing an electrohydrostatic actuator (EHA) in its F/A-18 Systems Research Aircraft (SRA). The EHA is a prototype of similar electrically powered flight-control actuators that promise to

significantly reduce the weights, costs, amounts of needed logistical support, and amounts of needed maintenance of future aircraft.

The EHA operates the left aileron in

the F/A-18 aircraft, without use of a conventional hydraulic system that would ordinarily power multiple hydraulic mechanisms in the aircraft. The EHA includes a hydraulic subsystem that contains a small (in comparison with a conventional hydraulic system) amount of hydraulic fluid. Taking its signals directly from a flight-control computer in the aircraft, the EHA uses electrical power generated by the aircraft engines to drive the pump in its hydraulic subsystem.

For many years, NASA, the U. S. Air Force, and the U. S. Navy have sought to eliminate sophisticated but heavy hydraulic systems in aircraft in favor of electrical "power-by-wire" systems for operating flight controls. Besides reductions in weight, cost, and the amount of needed support, the incorporation of such electrical systems eliminates the need for hydraulic lines in fuselages and wing boxes, thereby diminishing vulnerability in combat. The power-by-wire arrangement will also reduce complexity and increase reliability.

A major milestone on the road to an

all-electric airplane, the EHA offers the potential to eliminate or minimize dependence on pneumatic, hydraulic, and related mechanical systems during flights of future aircraft. The EHA and systems related to the EHA could lead to fuel saving between 5 and 9 percent on an all-electric passenger airplane, a reduction of 30 to 50 percent in the amount of needed ground equipment, a reduction of takeoff weight by 600 to 1,000 lb (270 to 450 kg), and a 14-percent reduction in the portion of the area of a military aircraft that is vulnerable to such threats as small-arms fire.

The U. S. Air Force Wright Laboratories (in Ohio) managed the overall EPAD EHA program. Contractors included Lockheed Martin (Binghamton, New York), which was responsible for the EHA electronic circuits and other components; Vickers Electro-Mech (Wichita, Kansas and Jackson, Mississippi), for the pump and motor; Dynamic Controls Incorporated (Dayton, Ohio) for the power-control unit and interface control electronics; and Dowty Aerospace (Los Angeles,



Figure 1. This Flight-Control Actuator comprising an electrohydrostatic actuator and electronic controller are used to operate the left aileron in the F/A-18 Systems Research Aircraft, without need for the usual central aircraft hydraulic system.



Figure 2. Flight Tests of the flight-control actuator in the F/A-18 Systems Research Aircraft were begun in January 1996.

ALL LOW-PROFILE LOAD CELLS



ARE NOT CREATED EQUAL

Interface Low-Profile Load Cells, with their unique shear web design and premium alloy construction, continue to set the performance standard in force measurement.

These high performance load cells excel in automotive, aerospace, medical, scientific and industrial applications world-wide. The superior design provides:

- High output
- High frequency response
- Excellent symmetry
- High resistance to off-center loading
- Multiple bridge options
- Capacities from 50 to 200,000 lbs


Don't settle for less. Call today to discuss your specific application.

Interface
ADVANCED FORCE MEASUREMENT

7401 East Butherus Drive
Scottsdale, Arizona 85260
Tel. (800) 947-5598
Fax (602) 948-1924

E-mail: gen@interfaceforce.com
<http://www.interfaceforce.com>

600°C Thermofoil™ Heaters deliver intensive heat for fast warmup



- Mica insulation operates to 600°C (1100°F) • Flat foil element gives excellent heat transfer, up to 110 W/in²
- Odd shapes, factory forming to curved heat sinks • Only 0.025" thick • Uniform or profiled heat

- Longer life, higher wattages, quicker thermal response than cartridge heaters • Clamp on convenience
- Thermal processing & packaging equipment • Heated rollers • Wafer processing • Commercial appliances

MINCO PRODUCTS, INC.


7300 Commerce Lane • Minneapolis, MN 55432-3177 U.S.A.
Telephone: (612) 571-3121 • FAX: (612) 571-0927

For More Information Circle No. 429

SUPER FAST HIGH TEMPERATURE EPOXY ADHESIVE/SEALANT

MASTER BOND POLYMER SYSTEM EP65HT

- Exceptionally fast room temperature cure - even in thin sections - within 2-10 minutes
- Thermal stability up to 400°F
- Passes NASA low outgassing test specifications
- No heat required for cure
- High bond strength
- Excellent chemical resistance
- Convenient packaging



For information,
call or write:
Master Bond Inc.
154 Hobart Street
Hackensack, NJ 07601
201-343-8983

Master Bond Inc.
Adhesives, Sealants & Coatings

California) for the assembled actuator. Dryden Flight Research Center performed ground testing, installed and integrated the EHA in the SRA, provided the necessary data-acquisition systems, and was responsible for flight safety.

The EHA is the second of three actuators to be tested under the EPAD program. In May 1993, Dryden Flight Research Center first flew the SRA with a "smart" actuator sponsored by the U. S. Navy and built by H. R. Textron. The third actuator is an electromechanical one that Dryden will fly on the SRA at the end of 1997.

This work was done by Gordon Fullerton, Harry Miller, Robert Navarro, Mauricio Rivas, Joel Sitz, Bob Varanai, and Eddie Zavala of Dryden Flight Research Center; Gavin Jenney of Dynamic Controls, Inc.; Dave Dawson of Wright Laboratories; Dennis Trosen of the U. S. Air Force; Sean Donley of the U. S. Navy; and Joe Dutko of Lockheed-Martin. No further documentation is available.

In accordance with Public Law 96-517, the contractor has elected to retain title to this invention. Inquiries concerning rights for its commercial use should be addressed to:

Bob Webb

Lockheed-Martin

600 Main St.

Johnson City, NY 13790-1888

(607) 770-2937

Refer to DRC-96-09, volume and number of this NASA Tech Briefs issue, and the page number.

Force-Feedback Device for Microsurgery

This device provides an unprecedented combination of accuracy, control, and workspace volume.

*NASA's Jet Propulsion Laboratory,
Pasadena, California*


A force-feedback device for robot-assisted microsurgery measures the position of a user's hand with great sensitivity — within 30 µm in translation and 0.07° in rotation. The device acts as the master manipulator in a master/slave system for extremely precise surgical procedures. It currently provides force feedback to the user in 3 axes with minimal inertia and friction but can be configured for 6-axis force feedback. It is compactly packaged and is symmetric for either right- or left-hand operation.

The device is set up to provide a maximum feedback force of 6 oz (1.7 N), although it can produce a force up to 47 oz (13 N) and a torque up to 42 oz-in. (0.3 N-m). It is preferable to minimize the force feedback in order to minimize friction and reflected inertia. It operates in a work envelope of 50-mm diameter.

The device includes a tendon-driven arm that comprises a base, shoulder joint, midarm link, elbow joint, forearm link, and wrist joint. A stylus for user manipulation is attached to the wrist (see figure). Motions along and around the various axes are decoupled from each other by double-jointed, tendon-driven revolute joints described in "Double-Jointed, Cable Driven Robot Arms" (NPO-19361), *NASA Tech Briefs*, Vol. 20, No. 10 (October 1996), page 1b.

The base houses dc brushless motors that drive the joints between the links to create the force feedback on the torso,

shoulder, and elbow axes. Also in the base are six high-resolution optical encoders (40,000 counts per revolution) that measure the positions and orientations of the arm links. The use of high-resolution optical encoders — one for each axis — reduces the amount of gearing needed to achieve the requisite positional resolution without excessive friction.



A Surgeon Manipulates a force-feedback device, which is a master robot arm used to control a slave robot arm that performs microsurgical manipulations. The master arm reflects forces and torques from the slave back to the surgeon's hand.

This work was done by Timothy Ohm of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Machinery/Automation category, or circle no. 152 on the TSP Order Card in this issue to receive a copy by mail (\$5 charge).

In accordance with Public Law 96-517, the contractor has elected to retain title to this invention. Inquiries concerning rights for its commercial use should be addressed to:

Technology Reporting Office

JPL

Mail Stop 122-116

4800 Oak Grove Drive

Pasadena, CA 91109

(818) 354-2240

Refer to NPO-19822, volume and number of this NASA Tech Briefs issue, and the page number.

Rotordynamic Seal and Bearing Tester

This tool advances seal bearing technology through demonstration in a realistic environment.

Marshall Space Flight Center, Alabama

A rotordynamic seal and bearing tester (RSBT) has been developed to provide seal bearing data for space vehicles, such as the Space Shuttle and the Reusable Launch Vehicle. This RSBT is an improved version of an apparatus previously reported in "Dynamic Tester for Rotor Seals and Bearings" (MFS-28493), in NASA Tech Briefs, Vol. 15, No. 12 (December 1991), page 80.

MARCH SEAL-LESS MAGNETIC DRIVE PUMPS

March seal-less magnetic drive pumps offer the ultimate in reliable, trouble-free performance for chemical, OEM, industrial, hydronic and solar applications.

- Leak-proof, seal-less magnetic drive
- Friction-free operation for reduced power consumption
- Capacities from 2 to 210 GPM
- Magnetic coupling acts as a clutch to provide overload protection
- Broad range of construction materials for most corrosive solutions
- Easy-to-service without special tools
- Over 150 stocking sales and service locations worldwide



Send for new catalog showing complete line.


MARCH MANUFACTURING INC.

1819 Pickwick Avenue
Glenview, Illinois 60025 U.S.A.

1 847 729-5300 Fax: 1 847 729-7062

For More Information Circle No. 431

Optics & Imaging Catalog



With Over
8,000 Products
We Have Your
Solution!

- Optical Components
- OEM Optics
- Test Equipment
- Video Systems
- Machine Vision
- Critical Measuring
- Positioning Equipment
- Lasers & Laser Optics

All items are in-stock and ready to ship. For over 50 years Edmund's has been providing technical solutions. Let us help you.

▲ Request Your Copy Today
609-573-6250

Edmund Scientific
INDUSTRIAL OPTICS DIVISION

Dept. B971, N954 Edscorp Bldg., Barrington, NJ 08007-1380
Phone: 609-573-6250 Fax: 609-573-6233 E-Mail: B971N954@edsci.com


For More Information Circle No. 432

TRIM-LOK[®] INC.

if you have an edge...we have a trim!

For over 25 years,
the leader in
flexible plastic
and rubber
extrusions!

if you have an edge...we have a trim!



call for
FREE samples

e-mail: trimlok@deltanet.com

call
toll-free

1-888 TRIMLOK

714-562-0500 fax 714-562-0600

6855 Hermosa Circle Buena Park, Ca 90622-6180

For More Information Circle No. 433

A HYDRAULIC SHOCK ABSORBER THAT WON'T LEAK



It's true!
The Cushioneer industrial shock absorber operates millions of cycles without leaking even one drop of fluid. It has a patented leakproof diaphragm seal and combines high load capacity with miniature size. Infinitely adjustable, the Cushioneer stops gently-moving 5 lb. loads or crashing 500 lb. loads with equal smoothness.
A companion unit, the leakproof adjustable Kinechek, holds speed of moving devices constant month after month without periodic re-setting.

Cushioneer[®] — Stops fast-moving equipment without bang or bounce.
Kinechek[®] — Trouble-free speed control — just set it and forget it.

FREE! Send for descriptive bulletins on these cost-saving devices.

The Deschner Corporation • 3211 W. Harvard St.
Santa Ana, CA 92704 (714) 557-1261

® Cushioneer, Kinechek, and Deschner logotype are registered trademarks of Deschner Corp.



For More Information Circle No. 434

The RSBT tool was designed to advance seal bearing technology through demonstration in a realistic environment where data are reliably produced to specify the rotordynamics and load-carrying capacity of seal bearings. Previous experience has shown that conventional testers in which test rotors are supported by ball bearings are ill-designed for testing seal bearings.

The rotor of the RSBT is fully suspended on seal bearings that are the very test article from which the rotordynamic data are to be extracted with the instrumentation of the tester. The tester design is based on the same bulk-flow analysis used for the decision to retrofit the high-pressure turbo-pumps in the Space Shuttle main engines. The instrumentation is a set of reliable proximity probes, readily accessible from outside the tester housing for calibration and inspection. The test rotor is tubular to supply the test seal bearing and the whirl bushing with lubrication without causing axial thrust. The added benefit is a light rotor that has a high resonance frequency outside the speed range of the rotor.

The squeeze film of the seal bearing generates a strong damping effect that makes the tester dynamically inert. The tester and its rotor are coaxially arranged with a stationary center bolt tying the two housing parts together. The bolt, which runs through the bore of the rotor end to the other end of the rotor, has multiple holes in the head to feed the flow from the outside to the rotor bore.

The whirl bushing, which rides on the rotor, is suspended on its own duplex seal bearing. It is lubricated as orifices ooze liquid from the rotor to the duplex seal bearing gaps. The liquid discharges into axial thrust bearings that axially guide on the whirl bushing ends.

The rotor has two separate rings of orifices to feed the two seal bearings of the whirl bushing independently. Two seal bearings form the duplex seal bearing of the whirl bushing. Thus stabilized against tilt disturbances, the whirl bushing freely spins and generates a strong whirl force that eventually squeezes the seal bearings of the rotor.

The whirl bushing, together with turbines, makes the tester leak-proof. This feature is essential for operating with cryogenics and hazardous liquids. The housing completely encloses the rotor and whirl bushing.

The tubular rotor is driven by its turbine at a constant speed. The speed is recorded with pressure and temperature as the test condition for a certain test. Test runs at different speeds are made when investigating the effect of the speed on the rotordynamic parameters of a test seal bearing.

Power for the RSBT is provided through pressurized water or any other working fluid of the seal bearings being tested. Therefore, the facility requires pumps for continuous testing or a blow-down tank for short-duration test runs. The RSBT testing facility consists of a laboratory room, the DSAS, a fluid supply, fluid sump tank, pump speed control, vent valves, electric power, a rack, and a tester pedestal.

The design of the RSBT is unique in its simplicity, low cost, and reliability. This tool should eliminate the long-standing misconceptions about fluid bearings and encourage the design of less costly, yet highly reliable, turbopumps, motors, hazardous-material pumps, jet engines, air-conditioners, and nuclear equipment.

This work was done by George L. von Pragenau of Provident Technology for the Marshall Space Flight Center. For further information, access the Technical Support Package (TSP) free online at www.nasatech.com under the Machinery/Automation category, or circle no. 110 on the TSP Order Card in this issue to receive a copy by mail (\$5 charge).


MFS-26472

UNISCA[®]

TECH BRIEFS



**Interarterial Fiber
Optic Probe**

**Holographic Microtags
for Security**



**New Photonics Products—
See page 14a**

LOOK TO CANON FOR SOLUTIONS TO ALL YOUR IMAGE CAPTURE NEEDS.



As video imaging becomes increasingly important in manufacturing, line inspection, automation, sorting, robotics, and machine vision in general, Canon continues to set the standard with superior optics that deliver unmatched quality and performance.

The worldwide leader in broadcast television lenses, Canon is equally committed to engineering the best industrial lenses, while providing real solutions for the broad range of high quality video user needs.

Our line of multi-use industrial lenses include the JY17X9.5 KTS A, the YH17X7 KTS A and the YH13X7.5 KTS A. These lenses feature many

important advantages such as super close-up, 17X zoom capability (found in the YJ17 and YH17), and other benefits normally associated with Canon's world-class broadcast television lenses. The lenses can be used with most any 2/3" or 1/2" camera and offer remote control zoom, focus and iris functions available via our TCR-101F, 201F or 301F line of controllers.

Lightweight and sturdy, these lenses are also available with a simple interface for use with custom controllers.

Rely on Canon to meet and exceed the most demanding expectations. For more information, please call 1-800-321-4388.

Canon
The Number One Lens

Web site @ <http://www.usa.canon.com>

For More Information Circle No. 480

LASCA[®]

TECH BRIEFS

Laser Tech Briefs Supplement to NASA Tech Briefs October 1997 Issue Published by Associated Business Publications

LASER TECH BRIEFS

- 4a Laser Probe for Characterizing Droplets in Clouds
- 6a Tailored Scattering of Light for Better Illumination
- 8a Experiments on Growth of GaN on MgAl₂O₄
- 8a Holographic Microtags for Security Applications
- 10a Optical Correlator Has Adjustable Sensitivity to Translation
- 11a Fiber-Optic Catheter Probe Would Measure Temperature

DEPARTMENTS

2a News Briefs

14a New Products

On the cover:

Panasonic Factory Automation's Soft Beam Intelligent Machine series for noncontact soldering, called the "SLIM" series, combines energy control, self-monitoring, and other advantages of soft-beam technology in a compact unit that requires only about 10 square feet of floor space, according to the company. *Photo courtesy Panasonic Factory Automation Inc.*

Laser Diode Optics & Instruments



- Laser Diode Collimating and Objective Lenses multi-element, glass and plastic aspheric
- Diode Laser Modules — 635 nm to 780 nm
- Line Generating Modules and Lenses
- Mounting Kits for Laser Diodes and Lenses
- Collimated Diode Lasers
- Anamorphic Prisms for Beam Shaping
- Laser Diodes from 635 nm to 850 nm with optical power from 3 mW to 50 mW
- Laser Diode Instruments — Precision Laser Diode Controllers from 100 mA to 2 Amp, Thermoelectric Temperature Controller, Temperature Stabilized Laser Diode Mount with Modulation to 500 Mhz via Bias-T Input



Optima Precision Inc.
775 SW Long Farm Road
West Linn, Oregon 97068

Phone: (800) 544-4118
(503) 638-2525
Fax: (503) 638-4545

For more information, please call for a catalog or visit our website today...

Website: www.optima-prec.com
email: optima-prec@worldnet.att.net

NEWS BRIEFS

Notes from Industry and the Federal Laboratories

The White House announced that the President intends shortly to name Duncan T. Moore, dean of the School of Engineering and Applied Sciences at the University of Rochester, NY, as associate director for technology of the White House Office of Science and Technology Policy (OSTP). The nomination is subject to recommendation by the Senate Committee on Commerce, Science and Transportation and to confirmation by the full Senate. If the appointment is approved, Moore will take a leave of absence from the faculty and work closely with President Clinton's science adviser, Jack Gibbons.

Moore is an optical engineer and an internationally recognized expert on lens design whose research specialty is the gradient index lens, a sophisticated type in which the refractive index varies along one of its spatial coordinates. In 1980 Moore founded **Gradient Lens Corp.** to commercialize the technology. The company produces high-quality, low-cost borescopes and is developing a

new type of medical endoscope.

During the past decade, Moore has played an important role in the modernization of optics fabrication. His research on using computers to guide the design and manufacture of lenses, along with similar work at Eastman Kodak, led to the formation of the University's Center for Optics Manufacturing (COM), created in 1989 jointly by the American Precision Optics Manufacturing Association (APOMA), an industry trade group, the Department of Defense, and universities. Moore has also served as director of the University of Rochester's Institute of Optics.

Precitech, a precision machine business based in Keene, NH, reached conditional agreement in July to be acquired by **Precision Instruments Holdings Limited**. Completion of the acquisition was expected by last month.

Precision Instruments is the holding company for **Taylor Hobson**, a metrology systems designer based in the United Kingdom and acquired from the Rank Organization last year. One of Taylor Hobson's lines is the Pneumo diamond turning machines, which over time will be integrated with the Precitech line of products. Don Brehm, original founder

of the company that produced the Pneumo line and current president of Precitech, will remain in that capacity after the acquisition.

The **National Institute of Standards and Technology (NIST)** and **Schott Glass Technologies Inc.** of Duryea, PA, signed a cooperative research and development agreement (CRADA) to study laser-light-transmitting glass and to examine why ultraviolet light changes the index of refraction in optical fibers and bulk glass. Schott will supply novel phosphate glass and silicate rare-earth-doped glass compositions. NIST's Optoelectronics Division will provide waveguide fabrication services and measurement support for waveguide and laser characterization, including optical near-field analysis and mode index, loss, lifetime, and spectroscopic and laser performance measurements.

In addition, the partners will study UV sensitivity of bulk glass samples, striving to understand the physical mechanism responsible for UV-light-induced index of refraction change in glass. Schott will provide glass samples and glass chemistry expertise to NIST, which will investigate techniques for measuring the samples' UV sensitivity.

**ONE PIECE,
ALL GLASS . . .
NOT A LAMINATE**
Billions of silver
crystals effect
the polarization

POLARCOR™
Polarizers for the near-infrared

QUALITY POLARIZERS That Go To Extremes
Available in wavelengths covering all major laser lines in the near-infrared from 633 nm to 2100 nm.

TEMPERATURE EXTREMES
From extreme cold, up to 400° C.
When the heat is on, POLARCOR™
polarizers perform.

SIZE EXTREMES
As small as 1.5 mm square, 0.2 mm thick.
Smaller and thinner on request.

PERFORMANCE EXTREMES
• High transmittance (up to 99% with AR
coatings)
• Contrast ratios to 10,000 to 1.
• Higher ratios on request.
• Highly linear output from unpolarized
incident light.
• Acceptance angles in excess of 30°.

QUANTITY EXTREMES
Corning can manufacture small proto-
type quantities or full scale production
quantities.

APPLICATIONS
• Optical Isolators
• Infrared Sensors
• Optical Detectors
• Fiber Optic Devices
• Optical Data Storage Devices
• And much more

CORNING

If you haven't found the
polarizer you need that's so
small it can pass through the
eye of a needle . . . you've been
looking in the wrong haystack.
Corning's POLARCOR™ polariz-
ers can perform in places other
polarizers can't fit, can't survive,
or simply can't do the job.
When you have a design that
requires a polarizer, give
Corning the opportunity to meet
your needs.

For information or to order,
contact:
Corning Incorporated
POLARCOR™ Team
Advanced Materials, HP-CB
Corning, NY 14831
Phone: 607-974-7966
Fax: 607-974-7210



**You said you
needed ultra
high resolution
imagers.**

**We said:
"We've got a
16 million pixel
full-frame chip
off the shelf!"**

**From the reliable
source for very high
resolution imagers.**

With over 16 million pixels (4k x 4k), our full-frame *Kodak Digital Science™* KAF-16800 Image Sensor is ready for your extremely high resolution imaging requirements.

The single output amplifier eliminates the matching problems associated with parallel output amplifiers. Use the KAF-16800 for your most demanding applications – including film digitizing, industrial inspection, aerospace, and medical.

Need high resolution interline imagers with electronic shutter, anti-blooming and low smear?

Try our 1k x 1k progressive scan KAI-1001M imager.

Or call us about our 2 million pixel KAI-2090 chip.

Both have built-in microlenses for improved sensitivity and optional color filter array!

And don't forget that Kodak provides a

complete line of high resolution linear imagers including our 6000 pixel KLI-6003 and our 8000 pixel KLI-8013 tri-color linear arrays. Ideal for film and document scanning, inspection, and studio cameras.

ISO 9001 CERTIFIED

Kodak is your reliable source for high performance, full-frame, interline, linear, and IR sensors as well as support ASICs. We're setting the standards for new and emerging imaging technologies worldwide with our comprehensive capability in design, fabrication, testing and technical support.

716-722-4385, ext. 503

Call us today and talk to a Kodak engineer about your application.

We'll help you select the imager your products deserve.

**THE
SOLID STATE
OF IMAGING
AT KODAK**

Kodak *ds*
digital science™

© Eastman Kodak Company, 1995. Kodak, Digital Science, and the ds monogram symbol are trademarks.

For More Information Circle No. 481

Laser Probe for Characterizing Droplets in Clouds

Incipient icing of aircraft surfaces could be detected and quantified.

Lewis Research Center, Cleveland, Ohio

The figure shows the outward appearance and optical layout of a laser probe for measuring water droplets in clouds. This probe is a prototype of instruments that would be mounted on aircraft or used in icing wind tunnels for real-time measurement of droplet sizes (typically of the order of microns) and determination of the liquid water contents of clouds to quantify the potential for accretion of ice on aircraft surfaces. Similar laser probes are used to measure the sizes of solid particles and liquid droplets suspended in flowing gases and liquids in a variety of natural, industrial, medical, and agricultural processes.


This probe is called an "Airborne Droplet Analyzer" (ADA-100), which is based on the phase Doppler technique, which is an extension of the laser Doppler velocimeter, a laser beam is split into two coherent beams, which are then made to inter-

sect in a small probe volume, where they form interference fringes. A droplet moving through the probe volume scatters light in a burst of oscillations (called a "Doppler burst") as it passes through the interference fringes. The scattered light includes far-field interference fringes with a spatial interval inversely proportional to the size of the droplet.

Some of the scattered light is focused onto a small aperture. Mounted in precise positions behind the aperture are the input ends of three optical fibers, each of which feeds light to a photomultiplier tube. The outputs of the photomultiplier tubes are fed to a Doppler signal analyzer (DSA), which is capable of processing signal components at frequencies up to 160 MHz. The DSA digitally samples the photomultiplier outputs and performs discrete Fourier transforms to determine frequencies and phases.

By the laser Doppler velocimeter principle, the outputs of the three photomultiplier tubes for the Doppler burst of a given droplet oscillate at the same frequency, which is proportional to the velocity of the droplet through the interference fringes. By the phase Doppler principle, the difference between the phases of the oscillations in the outputs of any two of the photodetectors is proportional to the size of the droplet. Thus, one can calculate the size of the droplet from the phase difference for two photomultipliers. The use of three photomultipliers instead of two extends the range of phase measurements and thus droplet sizes that can be determined, affords some redundancy for verifying calculated droplet sizes, and provides a basis for rejecting spurious signals from scattering by ice crystals.

To characterize a cloud, it is necessary to accumulate data from many Doppler bursts to obtain, among other



This Laser-Based ADA Probe measures the sizes of cloud water droplets under icing conditions. The regions indicated by shading are heated to prevent icing of the probe.

Imagine
Illumination
Software
That's Easy
to Learn,
Powerful to
Design With,
and Fun
to Use.

Imagine LightTools®

Imagine Easily Mastering New Software.

Our new Illumination Module is built on the award winning, 3D interactive solids modeling program, *LightTools*. It's so easy to learn, so intuitive and easy to use because our graphical interface allows you to rapidly model your entire illumination system, including sources, optics, mechanical parts, and receivers. All of this without needing to manipulate complex macros or rely on importing models from separate CAD programs. Which means you can say good-bye to long learning curves.

Imagine Testing a Mock Up Without Building a Mock Up.

Imagine illumination software that allows you to: define multiple illumination sources and receivers, specify surface optical properties, specify the type of illumination analysis desired and select the type of graphical output you want. *LightTools* gives optical and mechanical engineers the ability to quickly explore, visualize and analyze the functional trade-offs of alternative illumination designs. All without the need to build expensive prototypes. Which means you can say good-bye to trial and error design.



Imagine Trying *LightTools* Software for FREE.

And now for a limited time, we invite you to try *LightTools* Illumination module for 30 days. Free. Once you've tried *LightTools*, we're confident you won't imagine working without it. All of which means you'll be spending more time stretching your imagination and less time mastering the software.

LightTools®

(626) 795-9101 FAX (626) 795-0184

OPTICAL RESEARCH ASSOCIATES

Corporate Headquarters: 3280 East Foothill Blvd., Pasadena, CA 91107

East Coast Office: Bldg. 3, 1800 W. Park Dr., Westborough, MA 01581-3926 Midwest Office: 3601 Green Road, Suite 104, Beachwood, OH 44122

E-mail: service@opticalres.com WWW: <http://www.opticalres.com>

In tests in the NASA Lewis icing research wind tunnel, the probe has

This work was done by R. C. Rudoff, E. J. Bachalo, and W. D. Bachalo of Aerometrics, Inc., for Lewis Research Center. For further information, access the Technical

Inquiries concerning rights for the commercial use of this invention should be addressed to NASA Lewis Research Center, Commercial Technology Office, Attn: Tech Brief Patent Status, Mail Stop 7-3, 21000 Brookpark Rd., Cleveland, OH 44135. Refer to LEW-16158.

According to one of the two proposals (see Figure 1), the sources in a ceiling array would be connected by a flat translucent sheet made of transparent plastic or glass filled with light-scatter-




Figure 1. Light Propagating in the Sheet by internal reflection would be scattered out, providing diffuse illumination.

ing particles. The light would be coupled from each source into the sheet via a coupling taper that would be integral with the sheet. The coupling taper would provide a transition in light-transmission cross section from the source to the surrounding area of the sheet. The outer surface of the taper would be covered with a thin, partially reflective layer of metal so that light traveling directly from the source through the taper to the space below would be no brighter than the light scattered from elsewhere in the sheet.

The density of the particles would be made to vary with position in the sheet, such that the brightness of light scattered from every point on the sheet would be approximately the same. The needed spatial variation of density could be determined experimentally and/or theoretically.

According to the other proposal (see Figure 2), light would be scattered from both an upper white diffuse reflecting surface (which could be the ceiling) and by a translucent sheet below the sources. Additional layers of translucent material would be stacked under each source in a judiciously chosen pattern to obtain increased diffuse reflection of




Figure 2. Additional Layers of Translucent Sheets would be placed under the sources to obtain additional back-scattering under the sources.

light up to the ceiling in the vicinity of the source. As before, the net effect would be more nearly even illumination of the space below.

Devices of the second type were successfully developed, and they created a very even illumination with equal or slightly less light loss than that produced by standard, discrete, commercial diffusers. A prototype of the first type was also made and evaluated.

This work was done by Hendrik Gerritsen of Advanced Environmental Research Group for Johnson Space Center. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Physical Sciences category, or circle no. 181 on the TSP Order Card in this issue to receive a copy by mail (\$5 charge).

MSC-22374



With all the confusion about laser line generators, LASIRIS invites you to see the light. For machine vision, industrial inspection, alignment and R&D applications, our unique patented design and unbeatable customer service combine to give you the power of uniform precision. So when it comes to structured lighting, LASIRIS is the first and only choice for all your standard or custom needs. And that's not just a line.

- Uniform intensity distribution
- Focus adjustment down to 25µm
- Interchangeable pattern heads
(Single line, Crosshair, Multiple lines, Dot line, Dot matrix, Circle generators and custom patterns)
- ESD-protected to more than 8,000 volts
- Amplitude and frequency modulation
- Full CDRH safety compliance
- Compact and rugged design
- Available from stock

See for yourself. Call **1-800-814-9552**
— and cross the line to quality.

LASIRIS INC.

For U.S. customers, FOB West Chazy, NY

3549 Ashby Street, St-Laurent, Quebec, Canada H4R 2K3

Tel: (514) 335-1005 Fax: (514) 335-4576

Internet: <http://www.lasiris.com> E-mail: sales@lasiris.com

For More Information Circle No. 468

CHILLERS



Efficient and Precise Temperature Control

- Remote operation using Fuji Electric ISO 9001 PID Controllers
- Compact size, saving up to 50% amount of space
- Modular design with unrestricted access to all components
- Easy to maintain with lift-off bonnet
- Capacities from 1kW to 100kW
- Temperature, flow, and level alarms
- OEM and special configurations




Call for **FREE** product information

(603) 539-3600
FAX: (603) 539-8484
PO Box 1000,
Ossipee, NH USA

For More Information Circle No. 469

"From crystal growth to finished blanks."



Quick Quotations & Expedited Delivery on your Silicon & Germanium optical materials.

- Custom Prototypes
- High Volume Production
- Standard Fabrication Services

To see how Lattice can work for you, fax us at:

406/587-9055



516 East Tamarack
Bozeman, MT 59715
406/586-2122

For More Information Circle No. 470

Experiments on Growth of GaN on $MgAl_2O_4$

NASA's Jet Propulsion Laboratory,
Pasadena, California

A report describes an experimental study of the growth of gallium nitride on magnesium aluminate substrates. GaN exists in wurtzite and zinc-blende phases; the zinc-blende phase is more desirable for use as a semiconductor in optoelectronic devices. $MgAl_2O_4$ would be an excellent candidate substrate material for epitaxial growth of GaN, except that there is a mismatch of 10 percent between the GaN and $MgAl_2O_4$ crystalline lattices. In the experiments, low pressure metal/organic chemical vapor deposition from triethylgallium and ammonia source gases was used to grow GaN on (111)- and (100)-oriented $MgAl_2O_4$ substrates, with the expectation that the threefold symmetric (111) $MgAl_2O_4$ substrate would promote the growth of wurtzite GaN, while the fourfold-symmetric (100) $MgAl_2O_4$ would favor the zinc-blende phase. As expected, the GaN film that formed on the (111) substrate was of single-crystal wurtzite, albeit with a high density of stacking faults near the GaN/ $MgAl_2O_4$ interface. However, the GaN film that formed on the (100) $MgAl_2O_4$ substrate was not single-crystal zinc blende as expected; instead, the GaN film was found to be divided into five different regions, four of which contained the wurtzite phase in various lattice orientations and one containing the zinc-blende phase. Interfacial bonding, rather than lattice mismatch, appears to play a key role in determining the epitaxial characteristics of GaN films on $MgAl_2O_4$.

This work was done by Thomas George and William T. Pike of Caltech for NASA's Jet Propulsion Laboratory. To obtain a copy of the report, "Novel Symmetry in the Growth of Gallium Nitride on Magnesium Aluminate Substrates," access it **free on-line** at www.nasatech.com under the Materials category, or **circle no. 182** on the TSP Order Card in this issue to receive a copy by mail (\$5 charge).
NPO-19871


Holographic Microtags for Security Applications

A complete low-cost security system utilizes state-of-the-art extreme-UV microlithography for tagging DRAM chips, microprocessors, CDs, bank cards, etc.

Sandia National Laboratories,
Albuquerque, New Mexico

A holographic microtag is a tiny computer-generated hologram (CGH) that measures $56\ \mu\text{m}$ by $88\ \mu\text{m}$ and contains $0.15\text{-}\mu\text{m}$ features. The small dimensions allow a microtag to be easily hidden on a microchip or in a cluttered image on a credit card. When properly illuminated with a laser beam, the CGH forms a distinctive diffraction pattern several centimeters away from the microtag. The complete microtag-readout system consists of a laser diode, focusing optics, and an observation diffuser screen or a CCD camera.

Microtags are arrays of $0.3\text{-}\mu\text{m}$ -period gratings. They are read out with blue light ($442\ \text{nm}$) using the geometry shown in the figure. The laser readout beam illuminates a microtag



Readout System Geometry.

at a steep angle. The 64 grating patches arranged in an 8-x-8 array diffract the beam back toward a CCD. With this geometry, the phase at each patch can be changed by moving the corresponding grating a fraction of the 0.3- μ m period. The grating is translated perpendicular to its lines (see the figure). The reflectance amplitude of each patch can be reduced by trimming the corresponding grating. Note that phase is produced in one exposure step. This property makes microtags realistically mass-producible. Microtags can be arranged in clusters that require readout from a multitude of azimuth angles. The cluster may be easy to find but it will be difficult to decipher and duplicate, making forgery unprofitable.

A microtag can be designed to form arbitrary application-specific diffraction patterns. These patterns can be alphanumeric characters or abstract pixel codes decodable by a computer. The design process begins with the desired diffraction intensity pattern, such as the letter "E." The next step is an iterative algorithm that ultimately calculates a set of complex numbers that define the microtag. Each complex number represents a reflectance amplitude and a phase. By translation and trimming of the individual gratings, the set of complex numbers obtained by the design algorithm is represented in a microtag.

The research compared a predicted

irradiance pattern created by an 8-x-8-patch microtag and the observed irradiance pattern. The pattern had some lumps in it due to speckle. This effect is seen as a "fingerprint," unique to the starting point of the microtag-design process and therefore an added complication to a would-be forger. Furthermore, the introduction of a computer into the microtag system allows automated pattern recognition.

The microtag concept has been demonstrated with a HeNe laser readout source (632.8 nm) and 80- μ m-by-160- μ m microtags composed of 0.2- μ m features. Smaller microtags that measure 56 μ m by 88 μ m are currently in fabrication. These smaller microtags contain 0.15- μ m features and are designed for readout at 442 nm (HeCd laser source). Finally, microtags embedded in a protective polymer medium are in production.

Like any mass-produced item, microtags are not impossible to forge. The advantage of the microtag concept, however, is the relative ease with which a very complex and difficult-to-replicate security feature can be fabricated. The complexity can be adjusted to make counterfeiting of items protected by microtags unprofitable.

This work was done by William C. Sweatt at Sandia National Laboratories and Michael R. Descour at the University of Arizona. For further information contact W.C. Sweatt at (505) 845-8566 or wsweatt@sandia.gov.

JML OPTICAL

Precision Optics since 1972



PAST...PRESENT... FUTURE

Past

In the past 25 years, JML has emerged as one of the world's best designers and manufacturers of precision optics. Our engineering staff has over 125 years of combined experience in the field of multi-element optical systems.

Present

Our newest catalog and internet home page immediately bring you any of our thousands of stock components and multi-element systems. These easily accessible services allow you to build prototypes quickly and qualify your equipment before production.

Future

Your future is our future. JML Optical will be there for all your long range production needs. We are also developing innovative high speed techniques to produce and provide high quality precision optics and coatings to the optical community in the next millennium.

Call, fax or e-mail us today with your requirements and to receive a copy of our latest catalog.



JML Optical Industries, Inc.

690 Portland Avenue
Rochester, NY 14621
Phone (716) 342-8900
Fax (716) 342-6125

e-mail jml@jmlopt.com
Internet: <http://www.jmlopt.com>

"NEW" "NEW" "NEW"

SEE YOUR UV AND INFRARED

The **FIND-R-SCOPE®** 84499 Series are the most widely used infrared viewers. **WHY?**

1. Sensitivity from 180nm to 1550nm
2. High resolution and low cost
3. Easily replaceable parts
4. 18 month warranty
5. Custom optics
6. UL listed
7. Tripod mountable
8. Free carrying case
9. Hand-held portability
10. Technical service available



Call our **TECHNICAL SALES GROUP** at
1-800-355-4FJW for more information.

FJW OPTICAL SYSTEMS, INC.
629 VERMONT STREET
PALATINE, ILLINOIS 60067
PHONE: (847) 358-2500
FAX: (847) 358-2533




FIND-R-SCOPE®
Infrared Viewing

For More Information Circle No. 472

Measure surface stress and retained austenite

**NONDESTRUCTIVE RESIDUAL STRESS ANALYSIS
SYSTEMS AND SERVICES.**



▼ TEC Model 1630-3 Series Stress Analyzer

*Designed for use on the factory floor or in the laboratory.
X-ray diffraction technique, no destructive sectioning.*

▼ TEC Stress Services Group

*Fast, accurate analysis performed in our lab or at your site.
Residual stress analysis and retained austenite analysis.*



PRODUCTS and LAB SERVICES
10737 Lexington Drive, Knoxville, TN 37932
<http://www.tecstress.com/tec>
423-966-5856 fax: 423-675-1241

Optical Correlator Has Adjustable Sensitivity to Translation

This instrument can recognize partly obscured, modified, and imperfectly aligned objects.

*NASA's Jet Propulsion Laboratory,
Pasadena, California*

A compact optoelectronic image correlator of the Vander Lugt type is designed for adjustable sensitivity to, and some tolerance of, translation of an image or object to be recognized. Denoted a "translation sensitivity adjustable compact optical correlator" (TSACOC), this instrument can recognize partly obscured, modified, and imperfectly aligned images and objects. In contrast, Vander Lugt correlators of older design are characterized by fixed sensitivities to translation and are unable to recognize such images and objects. The TSACOC offers advantages of speed and storage capacity over older optical correlators. The basic TSACOC design can be adapted to a variety of commercial applications, including recognition of fingerprints, verification of paper money and credit cards, photographic identification, and literature searches.

The TSACOC includes a laser with optics to generate a collimated beam of light, a spatial light modulator, a multichannel replication holographic element, Fourier-transform lenses, a holographic matched spatial filter (MSF) with an electronically controlled array of shutters, and an array of photodetectors in a classification output plane. Adjustability of sensitivity to translation is achieved by use of a converging reference laser beam.




Figure 1. **Recording and Readout** in the TSACOC are performed with similar (nominally identical) configurations. Unlike in other optical correlators, a converging reference beam is used in recording.

In operation in the object-recognition mode, the collimated laser beam passes through the spatial light modulator, which enhances the beam and enters the input image to be identified. The beam as spatially modulated by the image then passes through the multichannel replication holographic element, which contains images of all the known objects to be searched. Continuing on its way, the beam then passes through a Fourier-transform lens to the MSF with its electronically controlled shutters, where a matching function is performed. Finally, the beam as thus processed impinges on the classification output




Figure 2. This Simplified TSACOC is an experimental prototype of an instrument for recognizing fingerprints.

plane, forming whichever one of the stored images correlates with the input image.

Figure 2 schematically illustrates a simplified experimental TSACOC for recognizing fingerprints. An MSF containing the information on a known fingerprint is made by use of both the object and reference beams, with the known finger pressed against the prism. Thereafter, to verify that an unidentified finger is the same finger as that represented in the MSF, the reference beam is blocked off, and the unidentified finger is pressed against the prism. Experiments have shown that it is desirable to provide a fixture to hold the finger as nearly as possible in the same position in which it was held while making the MSF. A preliminary prototype, which is the size of a suitcase, has been built for commercialization.

This work was done by Hua-Kuang Liu and Neville Marzwell of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasa.gov under the Physical Sciences category, or circle no. 183 on the TSP Order Card in this issue to receive a copy by mail (\$5 charge).

In accordance with Public Law 96-517, the contractor has elected to retain title to this invention. Inquiries concerning rights for its commercial use should be addressed to

*Larry Gilbert, Director
Technology Transfer
California Institute of Technology
Mail Code 315-6
Pasadena, CA 91125
(818) 395-3288*

Refer to NPO-19808, volume and number of this NASA Tech Briefs issue, and the page number.

Fiber-Optic Catheter Probe Would Measure Temperature

The probe could be used in a human artery.

NASA's Jet Propulsion Laboratory,
Pasadena, California

Figure 1 schematically illustrates a proposed multiple-wavelength infrared radiometric instrument with a catheter probe that would be used to determine the temperatures of the inside walls of tubes, cavities, and the like. The instrument could be useful in a number of industrial and biomedical applications; for example, to monitor the temperature of a

Laser Chillers



- Capacities from 1kW to 100kW
- Compact & Portable
- Refrigerated & Non-Refrigerated
- Custom Configurations
- Always CFC-Free

Affinity

603/539-3600 • FAX: 603/539-8484
PO Box 1000 Ossipee, NH 03864 USA


For More Information Circle No. 473

Piezoelectric Sensors and Assemblies

Whatever your sensor application, we have the capability to produce piezoceramic components, attach wiring and assemble packaging.

We've built sensor assemblies for fiber optic X-Y positioning, gas leak detectors, inertial guidance systems, commercial broadcast tape head alignment, touch screen sensors, vibration monitoring and various medical sensors including blood pressure monitors and dopplar flow.

Our assembly capability also includes a full range of testing at quality levels equivalent to mil spec standards, including environmental cycling.



Morgan Matroc Inc

▲ Electro Ceramics Division
232 Forbes Road
Bedford, Ohio 44146 USA
(440) 232-8600
Fax: (440) 232-8731
E-mail: morgan-ecd@juno.com
www.morganmatroc-ecd.com



human arterial wall from within.

The catheter probe would consist of two optical fibers, a guide wire, and a balloon. The fiber-optic tip has a device on the end that gives a radial field of view, rather than a forward view. This allows localization of measurement. One of the optical fibers, called the "signal" fiber, would transmit infrared radiation from the surface to be monitored to the radiometric equipment. The other optical fiber, called the "refer-

ence" fiber, would be coated with a reflective material at the probing end and would provide the radiometric equipment with radiation that would be used to compensate for any gradients of temperature along the probe. In order to avoid absorption by water in the blood, as well as scattering by cellular blood components, the measurement is done from within a balloon. An expandable balloon is inflated to contact the artery walls, and the fiber-optic tip mea-

sures the balloon-wall temperature from the inside. Since the balloon is in contact with the artery wall and has a small thermal mass and conductance, it has the same temperature as the artery wall.

The radiation leaving the optical fibers would pass through a rotating circular band-pass infrared filter, the pass band of which would vary with rotation angle in a predetermined way. The filtered radiation from each fiber would be detected, then digitized as a function




Figure 1. Optical Fibers in the Catheter Probe would carry infrared radiation from the probe tip to the radiometric equipment.

ADVERTISEMENT

TECHNOLOGY LEADERS

Profiles Of Pathsetting Companies Serving The Engineering Field

AFFINITY INDUSTRIES INC.

Affinity manufactures re-frigerated chillers and nonre-frigerated heat exchangers, designed to meet the demands of industry and the precise requirements of science. President Fred Piehl founded Affinity in 1990 on the concept that more reliable and efficient chillers could be constructed by incorporating the latest technology and advanced design into a product that had been built the same way for 50 years. Affinity products achieve cooling through plate heat exchangers, the most efficient style available, enabling smaller compressors to do more work, saving energy, and reducing noise. Standard digital micro-processors provide precise temperature control, even under fluctuating heat loads.

Chillers and heat exchangers should not only supply reliable service, Affinity believes, but should be user-friendly as well. Affinity builds all its chillers and heat exchangers around a unique modular design. Fully removable bonnets allow unrestricted access to all components. Internal components with related functions are grouped together, saving space and creating a sensibly laid-out unit. Options, including restricted materials coolant loops, de-ionization packages, filters, heater packages, and communications packages, are more easily and effectively incorporated into modularly designed units. Affinity's design also allows the refrigerant circulation, coolant circulation, and electrical systems to be indi-



vidually specified to meet customer needs.

Customers' needs do not end with the design, construction, and shipment of a chiller or heat exchanger, however. Since its founding, Affinity has been actively engaged in education programs developed to

help its customers understand their chillers' operation. And Affinity's 24-hour support team always stands by its customers and its products.

For more information about Affinity Industries, PO Box 1000, Ossipee, NH 03864, call (603) 539-3600; fax (603) 539-8484.




Figure 2. To a Close Approximation, the black-body spectra of different temperatures in the range of interest merge at a wavelength of 3 μm ; this feature provides a reference for calibration.

of time, then processed to obtain a spectrum from the known relationships among the rotation angle of the filter as a function of time, the nominal wavelength of the pass band as a function of the angle, and the sensitivity of detection as a function of wavelength.

the biological temperature range of interest (300 to 310 K). It would do this by sampling at a wavelength of 3 μm (in addition to other wavelengths). A reading at 3 μm constitutes a reference because the intensities of all black-body spectra in this temperature range at

The temperature would be taken to be that of the black-body spectrum that best fit the compensated spectrum from the signal fiber. One of the salient features of the proposed instrument is that it would automatically provide a reference for each black-body spectrum in

this wavelength are so nearly equal (see Figure 2) that they can be taken to be equal for the purpose of calibration. This feature "locks down" the low-wavelength side of the spectrum.

This work was done by Gregory H. Bearman, Michael L. Eastwood, and Timothy N. Krabach of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Life Sciences category, or circle no. 184 on the TSP Order Card in this issue to receive a copy by mail (\$5 charge).

In accordance with Public Law 96-517, the contractor has elected to retain title to this invention. Inquiries concerning rights for its commercial use should be addressed to

Larry Gilbert, Director
Technology Transfer
California Institute of Technology
Mail Code 315 - 6
Pasadena, CA 91125
(818) 395-3288

Refer to NPO-19452, volume and number of this NASA Tech Briefs issue, and the page number.

NSCA
TECH BRIEFS

LITERATURE

Free catalogs and literature for *Laser Tech Briefs* readers. To order, circle the corresponding number on the Reader Information Request Form (preceding page 97).



IMPROVE ANY FUZZY PROBLEM WITH APART!

- World's leading stray light program! • Improve your signal-to-noise ratio (SNR) in any optical system. • Optimize your contrast/detection on any ground- or space-based system. • Specify your surface quality and BRDF from a full coating library. • Calculate ghost, glints, and particle problems before they happen. Breault Research Organization Inc., 6400 East Grant Rd., Ste. 350, Tucson, AZ 85715; Tel: (800) 882-5085 or (520) 721-0500; FAX: (520) 721-9630. E-mail: sales@breault.com; <http://www.breault.com>

Breault Research Organization Inc.

For More Information Circle No. 460



OPTICS FOR METROLOGY

New 1997 catalog contains 120 pages of information and prices on toolmakers' microscopes, stereo microscopes, alignment microscopes, monocular zoom microscopes, micro-telescopes, pocket microscopes, borescopes, micro video lenses, and fiber optic and miniature illumination systems. Also described are centering microscopes, optical cutting tool geometry analyzers, X-Y tables, and microfinishing equipment. Titan Tool Supply Co., Inc.; Tel: 716-873-9907; Fax: 716-873-9998.

Titan Tool Supply Co.

For More Information Circle No. 461



NEW! OPTICS & OPTICAL INSTRUMENTS

Edmund Scientific's free 272-page catalog features our machine vision components and one of the largest selections of precision off-the-shelf optics and optical instruments. Our precision off-the-shelf optics, TechSpec™ Optics and optical components can take you from design, to prototype, to final production. We provide technical design and production solutions. Over 8,000 scientific and technical products, including magnifiers, lasers, microscopes, telescopes, "machine vision," and video microscopy. Tel: 609-573-6259; Fax: 609-573-6233; E-mail: B971N948@edsci.com; web site: www.edsci.com

Edmund Scientific Co.

Industrial Optics Division, Dept. B971N948

For More Information Circle No. 462



FREE CATALOG "OPTICS FOR INDUSTRY"

Free 130 page catalog from Rolyn, world's largest supplier of "Off-the-Shelf" optics. 24-hour delivery of simple or compound lenses, filters, prisms, mirrors, beamsplitters, reticles, objectives, eyepieces, plus thousands of other stock items. At off-the-shelf prices. Rolyn also supplies custom products and coatings in prototype or production quantities.

Rolyn Optics

706 Arrow Grand Circle, Covina, CA 91722-2199
Tel: 626-915-5707; Fax: 626-915-1379

For More Information Circle No. 463



LASER TEST 22 LASER DIODE CONTROLLER

The Laser Test 22 laser diode controller offers drive power and versatility. The laser diode is designed to simultaneously power an internal TEC (10 VA) and an external, high-power TEC (90 VA). The Laser Test 22 provides low noise, safe operation, and two photodetector inputs for internal or external APC. EXFO Electro-Optical Engineering Inc., 465 Godin Ave., Vanier, P.Q. G1M 3G7, Canada; (418) 683-0211; 800-663-3936; Fax: 418-683-2170.

EXFO E.O. Engineering Inc.

For More Information Circle No. 464

SPACE STATION T-SHIRT




Colorful rendition of orbiting station superimposed dramatically on back of black shirt; image of Earth on front left side. 100% cotton. Adult L or XL.

\$12.95 Add \$5.00 for handling and shipping charges

Mail payment to: NASA Tech Briefs, Dept F
317 Madison Ave, New York, NY 10017
For credit card orders call (212) 490-3999

NEW PRODUCTS

PRODUCT OF THE MONTH



Laser Cutting System for Micromachining

New Wave Research, Sunnyvale, CA, describes the EzLaze™ as a small solid-state laser cutting system designed for semiconductor failure analysis, design verification, LCD repair and other micromachining applications. Available in single- and multiwavelength models that include New Wave's patented Advanced Beam Delivery System (ABDS), EzLaze features single-shot, 1-Hz- or 5-Hz-burst pulse repetition rates. Mounted on the Mitutoyo FS60 or A-Zoom microscopes, it can produce uniform, repeatable cuts ranging from $1 \times 1 \mu\text{m}$ to $50 \times 50 \mu\text{m}$. Three wavelengths—1064 nm, 532 nm, and 355 nm—are available at the flip of a switch. Energy output is 0.6 mJ; pulse widths vary from 5 to 7 ns depending on wavelength. EzLaze comes with PCLaze™, a Windows interface that allows users to select cut size, triggering, and wavelength through a computer running Windows 95 or Windows NT.

For More Information Circle No. 793



On-Machine Form Error Measurement

The Ultracomp™ on-machine form measurement system from Precitech, Keene, NH, features corrective form error compensation. Measurement is performed with an ultraprecise air-bearing linear variable differential transformer probe mounted next to the cutting tool. The Ultracomp software processes the data, compares it with the ideal surface profile, and after presenting the error on the machine's controller screen generates an error-corrected tool path program that removes repeatable symmetrical errors from the workpiece. Precitech says Ultracomp systems are currently being used in single-point diamond turning and precision grinding.

For More Information Circle No. 795



UV/Visible Light Source

The Novacure™ from EFOS Canada Inc., Mississauga, Ontario, Canada, is a microprocessor-controlled

ultraviolet and visible light source capable of providing up to 20,000 mW/cm² of radiant power. A built-in radiometer is removable for calibration to NIST standards. The Novacure is a lightweight unit with adjustable intensity and a high-efficiency cooling system that the company says prolongs lamp life. The "lamp-in-a-drawer" design makes for easy replacement and eliminates the need for focusing, EFOS says. The unit has a switching power supply (90-264 VA).

For More Information Circle No. 798



TE Thermal Reference Source Assemblies

A new addition to the thermoelectric cooler product line from Marlow Industries, Dallas, TX, are Thermoelectric Thermal Reference Source Assemblies (TTRS), hermetically sealed devices consisting of a TE cooler, an emitting surface, and a temperature sensing device which are used in conjunction with control-servo electronics. The company says the assemblies provide high slew rates and low power consumption. Marlow calls the TTRS ideal for calibrating radiometers and forward-looking infrared systems used for surveillance, process control, and "hot-spot" applications.

For More Information Circle No. 801



Single-Mode Connector Compatible with FC/SC

Seiko Instruments USA Fiber Optics Group,

Torrance, CA, introduces a new quick fiber optic connector assembly that it says is the only one in the industry compatible with both FC and SC connector styles. The SUP-1 Universal Connector features pre-assembled, one-piece crimp technology and uses a proprietary funnel-type preradiused ferrule. The connectors accommodate 3-mm, 2-mm, and 0.9-mm fiber types. Insertion loss is less than 0.5 dB typical, and return loss is less than -50 dB typical (Ultra PC polish). Available from stock, the SUP-1 is priced at \$6.50 in quantities less than 1000.

For More Information Circle No. 796



UV Microscope for Defect Analysis

Carl Zeiss, Thornwood, NY, says its Axiotron 2 UV microscope is the first

to have deep UV (DUV) imaging. Designed for quality control and defect classification of structures below 0.25 micron, the Axiotron 2 UV is optimized for i-line (365 nm) and DUV (248 nm) analysis. A high-resolution scanning stage allows positioning to defect sites using navigation software. The microscope achieves a resolution of less than 0.03 micron per pixel on the wafer within a measurement field of 20×20 microns. Objectives include the patented Zeiss DUV Ultrafluar 100x/0.9.

For More Information Circle No. 799



Laser Protective Lenses

Trinity Technologies, Minneapolis, MN, adds to its laser eyewear line Clear View protective

lenses that permit the wearer to see all colors of the spectrum when using a ruby laser. A proprietary lens coating provides protection for ruby lasers with an optical density of 6+ at 694 nm and a visible transmission of more than 80%. The filter also provides protection against alexandrite, diode, Nd:YAG, holmium, and erbium lasers. Because the filter allows the wearer to see red, the company says it is particularly useful in medical laser applications where accurate perception of skin color is particularly important.

For More Information Circle No. 802



Expanded Optical Design Software

Optical Research Associates (ORA), Pasadena, CA, announces CODE V version 8.20,

which the company calls a major update to its CODE V optical design software. ORA says the new version has a wealth of new features that enable lens designers to analyze and optimize a wider variety of optical systems with greater power and ease. Many new surface types, such as superconic, thirtieth-order aspherical, compound parabolic concentrator, and 3D cylindrical and circular Fresnel, have been added. Another new capability is analysis and optimization of optical systems using Zernike polynomial coefficients. It is being shipped on CD-ROM for faster installation.

For More Information Circle No. 794



Multi-Channel Dense WDM Laser Source

Profile Optische Systeme GmbH, Karlsruhe, Germany, offers the modular

PRO 8000 series multichannel laser source for dense wavelength division multiplexing applications. The system, which provides up to 8 channels in each mainframe, can be cascaded, resulting in up to 64 individual channels of stabilized laser radiation in the 1550-nm range. Each source can be custom-selected and spaced according to the ITU-T recommendations. Features include wavelength tuning via temperature and internal modulation, GPIB interface, and drivers for LabVIEW® and LabWINDOWS®.

For More Information Circle No. 797




Low-Noise Laser Diode Drivers

Newport Corp., Irvine, CA, bases its new Series 5000 laser diode drivers on the technology it incorporated in its 6000

and 8000 Series modular controller products. The company says the low-noise, highly stable, high-precision current sources include models with maximum current outputs of 500 mA, 3 A, and 6 A. They feature an internal function generator that is programmable from 200 Hz to 300 kHz with either sine wave or square wave output, providing a means to generate datacom and telecom test tones for system evaluation.

For More Information Circle No. 800



Optical Parametric Oscillator

The ScanLine-S™ from Lambda Physik, Ft. Lauderdale, FL, is a solid-state optical

parametric oscillator designed for the 355-nm output of the company's StarLine diode-pumped solid-state laser. The compact system offers tunable output from the visible through the near-infrared (410-2500 nm), with TEM₀₀ mode quality. The company says that unlike traditional OPO/pump combinations that offer low repetition rates only, ScanLine-S makes possible operation of ScanLine-S at up to 1 kHz. Specially coated resonator mirrors allow the OPO to be tuned over the entire spectral range without any change of optics.

For More Information Circle No. 803



Holographic Lithography With Phase Feedback

Better gratings can be made at lower cost.

Marshall Space Flight Center, Alabama

Phase feedback can be used to stabilize interference fringes in holographic lithography. For decades, holographic lithography has been used to make precise gratings for scientific and industrial applications. The figure schematically illustrates a typical interferometer used in holographic lithography, with or without phase feedback. A laser beam is split into two beams, which are reflected and spatially filtered to produce two beams with spherical or planar wavefronts that impinge on an exposure station. A variable attenuator is used to adjust the irradiance of one of the beams to make the irradiances of both beams equal (this adjustment maximizes the achievable fringe contrast). A photosensitive film (e.g., a photographic emulsion or a photoresist on a suitable substrate) is mounted on the exposure station, where it is exposed to the interfering laser beams.


In the absence of deliberate stabilization measures, mechanical vibrations of an interferometer used in holographic lithography give rise to fluctuations in the relative phases of two interfering laser beams, causing the interference fringes to oscillate. This oscillation degrades the quality (in particular, when averaged over the exposure time, it degrades the contrast) of any grating that one attempts to make by use of the interference fringes. Heretofore, it has been standard practice to attempt to stabilize the fringes by mounting the interferometer on a high-quality vibration-isolation table. The present technique using phase feedback is potentially more effective for stabilizing the fringe pattern in space and time, making it possible to pro-

duce larger, higher-contrast gratings while using a vibration-isolation table of lower quality and thus lower cost.

The present phase-feedback technique involves a beam-splitting optical flat mounted on the exposure station just above (out of the plane of the figure) the photosensitive film. Each of the two beams coming from the left and right is partially reflected from, and partially transmitted through, this optical flat, and the overlapping reflected and transmitted beams on each side is sampled by a photodiode. The overlapping beams are characterized by "bull's-eye" (in the case of spherical wavefronts) or

parallel-line (in the case of planar wavefronts) fringe patterns that arise because of interference between the transmitted and reflected beams. In the bull's-eye case, the central spot and the successive rings on one side tend to darken, while the central spot and the corresponding rings on the other side tend to brighten.

The difference between the two bull's-eye patterns depends on, and fluctuates with, the fluctuating phase difference between the right and left laser beams. The photodiodes sense the irradiances in the central spots, and thus the outputs of the photodiodes indicate the instantaneous difference between the



This **Interferometric Apparatus** is used in holographic lithography. For phase feedback, the difference between the phases of the right and left beams is measured by use of the two photodiodes positioned at the centers of the bull's-eye interference patterns. A feedback signal derived from the outputs of the photodiodes is applied to the phase shifter to cancel the phase difference.

phases of the two beams. The outputs of the photodiodes are amplified and otherwise processed into a high-voltage signal that is applied to a Pockels cell or other phase shifter in the path of one beam to cancel the phase difference.

This work was done by Eric Hyde Anderson, Henry I. Smith, and Mark L. Schattenburg of Massachusetts Institute of

Technology for Marshall Space Flight Center. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Manufacturing and Fabrication category, or circle no. 172 on the TSP Order card in this issue to receive a copy by mail (\$5 charge).

In accordance with Public Law 96-517, the contractor has elected to retain title to this

invention. Inquiries concerning rights for its commercial use should be addressed to

*Massachusetts Institute of Technology
77 Massachusetts Avenue
Cambridge, MA 02139*

Refer to MFS-26299, volume and number of this NASA Tech Briefs issue, and the page number

Soldering Parts Together at Precise Faying Surfaces

By capillary action, the faying surfaces are pulled into intimate contact.

NASA's Jet Propulsion Laboratory, Pasadena, California

A special method of low-temperature metal bonding (in essence, a special method of soldering) has been devised for joining two parts at faying surfaces that are required to conform to submicron tolerances. In principle, the method is not limited to joining parts made of a particular material or geometry; however, in practice, the method is likely to be particularly useful for bonding micromachined silicon wafers to form miniature sensors and actuators.

The method is best explained by use of an example in which two silicon wafers are joined at flat surfaces. First, a shallow groove or pit is made at each bonding location in the affected surface

of one wafer. The required depth of the groove or pit depends on the specific application and is typically of the order of 1 μm . Part or all of the recessed surface in the groove or pit is coated with a thin layer of titanium/tungsten alloy followed by a thin layer of gold; this layered metal coat is needed because it is wet by a molten eutectic alloy that is to be used as the solder. The entire affected surface of the other wafer, or at least the part of the surface that faces the metal-coated portion of the recess in the first wafer, is similarly coated so that the solder can wet both wafers at the bonding location.

In this example, the eutectic alloy is made of aluminum and germanium. A

layer of aluminum 1 μm thick is deposited on part of the coated portion of the recessed surface in the groove or pit. A layer of germanium 0.6 μm thick is deposited on the aluminum. The combined thickness of the aluminum and germanium exceeds the depth of the groove so that the top of the germanium layer protrudes slightly above the wafer surface. However, the combined volumes of aluminum and germanium are chosen so that when they are subsequently melted, the volume of the resulting aluminum/germanium alloy will be less than that of the groove or pit.

The second wafer is placed like a lid on the first wafer with the bonding locations aligned. The wafers are clamped together and heated to a temperature near the eutectic melting point, causing the aluminum and germanium to diffuse into each other to form the molten eutectic aluminum/germanium alloy. Because the molten alloy wets the metal-coated surfaces of the wafers, it spreads out on those surfaces, thereby pulling the two wafers toward each other by capillary action. Because the volume of the molten alloy is less than that of the groove or pit, the spreading and pulling continues until the faying surfaces of the wafers are in intimate contact with each other.

The joined wafers are then cooled. The coefficient of thermal expansion of the eutectic alloy exceeds that of the wafers; therefore, differential thermal shrinkage of the alloy during cooling pulls the two wafers together even more tightly.

This work was done by Frank T. Hartley of Caltech and Paul M. Zavracky of Northeastern University for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Manufacturing and Fabrication category, or circle no. 102 on the TSP Order card in this issue to receive a copy by mail (\$5 charge).

NPO-19477

THINK FOAM!

The design possibilities offered by Voltek's closed-cell, crosslinked polyolefin foams are virtually endless.

- Offered in a wide range of densities, thicknesses, and colors.
- Provides excellent cushioning, insulation, and compression strength properties, as well as superior thermal, chemical, and moisture resistance.
- Can be die-cut, vacuum-formed, adhesive-coated, laminated, sewn, embossed, and printed.
- Available in roll, sheet or bun form.

THINK VOLTEK!

To find out more, fax us at (508) 685-9861 or call 1-800-225-0668 to receive a free "Thought Starter".



Voltek, Division of Sekisui America Corporation
100 Shepard Street Lawrence, MA 01843



Soldering Stacked Integrated-Circuit Chips

Connections would be made on broad surfaces and edges.

NASA's Jet Propulsion Laboratory,
Pasadena, California


An advanced concept of fabrication and packaging of electronic circuitry calls for soldering and similar thermal bonding to form intimate electrical, mechanical, and thermal connections between adjacent stacked silicon and other wafers, including integrated-circuit chips. The method would provide additional options for designing and fabricating high-density electronic circuits in robust packages.

The concept is a generalization of the method described in the preceding article, "Soldering Parts Together at Precise Faying Surfaces" (NPO-19477). For example, (see figure) eutectic metal alloy bonds in grooves and pits, as described in the preceding article, could simultaneously constitute wireless electrical interconnections, high-thermal-conductance paths for dissipation of heat, and strong mechanical bonds between adjacent chip layers in a stack of chips. Optionally, a suitable plastic could be used, instead of a eutectic alloy, in joints in which thermal and electrical conductance are not required.

Electrical connections through one or more chip layer(s) or through an entire stack could be made by etching holes completely through the affected chip(s) and depositing metal in the holes. Electrical connections could also be made at and across the edges of stacked chips by selective etching and metallization of the edges.

This work was done by Frank T. Hartley of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Manufacturing and Fabrication category, or circle no. 132 on the TSP Order card in this issue to receive a copy by mail (\$5 charge).

NPO-19473



A Eutectic Alloy (e.g., solder), placed in grooves in amounts that do not quite fill the grooves, would be used to make electrical, thermal, and mechanical connections between stacked integrated-circuit chips. Electrical connections could also be formed on the edges of stacked chips.

EGC is the name to know for reliable, cost-effective fluid sealing products. Our line includes Thermofoil®/Grafoil®

Dig into a box that's all free prizes and no cereal.



pre-formed rings, die-cut gaskets, Thermofoil® braided packing, Tri-Clad™ custom seals, and more. And right now you can get a free Engineering Design Kit full of EGC product samples. You'll also get a copy of our new interactive catalog on CD.

To request your Engineering Design Kit, call EGC today at 800.EGC.0211.

Or visit our web site at www.egc-ent.com. We'll get your kit to you right away. Best of all, the neat stuff won't be buried at the bottom of the box.



EGC
enterprises incorp.

©1997 EGC Enterprises, Inc.


7315 Industrial Parkway • Mentor, OH 44060
800.EGC.0211 • www.egc-ent.com

For More Information Circle No. 437

Intelligent IR Thermometer takes the emissivity guess work out of Temperature Measurement.


Pyrofiber® AEMS high performance thermometer dynamically measures both the target emissivity and radiance to produce the **true target temperature**.

- Microprocessor based system insures accuracy to $\pm 5^\circ\text{F}$
- Six temperature models from 1100°F to 5400°F
- Measures Emissivity from 0.01 to 1.00 ± 0.01
- LCD displays target Emissivity, uncorrected, Corrected temperature
- Connects directly to standard industrial controllers via 4-20 mA or RS232



Fiber Optic Sensors

- Rugged industrial NEMA 4
- Hostile environments to Sensor Heads: 600°F
F.O. Cables: 225°F
- Standard & Custom Sensors
Target Distance: 4" to 120"
Target Sizes: 0.04" to 2.50"



For complete information Call 1-800-HOT-PYRO.



PYROMETER INSTRUMENT COMPANY, INC.

234 INDUSTRIAL PARKWAY • NORTHVALE, N.J. 07647 USA

Phone: 201-768-2000 • Fax: 201-768-2570

Email: pyroinfo@pyrometer.com

Fabricating and Testing an Ultrathin Mirror

A network of pockets and manifolds minimizes handling and damage risks to mirrors during fabrication and testing.

Marshall Space Flight Center, Alabama

A new method to fabricate and test ultrathin optics has been developed to improve on the traditional process. This method uses a block not only to support the optic during processing but also to support the optic in a nearly strain-free deterministic manner during testing.

The rear surface of the optic (which is larger than the specified dimensions of the finished optic) is ground against the front surface of the block to form matching surfaces. Vacuum, which is applied through a manifold to a network of pockets machined into the block, secures the optic to the block for optical fabrication. For testing, the air is forced through the manifold, floating the mirror on a uniform film of air between the block and the optic.

The network of carefully designed pockets and manifolds is machined into the front surface of the block before it is ground against the rear surface of the optic. Each pocket consists of a central vent, a land, and an annular exhaust vent. Two manifolds are used to connect the pockets — one connects all the central vents, the second connects the annular exhaust vents.

The mirror blank is firmly attached to the block for machining to near final thickness, fine grinding, polishing, and figuring by applying and maintaining a partial vacuum on both the central and exhaust vents. The annular exhaust vents and the separate manifold are required for subsequent operations when the pockets are used to support the mirror during testing. The partial vacuum, as well as the number, spacing, and pocket design are chosen to minimize the deflection of the optic into the


pockets during machining, grinding, and polishing.

This network of pockets and manifolds is also used to supply abrasive slurry to the interface between the optic and the block during match grinding operations. During grinding, a change

cleaning fluids. This *in situ* cleaning reduces the risk to the optic by eliminating the need to lift and handle the optic.

Upon completion of the match grinding and cleaning, the front surface of the optic, attached to the body by vacuum, is machined to near-final thickness, fine ground, polished, and figured.

Support for in-process and final testing of the optic is accomplished by supplying air or a similar gas through the central vent of each pocket. This gas is vented through the annular exhaust ring surrounding each central vent. The airflow through each central vent is controlled by a precision restrictor plate. If the total cross-sectional area of the restrictor plates is small compared to the capacity of the supply manifold and the annular exhaust vents, the air pressure at the inlet of each restrictor plate will be identical. This will result in an equal, normal pressure being exerted on the mirror at each pocket since an equal amount of gas is flowing through each of the orifices. Using this known force, the thickness of the optic, and the configuration of the pockets, the gravity-induced deformation of the optic can be determined and subtracted



A Pocket-and-Manifold System is used during fabrication and testing of an ultrathin mirror.

to a finer abrasive can be made without removing the optic from the block by simply feeding a finer abrasive slurry through the manifolds, flushing away the coarser abrasive. When grinding is complete, the interface between the optic and the block is cleaned without separating the two components. Water or other cleaning fluid is pumped through the manifolds, flushing away any remaining abrasive slurry. If necessary, dry air can be blown through the manifolds to evaporate any remaining

from the measured figure of the optic to obtain the actual figure. *In situ* testing eliminates handling of the thin, fragile optic and the associated risks.

This work was done by Howard D. Hall of Marshall Space Flight Center. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Manufacturing and Fabrication category, or circle no. 187 on the TSP Order card in this issue to receive a copy by mail (\$5 charge).

MFS-31174



Predicting Where Terminated Unpiloted Aircraft Will Land

An algorithm updates estimated ground impact locations in real time for improved safety.

Dryden Flight Research Center, Edwards, California


An algorithm has been developed at Dryden Flight Research Center to enhance range safety during tests of unpiloted aircraft [also called "uninhabited aerial vehicles" (UAVs)]. On the basis of current information on winds and an estimate of the rate of descent of the UAV, the algorithm estimates, in real time, the location where the UAV would impinge on the ground if its test flight was suddenly terminated. The predicted location of impact is shown continuously on a range safety officer's moving-map video display so that the flightpath of the UAV can be selected to avoid ground assets (e.g., manmade structures) in the event that the flight must be terminated. The algorithm can be adapted easily to various termination techniques.

Every unpiloted aircraft operating at Dryden Flight Research Center is required to contain a flight-termination system (FTS) to ensure that the aircraft does not leave the designated airspace or range in the event that normal command and control is lost. In addition, the location where the UAV would strike the ground is of concern inasmuch as the designated airspace includes areas of high value. A means of predicting where a UAV will land is critical for real-time flightpath management.

Algorithms in use at other range facilities were designed for high-kinetic-energy aircraft. The need at Dryden Flight Research Center was for an algorithm that could account for low-speed (low-kinetic-energy) aircraft. In addition, the algorithm was required to operate in real time, to be flexible in its ability to account for a variety of termination techniques, and to provide a reasonable estimate of the location of impact.

The moving-map display (see figure) provides continuous information on the present horizontal location, altitude, speed, and heading of a UAV, plus range boundaries and other information. Additional operational boundaries can also be displayed; these boundaries can be des-

The estimate of the location of impact is based on the assumption that the aircraft descends as though under a parachute. Thus, the rate of descent is characterized by a parachute drag coefficient and reference area. The predicted location of impact is a function of the altitude of



The **Moving-Map Display** presents continuously updated information on the present three-dimensional location, velocity, and other flight parameters, and of the estimated location of impact in the event of termination of the flight.

ignated as UAV keep-out zones. They are typically drawn around ground assets. During the flight, the range safety officer provides guidance to the UAV operator so that the predicted location of impact does not enter any UAV keep-out zone.

the UAV, the assumed rate of descent, and the magnitude and direction of the wind. The wind data are critical; they are used by the algorithm to predict the down-range drift during the descent. Wind data are obtained from weather balloons launched

NASA Tech Briefs, October 1997

- During each time slot, each server must decide which of its connected input queues to serve and into which of its output queues it should place the completed job.


The basic policy and algorithm, implemented independently by each server, is as follows: Upon completion of each job, each server would calculate the number of jobs queued up along every path from itself to the destination and would dispatch the just-completed job along the path containing the fewest jobs. If two or more paths to the destination were equally populated, one would be chosen at random. Each server would always serve whichever of its input queues was the longest according to the most recent calculation.

In performing its routing calculations, the server would utilize queue-length information that it obtained from the rest of the network. This information could be attached, for example, to acknowledgments of receipt of packets of data. Each server must know the lengths of all the queues in the network, but knowledge of connection probabilities is not needed. Thus, the network would respond dynamically to changes in network connection probabilities.

It has been demonstrated theoretically that the foregoing policy and algorithm would maximize the network throughput and result in stabilization of the network in the sense that queue lengths at the intermediate nodes of the network would be stabilized if these lengths were stabilizable at all. In practice, the queue-length information available to each server would not always be entirely accurate and timely; however, it has been conjectured that the stability of the network would be robust with respect to delays in queue-length information. The results of an initial simulation in software have been interpreted as signifying that the algorithm would perform well over a broad range of inputs and under partial or delayed queue-length information.

This work was done by Keith Scott of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Mathematics and Information Sciences category, or circle no. 176 on the TSP Order Card in this issue to receive a copy by mail (\$5 charge).

This software is available for commercial licensing. Please contact Don Hart of the California Institute of Technology at (818) 393-3425. Refer to NPO-20188.



This Single-Input, Single-Output, Six-Node Network is a simple example of a network with random connectivities. Each symbol P_{ij} denotes the probability that server j is connected to the output of server i during a given time slot. Each numbered node denotes a server.




Cosmic strings and universe contours made visible with IE 3.0 on a DEC 3000 with 256MB RAM.



Ue-Li Pen, Ph.D.
Center for
Astrophysics*

I am a theoretical cosmologist studying the origin and structure of the universe. IRIS Explorer helps me visualize clusters of galaxies as interactive, 3D datasets. And we're dealing with some big datasets. Using IE routines like Volume Rendering is like having a telescope that can see 350 million light years, or like creating a huge spaceship that can whiz around in deep space and examine our simulation. IE accelerates my work and makes it easy to show to non-experts. I'm currently studying the core sizes of clusters of galaxies in numerical simulations. These were unknown until we ran out simulations with IE. Being able to calculate their size is quite an event.

What can IRIS Explorer help you see?



Medical imaging, chemistry, and fluid dynamics are among the wide-ranging scientific and engineering applications for IRIS Explorer.

IRIS Explorer - bringing you a new view of science.
Now offered by NAG for numerous UNIX workstations and Windows NT


NUMERICAL ALGORITHMS GROUP, INC.

NAG[®]

1400 Opus Place, Suite 200 • Downers Grove, IL 60515-5702
(630) 971-2337, Fax: (630) 971-2706 • <http://www.nag.com> • info-ntb@nag.com

**16 Bit A/D Cards
At Ultra-Fast Speeds
Up to 10 MSPS**

16 BIT 10 MSPS A/D



New

CompuScope 1016

- ◆ 16 Bit Resolution
- ◆ 10 MSPS Sampling
- ◆ 5 MHz Bandwidth
- ◆ Up to 8 Meg Memory

Other Models Available

GaGe

Gage Applied Sciences Inc.

1233 Shelburne Road, Suite 400
South Burlington, VT 05403

Tel: 1-800-567-4243 Fax: 1-800-780-8411

e-mail: prodinfo@gage-applied.com

web site: <http://www.gage.applied.com>

Outside U.S. Tel: 514-337-6893 Fax: 514-337-9844

For More Information Circle No. 435

ISCAN®

**AUTOMATIC
VIDEO
TRACKING
SYSTEMS**

ISCAN's real-time trackers feature unsurpassed performance and low cost. Applications include motion analysis, automated inspection, vehicle guidance and missile seekers. Single and multiple target versions are available.



ISCAN, Inc.

89 Cambridge Street
Burlington, MA 01803 USA

Web: www.iscaninc.com
Email: info@iscaninc.com
Tel: 617-273-4455
Fax: 617-273-0076

For More Information Circle No. 436



Life Sciences

Continuous Unidirectional Locking Orthotic Joint

New orthotic joint can help rehabilitate patients with knee and ankle injuries.

Marshall Space Flight Center, Alabama


A continuous unidirectional locking orthotic joint has been designed to help rehabilitate patients with knee and ankle injuries. In some cases, this device can also be used during recovery from wrist or elbow injury.

During rehabilitation with the unidirectional locking joint, the patient gradually stretches the damaged joint toward full extension. The orthotic joint aides in this therapy by resisting flexion of the joint, while still allowing extension.

To flex the braced limb, the patient simply releases the locking feature manually. This allows the unidirectional joint to rotate freely through the normal range of flexion. When used for knee or ankle joint recovery, this device also prevents the damaged joint from collapsing because it can bear the full weight of the patient.

This continuous unidirectional locking orthotic joint was designed using a hinge-type joint with a manually selectable continuous locking feature. Two long straps with boltholes allow it to be attached to standard orthotic brace parts. When this new joint is used in the knee area, for example, one side of the hinge joint is attached to the thigh portion of the brace, while the other is attached to the calf portion. Two identical joints are required for this type of application.

One of the principal novel features of this joint, the use of an overriding clutch as the mechanism that allows free rotation in the sense of extension but locks when rotation in the sense of flexion is attempted, can be compared with two similar previously developed orthotic joints. These two joints were discussed in NASA Tech Briefs articles "Automatic Locking/Unlocking Orthotic Knee Joint" (MFS-28633), Vol. 18, No. 5 (May 1994), and "Improved Automatically Locking/Unlocking Orthotic Knee Joint" (MFS-27997), Vol. 19, No. 5 (May 1996).



A Compression Spring operating inside a hollow shaft locks and unlocks the continuous unidirectional locking orthotic joint by urging the housing and its pins into engagement with the wheel. This spring acts through a retaining ring, which is affixed to the shaft and protrudes from the housing through the hollow shaft.

Another novel feature is the method of controlling the locking and unlocking of the joint. Like the previously developed joints, this device includes an over-travel stop to prevent hyperextension. The configuration of the joint and of the overrunning clutch affords an unprecedented capability for operation without the need for additional connecting members.

This work was done by Bruce Weddendorf of Marshall Space Flight Center. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Life Sciences category, or circle no. 166 on the TSP Order Card in this issue to receive a copy by mail (\$5 charge).

Inquiries concerning rights for commercial use of this invention should be addressed to the Patent Counsel, Marshall Space Flight Center: (205) 544-0021. Refer to MFS-31114.

www.nasatech.com

NASA Tech Briefs, October 1997

Motion **CONTROL** Tech Briefs


**Interface for
Electro-Pneumatic
Communications**

**Traveling-Wave
Rotary
Actuators**



**New
Motion Control
Products**
— see page 18b

Looking for Quiet, Brushless Motors?



Ask Litton.

The Silencer™ series of brushless DC motors provides strong, quiet operation. In fact, Silencer motors offer such low acoustical noise you can hardly tell they're running.

Call us with your motor requirements. We'll speed prototyping and slash design/manufacturing cycle times by faxing you a **free** computer model of your motor.

Clifton Precision® DC Brushless Motors

- 2.25" diameter housings
- Lengths from 1.3" to 2.8"
- Continuous torques range from 7.5 to 56 oz-in
- Speeds up to 20,000 rpm
- Standard options include gearheads, resolvers, encoders and electronic drivers
- Coming soon are size 12, 34 and 42 NEMA frame brushless motors

Litton

Poly-Scientific

800-336-2112
ext. 279

Blacksburg, VA
540-953-4751
FAX 540-953-1841
<http://www.litton-ps.com>
e-mail: msg@litton-ps.com


Motion CONTROL Tech Briefs

Motion Control Tech Briefs Supplement to *NASA Tech Briefs* October 1997 Issue Published by Associated Business Publications

MOTION CONTROL TECH BRIEFS

- 2b Improved Spherical Gas Bearing
- 4b Electronic System for Teleoperation of Robotic Vehicles
- 7b Quantifying Gear Damage by Optimal Tracking of Vibrations
- 9b Printed-Circuit Board for Driving Multiple Actuators
- 10b Traveling-Wave Rotary Actuators
- 11b Motion Control for Laser Soldering
- 15b Planetary Speed Reducer With Balls Instead of Gears
- 16b An Interface for Electro-Pneumatic Communications

BLUEPRINT FOR A GREAT 8 AXIS MOTION CONTROLLER



0 TO 1,400,000 pps STEP PULSE
UP TO 4MHz ENCODER FEEDBACK RATES

*Design the best, with our smallest and fastest motion controller to date at the industry's lowest installed cost.
Satisfaction Guaranteed!*

Specifications

- All 8 axis can be synchronous, independent or any combination.
- Linear or circular interpolation at constant velocity.
- Motion profiles include linear, parabolic and S-curve.
- Interface software includes Windows 3.1, 95 & NT, DOS, Visual Basic, LabView, C/C++, Basic, Pascal, and others (at no charge).
- Feedback is independent to the axis motion or can be commanded to close the loop or flag slippage.
- Over 100 easy to use commands.

Call, fax, or e-mail "The Company in Motion" for pricing and a detailed brochure on the NEW PC48 Stepper Motion Controller.



Oregon Micro Systems, Inc.

A Pro-Dex Company
1800 NW 169th Place • Suite C100
Beaverton, Oregon 97006

Voice: 503.629.8081
Fax: 503.629.0688
Web: <http://www.OMSmotion.com>

DEPARTMENTS

18b New Products

On the cover:

The cover shows Clippard Instrument Laboratory's Serial Valve Board with manifolded valves mounted on it. Clippard says this electro-pneumatic interface network device can be used with the company's solenoid valves to provide maximum power and flexibility in operation control. The device's unique features are described in the brief on page 16b.

DESCRIPTION
**MOTION
CONTROLLER**

MODEL NO.
PC48

Improved Spherical Gas Bearing


The improved bearing makes a ball-and-socket joint nearly frictionless.

Lyndon B. Johnson Space Center, Houston, Texas

A spherical gas bearing that serves as a low-friction ball-and-socket joint incorporates improvements over older spherical gas bearings. The improvements are such as to create a safer joint that is even closer to being frictionless. Also in comparison with a typical older spherical gas bearing, the improved bearing can be manufactured at lower cost, can be made smaller for the same

magnetic levitation and alternative joints. Both conventional (non-gas-bearing) ball-and-socket and rod-end joints can support large loads, but they exhibit high levels of internal friction. Magnetic levitation relies on sophisticated control systems that consume much power and that induce undesirable eddy currents and magnetic fields. In comparison with the present spheri-

includes three major components: (1) a ball with an integral stem, (2) an upper socket body that contains a hemispherical socket, and (3) a lower socket body that contains a partial continuation of the spherical socket surface and that includes a hole through which the stem passes (see figure). These components can be made from any number of metal alloys or a combination of metal alloys.



This **Improved Spherical Gas Bearing** is basically a ball-and-socket joint lubricated by pressurized air that is injected via holes in the ball. The prototype was made from stainless steel and aluminum bronze.

load capacity, and offers more freedom of rotation. Researchers at the Johnson Space Center use this spherical gas bearing with various satellite mockups to simulate the frictionless conditions of microgravity for crew training. Bearings like this one can also be used in other applications to provide rotational freedom with low friction for large loads.

This spherical gas bearing offers advantages over other means of supporting large loads; such means include

cal gas bearing, older types of spherical gas bearings are more expensive to manufacture because they include jeweled orifices in gas passageways that are machined into their sockets. Moreover, unlike the present spherical gas bearing, older spherical gas bearings generally have no provisions to contain their balls in their sockets, so that the older bearings are less safe.

This spherical gas bearing has a basic ball-and-socket configuration and

The upper and lower socket bodies start out as square (viewed along vertical lines) blocks, and the spherical depressions that constitute their bearing surfaces are machined into them, with the center lines of the spheres coincident with the vertical center lines of the blocks. The diameter of the socket is slightly larger than that of the ball. The lower socket body serves mainly to prevent inadvertent separation of the bearing — an important safety consid-



"GOOD DOG, HUMPHREY.
NOW JUST FETCH OUR OTHER 50,131
AIR VALVES AND ACTUATORS."



With over 50,000 different pneumatic control components (and, shucks, we're still counting), you can be pretty sure we've got what you need. At Humphrey, we'll help you meet your motion control or special pneumatic design requirements. What's more, we'll help you meet your budget. And through our international group of distributors, you'll enjoy hands-on application assistance and personal service. For the Humphrey distributor nearest you, call 1-800-477-8707.

Humphrey
SUPERIOR SERVICE. UNLEASHED.



AME
Pneumatic Motion Control

ALLEN-DRAPER
Pneumatic Motion Control

eration in applications that involve interactions with humans. In addition, changes in the mounting of the lower socket body cause changes in airflow patterns and in the level of clearance between the ball and the upper socket body.

The stem is used to rigidly attach the bearing to a mount and to deliver pressurized air to the narrow radial gap between the ball and socket surfaces. A passageway for the pressurized air is machined through the center of the ball and along the axis of the stem. The pressurized air enters through a single orifice at the base of the stem. Near the top

of the ball, branch passageways deliver the pressurized air to exit holes, the number and arrangement of which can be chosen to maximize the load capacity of the bearings. The exit holes contain bronze inserts (in place of the jeweled inserts of older designs).

Once the socket is assembled around the ball and pressurized air is supplied, the gap between the ball and socket becomes filled with pressurized air, which exerts an upward force on the socket. When the net upward force of the air equals the weight of the socket plus any attached load, the socket levitates, allowing more air to enter the cav-

ity. The film of pressurized air continues to increase until equilibrium is reached between the pressure and volume of the incoming air and the load on the socket. Traveling fully along the surfaces of the ball/socket interface and then dissipating into the atmosphere, the air serves as a lubricant, centering the socket on the ball and preventing contact between the ball and socket surfaces.

This work was done by Thomas Smith of Johnson Space Center. No further documentation is available.

MSC-22718

Legendary Performance Even Under The Toughest Conditions.



Kollmorgen motion control products

are famous for
performing under the
toughest conditions.

Our motors, drives and
actuators are critical to

a variety of military and
commercial aerospace
programs like Rafale,

Airbus A300, 310,

320, 330 and 340,

Boeing 747, 757, 767

and 777, and

McDonnell Douglas MD11.

For seat actuation, power

drive units, hydraulic

pumps and compressors,

auxiliary controls, fuel

distribution and even

windshield wipers.

Capable of withstanding

incredible shock and vibra-

tion, bone-chilling to

sun-baked conditions,

torrential winds,

rain and snow.

And, just about
anything in between.

KOLLMORGEN

Motion Technologies Group

1-800-77 SERVO

Fax: 540-731-0847

Internet: <http://www.kollmorgen.com>

Call on Kollmorgen.

Your Motion Technology

Experts. Because you

have to be ready for

what lies ahead.

Electronic System for Teleoperation of Robotic Vehicles

**Control is implemented with
less complexity and at less
cost than in older systems.**

*NASA's Jet Propulsion Laboratory,
Pasadena, California*

The Surface Navigation and Simulation System (SNSS) is an electronic control system for teleoperation of robots. The SNSS has been undergoing development, following an approach that involves the use of off-the-shelf electronic components and innovative control software to reduce the cost and complexity of teleoperation, both nearby and at long distance. Key components of a prototype of the SNSS are multiple linked personal-computer-based control stations and software for control of, and acquisition of data from, the robots. The prototype SNSS also includes the robots themselves; the prototype robots are small, six-wheeled vehicles equipped with onboard power and data-management subsystems.

Older systems for telerobotic control generally include "high-end" data-processing modules at both rovers and control stations. These systems must be operated with customized, highly complex software. They also require wide-band communications between the control stations and rovers. The foregoing attributes have resulted in high cost and complexity, which have inhibited more-widespread application: In particular, the use of "high-end" computer workstations and sophisticated onboard robot data-processing modules results in high costs of acquisition, even for rough prototype systems. Typically, wide-band communications for control and telemetry rely on expensive satellite links and/or special terrestrial commu-

BRU SERIES

All the performance and functionality of the larger drives at 1/4 their size

Optional touchpad MMI is ideal for the factory floor

UL, cUL listed and CE marked



Available in 0.5, 1.0, and 2.0 kW continuous output ratings


Accepts a variety of command sources

- analog input
- step and directional w/electronic gearing
- master encoder following
- preset positions/velocities/torques
- RS-232/485 commands

Same features, performance software and cables throughout the Advantage Line family

Advanced multi-processor design for leading edge velocity loop bandwidth, digital current, velocity and position loops, and advanced low speed control algorithm

BRU Master, Windows™-based software



A LOT OF DRIVE IN A COMPACT SIZE.

The BRU-Series Advantage Line universal drive family now includes three new micro drives that extend its power range from 0.5 kW all the way to 15 kW.

The Advantage Line micro-size drives deliver more power and better performance than other micro drives on the market. Moreover, they have virtually the same full-feature functionality of the larger drives in a package that's 25% of their size. And with the Windows™-based BRU Master or the optional TouchPad MMI, setup and operation are a breeze.

Small size and exceptional performance make these new micro drives ideal for servo markets and stepper replacements.

To learn how standardizing on the BRU-Series Advantage Line for all your applications can increase productivity, call 1-800-328-3983. Rockwell Automation. **THE RIGHT COMPANY. THE RIGHT SOLUTION.**



Rockwell Automation

Electro-Craft

Windows™ is a trademark of Microsoft Corporation. Electro-Craft® is a registered trademark and BRU-Series™ is a trademark of Reliance Electric Co. or its subsidiaries

Electro-Craft
SERVO SYSTEMS

nication lines. Moreover, it is necessary to train operators extensively in the use of the associated software to enable competent operation and interpretation of data received from the robots.

The SNSS operates as an integrated unit. It includes operator-interface hardware and software that enable operators to "drive" the rovers while viewing images transmitted in real time from video cameras mounted on the rovers. The operators also have access to easy-to-read displays of data acquired from other sensors aboard the rovers. A combination of simple radio and telephone links provides communications between the rovers and their respective operators.

The prototype SNSS includes two instrumented six-wheeled rovers (see figure). The capability of the SNSS has been demonstrated in simultaneous operation of both rovers —

one in a local operating mode and the other in a remote environment. This demonstration was conducted for intervals as long as two hours without interruption. Images received at the control station from the video cameras were found to be of sufficient quality to support rover navigation. Data received at


the control station from other sensor cameras were found to be accurate.

At the time of reporting information for this article, development was continuing and several improvements were expected to be made sequentially during the next two years. One of these improvements would be the incorporation

of an "executive" control subsystem that would provide autonomous monitoring and control of robotic devices.

This work was done by David Mazaika, Gregory Nemitz, Michael Simon, John Risque, David Mitchell, and Cris Fitch of International Space Enterprises, Inc., for NASA's Jet Propulsion Laboratory. For further information, contact Greg Nemitz, International Space Enterprises, 4909 Murphy Canyon Road, Suite 220, San Diego, CA 92123, Telephone No.: (619) 637-5773.


NPO-30020



Six-Wheeled Robotic Vehicles carrying video cameras, other sensors, and power and data-management subsystems are operated simultaneously in a demonstration of the SNSS.

PRECISION STAGES

Accurate Systems at an Affordable Price!



X-Y Stages



Rotary Tables



Single Axis Stages

NEAT offers a wide range of motorized stages to meet your most demanding requirements. Intelligent engineering and state-of-the-art manufacturing result in unsurpassed performance. Many options are available including: stepper or servo motors, rotary or linear encoders, special hole patterns, and a wide range of leadscrew pitches. NEAT also designs custom stages for OEM applications -- call us today to discuss your requirements!

Call today! 1-800-227-1066



Free 160 Page Catalog!



New England Affiliated Technologies

620 Essex Street, Lawrence, MA 01841

TEL: 978.685.4900 FAX: 978.688.8027 WEB: www.neat.com

Quantifying Gear Damage by Optimal Tracking of Vibrations

A one-dimensional mathematical model of gear-mesh dynamics yields useful results.

Lewis Research Center, Cleveland, Ohio

A technique for quantifying damage in gear teeth in a transmission is based on the observation that damage (which can include wear, pits, and fractures) alters the gear-mesh stiffness and thereby alters the vibrations of the transmission during operation. The essence of this technique is to process vibration measurements (instantaneous amplitude as a function of time or gear angle) to estimate the time-varying gear-mesh stiffness and quantify deviations from the periodic mesh-stiffness variations of gears in good condition. The technique involves mathematical modeling of gear-mesh dynamics coupled with nonlinear numerical optimization.

The gear-mesh dynamics are represented by a one-dimensional mathematical model equivalent to the model of a mass m (roughly, the mass of a pinion in mesh with a larger gear) suspended on a spring with time-varying stiffness $k(t)$ and moving in a frictional medium with damping coefficient c . The time-varying spring stiffness is set equal to the time-varying gear-mesh stiffness and represented as

$$k(t) = k_{ave} - k_{periodic}(t) - k_{perturb}(t),$$

where k_{ave} is a constant or time-averaged component, $k_{periodic}$ is the periodic variation in stiffness of the tooth-pass cycles of gears in good condition, and $k_{perturb}(t)$ is a stiffness perturbation associated with damage. The equation of motion is therefore

$$\ddot{x} + (c/m)\dot{x} + \Omega^2 x = u(t)x,$$

where x is a displacement, t is time, $\Omega^2 \equiv k_{ave}/m$, and $u(t) \equiv [k_{periodic}(t) + k_{perturb}(t)]/m$. Note that $u(t)$ is proportional to the total of time-varying components of stiffness. By defining state variables $x_1 \equiv \dot{x}$ and $x_2 \equiv x$, one can divide the equation of motion into two equations in state-variable form:

$$\begin{aligned}\dot{x}_1 &= -(c/m)x_1 - \Omega^2 x_2 + u(t)x_2 \text{ and} \\ \dot{x}_2 &= x_1.\end{aligned}$$

Suppose that vibration measurements $\tilde{x}_2(t)$ corresponding to the modeled state variable $x_2(t)$ are acquired during the interval $[t_0, t_f]$. The problem is to find the function $u(t)$ that makes

the model output $x_2(t)$ approximate the measurement data $\tilde{x}_2(t)$. The problem is solved by following an optimal-tracking approach: The objective in this approach is to minimize a quadratic cost functional that (1) penalizes the deviation of $x_2(t)$ from throughout the interval $[t_0, t_f]$, (2)

imposes an additional penalty on the deviation of $x_2(t)$ from $\tilde{x}_2(t)$, and (3) penalizes too large an estimate of $u(t)$ throughout the interval $[t_0, t_f]$. In the optimal-tracking formulation, the state-variable equations of motion are treated as equality constraints imposed on the minimization of cost



The VEXTA® NanoStep Series combines a 5-phase PK high torque stepping motor and compact microstep driver for the ultimate smoothness.

Smooth – Extremely quiet and smooth operation even at low speeds.

Low Vibration – Motor vibration and noise have been significantly reduced by several improvements to the PK Series high torque stepping motor.

High Torque – Provides 50-100% more torque than conventional 2 and 5-phase full or microstepped systems.

High Resolution – Up to 125,000 steps per revolution. Sixteen levels of resolution available.




QUIET



ORIENTAL MOTOR U.S.A. CORP.

1-800-816-6867

<http://www.omusa.com>



More and more machine tool owners, integrators and OEMs are!

They've discovered the power and flexibility of our new PMAC-NC for Windows™ program.

On a PC platform with Windows '95™ and NT.

They're switching to PC-based, open architecture solutions.

Transforming merely adequate machines into real performers.

Their machines are cutting better circles. More accurate parts. Much faster.

And that's not the half of it. They're *really* taking control by:

- Selecting the controller, amplifier and motors which work best for their applications.

- Going into fifth axis up to eight axis applications. At huge savings.

- Achieving superior and reliable servo performance.

- Delivering block throughput rates to well over 1,000 per second.

- Increasing performance.

- Reducing costs with our PMAC 2 and digital PWM amplifiers.

Are your CNC machine tools out of control?

Call us.

Discover how easy it is to take control!



9036 Winnetka Ave., Northridge, CA 91324


Phone: 818-998-2095 Fax: 818-998-7807

Internet: www.deltatau.com

For More Information Circle No. 668

and as such they are appended to the cost function by use of time-varying Lagrange multipliers, which are governed by differential equations called the "costate equations." The state-variable equations of motion and the costate equations, taken together with a stationarity condition and end-point conditions, constitute the system of equations of a two-point boundary-value problem (TPBVP). The equa-

hanced vibration analysis of the gear transmission done by a previously developed time-frequency Wigner-Ville distribution technique, which gives indications of the type and location, but not the extent of the damage. The two techniques are used together to monitor for the onset of damage during operation of gear trains, or to diagnose gear trains during maintenance.



The Optimal-Tracking Problem Is Solved Numerically in an iterative procedure. The objective is to find an approximation for $u(t)$ that minimizes a cost functional.

tions are solved numerically in an iterative procedure illustrated schematically in the figure.

The technique was tested on a set of fictitious data generated by a computer simulation of a one-degree-of-freedom mechanical system with time-varying stiffness. The solution of the optimal-tracking problem was found to closely approximate the stiffness profile used in the simulation. In another test, the technique was applied to experimental data from a gear-test rig. Despite the simplicity of the one-dimensional dynamical model, the technique was found to be useful in that changes in the estimated stiffness profile could be correlated with damage.

This technique has further en-

This work was done by R. C. Hendricks of Lewis Research Center and F. K. Choy, R. J. Veillette, V. Polyshchuk, and M. J. Braun of the University of Akron. For further information, access the Technical Support Package (TSP) **free on-line** at www.nasatech.com under the Machinery and Automation category, or circle no. 143 on the TSP Order card in this issue to receive a copy by mail (\$5 charge).

Inquiries concerning rights for the commercial use of this invention should be addressed to NASA Lewis Research Center, Commercial Technology Office, Attn: Tech Brief Patent Status, Mail Stop 7-3, 21000 Brookpark Road, Cleveland, Ohio 44135. Refer to LEW-16454.

www.nasatech.com

October 1997

Printed-Circuit Board for Driving Multiple Actuators

Short-circuiting of one actuator does not cause the others to lose power.

NASA's Jet Propulsion Laboratory, Pasadena, California

A special-purpose printed-circuit board (PCB) holds power-conversion, digital control, and power driver circuits for driving as many as 20 actuators. The actuators can be electro-mechanical devices (e.g., relay switches or solenoid valves) that present inductive loads to their driver circuits.

Included on the PCB is a switching dc-to-dc power converter rated at a power level of 75 W. The power converter takes its input power from an unregulated source at a potential up to 36 V. The power converter generates output power for the actuators, regulated at 25 V. The regulated output voltage can be changed to any desired value within the capability of the converter by changing a single resistor on the PCB. The power converter includes a circuit for protection against undervoltage in the output load.

The digital control circuitry accepts digital control inputs for the actuators. Power is applied to the actuators through high-power, fast-switching actuator-driver circuits. There are 20 such driver circuits — one for each actuator. The driver circuitry includes twelve pairs of diodes that help to suppress inductive transients in the actuators.

The power converter can withstand a momentary short circuit in its output load. A short circuit in any actuator is detected by the undervoltage-protection circuit in the power converter. Upon sensing a low voltage indicative of a short circuit, the undervoltage-protection circuit generates an input "reset" logic signal that countermands the input digital signal for the short-circuited actuator; this causes the driver circuit for the short-circuited actuator to be disabled, while the driver circuits for the remaining actuators continue to operate normally in response to their respective digital inputs.

This work was done by Thieu T. Ton and Edward H. Kopf of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Electronic Components and Circuits category, or circle no. 144 on the TSP Order card in this issue to receive a copy by mail (\$5 charge).

In accordance with Public Law 96-517, the contractor has elected to retain title to this invention. Inquiries concerning rights for its commercial use should be addressed to:


*Technology Reporting Office
JPL*

Mail Stop 122-116

4800 Oak Grove Drive
Pasadena, CA 91109
(818) 354-2240

Refer to NPO-20008, volume and number of this NASA Tech Briefs issue, and the page number.

POWER TOOLS.



POWER AND FLUID MANAGEMENT SYSTEMS FROM DAYCO/EASTMAN.

Dayco Products and Imperial Eastman combined to bring you one of the most comprehensive lines of hydraulic hose, couplings and accessories available today.

The result; the newly-consolidated Dayco/Eastman Catalog. Included are more than

300 pages of Power and Fluid Management systems, accessories and crimping equipment in an easy-to-use, indexed format.

To order your copy, or for the name of your nearest Dayco/Eastman Power and Fluid Management Systems

distributor, contact:

Dayco Products, Inc.
1 Prestige Place
P.O. Box 1004
Dayton, OH 45401-1004
Phone: (800) 283-2926
Fax: (800) 688-4854
<http://www.dayco.com>

DAYCO

EXTREME ENVIRONMENT STEPPER MOTORS

phytron



VSS Series

Phytron VSS series of stepper motors are offered in three different categories to cover most extreme environment applications.

VSS-FV

- Vacuum up to 10^{-3} Torr
- Temperature range -40°F to $+250^{\circ}\text{F}$
- Clean Room, Class 10

VSS-HV

- Vacuum up to 10^{-7} Torr
- Temperature range -40°F to $+400^{\circ}\text{F}$
- Clean Room, Class 1

VSS-UHV


- Vacuum up to 10^{-11} Torr
- Temperature range -454°F to $+600^{\circ}\text{F}$
- Radiation hardened to 10^6 Rad
- Clean Room, Class 1

Options: Second shaft, Heat sink, Gear head, Custom design.

Phytron, Inc.
1345 Main Street,
Waltham, MA 02154
1-800-96-Phytron
Fax 617-647-3526
www.phytron.com
e-mail:
info@phytron.com

For More Information Circle No. 670

For Power Transmission
and Linear Component Products
we supply everything between the
Driver and the Driven.



BERG
BEST IN
ENGINEERING SUPPORT
RELIABLE PRODUCTS
GUARANTEED DELIVERY

We are the only company that offers guaranteed deliveries on production lots of gears, sprockets and belts. We guarantee it!

&
You don't pay the freight if we ship the product late.

We can deliver and stock for your needs. Call for a free inch (B97) and metric (M97) Catalog, Product Bulletins or a Special Quote on your scheduled delivery needs.

TEL: 1-800-232-BERG

FAX: 1-800-455-BERG

Web Address www.wmberg.com



BERG

W. M. BERG, INC.

PRECISION MECHANICAL COMPONENTS

488 Ocean Avenue, East Rockaway, NY 11518


Traveling-Wave Rotary Actuators

Piezoelectrically generated traveling waves drive harmonic gears.

NASA's Jet Propulsion Laboratory,
Pasadena, California

Two experimental rotary actuators combine the light weight, small volume, and cleanliness of a piezoelectric traveling-wave motor with the positive action and high torque of a harmonic gear motor. The actuators contain piezoelectric inserts that drive flexible spline gears in sinusoidal patterns; the spline gears, in turn, drive internal spur gears.

A conventional piezoelectric traveling-wave motor relies on friction between a driving flexing stator and a driven member. Friction gives rise to elements of uncertainty and slippage. A conventional harmonic gear includes a flexible gear driven by an electromagnetic motor; it produces a large, dependable torque, but the motor and gear are large, complex, and often dirty.



Piezoelectric Elements on a Stationary Shaft create a wave on a flexible spline gear. The spline teeth on the wave engage and drive the teeth of the internal spur gear.

The figure illustrates the two experimental rotary actuators. In each actuator, piezoelectric elements attached to a stationary shaft alternately bend a spline gear to larger and smaller radii at several points around the circumference. The piezoelectric elements are activated in sequence so that the teeth on the spline rise and fall in a sinusoidal wave that travels circumferentially. The teeth at the crest of the wave engage an internal spur gear (the output gear) and thus turn the gear as the crest travels around the circumference.

This work was done by Virginia G. Ford and John Kievit of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Machinery and Automation category, or circle no. 145 on the TSP Order card in this issue to receive a copy by mail (\$5 charge).

NPO-19261

Motion Control for Laser Soldering

A spreadsheet generates motion control data for a laser soldering process which is verified by computer animation.

AlliedSignal Federal Manufacturing & Technologies, Kansas City, Missouri

A method was developed to allow a user to easily generate and verify the required motion of a radar housing under a laser for a laser soldering process. The purpose of this process is to solder a lid to a backing plate in order to seal the hybrid microelectronic circuit assembly against the environment. The design of this housing makes this a nonstandard application in which a two dimensional table and

for the motion control system was to allow the user to describe the desired motion around the part in the body fixed coordinate frame. This data was then to be transformed into incremental moves in the global coordinate frame required by the motion control system. The motion around the part is defined by the user in terms of the body fixed S' vector. The components of this vector are the

distances from the center of the part to the focal point of the laser, as the laser moves around the entire perimeter of the part. The focal point of the laser will always be on the outer surface of the part. A transformation matrix is used to convert the S' vector in the body fixed coordinate frame to the S vector in global coordinates. The position of the focal point of the laser is labeled as the r_p vec-





Figure 1. Motion Control System.

common contouring motion control operation cannot be used, because the laser is not along the axis of rotation of the part. Instead, the laser is along one of the translational axes, and the motion requires a method of driving the assembly under the laser in two dimensions while rotating about the assembly's center. To further complicate matters, there are coaxial cables which get in the way and shade the assembly from the laser beam. This requires special movements to solder under the cables.

To generate the motion, a four axis system driven by a Compumotor AT6400 indexer was used. The software to program this indexer allows for a timed data streaming mode for non-standard movements. In this mode, the user picks a streaming update interval, which may be any even number time interval from 10 milliseconds minimum to 50 milliseconds maximum. The user then supplies incremental move distances for each axis at each update point in time. In order to generate the data required for this streaming mode, a Microsoft Excel 5.0 spreadsheet was created to allow the user to easily calculate the movement of the part under the laser, and convert this movement into the incremental step moves required.

The approach to generating the data


Not since the piranha...



has there been such massive tooth contact area in such a powerful little package.

Harmonic Drive Zero-Backlash Gearing

Teeth mesh across two large arcs in a unique way that produces exceptional torque capacity with minimal wear.



Harmonic Drive speed reducers are proven high-ratio torque multipliers. Lightweight, durable, and efficient, they assure precise motion control in robot joints, print registration, space satellites, semiconductor manufacturing, and factory automation. For more information, contact:



MADE IN USA



Visit our web site:
www.harmonic-drive.com

Harmonic Drive®
TECHNOLOGIES

HARMONIC DRIVE
TECHNOLOGIES

247 Lynnfield Street
Peabody, MA 01960
TEL: (978) 532-1800
FAX: (978) 532-9406

© 1995 Harmonic Drive Technologies

"The best kept secret in motion"...

for over 30 years ...

Designing, Developing and Manufacturing ...

- DC Servo Amplifiers
- Brushless Servo Amplifiers
- DC Servo Motors
- Brushless Servo Motors

Offering:

- Small, cost-effective design
- High-performance quality and reliability
- One of the World's broadest range of products
- Fast delivery
- World-class customer service



GK GLENTEK
MOTION CONTROL SOLUTIONS

208 Standard Street
El Segundo, CA 90245 USA
(310) 322-3026 (310) 322-7709 Fax
www.glentek.com

For More Information Circle No. 673

tor and is fixed at all times with respect to the global coordinate system. The position of the center of the part (at any point in time, in global coordinates) is labeled as the r_A vector. This vector is found by subtracting the S vector from the r_p vector. The incremental moves used to drive the motion control system are equal to the changes in the global x and y components of the r_A vector. Derivatives of the S vector were taken to determine the velocity and acceleration of the motion control system. If the velocities are too high, whipping of the lead screw will occur. If the accelerations are too high, the stepper or servo motors of the motion control system will not have enough power and torque to create the motion.

If the part is to move at a constant travel speed under the laser and the laser to remain perpendicular to the edge of the part, and the part rotations are to begin and end with the beginning and ending of each corner, the velocities and accelerations in the corners become very large. The smaller the corner radius, the higher these velocities and accelerations become until approaching infinity for a zero radius (perfectly sharp) corner. The demands on the motion control system, for a part with a small corner radius, may be significantly reduced if the constraint of holding the part perpendicular to the laser is relaxed when nearing and exiting a corner. This allows the rotation of the part to be spread over a greater distance (beginning rotation at a small distance before reaching the corner radius, and ending rotation at a small distance after the corner radius).

A method was developed to allow the laser to solder under the area shaded by a cable. In this method, the laser is brought up to the edge of the cable diameter, or the diameter of a tolerance "keep out" zone around the cable. The edge of the laser then "hugs" this diameter as the part is rotated, to allow the beam to move under the cable. Since the angle β is used to describe the absolute rotation of the part, the angle α is used to describe the angle of the laser as it moves under the cable. The angle α was solved using trigonometric relationships as a function of the distance of the centerline of the laser under the cable. The absolute rotation β of the part is then either increased or decreased by the α angle, depending on the direction of movement around the part.

The spreadsheet and macros only require the user to provide the minimum data needed to define the desired motion of the part under the laser. This definition data consists of the major points around the part geometry where

LINTECH

POSITIONING SYSTEMS

GIVE TOTAL F-L-E-X-I-B-I-L-I-T-Y

- Lintech positioning tables offer precision performance and design flexibility.
- All standard tables are available in manual and motorized models.
- Standard accessories are available to customize your positioning table for your specific needs.
- 2 different series of rotary tables are available.
- Custom Positioning Systems are also available.

SINGLE OR MULTIPLE AXIS TABLES

Lintech's positioning tables offer precision performance and design flexibility for use in a wide variety of Motion Control applications.

OTHER LINTECH PRODUCTS...

- SINGLE SHAFT ASSEMBLIES
- TWIN RAIL® SHAFT ASSEMBLIES
- TWIN RAIL® CARRIAGE ASSEMBLIES



IDEAL FOR:

- Pick & Place
- General Automation
- Inspection Stations
- Test Stands
- Laser Positioning
- Part Insertion
- Part Scanning & many more!

Lintech Automation Specialists are located throughout the U.S. and Canada. For more information call, write or fax for a **FREE!** complete catalog of all Lintech products.

LINTECH®

1845 Enterprise Way
Monrovia, California 91016
Telephone (818) 358-0110
Toll Free... (800) 435-7494
Fax... (818) 303-2035

DC Mini Motors That Keep Going and Going and Going and...

In high performance DC mini motors, no one offers more sizes, longer life and higher efficiency than API Portescap.


- **Ideal for battery-powered applications** - ironless rotor technology yields exceptionally high efficiency and acceleration
- **More commutator segments than competitive motors** of equal size for improved motor brush life and reduced torque ripple
- **Superior winding technique and patented REE® commutator anti-erosion system** extends motor life up to 8 times that of conventional DC motors
- **Miniature encoders available with low power standby** to extend motor capability and battery life

Call today for more information:

1-800-566-5274

Fax: 716-691-9181

<http://www.apiportescap.com>



API Portescap

TURCON® SEALING SOLUTIONS

Now
In
Stock!

Our Turcon® seals are well known as the industry's best proprietary engineered thermoplastic components, offering very low friction, excellent leakage control, and long-lasting service life. Available in the most popular sizes to fit your needs. We want to be your *Single Source For Superior Sealing Solutions*.

Busak+Shamban

Seals Division, P.O. Box 176, Fort Wayne, IN 46801 • Fax 219-749-0066

For immediate off-the-shelf product availability

Call 1-800-767-3257

For More Information Circle No. 675



FORGET BALL SCREWS

Remember Kerk Anti-Backlash and general purpose Lead Screw Assemblies for unsurpassed quality.

- PRECISION SCREWS
- PATENTED NUT DESIGNS
- NO PRE-LOADING OR LUBRICATING
- LEAD ACCURACY TO .0001 IN./IN.
- LONG LIFE, SMOOTH OPERATION
- LOW DRAG TORQUE / LOW COST



For more information: tel 603-465-7227 • fax 603-465-3598
1 Kerk Drive, Box 539 • Hollis, NH 03049

an event is to occur. Examples of the points which the user defines are: the starting and ending points, the corners, the cables, and any other points in which a specific travel speed under the laser or part rotation angle is desired. To make this definition easier for the user, the method for defining the moves through corners and under cables was simplified. The user simply makes a notation designating the corner number to




Figure 2. Positional Vectors of Part in body's fixed and global coordinate frames.




Figure 3. Method of Rotating Part to allow the laser to solder under cable.

define a corner move. Likewise, the user provides the minimum data required to define a cable move. The spreadsheet then generates the large amount of data that defines each incremental move at every time step that occurs between any pair of major points that the user defined.

A verification method was developed by simulating the motion data. The geometry of the assembly was generated using Parametric Technology Corporation Pro/E version 15. This geometry was then converted using DADS/Pro version 3.1 from Computer Aided Design Software Inc. (CADSI) and the simulation was carried out using DADS version 8.0 from Computer Aided Design Software Inc. (CADSI). This process animated the results of the motion of the part on the computer screen. This was extremely useful in catching and correcting errors in the Excel spreadsheet.

This work was done by Scott Yerganian of AlliedSignal Federal Manufacturing & Technologies. AlliedSignal Federal Manufacturing & Technologies is operated for the United States Department of Energy under contract no. DE-ACO4-76-DP00613.

For further information contact Alan Updike at AlliedSignal FM&T, 2000 East 95th St., Kansas City MO 64131-3095; (816) 997-2605; aupdike@kcp.com.

Planetary Speed Reducer With Balls Instead of Gears

The basic design can be adapted to numerous applications.

NASA's Jet Propulsion Laboratory, Pasadena, California

A novel friction-drive speed-reducing mechanism weighs less and occupies less space than does conventional gearing. This speed reducer can be manufactured readily with loose dimensional tolerances, does not have to be lubricated, and can function even when contaminated with dust. The basic design gives a reduction ratio of about 150 to 1 and can be readily modified to obtain other reduction ratios. The basic design can also be miniaturized and adapted to a variety of applications that could include miniature robots, small instruments, and toys.

This speed reducer (see figure) has a differential planetary configuration, but with balls instead of planet gears and cones instead of ring gears. A spring presses the balls between two cones, one of which is stationary, the other of which can rotate and is connected to an output shaft. The conical tapers are chosen to make the radius of contact between the stationary cone and the balls slightly greater than the corresponding radius for the rotating cone. Rotation of an input shaft causes the balls to rotate in planetary fashion. The small difference between the radii of contact produces a differential rotation that is coupled to the output shaft.


This work was done by Donald B. Bickler of Caltech for NASA's Jet Propulsion Laboratory. No further documentation is available.

In accordance with Public Law 96-517, the contractor has elected to retain title to this invention. Inquiries concerning rights for its commercial use should be addressed to

Technology Reporting Office
JPL

Mail Stop 122-116
4800 Oak Grove Drive
Pasadena, CA 91109
(818) 354-2240

Refer to NPO-19951, volume and number of this NASA Tech Briefs issue, and the page number.



The Balls and Cones function analogously to planet gears and ring gears. The speed-reduction ratio depends on the ratio between the radii of contact of the two cones with the balls.

Free catalogs and literature for Motion Control Tech Briefs' readers. To order, circle the corresponding number on the Reader Information Request Form (preceding page 97).



NEW CATALOG OF BOARD-LEVEL MOTION CONTROLLERS

Tech 80's 30-page Product Catalog features the industry's most extensive line of board-level motion controllers and encoder interfaces for IP, PC, PC/104, STD and VME-based applications. Designed for a performance edge, Tech 80 products focus on core functions to offer one of the industry's best performance values. All Tech 80 products feature 'C'-based software libraries, demos, and example code to provide you with a flexible, open environment for software development. Technology 80 Inc., 658 Mendelssohn Avenue North, Minneapolis, MN 55427; (612) 542-9545; (800) 545-2980; Fax: (612) 542-9785; E-mail: info@tech80.com; URL: http://www.tech80.com


Tech 80 Inc.

For More Information Circle No. 695

When you need a rotary position sensor that's economy priced without sacrificing specs or reliability, the SP 2800 series is the ultimate choice. Standard specifications are:

- Minimum life of 50×10^6 revolutions
- Rotational speed to 120 rpm
- Vibration from 5 to 2,000 Hz
- Repeatability to $\pm 0.3\%$
- Tempco of less than 5ppm/ $^{\circ}\text{C}$

50 MILLION REVOLUTIONS WITHOUT A SACRIFICE



SP 2800s are also impervious to dust and moisture by sealing to the IP 65 standard. Reliability is further enhanced by utilizing a precious metal, multi-finger wiper assembly. Other features include mechanical travel range of 360° , electrical travel of 308° or 100° (depending on model), and push-on coupling or marked shaft provide easy mounting options.

For pricing or catalog, contact:

novotechnik

Novotechnik U.S. Inc./Siedle Group

237 Cedar Hill Street ■ Marlborough, MA 01752 Phone: 508-485-2244
Visit our Web site at <http://www.novotechnik.com> Fax: 508-485-2430



An Interface for Electro-Pneumatic Communications

A bidirectional serial interface communicates at speeds up to 500 kbaud in the control of pneumatic valving.

Clippard Instrument Laboratory, Inc., Cincinnati, Ohio


Today's market requires machines with increased throughput, extremely low down time, and ability to combine multiple operations with minimal human input. This results in machines requiring highly complex control systems to move large amounts of data rapidly to and from operating members. Yet, in the face of global competition, the pressure is on for extreme reliability in data communication at reduced cost. As a result, Clippard has developed a highly reliable bidirectional serial communication interface. Termed the Serial Valve Board (SVB), it operates according to the DeviceNet™ protocol, the open communication system for industrial devices developed by Allen Bradley and now overseen by the Open DeviceNet™ Vendors Association.

The SVB is a node used to interface between a control entity or entities and a pneumatic valve manifold. The SVB accepts commands from the control and returns status. In addition, the SVB can be used to interface to electronic sensors transmitting digital input to the controller. The serial data is carried

over a four-conductor cable that is connected to each node in trunk-line, drop-line configuration, in which drops can be daisy-chained.

A unique aspect of this device is that the SVB can be either mounted directly to a solenoid valve manifold or in a central location for a limited group of valves that are wired to the interface by individual connectors. This allows the user to run a single bus cable through the machine, connecting to each SVB node. By using the SVB at specific locations within a device connected to remotely mounted solenoids, the amount of wiring is significantly reduced. At the same time, the valves can be closely coupled to their respective operators, thereby enhancing speed of response.

The SVB, in its current configuration, can connect either 8 or 16 input/outputs (I/O) to a DeviceNet™ bus with custom configurations capable of up to 64 I/O. Since a DeviceNet™ bus can have up to 63 nodes (plus one for a controller), this device provides the flexibility to connect hundreds or even thousands of



The Serial Valve Board (SVB) shown with manifolded valves mounted on it.

I/O via a limited number of connections. Data transmission speeds up to 500 kbaud are possible, depending on total bus length. Applications for this technology include conveyor and sorting lines, automated inventory pull systems, and multimachine manufacturing cells, among others.

Power to the SVB is provided by the bus cable for low-power applications; otherwise, a power-input connector is provided. On-board short-proof drivers actuate the solenoids, Zener diodes provide fast turn-off and coil spike suppression, and a regulator produces 5 V (required internally by the board) from the 24-VDC input. These protection features make optoisolators unnecessary.

Solenoids can draw up to 700 mA each and are operated independently. The SVB has a maximum switching frequency of 100 Hz per solenoid. The drivers will drop a maximum of 0.6 V at 700 mA.

The SVB allows the bus address (MAC ID) to be set manually. Since the DeviceNet™ protocol allows bus addresses from 00 to 63, any setting higher than 63 will place the SVB in automatic self-test cycle, wherein each contact is tested for open or shorted coils. All valves are off at power-up, and the self-test is performed before the SVB is allowed to go on-line. Any fault detected is reported to the controller. In addition, each contact has an on-board LED that will flash if a fault is detected.

To facilitate installation and field service, manual override switches for each contact are provided. These switches are three-position slides, allowing the contact to be manually off, manually on, or under the aegis of the controller(s).

This work was done by a team, with Sid Hendry as Project Manager, at Clippard Instrument Laboratory, 7390 Colerain Rd., Cincinnati, OH 45239. For more information call Sid Hendry at (513) 521-4261 or E-mail: shendry@ix.netcom.com.

HSI: The Linear Motor Experts

Above & Beyond The Call of Duty

No one offers you more quality, technical support and quick turn-arounds

From our quality U.S. production facility

► LINEAR & ROTARY MOTOR SERIES

From .5" to 1.8" diameter – HSI has the thrust and torque ratios you want, in a variety of...

- captive or non-captive shafts
- linear, rotary, oscillating and pancake designs.

► Z-SERIES MOTORS

High performance, economical linear and rotary motors for high volume applications


► ON-SITE ENGINEERING FOR CUSTOM DESIGNS



Call 800-243-2715 (In CT call 203-756-7441)

HSI

Haydon Switch & Instrument
1500 Meriden Rd.
Waterbury, CT 06705



Now you can subscribe to *NASA Technology Today*

the exciting new teaching
tool for educators and
parents

NASA Technology Today's mission is to share the excitement, adventure, and knowledge of NASA's work with teachers and parents for use in the classroom and home. Each full-color, illustrated edition will be your guide inside NASA, spotlighting the agency's major missions, launches, science projects, discoveries, and technology breakthroughs — with fun activities for students. Plus, you'll learn where and how to take

advantage of NASA educational resources, including special Internet sites, software, videos, and more.

Subscribe for a full year — six issues — for the charter rate of \$26.95... or two years for just \$39.95. Additional copies (addressed to same subscriber) are only \$1.00 each (\$6.00 additional per year).

Don't miss a single issue...subscribe today!

Published in cooperation with NASA and the International Technology Education Association.

☐ Please enter my subscription to *NASA Technology Today* for: ☐ one year at \$26.95 ☐ two year at \$39.95
(Price includes Air Mail Postage)

☐ I also want to receive ____ additional copies of each issue, at U.S. \$1.00 per copy x 6 for the subscription year
(e.g. — U.S. \$12.00 for 2 extra copies of each issue)

Total: \$ _____

☐ check enclosed (payable to Associated Business Publications Intl.)

☐ charge my: ☐ VISA ☐ MasterCard ☐ American Express

Card No./Exp. Date _____

Name _____

Signature _____

Organization _____

Phone No. _____

Address _____

Fax No. _____

Mail to: Associated Business Publications Intl., 317 Madison Avenue, New York, NY 10017
Or fax credit card orders to: 1-(212) 986-7864.

For information on advertising contact Joe Pramberger at (800) 944-6272.

New Products



Firestone Industrial Products Co., Carmel, IN, says the 2M2A air actuator, dubbed the Microactuator, is the smallest air spring offered by the company and the smallest available from any manufacturer. A pneumatic bellows-type air cylinder, it can utilize pressures from 0 to 100 psi; at 100 psi it can lift 200 lb. Maximum diameter is 2.2 in. Because the 2M2A's minimum height is 1.2 in., it is suited for small-space applications, yet can deliver more than 1 in. of stroke.

For More Information Circle No. 747



The 25M Series, the newest family of AC flux vector controls from Baldor Electric Co., Fort Smith, AR, has a NEMA 4x keypad with a 32-character English-language display for drive setup. One power supply module powers several 25M controls, which in turn drive several AC vector motors. Control range is from 2-90 A continuous, and input is either direct 230 or 460 VAC. Baldor says its auto-tuning system reduces setup time.

For More Information Circle No. 750



The Series ML multumotion actuators from PHD Inc., Fort Wayne, IN, are designed to provide both linear and rotary motion in one compact unit. The series uses PHD's Series CTS compact guide rod cylinder and Series RL rotary actuator to achieve simple reach-and-turn motion. They are available in 7 sizes with six standard rotations from 45-270° and linear stroke lengths from 1/8 in. to 3 1/2 in. Shock pads, standard on the linear section and optional on the rotary section, minimize piston noise and extend unit life, PHD says.

For More Information Circle No. 753



The new DSL series of pneumatic actuators from Festo Corp., Hauppauge, NY, features rotary, linear, and simultaneous rotary/linear actuation in one compact module. The series comes in 4 metric bore sizes: 16, 20, 25, and 32 mm, with double-ended or hollow double-ended piston rod options. The actuation combination is made possible by a double-acting vane-type rotary actuator for adjustable rotation angles up to 270° and a double-acting linear pneumatic cylinder with linear strokes up to 4 in.

For More Information Circle No. 758



Haydon Switch and Instrument (HSI), Waterbury, CT, has expanded its product line to include gearmotors that incorporate the company's stepper motors with a rugged cast metal gearbox. The gearboxes can sustain loads up to 200 oz-in. of torque and are available in a range of gear ratios from 12:1 to 360:1. The stepper motors are built with 15° or 7.5° step angles. Gears are constructed of composites, brass, hardened steel or a combination of these materials.

For More Information Circle No. 748



Ruland Manufacturing Co., Watertown, MA, has expanded its NOMAR® line of rigid shaft couplings and added beam-style flexible couplings to its line. The rigid line now includes couplings with bores from 1/4 in. to 2 in. They come in 1- and 2-piece clamp-style designs, and are available in carbon steel, stainless steel, and aluminum. The beam-style flexible devices are 1-piece aluminum couplings with spiral cuts to accommodate misalignment and axial motion. The Flexbeam-3™, with two sets of three spiral cuts for high torsional strength, is designed for use on servo motors, encoders, tachometers, and similar components.

For More Information Circle No. 751



Eastern Air Devices, Dover, NH, describes its new DB23 and DB34 brushless DC servo motors as being designed for high-speed processing applications where precision accuracy is important. Their 3-phase design is compatible with industry-standard servo amplifiers and controllers. Equipped with rare-earth magnets, the motors operate at speeds up to 15,000 rpm. Optical encoders provide 500- or 1000-line precision position feedback for standard servo controllers.

For More Information Circle No. 754



Micro Mo Electronics, Clearwater, FL, has introduced the MVP™ 2001 single-axis motion controller. The only controller to date to be certified as DeviceNet™ compliant, according to the company, the MVP can provide control of motion, velocity, and position via serial or DeviceNet interfaces with a wide range of brush-type and brushless DC motors. Up to 63 motor axes can be addressed using the RS-485 Multidrop interface. It is offered in two versions: with either an integrated PWM amplifier or an integrated linear amplifier.

For More Information Circle No. 759



Motion Engineering Inc. (MEI), Santa Barbara, CA, calls its CPCI/DSP the first 8-axis level motion controller for the Compact/PCI bus. The device provides up to 8 axes of servo or stepper control in a single 6U Compact/PCI bus card. It offers point-to-point and coordinated motion, electronic gearing and camming, dual-loop control, and a variety of motion profiles, including trapezoidal, S-curve, parabolic, and user-defined.

For More Information Circle No. 749




The new A-max moving coil motors from Maxon Precision Motors, Burlingame, CA, are just 31.9 mm long and 22 mm in diameter. Available with either precious-metal brushes or graphite brushes, the motors have power ratings from 3.5 to 6 W. Several different windings are available to match desired speed to available voltage. Other options include a single shaft or a passing shaft, ball bearings or sleeve bearings, and terminals or leads.

For More Information Circle No. 752



Vickers Inc., Maumee, OH, introduces the KB Series proportional directional valves that the company says combine advanced electrohydraulics technology with "plug and play" integrated electronics in a compact package. Available in ISO sizes 03 and 05, the valves are rated at 350 bar (5000 psi), and can be placed directly on the cylinder or motor regardless of environment. Fluid cleanliness levels are ISO 18/16/13, a more lenient fluid contamination level than conventional proportional valves, Vickers says.

For More Information Circle No. 755



The Type RSR-Z linear motion guide from THK America, Mount Prospect, IL, features the use of resin in the block body, decreasing the block's mass by up to 28 percent compared to the conventional Type RSR-V. Areas of passage free of loads applied by the ball bearings are molded in resin, resulting in silent operation. The stainless-steel construction of the miniature guide gives it corrosion resistance.

For More Information Circle No. 760

Fast Fax Information Form

Use this form for quickest processing of your inquiry, or if the bind-in card has been removed. Fax: (413) 637-4343.

Name _____

Company _____

Address _____

City/St/Zip _____

Phone _____ Fax _____

e-mail _____

Circle the numbers below to order Technical Support Packages for briefs in this issue.

101	102	103	104	105	106	107	108	109	110	111	112	113	114
115	116	117	118	119	120	121	122	123	124	125	126	127	128
129	130	131	132	133	134	135	136	137	138	139	140	141	142
143	144	145	146	147	148	149	150	151	152	153	154	155	156
157	158	159	160	161	162	163	164	165	166	167	168	169	170
171	172	173	174	175	176	177	178	179	180	181	182	183	184
185	186	187	188	189	190	191	192	193	194	195	196	197	198
199	200	201	202	203	204	205	206	207	208	209	210	211	212
213	214	215	216	217	218	219	220	221	222	223	224	225	226
227	228	229	230	231	232	233	234	235	236	237	238	239	240
241	242	243	244	245	246	247	248	249	250	251	252	253	254
255	256	257	258	259	260	261	262	263	264	265	266	267	268
269	270	271	272	273	274	275	276	277	278	279	280	281	282
283	284	285	286	287	288	289	290	291	292	293	294	295	296
297	298	299	300	301	302	303	304	305	306	307	308	309	310

There is a \$5.00 postage & handling charge for each TSP ordered, payable by check or credit card.

Method Of Payment:

☐ Check to NASA Tech Briefs

☐ American Express

☐ VISA

☐ Mastercard

Card No.

Exp. Date

Signature

No. of TSPs: _____ x \$5.00 each = total enclosed: \$ _____

Circle the numbers below to receive more information about products and services featured in this issue.

401	402	403	404	405	406	407	408	409	410	411	412	413	414
415	416	417	418	419	420	421	422	423	424	425	426	427	428
429	430	431	432	433	434	435	436	437	438	439	440	441	442
443	444	445	446	447	448	449	450	451	452	453	454	455	456
457	458	459	460	461	462	463	464	465	466	467	468	469	470
471	472	473	474	475	476	477	478	479	480	481	482	483	484
485	486	487	488	489	490	491	492	493	494	495	496	497	498
499	500	501	502	503	504	505	506	507	508	509	510	511	512
513	514	515	516	517	518	519	520	521	522	523	524	525	526
527	528	529	530	531	532	533	534	535	536	537	538	539	540
541	542	543	544	545	546	547	548	549	550	551	552	553	554
555	556	557	558	559	560	561	562	563	564	565	566	567	568
569	570	571	572	573	574	575	576	577	578	579	580	581	582
583	584	585	586	587	588	589	590	591	592	593	594	595	596
597	598	599	600	601	602	603	604	605	606	607	608	609	610
611	612	613	614	615	616	617	618	619	620	621	622	623	624
625	626	627	628	629	630	631	632	633	634	635	636	637	638
639	640	641	642	643	644	645	646	647	648	649	650	651	652
653	654	655	656	657	658	659	660	661	662	663	664	665	666
667	668	669	670	671	672	673	674	675	676	677	678	679	680
681	682	683	684	685	686	687	688	689	690	691	692	693	694
695	696	697	698	699	700	701	702	703	704	705	706	707	708
709	710	711	712	713	714	715	716	717	718	719	720	721	722
723	724	725	726	727	728	729	730	731	732	733	734	735	736
737	738	739	740	741	742	743	744	745	746	747	748	749	750
751	752	753	754	755	756	757	758	759	760	761	762	763	764
765	766	767	768	769	770	771	772	773	774	775	776	777	778
779	780	781	782	783	784	785	786	787	788	789	790	791	792
793	794	795	796	797	798	799	800	801	802	803	804	805	806
807	808	809	810	811	812	813	814	815	816	817	818	819	820
821	822	823	824	825	826	827	828	829	830	831	832	833	834

Mail in envelope to:

NASA Tech Briefs

PO Box 5077

Pittsfield, MA 01203-5077

or fax to: (413) 637-4343

Thank you for your order.

**TSPs can be accessed
free on-line at
www.nasatech.com**



Books & Reports

Factors That Affect Readings of Ultrasonic Bolt-Load Gauges


Three reports discuss the principles of operation and factors that affect the readings of ultrasonic extensometers used to measure preloads in bolts, studs, and similar fasteners. These

instruments measure "ultrasonic lengths" proportional to round-trip times of travel of ultrasonic pulses along fasteners. To a first approximation, the amount by which the ultrasonic length of a fastener under tensile load differs from the unloaded length is proportional to the load, and can thus be used to indicate the load. How-

ever, the reading of the ultrasonic instrument is complicated by such other effects as thermal expansion of the fastener, dependence of the speed of sound on temperature and stress, and variations in tension along the gripped portion(s) of the length of fastener.

This work was done by Ajay M. Koshti of Rockwell International Corp. for Johnson Space Center. To obtain copies of the reports, "Estimation of Accuracy in Ultrasonic Preload Measurements," "Preload Measurement in Sleeve Bolts Using An Ultrasonic Bolt Gage," and "Preload measurement in sleeve bolts using an ultrasonic technique," access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Physical Sciences category, or circle no. 136 on the TSP Order Card in this issue to receive a copy by mail (\$5 charge). MSC-22674

We Have The Solution...



HARMONIC DRIVE COMPONENT SETS

Allows the design engineer to integrate the gearing directly into their equipment providing a compact, low weight solution.




HARMONIC DRIVE GEARHEADS

Shaft or flanged output members provides design flexibility, yet simplifies the design process by enclosing our component sets in housings with rigid output bearing support.



HARMONIC DRIVE ACTUATORS

DC or DC brushless servo motors are matched to precision gearheads to produce an actuator with optimum performance. Integral encoders are used for position or velocity feedback.



COMPLETE MOTION CONTROL SYSTEMS

DC or DC brushless servo actuators are available with matched amplifiers and controllers allowing fast prototyping of your new design.

...Reliability
...Precision
...Zero Backlash



HD Systems, Inc. 89 Cabot Court, Hauppauge, NY 11788

Tel: (516) 231-6630 • Fax: (516) 231-6803

Visit our home page at <http://www.hdsystemsinc.com>

Speak with Our Application Engineers
To Find the Solution for Your Motion Control Problem **Call Toll Free 800-231-HDSI**

Adaptive Footpads With Pyrotechnically Anchored Tethers

A report describes a proposed system for landing a spacecraft on a comet, asteroid, small planet, or other extraterrestrial body with low gravitation. The system would include three terrain-conforming footpads rigid enough to withstand impact on a hard surface and broad enough to land on a soft surface without sinking excessively. Each footpad would be equipped with sensors, a pyrotechnically actuated harpoon, and a winch connected to the harpoon via a tether. In computational simulations, the system has been found to be capable of arresting rebound and rollover during landings on terrains with a variety of slopes and obstacles.

This work was done by Randel Lindemann, Donald Sevilla, Kevin Burke, and Greg Gillis-Smith of Caltech for NASA's Jet Propulsion Laboratory. To obtain a copy of the report, "Adaptive Footpad With a Pyrotechnically Anchored Tether for Landing Gear on Low Gravity Planetary Bodies," access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Machinery and Automation category, or circle no. 147 on the TSP Order Card in this issue to receive a copy by mail (\$5 charge). NPO-20117

High-Temperature Fatigue Testing of PMCs

A report describes an experimental study of the tensile and cyclic fatigue behavior of a polyimide-matrix/carbon-fiber composite material under elevated-temperature conditions. The study was undertaken primarily to develop and refine techniques of high-temperature, uniaxial (tension/compression) fatigue testing of polymer-matrix composite (PMC) materials in general.

This work was done by John R. Ellis of Lewis Research Center, Andrew L. Gyekenyesi of Cleveland State University, and Michael G. Castelli and Christopher S. Burke of NYMA, Inc. To obtain a copy of the report, "A Study of Elevated Temperature Testing Techniques for the Fatigue Behavior of PMCs: Application to T650-35/AMB21," access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Physical Sciences category, or circle no. 128 on the TSP Order Card in this issue to receive a copy by mail (\$5 charge).

Inquiries concerning rights for the commercial use of this invention should be addressed to NASA Lewis Research Center, Commercial Technology Office, Attn: Tech Brief Patent Status, Mail Stop 7-3, 21000 Brookpark Road, Cleveland, Ohio 44135. Refer to LEW-16496.

More About a Laser-Speckle Surface-Strain Gauge

The report, "Compact Simultaneous-Beam Optical Strain Measurement System—Phase V," is one in a series of documents about an optoelectronic instrument that uses laser speckle for noncontact measurement of strains on the surfaces of specimens, which can be hot even though the instrument remains at room temperature. Several prior articles in NASA Tech Briefs have described this instrument at various stages of development; the most recent description appeared in "Improvements in a Laser-Speckle Surface-Strain Gauge" (LEW-15914), Vol. 20, No. 4 (April 1996), page 54. The report reiterates information from the prior articles and supporting documents and describes some more-recent advances. One notable advance addresses a disadvantageous reduction in the separation of speckle patterns that are generated by two lasers and imaged in a video camera. Such a reduction occurs during observation of a depolarizing specimen. The report

proposes the use of two different laser wavelengths, combined with the use of a refracting prism in front of the camera, to increase the separation of the corresponding speckle patterns.

This work was done by Christian T. Lant of Sverdrup Technology, Inc., for Lewis Research Center. To obtain a copy of the report, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Physical Sciences category, or circle no. 189 on the TSP Order Card in this issue to receive a copy by mail (\$5 charge).

Inquiries concerning rights for the commercial use of this invention should be addressed to NASA Lewis Research Center, Commercial Technology Office, Attn: Tech Brief Patent Status, Mail Stop 7-3, 21000 Brookpark Road, Cleveland, Ohio 44135. Refer to LEW-16441.

Macroseggregation and Nucleation in Undercooled Pb/Sn Alloys

A report describes an experimental study of macroseggregation and nucleation in three alloys of Pb and Sn. The alloys had tin contents of 12.5, 61.9 (eutectic), and 77 weight percent. Ingots of the alloys, each with a volume of 2.7 cm³, were melted, then frozen with undercoolings ranging from 4 to 34 K and cooling rates from 0.04 to 4K/s. The nucleation behavior of the Pb/Sn system was found to be nonreciprocal; the solid Sn phase effectively nucleated the Pb phase of the eutectic, but large undercoolings developed in Sn-rich eutectic liquid in the presence of the solid Pb phase. This phenomenon is believed to be mainly a result of differences between interfacial energies of (1) solid Sn/eutectic liquid and (2) solid Pb/eutectic liquid. Amounts of macroseggregation in eutectic ingots were found to increase with undercooling.

This work was done by Henry C. deGroot of Lewis Research Center. To obtain a copy of the report, "Macroseggregation and Nucleation in Undercooled Pb-Sn Alloys," access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Physical Sciences category, or circle no. 149 on the TSP Order Card in this issue to receive a copy by mail (\$5 charge).

Inquiries concerning rights for the commercial use of this invention should be addressed to NASA Lewis Research Center, Commercial Technology Office, Attn: Tech Brief Patent Status, Mail Stop 7-3, 21000 Brookpark Road, Cleveland, Ohio 44135. Refer to LEW-16414.

Looking To Increase Your Exports?

Exporter Insider

An Associated Business Publications International Titleholder

Export Interest: High at National Manufacturing Week

National Manufacturing Week 93, the annual celebration of the U.S. manufacturing industry, is under way in the heart of the nation's industrial capital, Detroit. The week-long event, which runs from September 14-20, is a major showcase for the industry. It features a variety of exhibits, seminars, and conferences. The event is a major opportunity for manufacturers to showcase their products and services to a wide audience of potential buyers and investors. The event is also a major opportunity for manufacturers to network with other industry professionals and to learn about the latest trends and developments in the industry.

Exporters Thrive in New Orleans: Mississippi Makes Port Gateway to Industrial Heartland

Some articles from the "Export Insider" newsletter, which is a free monthly newsletter for exporters, are featured in this section. The newsletter provides a variety of information for exporters, including market news, product information, and export opportunities. The newsletter is a valuable resource for exporters who are looking for new markets and opportunities to grow their business. The newsletter is also a valuable resource for exporters who are looking for information about the latest trends and developments in the export industry.

Write today for a FREE sample copy of *Exporter Insider*—the new monthly newsletter filled with expert advice and ideas to help your business penetrate international markets.

Circle no. 477 on the Information Request Form or fax your request on company letterhead to (212) 822-2028.

Encoder to do list . . .

- ✓ Find a small, optical encoder
- ✓ Minimum 25 cycles (100 in quad)
- ✓ Maximum 5VDC @ 8mA, TTL output
- ✓ GET SPECS FOR THE NEW RE20!!

8mA

(TTL, 5VDC)



RE20


(actual size)

Manual Optical Encoder

- 8mA max current draw!
- 20 & 25 full cycles/revolution
- 0.96"H x 0.76"W x 0.36"D
- TTL, CMOS, panel, pcb
- Lowest cost vs competition

NC Machine Tool Pulser

- 100 notch graduated knob
- Ø2.6"/Ø3.15" sizes
- PC board, terminal block
- Integral or stand-alone
- 5~30VDC input



RE45

Check out all the RE20 and RE45 models in our on-line catalog:
www.cuistack.com



800-275-4899

CUI STACK

FAX: (503)643-6129

On top of it.™

For More Information Circle No. 439

THE WORLD'S SMALLEST 4-WAY FIBERSCOPE

ITI's 5mm, 4-way articulating Fiberscope gives you access to difficult environments never thought possible before.

- One-handed operation allows equal dexterity with left-hand or right.
- Teflon®-impregnated tungsten braid sleeve gives additional protection.
- Sealed to permit underwater use.
- Patented over-torque mechanism reduces accidental breakage of control wires.

Learn about the scope everyone said wasn't possible. ITI-The Leader in Remote Viewing.



ITI INSTRUMENT TECHNOLOGY, INC.

P.O. Box 381, Westfield, MA 01086-0381
 Tel: 413-562-3606 • 413-568-9809

© 1995 ITI

For More Information Circle No. 440



Reconfigurable Pointing Control for Spaceborne High-Resolution Spectroscopic Instruments

A collection of documents summarizes preliminary efforts to develop improved pointing control for spaceborne scientific instruments. A significant effort was expended to develop a theory to provide a pointing-control-performance criterion, the satisfaction of which would ensure the acquisition of high-quality data by high-resolution spectroscopic instruments. The theory is presented and it is found that the criterion is very stringent and difficult to satisfy by use of standard three-axis spacecraft control equipment now in use. This finding leads to the second major effort, regarding a novel reconfigurable-control concept proposed to satisfy the pointing criterion while using currently available gyroscopic spacecraft hardware. This concept involves switching the control error (which one seeks to null) among detuned Kalman filters. The feasibility of the concept is verified by use of a covariance analysis, and effectiveness is demonstrated by example calculations for the Infrared Spectrograph (IRS) payload aboard the Space Infrared Telescope Facility (SIRTF). Numerical results indicate that by proper choice of filter detuning and handoff timing, the optical flux offset could be held (with 0.95 probability) to within 6 percent of the ideal flux. In contrast, the corresponding flux offset would be 12 percent with conventional three-axis control.

This work was done by David S. Bayard, Tooraj Kia, and Jeff Van Cleve of Caltech for NASA's Jet Propulsion Laboratory. To obtain a copy of the collection, "Reconfigurable Pointing Control for High Resolution Space Spectroscopy," access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Electronic Systems category, or circle no. 140 on the TSP Order Card in this issue to receive a copy by mail (\$5 charge).
 NPO-20182



Using Genetic Algorithms To Plan a Spacecraft Landing

A report summarizes a study in robust flightpath planning for a low-lift spacecraft to land on Mars. The basic problem was one of optimization: to plan a sequence of control actions — specifically, shifts in the position of an internal proof mass to change the center of mass of the spacecraft and thereby shift its angle of attack — to make the final landing position as insensitive as possible to such perturbations as errors and uncertainties in approach-trajectory parameters and in mathematical modeling of the Martian atmosphere. In the study, landing trajectories were computed by a nonlinear mathematical model of the descent dynamics, and optimization was performed by use of genetic algorithms to minimize a quadratic cost function of the landing miss distance over several realistically perturbed trajectories. It was found that by suitable scheduling of proof-mass shifts, the perturbed trajectories could be made to coalesce to a "bounce and drop" form, with root-mean-square landing errors reduced from 111 to 43 km. The results of this study also indicate that while genetic algorithms require long processing times (200 hours in this case), they are fairly easy to program and can provide useful solutions to complex optimization problems.

This work was done by David S. Bayard and Hamid Kohen of Caltech for NASA's Jet Propulsion Laboratory. To obtain a copy of the report, "Robust Flight Path Determination for Mars Precision Landing Using Genetic Algorithms," access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Mechanics category, or circle no. 160 on the TSP Order Card in this issue to receive a copy by mail (\$5 charge).
 NPO-20185

LITERATURE SPOTLIGHT

Free catalogs and literature for NASA Tech Briefs' readers. To order, circle the corresponding number on the Readers Information Request Form preceding page 97.



MOTORIZED VALVES

APP's compact, electrically operated motorized metering and on-off valves are available in various configurations, including straight, two-way angle, and three-way. APP's Motorized Valves take approximately 5 to 30 seconds to travel from fully open to fully closed and can be stopped in between. Easily adaptable, they retrofit other manually operated valves and come in custom cable lengths. Control of the valves is possible with APP Controllers such as the Remote Valve and Position Valve Controllers. Advanced Pressure Products, 83 Brown Rd., Bldg. 4, Ithaca, NY 14850; Tel: 607-257-5544; www.pmiapp.com

Advanced Pressure Products

For More Information Circle No. 600



BURST PRESSURE TESTER

APP's Burst Pressure Tester determines the exact pressure at which materials burst or fail. The Burst Pressure Tester is fully automated and features testing pressures up to 60,000 PSI, multiple sample testing, and rapid results (test length as low as 10 minutes). Applications include: burst pressure of disks or filter walls; crushing point of materials; crimp or vent failure of battery casings; and fatigue cycling. Advanced Pressure Products, 83 Brown Rd., Bldg. 4, Ithaca, NY 14850; Tel: 607-257-5544; www.pmiapp.com

Advanced Pressure Products

For More Information Circle No. 601



PRESSURE GAUGE CALIBRATION SYSTEM

APP introduces the Complete Pressure Gauge Calibration System for pressure gauge testing and calibration. The system includes a precise pressure controller with a high-accuracy master pressure gauge, a manifold for easy connection of test pressure gauges (slave gauges), and a fully automated data acquisition system. Controlled by Windows-based software, the system provides flexible test and graphics output. The calibration process can be performed automatically or manually. Advanced Pressure Products, 83 Brown Rd., Bldg. 4, Ithaca, NY 14850; Tel: 607-257-5544; www.pmiapp.com

Advanced Pressure Products

For More Information Circle No. 602



DC MINI MOTORS & MORE

API Portescap's new 50-page brochure highlights the world's largest range of ironless rotor DC mini motors, ranging from 0.29" to 2.7" and 1.5 kW peak. Also includes information on spur and planetary gearboxes; small DC brushless motors, including two-wire versions; disc magnet stepper motors; optical and magnetic encoders; tachometers; and drive electronics. API Portescap Inc., 110 Westtown Rd., West Chester, PA 19382; Tel: 800-566-5274 or 610-692-2700; Fax: 610-696-4598; www.apiportescap.com

API Portescap Inc.

For More Information Circle No. 603




PRECISION MOTION CONTROL

API Controls' 172-page step motor systems catalog, featuring the new Intelligent Drive series, includes definitions, applications, comparison charts, specifications, and diagrams that simplify the selection/application process. API Controls' products range from full/half-step driver modules to complete, high-performance microstep systems. API Controls Inc., 45 Hazelwood Dr., Amherst, NY 14228-2096; Tel: 800-566-5274 or 716-691-9100; Fax: 716-691-9181; www.apicontrols.com

API Controls Inc.

For More Information Circle No. 604



WORLD OF CLAMPING

The World of Clamping introduces DE-STA-CO's new line of high-strength composite clamps, details their remaining line of approximately 500 toggle clamps, and features expanded dimensional and application information. DE-STA-CO's toggle clamp line includes hold-down, latch, straight-line and squeeze-action clamps. The catalog also contains DE-STA-CO's pneumatic and hydraulic clamping systems (Catalog 197). DE-STA-CO, PO Box 2800, Troy, MI 48007; Tel: 248-594-5600; email: cust.serv@destaco.com; <http://www.destaco.com>

DE-STA-CO

For More Information Circle No. 605




OLYMPUS HIGH-SPEED VIDEO CAMERA

New Olympus Encore™ video camera monitors equipment to maximize productivity, lower per-unit costs, and increase line output. It digitally records up to 2,000 frames per second and provides instant, variable-speed slow-motion replay for analysis. Ideal for manufacturing, testing, QC, and research applications. Compatible with Olympus fiberscopes and borescopes. Olympus America, Inc., IPG, Melville, NY; Tel: 800-446-5260; Fax: 516-844-5620; email: info@ipg.olympus.com; www.olympusipg.com

Olympus America, Inc., IPG

For More Information Circle No. 606



WAVELET AND FILTER BANK TOOLKIT

The LabVIEW Wavelet and Filter Bank Design Toolkit delivers wavelet and filter bank tools for developers in signal and image processing, computer vision, biomedical signals and imaging, physics, and mathematics. For developers who are not LabVIEW users, the toolkit includes a ready-to-run application that can be used in other software applications such as C and Visual Basic. National Instruments, 6504 Bridge Point Pkwy., Austin, TX 78730; Tel: 512-794-0100 or 800-433-3488; Fax: 512-794-8411; email: info@natinst.com; <http://www.natinst.com>

National Instruments

For More Information Circle No. 607



VISION SOLUTIONS

Learn how to use PC-based vision systems with National Instruments' Image Processing Solutions application notes, to solve diverse science, medical, machine vision, and electronic inspection applications. Learn how PC-based vision systems can save you and your business time and money in applications requiring fast and repetitive machine vision inspection and automation. National Instruments; Tel: 512-794-0100; Fax: 512-794-8411; email: info@natinst.com; <http://www.natinst.com>

National Instruments

For More Information Circle No. 608



MAGNETIC SHIELDING KIT

Brochure describes techniques for shielding H-fields up to 100 KHz. Kit includes a variety of fully annealed CO-NETIC and NETIC alloys, plus an AC magnetic pickup probe to measure field strength and attenuation. Complete design information covers theory, prototypes, fabrication methods, and specifications. The kit is useful for anyone who needs fast solutions to magnetic shielding problems. Part Number LK-120 - \$129.00. Magnetic Shield Corp., Perfection Mica Co., 740 N. Thomas Dr., Bensenville, IL 60106; Tel: 630-766-7800; Fax: 630-766-2813; www.magnetic-shield.com

Magnetic Shield Corp.

For More Information Circle No. 609



NEW MATERIALS MICROSCOPE

Axiovert 25 CA is an inverted, incident light microscope that features high stability, versatile operation, and superb results. A rotary mechanical stage eases contrasting and identification of anisotropic materials, and

a video zoom adapter provides standard magnifications of video prints. Famous Zeiss optics produce brilliant images in darkfield, bright field, polarization, interference contrast, and fluorescence. Carl Zeiss, Inc., Microscopy Div., Thornwood, NY 10594; Tel: 800-233-2343; email: micro@zeiss.com

Carl Zeiss, Inc.

For More Information Circle No. 612



PEM® R'ANGLE™ RIGHT-ANGLE CLINCH FASTENER

The new self-clinching PEM® R'ANGLE™ fastener provides a strong right-angle attachment point in aluminum sheets as thin as 0.040"/1mm. Now you can securely attach another sheet or component perpendicular to the section in which the R'ANGLE fastener is installed. Attachment is made using a self-piloting, thread-forming screw. The result is an extremely tight thread fit that resists vibration and exhibits excellent strip-out characteristics. Penn Engineering & Manufacturing Corp.; Tel: 800-237-4736; Fax: 215-766-0143; http://www.pemnet.com

Penn Engineering & Mfg. Corp.

For More Information Circle No. 615



MINI LINEAR SLIDES AND STAGES

Mini slides in many styles: balls, rollers, stages, recirculating type. Deltron slides accommodate today's trend toward increasingly smaller assemblies and instruments in automated industrial systems. These microminiature components offer the same high quality and performance as that of their larger and more traditionally sized companion components. Del-Tron Precision Inc., 5 Trowbridge Dr., Bethel, CT 06801; Tel: 800-245-5013; Fax: 203-778-2721; email: deltron@deltron.com

Del-Tron Precision Inc.

For More Information Circle No. 618




NEW ENCLOSURES PREVENT MONITOR JITTER

ImageGuard II™ CRT enclosures eliminate monitor screen disturbances due to magnetic fields from power lines and electrical equipment. Easily installed ImageGuard II CRT Monitor Enclosures surround the display to stop smeared colors or jitter. Shield construction utilizes Military-Spec CO-NETIC AA magnetic shielding alloy for high attenuation of magnetic fields. Optional appearance enhancements include paint, Formica, or wood veneer exterior. Ask for Brochure IG-3. Magnetic Shield Corp., 740 N. Thomas Dr., Bensenville, IL 60106; Tel: 630-766-7800; Fax: 630-766-2813; www.magnetic-shield.com

Magnetic Shield Corp.

For More Information Circle No. 610



E-M ANALYSIS FOR WINDOWS

2D and 3D electromagnetics simulation is now available for PCs running Microsoft Win-

dows. MagNet 5.2.3 lets you cut/paste field plots, graphs, and other data directly into Windows applications to generate reports. Fully adaptive solutions tailored to user-defined error criteria. Free demo diskette. Infolytica: the e-m specialists; Tel: 514-849-8752; Fax: 514-849-7239.

Infolytica

For More Information Circle No. 613




NEW! OPTICS & OPTICAL INSTRUMENTS

Edmund Scientific's free 272-page catalog features our machine vision components and one of the largest selections of precision off-the-shelf optics and optical instruments. Our precision off-the-shelf optics, TechSpec™ Optics and optical components can take you from design, to prototype, to final production. We provide technical design and production solutions. Over 8,000 scientific and technical products, including magnifiers, lasers, microscopes, telescopes, "machine vision," and video microscopy. Tel: 609-573-6259; Fax: 609-573-6233; email: B971N954@edsci.com; http://www.edsci.com

Edmund Scientific Co.

Industrial Optics Division, Dept. B971, N954

For More Information Circle No. 616



NEW BOOK MAKES NONLINEAR FEA EASIER FOR ENGINEERS

A completely new book from Dr. Constantine Spyros and Dr. John Raftoyiannis. Filled with visual aids and easy-to-read FEA theory, it will

help engineers gain insight and master the once-considered difficult concepts of nonlinear FEA. APD; Tel: 800-48ALGOR; email: apd@algor.com; www.algor.com/apd

APD

For More Information Circle No. 619



COMPOSITE BEARING MATERIALS

Orkot Inc. offers a full-color brochure on composite bearing materials covering a wide range of bearing applications in the marine, hydroelectric, and industrial industries. Our environmentally friendly materials offer unique mechanical and physical properties that make it an ideal bearing material. Orkot® is available in either self- or non-lubricated forms and manufactured in tube, sheet, and finished product. For complete specs and pricing, contact Orkot Inc., 2535 Prairie Rd., Eugene, OR 97402; Tel: 800-546-7568; Fax: 541-688-2079.

Orkot Inc.

For More Information Circle No. 611



VACUUM SYSTEMS

This full-line brochure features Nilfisk's expanded vacuum cleaner line, including local exhaust hand tools and specialty products such as equipment for lead abatement and vehicle brake maintenance. Highlights of the

brochure include product application photographs and illustrations of the three filtration systems offered by Nilfisk. Nilfisk of America, Inc., 300 Technology Dr., Malvern, PA 19355; Tel: 215-647-6420; www.nilfiskamerica.com

Nilfisk of America, Inc.

For More Information Circle No. 614



IMAGINATION SYSTEMS' HYPERKERNEL

Hyperkernel is the first product that enables software developers to implement real-time systems applications that execute cooperatively with Windows NT. With Hyperkernel, developers can integrate highly deterministic real-time application programs. Hyperkernel enables devices such as robots, process controllers, and machine control systems to be configured as application servers on standard network systems. Imagination Systems Inc., 5752 Princess Anne Rd., Virginia Beach, VA 23462; Tel: 800-331-2565 or 804-497-8200; Fax: 804-497-2062; http://www.imagination.com

Imagination Systems Inc.

For More Information Circle No. 617



NEW BARNANT TEMPERATURE CONTROLLERS

Barnant Co.'s new temperature controllers feature direct plug-in of heating devices and adjustable over-temperature and loop break cutoff for fail-safe operation. Available in standard and deluxe models, they provide three control modes, basic on-off autotune PID and programmable PID, field calibration offset capability, and programmable alarms. Maximum accuracy is $\pm 0.4^\circ\text{C}$. Temperature input is via J, K, T, E, N, B, R, and S thermocouples. Barnant Co., 28W094 Commercial Ave., Barrington, IL 60010; Tel: 800-637-3739; Fax: 847-381-7053.

Barnant Company

For More Information Circle No. 620




PLASTIC & RUBBER EXTRUSIONS

For over 25 years, Trim-Lok, Inc. has been recognized as a leader in the field of plastic and rubber extrusions. Offering a full line of trims and seals designed for many industries such as automotive, boating, and aerospace, we are committed to finding solutions to any manufacturing needs. Located in Buena Park, CA, our state-of-the-art, 90,000-sq.-ft. facility enables us to offer quality products, manufactured on the premises, backed by unmatched delivery and customer service. Competitive pricing, on-time delivery, and unparalleled customer service. At Trim-Lok, we stake our reputation on it!

Trim-Lok, Inc.

For More Information Circle No. 621



GT50-DIO DYNAMIC DIGITAL I/O

Now, for the first time, PC-based high-speed digital testing is possible. The GT25/50-DIO provides the latest state-of-the-art digital testing capability for PC-based systems. Main features include: programmable test rates up to 50MHz, 32 to 256 bidirectional I/O pins, up to 1 Mbit memory behind each pin, powerful sequencer, and triggering mechanism. Geotest; Tel: 800-330-9774; www.geotestinc.com

Geotest, Inc.

For More Information Circle No. 624




FREE DATA ACQUISITION CATALOG

UEI's catalog gives you full specs for data acquisition boards that are DSP-enhanced and provide 16 channels at 1 MHz continuous A/D. Options include on-board simultaneous sampling and individual prog. gain amplifiers for all channels. Also available: 16 bits at 200,000 samples/sec. Describes UEI's new PowerDAQ™ boards for the PCI bus, incorporating a 66 MHz DSP and bus-mastering data transfer. UEI, 10 Dexter Ave., Watertown, MA 02172; Tel: 800-829-4632; Fax: 617-924-1441; www.ueidaq.com

United Electronic Industries

For More Information Circle No. 627



Hiram Jones Electronics, Inc./A Division of the Seastrom Hardware Group manufactures a complete line of standard miniature and sub-miniature terminals including: insulated test jacks, assembled standoffs and press-type terminals. All standard catalog items are available

for immediate pricing and delivery. Call today for your free 27-page catalog: 800-634-2356.

Hiram Jones Electronics, Inc.

For More Information Circle No. 630



21ST CENTURY PREVIEW EDITION

Vol. MM™ 21st Century™ Preview Edition contains over 750 full-color pages and is your source for the latest products in:

- Temperature
- Pressure and Force
- Flow and Level
- Data Acquisition
- pH and Connectivity
- Electric Heaters
- Environmental

Omega Engineering

For More Information Circle No. 622



ADVANCED COMPOSITE TRAINING

The industry leader in advanced composite training since 1983, Abaris Training offers engineering-level courses in design and analysis of composites: Introduction to Laminate Design, Structural Analysis and Repair Design, Design and Analysis of Composite Structural Joints, and Composite Crack Patching of Aluminum Airframes. We also offer introductory-level courses and practical workshops in fabrication and repair. Abaris Training Resources Inc.; Tel: 800-638-8441; Fax: 702-827-6599; e-mail: cn@training.abaris.com; www.training.abaris.com

Abaris Training Resources, Inc.

For More Information Circle No. 625



FREE LAMP CATALOG

Bulb Direct, Inc. sells replacement specialty lamps for A/V, photographic, stage, studio, video, micrographic, and graphic arts equipment, plus medical and electronic instruments. We offer brand names with two-day air delivery at no extra cost! New this year...Specialty Energizer Batteries. Bulb Direct Inc., 1 Fishers Rd., Pittsford, NY 14534-9511; Tel: 800-772-5267 or 716-385-3540; Fax: 716-385-4976.

Bulb Direct, Inc.

For More Information Circle No. 628



ELECTRO-MAGNETIC DESIGN SOFTWARE

The legendary Vector Fields suite of software, including the TOSCA, ELEKTRA and OPERA packages, combines classical finite element techniques with user friendly interactive graphics for high accuracy 2D and 3D simulation and design of all types of electromagnetic equipment.

Vector Fields Inc.

1700 North Farnsworth Avenue
Aurora, IL 60505
Tel: 630-851-1734 Fax: 630-851-2106

For More Information Circle No. 631



Load Cells Force/Torque Sensors

New catalog describes load, force, and torque sensors. Gram Sensors: from 10 to 1K grams; Load Cells: to 400K lbs.; Load Buttons: to 50K lbs.; Thru Hole Load Cells: to 30K lbs.; Torque Sensors: to 50K

Transducer Techniques Inc.

For More Information Circle No. 623



ALGOR PROVIDES "4-WAY" INFO ON THE WORLD WIDE WEB

Algor's Internet place has detailed information on four product lines. Discover Houdini, Algor's automatic CAD solid model to 8-node "brick" mesh converter. Learn about Algor FEA, including case histories. Preview engineering videos, books and multimedia. See all new integrated piping/vessel/plant design software. If you do not have Internet access, call for free info. Algor, Inc.; e-mail: info@algor.com; URL: http://www.algor.com; Tel: 412-967-2700; Fax: 412-967-2781.

Algor, Inc.

For More Information Circle No. 626



VESPEL® POLYIMIDE PARTS & SHAPES

DuPont VespeL® parts offer reliability and durability for semiconductor manufacturing. These high-performance components can reduce costs through longer life and extended maintenance intervals versus quartz and ceramics. VespeL® parts perform at high temperatures, resist chemical attack, and exhibit superior cleanliness, dimensional stability, and dielectric performance. Applications include clamping rings and other "in chamber" applications, wafer handling and processing, and IC handling and testing. DuPont Engineering Polymers, Barley Mill Plaza, Bldg. 22, PO Box 80022, Wilmington, DE 19880-0022; Tel: 800-972-7252.

DuPont Engineering Polymers

For More Information Circle No. 629



COMPUTERS AND ELECTRONICS

Circuit Specialists, Inc., in business for 26 years. Our 150-page catalog has over 9,000 products including industrial & personal computers, computer peripherals, board-level data acquisition & control products, test equipment, motion control products, educational laser & fiber optics, wiring products & much more. Circuit Specialists, Inc., 220 S. Country Club Dr., Bldg. 2, Mesa, AZ 85210; 24-hour catalog request line: 800-811-5201, ext. 5; Fax: 602-464-5824; http://www.cir.com

Circuit Specialists, Inc.

For More Information Circle No. 632




NEW KIND OF MULTIMEDIA VIDEO TEACHES FEA LESSONS

Finite Element Analysis in Action! is a new kind of instructional video for engineers. Available on VHS tape or interactive, multimedia CD-ROM, the video packs a lot of information into a short running time of only 26 minutes. Live lab experiments and FEA analysis are conducted to show how to better use any FEA software. Demonstrates specific modeling and analysis techniques. Tel: 1-800-482-5467; URL: <http://www.algor.com/apd.htm>; e-mail: apd@algor.com

APD

For More Information Circle No. 633



PLX HOLLOW RETROREFLECTOR BROCHURE

Pioneers in the development of hollow retroreflector technology, PLX can provide solutions where great optical stability and high-quality wave fronts are essential. The brochure features products designed for a variety of military, aerospace, industrial, and medical applications involving boresighting, interferometry, and spectroscopy. For a free copy, contact Jack Lipkins at: PLX, 40 Jeffrym Blvd., Deer Park, NY 11729; Tel: 516-586-4190; Fax: 516-586-4196; E-mail: plx@netusa.net

PLX

For More Information Circle No. 634



VXI PRODUCTS

The new HP Systems Builder's Source includes comprehensive technical information for the most complete selection of test system components available. Test system and VXI components, HP VEE - the graphical programming language for test engineers - and custom system integration services are detailed for solutions in electronic manufacturing test and data acquisition applications ranging from telecommunications to automotive. For a FREE catalog and CD-ROM, call Hewlett-Packard at 800-452-4844, ext. 1803.

Hewlett-Packard

For More Information Circle No. 635



1997 PCMCIA PRODUCTS CATALOG

The new PCMCIA-PC CARD standard has been incorporated into many new applications such as: Data-logging, agriculture, digital film, and wireless communications. Envoy Data has just released its new catalog for these new applications plus many other products like: memory, I/O (serial, parallel, SCSI, A/D, etc.) cards; PC card drives for ISA, IDE, SCSI, etc.; along with industrial card and drives, multimedia, industrial, and engineering tools for PCMCIA applications. Envoy Data Corporation, 6 E. Palo Verde, #3, Gilbert, AZ 85296; Tel: 602-892-0954; Fax: 602-892-0029; e-mail: info@envoydata.com; <http://www.envoydata.com>

Envoy Data Corporation

For More Information Circle No. 636



EMI/RFI SHIELDING PRODUCTS

New catalog details hundreds of standard gaskets and grounding strip variations, engineered to meet the most common shielding applications. Standard as well as custom designed shields are manufactured from Beryllium, Copper, and other High-performance materials. Special finishes and a variety of mounting methods are offered. For World Class quality and service call 973-890-7455 or visit our Web Site at: [HTTP://WWW.OMEGASHIELDING.COM](http://WWW.OMEGASHIELDING.COM); e-mail: SALES@OMEGASHIELDING.COM

Omega Shielding Products Inc.

For More Information Circle No. 637



THE SOURCE FOR ELECTRONIC & MECHANICAL HARDWARE

Seastrom takes pride in offering one of the widest selections of standard electronic and assembly hardware available from stock. Seastrom's 66-A Catalog provides a complete source for over 45,000 products. For a free 550-page catalog, call 800-634-2356.

Seastrom Manufacturing Co. Inc.

For More Information Circle No. 638




PRECISION MEASUREMENT & SENSING INSTRUMENTS FOR MANUFACTURING

Advanced line of measurement and sensing instruments for the calibration and maintenance of machine tools, robots, and CMMs. Includes 5-D laser measuring system, ballbars, spindle dynamic and thermal analysis system, levels, dual-axis beam steerer systems, laser trackers, and more. Automated Precision, Inc., 7901-C Cessna Avenue, Gaithersburg, MD 20879; Tel: 800-537-2720 or 301-330-8100; Fax: 301-990-8648.

Automated Precision, Inc.

For More Information Circle No. 639



HI-TEMP SOLUTIONS WORLDWIDE

Aremco produces high-temperature ceramics, adhesives, coatings, sealants, tapes, greases, castables, and potting compounds. These materials are used throughout industry in the design of sensors, electrical components, and analytical instruments, as well as the maintenance of high-temperature industrial process equipment. Aremco also produces dicing equipment and screen printers which are used in the processing of electronic and technical ceramics. Aremco Products, Inc., PO Box 429, 23 Snowden Ave., Ossining, NY 10562-0429; Tel: 914-762-0685; Fax: 914-762-1663.

Aremco Products, Inc.

For More Information Circle No. 640




VLSI INTERCONNECTION SPECIALISTS

Ironwood Electronics produces a range of interconnect solutions including hundreds of prototyping adapters, test probe adapters, programming adapters, and other interconnect devices. For fully compliant surface mount interconnect test adapters, we offer a wide selection of high-quality solutions. We also have custom design services for unique solutions in packaging. Ironwood Electronics, PO Box 21151, St. Paul, MN 55121; Tel: 612-452-8100; Fax: 612-452-8400; www.ironwoodelectronics.com

Ironwood Electronics

For More Information Circle No. 641




NEW LEVEL, FLOW AND PRESSURE SENSORS CATALOG

New 232-page catalog (more than 350 standard products) is now available from The Fluid Sensor People™ at GEMS! In addition to the thousands of sensor variations for OEM design engineers, the full-color Qwik Piks™ Section showcases hot products and cool tips for novices and experts alike, plus same-day shipping! Sensor technologies include: ultrasonic, electro-optic, fiber-optic, float, conductivity, Hall Effect, CVD transducers, and more. Gems Sensors, 1 Cowles Rd., Plainville, CT 06062; Tel: 800-321-6070; Fax: 860-793-4500.

Gems Sensors

For More Information Circle No. 642



STATIC ELIMINATORS

EXAIR-Ionizers improve static and dust removal in many applications and contain no radioactive element. Air-delivered ions neutralize static and clean surfaces at distances to 20 feet. Three styles, including air knife and blowgun, are available. Applications include web cleaning, pre-paint auto body blowoff, and neutralizing plastic parts. EXAIR Corporation, 1250 Century Circle North, Cincinnati, OH 45246; Tel: 800-903-9247; Fax: 513-671-3363; E-mail: techelp@exair.com; <http://www.exair.com>

EXAIR Corporation

For More Information Circle No. 643



RUGGED MINIATURE SWITCH

The Series 70 is an environmentally rugged line of lighted and unlighted switches. Wet, dusty or oily duty. DPDT MOM or ALT switch actions. Mounts on 0.700" centers with 0.880" depth. Lighted pushbuttons use T-1 MFB lamps. Variety of display types, colors, and styles. StacoSwitch, 1139 Baker St., Costa Mesa, CA 92627; Tel: 714-549-3041; Fax: 714-549-0930.

StacoSwitch

For More Information Circle No. 644



POWDER METALLURGY DESIGN SOLUTIONS

This 20-page brochure, published by the Powder Metallurgy industry trade association, is yours free for the asking. It features cost-effective design solutions and new ways to handle parts fabrication. Metal Powder Industries Federation, 105 College Road East, Princeton, NJ 08540; Tel: 609-452-7700; Fax: 609-987-8523; <http://www.mpif.org>

Metal Powder Industries Federation

For More Information Circle No. 645



VIBRATION ISOLATION & IMPACT ABSORPTION

New, full-color brochure describes the dynamic properties of Sorbothane, the unique vibration isolation and impact absorption material. New test data details the damping properties of Sorbothane compared to other elastomers. Sorbothane is a patented visco-elastic polymer. Includes information on Sorbothane's new line of advanced vibration isolation/shock absorption products, as well as applications engineering, manufacturing capabilities, and the many applications for Sorbothane. Sorbothane, Inc.; Tel: 330-678-9444; Fax: 330-678-1303; E-mail: webmaster@sorbothane.com; <http://www.sorbothane.com>

Sorbothane, Inc.

For More Information Circle No. 648




TOOLING COMPONENTS AND CLAMPS

This 500-page catalog contains an assortment of components including toggle clamps, modular fixturing, clamping devices, power workholding, chuck jaws, pins, knobs, drill bushings, leveling feet, and much more. Carr Lane Manufacturing Co., 4200 Carr Lane St., PO Box 191970, St. Louis, MO 63119-7970; Tel: 314-647-6200; Fax: 314-647-5736.

Carr Lane Manufacturing Co.

For More Information Circle No. 651



NETWORK FOR DSP APPLICATIONS

Introducing FibreXpress™, SYSTRAN Corp.'s new line of Fibre Channel host bus adapters. FibreXpress is ideal for very-high-speed mass storage and high-throughput, data-intensive DSP applications such as radar, sonar, medical scanners, and OCR. Request your free tech overview today! SYSTRAN Corp.; Tel: 937-252-5601; Sales: 800-252-5601; Fax: 937-258-2729; E-mail: info@systran.com; WWW: <http://www.systran.com>

SYSTRAN Corp.

For More Information Circle No. 654



ALGOR: FINITE ELEMENT SOFTWARE THAT'S CAPABLE & EXCITING

Algor's finite element analysis and virtual engineering software for the 21st century is revolutionizing the way engineers solve problems. Having more advanced solution techniques, a friendlier interface, and lower cost, Algor enables you to do things other software can't do. To see Algor in action, ask for your free information. Algor; Tel: 412-967-2700; Fax: 412-967-2781; e-mail: info@algor.com; <http://www.algor.com>

Algor

For More Information Circle No. 646




AIR MOVERS

Air Amplifiers convey, vent, exhaust, cool, dry, and clean—with no moving parts. Using a small amount of compressed air as a power source, Air Amplifiers move large volumes of surrounding air to produce high-velocity outlet flows. Air amplifiers are compact, durable, portable, and maintenance-free. Applications include small parts conveying; venting fumes; and cleaning, drying, or cooling parts. EXAIR Corporation, 1250 Century Circle North, Cincinnati, OH 45246; Tel: 800-903-9247; Fax: 513-671-3363; E-mail: techhelp@exair.com; <http://www.exair.com>

EXAIR Corporation

For More Information Circle No. 649



NEW GEMINI FOR WIDOWS

Fast 2D magnetostatics simulation at a budget price from Infolytica. Gemini for Windows incorporates neural network-based solutions, LDCG solvers, the Open Boundary Technique, and "tunable Maxwell stress" calculations. Call 800-492-6464 for full details and our promotion price. Infolytica: the e-m specialists; Tel: 514-849-8752; Fax: 514-849-4239; Europe: +44.123.582.3288; Japan/Adtech: 03-5276-5291.

Infolytica

For More Information Circle No. 652



THERMO-COUPLES, MAKE YOUR OWN

The HOTSPOT allows thermocouple wire to be formed into free-standing junctions, or welded to metal surfaces. It provides a simple means of fabricating thermocouples "when needed and where needed." Brochure and specification sheet available. Address: 7300 North Crescent Blvd., Pennsauken, NJ 08110. Tel: 609-662-7272; Fax: 609-662-7862; <http://www.thomasregister.com/dcc>

DCC Corp.

For More Information Circle No. 655



PRECISION ALUMINUM EXTRUSIONS

New! An informative brochure from MIN-ALEX, leader in close tolerance shapes to 3 1/2", illustrates typical applications and describes capabilities including short runs. MINALEX, quality leader, delivers on time, every time. MINALEX, PO Box 247, Whitehouse Station, NJ 08889; Tel: 908-534-4044; Fax: 908-534-6788.

Minalex

For More Information Circle No. 647



METAL BELTS AND DRIVE TAPES

This general product brochure describes the various attributes that make metal belts and drive tapes an exceptional and exciting option for design engineers. Manufactured by Belt Technologies for 25 years, this unique family of products has helped design engineers overcome challenging application requirements in the electronics, aerospace, biomedical, optical and packaging industries. Belt Technologies, Inc., PO Box 468, Agawam, MA 01001; Tel: 413-786-9922; Fax: 413-789-2786.

Belt Technologies, Inc.

For More Information Circle No. 650



NEW GUIDE TO SPRING DESIGN

Mid-West Spring's new Guide to Spring Design helps engineers/designers plan, design and specify springs. Brochure includes design formulae, materials property and Wahl curvature stress correction data. Compression, torsion and extension springs are discussed, along with materials data on high carbon spring steel, steel alloys, stainless steel, non-ferrous, and high temperature alloy wire and flat high-carbon spring steels. For a free copy contact Mid-West Spring Manufacturing Company, 1404 Joliet Road, Unit C, Romeoville, IL 60441; Tel: 800-619-0909; Fax: 708-739-3890.

Mid-West Spring Manufacturing Co.

For More Information Circle No. 653



INSTRUMENT DATA ACQUISITION

The SoftwareWedge™ directs serial (RS-232, RS-485, RS-422) data from any instrument into any Windows 3.x, 95, or NT application such as Excel, MMIs, VB, Control, and Statistical applications. This configurable driver provides full data acquisition and control of PLCs, data loggers, scales, flow meters, lab instruments, etc. Please contact TAL Technologies, Inc., 2027 Wallace St., Philadelphia, PA 19130; Tel: 800-722-6004 or 215-763-7900; Fax: 215-763-9711; <http://www.taltech.com>

TAL Technologies, Inc.

For More Information Circle No. 656

San Jose Convention Center



**More than 50,000
Electronics Professionals
will Converge at
Wescon - IC Expo/97**

**For the first time...
Bringing Wescon to the
Silicon Valley**

Wescon - IC EXPO

November 4 - 6, 1997

**North America's Largest Electronics
Trade Exhibition and Conference**

**Now the Largest Technology Event
in the Silicon Valley**

**FREE and CONVENIENT Transportation
Between Both Venues**

**For Complimentary Admittance
Visit and Register at
www.wescon.com**

**For More Information, Contact
Electronic Conventions Management
8110 Airport Boulevard
Los Angeles, CA 90045-3194**

**Phone 800/877-2668, 310/215-3976, ext. 218
Fax 310/641-5117 • Email wescon@ieee.org**

For More Information Circle No. 532


wescon

Technology on the Move

ic expoTM

A Wescon Event For The Semiconductor Industry


Santa Clara Convention Center



**Simultaneously at both the
San Jose and Santa Clara
Convention Centers**

New on Disk

Product of the Month



Manufacturing and Consulting Services, Scottsdale, AZ, has announced Anvil Express™ CADD/CAM software for Windows that includes the SolidWorks™ solid modeler for parts and assembly modeling, multiple-surface milling, tool path simulation and verification, photo-realistic rendering and animation, and Autosnap-3-D™ technology that automatically generates solid models from 2D geometry with a single mouse click. Other features include multimedia tutorials; parametric, surface, and wireframe modeling; and NC programming with support for multiple-surface machining.

For More Information Circle No. 700

Gridgen version 12 numerical grid generation software from Pointwise, Bedford, TX, uses OpenGL 3D graphics. The software enables construction of meshes for use with CFD and finite-element analysis software, and includes geometry modeling, IGES import, grid generation, and compatibility with Silicon Graphics, Hewlett-Packard, and IBM workstations.


For More Information Circle No. 707

Eos Systems, Vancouver, BC, Canada, has introduced Photo-Modeler Pro 3.0 modeling software that creates 3D models of existing objects and scenes through the use of photographs. Features include automatic camera orientation, surface drawing, enhanced file export and photo-texturing.

For More Information Circle No. 704

B.A. Intelligence Networks, Southfield, MI, has released a new version of BAAN PDM design-to-manufacturing software that provides two-way transfer of product-related data through an integrated suite of document management, versioning and change control, and product structure and workflow management capabilities.

For More Information Circle No. 708



TechOptimizer 2.5 Professional Edition Windows 95/NT engineering solution software from Invention Machine, Boston, MA, supports engineers in the conceptual stage of product and process development. TechOptimizer Module allows engineers to correctly state a problem; Effects, Principles, and Prediction Modules help find solutions; and the Feature Transfer Module allows transfer of desirable features from one system to another.

For More Information Circle No. 705

HyperForm™ metal stamping simulation software from Altair Computing, Troy, MI, contains HyperMesh® finite-element pre- and post-processor, and Simex® finite-element code for sheet metal forming. The program allows users to identify and correct potential stamping problems.

For More Information Circle No. 701



AC Technology North America, Louisville, KY, has introduced C-MOLD 3D QuickFill injection molding simulation software that accepts solid geometry models from any CAD package, and displays simulation results on the designer's solid model. The software reveals potential design or manufacturing problems and provides solution advice.

For More Information Circle No. 702

Microcal Software, Northampton, MA, has announced Origin™ version 5.0 Windows-based data analysis and technical graphics software for analyzing, graphing, and presenting data. The software opens Excel workbooks within its work space, allowing users to visually manipulate data within the Origin graph.

For More Information Circle No. 706

Corel Corp., Ottawa, ON, Canada, offers CorelCAD™ Modeler solid modeling software for visualizing, manipulating, and refining of 3D models. Based on ACIS® solid modeling, the program allows sharing and collaboration by multiple users. The Windows 95/NT 4.0-compatible software enables creation of parts and components individually, allowing users to arrange them into a single assembly.

For More Information Circle No. 703



HIGH-PERFORMANCE MOTION CONTROL SOLUTIONS

Globe Motors is a one-stop motion control resource for high-precision, miniature electric motors and motorized devices.

- Standard and custom products
- Planetary and spur geartrains

Call for immediate information!

Broad Product
Portfolio

Application
Engineering
Support

Rapid
Prototyping

GLOBE MOTORS™

A Division of Labinal Components and Systems, Inc.


9 3 7 / 2 2 8 - 3 1 7 1

2275 Stanley Avenue ■ Dayton, Ohio 45404 ■ Fax: 937/229-8531

For More Information Circle No. 442

CLOSE THE GAP!

SEAL MASTER INFLATABLE SEALS



"They're
Deucedly
Clever!"

OVERCOME TROUBLESOME DESIGN PROBLEMS



Inflatable seals in a wide range of sizes and configurations are used anywhere a positive seal is needed between opposing surfaces. It's the innovative solution for many difficult applications. Design assistance available.



SEAL MASTER CORPORATION

INFLATABLE SEALS AND OTHER CUSTOM RUBBER PRODUCTS
368 MARTINEL DRIVE • KENT, OH 44240-4368 USA
(330) 673-8410 • FAX (330) 673-8242
E-Mail: info@sealmaster.com • www.sealmaster.com

Bellows Assemblies... A Performance Classic



Servometer's craftsmanship and design capabilities can provide precision Bellows Assemblies for applications where weight, strength or flexibility are a priority. The exceptional life, extreme sensitivity and high flexibility of our bellows has greatly influenced their usage within the Instrumentation, Laser, Medical and Aerospace Industries.

- Can be soldered or welded to a leak tightness of less than 1×10^{-9} cc/sec.
- Pressures of 5000 PSI or higher
- Variable Wall Thicknesses
- Extremely low spring rates

Call for a
**free sample
and Brochure**

SERVOMETER®
501 Little Falls Road
Cedar Grove, NJ 07009

Fax (USA): (800) 785-0756
Fax: (973) 785-0756
Tel: (973) 785-4630
www.servometer.com

For More Information Circle No. 444

**NEW
CATALOG!**

Load Cells Force/Torque Sensors



Catalog Includes:

Gram Sensors	Thru Hole Load Cells
Tension Load Cells	Low Profile Load Cells
Mini Load Cells	Load Pins
Torque/Sensors	Transducer Indicators
Special OEM Sensors	




Transducer Techniques
(909) 676-3965 FAX (909) 676-1200
e-mail: tti@ttloadcells.com
URL: <http://www.ttloadcells.com>

43178 BUSINESS PARK DRIVE, B-101 • TEMECULA, CA 92590

For More Information Circle No. 445

New on the Market



The 16AC Series **plastic gearheads** from MicroMo Electronics, Clearwater, FL, feature load-bearing values of 6N (21.6 oz.) radial and 2N (7.2 oz.) axial. The gearheads have operating temperatures from -30 to 65°C and are capable of bi-directional operation. Gearhead weights vary from .11 to .21 ounces, depending on ratio, with efficiencies to 81%.

For More Information Circle No. 716

North American Capacitor Co., Indianapolis, IN, offers **piezoelectric and electromagnetic transducers**. The piezo transducers are available in external drive with no feedback, self-drive with feedback, surface mount, miniature speaker/piezo type, and miniature speaker cone type styles with sound output from 75 dB to 105 dB. Electromagnetic transducers are available with mounting pins or lead wires and offer sound outputs of 80 dB or 85 dB at 1.5V.

For More Information Circle No. 720



The TOO Bender electronically controlled, motor-driven **tube bender** from Swagelok Co., Solon, OH, bends carbon steel and stainless steel tubing in 1, 1-1/4, 1-1/2, and 2-inch sizes with a bending range from 1 to 110 degrees. The bender is self-contained and operates horizontally or vertically. Bends can be preset, and a digital display shows degree and progress of the bend.

For More Information Circle No. 714

Endura Coatings, Warren, MI, has introduced two synergistic **coatings** for use in the aerospace, automotive, chemical processing, packaging, plastics, medical, and pharmaceutical industries. The coatings provide surface hardness to 85 Rc, corrosion resistance, permanent release, and a low coefficient of friction.

For More Information Circle No. 713

DRS Precision Echo, Santa Clara, CA, has introduced the MTG-110 **digital tape drive** for high-speed data acquisition and video/image storage. The drive allows users to store 42 GB of uncompressed data on a single cassette, with a sustained data transfer rate of 12 MB per second over a SCSI-2 interface. It is compatible with most workstations, as well as Windows 95/NT.

For More Information Circle No. 712



The Goldline™ **brushless servomotor** from Kollmorgen Motion Technologies Group, Radford, VA, can withstand shocks of up to 40 g's and features a stainless steel shaft and rust-resistant plating and epoxy paint. Continuous stall torque from 0.62 to 80 lb-ft is available. The motor incorporates rare earth neodymium-iron-boron magnets.

For More Information Circle No. 715



The Compaq Professional Workstation 5100 **computer workstation** from Compaq Computer Corp., Houston, TX, features dual memory controller architecture that provides 1.07 GB/second of memory bandwidth; dual-peer PCI buses; and SMP support with up to two Pentium II 266-MHz or 300-MHz processors. The workstation features host interoperability application software for operation in both Windows NT and UNIX environments.


For More Information Circle No. 711

New on the Market



The DG-525 digital linear gauge from Ono Sokki Technology, Addison, IL, measures dimensions, thickness, curvature, eccentricity, displacement, height, depth, flatness, variation, run-out, roundness, distortion, and deflection. It measures to 0.00002" through a 25-mm measuring range. The gauge has an adjustable measuring force for taking measurements on compressible materials that require low pressure.

For More Information Circle No. 721



Ball Screws & Actuators Co., San Jose, CA, offers the XCT Supernut® and AFT Supernut® plastic nuts for linear positioning with zero backlash when mated with the company's stainless steel leadscrews. The XCT features the Active Cam™ Mechanism that automatically adjusts for wear; the AFT is designed for light load OEM applications up to 10 pounds.

For More Information Circle No. 710

MITAC Industrial Corp., Fremont, CA, has introduced the MIPC-106 industrial panel PC with a 10.4" TFT LCD display and a NEMA 4/12 rated front panel. The Pentium-based system includes a choice of CPUs up to a Pentium 200, and an optional Ethernet connector. It features up to 128 MB of DRAM, 150W power supply, and two serial ports for RS232/422/485 interface.

For More Information Circle No. 718

Pro-Log Corp., Monterey, CA, has introduced the P7000 Pentium II single-board computer that features a 233-MHz CPU and support chipset, a SCSI interface, and 2-MB Flash BIOS. A floppy drive, keyboard, mouse, and LPT port also are included. Four DIMM sockets can hold up to 1 GB of synchronous DRAM. The computer conforms to the PICMG PCI-ISA standard.

For More Information Circle No. 722



The DAQMeter™ 4350 temperature and voltage measurement instruments from National Instruments, Austin, TX, are plug-in boards used with thermocouples, RTDs, and thermistors. Models are available for PCMCIA-based notebook computers and ISA PCs and feature five half-digit measurements, a ±15V input range, NI-DAQ™ driver software for Windows, VirtualBench™ Logger turnkey virtual instrumentation software, and an instrument driver.

For More Information Circle No. 719

Servometer Corp., Cedar Grove, NJ, offers a line of metric bellows-type flexible shaft couplings that feature zero backlash and can absorb parallel shaft misalignments up to 1.73 mm. They also can absorb angular misalignments to 31° and axial movements of 5.84 mm. Stock bore sizes range from 3 to 8 mm, with custom sizes available. Outside diameters range from 6.4 to 25.4 mm, with overall lengths from 12.7 to 43.5 mm.

For More Information Circle No. 723



The Vivid 700 digitizing camera from Minolta Corp., Ramsey, NJ, converts objects into three-dimensional coordinate data for input into a computer. The portable color scanner is a non-contact system with zoom and autofocus functions that are used to define the target object and eliminate backgrounds. An ATA-PC card enables it to operate without a workstation.

For More Information Circle No. 717

ADHESIVE BONDS POLYETHYLENE & POLYPROPYLENE

MASTER BOND POLYMER SYSTEM X17

- No surface preparation needed ■ Room temperature or heat cure
- One component system ■ Easy to apply - brushable
- High bond strength - shear and peel ■ Excellent moisture resistance
- Convenient packaging



For information, call or write:
Master Bond Inc.
154 Hobart Street
Hackensack, NJ 07601
201-343-8983

Master Bond Inc.
Adhesives, Sealants & Coatings

For More Information Circle No. 446

INNOVATIVE INSTRUMENTATION . . .



Modular Instrumentation



Digital Signal Processing



Exotic Controllers



Hand Held Monitors



Vibration Alarms



Portable Calibrators



Portable
Signal Conditioning



Vibration Protectors



Precision Calibrators

. . . NO ONE ELSE COMPARES

- SIGNAL ANALYSIS
- SIGNAL CONDITIONING
- SIGNAL TRACKING
- SIGNAL FILTERING
- SIGNAL CONVERSION
- SIGNAL AMPLIFICATION
- SIGNAL GENERATION
- VIBRATION CONTROL
- MACHINERY MONITORING
- ENGINE ANALYSIS
- CHATTER CHECKING
- CALIBRATING
- TRIM BALANCING
- PRODUCTION SCREENING

When it comes to accurate and reliable vibration control, dynamic signal monitoring, and analysis there is no room for error. Trig-Tek, Inc. offers a wide variety of standard and specialized instrumentation to meet many dynamic applications.




For Free Information Call
(714) 956-3593 or Fax (714) 956-0162

Trig-Tek, Inc. • 423 S. Brookhurst St., Anaheim, CA 92804

For More Information Circle No. 447

109

Linear and Circular Precision Encoders



- Metal, glass or film
- Linear or Disk
- Close tolerance, custom designs
- Binary Code, Motor Control
- Applications: Automotive, office equipment, medical products, robotics

Call us toll-free for information or prompt quotation:

1/800-BMC-ETCH

Buckbee-Mears St. Paul
A UNIT OF BMC INDUSTRIES, INC.

278 E. 7th St., St. Paul, MN 55101
612/228-6400 • FAX 612/228-6572
info@bmcind.com • <http://www.bmcind.com>

For More Information Circle No. 448

Rotating Electrical Connectors



- Superior to conventional slip rings, Mercotac's liquid metal-wetted contacts provide reliability. No electrical noise, less than 1 milliohm resistance.
- Durable, compact, low cost, no maintenance. Ideal for computers, instrumentation, thermocouples, strain gauges, packaging, heating and control equipment.



Mercotac Inc.

6195 Corte del Cedro #100
Carlsbad, California 92009
760 431 7723 • Fax 760 431 0905
Internet: www.mercotac.com
e-mail: info@mercotac.com

For More Information Circle No. 449

New Literature


The SC900 Series servo drives are described in a brochure from Pacific Scientific Automation Technology Group, Rockford, IL. Also described are serial interface, SERCOS interface, and programmable single-axis position control option cards.

For More Information Circle No. 743



GyroMax™ speed reducers from Shimpco Drives, Skokie, IL, are described in a 28-page catalog. Included are single- and double-reduction models, and overhung load models. The speed reducers feature the patented Circulate® tooth design for minimal contact stress.

For More Information Circle No. 741




Control Resources, Littleton, MA, has released a 44-page SmartFan Catalog and Design Guide that includes SmartFan® speed controllers and alarms for AC or DC fans and blowers. The products are used in electronics cooling and HVAC applications.

For More Information Circle No. 742


Xantrex, Bellingham, WA, offers a 48-page catalog of programmable DC power supplies. Rackmounts, interfaces, analog programming, and other accessories also are included.

For More Information Circle No. 740



A six-page brochure describing miniature and instrument bearing assemblies is available from Dynaroll Corp., San Fernando, CA. Assembly component materials include stainless steel, aluminum, brass, and bioplastics.

For More Information Circle No. 745



NSK, Bloomington, IL, has released a 12-page brochure describing motion and control products such as ball screws, linear guides, motor systems, and mechanical systems. Also included are coatings, lubricants, and other related accessories.


For More Information Circle No. 746



Indigo Systems Corp., Santa Barbara, CA, offers a brochure describing mixed-signal VLSI circuits available in full-custom designs. Readout devices for infrared focal-plane arrays in standard, off-the-shelf designs also are included.

For More Information Circle No. 744

ARE YOU STILL TRYING TO MEASURE VERY THIN GAPS THE HARD WAY?



Capacitec HPS Series of thin (back to back) sensors can measure gaps as small as 0.0085" (.22mm) inboard 84" (2133.6mm) with accuracies of 0.0003" (7.6µm), without scratching delicate surfaces.

Capacitec


P.O. Box 819, 87 Fitzburg Rd., Ayer, MA 01432 U.S.A.
Tel. (978) 772-6033 • Fax (978) 772-6036

For More Information Circle No. 411

POSITION ACCURACY to ±0.5 arc second!

Inductosyn® transducers provide absolute or incremental position data to ±0.5 arc second (Rotary) or ±40 micrometers (Linear). Resolution to 26 bits.

For brochure, call 914/761-2600 or fax 914/761-0405.



FARRAND CONTROLS
DIVISION OF RUHLE COMPANIES, INC.
99 Wall Street, Valhalla, NY 10595

For More Information Circle No. 581

ASL Applied Science Laboratories
175 Middlesex Tpk, Bedford, MA 01730
tel: 617-275-4000 ASL@A-S-L.com

Eye Tracking

Pupil Size

Easy to use
Reliable
Flexible
Customized



For More Information Circle No. 582



FREE!
130
Page
Catalog


"Optics
for
Industry"

Free 130 page product catalog from Rolyn, world's largest supplier of "Off-the Shelf" optics. 24-hour delivery of simple or compound lenses, filters, prisms, mirrors, beamsplitters, reticles, objectives, eyepieces, plus thousands of other stock items. Rolyn also supplies custom products and coatings in prototype or production quantities. ROLYN OPTICS Co., 706 Arrowgrand Circle, Covina, CA 91722-2199, (626)915-5707, FAX (626)915-1379

For More Information Circle No. 583

MASS FLOW APPLICATION HANDBOOK VOL. II

Volume II of all new applications handbook from ABB K-Flow graphically illustrates coriolis flow process configurations with ABB K-Flow flowmeter system appropriate for each application. Updated applications involving Mass, Density, Batching, Proportioning, and others are included. ABB Instrumentation, P.O. Box 20550, Rochester, NY 14602-9913. Phone (800)82K-FLOW.



For More Information Circle No. 584

TECHNICAL FIBRE PRODUCTS MATERIAL ADVANTAGE



TFP is an Advanced Fiber Nonwoven Manufacturer that produces veils varying from 0.2-8.0 oz/yd from virtually any fiber type. Examples are Carbon, Aramid, Quartz, Silicon Carbide, Metal-coated and Glass. TFP's accurate fiber blending technology can produce a hybrid, tailor a specific resistivity level or utilize a thermoplastic fibre for molding. TFP also produces Intumescent mats for fire protection. Technical Fibre Products Limited. Tel: 914-355-4190; Fax 914-355-4192.

For More Information Circle No. 585

The Technology Connection

To Advertise Call (800) 944-NASA

Engineering Catalog

80/20 Inc.
The Industrial Erector Set
For the Full Story...
www.8020.net
(219)248-8030 • FAX 248-8029
1701 South 400 East • Columbia City, IN 46725

Inventors Marketplace

"How To Offer Your Invention For Sale."

We have helped hundreds of inventors and showed them how to offer their inventions for sale to businesses all over the world. No cost. Free Information.

Call 1-800-537-1133. Kessler Sales Corp.,
C-47-7, Fremont, Ohio 43420.

Idea Protection

IT'S MY IDEA, AND I CAN PROVE IT! Store and protect your ideas, inventions, innovations, business plans, and scripts in the INTELLECTUAL VAULT. Your sealed, dated and notarized records ready when you need independent, unbiased, unimpeachable proof: "THAT'S MY IDEA AND I HAD IT FIRST." Free info: (888) MY-VAULT. (888) 698-2858.

CAD/CAM Job Listing

CAD/CAM Job Listings

Pro/ENGINEER - www.pejn.com
Unigraphics - www.ugjn.com
SolidWorks - www.swjn.com
I-DEAS - www.ideasjn.com
CATIA - www.catjn.com

free to job-seekers:\$100 for employers

Have you visited the NEW NASA Tech Briefs web site?


- Renew or start your subscription
- Order Technical Support Packages
- Share Ideas in Reader Forum
- Preview upcoming issues
- "Visit" NASA R&D centers
- Find vendors and products

...all on-line now at
www.nasatech.com

NASA Tech Briefs, ISSN 0145-319X, USPS 750-070, copyright© 1997 by Associated Business Publications Co., Ltd. Copyright is not claimed for the individual "tech briefs" contained in this publication. The U.S. Government has a paid-up license to exercise all rights under the copyright claimed herein for government purposes. NASA Tech Briefs is published monthly by Associated Business Publications Co., Ltd., 317 Madison Ave., New York, NY 10017-5391. Editorial, sales, production and circulation offices at 317 Madison Ave., New York, NY 10017-5391. Subscription for non-qualified subscribers in the U.S., Panama Canal Zone, and Puerto Rico, \$75.00 for 1 year; \$135.00 for 2 years; \$200.00 for 3 years. Single copies \$10.00. Foreign subscriptions one-year U.S. Funds \$195.00. Remit by check, draft, postal, express orders or VISA, MasterCard, or American Express. Other remittances at sender's risk. Address all communications for subscriptions or circulation to NASA Tech Briefs, 317 Madison Ave., New York, NY 10017-5391.

Advertisers Index

Company	Web Site	Circle Number	Page	Company	Web Site	Circle Number	Page
Abaris Training Resources, Inc.	www.training.abaris.com	625	103	Kingston Technology Company	www.kingston.com/storage	505	15
ABB K-Flow		584	111	Kistler Instrument Corporation	www.kistler.org	414	48
ADAC, American Data Acquisition Corporation		456	81	Knurr USA Inc.		526	71
Adaptive Research	www.adaptive-research.com	550	3	Kollmorgen, Motion Technologies Group	www.kollmorgen.com	666	4b
Advanced Pressure Products	www.pmiapp.com	600,601,602	101	Lasiris Inc.	www.lasiris.com	468	7a
Affinity		469,473,475	8a,11a,12a	Lattice		470	8a
Alesa Aluisse Canada Ltd.		452	76	LinTech		674	12b
Algor, Inc.	www.algor.com	510,626,646	7,103,105	Liton Poly-Scientific	www.liton-ps.com	683	COV IIb
American Variseal	www.variseal.com	425	79	Magnetic Shield Corp.	www.magnetic-shield.com	609,610	102
AMP Incorporated	www.amp.com	525	47	MARC Analysis Research Corporation	www.MARC.com	519	53
APD	www.algor.com/apd.htm	619,633	102,104	March Manufacturing Inc.		431	87
API Controls Inc.	www.apicontrols.com	604	101	Master Bond Inc.		430,446	86,109
API Portescap Inc.	www.apiportescap.com	682,603	13b,101	Mathsoft, Inc.	www.mathsoft.com/mathcad	539	77
Applied Science Laboratories		582	111	MathWorks, Inc.	www.mathworks.com/ntb	508	16A-B,17
Aremco Products, Inc.		640	104	Media Cybernetics	www.mediacy.com	415	54
Astro-Med, Inc.	www.astro-med.com	521	55	Mercotec Inc.	www.mercotec.com	449	110
Autodesk, Inc.	www.autodesk.com		9-11	Metal Powder Industries Federation	www.mpif.org	645	105
Automated Precision, Inc.		639	104	Micron Electronics	www.micronpc.com	511	25
Barnant Company		620	102	Mid-West Spring Manufacturing Co.		653	105
Belt Technologies, Inc.		650	105	Minalex		647	105
Bentley Systems, Incorporated	www.bentley.com	509	23	Minco Products, Inc.		429	86
W.M. Berg, Inc.	www.wmberg.com	671	10b	MKS Instruments, Inc.	www.mksinst.com	412	42
Breault Research Organization Inc.	www.breault.com	460	13a	Morgan Matroc Inc.	www.morganmatroc-eed.com	474	11a
Buckbee-Mears St. Paul	www.bmcind.com	448	110	National Instruments Corporation	www.natinst.com, www.natinst.com/HiQ	500,409,607,608	COV II,16,101
Bulb Direct, Inc.		628	103	NEAT (New England Affiliated Technologies)	www.neat.com	679	6b
Busak + Shamban		675	14b	Nilfisk of America, Inc.	www.nilfiskamerica.com	614	102
Canon	www.usa.canon.com	480	COV IIa	Novoteknik U.S. Inc./Siedle Group	www.novoteknik.com	677	15b
Capacitec		580	111	Numerical Algorithms Group, Inc.	www.nag.com	441	95
Cardinal Aluminum Co.		416	56	Ocean Optics Inc.	www.Ocean Optics.com	420	34
Carl Zeiss, Inc.		612	102	Olympus America, Inc., IPG	www.olympusipg.com	606	101
Carr Lane Manufacturing Co.		651	105	Omega Engineering, Inc.	www.omega.com	501,622	1,103
Chino Works America Inc.		427	82	Omega Shielding Products Inc.	www.omegashielding.com	637	104
Circuit Specialists, Inc.	www.cir.com	632	103	Omron	www.oel.omron.com	514	37
Cole-Parmer Instrument Company	www.coleparmer.com	513	32A-B,33	Optical Research Associates	www.opticalres.com	467	5a
Compaq Computer Corporation	www.compaq.com	518	44-45	Optima Precision Inc.	www.optima-prec.com	465	1a
Corning Incorporated		466	2a	Oregon Micro Systems, Inc.	www.OMSmotion.com	665	1b
CUI Stack		439	100	Orkot Inc.		611	102
Cybernetics			21	Oriental Motor U.S.A. Corp.	www.omusa.com	667	7b
Data Technology, Inc.		455	74	Paroscientific, Inc.	www.paroscientific.com	424	79
Dayco Products, Inc.	www.dayco.com	669	9b	Patriot Sensors & Controls	www.xducer.com	453	94
DCC Corp.	www.thomasregister.com/dcc	655	105	Penn Engineering & Manufacturing Corp.	www.pemnet.com	615	102
De-Sta-Co	www.destaco.com	605	101	Phytron, Inc.	www.phytron.com	670	10b
Del-Tron Precision Inc.		618	102	PLX		634	104
Delta Tau Data Systems	www.deltat.com	668	8b	Power Technology Incorporated	www.PowerTechnology.com	507	67
The Deschner Corporation		434	88	Presray Corporation	www.presray.com	419	64
Digi-Key Corporation	www.digikey.com	504	5	Pyrometer Instrument Company, Inc.		438	91
Dolch Computer Systems, Inc.	www.dolch.com	512	27	Research Systems, Inc.	www.rsinc.com	515	COV IV
DuPont Engineering Polymers		629	103	RGB Spectrum	www.rgb.com	408	12
DuPont Vespel	www.dupont.com/enggpolymer	529	18-19	Rockwell Automation, Electro-Craft		681	5b
Eastman Kodak Company		481	3a	Rolyn Optics Co.	www.rolyn.com	583,463	111,13a
Edmund Scientific Co.	www.edsci.com	432, 462,616	87,13a,102	Seal Master Corporation	www.sealmaster.com	443	107
EGC Enterprises Inc.	www.egc-ent.com	437	91	Seastrom Manufacturing Co. Inc.		638	104
Endevco	www.endevco.com	573	39	Servometer	www.servometer.com	444	108
Envoy Data Corporation	www.envoydata.com	636	104	Setra Systems		423	78
Epix, Incorporated	www.epixinc.com/epix	426	80	SL Corporation	www.sl.com	413	43
Ergotron	www.ergotron.com	417	58	Sony Electronics Inc.	www.sony.com/professional		50-51
The Evans Capacitor Company	www.evanscap.com	411	66	Sorbothane, Inc.	www.sorbothane.com	648	105
EXAIR Corporation	www.exair.com	643,649	104,105	SPSS Inc.	www.spss.com/science/sigmaplot, www.spss.com/software/science/tcurve2		4
EXFO Electro-Optical Engineering		464	13a	StacoSwitch		644	104
Farrand Controls		581	111	Sumitomo Metals Industries		422	78
Folsom Research	www.folsom.com	506	2	Sunx Sensors		570	31
FJW Optical Systems, Inc.		472	10a	Systran Corp.	www.systran.com	654	105
Gage Applied Sciences Inc.	www.gage-applied.com	520, 435	75,96	TAL Technologies, Inc.	www.taltech.com	656	105
Gems Sensors		642	104	Tec Products and Lab Services		476	10a
Geotest, Inc.	www.geotestinc.com	624	103	Tech 80 Inc.		695	15b
Glentek	www.glentek.com	673	12b	Technical Fibre Products Limited		585	111
Globe Motors		442	107	Teledyne Relays	www.teledyneclays.com	517	41
Government Micro Resources, Inc.	www.gmri.com	516	49	Titan Tool Supply Co.		461	13a
Harmonic Drive Technologies	www.harmonic-drive.com	672	11b	Torrington, Ingersoll-Rand	www.torrington.com		13
Haydon Switch & Instrument		678	16b	Transducer Techniques, Inc.	www.tloadcells.com	445,623	108,103
HD Systems, Inc.	www.hdsystemsinc.com	451	98	Trig-Tek, Inc.		447	109
Hewlett-Packard Company	www.hp.com/go/technical		60-61	Trim-Lok Inc.		433,621	88,103
Hewlett-Packard LogicDart	www.hp.com/info/LogicDart1	530	83	United Electronics Industries	www.ueidaq.com	627	103
Hiram Jones Electronics, Inc.		630	103	Vector Fields Inc.		631	103
Hitachi Denzhi America, Ltd.		410	24	Voltek, Division of Sekisui America Corporation		459	90
Humphrey		680	3b	Watlow Gordon	www.watlow.com	545	29
Imagination Systems, Inc.	www.imagination.com	617	102	Wescon-IC Expo/97	www.wescon.com	532	106
Infolytica		613,652	102,105	Western Graphtec, Inc.		418	59
Instrument Technology, Inc.		440	100	Wolfgram Research, Inc.	www.wolfgram.com/v3/ntb	524	69
Instrumented Sensor Technology	www.isthq.com	454	94	Working Model, Inc., Div. of Knowledge Revolution	www.workingmodel.com	523	63
Integrated Systems, Inc.	www.isi.com	542	57				
Interface	www.interfaceforce.com	428	85				
Intergraph Software Solutions	www.intergraph.com/solidedge	527	73				
Interpoint, A subsidiary of Crane Co.	www.interpoint.com	531	COV III				
IOtech, Inc.	www.iotech.com	401-407	64A-B				
Ironwood Electronics	www.ironwoodelectronics.com	641	104				
Iscan, Inc.	www.iscaninc.com	436	96				
JML Optical Industries, Inc.		471	9a				
Kerk Motion Products, Inc.		676	14b				



Get ready to launch your space projects faster than ever before.

Off-the-shelf space-qualified converters. Out-of-this-world reliability.



Power Converters

SMHF	SMSA
15 watts	5 watts
Outputs:	Outputs:
3.3, 5, 12, ± 12 , or ± 15 VDC	5, 12, 15, ± 12 , or ± 15 VDC
Complete protection features	
Input voltage range: 16-40	

EMI Filter

SFMC

Meets MIL-STD-461C requirements

Interpoint's new fully qualified, radiation hardened DC/DC power converters and EMI filters deliver the performance of custom products with the convenience of off-the-shelf power solutions.

They're the first space-qualified power products of their kind. And they're ready to go when you are, eliminating the time and expense of custom power solutions.

Models with up to 15 watts of output power delivered in a galaxy of configurations meet your every system need. Products are available in three different environmental screening grades with three different radiation tolerance options.

Concerned about quality? Don't be. Our new space power products are compliant to MIL-PRF-38534 Class K requirements. Screened models are guaranteed to withstand up to 100 k

Rads (Si) and survive SEUs. And they're designed with the small size and light weight that space applications demand.

Need the best of both worlds? Then call us for out-of-this-world power products at down-to-earth pricing.

Call: 1-800-822-8782
(For your free poster)

Visit our Web site:
<http://www.interpoint.com>

Paris Air Show Booth
Hall 4, Stand E-5

CRANE

interpoint
A SUBSIDIARY OF CRANE CO.

Corporate Headquarters, USA
Redmond, Washington
Phone (425) 882-3100
Fax (425) 882-1990
E-mail power@intp.com


Interpoint France, Saint Gratien
Phone +33-134285455
Fax +33-134282387
E-mail powerfr@intp.com

International Headquarters, UK
Phone +44-1252-815511
Fax +44-1252-815577
E-mail poweruk@intp.com

Interpoint Germany, Darmstadt
Phone +49-6151-177629
Fax +49-6151-177654
E-mail powergr@t-online.de



Create Revolutionary Results. Fast.



Visualize your data with IDL®, the *Interactive Data Language*, and see results in a whole new way.

Easily create amazing graphics with IDL software's accelerated 3D system. Want to spin or fly-through a surface? No problem. Shade and illuminate with multiple light sources?

IT'S A SNAP IN IDL.

IDL software's array-oriented architecture is designed for high-performance processing of large, complex data. That's why it's the standard in the world's preeminent medical, military, engineering & science organizations. IDL is so efficient that a few lines of IDL can do the job of hundreds of lines of C or Fortran. And, its object-oriented system lets you develop sophisticated applications from reusable code modules.

Image processed in IDL software and courtesy of NASA and ST ScI.

Analyze data faster. Create simulations easier. Write better applications.

Read in, analyze and output your data with the click of a mouse with IDL Insight™.

Connect to your relational database with the IDL DataMiner™.

Automatically share your programs – with full graphical interfaces – among Windows, Unix and Macintosh systems. Check out our flexible license options – we'll help you protect your intellectual property and economically distribute your applications.

Create maps in any of 16 projections.

Crunch numbers with IDL's integrated mathematics, statistics and industry-standard Numerical Recipes™ algorithms.



new release

IDL 5.0

For More Information Circle No. 515

Stop waiting for your results. Call us for a free Demo CD or visit our website and download it today. www.rsinc.com

Research Systems 303-786-9900 info@rsinc.com Software = Vision™

International Distributor Offices
Austria, Germany, Liechtenstein, Luxembourg, Switzerland, The Netherlands: CREASO GmbH tel: 49 8105 25055 • Brazil: SulSoft tel: 55 51 337 38 91 • China, Hong Kong: 3-Link Systems Pte Ltd. tel: 86106 261 0161
France, Belgium: Fast Parallel Solutions France tel: 33 1 41 73 20 00 • Italy: Alliant Computer Systems SRL tel: 39 39 6091766 • Japan: Adam Net Ltd. tel: 81 3 5802 2251 • Korea: InterSys tel: 82 42 869 4746

IDL SOFTWARE