

NASA Tech Briefs


THE DIGEST OF NEW TECHNOLOGY


Official Publication of the National
Aeronautics and Space Administration
Incorporating Federal Lab Tech Briefs
August 1995 Vol.19 No.8

Transferring Engineering
Technology to Over 200,000
Qualified Readers Throughout
Industry and Government

New Graphics & Simulation Software

High-Tech Tool Aids Oklahoma City Rescue





Test and Measurement

"Programming in LabVIEW reduced the development time of our system from the expected 16 months to four months and allowed us to quickly make changes to our system."


Keith Simmons
Electrical Engineer



Virtual Instrumentation

"LabVIEW handles the 'nuts and bolts' of computer programming without my knowledge of the details. That makes it what I call an engineer's and scientist's programming language."

John O'Neal
Laboratory Automation Specialist



Process Monitoring and Control

LabVIEW[®]

Proven Productivity for Your Industry

To increase productivity and reduce time to market, you need software that's easy to use, yet versatile enough to handle your demanding applications. Whether you're in research, production, automation, or test, the key to success is software – software that empowers your organization to build higher quality products faster and for less money. That's where LabVIEW comes in.

Software Innovation – for Your Applications

LabVIEW, the leading graphical programming language, gives you the software to automate your measurement, control, and analysis applications. LabVIEW pioneered Virtual Instrumentation almost a decade ago and continues to deliver proven productivity through breakthrough innovations and years of customer feedback.

Flexible I/O – for Your Instrumentation

LabVIEW communicates with thousands of I/O devices, including our complete line of data acquisition hardware, GPIB and

VXI instruments, serial devices, PLCs, and much more. Take advantage of the hundreds of instrument drivers and ready-to-run programs included with LabVIEW.

Solutions Worldwide – for Your Industry

Today, LabVIEW is making a difference in many industries, including automotive, telecommunications, semiconductor, electronics, aerospace, chemical, and education. Industry leaders worldwide use LabVIEW because it delivers proven productivity over and over again. For specialized needs, hundreds of third-party Alliance Program companies are ready with their LabVIEW expertise.

If you want to learn more about LabVIEW, give us a call. We'll show you how you can benefit from the graphical programming power of LabVIEW – **It's Proven Productivity for Your Industry.**



Call (800) 433-3488
today for **FREE** LabVIEW
demo software.



U.S. Corporate Headquarters: Tel: (512) 794-0100 • Fax: (512) 794-8411 • E-mail: info@natinst.com • WWW: <http://www.natinst.com>

Branch Offices: Australia 03 9 879 9422 • Austria 0662 45 79 90 0 • Belgium 02 757 00 20 • Canada 519 622 9310 • Denmark 45 76 26 00
Finland 90 527 2321 • France 1 48 14 24 24 • Germany 089 741 31 30 • Hong Kong 2645 3186 • Italy 02 48301892 • Japan 03 5472 2970
Korea 02 596 7456 • Mexico 95 800 010 0793 • Netherlands 03480 33466 • Norway 32 84 84 00 • Singapore 2265886 • Spain 91 640 0085
Sweden 08 730 49 70 • Switzerland 056 20 51 51 • Taiwan 02 377 1200 • U.K. 01635 523545

© Copyright 1995 National Instruments Corporation. All rights reserved. Product and company names listed are trademarks or trade names of their respective companies.

For More Information Write In No. 503

SPECIAL VISUAL CADD OFFER!

VISUAL CADD™

VERSION 1.2

WHO SAYS YOU CAN'T BUILD A BETTER MOUSETRAP?

*Open architecture,
fully programmable CAD
for under \$500.
We've built it.*

Customizable, flexible CAD at a reasonable cost. Impossible? Not anymore.

Introducing Visual CADD 1.2, the only open architecture CAD program for Windows that lets you program and customize as much or as little as you need. No other CAD program under \$1,000 offers this flexibility—including AutoCAD LT®.


Enjoy a familiar two-letter command set for speedy input, a huge viewing area for better visibility, and full read-write capabilities for AutoCAD® DWG and DXF files (judged "best on the market" by Computer Aided Engineering magazine, 1/95). Add our 60-day money-back guarantee and free technical support from some of the brightest minds in the business, and you've got a powerful combination of cost and features.

We call it Ultra Value. And it's only from Numera. Never say never.

Visual CADD 1.2 Lets You:

- Create custom, event-driven, interactive commands with Windows-supported languages like C/C++, Visual Basic, Delphi and FORTRAN.
- Achieve seamless integration with customized commands on menus, button palettes, and even keystroke combinations.
- Add custom, private user data to Visual CADD's entities and drawing environment.
- "Hot link" custom applications to a Visual CADD editing session through DDE notification.

**COMPETITIVE
UPGRADE \$199
OFFER ENDS
AUGUST 31, 1995.**



numera™
Software

1-800-956-CADD

HOME PAGE ADDRESS:
HTTP://WWW.NUMERA.COM/


Numera Software Corporation • 1501 Fourth Avenue Suite 2880 • Seattle, WA 98101 • Voice 206.622.2233 • Fax 206.622.5382 • Compuserve 74774.532
© 1995 Numera Software Corporation. Visual CADD is a trademark of Numera Software Corporation. All other brand and product names are trademarks or registered trademarks of their respective holder.

For More Information Write In No. 660

IN CASE YOU MISSED IT!

Here's what **they*** said about DADiSP 4.0

A streamlined user interface that fully conforms to Windows is the first obvious feature of a long-awaited upgrade to DADiSP, a graphical analysis program from DSP Development Corp. that's designed for the needs of scientists and engineers.



A major overhaul of the user interface, the introduction of an integrated programming language and new option modules highlight Ver. 4.0 of DADiSP...

Besides adopting a complete Windows look and feel, the overall interface scheme has gained a more streamlined look... [W]ith the flattened hierarchy on this upgrade, the software always starts up in a worksheet; indeed, when loaded, the software returns to the setup that was on the screen when the user last exited the program. Although you don't have to go through a hierarchy, the package still maintains labbooks, datasets and worksheets to provide a simple method of organizing large complex datafiles and projects.

As part of the Windows implementation, Ver. 4.0 adds support for DDE as a client or server either with functions at the command line or with Copy/Paste Link for the pulldown menu. It performs both warm and hot DDE links with either ASCII or binary datatypes...

Ver. 4.0 also gives users the ability to define their own operations and functions to a far greater extent than the macros found in the previous version. Specifically, the upgrade marks the introduction of a programming language called SPL (series processing language). Modeled on C, it provides all the expected facilities including user-defined functions, looping and iteration, conditional statements, array references and variables. Variables can be global to a session or local to a function.

An interesting feature is the hot variable, which can contain real or complex numbers, strings, data series and matrices. A hot variable links a formula to a variable so that when a dependent element of a formula changes, the hot variable automatically reevaluates. For example, the SPL code fragment:


```
size := 10
W2: Movavg(W1, size)
```

performs a 10-point moving average on the waveform in Window 1 and displays the results in Window 2. The := operator establishes the hot variable. You can explore the effects of changing the moving-average length simply by reassigning size := 20 so that W2 automatically updates and shows a plot based on that new parameter.

Also improved is the package's hardcopy facility. Plot titles, legends, multiple scales, selectable fonts and a Preview mode help users produce publication-quality output...

[T]wo more modules... address advanced DSP and control applications. The AdvDSP module performs Chirp-Z transforms, N-point FFTs independent of series length and zoom FFTs. It also handles multiple forms of PSD estimation (classical, autoregressive parametric, moving-average parametric, autoregressive moving-average parametric), transfer-function estimates, Cepstrum analysis and digital interpolation. The controls module allows you to execute command line or pulldown menus, and it addresses the design, analysis and simulation of digital and continuous open- and closed-loop controllers for linear single-input/single-output dynamic systems. Among its algorithms are those that handle PID loops as well as lead and lag controllers.


* Personal Engineering & Instrumentation News 1/95



For a Free TRIAL

Call today: 1-800-777-5151

For More Information Write In No. 541

 **DSP**
Development
Corporation
One Kendall Square, Cambridge, MA 02139
617-577-1133, FAX: 617-577-8211

'Don't freeze your assets'

Get cold, hard cash!

RAG buys the
re-owned,
recent-model
test equipment
you're not
using anymore.

RF and
Microwave
Equipment,
Spectrum
Analyzers,
Synthesizers
Oscilloscopes
Environmental
Chambers
Power Supplies
and More!



FREE
Test Equipment
Catalog

Calibrated & NIST
Traceable Used
Equipment,
Factory Authorized
New Equipment



To sell your
extra test equipment
or order a free catalog call

RAG Electronics, Inc.

1-800-455-3457

450 Turquoise Circle, Newbury Park, California, U.S.A. 91320-1200 • FAX 805-498-3733 • Tel: 805-498-9933
For More Information Write In No. 508

A powerful PC X server to access multiple X-based platforms such as UNIX and VMS while maintaining the advantages of the PC.

100% Microsoft® Windows™ compatible.

Local Windows and host-based X applications run concurrently on the PC screen with seamless copy and paste of data and images.

Performance optimized 32-bit PC X server

redesigned to harness the maximum speed from a wide range of PC microprocessors including the Intel 486 and Pentium.

Setup Configuration Administrator to customize the installation process to site requirements, effectively eliminating or minimizing end-user involvement.

Remote Configuration

Administrator to easily manage and administer configuration changes on an unlimited number of PCs.

Built-in eXceed Basic scripting language

for customizing applications and automating repetitive tasks.

MIT X11

Release 6 fully compliant.

Unique, full-featured X Development Kit

included to port, design and run X clients right on the PC.

LPR/LPD printing

support between PCs and hosts.

Integrated high-performance VxD-based TCP/IP network connectivity software

plus support for over 20 other TCP/IP transports.

eXceed/Xpress dial-up X connectivity software included

for X access by remote PCs and LANs over telephone lines.

Integrated drag-and-drop FTP

with graphical user interface for easy file transfer.

Support for up to VT 320 Telnet emulation including font resizing and scripting capabilities.

Graphical keyboard configurator for simple remapping of keys and key sequences.

Exclusive Xtrace protocol tracer

captures X network protocol for greatly simplified troubleshooting and application debugging.

Unique Launch Pad user-programmable

menuing facility with graphical interface which simplifies window management and application launching.

Choice of window managers — choose a host-based window manager such as Motif or OpenLook; or local one, either Microsoft Windows or Hummingbird's Motif-like window manager (hwm).

Xsession, drag-and-drop multiple program starter for concurrent startup of X, non-X and Windows applications.

eXceed 4

It's X, from A-to-Z.

If you want comprehensive PC-to-UNIX integration, Hummingbird's eXceed® 4 for Windows™ is the one PC X server that gives you everything. And now, the new eXceed 4 for Windows NT™ brings this same remarkable functionality and ease-of-use to the NT platform. eXceed 4 is the only PC X server that bundles in a BASIC scripting language plus a full-featured X Development Kit. And from the worldwide leader in PC-to-UNIX integration, eXceed is the only family of PC X servers available for Windows, Windows NT, OS/2® and DOS. So if what you want is seamless, stable PC-to-UNIX technology, what you really need is eXceed.


For more information or the name of the reseller nearest you, call (416) 496-2200



1 Sparks Avenue, North York, Ontario, Canada M2H 2W1 Tel: (416) 496-2200 Fax: (416) 496-2207 • In Europe: 37 rue de Vermont, 1202 Geneva, Switzerland Tel: +41 (22) 733 18 58 Fax: +41 (22) 733 64 03
Offices in: Washington DC & Mountain View CA, USA • Munich, Germany • Paris, France • Leeds, U.K.

eXceed is a registered trademark of Hummingbird Communications Ltd. All other brand or product names are trademarks or registered trademarks of their respective companies. © 1995, Hummingbird Communications Ltd.

PROTOTYPE TO PRODUCTION



On orders placed by
5:00 p.m. central time

**DIGI-KEY: Your Ultimate Source
For Quality Electronic Components!**

- #1 for Availability of Product
- #1 for On-Time Delivery
- #1 for Overall Performance

Call, write or fax for your
FREE CATALOG today!

Digi-Key
CORPORATION

1-800-344-4539

701 Brooks Ave. South, Thief River Falls, MN 56701
Fax: 218-681-3380

Contents

NASA Tech Briefs

Transferring Engineering Technology
to Over 200,000 Qualified Readers
Throughout Industry and Government

FEATURES

- 20 Mission Accomplished
- 22 Resource Report: Kennedy Space Center

TECHNICAL SECTION

24 Special Focus: Computer Graphics and Simulation



- 24 Program for Simulating Dynamics of Aerospace Vehicles
- 26 Software for Real-Time Simulation of Subsystems
- 28 Graphical Displays Assist in Analysis of Failures
- 30 Program Aids Visualization of Data
- 32 Software Aids in Graphical Depiction of Flow Data

33 Electronic Components and Circuits



- 33 Tilting a Small Reflector for Vernier Pointing of a Large Antenna
- 33 Improved Controllers for Heaters in Toxic-Gas Combustors
- 34 Method To Display Data on a Face Mask
- 34 Improved Dichroics for Microwave Reflector Antenna Systems
- 38 Making Curved Frequency-Selective Microwave Reflectors

40 Electronic Systems



- 40 Prototype Focal-Plane-Array Optoelectronic Image Processor
- 42 Satellites Would Transmit Power by Laser Beams
- 45 Hardware and Software for Development of Robot Arms

46 Physical Sciences



- 46 Thermoelectric Control of Temperatures of Pressure Sensors
- 48 Stabilizing Optical Path Length on a Vibrating Structure

50 Materials




- 50 Replacements for Ozone-Depleting Foaming Agents
- 50 N-Butane To Replace Trichlorofluoroethane
- 52 Hydrophobic, Porous Battery Boxes
- 52 Temporally and Thermally Stable Iron/Nickel Alloy

54 Computer Programs



- 54 Genetic-Algorithm Tool for Search and Optimization
- 54 System-Availability and Resource-Allocation Program
- 56 Estimating Noise Levels in an Enclosed Space
- 56 Computing Tolerance Factors and Noncentral t Distribution


(continued on page 10)



To increase the life of linear-motion suspension for a cryogenic instrument, the bearings are located outside the cooling chamber. A mechanism suspends an optical component in the cryogenic chamber so the component can move smoothly along one axis. The optical component and most of the mechanism are inside the cooled chamber; the optical component moves along four rollers, which are mounted on shafts that extend to the outside of the cooled chamber. See the brief on page 58.

Photo courtesy of Jet Propulsion Laboratory

At 200 MB Per Minute, We're Setting The Pace.



TRUE COMPATIBILITY WITH

Alliant	Macintosh
Alpha Micro	McDonnell Douglas
Altos	Motorola
Apollo	NCR
Arix	NeXT
AT&T	Novell
Basic-4	OS/2
Concurrent	PS/2
Convergent	Parallel Port
Data General	PC 386/ix
DEC SCSI	PC MS-DOS
DEC BI-Bus	PC Xenix/Unix
DEC DSSI	Pertec
DEC HSC	PICK
DEC Q-Bus	Plexus
DEC TU/TA81	Prime
DEC Unibus	Pyramid
Gould/Encore	Sequent
HP	Silicon Graphics
IBM AS/400	STC
IBM Mainframe	Stratus
IBM RISC/6000	Sun
IBM RT	Texas Instruments
IBM S/38	Unisys
ICL	Ultimate
Intergraph	Wang
	— and more

The CY-ASP is the fastest digital data storage solution on the market, able to store up to 70 GB at speeds of up to 200 MB per minute, unattended.

But there's more.

The fastest subsystem is also the most flexible, giving you a choice of four recording modes plus offline copy and verify functions.

In **Single Mode** the drives operate independently.

In **Cascade Mode** data automatically writes to the next tape once the previous tape is full.

In **Mirroring Mode** the same data writes to multiple tapes simultaneously.

In **Striping Mode** data writes to two or more tapes at once, maximizing throughput.

Consider it a data storage management tool, a solution that will help you solve the problems you encounter every day: the need for higher capacity and speed, the need to make duplicate tapes for off-site storage and data exchange, the need for real-time status information, and the need to save resources and boost productivity on every level.

Of course, we also know that a storage solution is only as good as the data you get back. With a bit error rate of less than 1 in 10^{17} bits read, the CY-ASP gives you the *highest* data integrity.

Based on proven 8mm helical scan technology, each drive supports our switch-selectable *data compression* option. And each drive features a 2-line, 40-column backlit display that gives complete status information.

Backed by a two year warranty that includes expert service and support from our in-house engineering group, the CY-ASP is setting the pace in performance, flexibility and value.

Other configurations are available, ranging from a 2.5 GB subsystem to an intelligent, automated 3 TB tape library. And they're all compatible with the widest range of computer systems and networks.

When you're ready for a data storage solution that means business, call for complete information.

(804) 833-9000

CYBERNETICS

Tera One • Yorktown, Virginia 23693 • Fax (804) 833-9300

For More Information Write In No. 504

You have this idea.

Could be great, could be a dead end. You're not sure yet because you can't *see* it.

So you knock out a 3-D model on your Power Macintosh.™ Render it. Rotate it. Shade it.

Run your model through a simulation. *Ouch.*



For more information by fax, call 800-503-3855; by mail, 800-732-3131, ext. 240. Or visit us on the Internet at <http://www.apple.com>.


revert to saved.

Modify your model. Run another simulation. *Push* it.

That's when you discover that it's only taken 30 minutes to figure out

that it isn't a dead end after all.

And it occurs to you:



It's how powerful the
computer makes *you*.

It's not how powerful
the computer is.

604 PowerPC[®]
RISC processor,
132 MHz, 6 PCI slots, up
to 768MB of DRAM with 12
sockets, 3 drive bays, 2GB
hard disk, processor
upgradable.

Introducing the Power Macintosh 9500.

The power to be your best.® 

Contents *(continued)*

58 Mechanics



- 58 Long-Lived Linear-Motion Suspension for Cryogenic Instrument
- 58 Fatigue-Arrestor Bolts

62 Machinery



- 62 Auxiliary Control Mechanisms for RUM Actuators
- 63 Universal Controller for Supersonic Engine Inlet
- 64 Special-Purpose Robotic Welder

67 Manufacturing/Fabrication



- 67 Probes Measure Slots
- 67 Composite Cured Modular Eggcrate-Core Sandwich Structure
- 68 Cutting Tool for Shaving Weld Beads

70 Mathematics and Information



- ### Sciences
- 70 Improved Adjoint-Operator Learning for a Neural Network
 - 72 Synthesis of Realistic Animations of a Person Speaking

74 Life Sciences



- 74 Compact, Automated, Frequency-Agile Microspectrofluorimeter
- 78 Modified, Packaged Tortillas Have Long Shelf Life

79 Books and Reports

- 79 Experiment To Test Raster Scanning With RUM Actuator
- 79 Shape-Memory-Alloy Actuator for Flight Controls
- 79 Back-to-Back Barrier Varactor Frequency Multipliers
- 79 Uncertainty in Measuring Loads on Launch-Pad Supports
- 79 Mass-Additive Vibration Testing of Constrained Structures

DEPARTMENTS

NASA Commercial Technology Team	14
NASA Patents.....	16
New Product Ideas	18
New on the Market.....	102
New on Disk	104
New Literature	105
Advertisers Index.....	107

- 80 Studies of Residual Flexibility and Vibration Testing
- 80 Depositing Adherent Ag Films on Ti Films on Alumina
- 80 Electrically Conductive White Thermal-Control Paint
- 80 Technology of Controlled-Environment Agriculture
- 80 Apparatus for Making Glass Fibers Without the Aid of Gravity
- 80 Welding Using Chilled-Inert-Gas Purging
- 94 Numerical Stability in Hyperbolic Boundary-Value Problems
- 94 Finite-Element Modeling for Structural Analysis
- 94 Constraint-Based Scheduling System
- 94 Calibration of Partial-Pressure-of-Oxygen Sensors
- 94 More About Measuring Interfacial Tension Between Liquids

1A-21A Laser Tech Briefs

Follows page 64 in selected editions only.

On the cover:

Various NASA facilities are using an interactive CFD post processing package called Fieldview from Intelligent Light (Lyndhurst, NJ) that enables scientists to study complex, 3D fluid dynamics datasets. Depicted is the pressure rise along the shroud of a 30-degree backswept impeller with 24 blades, rotating at 22,363 rpm, that was analyzed with Fieldview. The data was provided by Northern Research Engineering Corp. (Woburn, MA).

Photo courtesy of Intelligent Light

This document was prepared under the sponsorship of the National Aeronautics and Space Administration. Neither Associated Business Publications Co., Ltd. nor the United States Government nor any person acting on behalf of the United States Government assumes any liability resulting from the use of the information contained in this document, or warrants that such use will be free from privately owned rights. The U.S. Government does not endorse any commercial product, process, or activity identified in this publication.

Permissions: Authorization to photocopy items for internal or personal use, or the internal or personal use of specific clients, is granted by Associated Business Publications, provided that the flat fee of \$3.00 per copy be paid directly to the Copyright Clearance Center (21 Congress St., Salem, MA 01970). For those organizations that have been granted a photocopy license by CCC, a separate system of payment has been arranged. The fee code for users of the Transactional Reporting Service is: ISSN 0145-319X/94 \$3.00+.00

NASA Tech Briefs, ISSN 0145-319X, USPS 750-070, copyright © 1995 in U.S. is published monthly by Associated Business Publications Co., Ltd., 41 E. 42nd St., New York, NY 10017-5391. The copyright information does not include the (U.S. rights to) individual tech briefs that are supplied by NASA. Editorial, sales, production, and circulation offices at 41 East 42nd Street, New York, NY 10017-5391. Subscription for non-qualified subscribers in the U.S., Panama Canal Zone, and Puerto Rico, \$75.00 for 1 year; \$125 for 2 years; \$200.00 for 3 years. Single copies \$10.00. Foreign subscriptions one-year U.S. Funds \$150.00. Remit by check, draft, postal, express orders or VISA, MasterCard, and American Express. Other remittances at sender's risk. Address all communications for subscriptions or circulation to NASA Tech Briefs, 317 Madison Ave., New York, NY 10017-5391. Second-class postage paid at New York, NY and additional mailing offices.

POSTMASTER: Please send address changes to NASA Tech Briefs, P.O. Box 10523, Riverton, NJ 08076-0523

The World of Houdini

A video training kit for Algor® Houdini™.

Learn how to use Houdini to automatically produce an 8-node "brick" finite element model from a CAD solid model for analysis by any FEA software.

Valuable techniques for Houdini users at any level:

Beginner:

Learn the steps Houdini uses to automatically turn a CAD solid model into a high-quality, solid, 8-node "brick" finite element model.

Intermediate:

Learn through a step-by-step demonstration about Houdini's global controls for optimizing the solid mesh.

Advanced:

Learn to use Houdini's advanced mesh manipulation capabilities which help engineers deal with complex finite element modeling and analysis challenges.

The World of Houdini adds value even if you have attended Algor's 2-day Houdini classroom seminar.

Kit Contents:

- 1) *The World of Houdini* training video.
- 2) The complete training notes from Algor's 2-day Houdini classroom seminar, both printed and in Microsoft PowerPoint file format.
- 3) A CD-ROM with the models used in the video for PCs and UNIX workstations.
- 4) Viewpak™ software to examine the models in detail on your computer screen.

Optional:

Files with the finite element models formatted for specified FEA packages may be purchased separately.

Order by Phone: North America: **1-800-48ALGOR** (1-800-482-5467)
Europe: +44 (784) 442 246 • Tokyo: +81 03-3589-6148 • Others: +1 (412) 967-2700
Order by Fax: +1 (412) 967-2781

Houdini Supports CAD Solid Modelers:
Pro/ENGINEER • EDS/Unigraphics • CATIA
• AutoCAD • Cadkey • Intergraph • SDRS • More

Houdini Supports FEA Software:
Abaqus • Algor • Ansys • Cosmos • Nastran
• NISA • Patran • Procast • More

Ship to: (No P.O. boxes please)

Name _____
Company _____
Address _____
City _____ State _____ Zip _____
Country _____
Phone () _____ Dept. NTB895
Fax () _____

You Have Four Ways To Pay:

☐ Charge to Credit Card No.: Date Card Expires _____

☐ American Express ☐ MasterCard ☐ VISA ☐ Diner's Club ☐ Discover

Card Holder's Name _____

Authorized Signature _____ Date _____

☐ Wire transfer ABA Routing Code: 043000261
Account No.: 010-5064 Mellon Bank, Pittsburgh, PA USA

☐ Check enclosed (payable to: Algor, Inc.)

☐ Purchase Order (subject to credit approval.)

P. O. Number: _____

* We will send the VHS format used in your country. Please call for exception. Offer valid while supply lasts. © Copyright 1995 Algor, Inc. TM Trademark of Algor, Inc.

All prices are in US Dollars		QTY	Price	Total
Video Training Kit(s)*			\$495.00	
Optional file(s) on CD-ROM with models formatted for FEA package(s) shown: (Must be ordered at the same time as the Video Training Kit.)	Nastran		\$50.00	
	Ansys		\$50.00	
	Cosmos		\$50.00	
	Patran		\$50.00	
	Abaqus		\$50.00	
	I-DEAS		\$50.00	

Shipping & Handling: (insert cost from schedule below)

Order Subtotal:

Sales Tax: (shipments to PA add 7%; CT add 6%)

Order Total:


Shipping & Handling Cost Schedule (US Dollars)					
Video QTY	USA Regular	USA Next-day Air	Canada Regular	Canada (Air)	All other Countries (Air)
1-2	\$6.00	\$25.00	\$18.00	\$25.00	\$35.00
3+	please call for quotation				

ALGOR

Algor, Inc.
150 Beta Drive
Pittsburgh, PA 15238 USA

CONVERT COMPUTER GRAPHICS TO VIDEO

RECORDING, TRANSMISSION,
PROJECTION AND
TELECONFERENCING



RGB/Videolink®

VIDEO SCAN CONVERTERS

- Autosync
- Simple external connections
- Flicker filter
- Optional graphics/video overlay
- Up to 1280 x 1024 pixel input
- Models from \$7,995.00
- Pan & zoom



SPECTRUM®

950 Marina Village Parkway Alameda, CA 94501
Tel: (510) 814-7000 Fax: (510) 814-7026

NASA Tech Briefs

Official Publication of the
National Aeronautics and
Space Administration



Published by **Associated Business Publications**
President/Chief Executive Officer **Bill Schnirring**
Publisher **Joseph T. Pramberger**
Senior Editor **Linda L. Bell**
Senior Editor **Lantz Miller**
Editor, Federal Lab Tech Briefs **Robert Clark**
Production Manager **Donna Pituras**
Advertising Coordinator **Margery Koen**
Art Director **Lois Erlacher**
Production Artist **Brian Edgar**
Circulation Director **Martin J. Horan**
Assistant Circulation Director **Lori Coppin**
Marketing Director **Wayne Pierce**
Telemarketing Specialist **Evelyn Mars**
Assistant to Reader Service Manager **Damiana Garcia**

BRIEFS & SUPPORTING LITERATURE: Written and produced for NASA by
Advanced Testing Technologies, Inc., Commack, NY 11725

Technical/Managing Editor **Ted Selinsky**
Sr. Technical Analyst **Dr. Larry Grunberger**
Art Manager **Eric Starstrom**
Administrator/Chief Copy Editor **Greg Galitzine**
Staff Writers/Editors **Dr. Theron Cole, George Watson,**
Howard Falk, Gail Pyke
Graphics **Robert Simons**
Editorial & Production **Joan Schmiemann, Caroline Weaver**
Becky D. Bentley

NASA:

NASA Tech Briefs are provided by the National Aeronautics and Space
Administration, Technology Transfer Division, Washington, DC:
Administrator **Daniel S. Goldin**
Director, Commercial Technology **Robert Norwood**
Manager, Technology Transfer Office, NASA Center
For AeroSpace Information **Walter M. Heiland**

ASSOCIATED BUSINESS PUBLICATIONS

41 East 42nd Street, Suite 921, New York, NY 10017-5391
(212) 490-3999 FAX (212) 986-7864

President/Chief Executive Officer **Bill Schnirring**
Executive Vice President/Chief Operating Officer **Domenic A. Mucchetti**
Treasurer **Joseph T. Pramberger**
Credit/Collection **Felecia Lahey**
Staff Accountant **Larry Duze**
Trade Show Director **Wendy S. Janiel**
Trade Show Manager **Tricia Palumbo**
Exhibition Sales **Wayne Pierce**
Trade Show Coordinator **Tracy A. Wenz**
Human Resources Manager **Lourdes Del Valle**
MIS Manager **Ted Morawski**
Assistant MIS Manager **Pak Tong**
MIS Data Entry **Roxanne Portella**
Office Manager **Sylvia Valentin**
Mailroom Operations **Thomas C. Snyder, Rose D'Addozio**
Administrative Assistant **Christine Saluzzi**

NASA TECH BRIEFS ACCOUNT EXECUTIVES

NY, NJ (Area Code 201) **Doug Shaller**
at (212) 490-3999
PA, DE, NJ (Area Code 908, 609), VA, DC, MD, WV **Tara Morie**
at (610) 640-3118
Eastern MA, NH, ME, RI **Paul Gillespie** at (508) 429-8907
Bill Doucette at (508) 429-9861
Western MA, CT, VT **George Watts**
at (802) 875-3310
Southeast, South Central **Robert Hubbard**
at (910) 299-7754
OH, MI, IN, KY **Louise Clemens**
at (216) 479-6868
IL, WI, MO, IA, MN, ND, SD, NE, KS **Melinda Mead**
at (312) 296-2040
N. Calif., ID, MT, WY, CO **Bill Hague**
at (206) 858-7575
WA, OR **Bill Madden**
at (206) 858-7575
S. Calif., (Area Codes 909, 818, 805, 213, 310), NV, UT **Tom Stillman**
at (310) 372-2744
S. Calif., (Area Codes 619, 714), AZ, NM **Richard Ayer; Jane Hayward**
at (714) 366-9089
Japan **Akio Saijo**
at 03 (5691) 3335

How To Reach Us On Line

Letters to the editor: ntb_edit@interramp.com
To find out about advertising opportunities: ntb_advertise@interramp.com
For information on the Technology 2005 conference (October 24-26, Chicago):
T2005@interramp.com
For information on Internet Tech Connection workshops: techcon@interramp.com

World's Fastest A/D Cards For IBM PC



**LabVIEW &
LabWindows CVI
Compatible !!**

- ✓ Up to 60 MSPS, 12 bit Real Time A/D
- ✓ Up to 250 MSPS, 8 bit Real Time A/D
- ✓ Memory depth up to 16 Megasamples
- ✓ Up to 32 inputs in one chassis
- ✓ Drivers in C, BASIC, Windows DLL
- ✓ FREE GageScope software

CALL 1-800-567-GAGE

Ask for extension 3406

CSLITE	8 bit / 40 MSPS / 16K	\$595
CS225	8 bit / 50 MSPS / 128K	\$1,995
CS250	8 bit / 100 MSPS / 32K	\$3,500
CS2125	8 bit / 250 MSPS / 256K	\$4,995
CS1012	12 bit / 20 MSPS / 512K	\$4,995
CS6012	12 bit / 60 MSPS / 512K	\$6,995

U.S. Prices listed above. International prices may vary

GaGe

GAGE APPLIED SCIENCES INC.

5610 Bois Franc Street

MONTREAL QC, CANADA H4S 1A9

Tel : (514) 337-6893. Fax : (514) 337-8411

BBS : (514) 337-4317. CompuServe : 73042,346

NASA's R&D efforts produce a robust supply of promising technologies with applications in many industries. A key mechanism in identifying commercial applications for this technology is NASA's national network of commercial technology organizations. The network includes ten NASA field centers, six Regional Technology Transfer Centers (RTTCs), the National Technology Transfer Center (NTTC), business support organizations, and a full tie-in with the Federal Laboratory Consortium (FLC). We encourage all businesses with technical needs to contact the appropriate organizations for more information. For those who have access to the Internet, general information can be accessed with Mosaic software on the NASA Commercial Technology Home Page at URL: <http://nctn.oact.hq.nasa.gov>. Instructions regarding how to acquire the free Mosaic software can be obtained by sending an e-mail request to: innovation@oact.hq.nasa.gov.

NASA's Technology Sources

If you need further information about new technologies presented in *NASA Tech Briefs*, request the Technical Support Package (TSP) indicated at the end of the brief. If a TSP is not available, the Commercial Technology Office at the NASA field center that sponsored the research can provide you with additional information and, if applicable, refer you to the innovator(s). These centers are the source of all NASA-developed technology.

Ames Research Center
Selected technological strengths:
Fluid Dynamics;
Life Sciences;
Earth and Atmospheric Sciences;
Information, Communications, and Intelligent Systems;
Human Factors.
Syed Shariq
(415) 604-0753
syed_shariq@qmgate.arc.nasa.gov

Goddard Space Flight Center
Selected technological strengths:
Earth and Planetary Science Missions; LIDAR; Cryogenic Systems; Tracking; Telemetry; Command.
George Alcorn
(301) 286-5810
galcorn@gscf-mail.nasa.gov

Jet Propulsion Laboratory
Selected technological strengths:
Near/Deep-Space Mission Engineering; Microspacecraft; Space Communications; Information Systems; Remote Sensing; Robotics.
William Spuck
(818) 354-2240
william_h_spuck@jpl.nasa.gov

Johnson Space Center
Selected technological strengths:
Artificial Intelligence and Human Computer Interface; Life Sciences; Human Space Flight Operations; Avionics; Sensors; Communications.
Hank Davis
(713) 483-0474
hdavis@jp101.jsc.nasa.gov

Kennedy Space Center
Selected technological strengths:
Emissions and Contamination Monitoring; Sensors; Corrosion Protection; Bio-Sciences.
Bill Sheehan
(407) 867-2544
billsheehan@ksc.nasa.gov

Langley Research Center
Selected technological strengths:
Aerodynamics; Flight Systems; Materials; Structures; Sensors; Measurements; Information Sciences.
Charlie Blankenship
(804) 864-6005
c.p.blankenship@larc.nasa.gov

Lewis Research Center
Selected technological strengths:
Aeropropulsion; Communications; Energy Technology; High Temperature Materials Research.
Walter Kim
(216) 433-3742
wskim@llms01.lerc.nasa.gov

Marshall Space Flight Center
Selected technological strengths:
Materials; Manufacturing; Nondestructive Evaluation; Biotechnology; Space Propulsion; Controls and Dynamics; Structures; Microgravity Processing.
Harry Craft
(800) USA-NASA
susan.van.ark@msfc.nasa.gov

Stennis Space Center
Selected technological strengths:
Propulsion Systems; Test/Monitoring; Remote Sensing; Nonintrusive Instrumentation.
Lon Miller
(601) 688-1632
lmiller@ssc.nasa.gov

NASA Program Offices

At NASA Headquarters there are seven major program offices that develop and oversee technology projects of potential interest to industry. The street address for these strategic business units is: NASA Headquarters, 300 E St. SW, Washington, DC 20546.

Gene Pawlik
Small Business Innovation Research Program (SBIR)
(202) 358-4661
gpawlik@oact.hq.nasa.gov

Bill Smith
Office of Space Sciences (Code S)
(202) 358-2473
wsmith@sm.ms.ossa.hq.nasa.gov

Robert Norwood
Office of Space Access and Technology (Code X)
(202) 358-2320
mnorwood@oact.hq.nasa.gov

Bert Hansen
Office of Microgravity Science Applications (Code U)
(202) 358-1958
bhansen@gm.olmsa.hq.nasa.gov

Philip Hodge
Office of Space Flight (Code M)
(202) 358-1417
phodge@osfms1.hq.nasa.gov

Gerald Johnson
Office of Aeronautics (Code R)
(202) 358-4711
g_johnson@aeromail.hq.nasa.gov

Granville Paules
Office of Mission to Planet Earth (Code Y)
(202) 358-0706
gpaules@mtpe.hq.nasa.gov

NASA's Business Facilitators

NASA has established several organizations whose objectives are to establish joint sponsored research agreements and incubate small start-up companies with significant business promise.

Dr. Stephen Gomes
American Technology Initiative
Menlo Park, CA
(415) 325-5353

John Gee
Ames Technology Commercialization Center
Sunnyvale, CA
(408) 734-4700

Jill Fabricant
Johnson Technology Commercialization Center
Houston, TX
(713) 335-1200

Dan Morrison
Mississippi Enterprise for Technology
Stennis Space Center, MS
(800) 746-4699

NASA-Sponsored Commercial Technology Organizations

These organizations were established to provide rapid access to NASA and other federal R&D and foster collaboration between public and private sector organizations. They also can direct you to the appropriate point of contact within the Federal Laboratory Consortium.

Lee Rivers
National Technology Transfer Center
(800) 678-6882

Dr. William Gasko
Center for Technology Commercialization
(800) 472-6785 or
(508) 870-0042

Gary Sera
Mid-Continent Technology Transfer Center
Texas A&M University
(800) 472-6785 or
(409) 845-8762

Chris Coburn
Great Lakes Industrial Technology Center
Battelle Memorial Institute
(800) 472-6785 or
(216) 734-0094

Robert Stark
Far-West Technology Transfer Center
University of Southern California
(800) 472-6785 or
(213) 743-6132

J. Ronald Thornton
Southern Technology Applications Center
University of Florida
(800) 472-6785 or
(904) 462-3913

Lani S. Hummel
Mid-Atlantic Technology Applications Center
University of Pittsburgh
(800) 472-6785 or
(412) 648-7000

Easy Access To The FLC: Call (206) 683-1005 for the name of the Federal Laboratory Consortium Regional Coordinator in your area. The Regional Coordinator, working with the FLC Locator, can help you locate a specific laboratory to respond to your needs.

If you are interested in information, applications, and services relating to satellite and aerial data for Earth resources, contact: Dr. Stan Morain, **Earth Analysis Center**, (505) 277-3622. For software developed with NASA funding, contact **NASA's Computer Software Management and Information Center (COSMIC)** at (706) 542-3265, fax (706) 542-4807. If you have a questions...**NASA's Center for Aerospace Information** can answer questions about NASA's Commercial Technology Network and its services and documents. Use the Feedback Card in this issue or call (410) 859-5300, ext. 245.



Remove bottlenecks with our PCI Frame Grabber.

The Mach Series DT3155 is the only **real-time** PCI frame grabber that takes full advantage of PCI for **under \$1000**. For scientific and industrial

applications, there's no better way to upgrade your imaging system to the PCI bus. With real-time transfer to system memory and real-

time display via your own VGA card, the DT3155 can transfer an unlimited number of consecutive frames through your system at breakneck speeds. Plus, Data Translation's proprietary circuitry ensures your data is accurate and consistent. So before you restrict data throughput with a vintage imaging board, call us today at 1-800-525-8528.

TELEPHONE:
1-800-525-8528
FAX:
(508) 481-8620
INTERNET:
574-7126@mcimail.com

DATA TRANSLATION®

World Headquarters (508) 481-3700, UK Headquarters: 1734793838, Germany Headquarters: 714295310, Italy Headquarters: 302425696.
 Sales Offices: Argentina 13223791; Australia 29795643, 33507377; Austria 13697660; Belgium 25695647; Brazil 115646024, (312) 915-3135; Canada (416) 625-1907; China 18331145; Denmark 48141488; Finland 03511800;
 France 169077802; Greece 13614300; Hong Kong 25150018; India 22231040; Israel 9545685, 9407352; Japan 354893871; Korea 27189521; Malaysia 32486786, 32616786; Mexico 55756091, 55756098;
 The Netherlands 104795700; New Zealand 94158362; Norway 22434150; Portugal 17934834, 17934934; Singapore 7734300; South Africa 128037680; Spain 15558112; Sweden 87650280; Switzerland 19081313;
 Taiwan 623039836; Thailand 22819596; Turkey 2122886312, 2122886215, 2122749097 04/21/95

For More Information Write In No. 530

"The laboratory contacts given to us by the NTTC's technology access agent helped to create a new product that should double our sales. . . saved us \$100,000 in research costs and cut time-to-market by almost a year."

—Paul Fischione

E. A. Fischione Instruments, Inc.

Access to the world of federally funded research and expertise is now available to you. . . for **Free**.

Whether your need is for your own research efforts, a manufacturing process or a new technology, the National Technology Transfer Center's technology access agents will help you.

You will receive:

- Personalized service by an experienced staff
- Prompt turnaround of your request
- The best contacts in the federal research network, giving you the expertise, facilities or technology you need

Call
800-678-6882
today!



National Technology Transfer Center
Wheeling Jesuit College
316 Washington Avenue
Wheeling, WV 26003
Fax: 304-243-2539

For More Information Write In No. 401

PATENTS

NASA

Over the past three decades, NASA has granted more than 1000 patent licenses in virtually every area of technology. The agency has a portfolio of 3000 patents and pending applications available now for license by businesses and individuals, including these recently patented inventions:

Water-Driven Turbine/Brush Pipe Cleaner

(U.S. Patent No. 5,406,666)

Inventor: Rudy J. Werlink, Kennedy Space Center

To clean contaminant buildup in pipe walls, common methods have involved environmentally damaging freon solvents, which will soon be phased out by law, or a circular brush driven by a longitudinal shaft connected to a motor, limited by 90-degree turns in the pipe and by tube width. Mr. Werlink designed a brush-turbine assembly that employs the pipe's regular fluid flow to drive the apparatus through the pipe, disposes of the need for freon, and negotiates 90-degree bends.

For More Information Write In No. 744

Leak Detection Utilizing Analog Binaural (VLSI) Technique

(U.S. Patent No. 5,417,113)

Inventor: Frank T. Hartley, Jet Propulsion Laboratory

Using acoustic methods to detect leaks in pipes, or any structure supporting standing-wave propagation, runs into problems when there are overwhelming levels of background noise. To overcome such noise, Mr. Hartley's detection device employs a very large scale integration (VLSI) circuit constituting the traveling-wave structure of the human cochlea to derive spatial and spectral information in a 2-D plane, and calculates several representations of these planes to render a 3-D stereausis representation.

For More Information Write In No. 741

Particle Fallout/Activity Sensor

(U.S. Patent No. 5,412,221)

Inventors: Ihlefield M. Curtis, Robert C. Youngquist, John S. Moerk, and Kenneth A. Rose, Kennedy Space Center

In measuring particle fallout, such as dust and fibers, in a particle-sensitive area, knowing the timing of the accumulation and how much was accumulated in an interval can help pinpoint when potentially destructive events occur. Current methods such as witness plates for collecting material for laboratory examination restrict fallout measurements to an accumulation account over an extended time. The present invention digitizes accumulation data from an optical particle sensing system and sends it to a data-acquisition module with a timekeeper to keep track of the timing of different levels of accumulation.

For More Information Write In No. 743



Method for Determining Surface Coverage by Materials Exhibiting Different Fluorescent Properties

(U.S. Patent No. 5,412,219)

Inventor: Emmett W. Chappelle, Craig S.T. Daughtry, and James E. McMurtrey, III, Goddard Space Flight Center

Maintaining as little as 30% of a crop's residue—the dead part of a crop left in the field after harvest—can reduce soil erosion by about 90%. The present invention allows a quick, accurate, and objective way to measure the crop residue by irradiating the surface with ultraviolet radiation, detecting the fluorescent emission, characterizing the emission's spectral content, and calculating the surface covered by living plants, dead vegetation, and soil. This method has advantages over previous photographic and intercept techniques, which are slow and to some degree subjective.

For More Information Write In No. 742

Crystalline Imide/Arylene Ether Copolymers

(U.S. Patent No. 5,418,300)

Inventors: Brian J. Jensen, Paul. M. Hergenrother, and Robert G. Bass, Langley Research Center

Pol(arylene ethers) have good mechanical properties, thermo-oxidative stability, relative ease of processing, and solubility in common solvents; wholly aromatic polyimides have exceptional thermal, thermooxidative, and chemical resistance; and crystallinity in a polymer improves solvent-resistance, increases the modulus, and may increase toughness. The new crystalline imide/arylene ether copolymers developed at Langley combine many of these properties. At 25° C, solution cast films of the block copolymers had tensile strength up to 16,200 psi, tensile moduli up to 535,000 psi, and elongation at break up to 8%.

For More Information Write In No. 745


Forback DC-to-DC Converter

(U.S. Patent No. 5,418,709)

Inventor: Alan T. Lukemire, Goddard Space Flight Center

DC-to-DC power converters use a switching device and a combination of inductors and capacitors to derive power from one source of DC voltage and deliver it to a load at the same or different DC voltage. Mr. Lukemire made a relatively simple DC-to-DC converter topology through the particular location of the current-sensing transformer and the use of equal-valued first and second inductors. This pulse-width modulated converter has current mode control and provides both volt-second balance of the power transformer and ampere-second balance of the current-sensing transformer simultaneously.


For More Information Write In No. 746



MATLAB simplifies analysis and algorithm development with integrated modeling, design, and visualization tools. This spectrogram shows how a speech signal varies with time and frequency.

Speak the language of signal processing with MATLAB®.

The MATLAB Signal Processing Toolbox is a powerful, interactive environment for signal analysis, algorithm development, and DSP design.



Leading-edge filter design tools make it easy to design filters to fit any specification.

Because its matrix language is ideal for vector processing and data analysis, MATLAB helps you solve the widest range of signal processing problems.

Signal processing power

The Signal Processing Toolbox gives you an unrivaled ability to filter, model, and analyze signals and time-series data. Powerful functions let you perform FFTs, spectral estimation, and filter design in a single step, then display the results automatically.


Without writing a single line of C or Fortran, you can easily explore, create, and apply the innovative signal processing tools that let you keep up with—and advance—the leading edge.

Rapid algorithm development

You create DSP algorithms in MATLAB just as you would write them mathematically. As a result, you can rapidly validate your designs long before you commit to a full implementation.

Your work always draws upon world-class tools, whether you rely on classical methods or invent state-of-the-art technology.

MATLAB brings a foundation of over 500 math, scientific, and engineering functions to your desktop. Each function is tuned for maximum efficiency and numeric reliability. So you always get immediate, accurate results.



Visualization of a 2-D FFT. Efficient FFT algorithms form the basis for powerful spectral analysis and estimation functions.

Expand your DSP vocabulary

With the high-level MATLAB language, it's easy to modify the source code for any toolbox function, or add your own. Or combine signal processing with other toolboxes to design custom solutions to complex problems.

Powerful GUI tools let you build intuitive applications that look like pre-packaged software, but address your specific design and analysis needs.

MATLAB

Picture the Power

Signal Processing Toolbox

- Complete tools for filter design, analysis, and implementation
- FFT, DCT, cepstrum, chirp-z, Hilbert, and other transforms
- Spectrum estimation and statistical signal processing
- Signal and linear system models
- Specialized design tools for embedded real-time, multi-rate, and communications systems
- Integrated with application toolboxes for:
 - Image Processing
 - System Identification
 - Higher-Order Spectral Analysis
 - Neural Networks
 - Optimization

The Ultimate Technical Computing Environment™

MATLAB is an extensible, interactive Technical Computing Environment that seamlessly integrates computation, visualization, and modeling on PCs, workstations, and supercomputers. You'll find it wherever people speak the language of signal processing.

For a free technical brief that will show you the signal processing power of MATLAB, call us today.

508-653-1415

The
**MATH
WORKS**
Inc.

24 Prime Park Way / Natick, MA 01760
Tel: 508/653-1415 Fax: 508/653-6284
E-mail: info@mathworks.com
Web: <http://www.mathworks.com>

The MathWorks is represented in the following countries:
Australia: +61-2-922-6311 • Brazil: +55-11-816-3144
France: +33-1-45-34-23-91 • Germany: +49-241-26041
India: +91-80-2-260-260 • Israel: +972-3-561-5151
Italy: +39-11-24-85-332 • Japan: +81-3-5978-5410
Korea: +82-2-517-1257 • Portugal: +34-3-415-49-04
Scandinavia: +46-8-15-30-22 • Spain: +34-3-415-49-04
Switzerland: +41-31-998-44-11 • Taiwan: +886-2-501-8787
For Belgium, Luxembourg, The Netherlands, United Kingdom and Republic of Ireland call Cambridge Control, Ltd: +44-1223-423-200
or Rapid Data, Ltd: +44-1903-821-266

MATLAB is a registered trademark of The MathWorks, Inc.



New Product Ideas

New Product Ideas are just a few of the many innovations described in this issue of *NASA Tech Briefs* and having promising commercial applications. Each is discussed further on the referenced page

in the appropriate section in this issue. If you are interested in developing a product from these or other NASA innovations, you can receive further technical information by requesting

the TSP referenced at the end of the full-length article or by writing the Commercial Technology Office of the sponsoring NASA center (see page 14).

Improved Controllers for Heaters in Toxic-Gas Combustors

Electronic proportional controllers maintain electric heaters in toxic-gas combustors at precise preset temperatures. This measure eliminates excess power consumption and stressful on/off cycling that were encountered with previous mechanical controllers (See page 33.)

Replacements for Ozone-Depleting Foaming Agents

Two fluorinated ethers are being investigated as potential replacements of blowing agents that are currently used in the manufacture of polyurethane foam. These ethers do not have ozone depletion potential and can be used in existing foam-producing equipment. (See page 50.)

Hardware and Software for Development of Robot Arms

A system of modular, reusable hardware and software has been assembled for use in developing remotely controlled robotic arms. The system consists mostly of commercial products. (See page 45.)

Universal Controller for Supersonic Engine Inlet

Engine-demand airflow would be used as the primary control parameter in an advanced supersonic airplane. Advantages include design and installation of upgraded engines requiring practically no changes in the hardware and software of air-inlet controllers, fewer air-inlet controllers, and enhanced supportability and maintainability of the aircraft. (See page 63.)

Hydrophobic, Porous Battery Boxes

These boxes safely contain corrosive, toxic electrolytes and allow gases to flow in and out. Developed for zinc-air batteries, the boxes use hydrophobic polymers, which can be readily adapted for other types of batteries requiring venting without electrolyte leakage. (See page 52.)

Special-Purpose Robotic Welder

This robotic welder uses copper bars to cool the area around the pool of molten metal. Designed for repairing combustion chambers of rocket engines, the welder can be adapted to repair pressure vessels and chemical-processing vessels. (See page 64.)



Get to know the new IRIS Explorer

The latest version of the complete object-oriented visualization package for scientists and engineers displaying and analyzing complex data

The Numerical Algorithms Group proudly announces IRIS Explorer™ release 3.

Designed for top-quality performance in distributed processing environments or on individual workstations, this comprehensive package is the visualization software choice of scientists, engineers and other business professionals worldwide.

NEW features!

- 64-bit support for R8000 machines
- system enhancements, including an improved scripts interface; a new visual "drag & drop" interface; new widgets for module control panels; editable groups
- new modules for vector data, geometry, annotation, data analysis; "NAG" modules based on the NAG Graphics Library and NAG numerical libraries
- completely revised, updated documentation

Varied applications!

IRIS Explorer is a valuable problem-solving tool for:

- computational fluid dynamics
- mechanical, electrical engineering
- aerospace engineering
- geology
- physics
- biochemistry
- medical research
- atmospheric research
- architecture
- financial modeling
- and many more applications!

NEW platforms!

- available now for SGI, SUN SPARC (OS 4.1.x and Solaris 2.x), IBM RS/6000, Cray YMP and HP 9000/700; available soon for DEC Alpha (OSF1)

For more information about the **NEW & IMPROVED IRIS Explorer release 3** and other products for software development and research, contact NAG at the numbers below, or e-mail info-ntb@nag.com.

NAG®

NUMERICAL ALGORITHMS GROUP, INC.

ntbad

1400 Opus Place, Suite 200 • Downers Grove, IL 60515-5702 • 708.971.2337 • fax 708.971.2706

Burt Rutan Makes Vellum Fly



Two years after the Voyager completed its record-shattering around-the-world flight, you could still find its designer, Burt Rutan, working at a drafting table with pencil and paper. Hardware wasn't the problem. He had computers. His company could buy any design system worth owning. What kept Burt grounded was software. CAD so clumsy, it squashed creativity. Or so weak, it simply couldn't do his job. Maybe that's why the first time he sat down to design with Vellum®, Burt compared the experience to the exhilaration of flying. Vellum is the first CAD program with an autopilot.


CAD Software that Works the Way You Think

From GD&T symbols to NURB splines to DXF and IGES file format translators, Vellum has every professional design and drafting tool your job demands. And each tool is endowed with an expert system called the Drafting Assistant™—built-in intelligence that instantly makes every designer more productive. Even on enormously complex jobs. Rather than force you to fight with the keyboard, or guess about alignment as you draw, Vellum pinpoints and spells out every logical design point for you, on screen. Draw a simple line and the midpoints, endpoints, and construction lines appear automatically. Click the mouse and you get precise alignment to 16 decimal places, instantly.

The Power of Parametrics

Before Vellum, using CAD for conceptual design was like trying to draw in the dirt with a backhoe. Vellum makes precise design as natural as free-hand sketching, with the combined power of Parametrics and Associative Dimensioning.

Burt's creativity and willingness to explore uncharted territory is exemplified by this sneak peek at one of his latest designs produced (of course) in Vellum.



Simply draw a rough approximation of your design, dimension it, plug in values and click: geometry is automatically redrawn to scale. A part needs to change? Simple. Just change the dimensions and the geometry updates as you watch. Or change the geometry and all the dimensions update perfectly.

From Concept to Finish in Half the Time

According to Burt, "the only way to fully appreciate Vellum is to sit down and use it; tackle a tough job right off. See if the Drafting Assistant doesn't make you two, or even three times more productive than any other CAD package." If you're like Burt Rutan, you'll find yourself using Vellum from conceptual design right through finished drawings. Best of all, you'll never give the drafting board, or another CAD program, a second thought.

For more information, a free video, a trial version, or the name of an authorized Ashlar® reseller near you call us at:

**800-877-2745 or
408-746-1800**

 **ASHLAR**
Ashlar Incorporated
1290 Oakmead Parkway
Sunnyvale, CA 94086

Mission *A*ccomplished

The television crews captured the drama. A two-ton slab of concrete hung from the roof of the Murrah Federal Office Building by a one-inch piece of reinforced bar, threatening the rescue workers below. A firefighter climbed to the roof, hooked the cutter section of a special instrument around the reinforced bar, pulled back on the actuation handle and depressed the trigger. Instantly, the two-ton slab dropped six stories, allowing rescuers to continue their lifesaving work.

Lifeshear, the instrument behind this 30-second action in Oklahoma City last April, was developed through an Advanced Research Project Agency-funded, multiple-agency-sponsored Technology Reinvestment Project (TRP) award managed by NASA, in conjunction with the manufacturer, Hi-Shear Technology Corp. of Torrance, CA, and the City of Torrance. Although designed to sever automotive brake and clutch pedals and roof posts and pillars for removing an automobile's roof and rescuing accident victims, Lifeshear has found other lifesaving applications. The tool also can cut through water pipe,

electrical conduit, reinforced bar, and other structural components of buildings, and provides life-saving assists in fire-department rescue situations involving occupants trapped in their homes.

NASA teamed with Hi-Shear and the City of Torrance Fire Department to develop an earlier-model extraction tool into a new one for automotive rescues. In Oklahoma City, the new tool drew the attention of Federal Emergency Management Agency officials. After rescue workers in Oklahoma City used it to penetrate building materials and rescue trapped victims, FEMA officials ordered 36 cutters and 6400 power units and trained rescue teams in the tool's use. FEMA has also recommended its use by all Urban Search and Rescue groups across the nation.

What raises this cutter above its predecessor is the power unit, based on NASA-developed pyrotechnics. Called initiators, they look like a shell, or cartridge, and are loaded into the tool like a shell into a gun. The power unit generates hot gases that drive the blade through the target, whereas the earlier extractors employed expensive, gasoline-powered hydraulic pumps and hoses that were heavier and less efficient.

Although NASA is considering using the cutter for emergencies in space, its principal purpose in developing it lay in leveraging the cost of the power unit by means of dual-use: by making the power unit a commercially viable product, NASA and the Department of Defense can bolster their own use of the technology. "These initiators are the same as those used in multi-stage rockets and in explosive bolts," explained Carl Ray, who is a technology programs operations manager and the TRP point of contact at NASA Headquarters. "NASA and the military use these initiators for different spaceborne projects, as in separating the first and second stages on small rockets, which must be explosively separated."

Because of the small number of such rockets, the manufacturer made only a limited amount of the initiators, and so the cost was high. "But now with the advent of these initiators in the commercial market," Ray said, "you've expanded the production and the use of these items—the supply and demand goes up—so the price goes down."

Using only a nine-gram power unit, Lifeshear is compact—only 22 to 26 inches long—and lightweight, making it easily transportable to remote areas. The device takes only 30 seconds to set up. Hi-Shear makes two sizes. The LS200, a 1.5-inch cutter for shearing brake pedals, door hinges, seat sections, and steering wheel rims, weighs 8.5 pounds. LS100, a four-inch cutter for shearing the A, B, and C posts on cars, weighs 11.5 pounds. Lifeshear's portability and light weight, along with the tool's speed of operation, paid off in the treacherous collapsed-structure environment at the Oklahoma City site. The lighter weight also reduces the probability



The LS100 Lifeshear cutter (top) is a four-inch cutter, and the LS200 is a 1.5-inch cutter.

of lower back injuries to rescue workers using extractors.

As an industry leader in pyrotechnical actuated thrusters, explosive bolts, separation nuts, pin pullers, and cutters, Hi-Shear made a strong candidate for the TRP development project. It has supplied these items to nearly all of NASA's major deep space missions over the past 23 years. The company has demonstrated it intends to make a good return on the 1.6 million dollar investment in Lifeshear, half of which was supplied by TRP. By June 1995, Hi-Shear was finishing 100 units per month, with 1000 LS100s and 1000 LS200s in production. The effort supports seven machine shops and has created approximately 40 jobs in the Los Angeles area. Hi-Shear has deployed 60 distributors to market the tool to the nation's 40,000 fire departments. The cutter is listed below \$2,000 (about 70 percent less than competing rescue equipment) to make it affordable for community rescue groups throughout the United States. The company also plans to expand the tool to other markets, such as military and civilian search and rescue operations, mining excavations, and cable- and wire-cutting operations. "We've shown it to sheriffs, highway patrol, ambulance groups, and there's a sizeable amount of interest from each one of them," said Hi-Shear Vice-President Walt Smith.

"We're working on a similar cutter for power companies," Smith added. "It's slightly more [advanced] than the unit we derived from the TRP program, but this device can cut a high-voltage power line. We're talking about 84 conductors of aluminum with 19 steel cords on the inside. It's very difficult to cut that even with a hydraulic unit."

The February 1994 TRP award to Hi-Shear represented the first TRP cooperative agreement with a contractor. Within six months, the company had Lifeshear in full production, making it the first contractor to complete a TRP design and development program. Announced by President Clinton in March 1993, the TRP program is part of a \$1.7 billion

Defense Reinvestment and Conversion Act passed by Congress. TRP projects are structured to reduce the cost of products made by the federal government while enhancing US competitiveness in the world market—which falls in line with NASA's mission to transfer technology to the private sector. The agency

projects the TRP with Hi-Shear will generate millions in cost-savings for federal, state, and local rescue services.

For more information, contact Walt Smith, Hi-Shear Technology Corp., 24225 Garnier Street, Torrance, CA 90505-5323; Tel: (310) 784-2101; Fax: (310) 325-5354.



Rescue workers in Oklahoma City learn use of the Lifeshear cutter.



John F. Kennedy Space Center

In 1962, NASA began acquiring property for a space center to serve as a launch operations base for the Manned Lunar Landing program. Approximately 140,000 acres of state-owned land were purchased adjacent to Cape Canaveral, FL on Merritt Island, which became the home of John F. Kennedy Space Center (KSC).

KSC is the major NASA installation for preflight, launch, and landing operations and related programs supporting the space shuttle. Its activities include assembly, integration, and preflight preparation of the shuttle and its payloads; ground support equipment design and development; tracking and data acquisition; launch operations; recovery of the shuttle's solid rocket boosters; landing operations; refurbishment of the orbiter; flight operations support; and design, construction, operation, and maintenance of launch facilities.

Although these activities require extensive support facilities, only 5945 acres of KSC land have been developed or designated for NASA operations. Because Merritt Island is inhabited by endangered and potentially endangered wildlife, NASA entered into an agreement with the U.S. Fish and Wildlife Service to establish the Merritt Island National Wildlife Refuge within KSC boundaries. In addition, most of the Canaveral National Seashore falls within KSC. An Environmental Resources Document was created to forge an understanding of conditions and operations at the center—especially space shuttle launches—that may have an influence on the area's environment.

Getting the Message Out

KSC performs mainly applied—not basic—research, to support the space shuttle program. Bill Sheehan, chief of KSC's Technology Programs and Commercialization Office, explains that this operations focus brings the center more in alignment with industrial activity. The KSC research staff continually seeks to solve

problems similar to those encountered in commercial applications.

"The fact that we do more applied research means that we probably are going to have a better opportunity to match up with commercial partners and transfer the technology we develop," Sheehan said. "When we develop a technology, we're advancing the state of the art in an area that has significant commercial applications. Our focus on new technology helps us improve the operations process."


In order to consolidate and expedite the transfer of that technology, in 1991 KSC became the first NASA center to combine its technology transfer and patent offices. A year-and-a-half later, technology development activities were brought in, combining Technology Transfer/Commercialization,

Patent Counsel, Dual-Use, University Activity, Technology Inreach/Outreach, SBIR, and Advance Technology Development programs in one office. This provides single-point oversight of all technology development and research functions, reducing conflict between projects, eliminating duplication of research efforts, and resulting in a more efficient utilization of limited funds and personnel.

A unique aspect of technology transfer at KSC is the Dual-Use Program. Dual-use projects are research and development projects jointly pursued by NASA and industry where the results are planned to have both NASA and industry applications. Commercial partners and NASA co-fund dual-use projects; NASA also may provide funding for university or nonprofit organization projects.

Florida's Technology Research and Development Authority (TRDA) joined with KSC in 1993 in a technology transfer partnership to "co-fund projects of mutual interest that have dual-use capability within the state," according to Sheehan. The agreement seeks to develop relationships with local economic development agencies as a means to reach businesses across Florida to commercialize new technologies, produce new products, and bring them to the marketplace. KSC joined with Marshall Space Flight Center and Stennis Space Center in the Southeast Regional Outreach Alliance to transfer benefits of NASA expertise to industries in the southeast U.S. The KSC program expands on this concept by utilizing Economic Development Councils in Florida as ambassadors of NASA technologies, providing an open and continuous information flow throughout the state.

In 1994, a dual-use project was instituted to develop the Universal Signal Conditioning amplifier (USCA), which can connect all types of sensors and transducers universally to current and proposed data acquisition systems. The USCA is needed



The Space Shuttle Endeavour, weighing more than 19 million pounds with its support and transport hardware, is loaded aboard a crawler-transporter for its trip from the Vehicle Assembly Building to Launch Pad 39A. Once at the pad, the Endeavour and the mobile launch platform on which it was assembled and from which it will lift off, is deposited atop support columns to prepare for launch.

for KSC operations, but also has commercial applications. Originally designed by engineers from the center and I-NET, the KSC engineering support contractor, the TRDA assisted in co-funding the product with its partner, Loral Test and Information Systems.

The most important dual-use project currently underway is a joint effort with the Department of Energy to develop electronically active polymer coatings to protect metal from corrosion damage. Repainting metal structures on Shuttle launch pads that are exposed to multiple corrosive environments caused by the Sun, hydrochloric acid, and salt air, is extremely costly to NASA. If use of the coating is successful, the cost of NASA's investment could be recovered in a matter of years.

Through the Technology Transfer program, co-developers at KSC, Lockheed Space Operations, and NASA Ames received the largest Space Act Agreement award to date in 1993 for developing the Ground Processing Scheduling System, a software system that expedites scheduling of complex interactions of personnel, flight and ground hardware, and other resources involved in Space Shuttle Orbiter

prelaunch processing operations. Through a copyright license, the technology was spun off by Red Pepper Software of San Mateo, CA, which introduced a commercialized version called ResponseAgent™ scheduling and planning software.

NASA On-Line

Over the past two years, KSC has developed the NASA-wide TechTracS database to manage and track new technologies reported to its Technology



The Merritt Island National Wildlife Refuge within Kennedy Space Center is home to many species of endangered and potentially endangered animals and birds. The most famous residents are a family of Southern Bald Eagles that inhabit a nest just off KSC's main road. According to wildlife experts, eight to nine pair of bald eagles inhabit nests in KSC.

Programs and Commercialization Office. Most NASA centers feed technology information into the KSC central database, which automatically posts the data for access by NASA headquarters.

KSC also has its own World Wide Web (WWW) home page that provides a publicly-accessible source of information regarding the commercialization of KSC-developed technology. With this effort, KSC has led the way in "a unified NASA effort to make a presence on the World Wide Web," says James Aliberti, Manager of External Programs, Technology Transfer and Commercialization. Updated information on commercialization opportunities, patent and licensing information, and KSC facilities available for commercial use is available. The KSC home page can be accessed on the Internet at URL <http://technology.ksc.nasa.gov>.

For more information on commercial opportunities available through Kennedy Space Center, contact Bill Sheehan, Chief, Technology Programs and Commercialization Office, Mail Code DE-TPO, Kennedy Space Center, FL 32899; (407) 867-3017; E-mail: billsheehan@ksc.nasa.gov.

MEGA
MOTORS



Pittman offers big performance in a compact package. Choose from four series of DC motors, 1.18" to 2.13" diameter. Continuous-duty torques from 1.2 to 50 oz.-in. Options include spur or planetary gearheads, optical encoders, EMI filters, and other value-added assemblies.

Call 215-256-6601 Fax 215-256-1338



PITTMAN®
HARLEYSVILLE, PA 19438-0003 USA
A DIVISION OF PENN ENGINEERING & MANUFACTURING CORP.

© Pittman, 1995 G10



Special Focus: Computer Graphics and Simulation



Program for Simulating Dynamics of Aerospace Vehicles

A modular structure facilitates application to a variety of trajectory-analysis problems.

Lyndon B. Johnson Space Center, Houston, Texas

SORT (Simulation and Optimization of Rocket Trajectories) is a general-purpose three-degree-of-freedom with three axis static moment balance simulation of the flight dynamics of an arbitrary aerospace vehicle. It has been used extensively by the Missions Operation Directorate (MOD) of the Johnson Space Center (JSC) in the development of data-initialization loads for space shuttle missions as well as by JSC's Engineering Directorate for ascent and entry trajectory optimization of advanced launch vehicle and spacecraft concepts. Simulations created by this program have been compared rigorously to a number of other simulations throughout the years to certify its overall fidelity. SORT numerically models vehicle subsystems such as propulsion, guidance, steering, and static moment balance. It also contains numerous models for environmental effects including atmosphere, drag, gravity, and winds for a rotating oblate planet.

SORT has a well-designed modular structure that enables its application to a wide range of trajectory-analysis problems without need for minor modifications. The program includes iteration logic and discrete-event-simulation logic that are completely independent of the mathematical-model logic. The discrete-event-simulation logic provides the user with the capability to simulate a limitless number of flight profiles. With the generalized targeting and optimization capability, iterations can be performed upon input parameters to minimize a cost function subject to constraints. The input parameters, cost function, and constraints are specified by the user. The constraints can be of the equality or inequality type.

SORT contains a math model of aerodynamics that is completely generalized. It computes both longitudinal and lateral forces and moments. In addition to the fore-body coefficients, it computes the longitudinal base effect aerodynamic forces and moments. A simplified ballistic-coefficient model is also available for analysis of ballistic entry.

SORT includes a math model of propulsion that is highly generalized but simple to use. In this model, the vehicle can be represented as containing as many as 15 engines. Each engine can be specified as either liquid- or solid-fueled. A liquid-fueled engine can be further specified as being of either the monopropellant or the bipropellant type. The solid-fuel-engine submodel can adjust the thrust, rate of flow, and chamber-pressure tables to compensate for the effects of ambient temperature and changes in the rate of burning. The program provides numerous options for specifying angles of deflection of engines as well as a thrust-deformation model for simulations of higher fidelity. Each of the engines can be specified to be either throttleable or nonthrottleable. For static moment control, individual engines can be specified to be controllable or noncontrollable. The degrees of controllability of individual engines can also be specified via gain tables.

SORT also includes a mass-properties math model; this is a composite model that enables the user to represent the vehicle as a system that contains as many as fifteen mass subsystems. Each mass subsystem can be specified to be either inert mass or propellant. For higher fidelity, a center-of-mass history is attributed to each mass subsystem. The composite center of mass of the vehicle is computed by use of the parallel-axis theorem. The mass history of the vehicle is computed by integrating the propellant-depletion history via one of the three available numerical-integration schemes. In addition to expressing vehicle weights directly, SORT contains weight-estimation algorithms for use in analyses directed toward sizing two-stage launch vehicles.


SORT contains four stored atmosphere models as well as two generalized table-lookup models. The first generalized table-lookup algorithm provides the capability to input speed-of-sound data as well as to compute speed of sound by use of the perfect-

gas law. The second table-lookup algorithm provides the capability to gain access to data from a binary direct access file.

The parameter optimization logic of SORT is unique in that it provides the flexibility to solve difficult trajectory-design problems via a multilevel approach. The program provides the capability to break a trajectory design into as many as seven levels. Each of the levels can be nested either sequentially or recursively. A library of six iteration-and-optimization techniques is available to be used in any optimization level. These algorithms include the Variable-Metric Algorithm for Constrained Optimization (VMACO), the Multiple-Gradient Optimization Algorithm (MGOA), Newton-Raphson technique, a quadratic-curve-fit algorithm, a secant-method algorithm, and a carpet-plotting algorithm. In addition, a SORT interface to NPSOL (Nonlinear Programming algorithm from Stanford University's Systems Optimization Laboratory) is also provided. Any feasible flight dynamics math model input parameter can be used as a control parameter and any feasible flight dynamics math model output parameter can be used as a constraint or optimization parameter.

The input and output features of SORT are designed to maximize flexibility and ease of use. Highlights include comprehensive input error diagnostics as well as complete control by the user over the output from the program. For ease of use, SORT provides output in either landscape or portrait format. To aid the interpretation of the results of iterations, modular tabular histories of iterations as well as abbreviated summaries of trajectories are provided. Trajectory ephemeris data are provided in both ASCII and binary formats. Two binary ephemeris output options are provided to enable use with various plotting programs.

SORT was written using ANSI FORTRAN 77 and runs on DEC VAX-series computers under VMS, CRAY X-MP- and Y-MP-series computers under UNI-



**Hewlett-Packard
DesignJet 650C
PostScript E-Size
Color Inkjet Plotter**

Final quality E-size color plots in about 10 minutes with 300dpi color/600dpi black resolution for laser-quality output in millions of brilliant colors. Adobe PostScript Level 2, AutoCAD HP-GL/2, Windows 3.1 and Macintosh® drivers standard.

CLIN 83978A

\$7,784



**Tektronix Phaser 340
Color Printer**

The new Phaser 340 PostScript Color Printer provides brilliant yet affordable color on plain paper with a cost per print of 10¢. With 4PPM speed and unprecedented ease of use, the Phaser 340 is appropriate for any color application.

CLIN 033-89847A

\$4,600

**Apple® Power Macintosh®
6100/66 Macintosh/DOS
XTerminal Solution**

XTerminal, 486PC, Power Macintosh – it's all here in one versatile system. Also includes Apple Design® keyboard, MacX and transceiver. Display must be purchased separately.

CLIN 8A541A

\$2,441



Authorized Reseller

NOBODY CAN MATCH GTSI'S RECIPE FOR NASA SEWP.

Looking for the perfect SEWP recipe? Government Technology Services Inc. (GTSI®) has all the fixings you'll need to serve up your best NASA contract ever.

Start with over 6,000 hot computer products from over 60 leading manufacturers. Stir in a huge variety of commercial off-the-shelf choices for cross-platform interoperability. Then add the widest range of software and storage solutions, workstation alternatives, and printers. Top off with a generous \$10 million order limit.

Need more spice? How about a menu-driven, on-line GTSI catalog that provides comprehensive product

information and purchasing configuration capabilities, plus an e-mail connection to our sales and customer support professionals. Then finish with a well seasoned staff that can help make your IT procurements easy as pie.

Want this award winning recipe? If you're buying for NASA, NASA Primes or other federal agencies having joint projects

with NASA, just call 1-800-999-GTSI or contact us on GTSI Online. We'll make sure you have all the right ingredients for an excellent SEWP.



NAS5-37008

GTSI Online

<http://www.gtsi.com>

1-800-999-GTSI



**UNITING GOVERNMENT
WITH TECHNOLOGY**

End users: call our Express Line at 1-800-XPR-GTSI for pricing, credit card or technical information. BBS#: 703-222-5227. This promotion refers to various companies or products by their trade names. In most if not all cases, these designations are claimed as trademarks, registered trademarks, service marks, or registered service marks by their respective owners. © GTSI, 1995 – All rights reserved.

For More Information Write In No. 505

COS, and HP9000-series 700/800 computers running HP-UX v9.01 or higher. With minimal modifications, SORT can be ported to other computers and operating systems. The program requires 2MB of random-access memory for execution and approximately 15MB of disk space for installation. It should be noted that the 15MB of disk space includes storage for sample input and output data. For full implementation of the SORT program, the user needs to obtain the Nonlinear Programming algorithm, NPSOL, developed at Stanford University's Systems Optimization Laboratory [Stanford Business Software, Inc., Stanford, CA, Dr. Mukund Thapa, (415) 962-8719].

The VAX/VMS, CRAY, and HP9000 distributions of SORT contain identical code, including the machine-independent code and the machine-dependent code for all three types of computers; only the storage formats and distribution media differ. The standard distribution medium for the DEC VAX/VMS version of SORT is a 1,600-bit/in. (≈ 630 -bit/cm), 9-track magnetic tape in DEC VAX BACKUP format. This version is also available on a TK50 tape cartridge in DEC VAX BACKUP format. The standard medium for distribution of the CRAY version of SORT is a 0.25-in. (6.35-mm) streaming-magnetic-tape cartridge (Sun QIC-24) in UNIX tar format. The standard medium for distribu-

tion of the HP9000 version of SORT is a 4-mm DAT tape in UNIX tar format. For the HP9000 and CRAY versions, alternate distribution media and formats are available upon request. SORT has been developed over a period of years, version 7.0 having been released in 1993. For the next release of SORT, a Graphical User Interface (GUI) is currently under development.

This program was written by M. J. Berning and K. D. Sagis of Lockheed Engineering and Sciences Co. for Johnson Space Center. For further information, write in 61 on the TSP Request Card. MSC-22496/97/98



Software for Real-Time Simulation of Subsystems

This program provides a practical method of understanding small systems integrated into larger ones.

Lyndon B. Johnson Space Center, Houston, Texas

The Real-Time Software Simulation of a Small Imbedded System (SSO) computer program was developed for use in simulating any one of a number of systems and subsystems of the space shuttle *Columbia*. These systems and subsystems include the system control module (SCM), its ground support equipment and test assembly (GSE/TA), and the support system for orbiter experiments (OEX). The support system consists of the SCM, the orbiter experiments tape recorder, and the orbiter experiments pulse-code-modulation (PCM) data system. Some of the apparatuses that implement the experiments are the Shuttle Entry Air Data System, the Shuttle Upper Atmosphere Mass Spectrometer, the Shuttle Infrared Leeside Temperature Sensing System, the Aerodynamic Coefficient Identification Package, and the High Resolution Accelerometer Package.

SSO includes subprograms called the "GSE/TA simulator" and the "SCM simulator." The GSE/TA simulator determines the integrity of the SCM in a pre- and in a post-flight configuration. With the help of SSO, the time spent in cross training will be significantly less than that spent in cross training by the present method. SSO also provides a practical method of understanding small systems imbedded in an integrated environment like that of the space shuttle *Columbia* without having to turn on the real GSE/TA and flight hardware.

The SCM and GSE/TA simulators provide an extremely flexible means of controlling the OEX tape recorder, the PCM system, and the experiment. These simulators receive and send commands from simulated ground stations at Kennedy Space Center, Edwards Air Force Base, and the Johnson Space Center via a simulated multiplexer/demultiplexer computer. These commands provide on/off discrete outputs to control the tape recorder and as many as 31 other functions of the experimental apparatuses and the data system.

SSO also provides for simulation of an analog subsystem in which one can switch any one of 32 simulated analog inputs to any one of 28 tape-recorder tracks and 4 simulated ground-support data channels. All of the traditional tape-recorder controls are also provided, with the addition of several functions, including track sequence, mark, go to mark, snapshot, and log. SSO also provides the capability to store sequences or commands for later execution. The commands can be sent from the simulated ground station or stored in a simulated program memory before flight. The execution delays for the valid commands can be modified during all simulated missions, enabling adaptation to contingencies.

The most complex parts of SSO involve the real-time operations. These operations include the command input/output (I/O), the imple-

mentation of the internal clock, and control of the OEX tape recorder, with commands and arguments to be received asynchronously on an interrupt basis. The timing between command words can vary between milliseconds and hours. Consequently, all operations are performed with interrupts enabled because disabling interrupts can cause a command to be missed entirely.

The ultimate real-time function of SSO is the control of the OEX tape recorder. Apart from the expected speed and direction settings, SSO provides a number of high-level functions that enable the recorder to be positioned automatically at the beginning or end of the tape or at a position previously set by a special "mark" command. SSO maintains a table, by means of which a "mark" number is issued at the end of a recording sequence. The simulator places a 9,000-ft ($\approx 2,700$ -m) tape within 7 in. (≈ 18 cm) of the marked position at a later time. SSO provides for reversal of the direction of travel of the tape, redirecting data from sources to unused tracks, and restarting a recording sequence automatically when either end of the tape is reached. The GSE/TA simulator provides 17 self-tests that determine the health of the SCM simulator while using a switch-setting function on the control page (an interactive display) of the GSE/TA simulator. All control pages were designed to be user-friendly.

The Answers to Your Questions...



Immediately gain insight from your data with IDL, the pioneering software for interactive analysis and application development. If you analyze data from tests, experiments, simulations, or images – or write applications for others to use – IDL will give you clear results faster.

Dramatically improve your productivity using IDL for visual data analysis, rapid prototyping, or application development. Nothing else provides the speed, flexibility, and breadth of built-in functions for access, manipulation, and display of scientific and engineering data.

See results "on the fly" with integrated

graphics, image processing, mathematics, and statistics. Quickly turn your ideas into powerful applications using IDL's high-level, array-oriented programming language and cross-platform GUI tools.

A few lines of IDL code can do the job of hundreds of lines of C or Fortran, without sacrificing flexibility or performance. Plus, you can call functions in other languages or link IDL to your C or Fortran applications.

IDL programs are portable. You can deliver complete solutions on UNIX[®], VMS[™], Windows, Windows NT[™], Macintosh[®], and Power Macintosh, while writing programs only once.

So why waste time starting from scratch? Exploit IDL and find the answers – in less time, with less programming, and less hassle.


SEE THE ANSWERS FOR YOURSELF

For a free evaluation copy, call

303-786-9900

Email: info@rsinc.com/Fax: 303-786-9909

Software $\equiv$ Vision[™]



Research Systems, Inc.

2995 Wilderness Place
Boulder CO 80301

Research Systems, Inc. is represented by the following distributors: **GERMANY** CREASO, GmbH 49 8105 25055 • **FRANCE** Fast Parallel Solutions 33 1 46 87 25 22 • **UK** Floating Point Systems UK Ltd. 44 734 776333 • **ITALY** Alliant Computer Systems SRL 39 39 6091766 • **JAPAN** Adam Net Ltd. 81 35802 2251 • **BRAZIL** SulSoft 55 51 488 22 57 • **KOREA** InterSys 82 42 869 4746

For More Information Write In No. 555

Visualize, Realize, *Crystal* EYES²

CrystalEyes 2 Eyewear
New Low Price, \$595*
New Improved Product

CrystalEyes 2 eyewear is available NOW from Stereographics Authorized Distributors and Resellers at the New Low Price of \$595!*

The new, improved, more comfortable eyewear features: folding temples that activate on/off, better weight balance and an integral silicone rubber nose piece.

CrystalEyes 2 eyewear is compatible with all existing CrystalEyes products.

With **CrystalEyes 2** eyewear, computer or video-generated images leap out of the screen in true 3D stereo depth. More than ever before **CrystalEyes 2** eyewear is a higher quality, more affordable solution to viewing stereo images in molecular modeling, computer aided design, mapping, medical endoscopy, medical imaging, training and entertainment.

Call for information today!

* Current CrystalEyes users can add a second pair of eyewear for the new low price. New users will require CrystalEyes 2 and emitter - priced at \$795

STEREOGRAPHICS

2171 E. Francisco Blvd., San Rafael, CA 94901

Tel: 415.455.1832, Fax: 415.459.3020

email: sales@crystaleye.com

web page: <http://infolane.com/infolane/stereog/sghp.html>

Stereographics and CrystalEyes are registered trademarks of Stereographics Corp. All other trade names are trademarks or registered trademarks of their respective holders

800 783-2660

SSO consists of four subprograms written in C language for use on IBM PC-series and compatible computers running MS-DOS. It requires at least 640K of random-access memory and MS-DOS 3.1 or higher. Because of the complexity of SSO, a VGA graphics display is highly recommended. The source code requires the MicroSoft C v6.0 compiler; however, a sample MS-DOS executable code is provided. The standard distribution medium for this program is a set of three 5.25-in. (13.335-cm), 360K MS-DOS format diskettes. The contents of the diskettes are compressed by use of the PKWARE archiving software tools. The utility software to unarchive the files, PKUNZIP.EXE, is included. This program was developed in 1990.

This program was written by Dwight A. Favors, Dan Devoss, and Michael Cheatham of Lockheed Engineering and Sciences Co. for Johnson Space Center. For further information, write in 202 on the TSP Request Card. MSC-22250

Σ Graphical Displays Assist in Analysis of Failures

Digraphs or engineering schematics can be used.

*Lyndon B. Johnson Space Center,
Houston, Texas*

The Failure Environment Analysis Tool (FEAT) computer program enables people to see and better understand the effects of failures in a system. FEAT uses digraph models to determine what will happen to a system if a set of failure events occurs and to identify the possible causes of a selected set of failures. The user can select failures from graphical displays in either engineering schematic form or digraph model form, and the effects or potential causes of the failures will be highlighted in color on the same schematic or model graph.

As a design software tool, FEAT helps design reviewers understand exactly what redundancies have been built into a system and where it is necessary to protect or design out weak parts. A properly developed digraph can reflect how a system functionally degrades as failures accumulate. FEAT can also be used in operations to help identify causes of failures after they occur. Finally, FEAT is valuable both in conceptual development and as a training aid, inasmuch as digraphs can identify weaknesses in scenarios as well as hardware.

Digraph models for use with FEAT are generally built with the help of the Digraph Editor — a Macintosh-based application program that is distributed with FEAT. The Digraph Editor was developed specifically with the needs of FEAT users in mind and offers several timesaving features. It includes an icon software toolbox of components needed in a digraph model and a menu of functions for manipulating these components. It also offers the FEAT user a convenient way to attach a formatted textual description to each digraph node. These node descriptions are necessary to enable FEAT to recognize nodes and propagate failures within a digraph.

The FEAT user stores node descriptions in modeling tables by use of any word-processing or spreadsheet software package capable of saving data to ASCII text files. From within the Digraph Editor, the user can then interactively attach a properly formatted textual description to each node in a digraph. Once descriptions are attached to them, a selected set of nodes can be saved as a library file that represents a generic digraph structure for a class of components. A feature called

These won't save you time or money...


$$\nabla \times H = J + \epsilon \frac{\partial E}{\partial t} \quad \nabla \times E = -\mu \frac{\partial H}{\partial t} \quad \nabla \cdot E = \frac{\rho}{\epsilon} \quad \nabla \cdot H = 0$$

THESE WILL.



A CAE package that provides immediate productivity and saves prototyping dollars is very hard to find. With our line of fully integrated BEM electromagnetic simulation software, we can help.

Each of our packages is designed around three basic principles: advanced technology, productivity and exceptional customer service.




B-Field Bands: Periodic condition on a magnetic clutch for arbitrary rotor position.

Advanced Technology

"I have analyzed literally hundreds of linear and non-linear electromechanical devices with IES software. It has become an invaluable tool to me, as it's so much easier to work with than FEM software. Unlike FEM, BEM software does not necessitate any re-gridding of the problem when one medium is being rotated or translated with respect to another, which results in a significant time saving."

Dr. Kent Davey
American Maglev

Progressive features like our automatic/adaptive boundary element refinement, relative error detection, 3D symmetry conditions and a consistent graphic interface give you the most advanced programs available anywhere.



Torque vs. position curves for optimal motor design are readily calculated.

Productivity

"IES BEM programs have consistently outperformed the seven FEM packages I have evaluated in the past few years. The operator interface of IES programs allows for immediate productivity, where

there is a significant learning curve involved in all FEM packages."

Nicholas F. Campagna
Consultant

We have set up sample problems for you to work through along with databases of solved problems comparable to conventional industry-specific needs. Shorten the steps to your solution with IGES or DXF geometry translators and parametric definitions.

Customer Service


"IES has consistently impressed us with their speed of

response and strong commitment to work with us on unique problems."

Jim Aydelotte
Dymacast Magnetics

On-line help, full technical support and two complete program enhancements each year keep you on the cutting edge of CAE design and analysis.

Load a single diskette or tape onto your PC or workstation. Within one day you will begin working on your own problems. In just a week, even the most sophisticated 3D design solutions are yours. We give you our word. And so have our customers.



Use BEM to solve non-linear eddy current problems.

Call today for your 30-day no-charge software evaluation.



INTEGRATED
ENGINEERING SOFTWARE

TEL: (204) 632-5636 FAX: (204) 633-7780
e-mail: info@integrated.mb.ca

"Generate Model" can then use library files to generate digraphs for every component listed in the modeling tables, and these individual digraph files can be used in a variety of ways to speed generation of complete digraph models.

FEAT contains a preprocessor subprogram that performs transitive closure on the digraph. This subprogram implements a multistep algorithm that builds a series of phantom bridges, or gates, that enable accurate bidirectional processing of digraphs. In the cases of extremely large models, this preprocessing can consume substantial time, but once preprocessing is complete, queries can be answered and displayed within seconds. A UNIX X-Windows port of version 3.5 of FEAT, called "XFEAT," is also available, and can speed the processing of digraph models. These models are created on a Macintosh computer. FEAT v3.6, which is available for the Macintosh only, provides some report-generation capabilities that are not available in XFEAT.

For very large integrated systems, FEAT can reduce the costs of evaluation of designs, training, and capturing knowledge. Because it is possible to load multiple digraphs and schematics

into FEAT, modelers can use FEAT to organize models of systems into smaller, more focused digraphs. Typically, each digraph file represents only a portion of a larger failure scenario. FEAT combines these files and digraphs to form a continuous mathematical model of the failure logic of a system. Inasmuch as multiple digraphs can be cumbersome to use, FEAT ties propagation results to schematic drawings produced by use of MacDraw II (version 1.1v2 or later) or MacDraw Pro. This makes it easier to identify single- and double-point failures that may have to cross several system boundaries and multiple engineering disciplines before creating a hazardous condition.

FEAT v3.6 for the Macintosh computer is written in C language by use of Macintosh Programmer's Workshop C v3.2. It requires at least a Mac II-series computer running System 7 or System 6.0.8 and 32-Bit QuickDraw. It also requires a math coprocessor or coprocessor emulator and a color monitor (or one with 256-gray-scale capability). A minimum of 4MB of free random-access memory (RAM) is highly recommended. The UNIX version of FEAT

includes both FEAT v3.6 for the Macintosh and XFEAT. XFEAT is written in C language for Sun-series workstations running SunOS, SGI workstations running IRIX, DECstations running ULTRIX, and Intergraph workstations running CLIX version 6. It requires the MIT X Window System, Version 11, Revision 4, with OSF/Motif 1.1.3, and 16MB of RAM.

The standard medium for distribution of FEAT 3.6 (Macintosh version) is a set of three 3.5-in. (8.89-cm) Macintosh-format diskettes. The standard distribution package for the UNIX version includes FEAT in three FEAT 3.6 Macintosh diskettes, plus XFEAT in a 0.25-in. (6.35-mm) streaming-magnetic-tape cartridge (QIC-24) in UNIX tar format. Alternate distribution media and formats for XFEAT are available upon request. FEAT has been under development since 1990. Both FEAT v3.6 for the Macintosh and XFEAT v3.5 were released in 1993.

This program was written by Ginger Pack, David Wadsworth, and Reza Razavipour of Johnson Space Center. For further information, write in 52 on the TSP Request Card. MSC-22446

Program Aids Visualization of Data

This program eliminates the need for custom graphical-display software for application programs.

Lewis Research Center, Cleveland, Ohio

The Living Color Frame System (LCFS) computer program was developed to solve some of the problems that arise in connection with the generation of real-time graphical displays of numerical data and of the statuses of systems. The need for a program like LCFS arises because computer graphics are often applied for better understanding and interpretation of data under observation and these graphics become more complicated when animation is required during run time, as in many typical modern artificial-intelligence and expert systems.

LCFS includes a software tool for the generation and management of graphics, provides a user-friendly graphical interface with mouse-driven controls, and provides extensive on-line instructions. Regarded as a system, LCFS consists of a number of modules that can be used to create graphics screens (frames), receive and record data from a hardware or software source, and update screen information to reflect changes in incoming data.

The modules also make it possible for the graphics screens to be logically linked (through frame objects), and then dynamically recalled (unique object-oriented zooming technique) for display in real time by use of mouse commands. Run-time software for the inclusion of custom video and sound effects on these frames is also provided (complete demonstration programs). Support for such functions as display of monitored data, manipulation of graphical images, and sounding of the computer buzzer is included.

In some applications, the generated graphical frames can be visual aids for managing systems. LCFS is suitable for integration into a wide range of real-time application programs in which graphical displays are needed. For example, for purposes of monitoring, diagnosis, and/or control, circuit or system diagrams can be brought to life by use of designated video colors and intensities to symbolize the status (real-time feedback from sensors, calculated values, etc.) of systems, sub-

systems, and components of hardware. LCFS eliminates the need for custom programming of computer graphics, enabling software developers to focus on the functionalities of their application programs.

LCFS is written in Turbo C++ for IBM PC-series and compatible computers running MS-DOS v3.3 or later. The program requires at least 88K of random-access memory, a color display (CGA, EGA, VGA), and a two-button mouse. The distribution medium includes an electronic copy of the documentation in WordPerfect format, a sample executable code, and a demonstration file. The standard medium for distribution of LCFS is a 3.5-in. (8.89-cm), 1.44MB, MS-DOS-format diskette. LCFS was developed in 1993 and is a copyrighted work with all copyright vested in NASA.

This program was written by L. V. Truong of Lewis Research Center. For further information, write in 26 on the TSP Request Card. LEW-15917

Just because

we make HP plotters so reliable doesn't mean we can't surprise you once in a while.



Now starting at
\$2,395

HP DesignJet plotters are well known for their crisp, clean print quality. Are noted for their impressive speed. And, of course, are consistently applauded for their reliability, backed by a next-day, on-site service warranty. Now, with two new models, we bring you affordability. The HP DesignJet 230 offers D-size monochrome plot-

ting for only \$2,395. And for \$2,995, the HP DesignJet 250C finally puts color plotting within reach.* For an output sample or the name of your local HP demo dealer, visit us on the World Wide Web at <http://www.hp.com/info/9552>.

Or, call 1-800-851-1170, Ext. 9552.*

*U.S. list prices. HP DesignJet 230 E-size model priced at \$3,195. HP DesignJet 250C E-size model priced at \$3,995. Price does not include optional legs. Plot designed by Minello Grafico, Inc. 11n Canada, call 1-800-387-3867, Ext. 9456. ©1995 Hewlett-Packard Company PE 12554




**HEWLETT®
PACKARD**

For More Information Write In No. 502

More Than Meets The Eye

Kevex X-Ray...

*Microfocus radioscopy
is only the beginning.*



*Our specialized x-ray
sources are widely used for:*

Gauging/Process Control

- On-line Metal Thickness
- Paper Composition
- Plating Thickness

XRF/Diffraction

- Chemical Analysis
- Stress Measurement
- Thin Film Characterization

Radioscopy

- Microelectronics & PCB Inspection
- Multilayer PCB Registration
- Aerospace Failure Analysis
- Clinical Fluoroscopy
- Stereotaxic Surgery
- Bone Density Scans

A full line of specialized x-ray sources.

Kevex X-Ray offers a complete spectrum of specialized x-ray sources: from our industry leading KM125 and KM160 microfocus series to our patented PXSTM integrated sources, high stability x-ray tubes and modular power supplies.

Unique problems require unique solutions.

Over 3000 installations worldwide attest to the fact that Kevex X-Ray products are designed to help detect problems in industry and medicine. **If you have a specific x-ray need, call Kevex X-Ray for the solution at 408-438-5940.**

KEVEX X-RAY, INC.
320 El Pueblo Road
Scotts Valley, CA 95066
Tel: 408-438-5940
Fax: 408-438-5892

FISONS
Instruments

The family of specialized solutions

For More Information Write In No. 405

Software Aids in Graphical Depiction of Flow Data

This program generates contour, vector, shaded, x-y, and carpet plots.

Lewis Research Center, Cleveland, Ohio

The Interactive Data Display System (IDDS) computer program is a graphical-display program designed to assist in the visualization of three-dimensional flow in turbomachinery. Grid and simulation data files in PLOT3D format are required for input. This program is able to unwrap the volumetric data cone associated with a centrifugal compressor and display results in easy-to-understand two- or three-dimensional plots. IDDS provides the majority of the visualization and analysis capability for the Integrated Computational Fluid Dynamics and Experiment (ICE) system. In the ICE computing environment, IDDS can be invoked from any subsystem, or it can be used as a stand-alone package of display software.

IDDS offers five different plotting styles: contour, vector, shaded, x-y, and carpet. All of these styles are available for both two-dimensional and three-dimensional data. For three-dimensional plotting, IDDS automatically combines the *i*, *j*, *k* indices and predetermines views. These views are cross-channel, blade-to-blade, and meridional. The cross-channel view is formed by combining all *i* and *j* indices, and is intended to show secondary flow characteristics. A blade-to-blade view is developed by combining all *i* and *k* indices, and is intended to show streamwise flow characteristics on a plane parallel to the hub from inlet to outlet. The meridional view is constructed by combining all *j* and *k* indices. This view is also intended to show streamwise characteristics, but in a plane parallel to a blade surface from inlet to outlet.

IDDS enables the user to select up to four windows and plots to be displayed on the computer video screen. A unique file can be associated with each window for comparison of plotted data. Options for customization of plots include: the variable for display, orientations of slices through the data, type of plot, numerical and color ranges for color bars, contour levels, and vector levels.

Geometric coordinates are taken directly from a grid file specified by the user. IDDS enables the user to display the geometry, orient it as desired, and then overlay the desired plot on top of the geometry. After selection of the desired plot(s) and geometry, the display is built. The user has the option to display the grid, the plot, and/or the geometry individually or in any combination. After the picture is rendered, the user can rotate, translate, or zoom on the display.

IDDS is written in C language for Silicon Graphics IRIS- and Indigo-series workstations running IRIX. IDDS requires a minimum of 16MB of random-access memory and a display capable of 24-bit Z-buffering. A sample executable code is included. The input file format used by IDDS is that of PLOT3D (COSMIC item ARC-12782). The creation of these input files is fully detailed in the documentation. The standard medium for distribution of IDDS is a 0.25-in. (6.35-mm) IRIX-compatible streaming-magnetic-tape cartridge in UNIX tar format. IDDS was developed in 1993.

This work program was written by J. D. Stegeman of Lewis Research Center. For further information, write in 90 on the TSP Request Card. LEW-15885



Electronic Components and Circuits

Tilting a Small Reflector for Vernier Pointing of a Large Antenna

It is easier to tilt the small mirror than to tilt the massive antenna structure.


NASA's Jet Propulsion Laboratory, Pasadena, California

A simple vernier pointing technique has been devised to facilitate scanning the beam pointing of a large paraboloidal reflector so that the line of sight of the antenna sweeps out a narrow cone about a fixed axis (conical scan, also known as "conscan" in the art). In this technique, the scan is effected by one of the relatively small beam-waveguide reflectors or mirrors (see figure) that couple signals between the antenna and its distant transmitting and/or receiving electronic circuits.

In the original application, the antenna is one of the Deep Space Network (DSN) antennas, with a paraboloidal reflector 34 m in diameter, operating at a frequency of 32 GHz. The required half-cone angle for scanning at 0.1 dB below the beam peak gain is 0.0016° . It would be very difficult to achieve such a fine conical scan by tilting the entire massive antenna structure as in previous DSN conscan systems. However, it is relatively easy to tilt one of the far smaller beam-waveguide mirrors.

Any of the beam-waveguide mirrors could be used for this purpose. The one chosen in the original application is located at the elevation axis of the antenna. A geometric analysis shows that the required 0.0016° conical scan of the beam peak of the antenna can be achieved by a 0.0375° conical scan of this mirror, labeled "M1" in the figure.

Note that this scan is much larger than is the required scan of the beam peak; this indicates that the aim of the antenna is relatively insensitive to an error in the tilt



One of the Flat Mirrors is Tilted through a small angle, θ_M , to obtain an even smaller beam-peak deviation, θ , of the line of sight of the antenna. Although M1 is tilted in this example, any of the other mirrors M2 through M6 could be tilted instead.

of this mirror, and consequently the scanning mechanism can be less precise than that needed for equivalent scanning of the entire antenna. The loss of beam peak gain directly attributable to the conical scan of this mirror is only about 0.01 dB.

This work was done by Watt Veruttipong and Dan A. Bathker of Caltech for NASA's Jet Propulsion Laboratory. For further information, write in 14 on the TSP Request Card. NPO-19366

Improved Controllers for Heaters in Toxic-Gas Combustors

Solid-state power controllers would overcome deficiencies of mechanical power controllers.


NASA's Jet Propulsion Laboratory, Pasadena, California

Commercial electronic proportional controllers have been installed in place of mechanical power controllers for electric heaters in toxic-gas combustors at NASA's Jet Propulsion Laboratory. A mechanical controller of the type in question is designed to maintain the temperature of a heater at a preset value by turning power fully on or fully off when the temperature falls below or rises above

that value, respectively. This results in an oscillating on/off mode of operation characterized by excessive consumption of energy and by frequent failures caused by (1) overpowering of the heater, (2) surging of power to the heater, (3) excessive temperature overshoot, (4) excessive on/off cycling of the temperature controller, (5) excessive expansion and contraction of the heater element, and (6)

thermal shock to the heater element.

In contrast, an electronic proportional controller supplies only the power needed to maintain the temperature of the heater nearly constant at the preset value, eliminating the large cyclic stresses of on/off operation (see figure). The result is increased efficiency and reduction of the incidence of failures. The operation of the combustor is not otherwise affected.



An **Electronic Power Controller** supplies just enough power to keep an electric heater at a preset temperature, whereas the older mechanical controller that it replaces subjects the heater to stressful on/off oscillation about the preset temperature.

This work was done by James Wishard, James Lamb, Edward Fortier, Hugo Velasquez, and Doug Waltman of Caltech for **NASA's Jet Propulsion Laboratory**. For further information, **write in 6** on the TSP Request Card.

In accordance with Public Law 96-517, the contractor has elected to retain title to this invention. Inquiries concerning rights for its commercial use should be addressed to:

William T. Callaghan, Manager
Technology Commercialization
JPL-301-350
4800 Oak Grove Drive
Pasadena, CA 91109

Refer to NPO-19281, volume and number of this NASA Tech Briefs issue, and the page number.

Method To Display Data on a Face Mask

A proposed electronic instrument would display information on a diver's or firefighter's face mask. The instrument would include a mask, a prism, electronic readouts, a transceiver and control electronics. For example, the instrument could be mounted at the

periphery of a diver's field of view to provide data on elapsed time, depth, pressure, and temperature. The prism could be made of glass or plastic, as needed, to provide resistance to corrosion, pressure, and/or heat. The use of a face mask with an integral display

would provide greater safety and convenience to the user.

This work was done by Kevin-Duron Moore, P. E. of **Johnson Space Center**. For further information, **write in 22** on the TSP Request Card.
MSC-22510

Improved Dichroics for Microwave Reflector Antenna Systems

Gridded square conductive loops are placed between dielectric slabs.

NASA's Jet Propulsion Laboratory, Pasadena, California

A panel that contains an array of grid and square conductive loops as array elements is designed to reflect most of the incident electromagnetic radiation in the K_u band (13.5 to 15.5 GHz) and to pass that in the X band (7 to 9 GHz). Furthermore, it is designed to exhibit this dichroic property at angles of incidence up to 40° in transverse electric, transverse magnetic, or circular polarization.

The concept of the gridded-square-loop dichroic array is related to that of the double-loop dichroic arrays described in "Frequency-Selective Microwave Reflectors" (NPO-18701), *NASA Tech Briefs*, Vol. 18, No. 1 (January 1994), page 32. Figure 1 shows part of an array of conductive loops, which is fabricated by etching the gridded-square-loop pattern on a polyimide substrate 0.003 in. (0.08 mm) thick and depositing copper on the pattern. Such an array on a substrate, unaccompanied by other components, exhibits the

(continued on page 38)





Figure 1. **Grid and Square Conductive Loops** of copper are deposited on a polyimide substrate to form a dichroic array of microwave antenna elements. The original version consists of such a substrate and array alone. The improved version consists of the substrate and array sandwiched between dielectric slabs.



The NVIS-Sunlight Readable Mil-Spec Switch.

The VIVISUN 95 illuminated pushbutton switch is NVIS compatible and sunlight readable per MIL-L-85762A. These two lighting extremes are no match for our state-of-the-art optics that provide excellent trimming and viewing angles while operating in high ambient (10,000 foot-candles) or low level (.1 foot-lambert) NVIS conditions.

The solderless Quik-Connect™ module is another unique feature of the VIVISUN 95. It is completely separate from the switch, allowing for both pre-wiring and bench testing for continuity. The Quik-Connect™ also provides outstanding benefits for both production installation and field maintainability. This results in unmatched performance.

As the industry's leading illuminated pushbutton

switch, the VIVISUN 95 also contains several additional options which make it the choice of today's design engineer. These options include: Up to 4 Pole Capacity • Dripproof/Dustproof/Splash-proof/Watertight • High Impact Shock • EMI.

The NVIS-Sunlight Readable VIVISUN 95 has proven to be a rugged, highly reliable switch for military designs. Make it part of yours.

Contact us today.



AEROSPACE OPTICS INC.

3201 Sandy Lane, Fort Worth, Texas 76112
Phone (817) 451-1141 • Fax (817) 654-3405

*VIVISUN 95 mil-spec switch.
The day-night all weather
lighting solution.*



SERIES
VIVISUN 95™

MIL-S-22885/108



PERFORMANCE TIMES ON PRO/ENGINEER v.14*

ALPHASTATION 250 4/266

177 sec.

HP 9000 735/125

202 sec.

SUN SPARCSTATION 20/61

322 sec.

**SOME OF US
AT DIGITAL
HAVE DECIDED
YOU'RE NOT
WORKING
FAST ENOUGH.**

Call us perfectionists. But we think you'll be

a lot happier (and more productive) with a faster workstation.

So we created the AlphaStation™

250 system. With it, you'll see

applications like Pro/ENGINEER, Design

Compiler, Unigraphics® and thousands of others perform as

never before—thanks to the world's

fastest microprocessor, coupled with next-generation system architecture.

You'll also see price/performance that puts competing machines to shame:

The AlphaStation 250 system is roughly half the price of the comparably

THE NEW ALPHASTATION 250. *performing HP*
IT'S FAST ENOUGH.

*workstation.** And you'll see virtually unlimited horizons, with the ability*

to run Digital UNIX® as well as Windows NT.™ What's more, an

AlphaStation 250 system delivers superior graphics, multimedia capability

and a no-nonsense three-year hardware warranty. Just like the rest of the

digital™

AlphaStation family. So if you think you're ready for

such fast company (we think you are), call us at 1-800-DIGITAL.

Or reach us via our Internet address: moreinfo@digital.com.

For More Information Write In No. 520

© 1995 Digital Equipment Corporation. Digital, the DIGITAL logo and AlphaStation are trademarks of Digital Equipment Corp. Windows NT is a trademark of Microsoft Corp. UNIX is a registered trademark in the United States and other countries, licensed exclusively through X/Open Company, Ltd. Digital UNIX V3.2 on Alpha is an X/Open UNIX93 branded product. Unigraphics is a registered trademark of Electronic Data Systems Corporation. All other products are trademarks or registered trademarks.

AAT

(continued from page 34)

desired dichroic property near normal incidence, but it exhibits unacceptably high losses at an angle of incidence of 40°. These losses are related to the fact that the resonant frequency of the array shifts by about 1.5 GHz as the angle of incidence increases from 0° to 40°.

The improved dichroic reflector is constructed by embedding a substrate that bears an array between two low-loss

dielectric slabs and bonding the layers together with low-loss adhesives. These slabs act as matching layers, reducing the dependence of the resonant frequency on the angle of incidence. Figure 2 shows computed transmission performances of the previous and improved dichroics, indicating that the shift in resonant frequency at 40° incidence on the improved reflector is less than 1 GHz.

This work was done by Te-Kao Wu of

Caltech for **NASA's Jet Propulsion Laboratory**. For further information, **write in 133** on the TSP Request Card.

This invention is owned by NASA, and a patent application has been filed. Inquiries concerning nonexclusive or exclusive license for its commercial development should be addressed to the Patent Counsel, NASA Resident Office-JPL; (818) 354-5179. Refer to NPO-18664.




Figure 2. **Transmission Characteristics** of the original and improved dichroic reflectors were calculated. The improved version exhibits a smaller shift of resonant frequency with angle of incidence.

Making Curved Frequency-Selective Microwave Reflectors

Conductive grid elements are formed photolithographically on the curved reflector surfaces.

NASA's Jet Propulsion Laboratory, Pasadena, California

Prototype curved lightweight dichroic microwave reflectors that are designed to be highly reflective in the X and K_a frequency bands and highly transmissive in the K_u and S bands were being fabricated at the time the information was submitted for this article. These reflectors are intended for use as subreflectors of

a main paraboloidal antenna reflector to enable simultaneous operation in both a prime-focus configuration in the K_u and S bands and a Cassegrain configuration in the X and K_a bands.

The basic concepts of these reflectors were described in "Frequency-Selective Microwave Reflectors" (NPO-18701),

NASA Tech Briefs, Vol. 18, No. 1 (January 1994), page 32. Closely related reflectors were described in "Double-Square-Loop Dichroic Microwave Reflector" (NPO-18676), Vol. 18, No. 3 (March 1994), page 38; "Triband Circular-Loop Dichroic Microwave Reflector" (NPO-18714), Vol. 18, No. 3

Top View of K_a -Band
Frequency-Selective surface

Bottom View of S/X/ K_u -Band
Frequency-Selective surface





Figure 1. These **Periodic Arrays of Double Square Loops** of metal on aromatic polyamid/epoxy face sheets act as the frequency-selective surfaces in the add-on design.

(March 1994), page 41; and "Improved Dichroic Microwave Reflector" (NPO-18664), Vol.19, No. 8, (August 1995), page 34.

The design selected for fabrication of the curved dichroic reflectors is the one called "add-on" in the first-mentioned prior article. To recapitulate: A reflector of this type is constructed as a unitary sandwich panel with a rigid dielectric core and frequency-selective front and back surfaces, which are implemented as periodic arrays of double-square-loop electrically conductive patches on thin dielectric sheets. The front surface is highly reflective in the K_a band and highly transmissive in the S, X, and K_u bands; the back surface is highly reflective in the X band and highly transmissive in the S and K_u bands (see Figure 1). (In another design called "integrated," only one dielectric face sheet supports an array of double-loop

conductive elements that satisfies the basic frequency-selective transmission and reflection requirement. The add-on design was selected over the integrated design on the basis of manufacturing and mechanical considerations.)

The prototype dichroic reflectors that were built and tested previously were flat approximations of the required curved ones. Figure 2 is a flow diagram of the process for fabrication of a curved one with a dielectric honeycomb core. The unique aspect of this process is that the conductive loop elements are formed photolithographically on the face sheets by direct laser imaging.

This work was done by Gregory S. Hickey and Te-Kao Wu of Caltech for NASA's Jet Propulsion Laboratory. For further information, write in 137 on the TSP Request Card. NPO-18755





Figure 2. A **Curved Dichroic Microwave Reflector** is formed by photolithographically defining patterns of conductive-loop antenna elements on curved face sheets.

THE NEXT GENERATION TAKES FLIGHT



Switching System Controls

To answer the avionic control needs of the aircraft and space vehicles that will propel us into the 21st century, Janco has engineered a new generation of switching systems that takes the high ground in longevity, simplicity, efficiency, and survivability. If you'd like to learn how to best orchestrate multiple switching and related electromechanical functions while decreasing component count, weight, and overall system size -- contact the engineers at Janco today for more information and a **free brochure**.



Janco

3111 Winona Avenue, Burbank, CA 91508

Phone: (818) 846-1800



Prototype Focal-Plane-Array Optoelectronic Image Processor

Advantages of optical and electronic processing are combined.

NASA's Jet Propulsion Laboratory, Pasadena, California

A prototype very-large-scale integrated (VLSI) planar array of optoelectronic processing elements combines the speed of optical input and output with the flexibility of reconfiguration (programmability) of an electronic processing medium. The basic concept of this processor was described in "Optical-Input, Optical-Output Morphological Processor" (NPO-18174), *NASA Tech Briefs*, Vol. 16, No. 11 (November 1992), page 52.

This processor performs binary operations on binary (black and white) images. Each processing element corresponds to one picture element of an image and is located at that picture element. Each processing element includes an input-plane photodetector in the form of a parasitic phototransistor that is part of a processing circuit (see figure). The output of each processing circuit would be used to modulate one picture element in an output-plane liquid-crystal display device, which had not yet been built when the information for this article was reported.

This processor is intended to implement morphological processing algorithms that transform an image into a set of features suitable for high-level processing; e.g., recognition. Morphological processing has been shown to be capable of removing noise and clutter and of editing an image on the basis of the sizes and shapes of objects of interest.


Morphological operations do not involve global communication of image data among all picture elements; only local data connections between adjacent picture elements are needed. Consequently, rapid morphological processing is readily implementable in a parallel optoelectronic architecture like that of this processor. In contrast, morphological image-processing algorithms, when executed on general-purpose computers, are extremely computationally intensive, and it is, therefore, difficult to execute them at video frame rates.

The processor includes a control circuit that generates clock and control strobe

signals for the processing elements in the array on the basis of the high-level morphological instructions to be executed. A 4-bit control word is fed into the control circuit to specify the operations to be performed. This control word is decoded to provide the control signals needed for each operation. Each time a command strobe signal is activated, the control word selects one of the morphological operations, which is executed by all of the morphological processors in parallel.

The prototype morphological processor was fabricated in complementary metal oxide/semiconductor (CMOS) VLSI circuitry, using 2- μ m design rules. The prototype circuit chip measures 1.2 by 1.2 mm and contains an 8 by 8 array of processing elements. Its digital circuitry operates at a rate of 40 MHz, which is sufficient for real-time processing of images at a video frame rate of 1 kHz.

This work was done by Wai-Chi Fang, Timothy Shaw, and Jeffrey Yu of Caltech for NASA's Jet Propulsion



The VLSI Focal-Plane Array of optoelectronic input and output devices and processing circuits combines the high throughput rate of a two-dimensional fine-grained array of simultaneous (parallel) processing elements with the programmability of the digital circuitry within each processing element.

Portable Data Acquisition

1 MHz



IOtech's new 1M sample/s WaveBook/512™ digitizer offers you the fastest notebook PC-based data acquisition available. This compact DSP-based unit provides:

- 8 differential analog input channels, expandable to 72
- 1 μ s/channel sampling & range switching
- 8 digital inputs, sampled up to 1 MHz
- digital calibration via on-board DSP
- single & multi-channel analog triggering
- internal simultaneous sample & hold option
- DC or battery power for portable applications

The WaveBook/512 connects to your PC via a high-speed PCMCIA card or enhanced parallel port (EPP) interface. What's more, because the WaveBook/512 can transfer data to your PC continuously at 1M sample/s, you can acquire large amounts of data directly into your PC's memory.

FREE Software

Software provided FREE with the WaveBook/512 includes:

- WaveView™, Windows™-based graphical software for effortless set up, acquisition, & real-time display
- PostView™, Windows™-based graphical software for post-acquisition review of waveforms
- Comprehensive DOS & Windows™ language drivers for Visual Basic™, C++™, Quick Basic™, & Pascal
- Support for icon-based software environments, such as Snap-Master™, LABTECH NOTEBOOK™, DASyLab™, & LabVIEW™

The WaveBook/512 is priced at **\$2,495** (other portable digitizers available from \$595).

Contact us today
for your free
IOtech catalog



(216) 439-4091
Fax (216) 439-4093




IOtech, Inc. • 25971 Cannon Rd. • Cleveland, OH 44146

WORLDWIDE DISTRIBUTORS: Australia, +61 3 579 3622; Austria, +43 (1) 259 72 70-0; Belgium, +32 (0) 2 466 81 99; Brazil, +55 11 853-2733; Canada, (905) 890 2010; Chile, +56 32 682 255; China, +86 1 205 9030; Denmark, +45 42 18 48 57; Eastern Europe, +43 1 54 515 88-0; Finland, +358 0 423911; France, +33 1 34 89 78 78; Germany, +49 711 79 80 37; Hong Kong, +852 2 830 5620; India, +91 80 6655 333; Israel, +972 03 498538; Italy, +39 2 66015566; Japan, +81 3 5688 6800; Korea, +82 2 538 4001; Netherlands, +31 (0) 70 399 6360; New Zealand, +64 9 309 2464; Southeast Asia, +65 482 5600; South Africa, +27 (12) 660 2884; Spain, +34 1 597 29 78; Sweden, +46 13 31 0140; Switzerland, +41 1 821 94 44; Taiwan, +886 2 5017065; United Kingdom, +44 (0) 1296 397676.

Prices and specifications may change without notice; prices are in U.S. dollars. F.O.B. Cleveland, Ohio, and do not include C.T. or duties, import taxes, freight and transportation charges. The following are trademarks of their respective holders: C++, DGS, Quick Basic, Windows, Microsoft Corporation, DASyLab, LABTECH NOTEBOOK, Laboratory Technology, LabView™, National Instruments, Snap-Master, HPU Data Corporation, ThinkJet, Hewlett-Packard.


For More Information Write In No. 665



Temperature & Voltage Measurement

The 19" rack-mountable MultiScan/1200™ temperature and voltage measurement instrument offers both channel-to-channel isolation and high accuracy. It can scan thermocouples and volts at up to 147 channels/s and digitize waveforms at up to 20 kHz. It can accept 24 differential voltage and temperature inputs, and can be easily expanded up to 744 channels. \$2490. IOtech, Inc. (216) 439-4091.

For More Information Write In No. 662



Visual Basic™ Software Tools

VisuLab 4.0™ software provides Visual Basic™ users with over 100 point-and-click tools for adding graphical user interfaces (GUIs), charts, and statistics and analysis functions to their data acquisition and IEEE 488 control applications. \$395. IOtech, Inc. (216) 439-4091.

For More Information Write In No. 663



Compact Serial/IEEE 488 Converter

The 2" x 2.3" Serial488/p™ serial-to-IEEE 488 converter enables users to directly link a PC or workstation to an IEEE 488 plotter or printer, such as a Hewlett-Packard ThinkJet™ printer. The miniature converter draws its power from the computer's serial port and can be connected to it directly or via cable. The Serial488/p incorporates a 120-character buffer, and it accepts RS-232C data at 9600 bps. \$295. IOtech, Inc. (216) 439-4091.

For More Information Write In No. 664

Laboratory. For further information, write in 84 on the TSP Request Card.

In accordance with Public Law 96-517, the contractor has elected to retain title to this invention. Inquiries concerning

rights for its commercial use should be addressed to:

William T. Callaghan, Manager
Technology Commercialization
JPL-301-350

4800 Oak Grove Drive
Pasadena, CA 91109

Refer to NPO-18941, volume and number of this NASA Tech Briefs issue, and the page number.

Satellites Would Transmit Power by Laser Beams

Arrays of diode lasers would concentrate power into narrow beams.

Langley Research Center, Hampton, Virginia

The concept of transmitting power by laser beams in outer space has received a major stimulus from the

recent emergence and rapid advance of the technology of laser-diode arrays. The basic idea is to use a nuclear,

solar, or other source of power to generate a powerful laser beam and transmit the beam, collimated and focused, to locations where its power can be used as is or converted to such other forms as electrical or thermal. Conceivably, one such power system could serve the needs of many consumers, as do central electric power stations on Earth. Further, such systems may provide the best means of accomplishing a scientific mission or offer capabilities not otherwise available.

Such a laser-beam power system (see figure) would likely include a solar collector/concentrator, a solar photovoltaic array, a laser, beam-transmission optics, heat radiators, and a receiver/converter. The baseline design of the system was formulated with regard to two particular missions that differ greatly in power requirements, thus showing the scalability and attributes of the basic system. The two missions are the provision of 1 MW of power to a lunar habitat and the provision of 75 kW to a large lunar rover.

The satellites for both missions would circularly orbit the Moon 2,000 km above its surface, a distance compatible with current aiming technology and with the capability to transmit power continuously by use of three identical satellites to any point in view on the lunar surface. Inclinations of the orbits to the lunar pole would be chosen to ensure almost continuous solar illumination of the satellites and produce an orbital precession that would make every point on the lunar surface accessible to transmission of power at some time.

This satellite system would feature a large-scale array amplifier of high efficiency, injection-locked amplifiers, coherent combination of beams, and the use of advanced lithographic technology to fabricate the diode lasers in the array. The extremely rapid development of the applicable technologies should make these



**Power.
When you
need it.
Whenever
you need it.**

The Evans Capattery. Very small, very powerful, very reliable.

This incredible double-layer capacitor is a unique carbon-based device that is housed in a welded tantalum package.

Its patented Permelective valve allows it to release CO_2 generated during normal operation while inhibiting the escape of electrolyte vapors and preventing contaminants from entering the container.


A 5.5-volt, 1F Capattery has a volume of 0.5 in.³, an 11-volt, 0.5 F Capattery has a volume of less than 1 in.³.

The Capattery has a temperature range of -55°C to 85°C. It withstands unlimited charge/discharge cycles.

EVANS

P.O. Box 4158, East Providence RI 02914
(401) 434-5600. Fax (401) 434-6908.

Infrared Engine



Sarnoff offers:

Commandable integration time

Full TV resolution imagery

Platinum Silicide MOS FPA

System Description:

The **Infrared Engine** uses our full television resolution 640 X 480 pixel Platinum Silicide (PtSi) MOS IRFPA mounted in a Stirling cycle cooled Dewar, with a f/1.5 baffled cold shield, and a cooled optical filter. The engine has complete drive and analog video electronics.

The **Infrared Engine** is extremely compact for use on gimbal systems and provides analog video at RS170 scan rates. A key capability is the eight IRFPA operating integration modes that can be selected for electronic shuttering (or an option can be added that will allow higher frame rate operation).

Technical Characteristics

640 X 480 Pixel PtSi FPA

- 24 (H) X 24 (V) micron pixels
- 50% fill factor
- No blooming, no lag, no transfer smear
- 3-5 μm spectral band
- NEDT = 0.15 (typical)

Cool Down Time: 12 minutes to first image

Outputs:

- Non-composite RS170 video
- Composite sync
- Linesync
- Vertical blanking
- Pixel clock
- FPA temperature voltage output

Controls:

- Commandable integration time (63 μs to 33ms)

Dimensions (mm)

- Camera head 77.72 (H) X 64.0 (W) X 156.72 (L)
- Electronics Box 23.88 (H) X 87.12 (W) X 116.08 (L)

Total weight: 1.2 kg

Applications

- Air to air/ground target tracking
- Personnel perimeter control
- Ground vehicle observation platform
- Industrial temperature measurement

Environmental Operating Conditions (Design Objectives)

- Temperature: -30°C to 60°C
- Performs within specification under typical random vibration environment of 6G (rms)

Options

- Frame-rate to 1KHz
- 12-bit video processor

DAVID
Sarnoff
RESEARCH CENTER
A subsidiary of SRI International

For further information contact: Business Development • David Sarnoff Research Center
CN5300/Princeton, NJ 08543 • Telephone (609)734-2553 • Facsimile (609)734-2443

The David Sarnoff Research Center reserves the right to change these specifications without notice
©Copyright 1994 David Sarnoff Research Center. All Rights Reserved


For More Information Write In No. 512

features realizable within a decade.

Though this baseline design concept applies to lunar missions, such satellites could be used at other locations in the solar system for other missions. For example, they could provide power at the asteroid belt, which is expected to be a source of raw materials for future development in outer space. For Earth itself, they offer pollution-free power for the projected demands of emerging nations in the next several decades.

This work was done by M. D. Williams, Gilbert H. Walker, and D. H. Humes of **Langley Research Center** and J. H. Kwon of Miami University. Further information may be found in NASA TP-2992 [N90-24585/TB], "Diode Laser Satellite Systems for Beamed Power Transmission."

Copies may be purchased [prepayment required] from the NASA Center for AeroSpace Information, User Services Division, Linthicum Heights, Maryland, Telephone No. (301) 621-0394. Rush orders may be placed for an extra fee by calling the same number. LAR-14633



This Power Station in Outer Space would transmit power concentrated into laser beams.


Cut cost and delays: Design and test in a *virtual* lab.

MicroWaveLab™, a 3-D finite element analysis program, acts as a virtual laboratory in which you design and test computer models of microwave structures - just as you would real structures, but without the excessive cost and delays.

MicroWaveLab accurately quantifies the important characteristics of microwave structures, such as: scattering parameters; port impedances; and power losses. Results are easily accessible as X-Y graphs, Smith charts, polar plots, and graphical visualization of electric and magnetic fields.

It's easy to use.

MicroWaveLab features solids geometry, fully automated 3-D meshing, fast and efficient solvers, and microwave component characterization in the format you want.



Applications include:

Connectors...adaptors ... transitions ... cavities ... resonators ... filters... microstrips ... striplines ... and high speed digital circuitry.

MSC: The #1 innovator in FEA for over 30 years.

MSC, the finite element analysis technology leader, spends more than the industry average on R&D, year after year. Listed in Forbes "200 Best Small Companies in

America," MSC is also one of the "200 Fastest Growing Companies."

MicroWaveLab is available on all popular UNIX-based workstations and multi-processing supercomputers. For a video, brochure, or more information, call 800-624-6442.

Simply Powerful™

MicroWaveLab

MSC The MacNeal-Schwendler Corporation

Hardware and Software for Development of Robot Arms

Simulated results of commands can be viewed in three dimensions.

Marshall Space Flight Center, Alabama

A system of modular, reusable hardware and software has been assembled for use in developing remotely controlled robotic arms. The system includes (1) a central computer and its peripheral equipment at a control and monitoring station and (2) a remote mechanical platform that supports a robotic arm. The central computer controls the motor drives of the robotic arm, but optionally, the platform can hold an on-board computer for autonomous operation. The system consists mostly of commercial hardware and software.

The remote mechanical platform is 25 in. (63.5 cm) long, 18 in. (45.7 cm) wide, and 9 in. (22.9 cm) high. It can support equipment weighing a total of 100 lb (45.4 kg). In addition to the robotic arm, the platform holds a stereoscopic pair of color television cameras, equipped with stereoscopic microphones, that are controlled by, and send images to, the central computer. A wireless audio/video-distribution subsystem sends the audio and video signals to the central computer. Another wireless communication subsystem carries command signals from the central computer to the platform over two channels. The commands for each channel are generated by use of a joystick controller. On the platform, proportional motors operate the switches of power motors for steering and propulsion.

The central computer is an IBM-compatible unit with a 486DX2 66-MHz central processing unit, a local bus, a 340MB hard drive, a color monitor, 8MB of random-access memory (RAM), a double-speed compact-disc read-only memory, and two frame grabbers. Each frame grabber accepts signals from one of the television cameras, digitizes them, and stores them in an internal RAM in 1/30 s. Together the two frame grabbers provide live stereoscopic vision with 640-by-480-pixel resolution. Viewing the monitor through a three-dimensional visor, the operator has a sense of full-scale, real-time operation of the remote robot on the platform.


The display is presented in a window by Microsoft Windows software. The multitasking software concurrently provides supporting scene models, driving

guidance, graphics, and auxiliary data. The computer also uses specially developed programs to generate depth maps of scenes and to create simulated three-dimensional scenes in motion.

This work was done by Daniel Usikov of the International Science Exchange Agency for Marshall Space Flight Center.

For further information, **write in 79** on the TSP Request Card.

Inquiries concerning rights for the commercial use of this invention should be addressed to the Patent Counsel, Marshall Space Flight Center; (205) 544-0021. Refer to MFS-26337.




**YOU SAY YOU
NEED QUALITY
ENCLOSURES
FAST?
YOU'LL HAVE
THEM SHIPPED
IN FIVE
WORKING DAYS.**

AMCO is ready to help meet your needs with quality products that get to you FAST! Consoles? Computer desks? Desktop cabinets? Cooling devices? We can ship it to you from stock within 5 working days.

- Among our most popular stock offerings are 19" or 24" panel width vertical or sloped consoles.
- Black frames complimented by a rainbow of colors from gunmetal to cranberry!
- Stock desks and a range of accessories are also available.

Call today for the full AMCO Quick-Ship product line:

1-800-833-3156



See us at ISC Expo, New York, NY
8-29/8-31, Booth #1058

Ask for FREE catalog or application assistance.
There's a local AMCO rep in your area.



Thermoelectric Control of Temperatures of Pressure Sensors

Sensors are heated or cooled, depending on ambient and set-point temperatures.

Langley Research Center, Hampton, Virginia

A prototype controlled-temperature enclosure containing thermoelectric devices has been developed to house an electronically scanned array of pressure sensors. Such an enclosure is needed because (1) the temperatures of the transducers in the sensors must be maintained at a specified set point to ensure proper operation and calibration and (2) the sensors are sometimes used to measure pressure in hostile environments (wind tunnels in the original application) that are hotter or colder than the set point. Thus, depending on the temperature of the pressure-measurement environment, the thermoelectric devices in the enclosure are used to heat or cool the transducers to keep them at the set point.

The enclosure (see figure) includes an aluminum box with walls 0.125 in. (3.2 mm) thick, encased in insulating foam 1 in. (25 mm) thick. The top of the enclosure is removable to provide access to the inside. The temperature in the sensor assembly is monitored, for the purpose of control, by use of a resistance temperature device (RTD). Single-stage thermoelectric heat pumps are thermally bonded and sandwiched between the underside of the aluminum box and a heat-sink plate. The number of thermoelectric devices used is directly related to the number of electronically scanned pressure-sensor modules to be kept at a controlled temperature.


The temperature in the box is controlled by varying the currents supplied to the thermoelectric devices in response to the reading of the RTD: The control circuit is an autotune proportional-plus-integral-plus-derivative (PID) dual-linear-output temperature controller (one output for heating and one for cooling); the outputs of the control circuit are fed to a variable 400-W bipolar dc power supply that, in turn, feeds power to the thermoelectric devices.

The prototype enclosure was tested in a laboratory in two phases. In the

first-phase tests, a dummy electrical heater was used as a thermal load, instead of an assembly of pressure sensors. The second-phase tests were performed with an operational pressure-sensor assembly installed. In these tests, the enclosure was tested in an environmental test chamber in which the temperature was varied from -185 to 60 °C (-301 to 140 °F), while the temperature of the pressure sen-

tubing and associated control wiring were bundled and passed through a slotted aluminum block to the exterior of the box.

Both the laboratory and tunnel tests showed that the temperature in the pressure sensors can be maintained within ± 0.5 °C (± 0.9 °F) of any set point in the set-point range mentioned above (this range of 10 to 30 °C was selected to optimize both the heating



The **Thermoelectrically Cooled or Heated Enclosure** maintains the pressure sensors within ± 0.5 °C of a preset temperature in the presence of wide variations in the ambient temperature.

sors was held at various set points between 10 and 30 °C (between 50 and 86 °F), and the pressure ranged up to 93 kPa (9 atm).

The prototype enclosure was also tested in the National Transonic Facility wind tunnel at the same temperatures and pressures. For these tests, the heat-sink plate was mounted directly on the tunnel wall. Pressure

and cooling capabilities of the thermoelectric devices).

This work was done by Cecil G. Burkett, Jr., James W. West, and Mark A. Hutchinson of **Langley Research Center**, and Robert M. Lawrence and James R. Crum of Wyle Laboratories. For further information, **write in 54** on the TSP Request Card. LAR-15389

42 GB at 12 MB Per Second.



*50 Times the Capacity
of 3490 Tapes*

*168 Times the Capacity
of 3480 Tapes*

*250 Times the Capacity
of 9-Track Tapes*

The CY-9000 1/2" digital tape drive gives you fifty times the capacity and four times the speed of 3490 drives—with a much lower cost per megabyte. Writing data at 12 MB per second, it can store 42 GB in less than an hour. With a 32 MB data buffer, it's the perfect match for the fastest host computer systems running the most demanding storage and data collection applications.

Based on field-proven helical scan recording, the CY-9000 brings capacity and speed together like no other

True Compatibility With:

Alliant	HP	Prime
Altos	IBM	Pyramid
Apollo	ICL	Sequent
Arix	Intergraph	Silicon Graphics
AT&T	Macintosh	STC
Basic-4	McDonnell	Sun
Concurrent	Douglas	Texas Instruments
Convergent	Motorola	Unisys
Convex	NCR	Ultimate
Cray	Parallel Port	Wang
Data General	PC	— and more
DEC	Pertec	
Gould/Encore	Plexus	

solution. With A MTBF of 200,000 hours and a bit error specification of less than one in 10^{17} bits read, reliability and data integrity are also unsurpassed.

The CY-9000 can read and write both 42 GB and 12 GB cartridges, and automatically adjusts for the cartridge in use. A backlit display provides complete status information.

Backed by a one year warranty and the service and technical support of our in-house engineering teams, the CY-9000 is the high speed data storage solution you've been waiting for.

Call today for more information at

(804) 833-9000

CYBERNETICS

Tera One • Yorktown, Virginia 23693 • Fax (804) 833-9300

For More Information Write In No. 596

Stabilizing Optical Path Length on a Vibrating Structure

Interferometry and feedback control reduce path-length disturbances.

NASA's Jet Propulsion Laboratory, Pasadena, California




Figure 1. **Actuators Compensate for Variations** in the length of the interferometric optical path.

The prototype apparatus shown schematically in Figure 1 was constructed to test the feasibility of a feedback control concept for stabilization of the length of the optical path between two points on a vibrating flexible structure. In the original intended application, the structure would be a truss that has dimensions of the order of meters and that supports optical components of a stellar interferometer. The basic requirement upon the feedback control system is to reduce optical-path-length disturbances to the nanometer level to maintain the precision needed for stellar interferometry. This feedback control concept may also prove applicable to other large optical instruments in which it is required to maintain precise path lengths without having to use massive, expensive structures to obtain the rigidity necessary for precision.

Some aspects of the present feedback control concept and the prototype apparatus were described in "Controllable Optical Delay Line for Stellar Interferometry" (NPO-18686), *Laser Tech Briefs*, Vol. 1, No. 1 (September, 1993), page 44 and "Test Bed for Control of Optical-Path Lengths" (NPO-18487), *Laser Tech Briefs*, Vol. 2, No. 1 (Winter, 1994), page 61. In the prototype apparatus, the optical path lies within an interferometer that includes stationary interferometric optical components on an optical bench, plus a retroreflective assembly of optical components on a trolley attached to the free upper end of a tower-like cantilevered flexible structure. The interferometric components on the optical bench measure changes in the length of the optical path, thus providing a feedback signal.

The trolley contains two optical-

path-length actuators; a voice-coil actuator connected between the trolley and the structure, and a piezoelectric actuator that moves a small, flat secondary mirror within the trolley. The piezoelectric actuator is used to compensate for small, high-frequency vibrations. The voice-coil actuator is used to compensate for low-frequency vibrations and keep the trolley positioned so that the desired constant optical-path length lies within the small dynamic range of the piezoelectric actuator. The dynamic response of the optical path length to the piezoelectric-actuator input is not affected significantly by the dynamics of the flexible structure because the mass of the secondary mirror is small and the piezoelectric-actuator stack is balanced for momentum compensation.

The input to the piezoelectric actuator is generated by processing the optical-path-length feedback signal through a digitally synthesized filter that implements a gain and frequency response represented by transfer function $K_1(s)$ (where s denotes the Laplace-transform complex

frequency). The input to the voice-coil actuator is generated by processing the piezoelectric actuator input through a second filter of transfer function $K_2(s)$ (see Figure 2). Unlike in the design of many control systems, the transfer functions are not designed from a parametric model of the dynamics of the structure and actuators: instead, they are synthesized from measurements of the frequency responses of the optical path length to voice-coil-actuator and piezoelectric-actuator inputs. The objective in designing $K_1(s)$ and $K_2(s)$ is to make the closed-loop system stable and make the total loop gain as large as possible over the largest achievable frequency range.

Initial experiments on the prototype showed that the system can reduce, to the level of tens of nanometers, the path-length disturbances caused by forced vibrations at levels of tens to hundreds of microns.

This work was done by John T. Spanos and Zahidul H. Rahman of Caltech for NASA's Jet Propulsion Laboratory. For further information, write in 153 on the TSP Request Card. NPO-19040




Figure 2. The **Feedback Control Loop** is implemented digitally to effect transfer functions with the desired gains and frequency responses based on the measured frequency responses of the system.

POWERFUL SOFTWARE

runs under DOS or Windows and supplies thousands of imaging functions

Programmable with extensive library of processing routines and C object code

VIDEO FORMATS

for all standard and non-standard cameras, CT, MR, Ultrasound medical equipment, and VCRs

HIGH SPEED CAPTURE BOARDS

provide up to 50Mhz sampling and display rates with analog or digital input

On-board DSPs for fast parallel processing of images

IMAGE SEQUENCES

Thousands of buffers with 256 Mbyte configurable image memory

COPROCESSORS

Add up to 550 MOPS for high speed image processing

INTERFACES

for non-standard digital or analog, area scan or line scan cameras

Unmatched Versatility

Imaging Boards

EPIX offers image capture boards in a variety of price and performance levels to suit any application or processing need. Give us a call or fax your specifications and we'll help select the best configuration.

Processing Software

EPIX makes processing and analysis a breeze. Programmable video formats and an extensive object code library offer the C programmer a new world of tools for image manipulation and process automation.

Technical Support

EPIX has many years of scientific and industrial experience. If you have a problem we haven't already solved, it will be a new and welcome challenge.

For unmatched performance in imaging boards and software, CALL or FAX today for complete specifications and pricing.



EPIX, Incorporated
381 Lexington Drive
Buffalo Grove, IL 60089 USA
Tel - 708 465 1818
Fax - 708 465 1919



Replacements for Ozone-Depleting Foaming Agents

Fluorinated ethers can be used in place of chlorofluorocarbons and hydrochlorofluorocarbons.

Marshall Space Flight Center, Alabama

Two fluorinated ethers are being investigated as potential replacements for the chlorofluorocarbon (CFC) and hydrochlorofluorocarbon (HCFC) blowing agents that are now used in the manufacture of polyurethane foam. Replacement is necessary because CFC's and HCFC's have been found to contribute to depletion of ozone from the upper atmosphere, and the manufacture and use of them are required by law to be phased out in the near future.

The two fluorinated ethers in question do not have ozone-depletion potential and can be used in existing foam-producing equipment, which is designed to handle liquid blowing agents that are soluble in the chemical ingredients that are mixed to make the foam. These fluorinated ethers (see table) are $\text{CH}_3\text{CH}_2\text{OCHF}_2$ (called "E245") and $\text{CF}_3\text{CH}_2\text{OCH}_3$ (called "E263"). They are compatible with both the isocyanate and the polyol ingredients of polyurethane foams. E245 is relatively expensive and, when released into the atmosphere, has a characteristic lifetime of about 6 years. E263 is relatively inexpensive and has an atmospheric lifetime of about 2 months. In other respects, their properties are similar.

The gelling times and densities of polyurethane foams made with these fluorinated ethers are similar to those made with CFC-11 and HCFC-141b. Furthermore, the foams made with the fluorinated ethers have superior cellular structures with finer cells. Any polyurethane-based foams and several cellular plastics can be blown with these fluorinated ethers which can be used in processes as diverse as small batch

$\text{CH}_3\text{CH}_2\text{OCHF}_2$ (E245)		$\text{CF}_3\text{CH}_2\text{OCH}_3$ (E263)
Molecular Weight, Daltons	150	114
Specific Gravity	1.146	1.160
Boiling Temperature, °C	29	30
Atmospheric Lifetime	6 Years	2 Months
Flash Point (Temperature in °C)	None	-16 °C
Solubility in Isocyanate, Weight Percent	13	>20
Solubility in Polyol, Weight Percent	No Limit	Between 26 and 50
Relative Cost of Production	High	Low

Selected Properties of Two Fluorinated Ethers are listed to show their suitability as replacements for CFC-11 and HCFC-141b as blowing agents in polyurethane foams.

pours, large sprays, or double-band lamination to make insulation for private homes, commercial buildings, shipping containers, and storage tanks, for example. Fluorinated ethers may also prove useful as replacements for CFC refrigerants and solvents.

Initially, there was concern that the two fluorinated ethers would form peroxides upon aging and exposure to air, even though their long atmospheric lifetimes would seem to preclude this (the long-chain ethers that typically form peroxides have lifetimes measured in hours). Attempts to form peroxides by oxygenating

the materials yielded negative results; that is, no peroxides were detected. Preliminary tests of toxicity showed that these fluorinated ethers should be handled similarly to other ethers—with adequate ventilation, taking account of their anesthetic effects. Other toxic effects, like carcinogenicity (if any), have not yet been investigated.

This work was done by Elana Blevins and Jon B. Sharpe of Martin Marietta Corp. for Marshall Space Flight Center. For further information, write in 95 on the TSP Request Card.
MFS-28805

N-Butane To Replace Trichlorotrifluoroethane

The only significant disadvantage is flammability.

Lyndon B. Johnson Space Center, Houston, Texas

According to a proposal, trichlorotrifluoroethane would be replaced by n-butane as a solvent for removal of oils, greases, hydraulic fluids, and other oily surface contaminants. Trichlorotrifluoroethane is

also called "refrigerant 113," "CFC-113," and variants thereof. It is one of a number of chlorofluorocarbon fluids sold under the trade name "Freon." Trichlorotrifluoroethane must be replaced because, like

other chlorofluorocarbons, it contributes to depletion of ozone from the upper atmosphere. Another factor that motivates replacement is cost: trichlorotrifluoroethane costs about \$127 per gallon

GE TechNotes

Comprehensive Engineering Plastics Technical Data Available On-Line

Complete access to over 1500 pages of up-to-the-minute technical data is now available on-line on the Internet.

Internet users worldwide can navigate within GE Plastics' WorldWideWeb address, www.ge.com, to access:

Global Resources Guide. A quick reference to GE products, services, technical support and worldwide offices.

Product Properties Guides. Individual properties and performance criteria for each GE engineering resin.

Design Guides. Detailed design criteria and suggestions for over 10 resin families.




Processing Guides. Parameters and procedures for molding and finishing processes.

Application Information. The latest press announcements and customer application case studies and photographs.

All available data can be downloaded or printed.

For more information on GE Plastics' on-line interactive system and customized software for simplified access, call today, 1-800-845-0600.

Internet users can navigate through 1500 pages of engineering thermoplastics technical data by accessing the GE system at www.ge.com



GE Plastics

(\$34 per liter, 1994 prices).

N-butane is a candidate replacement fluid because those of its physical and chemical properties that are relevant to use as a solvent are similar to the corresponding properties of trichlorotrifluoroethane. N-butane is also considerably less expensive; it costs about \$5 per gallon (\$1.30 per liter), the exact cost depending on the degree of purity. The only major disadvantage of n-butane is its flammability. As in the cases of other hydrocarbon fluids, the flammability hazard can be

minimized by engineering controls.

In addition to having wetting ability, surface tension, heat of vaporization, and vapor pressure suitable for use as a good cleaner, degreaser and cleanliness-certification solvent, n-butane is noncorrosive and is compatible with metals and soft goods. It also leaves very little nonvolatile residue, exhibits low toxicity, and evaporates about as quickly as trichlorotrifluoroethane does.

Like trichlorotrifluoroethane, liquid n-

butane can be handled easily while wearing normal laboratory attire. It is easily extractable in that it boils at a temperature of -0.5°C . It also exhibits a high degree of filterability, so that it can easily be filtered to obtain a count of particles suspended in it.

This work was done by Paul H. Biesinger of Lockheed Engineering and Sciences Co. for Johnson Space Center. For further information, write in 30 on the TSP Request Card. MSC-22517

Hydrophobic, Porous Battery Boxes

Corrosive, toxic electrolytes are contained safely, while gases are allowed to flow in and out.

Lyndon B. Johnson Space Center, Houston, Texas

Boxes made of porous, hydrophobic polymers have been developed to contain the aqueous potassium hydroxide electrolyte solutions of zinc/air batteries while allowing air to diffuse in as needed for operation. Boxes like these could also be used on other types of batteries for in-cabin use in which the electrolytes are aqueous and from which gases generated during operation must be vented without allowing the electrolytes to leak out. Examples include silver/zinc, alkaline/manganese, nickel/cadmium, nickel/metal hydride, and lead/acid batteries, all of which emit hydrogen.

The predecessors to the present polytetrafluoroethylene boxes were made of nonporous polycarbonate and featured vent holes covered with gas-permeable,

liquid-impermeable caps. These caps were made of polymeric laminates that included porous polytetrafluoroethylene films, and they were bonded adhesively to the boxes. Because of the nature of the materials used, it was difficult and often impossible to make leak-tight adhesive bonds. As a result, the boxes were susceptible to leakage of electrolyte at the vent holes.

A box of the present type is molded in two pieces: one piece comprises the bottom and sides; the other piece is the top. Both pieces are made from a hydrophobic fluorinated polymeric powder, e.g., poly(tetrafluoroethylene) or poly(vinylidene fluoride) powder. The powder is sintered, rather than melted as in injection molding, to give the molded pieces a porous

microstructure similar to that of the polystyrene foam used in some coffee cups. The pores allow gases to pass through, while the hydrophobicity prevents the aqueous electrolyte from passing through.

The two pieces of the box are bonded adhesively by use of an epoxy cement. Epoxies do not ordinarily adhere to smooth poly(tetrafluoroethylene) surfaces, but in this case, the surface is not smooth: The epoxy readily forms a bond to the microscopically rough surface of the porous box material.

This work was done by Bobby J. Bragg of Johnson Space Center and John E. Casey, Jr., of Lockheed Engineering and Sciences Co. For further information, write in 83 on the TSP Request Card. MSC-22389

Temporally and Thermally Stable Iron/Nickel Alloy

High-purity processing imparts an unusual combination of properties.

NASA's Jet Propulsion Laboratory, Pasadena, California


A specially prepared version of a commercial low-thermal-expansion iron/nickel alloy exhibits unprecedented thermal and temporal dimensional stability. Commonly designated by its trade name, Invar 36, this alloy has a nominal composition of 64 percent iron and 36 percent nickel. The special preparation consists of a high-purity powder-metallurgy process followed by a heat treatment. The carbon content of the specially prepared alloy is < 0.01 percent; the content of other impurities is also < 0.01 percent. The high purity of the alloy is essential for its unusual combination of properties.

The coefficient of thermal expansion (CTE) of a typical batch of this alloy is considerably less than $1 \times 10^{-6}/^{\circ}\text{C}$ (see figure), and the rate of relative temporal change in any of its linear dimensions

(essentially, a slow shrinkage) is less than $10^{-6}/\text{year}$. Previously, low CTEs were achieved by thermomechanical treatments that introduced temporal instabilities, so that low CTE and long-term stability have been mutually exclusive.

This work was done by Witold M. Sokolowski, Timothy P. O'Donnell, Marc S. Lane, and Cheng H. Hsieh of Caltech for NASA's Jet Propulsion Laboratory. For further information, write in 13 on the TSP Request Card.

This invention is owned by NASA, and a patent application has been filed. Inquiries concerning nonexclusive or exclusive license for its commercial development should be addressed to the Patent Counsel, NASA Resident Office-JPL; (818) 354-5179. Refer to NPO-19358.



This **Thermal-Expansion Plot** illustrates the exceptional thermal stability of a batch of the specially prepared nickel/iron alloy.

→ The problem with selecting your
lubricant at the *end* of the design
project is that your **competition** picked
theirs at the *beginning.*

**Level The
Playing Field.**



Request your free copy of Nye's new Product & Service Overview today. It's an engineer's guide to solving lubricant related problems quickly – or with a bit of foresight, *a way to avoid them altogether.*



**Call Nye now at
508.996.6721**




See us at
Booth 121

Choose the wrong lubricant for your new design, and problems will turn up sooner or later. Excessive wear. Noise. Evaporation. Oxidation, to name just a few. With luck, you may solve them quickly. Plan ahead, you can avoid them altogether. That's why more and more OEMs and their component suppliers call Nye Lubricants early in the design process. They find a well stocked "synthetic lubricant drugstore" and experienced lubrication engineers who guide their lubricant selection. They receive **evaluation samples**, matched to the demands of their applications and their quality standards. And they capture the competitive advantages that come when you select the right lubricant early on: smoother performance, longer life and a shorter design cycle.

*All for a little lubricant foresight,
and a telephone call to Nye.*

Nye[®]
LUBRICANTS

Specialty Lubricants Since 1844



Computer Programs

COSMIC: Transferring NASA Software

COSMIC, NASA'S Computer Software Management and Information Center, distributes software developed with NASA funding to industry, other government agencies and academia.

COSMIC's inventory is updated regularly; new programs are reported in *Tech Briefs*. For additional information on any of the programs described here, write in the appropriate TSP number.

If you don't find a program in this issue that meets your needs, call COSMIC directly for a free review of programs in your area of interest. You can also purchase the annual *COSMIC Software Catalog*, containing descriptions and ordering information for available software.

COSMIC is part of NASA's Technology Transfer Network.

COSMIC® —

Timothy L. Peacock, Director

Phone (706) 542-3265;

FAX (706) 542-4807

The University of Georgia,
382 East Broad Street,
Athens, Georgia 30602

Computer Programs

These programs may be obtained at a very reasonable cost from COSMIC, a facility sponsored by NASA to make computer programs available to the public. For information on program price, size, and availability, write in the reference number on the TSP and COSMIC Request Card in this issue.



**Mathematics and
Information Sciences**

Genetic-Algorithm Tool for Search and Optimization

SPLICER facilitates the creation of genetic-algorithm application programs.

The SPLICER computer program is a genetic-algorithm tool that can be used to solve search and optimization problems. Genetic algorithms are adaptive search procedures (i.e., problem-solving methods) based loosely on the processes of natural selection and Darwinian "survival of the fittest." The algorithms apply genetically inspired operators to populations of potential solutions in an iterative fashion, creating new populations while searching for an optimal or nearly optimal solution to the problem at hand.

SPLICER provides the underlying software framework and structure for building a genetic-algorithm application program. SPLICER has a modular architecture that includes a genetic-algorithm kernel, interchangeable representation libraries, fitness modules and user-interface libraries, and well-defined interfaces among these components. The architecture supports portability, flexibility, and extensibility. SPLICER comes with all source code and several examples. For instance, a "traveling salesperson" example searches for the minimum distance through a number of cities, visiting each city only once. Stand-alone SPLICER application pro-

grams can be used without any programming knowledge. However, to utilize SPLICER fully within new problem domains, familiarity with C-language programming is essential.

The genetic-algorithm (GA) kernel in SPLICER was developed independent of representation (i.e., problem-encoding), fitness-function, or user-interface type. The GA kernel comprises all functions necessary for the manipulation of populations. These functions include the creation of populations and members thereof, the iterative population model, fitness scaling, parent selection and sampling, and the generation of population statistics. In addition, miscellaneous functions are included in the kernel (e.g., random-number generators). Different problem-encoding schemes and functions are defined and stored in interchangeable representation libraries. This enables the use of the GA kernel with any representation scheme. SPLICER provides representation libraries for binary strings and for permutations. These libraries contain functions for the definition, creation, and decoding of genetic strings, as well as multiple crossover and mutation operators. Furthermore, SPLICER defines the appropriate interfaces to enable users to create new representation libraries.

Fitness modules are the only components of the SPLICER system that a user needs to create or alter to solve a particular problem. Fitness functions are defined and stored in interchangeable fitness modules, which must be created by use of C language. Within a fitness module, a user can create a fitness (or scoring) function, set the initial values for various SPLICER control parameters (e.g., size of a population), create a function that graphically displays the best solutions as they are found, and provide descriptive information about the problem. SPLICER comes with several example fitness modules, while the process of developing a fitness module is fully discussed in the accompanying documenta-

tion. The user interface is event-driven and provides graphic output in windows.

SPLICER is written in Think C for Apple Macintosh computers running System 6.0.3 or later and Sun-series workstations running SunOS. The UNIX version is easily ported to other UNIX computers and requires MIT's X Window System, Version 11 Revision 4 or 5, MIT's Athena Widget Set, and the Xw Widget Set. Example executable codes and source code are included for each machine version. The standard distribution medium for the Macintosh version is a set of three 3.5-in. (8.89-cm) Macintosh-format diskettes. The standard distribution medium for the UNIX version is a 0.25-in. (6.35-mm) streaming-magnetic-tape cartridge in UNIX tar format. For the UNIX version, alternate distribution media and formats are available upon request. SPLICER was developed in 1991.

This program was written by Lui Wang of Johnson Space Center and Steven Bayer of Mitre Corp. For further information, write in 50 on the TSP Request Card. MSC-22009



**Mathematics and
Information Sciences**

System-Availability and Resource-Allocation Program

ACARA can be used to perform many types of analyses and trade studies.

ACARA is a computer program for analyzing availability, life-cycle cost, and scheduling of resources. It uses a statistical Monte Carlo method to simulate the capacity states of a system as well as the failure and repair of components. Failures of components are modeled mathematically by use of a combination of

FEA EASY.




WITH ANSYS® FEA, IT'S EASY TO SOLVE EVEN THE HARDEST PROBLEMS.

Complex design analysis will never be confused with child's play. But with ANSYS FEA, it's easier...faster...and more interactive than ever before.

Not to mention more fun. New users navigate smoothly through ANSYS X-Windows Motif-based GUI, making the program's powerful capabilities easier to learn and apply. Experienced users simply work more efficiently. Underneath the interface is the same comprehensive code that makes ANSYS the industry's leading FEA program, with over 37,000 seats worldwide. Just ask Today's Kids which software worked best to optimize their play slide design. They'll tell you there was no question. It's ANSYS. Call today for more details: 1-800-WE-R-FEA-1 (1-800-937-3321) or visit our WWW site at <http://www.ansys.com>.

ANSYS® ANSYS, Inc.
201 Johnson Road
Houston, PA 15342-1300

ANSYS
REVISION 5.2
IS COMING IN
SEPTEMBER



ISO 9001 CERTIFICATION INCLUDES
ALL COMMERCIAL PRODUCTS

ANSYS FEA model constructed from a Pro/ENGINEER® assembly accurately showed that large, nonlinear deflections tripled the maximum stresses in the slide handrail.

Photograph and FEA model provided courtesy of Today's Kids, Dallas and DRD Corporation, Tulsa.

©1995 ANSYS, Inc. ANSYS is a registered trademark of SAS IP. Pro/ENGINEER is a registered trademark of Parametric Technology Corporation.

For More Information Write In No. 522

exponential and Weibull probability distributions. ACARA schedules replacement of components to optimize the performance of the system. The scheduling can be made to comply with any constraints on the production of components, capacities of resupply vehicles, spares kept on site, crews, and/or equipment.

ACARA is capable of many types of analyses and trade studies because of its integrated approach. It characterizes the performance of a system in terms of both state availability and equivalent availability (a weighted average of state availability). It can determine the probability of exceeding a capacity state to assess reliability and probability of loss of load. It can also evaluate the effect of the constraints upon resources on the availability of the system and its life-cycle cost.

ACARA interprets the results of a simulation and displays tables and charts for (1) performance; i.e., availability and reliability of capacity states, (2) frequency of failure and repair, (3) life-cycle cost, including hardware, transportation, and maintenance, and (4) usage of available resources, including mass, volume, and person-hours spent on maintenance. ACARA incorporates an easy-to-use, menu-driven interface with full screen data entry. It provides a file-management system to store and retrieve sets of input and output data for system-simulation scenarios.

ACARA is written in APL2, using the APL2 interpreter, for IBM PC-compatible computers running MS-DOS. Hardware requirements for the APL2 system include 640K of random-access memory, 2 Mb of extended memory, and an 80386 or 80486 processor with an 80 × 87 math coprocessor. A dot-matrix printer is necessary for printing a graph from a results table. An MS-DOS executable code is also provided on the distribution medium and does not require extended memory, an 80386, or a math coprocessor. It can be used to model systems of limited size. The executable code contains licensed material from the APL2 for the IBM PC product, which is program property of IBM: Copyright IBM Corporation 1988 — all rights reserved. It is distributed with permission of IBM. The standard distribution medium for this program is a set of three 5.25-in. (13.34-cm), 360K MS-DOS-format diskettes. The contents of the diskettes are compressed by use of the PKWARE archiving software tools. The utility software to unarchive the files, PKUNZIP.EXE, is included. ACARA was developed in 1992.

This program was written by L. A. Viterna and D. K. Stalnaker of Lewis Research Center. For further information, write in 39 on the TSP Request Card. LEW-15713



Mechanics

Estimating Noise Levels in an Enclosed Space

Contributions of multiple pieces of equipment at various locations and times are taken into account.

The GEGS Acoustic Analysis Program (GAAP) was developed to compute the composite profile of noise in the Spacelab module on the basis of data on noise produced by equipment, data on locations of equipment, and equipment-operating schedules. The impetus for the development of GAAP was provided by the noise that was generated in the Spacelab Module during the SLS-1 mission because of the concurrent operation of many pieces of experimental and subsystem equipment. The noise produced stress in the crew members. Although GAAP was originally intended specifically to help compute the noise in Spacelab, it is also applicable to any region in which there are multiple sources of noise.

Inasmuch as the composite profile of noise in the Spacelab module is a function of locations of equipment, times of turning equipment on and off, and reverberation characteristics of the enclosure that contains the equipment, a large number of data are generated in an analysis directed toward the generation of such a profile. Therefore, a graphical-interface subprogram was incorporated into GAAP to display the spatial distribution of the noise profile in a three-dimensional plot. The user can specify whether GAAP is to consider the direct sound field only, the reverberant sound field only, or both the direct and reverberant sound fields. GAAP is capable of using either the metric or the English system of measurement units.

GAAP is written in FORTRAN 77. It was originally developed for use on DEC VAX-series computers running VMS, but has also been successfully implemented on UNIX computers, including Sun computers running SunOS and DECstation-series computers running DEC RISC ULTRIX. The program requires 5MB of random-access memory for execution. Because this program puts out files in PostScript format, a means of viewing or printing PostScript files is necessary. The standard medium for distribution of GAAP is a 0.25-in. (6.35-mm) streaming-magnetic-tape cartridge (Sun QIC-24) in UNIX tar format. Alternate distribution

media and formats are available upon request. GAAP was developed in 1992.

This program was written by Elias Azzi of General Electric Government Services for Johnson Space Center. For further information, write in 43 on the TSP Request Card. MSC-22306



Mathematics and Information Sciences

Computing Tolerance Factors and Noncentral t Distribution

This program can be used in place of reference tables.

TF, the Tolerance Factors and Noncentral t Distribution computer program, computes the tolerance factor from a normal-distribution sample for an arbitrarily specified coverage probability, confidence level, and any positive (integer or noninteger) number of degrees of freedom. The program has been used extensively in engineering and quality analyses.

TF is menu-driven and implements four calculation routines: (1) one-sided tolerance-factor calculation; (2) two-sided tolerance-factor calculation; (3) noncentral t probability calculation; and (4) noncentral t percentage point calculation. The unique approach to the noncentral t routines is very computationally efficient. The use of the program compares favorably with the use of standard reference tables in terms of convenience, flexibility, and accuracy of results.


TF is written in Microsoft QuickBasic v2.0, and both an executable and a source code are included in the package. The only requirement for running the included executable code is an IBM PC*-compatible computer with an 80 × 87 math coprocessor. Compilation of the source code depends on the prior installation of the Microway 87SFL Math Function Software Library and MicroSoft QuickBasic V2.0 on the system. The standard distribution medium for this package is a 5.25-in. (13.335-cm), 360K MS-DOS**-format diskette. This program was developed in 1991.

*IBM PC is a trademark of International Business Machines Corporation.

**MS-DOS is a trademark of Microsoft Corporation.

This program was written by Zhaofeng Huang of Rockwell International Corp. for Marshall Space Flight Center. For further information, write in 85 on the TSP Request Card. MFS-29839

FROM SUPERCOMPUTER TO PC




Take the power of CFD into your own hands, the way you work, where you work — at your own desk!

Adaptive's newest version of CFD2000 can meet you on almost any platform: your PC, your workstation, or your supercomputer.

Now, computer simulations of physical processes involving fluid dynamics coupled with heat transfer can be performed on your desktop. With CFD2000™, full 3D viscous Navier-Stokes flow — once achievable only via the supercomputer — is at your fingertips.

As a leader in computational fluid dynamics for over 20 years, Adaptive delivers software with advanced simulation capabilities,

CFD SOLUTIONS *FLOW.*



accomplished through continuous development and application. The results: CFD2000™.

Today's advances in computer memory and computer speed, in conjunction with CFD2000's™ revolutionary advances in numerical methods and user interface graphics tools, provide an enabling technology for designers and analysts who are addressing real problems in engineering mechanics.

Equip yourself with the tools that make engineering solutions flow. Call your Adaptive Technical Sales Engineer today to find out how to solve your design challenges using computational fluid dynamics.



"Adapt or Die."



Long-Lived Linear-Motion Suspension for Cryogenic Instrument

Bearings are located outside the cooled instrument chamber for longer life.


NASA's Jet Propulsion Laboratory, Pasadena, California

A mechanism suspends an optical component in a cryogenic instrument in such a way as to allow the component to translate smoothly along one axis, without vibration. The mechanism allows a maximum stroke of 7 in. (17.8 cm) and has a life expectancy of 10^7 in. (254 km) of travel, which should enable approximately 1.4 million strokes at the full 7-in. amplitude.

The optical component (a corner-cube reflector) and most of the mechanism are located within the cooled instrument chamber. The optical component moves on four rollers, to which it is attached via flexible metal bands that are wound onto the rollers (see figure). Each roller is mounted on a shaft, both ends of which extend to outside the cooled instrument chamber, so that

bearings that support the shafts can be located outside the cryogenic environment for longer life. The shafts also act, in conjunction with the bearing supports, to provide thermal isolation.

This work was done by Douglas T. Packard and Michael L. Agronin of Caltech for NASA's Jet Propulsion Laboratory. No further documentation is available. NPO-19284



Thermal Isolators separate the bearings from the cryogenic environment inside the instrument chamber.

Fatigue-Arrestor Bolts


Interference fits introduce compressive preloads that retard fatigue by reducing the ranges of strains.

Marshall Space Flight Center, Alabama


Bolts that arrest (or, more precisely, retard) the onset of fatigue cracking caused by inelastic strains have been developed. The bolts were specifically developed to be installed in flange

holes of an unrestrained rocket engine nozzle. The flanges in question are sometimes used to bolt the nozzle to the test stand; however, when the rocket engine is operated without this


restraint, the region around the bolt holes experience severe inelastic strains causing fatigue cracking. The flange and bolts are made of an age-hardened nickel alloy, but the basic




Synthetic rubber latches




Butt-joint panel latches



Metal drawlatches



Hook-Lock™ latches



Link Lock® latches

How to draw and hold two panels together.


Southco can help satisfy your design requirements with hundreds of drawlatch options in a wide range of materials, sizes, finishes, colors, and styles.

In fact, there's probably a standard Southco drawlatch waiting to help solve your need to

- provide positive latching • tolerate misalignment • resist corrosion
- withstand UV • absorb vibration
- cushion impact • offer a low profile
- resist tampering • reduce heat transfer
- adjust quickly • reduce rattles.

Southco designs and manufactures a full line of latches and access hardware, offering value-added support such as • **CAD drawing files of our products to facilitate your design efforts** • **factory-trained field sales and engineering service — at your service!** • **product modifications and custom design expertise to provide precisely the solutions you want.**

For more information, or help with satisfying your application needs, contact Southco.




SOUTHCO, INC. • 214 Brinton Lake Road • Concordville, PA 19331
TEL: 610-459-4000 • FAX: 610-358-6314

**ISO 9001
Registered**

Circle no. 532 Call me, I'm interested.

Circle no. 533 Send Information only.

No other thermal imaging system can match it!



HIGH ACCURACY. HIGH RESOLUTION. HIGH SPEED. NOT HIGH PRICE.
Measures temperature at 300,000 points 30 times a second...accurately!

Consisting of a patented* unique near infrared solid state camera, with a digital image processor and PC, the Mikron 9000 Series Imaging Pyrometer* with infrared anti-blooming characteristic, low pattern noise and superior stability is ideal for high temperature process and research applications. It offers these remarkable features and capabilities:

- Exceptionally high spatial resolution: 640 x 480 pixels
- 30 frames/second
- High accuracy
- Temperature range of 500°C to 3000°C
- Sees through glass or quartz ports
- Minimally affected by emissivity
- Versatile image processing software

AND IT'S AFFORDABLE! CALL TODAY FOR MORE INFORMATION.

* Patent No. 4,687,344

445 W. Main St., Wyckoff, NJ 07481 U.S.A.
 Tel. 201-891-7330 • FAX: 201-891-1205



MIKRON®

For More Information Write In No. 417

REPEATED INSERTION & REMOVAL FORCES

Bal Seal springs enable consistent performance despite frequent cycling in connect/disconnect applications

Many applications require that the insertion and removal forces not change over repeated use. The design of Bal Seal's patented canted-coil spring allows the spring to deflect for thousands of cycles without becoming fatigued and without losing its initial force. Numerous standard spring designs provide forces from several grams to several hundred pounds.

Bal Seal springs are available in stainless steels, nickel alloys, and beryllium copper. Coil heights start from 0.015 inch and ring dimensions start from 0.020 inch.

For more information contact the technical sales department at:

Tel: 800-366-1006 • 714-557-5192
 Fax: 714-241-0185




BAL SEAL ENGINEERING COMPANY, INC.


620 West Warner Avenue
 Santa Ana, California 92707-3398



CANTED-COIL SPRING



CONNECT



HOLD

U.S. patent 4,678,210.
 ©1995 Bal Seal Engineering Co., Inc.

principle of these fatigue-arrestor bolts should also be applicable to holes in plates made of other materials and/or used for different purposes.

The rocket engine is generally tested without bolting the aft end of the nozzle (flange location) to the test stand. During ignition, the leading edge of the combustion gas creates pressure differentials on the nozzle shell as it flows towards the exit plane of the nozzle. These pressure differentials cause the circular end of the nozzle to ovalize in a random manner. Any position around




Figure 1. The Crack in the Ligament is typical of fatigue cracks that develop as a result of large cyclic loads applied to the bolthole.

the flange circumference experiences 100 or more stress strain cycles of tension and compression. The holes in the flange generate large stress concentrations (up to 3.6 times the nominal stress) which gives rise to fatigue cracks initiating in the ligament. The ligament is the narrow part of the flange above the bolt holes (see Figure 1). When installed, the fatigue-arrestor bolts retard the fatigue when the engine is operated in this unrestrained condition.

These fatigue-arrestor bolts use interference fit to retard fatigue accumulation. Similar interference fit assemblies have been used in industry to retard elastic fatigue in holes (where the alternating stresses are generally less than 50% the yield strength of the material). During an unrestrained engine start, the unrestrained hole experiences peak strains greater than three times the yield strength of the material. The bolt has a smooth shank made for an interference fit in the bolthole. The amount of the interference fit [the diameter of the bolt shank exceeds the 0.250-in. (6.35-mm) diameter of the bolthole by 0.0011 to 0.0020 in. (0.028 to 0.051 mm)] has been optimized by

experiments. The bolt is cooled in liquid nitrogen to shrink it, then quickly pressed into place in the bolthole before it warms up and expands to full size. The bolt is also held in the hole by a self-locking nut (see Figure 2).

The interference fit places the surrounding flange material under a compressive stress. This reduces the range of strains experienced by the ligament and thereby extends the low cycle fatigue life of the ligament. The concentrations of stress that would ordinarily occur around a hole in a plate are virtually eliminated for compressive loads, and are believed to be reduced for tensile loads as well. The interference fit causes the surrounding material to behave as though no hole exists until the tensile stress exceeds the compressive stress at the interface between the bolt and the hole.

The increase in fatigue life afforded by the fatigue-arrestor bolts was demonstrated by stress cycling of identical specimens with and without fatigue-arrestor bolts installed in the holes. Of twelve specimens tested with fatigue-arrestor bolts, the lives increased by factors ranging from 8.9 to more than 90. The wide variation in these observed values is attributed to the difficulty of reproducing identical interference fits and to the use of different strain ranges.

This work was done by Joseph W. Onstott, Mark Gilster, Sergio Rodriguez, John E. Larson, Mark D. Wickham, and Kevin E. Schoonover of Rockwell International Corp. for Marshall Space Flight Center. For further information, write in 74 on the TSP Request Card. MFS-30068





Figure 2. The **Interference Fit** of the bolt shank in the hole reduces fatigue by reducing the range of strains in the material surrounding the bolthole.

Videotape your high resolution computer graphics and animation with

HyperConverter®



HyperConverter1024...

from \$1395

input up to 1024 x 768 from PC and Mac

HyperConverter1280...

from \$2995

input up to 1280 x 1024 from PC, Mac, SUN, SGI, HP, DEC, IBM, E&S

HyperConverter enables you to:

- Easily and economically record your high resolution computer graphics on professional and consumer video recorders
- Show your computer-generated presentations on large screen TVs and video projectors
- Produce broadcast quality composite (NTSC/PAL), Y/C (S-VHS) and component (RGB/YUV) video signals



PC Video Conversion

1340 Tully Road Suite 309 San Jose CA 95122 Tel 408.279.2442 Fax 408.279.6105

For More Information Write In No. 410

"For the price, there isn't anything else around that can touch the HyperConverter in performance or quality"

Charlie Reis Advanced Imaging Magazine November '93



The new Hitachi HV-C20 provides a breakthrough in 3-chip color camera performance. Newly developed C-mount prism optics allow a much smaller and less expensive total package. Consider these features:

- 3 - 1/2" IT CCDs
- 700+ line resolution
- 60dB S/N ratio
- f8.0 at 2000 lux
- AGC
- C-mount lenses
- Extremely small size
- Integration up to 60 fields
- Field on Demand (FD)
- Computer control

Call for a demonstration

Hitachi Denshi America, Ltd.

▲ New York 516-921-7200

▲ Los Angeles 310-328-6116

▲ Atlanta 404-242-3636

▲ Dallas 817-488-4528

▲ Chicago 708-250-8050

▲ Canada 416-299-5900



Auxiliary Control Mechanisms for RUM Actuators

Weights, power demands, and costs would be reduced.

Marshall Space Flight Center, Alabama

Improved auxiliary control mechanisms for rotating-unbalanced-mass (RUM) actuators have been proposed. A RUM actuator is a proposed device that would be mounted on a gimballed, pivoted, or freely floating instrument and used to make the instrument oscillate about one or more axes. A RUM actuator would include one or more (typically, two) unbalanced masses (e.g., lump masses on arms) for each axis about which oscillation is desired. The unbalanced masses would be driven to rotate at constant angular velocity to produce oscillating centrifugal forces, which, in turn, would exert cyclic torques that make the instrument oscillate about the desired axis. RUM actuators could be used in both terrestrial and spacecraft applications: for example, to oscillate instruments as diverse as x-ray telescopes, magnetometers, accelerometers, and agricultural spraying nozzles in a variety of scan patterns that could include linear, circular, and raster.


An auxiliary control mechanism for a RUM actuator would serve to position and reposition the central coordinate about which the oscillating motion is produced. In the case of a line scan, it could be used to establish the midpoint of the line. In the case of a raster scan, it could produce the relatively slow motion along one raster axis while the RUM actuator would produce the faster oscillating motion along the perpendicular raster axis.

The figure illustrates schematically an instrument equipped with a RUM actuator for oscillation about a single axis to produce a line scan, plus a simple auxiliary control mechanism of the proposed type. The basic components of the auxiliary control mechanism would be a stepping motor, a speed-reducing (torque-increasing) gear train, and an angular-position encoder. The stator of the stepping motor would be mounted on a stationary supporting structure, while the motor would be connected to the low-torque input shaft of the gear train.

The high-torque output shaft of the gear train would lie on the axis about which the instrument is to be oscillated and would be connected to the instrument via a torsionally flexible coupling.

The encoder would monitor the angular position of the high-torque shaft. Driven by the RUM actuator, the instrument would oscillate torsionally, via the flexible coupling, about the angular position of the high-torque shaft. The holding torque of

ness of the flexible coupling would be chosen so that the resonant frequency of torsional oscillation of the instrument would equal the derived scanning frequency. Adjustable trim masses could be added to enable tuning to resonance and



The **Proposed Auxiliary Control Mechanism** would make it possible to design a smaller, cheaper, more energy efficient rotating-unbalanced-mass actuator.

the stepping motor, amplified by the gear train, would suffice to prevent the high-torque shaft from slipping out of the commanded center-of-scan position.

In a preferred version, the torsional stiff-

dampers could be added for stability. The resonance would amplify the effect of the RUM actuator (the dampers would reduce the amplification effect somewhat) so that the same scanning motion could be

achieved with smaller unbalanced masses. With smaller masses, the RUM actuator would consume less power: numerical examples from representative design cases suggest that RUM actuators equipped with auxiliary control mechanisms of this type could consume less power than do equally capable RUM actuators of older design, and as little as 1/100 the power of scanning mechanisms based on gimbal torque actuators.

The proposed auxiliary control mechanism as described thus far could be operated manually, in a quasi-open-loop fashion: A human operator would monitor the angular position of the high-torque shaft and issue step commands until the desired center-of-scan position was attained. No further adjustment or monitoring would be needed until it would be necessary to establish a different center-of-scan position. Alternatively, the stepping motor could be operated under angular-position-feedback control.

In comparison with previously designed RUM auxiliary control mechanisms, the proposed RUM auxiliary control mechanisms would be simpler and cheaper. They would be particularly suited for applications in which it is permissible to sacrifice some scanning precision for the sake of reducing weight, cost, and power consumption. In some cases, the reduction in power demand may make it feasible to use small batteries or solar cells as the sources of power.

This work was done by Michael E. Polites and Dean C. Alhorn of **Marshall Space Flight Center**. For further information, **write in 8** on the TSP Request Card.

This invention is owned by NASA, and a patent application has been filed. Inquiries concerning nonexclusive or exclusive license for its commercial development should be addressed to the Patent Counsel, Marshall Space Flight Center; (205) 544-0021. Refer to MFS-28817.

Universal Controller for Supersonic Engine Inlet

Engine-demand airflow is used as the primary control parameter.

*Ames Research Center,
Moffett Field, California*

In a developmental method of controlling the variable air inlet of an engine in an advanced supersonic airplane, engine-demand airflow is used as the primary


control parameter. In general, the optimum inlet angle depends on such other variables as the mach number, altitude, and ambient temperature. The optimum inlet angle as a function of these variables can be approximated by a schedule (the "inlet ramp schedule") of digitized values that can be implemented by a digital control system.

Research shows that the inlet ramp schedules of different engines that could be installed in the same supersonic airplane can all be corrected with engine-demand airflow. More specifically, the research shows that the optimum inlet angle depends primarily on the engine-

demand airflow and is good for all altitudes and ambient temperatures. Thus, one can develop a simple inlet ramp schedule of inlet angle as a function of engine-demand airflow. This approach offers the following advantages:

- The design and installation of upgraded engines require few or no changes in the hardware and software of air-inlet controllers.
- Fewer air-inlet controllers are needed in the field.
- The probability of installing the wrong air-inlet controller is reduced.
- The maintainability and supportability of the airplane is enhanced.

3-D RAPID PROTOTYPING • REVERSE ENGINEERING • MODELING • ANIMATION



WITH

SAC's New GP-12 3-D DIGITIZER

The most versatile, easy-to-use 3-D digitizer available. Capture 3-D data in real time from any solid object within an active volume of up to 8 ft. x 8 ft. x 8 ft. (512 cubic feet). It's easy to use, just unpack — plug it in — and type "install". Place the probe on the point(s) to be entered and you're capturing X, Y, Z Cartesian coordinates.

SOFTWARE-HARDWARE COMPATIBILITY • The GP-12 works with all popular CAD/CAM packages and PC platforms, and comes equipped with its own TSR (Terminate and Stay Resident) driver. Special packages are available for modeling/animation with HyperSpace™ software from Mira Imaging and CAM programs from Cutting Edge™. These packages provide complete turnkey solutions to increase your productivity.


THE MOST FLEXIBLE 3-D DIGITIZER AVAILABLE • It's portable, works in any environment, digitizes any material, and has easy RS-232 interface. Ideal for reverse engineering . . . acquiring 3-D data from prototypes . . . defining tool paths . . . generating data for 3-D graphics, plus applications only limited by your imagination.

SEE HOW THE GP-12 CAN PUT YOU INTO THE WORLD OF 3-D. CALL TODAY.

SAC SCIENCE
ACCESSORIES
CORPORATION

2 Research Drive, P.O. Box 825
Shelton, CT 06484
(203) 925-1661 Fax (203) 929-9636

Melles Griot makes 40 Watt HeNe Lasers



What's special about a HeNe? How about more than **40 Watts** of circulating power? For very special applications, we offer Brewster window HeNe tubes fitted with very high reflectivity, ultra-low scatter/absorption/transmission mirrors. Their application?

- Particle measurement systems
- Raman spectroscopy
- Gas flow measurement

If you have a need for very high intracavity power in a robust, rotationally stable package all for a truly low price, join the many users that have purchased almost two million lasers from Melles Griot.

Call or FAX for a quote!

MELLES GRIOT

Laser Division • 2251 Rutherford Road
Carlsbad, CA 92008 • **1(800) 645-2737**
(619) 438-2131 • FAX (619) 438-5208

Canada (613) 226-5880	Denmark 5361 5049	France (01) 3012-0680	Germany (06251) 84060	Japan (03) 3407-3614
Netherlands (0316) 333041	Singapore 743-5884	Sweden (08) 630-8950	Taiwan (035) 729-518	United Kingdom (01223) 420071

*This work was done by William A. Yonke, Daniel L. Robben, and Steve G. Nobbs of McDonnell Douglas Corp. for **Ames Research Center**. For further information, **write in 49** on the TSP Request Card.*

This invention is owned by NASA, and a patent application has been filed. Inquiries concerning nonexclusive or exclusive license for its commercial development should be addressed to the Patent Counsel, Ames Research Center; (415) 604-5104. Refer to ARC-13193.

Special-Purpose Robotic Welder

Cooling bars presented a unique design problem.

*Marshall Space Flight Center,
Alabama*

A robotic-welding apparatus has been developed for use in repairing the main combustion chamber of a rocket engine. Despite its special purpose, this apparatus has design features that would be beneficial in other robotic-welding applications; for example, the manufacture and repair of pressure vessels, chemical-processing vessels, and the like.

In the rocket-engine application, cracks and pinholes in the hot surface of the chamber are welded closed. During the welding process, copper bars are used to cool the area around the pool of molten metal. It was difficult to design brackets to support the robot arm, the robotic end effector with the welding torch, a wire feed-guide and manipulator, a camera, and positioning hardware so that none of these components would collide with or interfere with the cooling hardware. This design problem was solved by iterative application of computer-aided design techniques.

Each of the primary components of the apparatus is electrically insulated from the others by use of fiberglass brackets. The wire-feed guide is mounted at an angle to a micrometer-slide positioner to provide accurate, repeatable placement of the wire-feed guide with respect to the torch. The camera is also mounted at an angle to the positioner. The angles are necessary to provide adequate visual access to the weld pool during operation.

*This work was done by David C. McFerrin, J. Ben Coby, Jr., Kenneth J. Gangl, David S. Hoffman, and Sidney G. Dawson of Rockwell International Corp. for **Marshall Space Flight Center**. For further information, **write in 56** on the TSP Request Card. MFS-30020*

FEDERAL LAB

LASER

TECH BRIEFS

REPORTING THE LATEST FEDERALLY-DEVELOPED PHOTONICS TECHNOLOGY

- **LASERS • OPTICS**
- **ELECTRO-OPTICS**
- **IMAGING**
- **FIBER OPTICS**
- **SENSORS**


SITe DELIVERS NEW SOLUTIONS

For more than twenty years, the SITe team has been pushing CCD technologies to the limits with integrated digital solutions that have the industry's highest quantum efficiency, sensitivity, contrast range and resolution. These are our latest solutions.



Fiber Optic CCD Imagers

SITe fiber optic imagers are designed specifically for electronic imaging applications. Using either a tapered fiber optic coupler or a window as a substitute for a lens results in high transmission efficiency, increased field-of-view and low distortion.




TE Cooled CCD Imagers

SITe two stage thermoelectrically (TE) cooled CCDs have been developed for applications requiring thermal stability, large formats, high sensitivity, and low noise. These devices provide a hassle-free solution to CCD thermal management.

Solutions that work

The greater the quantum efficiency the *more information* realized to the users. SITe thinned, back-illuminated CCDs achieve greater than 85% QE throughout the visible spectrum and allow for imaging in the ultraviolet. The increased QE of SITe detectors also allows for reduced system costs by maintaining superior detectability with lower cost optics, electronics, and other system components.

Call us today for more information about our complete line of digital electronic imaging products. Our technical staff will assist in each stage of your system development.



Scientific Imaging Technologies, Inc.
P.O. Box 569 Beaverton, OR. 97075-0569
Tel: 503/644-0688 Fax: 503/644-0798

NASCA TECH BRIEFS

Federal Lab Laser Tech Briefs Supplement to *NASA Tech Briefs* August 1995 Issue Published by Associated Business Publications

LASER TECH BRIEFS

- 6a Fiber-Powered Electronic Sensors
- 8a A High-Power Pulsed Ultraviolet Laser System
- 8a Ho:Tm:Lu₃Al₅O₁₂ as an Infrared-Laser Material
- 12a Ultraviolet Source for Testing Hydrogen-Fire Detectors
- 13a Ammonia and Ethylene Optodes for Research on Plant Growth
- 14a Laser Velocimeter for Use on Helicopter Rotor
- 16a A Photonically Based Receive Signal Combiner for RF Phased Arrays
- 17a A Microwave Tapped Delay-Line Filter Using High-Dispersion Fiber

FEATURES

- 3a Moving Closer to the Sun's Power
The Omega laser at the University of Rochester

DEPARTMENTS

- 2a Editorial Notebook
- 19a New Literature
- 20a New Products

On the cover:

Engineers at the Chemical Vapor Deposition Facility at NASA's Langley Research Center use lasers to test the effects of heating on the flow of gas through a chemical vapor deposition reactor. The reactor, from the University of Virginia, is used to grow crystals for such uses as laser diodes. *Photo courtesy of NASA Langley Research Center*

* Thin-Film Photovoltaics * Flat Panel Displays * Electrochromic Devices * EMI/RFI Shielding * Anti-Static Coatings * Bar-Code Scanners * Copier Cover Plates * IR Reflecting Windows *

Imagine what you could do with a very special, transparent float glass that . . .

- Conducts electricity . . . with a wide range of available resistance
- Has a transparent, color-neutral coating (with excellent optical properties) bonded to the surface of the glass while it's still in its molten state
- Has high infrared heat reflectance
- Features a durable, abrasion-resistant surface that stands up to conditions that would quickly mar or scratch ordinary glass

That's Transparent Electrical Conducting (TEC) Glass . . . developed by Libbey-Owens-Ford Co. and produced by our patented, on-line chemical vapor deposition technology.

In fact, innovative engineers have already found a wide range of applications for TEC-Glass, including:

- Thin-Film Photovoltaics
- Flat Panel Displays



Imagine what
you can do with
TEC-Glass...

- Electrochromic Devices
- EMI/RFI Shielding
- Anti-Static Coatings
- Bar-Code Scanners
- Copier Cover Plates
- IR Reflecting Windows
- Heat-Reflecting Self-Cleaning Oven Doors
- Defrosting Refrigerator and Freezer Doors
- Solar Heating
- Security Systems

Now, imagine what you can do with TEC-Glass.

For specifications and additional information, just circle the reader response number, or write us.

Because the possibilities are limited only by your imagination.



Libbey-Owens-Ford Co.
Specialty Glass Products
811 Madison Avenue P.O. Box 799
Toledo, OH 43697-0799
419-247-4724

©1994 Libbey-Owens-Ford Co.

EDITORIAL NOTEBOOK

News of the Industry and Federal Labs

• Uniphase Corp., a San Jose, CA, manufacturer of HeNe, argon-ion, and diode lasers, acquired United Technologies Photonics (Bloomfield, CT), a division of United Technologies that supplies the cable television and long-haul telecommunications industries with integrated lithium niobate optical modulators for digital transmission of light signals through fiber optic cable. According to Kevin Kalkhoven, Uniphase's president and CEO, the company aims to repeat its success with the 1992 subsidiary Ultrapointe Corp., maker of a 3D imaging system for microcircuit defect detection and analysis. The new subsidiary will retain its acronym—it becomes Uniphase Telecommunications Products—as well as its location and current management. Among the latter is Vice President and Chief Technical Officer Fred Leonberger, who points to UTP's technological edge in its external modulation design and the advantage its waveguide technology will lend to Uniphase's developmental program in solid-state blue-emitting lasers.

• Optical Research Associates (Pasadena, CA) received NASA's Public Service Group Achievement Award, the only nongovernmental independent entity to be honored this year. The company was recognized for the role its Code V optical design software and engineering services played in the Hubble Space Telescope repair mission. The award certificate, signed by NASA Administrator Daniel S. Goldin, cites "outstanding contributions" in support of the Jet Propulsion Laboratory and NASA space exploration missions.

• SpecTran Corp. (Sturbridge, MA) announced completion of its purchase of Applied Photonic Devices (Danielson, CT), a privately owned manufacturer of high-performance fiber optic cable. Raymond E. Jaeger, SpecTran's president and CEO, commented that the APD acquisition furthers "our long-term strategy to...diversify the optical fiber-based products we manufacture."

• Laser Science Inc. (Newton, MA) has delivered a unique laser system for measuring atmospheric trace gases to the National Institute for Environmental Studies (NIES), a division of the Japanese Environmental Agency. The instrument is based on a pair of CO₂ lasers that will aim their pulses at a mirror located on a satellite, which will return signals for collection

and analysis. The mirror will be attached to the Advanced Earth Observing Satellite, to be launched by the Japanese government early next year. Laser Science organized the engineering team to deliver and assemble the system.

• The Center for Optics Manufacturing (Rochester, NY) has been granted \$3 million by the Department of Defense to continue work in cooperation with its industry membership in advancing precision optics manufacturing technology. The American Precision Optics Manufacturers Association founded the Center in 1990 to develop computer-automated lens-making machinery to bolster US competitiveness in optics fabrication and thus halt the erosion of the domestic manufacturing base.

• Laser Photonics (Orlando, FL), recently acquired by Helionetics Inc. (Irvine, CA), is to absorb Helionetics' AccuLase medical subsidiary, the parent company announced. The move will bring under the Laser Photonics scientific/medical umbrella AccuLase's excimer-laser and proprietary fiber-optic-catheter technology, currently employed in laser angioplasty and transmyocardial revascularization. Steve Qualls, Laser Photonics' COO, noted that AccuLase has limited manufacturing capability, but that Laser Photonics is "an approved GMP medical laser manufacturer with excess production capacity."

Big Lasers...Small Packages

People often call us and say, "You're the company that builds small lasers." We prefer to think of it another way. We build big lasers...we just put them in small packages.

New! Model CFR 200/MINICE

Applications:

- LIDAR
- Environmental Sensing
 - Ranging
- Spectroscopy
- Material Science

Specifications:

- 200 mJ @ 1064 nm
- 100 mJ @ 532 nm
- 12 nsec; 20 Hz
- Environmentally Sealed
- Compact, Portable



Your Source for Compact, Rugged Lasers

phone 406-586-0131 fax 406-586-2924 PO Box 8100
Bozeman, Montana 59715 e-mail BigSkyLasr@aol.com



To discuss your specific application, call 1-800-2-BIG-SKY

MOVING CLOSER TO THE SUN'S POWER

The Omega laser at Rochester's Laboratory for Laser Energetics steps out front in the quest for fusion energy.

In June the Laboratory for Laser Energetics (LLE) at the University of Rochester took a commanding position in the nation's effort to harness the process that powers the Sun and stars for a reliable energy source on Earth. When the newly revamped Omega went on line, it became the world's most powerful ultraviolet laser and a key resource in inertial confinement fusion research, the avenue scientists hope will lead to a novel and virtually inexhaustible supply of power for the future.

The \$61-million Omega, funded by the Department of Energy, puts Rochester at the forefront of the effort at direct-drive fusion, in which lasers directly illuminate, heat, and compress isotopes of hydrogen to generate energy. This new system enables scientists to study more closely than ever before the conditions needed to ignite and sustain a fusion reaction, and is expected to be an important precursor of the National Ignition Facility (NIF), scheduled to be completed later this decade (see *Laser Tech Briefs*, April 1995, page 6a). A joint project of scientists at Rochester, Lawrence Livermore, Sandia, and Los Alamos laboratories, the

NIF will be the biggest laser fusion machine ever built. The Department of Energy has designated Livermore as the preferred site for NIF and is seeking funds to begin construction next year.

The Omega system is a 30-kJ pulsed Nd:glass laser emitting a frequency-tripled beam at 351 nm. In boosting the football-field-sized Omega to its present capacity, engineers increased its energy output by a factor of 25, making it the world's most powerful ultraviolet fusion laser. It exceeds the present capacity of Livermore's indirect-drive Nova system, whose beams are converted to x-rays before hitting the target. But though it was designed primarily for direct-drive experiments, research with Omega is expected to help physicists understand phenomena of both methods. And since DOE has designated LLE the National Laser Users' Facility, scientists from all over the country will be able to use it to conduct high-energy laser experiments.

In direct-drive fusion research, Omega will be used to explore target physics at near-ignition conditions, with ion temperatures in excess of 2-3 keV and fuel density/radius products of more than about


2 g/cm²; to investigate the hydrodynamics of energy-scaled high-performance targets; and to perform laser-plasma interaction experiments relevant to direct-drive target implosions.

Hotter than the Sun

After the laser creates it, Omega's beam is amplified and expanded many times, travelling a total of more than 500 feet and splitting into 60 beams before reaching the target. Housing the hydrogen target is an aluminum chamber 11 feet in diameter, with ports for several diagnostic instruments as well as for the beams, which are reflected by mirrors around the structure into the chamber. Each of Omega's beams is aimed to hit a specified section of the target with an accuracy of within 25 microns.

In the target chamber, the beams converge on a plastic or glass cylinder less than a millimeter wide filled with deuterium and tritium, two isotopes of hydrogen. The beams ablate the target's shell and implode the thermonuclear fuel to obtain pressures and temperatures high enough to fuse the isotopes.

Inside the chamber, temperatures can



The Omega laser driver line and injection optics along with portions of the laser system are seen in a view looking southwest in the laser bay.

reach up to 50 million °C, hotter than the inside of the Sun. Because of such elevated temperatures, Omega's glass, mirrors, and lenses need some time to cool down between shots. Therefore the laser can be operated just once per hour.

As the atoms of the target fuel fuse, they give off energy in the form of neutrons, which can be used to generate electricity. But for fusion to be useful as an energy source, it must reach what researchers call "scientific breakeven:" that is, the energy to emerge from the fusion reaction must be greater than what is needed to create it.

Two Decades of Advances


LLE's credentials for reaching the goal of inertial confinement fusion are many. As long ago as 1976, LLE's materials group led the development of high-gain, low-index-of-refraction phosphate laser glass for Nd:glass laser systems. In 1980, LLE scientists developed a method of converting Omega's laser light from the infrared to the ultraviolet, which is absorbed more efficiently by a pellet of fuel. Called polarization mismatch, this blue-light conversion method has since been adopted by all high-power solid-state ICF programs in the world. According to Stephen Jacobs of LLE, polarization mismatch has increased the effectiveness of Omega as a fusion driver by a factor of ten. LLE engineers completed conversion of the Omega to 351-nm operation in 1985.

In 1989, LLE announced its pioneering beam-smoothing technique to produce more uniform beam profiles for its frequency-tripled laser systems. Called smoothing by spectral dispersion (SSD), the method reduced the variations in illumination of a pellet from 30 percent down to just a few percent. SSD has since been implemented on Lawrence Livermore's Nova laser.

Reaching Out to Industry

As part of the University of Rochester's outreach program, LLE has collaborated with industry and government in technology development. Companies which have contributed resources include the Empire State Electric Research Corp., Exxon Research and Engineering Co., Clark/MXR, Spectra-Physics, Rochester Gas and Electric, General Electric, and Standard Oil Co. In addition to DOE support, the New York State Energy Research and Development Authority has contributed important backing.

LLE scientists hold more than 63 patents in such fields as laser amplifiers, active mirrors, fusion target fabrication and coating, ultrafast switching, x-ray lithography, and liquid crystal devices.



The Omega upgrade is an image-relayed system with three laser drivers, six amplification stages, and frequency conversion. Ninety-seven percent of beam energy is furnished by the last three amplifiers.


The laboratory has issued 14 licenses for the use of these patents in producing commercial products.

As the National Laser Users' Facility, LLE provides researchers with unique capabilities for experiments in high-energy-density physics, as well as such other areas as plasma physics, x-ray laser physics, extreme ultraviolet spectroscopy, and instrumentation development. Laboratory staff includes 191 professional, technical, and administrative personnel,

and more than 100 graduate and undergraduate students from the university's optics, physics, and engineering departments participate in LLE programs.

Hailing the Omega upgrade, Victor H. Reis, Assistant Secretary for Defense Programs at the Department of Energy, called it "a highly flexible world-class laser that will serve the inertial fusion program well for many years....The laser was on time and on budget. The department is proud of this, the newest of our facilities."

L7B



View of target shot in the Omega's target chamber.




Photo courtesy of Schwartz Electro-Optics, Inc.

Your laser is vital to your work... why trust just any chiller to cool it?

At NESLAB, we have over 30 years experience in the temperature control business. As the original designer of recirculating chillers, our reliability data speaks for itself. Our progressive manufacturing standards, including ISO 9001 Registration, ensure that you receive the highest quality equipment, time after time. And, our commitment to customer satisfaction and continuous improvement have helped establish NESLAB as the industry leader.

Quality Engineered Products

As a quality conscious organization, we drive product reliability down to the production level. In addition, much of our equipment is designed to the standards of IEC, UL, Semi and CSA certifications, making us the worldwide choice for precision temperature controlled apparatus.

Product features that you can use

We've designed our recirculating chillers to give you more of the features you need and want. NESLAB chillers feature:

- Ozone friendly refrigeration system
- 24 hour, continuous duty operation
- Hot Gas Bypass control system
- Stainless steel reservoir and heat exchanger
- Extensive custom designs

World Class Service

NESLAB maintains sales and service offices around the globe. These direct locations offer technical assistance from factory trained professionals. Our service depots are fully staffed and supplied for rapid repairs. You can feel confident that you will get prompt assistance when you need it.

Temperature Control for the 21st Century



800/258-0830, Ext. 300



NESLAB Instruments, Inc.
P.O. Box 1178
Portsmouth, NH 03802-1178
603/436-9444 Fax 603/436-8411

For More Information Write In No. 451

LASER TECH BRIEFS

Fiber-Powered Electronic Sensors

New sensor circuit provides an alternative to fiber-based sensors in some applications.

EG&G Energy Measurements, Los Alamos Operations, Los Alamos, New Mexico

Electronic sensors powered by fiber optics may be a low-cost off-the-shelf alternative to fiber-based sensors in some applications. While using less expensive electronic equipment, the system has a totally fiber-based connection between a sensor and a data-recording device, offering electrical isolation between the sensor and the station receiving the data. This greatly reduces the introduction of potentially damaging noise spikes into sensitive circuitry. The availability of low-power integrated circuits developed for the cellular telephone and laptop computer markets helped make this possible, but the introduction of high-efficiency gallium arsenide photovoltaic converters made it practical.

Researchers at EG&G Energy Measurements' Los Alamos Operations—a Department of Energy contractor—are developing the fiber-powered electronic sensors. Their circuits are powered by light from a fiber optic cable connected to a small laser. The circuit will deliver the desired 3.3 V at 10 mA to a low-power data acquisition circuit. The total conversion efficiency is 40% at this time. Instead of using a boost-topology switcher to step up 2 V to 3.3 V, in labo-

ratory tests a shunt regulator followed by a voltage doubler proved superior. The startup currents of the boost-topology switcher were very high, causing startup failure at heavy loads. Also, the efficiency of the switcher was about 83% compared with about 95% for the voltage-doubler circuit.


Noise is a major design consideration at low operating voltages. Noise spikes from the boost-topology switcher's inductor were being coupled into the A/D circuitry, but the voltage doubler did not produce spikes, and its ramp-shaped ripple (as compared with a spike) was easy to filter.

The photovoltaic converter is shunt-regulated at 1.65 V, which is very close to the optimum power-out point of the V-I output characteristic curve for this 2-V (open circuit voltage) converter. If it was replaced by the 6-V version of the converter and linearly regulated to 5 V, or stepped down with a buck-topology switcher, the resulting circuit would not operate at the optimal power point of the 6-V version's V-I curve for the output current target of 10 mA; the 6-V part has a higher internal impedance. The circuit was used to power a Motorola 68HC05 central processing unit (CPU) connected

to an Analog Devices AD7714 A/D converter and driving a Brown Boveri fiber-coupled light-emitting diode with the data from the CPU UART. The circuit draws 4 mA at 3.3 V, running at a CPU clock rate of 2.4 MHz and a rate of 9600 baud. Up to 6 mA of current can be allocated to power the sensors feeding the A/D and still remain within the bounds of the 10-mA current budget.

This technology could benefit the automotive industry by reducing ignition noise during tests, and the electrical power industry by allowing experiments and testing in high-voltage areas. In medicine, it would be a way to isolate patients from wall current and thus from both electrical interference and the potential dangers of equipment failure.

This work is being done by Noor Khalsa and Ron Ramsey at EG&G Energy Measurements' Los Alamos Operations. For more information, contact Bruce Whitcomb, Director of EG&G Energy Measurements' Office of Research and Technology Applications, at (702) 295-3164. Inquiries may also be addressed to EG&G Energy Measurements, PO Box 1912, Las Vegas, NV 89125.



Circuit diagram for the fiber-powered electronic sensor.

From 20 Watts to 25kW.

From CO₂ to Nd:YAG.

From fiber optic beam delivery systems to weld joint design to metallurgical analysis.

From compact diffusion-cooled CO₂ lasers to high power CW Nd:YAG lasers.

From cutting to drilling.

From welding to microwelding to reflow soldering.

From cladding to marking.

From automotive to aerospace to electronic applications.

From one company.



That company...

THE POWER OF LIGHT

ROFIN SINAR

L A S E R

A SIEMENS Company

Rofin-Sinar, Inc. • 45701 Mast Street, Plymouth, MI 48170 • 313/455-5400, FAX: 313/455-2741

For More Information Write In No. 455

A High-Power Pulsed Ultraviolet Laser System

Ultraminiature Q-switched solid-state lasers have switching and analysis applications.

AlliedSignal Aerospace, Kansas City Division, Kansas City, Missouri

The Laser and Electro-optical Engineering Group at the AlliedSignal Kansas City Plant, operated for the US Department of Energy (DOE), has combined its solid-state laser technology with frequency-conversion technology to develop laser systems for switching high-voltage electronics. The application shows promise in laser spectroscopy. The compact, rugged lasers are designed to survive and operate in extreme mechanical and thermal environments.

The group has developed a UV laser source with eight simultaneous channels. The system, built around their compact laser (less than 50 cu. in.) rated at 700 mJ per pulse (10 ns nominal), generates 100 mJ of UV laser light. The conversion efficiency is approximately 65 percent in the second harmonic (530 nm) and 35

percent in the fourth harmonic (265 nm). These results are accomplished with a highly multimode input, a fact that distinguishes it from performance reported in the literature by others. The optical system's volume is 475 cu. in. The design also includes a custom thermoelectric cooler for the KD*P doubling crystal.


The laser pulses can be used for megavolt/mega-amp switching networks with nanosecond timing resolution between multiple switches. At the other end of the application spectrum, the UV light can be used to ablate materials and determine the concentration of metals for contamination study in a variety of situations.

Applications examples include radioactive-species identification, real-time heavy metal contamination analysis of soils and building materials, and per-

haps measurement of lead concentration in blood screening for schoolchildren. Extremely high-energy transmissions of light pulses through optical fiber in conjunction with this type of system have been proven. Other applications of this technology range from ordnance initiation systems to factory-environment manufacturing systems for laser welding, drilling, cutting, and power transmission.

This work was done at the AlliedSignal Kansas City Plant, operated for the US Department of Energy under contract DE-AC04-76DP00613. For additional technical information, contact Jim Hendrix at (816) 997-3483.

Inquiries concerning the availability of this technology should be addressed to Tom Davis in AlliedSignal's Office of Technology Transfer; (816) 997-5275.



A prototype of the compact eight-channel UV laser system.

Ho:Tm:Lu₃Al₅O₁₂ as an Infrared-Laser Material

This material was selected on the basis of quantum-mechanical modeling of lasing properties.

Langley Research Center, Hampton, Virginia

Lutetium aluminum garnet doped with holmium and thulium (Ho:Tm:Lu₃Al₅O₁₂, also called "Ho:Tm:LuAG") has been shown to be useful as a room-temperature infrared-

laser material. This material was selected from among a number of candidate materials for the development of a laser that would operate at room temperature at a wavelength near 2.0 μ m, but with

an efficiency greater than the efficiencies of 2.0- μ m room-temperature lasers based on Ho:Tm:Y₃Al₅O₁₂ ("Ho:Tm:YAG") and on Ho:Tm:YLiF₄ ("Ho:Tm:YLF"). Other desirable charac-

teristics for the candidate materials included compatibility with pumping by GaAlAs laser diodes at a wavelength in the vicinity of 0.8 μm , plus good thermal and mechanical properties.

The investigation of Ho:Tm:Lu₃Al₅O₁₂ and other candidate laser materials involved special attention to what was considered to be the greatest problem associated with room-temperature lasers at wavelengths near 2.0 μm ; namely, high thresholds. A theoretical expression was developed to describe the lasing threshold of a material in terms of such parameters of the material as the thermal occupation of the lower laser level and the effective stimulated emission cross section. A sophisticated mathematical model based on quantum mechanics was used to evaluate these parameters. Then the threshold was evaluated for each laser material and the materials with low thresholds were considered to be desirable candidates.

Ho:Tm:Lu₃Al₅O₁₂ features relatively low thermal occupation of its lower laser level because this level is higher than are the corresponding levels of most of the other available laser materials. In addition, Ho:Tm:Lu₃Al₅O₁₂ has a reasonably large effective cross section for stimulated emission because of the contribution of several transitions around a central strong transition. A low threshold results from the combination of these properties, making the performance of this laser material potentially superior to those of other commercially available laser materials. While Ho is the element that participates in the main laser process, it does not absorb the pump radiation efficiently by itself. Tm is incorporated into the laser material to absorb the pump radiation and efficiently transfer the energy of that radiation to the Ho (see Figure 1).

Yet another desirable property of Ho:Tm:Lu₃Al₅O₁₂ is that its calculated rate of upconversion is lower than those of other laser materials like Ho:Tm:YAl₅O₁₂ and Ho:Tm:YLiF₄. Inasmuch as upconversion detracts from the efficiency of a laser, this lower rate of upconversion is highly desirable. Finally, like other garnets, Lu₃Al₅O₁₂ has thermal and mechanical properties suitable for high performance in lasers.

An experimental Ho:Tm:Lu₃Al₅O₁₂ laser was constructed, pumped by a Ti:Al₂O₃ laser at a wavelength of 0.781 μm (to simulate pumping by a GaAlAs laser diode at about this wavelength). Fluorescence at room temperature in the wavelength range of 1.6 to 2.2 μm was observed, with a peak at 2.1 μm (see Figure 2). The efficiency of this laser was limited by the thinness of the





Figure 1. The Absorption Spectrum of Ho:Tm:Lu₃Al₅O₁₂ at a temperature of 300 K includes a peak at 0.78 μm that is attributed to Tm. Pumped energy at this wavelength can be absorbed and transferred efficiently to the Ho for lasing.



High Power Linear Flashlamps from EG&G

Solid Solutions. Maximum Performance.

EG&G flashlamps represent state-of-the-art construction. High temperature, graded seals ensure reliable operation over a wide range of conditions.

Available in various arc lengths, bore sizes and envelope materials, EG&G flashlamps provide maximum performance in a variety of high power applications by producing light output from ultraviolet through infrared.

And, custom flashlamp designs offer a cost effective approach for even the most stringent applications.

ISO 9001

1-800-950-3441.

EG&G
ELECTRO-OPTICS

EG&G OPTOELECTRONICS GROUP:

EG&G CANADA	EG&G JUDSON
EG&G ELECTRO-OPTICS	EG&G POWER SYSTEMS
EG&G HEIMANN	EG&G RETICON
EG&G IC SENSORS	EG&G VACTEC

AN OPTOELECTRONICS GROUP COMPANY

35 Congress Street
Salem, MA 01970
Tel (508) 745-3200
FAX (508) 745-0894

Ho:Tm:Lu₃Al₅O₁₂ sample (with consequent limited absorption of pump radiation) and by the limited overlap of the pumped volume with the volume of the laser electromagnetic mode. Further research and development will be directed toward increasing efficiency.

This work was done by Norman P. Barnes of **Langley Research Center**, Clyde A. Morrison of Army Research Laboratories, and Elizabeth D. Filer of Lockheed Engineering & Sciences Co. For further information, **write in 35** on the TSP Request Card.

This invention is owned by NASA, and a patent application has been filed. Inquiries concerning nonexclusive or exclusive license for its commercial development should be addressed to the Patent Counsel, Langley Research Center; (804) 864-9260. Refer to LAR-15105.




Figure 2. The **Emission Spectrum** of an experimental Ho:Tm:YAl₂O₅ laser includes a laser peak at a wavelength of about 2.1 μm. The efficiency plot shows relatively low efficiency, but future improvements are expected.

LASER DIODE OPTICS

When your application demands high quality laser diode optics, think of Optima. Our 336 Series collimating lenses have been used in space systems and in more down-to-earth applications like bar code readers, laser pointers, and smoke detectors.

Whether you need a custom assembly or just an off-the-shelf component, we'd like you to consider Optima. Please ask for our catalog covering the following items:

- COLLIMATED DIODE LASERS, VISIBLE THRU NEAR-INFRARED
- LASER DIODE MOUNTING KITS
- COLLIMATING AND OBJECTIVE LENSES -- GLASS OR PLASTIC
- SINGLETs, DOUBLETs AND ACHROMATs
- ANAMORPHIC PRISMS
- OPTICAL FLATS -- MIRRORS, BEAMSPLITTERS, FILTERS
- DIFFRACTION GRATINGS
- ASPHERIC LINE GENERATOR LENSES




OPTIMA

OPTIMA PRECISION INC., 775 SW LONG FARM ROAD, WEST LINN, OREGON 97068

PHONE: (503) 638-2525


OUTSIDE OREGON: (800) 544-4118

FAX: (503) 638-4545



II-VI Incorporated, Virgo Optics, and eV Products.

Three distinct units under one corporate umbrella, each offering users of lasers and optics more quality products and services, from the far infrared, through the visible, to gamma-ray wavelengths.



II-VI Incorporated
375 Saxonburg Blvd.
Saxonburg, PA 16056

Phone 412-352-1504
Fax 412-352-4980
Write in No. 490

Virgo Optics
6736 Commerce Avenue
Port Richey, FL 34668

Phone 813-845-3402
Fax 813-845-4957
Write in No. 491

eV Products
375 Saxonburg Blvd.
Saxonburg, PA 16056


Phone 412-352-5288
Fax 412-352-4980
Write in No. 492

II-VI
INCORPORATED

FREE CATALOG PRECISION OPTICS, LASERS & OPTICAL INSTRUMENTS

Inside you'll find:

Optical Components
Test Equipment
OEM Optics
Video Systems
Machine Vision
Critical Measuring
Positioning Equipment
Lasers & Laser Optics
Magnifiers & Comparators
Microscopes & Telescopes



At Edmund Scientific, we specialize in providing technical design and research solutions with our extensive line of precision optics and optical instruments—all of which are in stock and available for immediate delivery. Call today for your FREE 236 page catalog.

Edmund Scientific Co.

Dept. 15B1, N948 Edscorp Bldg., Barrington, NJ 08007-1380
Phone: 609-573-6250 Fax: 609-573-6295

CALL FOR YOUR FREE COPY 1-609-573-6250

For More Information Write In No. 464

**PRECISION
Slides
& ROTARY
Tables**

**Get to
the Point**
CHOOSE
FROM OVER 756
MODELS

**Get
the Catalog Free**

Call 800-642-6446 (Except NYS), Ask for Catalog M

USES Scanning or positioning of a probe, sensor, cutter or transducer. Also remote indexing, feeding or dispensing. **FEATURES** Compact, durable and moderate price. Easy to program motor controllers. Modular design for easy XYZ theta construction. **SPECS** 7 widths: 1½" to 9". Lengths: 3" to 10 ft. Maximum payload 400 pounds. Components or complete systems; motors and controllers.

VELMEX, INC.

P.O. Box 38 • Bloomfield, NY 14443 (in NYS) Call 716-657-6151

Ultraviolet Source for Testing Hydrogen-Fire Detectors

An improved hand-held unit can be adjusted and calibrated.

John F. Kennedy Space Center, Florida

A hand-held portable unit emits ultraviolet light similar to that emitted by hydrogen burning in air. The unit was developed for use in testing optoelectronic hydrogen-fire detectors, which respond to ultraviolet light at wavelengths from 180 to 240 nm. This wavelength range is unique in that within it, hydrogen fires emit small but detectable amounts of radiation, light from incandescent lamps and the Sun is almost completely absent, and air is sufficiently transmissive to enable detection of a hydrogen fire from a distance. Consequently, this spectral region is favorable for detecting hydrogen fires while minimizing false alarms.

In operation, the hand-held unit is aimed toward a hydrogen-fire detector from a prescribed distance and direction and turned on to simulate a hydrogen fire. The hand-held unit replaces an ultraviolet flashlight that was previously used to test hydrogen-fire detectors of three different levels of sensitivity at various distances and was powerful enough to trigger alarms in the least sensitive units at the maximum distance of 54 ft. (≈16 m). However, the flashlight was much too powerful for testing more sensitive units at smaller distances, and there was no way to adjust the intensity of its ultraviolet output. There was also no provision for calibration of the ultraviolet output.

As in the ultraviolet flashlight, the source of ultraviolet light in the present hand-held unit is a krypton discharge lamp. This lamp was chosen, not only because its ultraviolet spectrum is compatible with that of the hydrogen-fire detectors but also because of its low power consumption. A sapphire lens concentrates the output of the lamp into a beam with a divergence of ≈10°. The unit includes an internal photodetector that monitors the intensity of the lamp during a calibration procedure, and a microprocessor that implements the procedure. The unit is powered by a 9-V battery, which lasts about 100 on/off test cycles.

The intensity of the output is set at one of five discrete levels by use of a disk that contains openings of five different sizes: the disk is rotated to place the desired opening in front of the lamp. The disk can also be rotated to a sixth position with no opening for calibration. A spring-loaded set screw and a small detent hold the disk at each position. To operate the unit, the user turns the disk to the appropriate setting and presses an "on" button. If the battery voltage is adequate, a green light-emitting diode flashes, indicating that it is all right to proceed to test a hydrogen-fire detector.

To initiate a calibration procedure, the user rotates the disk to the calibration position, in which there is no opening between the lamp and the outside world. When the disk is in this position, a small hole inside the disk allows light to travel to an optical interrupter, which responds by sending a signal that indicates to the microprocessor that calibration has been requested. In this configuration, pressing the "on" button causes the control circuitry in the unit to turn the lamp on and off, monitor the intensity of the output, and modify the current supplied to the lamp to lock set the intensity at a determined level. The signal for setting the current is saved in a memory circuit and used to set the current until another calibration is requested. This approach to calibration is based partly on the assumption that the intensity of the output will not drift during an interval of a few hours. Thus far, tests have validated this assumption.

This work was done by Gregory A. Hall and William E. Larson

of **Kennedy Space Center** and Robert C. Youngquist, John S. Moerk, William D. Haskell, Robert B. Cox, Jimmy D. Polk, Stephen J. Stout, and James P. Strobel

of I-NET. For further information, **write in 32** on the TSP Request Card.

Inquiries concerning rights for the commercial use of this invention should

be addressed to the Patent Counsel, Kennedy Space Center; (407) 867-3017. Refer to KSC-11685.

Ammonia and Ethylene Optrodes for Research on Plant Growth

Low concentrations can be measured.

John F. Kennedy Space Center, Florida

Fiber-optic sensors are being developed for use in measuring concentrations of ammonia and ethylene near plants during experiments on the growth of the plants in enclosed environments. The roles of ethylene and ammonia in plant growth are not yet known, but it is known that plants emit these gases, and it has been conjectured that these gases either give rise to, or at least are associated with, environmental stresses on plants. The developmental fiber-optic sensors satisfy a need to measure concentrations as low as a few parts per billion (ppb) and are thus expected to contribute to research on the roles of ethylene and ammonia in the growth of plants.

Fiber-optic chemical sensors are also called "optrodes" and have been described in a number of previous articles in NASA Tech Briefs. An optrode typically includes a clear plastic lead-in optical fiber, a porous glass or polymeric sensing length of optical fiber with a chromophoric reagent sensitive to the analyte (the chemical to be detected) embedded in the glass or polymeric matrix, and a clear plastic lead-out optical fiber. The atmosphere containing the analyte permeates the pores, bringing the analyte into contact with the chromophoric reagent. The reaction between the analyte and the chromophoric agent changes the spectral characteristics of the sensing length of the fiber: in simplistic terms, it changes the color of the fiber by an amount proportional to the concentration of the analyte.

In the case of these particular optrodes, the spectral characteristic of

interest is the ratio between the spectral transmissivities at two different wavelengths. Light from two light-emitting diodes at the two wavelengths is coupled

through the lead-in fiber to the sensing length. After passing through the sensing length, the light travels along the lead-out optical fiber to photodetectors that mea-

A SCHNEIDER OPTICAL ENGINEER CAN SAVE MORE THAN JUST YOUR MONEY



You may not be an optical engineer, but you may be involved in a project with an optics component. If so, it would be well worth your time to talk with an optical engineer at Schneider.

We've been a world-leader in OEM lens design and technology for more than 80 years, and we'd like to share our expertise with you. There's no charge for the initial consultation. We know of no other precision optical manufacturer that is so willing to openly give you its technical data right up front.

We'll provide all the information, assistance, evaluation

units and prototypes you need to insure superb optical performance.


A Schneider optical engineer can help you avoid expensive mistakes. So, contact Stuart Singer, our Technical Director and Senior Optical Engineer, before designing, before bread-boarding, or before manufacturing. We can save you money and a whole lot more.



STUART SINGER
Senior Optical Engineer

Schneider Corporation of America

400 Crossways Park Drive
Woodbury, NY 11797
TEL: 516 496-8500
FAX: 516 496-7508



The **Response of an Optrode** to the concentration of ammonia in water is fairly sensitive up to about 50 ppm.

sure the remaining intensities, which can be used to calculate the ratio of interest and thus the concentration of the analyte.

Experimental ethylene-sensing optrodes have been made from porous glass optical fibers and found to be capable of indicating concentrations of ethylene as low as 50 ppb. Experimental ammonia-sensing optrodes have been made from a variety of plastic optical fibers and chromophoric reagents; these sen-

sors have been demonstrated to respond to ammonia vapor at concentrations from a few ppb to 200 parts per million (ppm) and to ammonia dissolved in water (see figure) at concentrations from a few ppb to 50 ppm. Two additional and unique features observed in experiments on sensing of ammonia were independence of pH in the pH range from 1 to 13 and selective detection of dissolved ammonia in the pres-

ence of ammonium ions.

This work was done by Quan Zhou and Mary Beth Tabacco of Geo-Centers, Inc., for Kennedy Space Center. For further information, write in 46 on the TSP Request Card.

Inquiries concerning rights for the commercial use of this invention should be addressed to the Patent Counsel, Kennedy Space Center; (407) 867-3017. Refer to KSC-11624.

Laser Velocimeter for Use on Helicopter Rotor

An image-rotating optic would transform the laser beams to the rotating reference frame.

Ames Research Center, Moffett Field, California

A laser velocimeter is being developed to measure the flow of air in the vicinity of one of the blades of a helicopter rotor. The outstanding feature of this velocimeter would be an image-rotating optical subsystem that would transform the velocity-probing laser beams into the rotating reference frame from the stationary laboratory reference frame, in which the beams would be generated. Thus, the transformed beams would be stationary with respect to the rotor blade; this would enable the continuous monitoring of the velocity of

flow at some point in the reference frame attached to the blade, provided that the blade did not vibrate.

The figure illustrates schematically the major optical components. The output of a laser would be divided by a beam splitter into two parallel beams, which would be steered by a stationary mirror onto a path coaxial with the rotor. On the way up toward the rotor, the beams would pass through an image-rotating optic, which could be a Dove prism, a Pechan prism, a folded Abbe prism, or a three-mirror device like the one in the

figure. When an optic of this kind is rotated through an angle θ about the optical axis (which is also the axis of the helicopter rotor in this case), the image viewed through the optic rotates through an angle 2θ . The image-rotating optic would be made to rotate in synchronism with the rotor but at half the rotor speed. Thus, the beams emerging from the top of the image-rotating optic would be stationary with respect to the turning rotor.

The beams would travel up along the hollow rotor shaft to a focusing lens, which would make them intersect at a point that would define the center of the probe volume. A mirror would steer the intersecting beams to position the point of intersection at the desired height above the surface of the blade and at the desired horizontal coordinate downstream or upstream of the leading edge.

Light back-scattered from small particles (e.g., dust) entrained in the flow that passes through the probe volume would be focused by a Schmidt-Cassegrain collector into an optical fiber. The collector and fiber would be part of the rotating assembly. Using the optical analog of an electrical slipring, the other end of the fiber would be aligned along the axis of rotation, along which the light would be coupled out to the nonrotating laboratory reference frame. This light would contain the frequency information that can be related to the velocity of the light-scattering particles; the light signal would be detected and processed by standard laser-velocimeter circuitry and processing methods.

The system arranged as shown in the figure would be sensitive to velocity in the plane of the page along a line slightly tilted with respect to the axis of the rotor. A second coaxial dual-laser beam subsystem of different color

NEW

Need to cool a laser?
Precisely? Economically?
Constantly? With no rust, scale
buildup or temperature/
pressure fluctuations?

LASER COOLING

THEN SPECIFY A REMCOR® CHILLER.

OUR FEATURES INCLUDE:

- ENVIRONMENTALLY SAFE GASES
- CAPACITIES FROM .25 TO 7.5 H.P.
- HIGH EFFICIENCY HEAT-EXCHANGER
- THUMBSCREW SERVICE PANELS
- USER FRIENDLY FILL/ DRAIN-PORTS
- REFRIGERANT/ LIQUID SIGHTGLASS
- ELECTRICALLY ISOLATED RESERVOIR



REMCOR® LIQUID CHILLERS

Get a free REMCOR® SpecKit today,
and discover the best way to cool a laser
or any other scientific instrument.

1-800-423-3477

"CALL OUR APPLICATION
TEAM FOR ASSISTANCE"


REMCOR®
Remcor Products Company
500 Regency Drive, Glendale Heights, IL 60139-2268

could be aimed at the same probe volume along the same bisector of the intersecting beams, but in a plane of intersection perpendicular to that of the first two beams; this would enable the simultaneous measurement of velocity along the horizontal direction running downstream or upstream of the leading or trailing edge. A third such subsystem of yet another color, aimed at the same probe volume from a final turning mirror at a different axial location, could enable the measurement of the third

component of velocity, although this measurement would be coupled with the other two and would have to be uncoupled in processing.

This work was done by Stephen E. Dunagan of Ames Research Center. For further information, write in 24 on the TSP Request Card.

Inquiries concerning rights for the commercial use of this invention should be addressed to the Patent Counsel, Ames Research Center; (415) 604-5104. Refer to ARC-13106.



The **Laser Beams Would Be Transformed** by the image rotator, so that they would be stationary in the coordinate frame attached to the rotor blade.

SORL

Over 25 Years of Excellence



**Model No. LUPI-II
AFAS Interferometric Test Station**




**Model No.
TOAN 7.5-8Q
Reflective Collimator**

**Off-Axis Parabolic,
Flat & Spherical
Mirrors/Mounts**



**COAR - 10x10-HQ Off Axis
Beam Expander**



FX15/5 F Fourier System

**SPACE OPTICS
RESEARCH LABS**

A DIVISION OF INTERGRAPH
7 Stuart Road, Chelmsford, MA 01824
(508) 256-4511, 1-800-552-7675
FAX (508) 256-5605

For More Information Write In No. 468

100A 15ns Laser Diode Drivers

- Pulse Current to 100A
- Pulse Widths 6ns to > 200ns
- Pulse Frequency > 15KHz
- Low Cost

LDM Laser Diode Driver Modules provide extremely fast high current pulses to laser diodes in PULSE DOPPLER, RANGE FINDER, LIDAR and other applications requiring high current and very narrow pulses.

Call today - 970.493.1901



Directed Energy, Inc.
2301 Research Blvd., # 105
Fort Collins, CO 80526
Fax 970.493.1903
Email deiinfo@dirnrg.com

For More Information Write In No. 469

Custom Pellicles



24 hours to 2 weeks!

1/16" to 48" and larger!

Ultra-custom designs estimated.

Custom Coatings

- Dichroic ■ Infrared ■ No Loss
- Attenuators ■ Anti-Reflective

Custom Frames

- Oval ■ Square ■ Rectangular ■ Brass
- Elliptical ■ Truncated Cylinders
- Stainless Steel ■ Aluminum ■ Others
- Critical Flatness/Transmission Requirements Met/Documented ■ Quantity discounts available ■ Expert Prototype Design



428 Waverly Avenue. P.O. Box 320.
Mamaroneck, NY 10543-0320 USA

Tel: 800-698-8151

Fax: 800-698-3629

MasterCard and VISA accepted.

For More Information Write In No. 470

A Photonically Based Receive Signal Combiner for RF Phased Arrays

The use of photonic implementation of a receive signal combiner in an RF phased-array antenna can reduce the weight of the antenna and provide several performance improvements.

Rome Laboratory, Photonics Center, Griffiss AFB, New York

Recent work has proven the advantage of implementing a receive signal combiner for an RF phased-array antenna in optical waveguides rather than in coaxial cable or pressurized RF waveguides.

In the demonstration of this project, conducted under an effort entitled "Microwave Optical Interconnect for RF Phased Arrays," a number of possible signal-combining efforts were examined. Here the slot radiators were followed by low-noise amplifiers (LNAs) and RF phase shifters. A diode-pumped Nd:YAG optical source operating at 1319 nm provided the optical signal to each of the four electro-optic modulators.

This resulted in four time-delay-equalized fiber optic links. The outputs of each of the four separate detectors were combined in a ring configuration. The RF output of the system is at 3.3 GHz.

The demonstration was conducted in a 16-element array with 4 active array elements. The receive beam was steered over a 120-degree scan angle. In addition, monopulse beam steering was demonstrated with more than 50 dB signal cancellation.

The technique demonstrated on this project is one of several that were studied. The decision to use a common optical source rather than separate optical sources was based upon concerns regard-

ing coherence effects such as noise.


This photonic-based receive signal combining technique could be applied to subarrays rather than individual elements, as accomplished in this demonstration.

A study has shown that the use of this receive signal-combining technique could reduce the weight of an airborne surveillance radar by about 30 percent with a corresponding reduction in the size and number of fuselage penetrations.

Rome Laboratory is also continuing investigations into other areas of photonic implementation into phased arrays for surveillance and communications applications. These include investigation into and demonstration of photonic-based true-time delay beam formation and beam steering for RF phased arrays as well as photonic-based signal processing techniques and high-dynamic-range links for antenna remoting.

This work was conducted by Rome Laboratory under contract to United Technology Photonics with a subcontract to Raytheon Company. The work was monitored by N. Bernstein, Surveillance and Photonics Directorate, Rome Laboratory. No further information is available.

Inquiries concerning rights for the commercial use of this technology should be addressed to the Patent Counsel, RL/JA, Griffiss Air Force Base, NY 13441.



Line diagram showing the signal path from the RF input at the antenna, through the RF cable, electro-optic modulators, and fiber to the detectors located in the receive signal combiner. The RF output from the signal combiner then is sent to the signal processing equipment or receivers, depending upon the application.

A Microwave Tapped Delay-Line Filter Using High-Dispersion Fiber

Microwave filters based on the use of high-dispersion fiber are reconfigurable.

*Rome Laboratory, Photonics Center,
Griffiss Air Force Base, New York*

Fiber-based lines have been a suggested method of time delay for several years. Such lines offer large bandwidths and wide dynamic range, all in a small package size. Several different methods have been demonstrated using fiber delay lines, most of which use several fixed lengths of fiber to achieve stepped time delay.

The method employed in the current example exploits fiber dispersion to achieve a variable time delay. By tuning the wavelength the relative time delay is changed. A 1-km length of high-dispersion fiber (-98ps/km-nm) has yielded approximately 5 ns of delay over a 50-nm tuning range.

Tapped delay-line filters are the weighted sum of several delayed versions of the same RF signal. Using the dispersion in fiber as the delay medium, it is possible to create a spectrum of RF delayed signals. In this idealized scheme, a broadband incoherent light source modulated with an RF signal would create this delay spectrum. Because of practical considerations, it is much easier to create a "sampled" broadband source by using several sources at various wavelengths. This comb of wavelengths can be weighted and summed to produce a more traditional transversal filter.

The configuration of the tapped delay-line filter is shown in the figure. This system uses 8 tunable laser diodes


to form the 8 spaced time delays. The wavelength tunability of the diodes allow a reconfigurable time separation between taps. The weighting of each tap is changed by varying the current sent to the particular diode. The 8 stepped wavelengths are combined by a star coupler and sent to a modulator. An external LiNbO₃ modulator is used to avoid any bulk time delays and to allow for high-frequency operation. The comb of wavelengths is then propagated through a 1-km length of high-dispersion fiber. The relative time delays seen between two adjacent taps is defined by

$$\Delta\tau = \Delta\lambda DL$$

where $\Delta\lambda$ is the wavelength difference between the two taps, D is the dispersion of the fiber, and L is the fiber length. In our system, tap spacing can be easily changed by varying the wavelength of each diode. This tunability also implies that unequal tap spacing can be used, and work is continuing to explore its signal-processing implications.


This work was done by Douglas Norton and Steven Johns of the Air Force Photonics Center, Surveillance and Photonics Directorate, Rome Laboratory, Griffiss AFB, New York. No further information is available.

Inquiries concerning rights for the commercial use of this invention should be addressed to the Patent Counsel, RL/JA, Griffiss AFB, NY 13441.



Reconfigurable Tapped Delay Line Filter is implemented using both wavelength- and amplitude-tunable laser diodes.

"User Friendly" Nd:YAG Laser



CW and Q-Switched

■ TEM₀₀-Mode Lasers

- 5 models 3-18 Watts
- Active Stabilization
- Q-Switch Option
- Applications
 - Resistor Trimming
 - Scribing/Cutting
 - Spectroscopy
 - Mode-Locking

■ Multimode Lasers

- Models 25W-1.8 kW
- Q-Switching up to 200 W
- Applications
 - Marking / Engraving
 - Soldering / TAB
 - Welding

■ Features

- Computer Interface
- OEM Configurations
- Optical Accessories
 - Fiber Optics
 - Beam Expanders
 - Focusing Optics

LEE LASER

3718 VINELAND RD., ORLANDO, FLORIDA 32811 U.S.A.
TEL: 407-422-2476 FAX: 407-839-0294

INDUSTRY LEADERS

Profiles of Pathsetting Companies In The Photonics Field

II-VI Inc.

SPANNING THE PHOTONICS SPECTRUM

II-VI Inc. has recently expanded its product line to include laser optics for wavelengths from the ultraviolet through the far infrared.

The recent acquisition of Virgo Optics of Port Richey, FL, has expanded the II-VI product line to include optical components for use in the spectrum from 190-3000 nm. Virgo Optics offers laser-gain materials such as Nd:YAG and Nd:YVO, as well as nonlinear crystals such as KNbO and BaTiO. Services provided by the Virgo Optics division include refurbishment of damaged laser crystals such as Nd:YAG and KTP. The Virgo division also offers custom coating, crystal fabrication, and wafer processing.

In addition to the recently acquired Virgo products and services, the II-VI product line includes a complete range of infrared products and services for industrial, commercial, medical, military, and research lasers covering the



2.0-to-20-micron range.

Recent II-VI new-product introductions include: **off-axis parabolic mirrors** for diffraction-limited performance; **ATFR beam delivery mirrors** to prevent unwanted reflections from re-entering the laser cavity; **all-reflective beam expanders** for broadband applications where refractive designs are not practical; and **motorized beam expanders** for dynamic control

of the laser-beam size in flying optic systems.

Our eV Products division is engaged in the development and uses of compound semiconductor materials for ionizing radiation detection applications, which include industrial gauging, security, medical imaging, and research and development.

Contact: II-VI Incorporated, 375 Saxonburg Blvd., Saxonburg, PA 16056; Tel. (412) 352-1504; FAX (412) 352-4980.

For More Information Write In No. 472

NESLAB INSTRUMENTS

GLOBAL SUPPLIER OF RECIRCULATING CHILLERS

NESLAB Instruments is a global supplier of recirculating chillers for use in the laser and optical equipment industries. These closed-loop chillers improve equipment performance by replacing unclean or unpredictable tap or building water with a coolant that is clean and free of minerals, organic matter, rust, or any number of pollutants. This allows for greater control of temperature, flow, and pressure of the coolant. Recirculating chillers offer trouble-free steady cooling with heat-load removal up to 75 kW, spanning temperatures of -5 °C to +35 °C. NESLAB offers 16 different chiller models as well as four water-to-water heat exchangers.

NESLAB's recirculating chillers feature 24-hour operation, LED display, operating status gauges, and easy access to internal components. Each cooling system can be ordered with temperature-control options, pump options, and an extensive list of customizing options. NESLAB's staff of



design engineers and applications engineers can work closely with customers to design and manufacture equipment that will suit their needs exactly.


NESLAB offers world-class OEM product programs, and can offer special pricing, delivery, and custom engineering assistance to meet specific requirements. Years of successful relationships with major OEM customers have made

NESLAB a first choice among manufacturers using temperature control in conjunction with their processes.

In addition to its USA locations, NESLAB has direct sales and service facilities throughout Europe and Asia. NESLAB is an ISO-9001 registered company, and all NESLAB products are backed by over 30 years' experience. Contact: Terri Pruett, Marketing Coordinator, NESLAB Instruments, Inc., PO Box 1178, Portsmouth, NH 03802-1178; Tel. (603) 436-9444; FAX (603) 436-8411.

For More Information Write In No. 473

NEW LITERATURE




Infrared Materials

An eight-page full-color brochure from II-VI, Saxonburg, PA, describes the range of zinc selenide (ZnSe), regular-grade zinc sulfide (ZnS), and multispectral-grade zinc sulfide available from the company. The booklet lists physical, mechanical, and thermal properties as well as optical wavelength, refractive index, and thermo-optic coefficient. It also sets out

standard tolerance specifications and surface finishes for its line of circular, rectangular, and square blanks and blanks with generated curved surfaces.

For More Information Write In No. 807



Signal Generation and Analysis Equipment

The "Scientific and Engineering Instruments" catalog from Stanford Research Systems, Sunnyvale, CA, has 176 pages of product and technical information, including more than 40 pages devoted to five instrumentation application notes. Features and specifications are detailed for a range of

equipment including spectrum analyzers, function and digital delay generators, lock-in amplifiers, gated integrators and boxcar averagers, photon counters, and more.

For More Information Write In No. 808




Fiber Access to Unusual Spectral Regions

Galileo Electro-Optics, Sturbridge, MA, offers a technical data sheet on its Fluorolase™ rare-earth-doped fluorozirconate (ZBLAN) fibers for use as fiber amplifiers, fiber laser sources, and sensors. Dopants of the four standard models include praseodymium, thulium, holmium, and erbium,

allowing upconversion output regions of red, blue, and green, as well as IR. The fibers are manufactured by Galileo using proprietary technology licensed from British Telecom.

For More Information Write In No. 809




Silicon and Germanium Optical Materials

An eight-page full-color brochure from Lattice Materials Corp., Bozeman, MT, contains descriptions of the company's capabilities in crystal growth, testing, shaping and slicing, curve generation, polishing, and final inspection. Material specifications of silicon and germanium are also detailed, as

well as fabrication and surface finish capabilities.

For More Information Write In No. 810



Handheld CRT Tristimulus Colorimeter

Graseby Optonics, Orlando, FL, offers a four-page brochure describing its SLS 9400 handheld battery-operated CRT colorimeter. Ergonomically designed to rest comfortably in one hand, it operates from simple menu-driven commands. The brochure sets out specifications of accuracy and

repeatability, as well as graphed spectral response curves compared with CIE response.

For More Information Write In No. 811



Precision Motion Control

The new edition of the positioning systems and components catalog from the MicroSlides division of Anorad Corp., Haupauge, NY, contains 17 pages outlining components, slide assemblies, stages, and integrated systems. Included are crossed roller bearings and ways, linear and rotary positioning systems, and positioning controllers. Warranty policy is also spelled out.

For More Information Write In No. 812

NEW PRODUCTS



Beam Diagnostics for Pulsed and CW Sources

The LaserGauge™ from Coherent, Auburn, CA, offers compact size, speed, and ease of use in CCD-based beam diag-

nostics, the company says. It is compatible with all Coherent beam diagnostics cameras, including the new Laser-Cam. Any NTSC-compatible video monitor can be used with the LaserGauge. Features include full automatic triggering, background zero, and gain adjust. It also has an RS-232 serial port for remote data storage.

For More Information Write In No. 801



Video Time Exposures with Peak Store

Colorado Video, Boulder, CO, announces the Model 443 video peak store, with a video memory capable of superim-

posing two or more images onto a single frame. Thus it provides the equivalent of a photographic time exposure. A standalone self-powered instrument, the 443 can be used with either a conventional TV camera or videotape. The company says it is ideal for capture of random transient events or for tracking moving objects.

For More Information Write In No. 802




Carbon Dioxide TEA Laser

Laser Science Inc., Newton, MA, is offering its μ -TEA carbon dioxide laser with a sealed replaceable plasma car-

tridge. Emitting up to 10 mJ of multimode pulse energy at 10.6 micrometers, it operates at a repetition rate of up to 20 Hz. Its 200-ns pulse can deliver as much as 50 kW peak power for applications in mass spectrometry, laser-induced plasma spectroscopy, and detection calibration.

For More Information Write In No. 803



Programmable Gas Assist for Process Control

Lumonics, Eden Prairie, MN, announces that its full line of Laserdyne™ Multi-axis laser systems equipped with the System 94 Laser Process Control will have a new programmable gas-

assist option. Called PresSure™, the feature provides control of assist-gas pressure from within the part program, eliminating the need to make pressure changes manually. Thus pressure can be precisely controlled from 0-200 psi. Pressure can also be quickly changed between optimums for a given area of a part.

For More Information Write In No. 804



Diode Laser Driver with Interface

The 06 DLD 203 diode laser driver, a micro-processor-driven low-noise current source and temperature controller from Melles Griot,

Irvine, CA, comes with an IEEE-488.2 interface as a standard feature. The unit offers current- and power-stabilized modes of operation, modulation capability up to 1 MHz, and the ability to preset all diode laser and temperature values before laser turnon.

For More Information Write In No. 805



Higher Powers for Industrial Excimers

The new INDEX-888 model that Lumonics, Kanata, Ontario, Canada, has added to its INDEX®-800 series of industrial

excimer lasers can deliver stabilized energies of 600 mJ/pulse on KrF and 400 mJ/pulse on XeCl, both at repetition rates of up to 100 Hz. Designed for high-precision materials processing, Lumonics' workstations incorporating the INDEX 888s use a centralized laser and motion-control system with a Windows-based operating environment.

For More Information Write In No. 806




LASER-BASED STRUCTURED LIGHT PROJECTORS

Lasiris Inc. is offering a complete line of laser-based structured light projectors for machine vision and alignment. Featured are focusable line generators from single-line to 99 parallel lines of a uniform, non-

Gaussian distribution of intensity; single-circle and concentric-circle projectors; and dots to dot-matrix optical alignment, interrupt sensors, and 3-D mapping. Tel: 800-814-9552; or 514-335-1005; Fax: 514-335-4576.

Lasiris Inc.

For More Information Write In No. 370



RECIRCULATING CHILLERS

64-page catalog features a complete line of recirculating chillers for cooling water-cooled equipment. These chillers offer steady cooling with heat load removal up to 75 kW, spanning temperature ranges of +5 °C to +35 °C. Chillers feature: 1) ozone-

friendly refrigeration-systems, 2) LED display, 3) operating status gauges, and 4) easy access to internal components. Also available is CFC-free Constant Temperature Equipment. Call toll-free at 1-800-258-0830.

NESLAB Instruments, Inc.

For More Information Write In No. 371



MACHINE VISION STROBE ILLUMINATION SYSTEMS

EG&G Electro-Optics is known in the industry for producing high-quality strobe systems and for its ability to customize those systems for specific applications. This brochure contains

individual data sheets which describe and specify the broad line of MVS systems and accessories used to provide uniform direct lighting, fiber optic lighting, or collimated lighting. EG&G Electro Optics, 25 Congress St., Salem, MA 01970; Tel: 508-745-3200; Fax: 508-745-0894.

EG&G Electro-Optics

For More Information Write In No. 372



GATED INTEGRATOR AND BOXCAR AVERAGERS

The SRS Boxcar system measures sub-nanosecond events within a NIM format. Modules include the Gated Integrator (gates from 2 ns to 15 µs), Fast Sampler (gates to 100 ps), Analog Processor, Gate Scanner, Fast Preamplifier, and Computer Interface (with RS-232 and IEEE-488). The SR270 (DOS) software package allows system set-up and control, data display and post-acquisition data reduction. Stanford Research Systems; Tel: 408-744-9040.

Stanford Research Systems

For More Information Write In No. 373



LOF HIGH PERFORMANCE TEC-GLASS

Libbey-Owens-Ford has updated the data sheets detailing their on-line CVD pyrolytically coated Transparent Electrical Conducting (TEC) Glass. LOF High Performance TEC-Glass coating is tough and durable for ease of fabrication and installation in a wide range of applications, including: thin-film photovoltaics, flat panel displays, electrochromics and freezer and oven doors. For more information, call Libbey-Owens-Ford at 419-247-4724, or write 811 Madison Ave., PO Box 799, Toledo, Ohio 43697-0799.

Libbey-Owens-Ford Co.

For More Information Write In No. 374




NEW INFRARED OPTICS CATALOG FOR RESEARCHERS, MANUFACTURERS, AND OPTICAL ENGINEERS

II-VI Incorporated, Saxonburg, PA, a worldwide leader in IR laser optics, is now offering a 48 page, full color optics catalog. This catalog is designed to assist researchers, manufacturers and users with the proper selection and specification of optics. It features detailed information on all significant aspects of infrared optics, including IR Materials.

II-VI Incorporated

For More Information Write In No. 375



LASER DYES

With Exciton, you get a specialized team of professionals knowledgeable in the field of laser dyes. Since more than one dye may cover a given spectral region, we provide the latest information concerning the best dye selection for a specific laser system and application. Exciton Inc., PO Box 31126, Overlook Station, Dayton, OH 45431; Tel: 513-252-2989.

Exciton Inc.

For More Information Write In No. 376



C-MOUNT COMPACT LENSES FOR ELECTRONIC IMAGE PROCESSING

- for 1/2" and 2/3" CCD imaging devices
- ruggedized design for industrial applications
- variable iris, with locking mechanism
- variable focus, with locking mechanism
- optically designed for spectral range 400 nm to 1000 nm

SCHNEIDER CORPORATION OF AMERICA, 400 Crossways Park Drive, Woodbury, NY 11797; Tel: 516-496-8500; Fax: 516-496-8524.

Schneider Corporation of America

For More Information Write In No. 377



POSITIONING/MOTION CONTROL CATALOG

NEW, 160 page catalog covers NEAT's line of precision positioning and motion control components and systems. Featured are single axis, X-Y, multi-axis, rotary, high vacuum, air bearing, and microscope stages, and stepping and servomotor drives and controls. NEAT provides modified, custom, and turnkey SOLUTIONS. Contact our Sales Engineers at 800-227-1066 or send E-mail to <http://www.neat.com/users/neat>. New England Affiliated Technologies, 620 Essex Street, Lawrence, MA 01841; Tel: 800-227-1066; Fax: 800-523-8201.

New England Affiliated Technologies

For More Information Write In No. 378

OFFICIAL NASA CAPS

Black cap with gold leaves and official NASA insignia.


Only \$9.95 each!

Please send (insert quantity) _____ NASA caps.
Add \$5.00 for handling and shipping charges.
NY residents add sales tax.

TOTAL Enclosed: \$ _____

NAME _____
ADDRESS _____
CITY _____
STATE _____ ZIP _____

Mail payment to: NASA Tech Briefs, Dept F
41 East 42nd St., Suite 921, New York, NY 10017
For credit card order call (212) 490-3999



LASER TECHNOLOGY AND APPLICATIONS

An 18-page brochure available from Rofin Sinar, Inc. provides a concise examination of laser technology and its expanding applications in the manufacturing environment. Detailed are the elements and concepts of lasers critical to modern industry:

versatility and flexibility; precision, control, and speed; and the laser's present and potential applications in welding, cutting, drilling, surface treatment, and product identification. Individual sections discuss CO₂ and Nd:YAG lasers, laser marking systems, and Rofin Sinar's capabilities and resources.

Rofin Sinar, Inc.

For More Information Write In No. 380

Reach 80,000 Photonics Professionals Direct


Laser Tech Briefs' Literature Spotlight advertisements carry your message to 80,000+ laser, optics, and video/imaging product buyers in industry, government, and the academy. These are technology managers, design engineers, and scientists who will avail themselves of this direct method of obtaining information on your product or service. The October 1995 issue is your next opportunity to use this marketing tool. Contact your Laser Tech Briefs sales representative or call Joe Pramberger at 212-490-3999.

From prototype to production...

UV to FAR IR, Standard, Custom & OEM Optics & Coating Production

- **Quality Customer Service & Support**
- **Custom, Standard, OEM Laser and Imaging Optics**
- **Complete In-house Capabilities for Design & Production**
- **UV-FIR State-of-the Art Coating Designs - Standard & High Power**

**Call our knowledgeable sales team at 303-651-2211
for custom solutions to your technical problems.**



R M I

ROCKY MOUNTAIN INSTRUMENT

**1501 South Sunset Street
Longmont, CO 80501
Fax (303) 651-2648**

Europe 0421-2208-147 • Fax 0421-2208-157

Japan Opto Science 03-3356-1064 • Fax 03-3356-3466

Korea Woo Kyung E-O 345-494-6855 • Fax 345-494-6859



Probes Measure Slots

Marshall Space Flight Center, Alabama

Contact probes have been devised for measuring the depths and widths of slots. The slot-width-measuring probes can be configured in conical or wedge shapes, depending on the specific applications. The conical or wedge surface of a probe centers the probe in a slot, while two thin probe rods are made to pro-

trude from the cone or wedge until their tips simultaneously make contact with the outer surface and the bottom of the slot. Data on depths are obtained by digitizing the voltage outputs of linear potentiometers connected to the two rods, then processing the digitized outputs in a computer. The data can be

stored and/or used to generate displays for purposes of quality control.

This work was done by John E. Maslakowski and Jeffrey L. Gilbert of Rockwell International Corp. for Marshall Space Flight Center. For further information, write in 87 on the TSP Request Card. MFS-30052.

Composite Cocured Modular Eggcrate-Core Sandwich Structure

Advantages include easier fabrication and better mechanical properties.

Langley Research Center, Hampton, Virginia

Lightweight composite-material (e.g., graphite fiber/epoxy matrix) cocured sandwich panels with eggcratelike cores are being developed for use as principal components of optical benches and other structures that support precise optical instruments. In comparison with struc-

tures (including composite structures) developed previously for this purpose, these structures offer greater thermal and mechanical stability. Unlike some of the previously developed structures, these structures can be fabricated without precise machining and precise alignment steps, and the remaining steps needed to fabricate these panels are fewer and simpler. Also, the core is fabricated without the use of adhesives, which reduces overall outgassing potential and weight contributions. Consequently, the fabrication times and costs are reduced.

The developmental panel structures can be made in many variations of the basic eggcrate core/sandwich design.

As shown in Figure 1, the basic design calls for an aggregate of square modular composite-material core units bonded to each other on their mating sides, with face sheets bonded to the core. Four bonded core units intersect at each interior junction, providing a continuation of the properties of the composite material through the junction. The core units and face sheets can be made of a variety of matrix and fiber materials, laminated in a variety of layups and thicknesses, and assembled in a variety of geometries to impart the desired mechanical, thermal, and other properties to the finished structure.




Figure 1. This Structure Is Representative of the eggcrate core/sandwich panel structures described in the text. A typical practical structure could be more complex: it could contain more cells and/or reinforcing and bonding tabs, or the cells could have different (e.g., hexagonal) shapes.




Figure 2. Tooling Blocks Wrapped With Prepreg Strips are assembled in preparation for curing the strips to form the eggcrate core.

Many variations in fabrication are also possible. A typical process for making a structure like that of Figure 1 begins with the preparation of strips of composite prepreg material, which is typically a laminate of four plies of graphite fibers (oriented at 0°, 45°, 90°, and -45°) with a partially cured epoxy matrix. These strips are cut to fit tooling blocks that serve as mandrels for the eggcrate core units. The prepreg strips are wrapped around the blocks, then the wrapped blocks are placed on a tooling plate and pushed together (see Figure 2), thus pressing the wrapped prepreg strips into a unitary core structure with adjacent units joined together in symmetric eight-ply (0°, 45°, 90°, -45°, -45°, 90°, 45°, 0°) walls. By use of a standard autoclave technique, the units are kept pressed together and

heated to cure the epoxy, thus bonding the units together to form a rigid eggcrate core.

After the cure, the tooling blocks are removed from the core. Face sheets made of the same or a different composite material are then bonded secondarily to the core to complete the sandwich structure. Alternatively, one prepreg face sheet can be included in the tooling-plate/tooling-block/core-unit assembly and autoclave-cured along with the core units to obtain a unitary single-face-sheet/eggcrate-core structure; then the tooling blocks can be removed, and the other face sheet bonded secondarily to complete the sandwich structure. In yet another of many alternatives, both face sheets are included in the tooling-plate/tooling-block/core-unit assembly

and autoclave-cured along with the core units to form a complete unitary sandwich structure. In this case, the tooling blocks must be made of a lightweight foam material that can be allowed to remain in the core, or else they could be made of a material that can be dissolved or melted, to remove them from the core after curing.

This work was done by Charles J. Magurany of Lockheed Engineering and Sciences Co. for **Langley Research Center**. For further information, write in **75** on the TSP Request Card.

Inquiries concerning rights for the commercial use of this invention should be addressed to the Patent Counsel, Langley Research Center; (804) 864-9260. Refer to LAR-14898.

Cutting Tool for Shaving Weld Beads

Marshall Space Flight Center, Alabama

A cutting tool has been proposed for use in shaving weld beads flush with the adjacent surfaces of the weldments. The tool would be a modified version of a commercial pneumatically driven rotary cutting tool, the cutting wheel of which turns at speeds sufficient for machining nickel

alloys, titanium, and stainless steels. The depth of the cutting wheel is adjustable in increments of 0.001 in. (0.025 mm). The tool could be equipped with a forward-mounted handle and a rear-mounted skid plate to maximize control and reduce dependence on the skill of the technician.

This work was done by David S. Hoffman of **Marshall Space Flight Center**, and David C. McFerrin, Ronald L. Daniel, Jr., John B. Coby, Jr., and Sidney G. Dawson of Rockwell International Corp. For further information, write in **88** on the TSP Request Card. MFS-30056.

NEW!

High Resolution Digital Color Imaging

New Models


FEATURES

- Models with up to 40,500 pictures per second
- Color and monochrome models available
- Instant slow motion replay
- Powerful post-event analysis and data reduction
- Quality, test, manufacturing, research and design

BENEFITS

- Increase product reliability
- Production line troubleshooting
- Shorten design cycle
- Speed prototype evaluations


For more information call:
EASTMAN KODAK COMPANY
MOTION ANALYSIS SYSTEMS DIVISION
800-462-4307, Ext. 824



**HIGH
SPEED
MOTION
ANALYSIS
FROM
KODAK**



OUR LASER IS WELL KNOWN AROUND THESE PARTS.




Gasket Manufacturing



*Color Marking on
Anodized Aluminum*



Engraving Wood



Marking Microprocessors



Cutting Plexiglas



Cutting Paper



Wire Stripping



Textile Cutting



Cutting Wood



Marking Plastic



Cutting and Welding Plastic



Rubber Stamps

And the list doesn't stop here. The more manufacturers get to know our RF-excited, sealed CO₂ lasers, the more uses they keep finding for them.

This growing popularity makes sense when you consider how versatile and cost-efficient our lasers can be. All the parts shown here were marked or cut in seconds or less – in some cases while moving on high speed production lines.

No tooling is required. The laser's power and motion are controlled using a simple PC. Images, graphics, and text can be created in standard CAD or graphics software – delivering



greater process flexibility. Changing the pattern is as simple and quick as loading a new computer file.

Plus, the laser's small focused spot and non-contact approach eliminate the use of dies, blades, scribes or ink. So you can expect increased accuracy, resolution and process savings.

We offer models from 10 to 250 watts of power, allowing you to select the laser that matches your application and budget. And, as they all take advantage of our patented all-metal construction, you get over




20,000 hours continuous operation.

With no gas bottles or other consumables. That's why Synrad lasers cost less to buy and run than any other models.

If you don't recognize your application on this page, don't worry. Our biggest customers had never used a laser before talking to us.

To find out how lasers can take part in your application, call (800) SYNRAD1.



11816 North Creek Parkway N., Bothell, WA 98011-8205 (206) 483-6100 FAX (206) 485-4882 E-mail: synrad@aol.com

International Representatives

Australia 61 (376) 15200. Belgium 32 (71) 488-44-8. China 86 143-658-91. Denmark 45 (354) 30133. England 44 (1295) 267755. France 33 1-60.79.59.00. Germany 49 898-90-1350. Greece 30 312-045-50. Hungary 36 1-269-0105. Israel 972 9574111. Japan 81 (33) 758-1111. Netherlands 31 17203-1234. Poland 48 224-318-02. Singapore 65 382-2633. Spain 34 1-35.88.61.1. Sweden 46 87-569-190. Turkey 90 2-122-63-2670.

For More Information Write In No. 538



Improved Adjoint-Operator Learning for a Neural Network

Temporally varying patterns could be learned in real time, with less computation.

NASA's Jet Propulsion Laboratory, Pasadena, California

An improved method of adjoint-operator learning reduces the amount of computation and the associated computational memory needed to make an electronic neural network learn a temporally varying pattern (e.g., to recognize a moving object in an image) in real time. This method is an extension of the method described in "Adjoint-Operator Learning for a Neural Network" (NPO-18352), *NASA Tech Briefs*, Vol. 17, No. 10 (October, 1993), page 55.

A lengthy description of the theoretical foundation of the method is prerequisite to give meaning to even a brief summary of the method. [A similar (but not identical) theoretical foundation was described in the noted prior article.] The evolution of a neural network is considered to be governed by the following set of coupled nonlinear differential equations:

$$\dot{u}_n + \kappa_n u_n = g_n \left[\gamma_n \left(\sum_m T_{nm} u_m + I_n \right) \right], t > 0$$

where u_n represents the output of the n th neuron and T_{nm} denotes the strength or weight of the synaptic coupling from the m th to the n th neuron. The constant κ_n characterizes the decay of neuron activity. The response of a neuron is governed by a sigmoidal function, g , and its gain, γ ; typically, $g(\gamma x) = \tanh(gx)$. The time-dependent term $I_n(t)$, called the "source" term, encodes contribution of the n th component of the temporal pattern $\alpha(t)$ via the expression

$$I_n(t) = \begin{cases} \alpha_n(t) & \text{if } n \text{ denotes an input neuron} \\ 0 & \text{if } n \text{ denotes a hidden or output neuron} \end{cases}$$

The problem in learning is to adjust the synaptic-coupling strengths T_{nm} to minimize a quantity called the "neuromorphic energy functional," E , given by

$$E(\bar{u}, \bar{p}) = \int_t \frac{1}{2} \sum_n \Gamma_n^2 dt = \int_t F dt$$

where t = time, the integral is taken over some finite interval, and

$$\Gamma_n(t) = \begin{cases} \alpha_n(t) - u_n & \text{if } n \text{ denotes an output neuron} \\ 0 & \text{if } n \text{ denotes an input or hidden neuron} \end{cases}$$

The vector $\bar{p}$ denotes the system of N^2 (where N is the number of neurons) synaptic-coupling strengths:

$$\bar{p} = \{T_{11}, \dots, T_{NN}\}$$

The solution of the learning problem begins with the formulation of the updating of the parameter vector $\bar{p}$ as a descent along the gradient of E in $\bar{p}$ space, starting from a guessed initial parameter vector. The dynamics of the neural network (as defined by the first equation presented above) are incorporated into the gradient descent by use of the adjoint operators. One begins with a set of equations called the "forward sensitivity equations":

$$\begin{cases} \dot{u}_{n,\mu} + \sum_m A_{nm} u_{m,\mu} = S_{n,\mu} & t > 0 \\ u_{n,\mu} = 0 & t = 0 \end{cases}$$

in which

$$A_{nm} = \kappa_n \delta_{nm} - \gamma_n \hat{g}_n T_{nm},$$

$$S_{n,\mu} = \gamma_n \hat{g}_n \sum_m T_{nm} u_m \delta_{p_\mu, T_{nm}},$$

$\hat{g}_n$ represents the derivative of g_n with respect to u_n , the subscript " μ " denotes partial differentiation with respect to the μ th component of $\bar{p}$, and δ is the Kronecker delta for the identity tensor. It can be shown that the computational cost is reduced by the use of the adjoint functions, $\bar{v}$, the n th component of which is defined by one of the equations in a system of equations called "adjoint system of equations," namely,

$$-\dot{v}_n + \sum_m A_{nm}^T v_m = S_n^*$$

To put this equation in closed form, one must define the source term S_n^* and temporal boundary conditions. Both should be independent of p_μ and its derivatives.

To begin the derivation of the improved method, one multiplies the forward sensitivity equations by $\bar{v}$, and the adjoint system of equations by $\bar{u}_\mu$, subtracts the two resulting equations, integrates over the time interval (t_0, t_f) , and selects the following new source terms and boundary conditions:

$$\begin{cases} \bar{S}^* = \frac{\partial F}{\partial \bar{u}} \\ \bar{v}(t = 0) = 0 \end{cases}$$

The resulting equation is

$$\int_t \frac{\partial F}{\partial \bar{u}} \bar{u}_\mu dt = \int_t \bar{S}^* \bar{u}_\mu dt = \int_t \bar{v} \bar{S}_\mu dt - [\bar{v} \bar{u}_\mu]_{t_f}$$

The computations of the gradient descent then involve two stages, which correspond to the two terms on the right side of this equation. The first term is computed by use of the adjoint functions; the number of arithmetic operations in this computation is proportional to $N^2 L$, where L is the number of time steps used in numerical integration.

The main difficulty resides with the evaluation of the second term. To compute it, the authors introduce an auxiliary adjoint system of equations:

$$-\dot{z}_n + \sum_m A_{nm}^T z_m = \hat{S}_n, t > 0$$

By choosing

$$\begin{aligned} \hat{S} &= \bar{v}(t) \delta(t - t_f) \\ \bar{z}(t_f) &= 0 \end{aligned}$$

the authors can show

$$[\bar{v} \bar{u}_\mu]_{t_f} = \int_{t_0}^{t_f} (\bar{z} \bar{S}_\mu) dt$$

Note that, even though the authors selected $\bar{z}(t_0) = 0$, they are still interested in solving the auxiliary adjoint system, forward in time. Thus, the critical issue is how to select initial condition [i.e., $\bar{z}(t_0)$], that would result in $\bar{z}(t_f) = 0$. It has been demonstrated that these initial and final conditions are related via a propagation kernel. Hence, computation of $[\bar{v} \bar{u}_\mu]_{t_f}$ involves two substages: a kernel propagation that entails a number of arithmetic operations proportional to $N^3 L$, and a numerical integration that requires a matrix-vector multiplication at each time step and entails a number of arithmetic operations proportional to $N^2 L$. Thus, the overall number of arithmetic operations is approximately proportional to $N^3 L$. However, the amount of computer memory required is minimal, being proportional to only N^2 .

This work was done by Nikzad Toomarian and Jacob Barhen of Caltech for NASA's Jet Propulsion Laboratory. For further information, write in 132 on the TSP Request Card.

This invention is owned by NASA, and a patent application has been filed. Inquiries

"General Devices? Don't they make..."

Okay we admit we don't have the most descriptive com-

pany name in the world. Just so you'll know,

here's what we make. **Slides:** Hundreds

of standard Chassis Trak® telescoping slides —

solid bearing, roller bearing, ball

bearing and bottom mount models.

Cabinets & Racks: A

big selection of standard Vent Rak® products
for electronics, telecommunications equipment,

and more. **Accessories:**

Cooling modules, handles and pulls,

shelves, drawers, and much, much more.




Custom Engineering: Can't

find exactly what you need? We'll make it — even design

it — just for you. You see, our name

may be General Devices, but our

specialty is specific solutions.




General Devices Company, Inc.

1410 S. Post Road, P.O. Box 39100, Indianapolis, IN 46239-0100

For more information call 1-800-626-9484

SIMULATION AND TRAINING SYSTEMS



enables a workstation to emulate a 4-channel simulator by splitting and directing each quadrant to a separate display.



SPECTRUM®...
a visual communications company™


950 MARINA VILLAGE PARKWAY, ALAMEDA, CA 94501
TEL: (510) 814-7000 FAX: (510) 814-7026

For More Information Write In No. 421

THINK POROUS CERAMICS

Designing process applications? Diffusing? Dispersing? Venting? Filtration? Fluidizing? Thinking about using conventional porous metal, porous plastic, foam or fiber? Think porous ceramics instead. Porous ceramics offers well-defined, consistent pores, providing uniformity, durability, chemical and temperature resistance, rigidity, and greater mechanical strength than any other material. Think you could use more information? Call Dick at 1-800-633-2143. Ferro Corporation, Filtros

Plant, P.O. Box 389,
East Rochester, NY 14445



For More Information Write In No. 422

concerning nonexclusive or exclusive license for its commercial development should be addressed to the Patent Counsel, NASA Resident Office—JPL; (818) 354-5179. Refer to NPO-18586.

Synthesis of Realistic Animations of a Person Speaking

Sequences of video images are produced automatically.

*NASA's Jet Propulsion
Laboratory, Pasadena,
California*

The Actors computer program implements an automated process that synthesizes realistic animations of a person speaking. Previously, artists made such animations through a tedious, labor-intensive process usually for cartoons and cartoonlike productions. The present application of the automated process produces "newscaster" type video sequences. The process uses images of a person and, therefore, is not limited to cartoons and cartoonlike movies. Potential applications also include use of the process for automatically producing on-the-fly animations for human/computer interfaces and for reducing the bandwidth needed to transmit video telephone signals. In preparation for the automated process, one assembles a database of video images representing the subject's face uttering individual phonemes. From the database, Actors synthesizes a sequence of images that correspond to a given spoken phrase. When played back in real-time, the sequence of images appears as a movie of a realistic human figure speaking naturally.

This work was done by Kenneth C. Scott, David S. Kagels, Stephen H. Watson, Hillel S. Rom, Jean J. Lorre, John R. Wright, and Elizabeth D. Duxbury of Caltech for **NASA's Jet Propulsion Laboratory**. For further information, **write in 29** on the TSP Request Card.

In accordance with Public Law 96-517, the contractor has elected to retain title to this invention. Inquiries concerning rights for its commercial use should be addressed to:

William T. Callaghan, Manager
Technology Commercialization
JPL-301-350
4800 Oak Grove Drive
Pasadena, CA 91109

Refer to NPO-19494, volume and number of this NASA Tech Briefs issue, and the page number.

A Technical Event for Technical People

Communications Technologies	Advanced ASICs	ISO 9000
High-Speed Networks	Advances in FPGAs	Project Management
Portable Power	EDA Tools	Virtual Reality
Multimedia	Neural-Fuzzy Technologies	LANs
Microcontrollers	Quality Control Techniques	Embedded Systems
Microelectromechanical Systems	HDTV	Advanced Medical Technologies
Complex PLDs		Flat Panel Displays

Design, Test & Production Engineers,
Purchasing Professionals & Engineering Management
Will Find the Latest in These Technologies and More at **Wescon®/95**

1,200 Exhibits Conveniently Grouped
by Product Type On the Exhibit Floor

Advanced Microelectronic Devices, EDA Tools, Workstations,
Engineering Software, Computer Systems/Subsystems,
Active/Passive Components, Connectors/Interconnects,
Software/Networks, Test and Measurement Equipment,
and Production Products and Services

Technology on the Move



Solutions For Success



November 7-9, 1995

Moscone Convention Center • San Francisco, California

Free Admission to All Qualified Attendees

To register contact Electronic Conventions Management

8110 Airport Blvd. Los Angeles, CA 90045

800-877-2668 or 310-215-3976, Ext. 218 • FAX 310-641-5117 • E-mail wescon@ieee.com

NEW

For updates on the latest developments at Wescon/95

Visit Wescon's World Wide Web site at <http://wescon.com/wescon/>

Sponsored by the San Francisco Bay Area Council and Los Angeles Council, IEEE  Northern and Southern California Chapters, ERA 

Wescon recognizes the support of AEA  American Electronics Association, EIA  Electronic Industries Association, and Joint Venture Silicon Valley Network 



Compact, Automated, Frequency-Agile Microspectrofluorimeter

Advanced features would be combined to obtain a highly useful apparatus.

John F. Kennedy Space Center, Florida

A compact, reliable, rugged, automated cell-culture and frequency-agile microspectrofluorimetric apparatus is being developed to perform experiments that would involve photometric imaging observations of single live cells. In the original application for which it was conceived, the apparatus would operate mostly unattended aboard a spacecraft; potential terrestrial applications include automated or semiautomated diagnosis of pathological tissues in clinical laboratories, biomedical instrumentation, monitoring of biological process streams, and portable instrumentation for testing biological conditions in various environments. The appa-


ratus would offer obvious advantages over present laboratory instrumentation that is large and delicate, must be operated manually and attended frequently, and has limited capability for spectral measurement and/or imaging at only a few wavelengths.

The apparatus (see Figure 1) would contain modules that would accommodate multiple samples of live animal and plant cells, provide for automatic addition of various substances to stimulate the cells, bring cell cultures to a microscope stage for spectrally resolved illumination and spectrally resolved imaging, and translate the stage to scan for cells of interest. The specimen cul-

ture on the stage would be illuminated by light at a chosen wavelength or combination of wavelengths, and would be imaged in the microscope at another wavelength or wavelengths — for example, the wavelength(s) of fluorescence excited in a particular substance of interest that binds to specific cell components and is thus indicative of cell structure. A charge-coupled-device video camera attached to the microscope would acquire the image. A computer in the apparatus would process and store the spectrally resolved image data acquired by the camera.

Of the many advanced features of this apparatus, one would contribute the

*If you know the right people,
you can get an HP-IB card*



*just as easily as an
ordinary IEEE 488 card.*

most to its miniaturization, frequency agility, and ruggedness, and to its relative simplicity in comparison with other apparatuses in which various illumination and observation spectra are obtained by mechanical switching of fixed-wavelength, band-pass filters and dichroic mirrors. That feature is the use of one or two acousto-optical tunable filters (AOTF's): optionally, one to obtain the illumination spectrum by filtering light from a xenon arc lamp, and the other to select the wavelength(s) of light from the specimen to be imaged in the camera (see Figure 2). AOTF's are solid-state electronically tunable devices that have no moving parts, are small, and can be switched rapidly from one wavelength to another. A conventional mechanically switched monochromator of high wavelength resolution (0.5 nm resolution in the wavelength range of 400 to 520 nm) occupies a volume of about 2,250 in.³ (about 3.7×10^4 cm³) and can switch among a few wavelengths no more frequently than a few times per second. An AOTF designed to operate in the same spectral region would occupy a volume of only about 1 in.³ (about 16 cm³) and could be tuned continuously in wavelength and/or switched among an unlimited number




Figure 1. The **Compact, Automated, Frequency-Agile Microspectrofluorimeter** would be a versatile, portable apparatus that would be useful in microbiological, medical diagnostic, process-monitoring, and environment-monitoring applications.

© 1994 Hewlett-Packard Co. TMVXD455/NASA

Introducing Carol.



You can get IEEE 488 cards from a lot of places. But now that it's so easy to get them from HP, why would you go anywhere else?

All you have to do is call us. You'll talk to an experienced engineer like Carol, who will help you determine which

HP-IB card is best for you. We can also fax you specs or more information on our entire line of HP-IB products right away.

Prices start at just \$395. So call 1-800-452-4844, Ext. 8909 today. And introduce yourself to HP quality.

There is a better way.



of discrete wavelengths, with switching times of the order of 10 μ s.

This work was done by Salvador M. Fernandez and Ernest F. Guignon of Ciencia, Inc. for **Kennedy Space Center**. For further information, **write in 91** on the

TSP Request Card.

In accordance with Public Law 96-517, the contractor has elected to retain title to this invention. Inquiries concerning rights for its commercial use should be addressed to:

Ciencia, Inc.

111 Robert St. Suite C
East Hartford, CT 06108

Refer to KSC-11611, volume and number of this NASA Tech Briefs issue, and the page number.




Figure 2. The **Microscope Optics** in the microspectrofluorimeter would include an acousto-optical tunable filter, which would provide control of the image spectrum, with rapid switching or scanning of the wavelength passband(s).

Modified, Packaged Tortillas Have Long Shelf Life

Part of the water in the recipe is replaced with glycerin.

Lyndon B. Johnson Space Center, Houston, Texas

Tortillas have been made from a modified recipe and sealed in low-pressure nitrogen in foil pouches in an effort to increase their shelf life at room temperature. Preliminary tests show that the shelf life of these tortillas is at least five months; in contrast, commercial tortillas last only a few days.

The ingredients in the modified recipe are similar to those of the basic tortilla recipe except that some of the water is replaced by glycerin to inhibit the growth of microorganisms. It is particularly necessary to avoid *Clostridium botulinum*, which can grow in anaerobic environments and produce the deadly toxin that causes botulism. The minimum water activity (the ratio between the partial pressure of water in the tortilla and the partial pressure of pure water) below which *Clostridium botulinum* cannot grow is about 0.90.

Accordingly, the proportions of water and glycerin in the modified recipe (see table) were chosen by experimentation to achieve a sufficiently low water activity (about 0.88) to prevent the growth of *Clostridium botulinum* while maintaining acceptable taste. A preference test showed that there is no significant difference between the taste of the long-shelf-life tortillas and commercial tortillas.

Ferrous salts are added to each foil package to remove any oxygen that remains inside after sealing in the tortillas with nitrogen. These measures prevent mold and yeast from growing on the tortillas after packaging. The factor that limits shelf life is now the retrogradation of the starch fraction of the tortillas; that is, the tortillas grow stale.

This work was done by Charles Bourland of **Johnson Space Center** and Kimberly Glaus-Late of **Lockheed**

Engineering and Sciences Co. For further information, **write in 23** on the TSP Request Card. MSC-22406

Ingredient	Percent by Weight
Wheat Flour	61.79
Water	26.58
Glycerin	4.02
Shortening	3.71
Mono/diglycerides	1.24
Salt	0.99
Baking Powder	0.87
Dough Conditioner	0.31
Fumaric Acid	0.19
Potassium Sorbate	0.15
Carboxymethyl Cellulose	0.12
Calcium Propionate	0.03

The **Ingredients of Long-Shelf-Life Tortillas** are similar to those of ordinary tortillas, except that some of the water is replaced with glycerin to inhibit the growth of deadly *Clostridium botulinum*.

Books & Reports

These reports, studies, and handbooks are available from NASA as Technical Support Packages (TSPs) when a Request Card number is cited; otherwise they are available from the NASA Center for Aerospace Information.



Machinery

Experiment To Test Raster Scanning With RUM Actuator

A report describes a proposed experiment to demonstrate the feasibility of using a rotating-unbalanced-mass (RUM) actuator to effect raster scanning of an instrument mounted in a two-axis gimbal. [A conceptual RUM and an auxiliary RUM control mechanism are described in "Auxiliary Mechanisms for Rotating-Unbalanced-Mass Actuators" (MFS-28817), which appears elsewhere in this issue of *NASA Tech Briefs*.] The report discusses the design of the experimental apparatus, which would include a gimbal-mounted I-beam (to represent the scanning instrument), two RUM actuators on the beam to effect the rapid component of the raster motion, stepping motors at the gimbals to establish commanded center-of-scan angles and to effect the slow component of raster motion, and electronic control circuitry. The report presents the results of a computer simulation of the experiment, concluding that the apparatus should perform well in both line and raster scans and in both zero and normal Earth gravitation.

This work was done by W. D. Lightsey, D. C. Alhorn, and M. E. Polites of Marshall Space Flight Center. Further information may be found in NASA TP-3249 [N92-29677/TB], "Definition and Design of an Experiment To Test Raster Scanning With Rotating Unbalanced-Mass Devices on Gimballed Payloads."

Copies may be purchased [prepayment required] from the NASA Center for Aerospace Information, Linthicum Heights, Maryland, Telephone No. (301) 621-0394. Rush orders may be placed for an extra fee by calling the same number. MFS-28771

Shape-Memory-Alloy Actuator for Flight Controls

A report proposes the use of shape-memory-alloy actuators, instead of hydraulic actuators, for aerodynamic flight-control surfaces. An actuator made of a shape-memory alloy could convert thermal energy into mechanical work by changing shape as it makes the transitions between the martensitic and austenitic crystalline phase states of the alloy. Changes in shape can be tailored since the transformation temperatures can be selectively tuned over a broad range. The response times of a shape-memory-alloy actuator are directly controlled via the rates of heating and cooling. Because both hot exhaust gases and cryogenic propellant liquids are available aboard launch rockets, shape-memory-alloy actuators should be exceptionally suited for use aboard such rockets.

This work was done by Chris Barret of Marshall Space Flight Center. To obtain a copy of the report, "Launch Vehicle Shape Memory Alloy Actuation for Flight Control Augmentation Devices," write in 73 on the TSP Request Card.

Inquiries concerning rights for the commercial use of this invention should be addressed to the Patent Counsel, Marshall Space Flight Center; (205) 544-0021. Refer to MFS-31033.



Electronic Components and Circuits

Back-to-Back Barrier Varactor Frequency Multipliers

Two reports present further detailed information about the odd-harmonic frequency-multiplier devices described in "Barrier/ n/n^+ Varactor Frequency Multipliers" (NPO-18428), *NASA Tech Briefs*, Vol. 16, No. 8 (August, 1992), page 28. These devices comprise Schottky-barrier/ n/n^+ diodes in a planar back-to-back configuration. The symmetry of the configuration gives rise to symmetry of nonlinear voltage-vs.-current characteristics, with resultant suppression of even harmonics and elimination of the need for dc bias.

This work was done by Debabani Choudhury, R. Peter Smith, Suzanne C. Martin, Antti Räisänen, and Margaret A. Frerking of Caltech for NASA's Jet Propulsion Laboratory. To obtain

copies of the reports, "Characterization and Analysis of Back-to-Back Barrier- $N-N^+$ " (bbNN) Varactor Devices for Millimeter and Submillimeter Wave Frequency Multipliers," and "Experimental Evaluation and Theoretical Analysis of Back-to-Back Barrier- $N-N^+$ " (bbNN) Varactor Frequency Multipliers for Millimeter and Submillimeter Wave Applications," write in 62 on the TSP Request Card. NPO-19232



Mechanics

Uncertainty in Measuring Loads on Launch-Pad Supports

A report describes a study of uncertainty in measurements of loads in structural members of the launch pad of the space shuttle. The measurements were taken by strain gauges installed on the members. Calibration data for the study were obtained by removing each thus-instrumented member from the structure and measuring its individual response on a test stand.

This work was done by J. S. Townsend of Marshall Space Flight Center and J. A. Richardson of the University of Alabama. To obtain a copy of the report, "Characterizing the Uncertainty in Holddown Post Load Measurements," write in 42 on the TSP Request Card.

Inquiries concerning rights for the commercial use of this invention should be addressed to the Patent Counsel, Marshall Space Flight Center; (205) 544-0021. Refer to MFS-28861.

Mass-Additive Vibration Testing of Constrained Structures

A report describes a study of the mass-additive method of modal survey testing of flexible structures that, in normal use, are constrained by other structures. In the mass-additive method, a structure that would normally be constrained by another structure is suspended freely and extra masses are attached to its boundary. The free-free vibrational mode shapes of the mass-loaded structure are measured and used to estimate the constrained-boundary modes of the structure in the absence of additional masses. Both the measured free-free vibrational modes and the esti-

mated constrained modes may be used to assess accuracy of a mathematical model and to update or refine the model.

This work was done by John R. Admire, Michael L. Tinker, and Edward W. Ivey of Marshall Space Flight Center. To obtain a copy of the report "Mass-Additive Modal Test Method for Verification of Constrained Structural Models," write in 10 on the TSP Request Card. MFS-28998

Studies of Residual Flexibility and Vibration Testing

A collection of reports presents theoretical and experimental studies in which the concept of residual flexibility is applied to modal vibration testing and verification of mathematical models of vibrations of a flexible structure constrained by another structure. "Residual flexibility" represents the effects of higher frequency structural modes not measured in the test. That is, it denotes that part of the interface flexibility due to mode shapes out of the frequency range of the test. These studies are directed, in particular, toward assessing the residual-flexibility approach as a substitute for fixed-base vibrational testing of payloads that are to be installed in spacecraft.

This work was done by John R. Admire, Michael L. Tinker, Paul S. Bookout, and Edward W. Ivey of Marshall Space Flight Center. To obtain copies of the reports, "Residual Flexibility Test Method for Verification of Constrained Structural Models," "Shuttle Payload Modal Testing Techniques," "Analysis of Residual Flexibility Modal Test Data," "Statistically Generated Weighted Curve Fit of Residual Functions," "Measurement of Residual Flexibility for Substructures Having Prominent Flexible Interfaces," and "Cost-Effective Test Methods for Shuttle Payloads," write in 71 on the TSP Request Card. MFS-28999



Materials

Depositing Adherent Ag Films on Ti Films on Alumina

A report discusses the cleaning of ceramic (principally, alumina) substrates in preparation for the sputter deposition of titanium intermediate films on the substrates followed by the sputter deposi-

tion of outer silver films. In the principal intended application, the substrates would be sliding parts in advanced high-temperature heat engines, and the outer silver films would serve as solid lubricants: the lubricating properties were described in "Solid Lubricant for Alumina" (LEW-15495), NASA Tech Briefs, Vol. 17, No. 12 (December, 1993), page 65.

This work was done by Frank S. Honey of Lewis Research Center. To obtain a copy of the report "Deposition of Adherent Ag-Ti Duplex Films on Ceramics in a Multiple-Cathode Sputter Deposition System," write in 67 on the TSP Request Card. LEW-15906

Electrically Conductive White Thermal-Control Paint

A report describes the development of a white thermal-control paint intended for use on spacecraft. The paint was required to exhibit a combination of high emittance (≥ 0.90), low absorptance (≤ 0.20), and electrical conductivity sufficient to prevent charging with static electricity to potentials beyond the range of ± 10 V. In tests, it exhibited an average measured emittance of 0.91 and an average measured absorptance of 0.20.

This work was done by Cheng-Hsien Hsieh, Gustaf A. Forsberg, and Timothy P. O'Donnell of Caltech for NASA's Jet Propulsion Laboratory. For further information, write in 65 on the TSP Request Card. NPO-19243



Computer Programs

Technology of Controlled-Environment Agriculture

A report discusses controlled-environment agriculture (CEA) for commercial production of organisms, whether plants or animals. Using controlled ecological life-support systems, environments are manipulated to fulfill human requirements for food, oxygen, and water by regenerative processing of waste streams to supply plant inputs. CEA is already being practiced in greenhouses to produce food on nonarable lands. The report describes a conceptual regenerative system that incorporates biological, physical, and chemical processes to support humans in extraterrestrial environments. Green plants would utilize light energy to produce potable water,

food, and oxygen while removing carbon dioxide, water, and inorganic elements from air and waste streams. Recycling of resources would involve the use of energy to control the fluxes of various materials in a biologically stable setting.

This work was done by David L. Bubenheim of Ames Research Center and Maynard E. Bates of The Bionetics Corp. To obtain a copy of the report, "Applications of CELSS Technology to Controlled Environment Agriculture," write in 53 on the TSP Request Card. ARC-13219



Manufacturing/Fabrication

Apparatus for Making Glass Fibers Without the Aid of Gravity

A report describes an apparatus for making optical fibers in microgravity. The apparatus includes a sting that makes initial contact with softened glass to start drawing a fiber. The absence of gravity helps to suppress the nucleation of crystallites, which increase scattering of light and thus reduce the transmission of light along a fiber. To prevent abrasion of the surface of the fiber and absorption of water in the fiber, an ultraviolet-curable acrylic material can be automatically applied.

This work was done by Dennis Tucker of Marshall Space Flight Center and Guy A. Smith and Gary Workman of the University of Alabama in Huntsville. To obtain a copy of the report, "A Glass Fiber Pulling Apparatus for Use in Low Earth Orbit," write in 89 on the TSP Request Card.

Inquiries concerning rights for the commercial use of this invention should be addressed to the Patent Counsel, Marshall Space Flight Center; (205) 544-0021. Refer to MFS-26339.

Welding Using Chilled-Inert-Gas Purging

A report describes a study of fusion welding using chilled inert gas. Marked improvement was shown in the welding of aluminum using chilled helium gas. Purging with inert gas during welding of a metal has produced improvements in the finished surfaces of weld roots, with formation of relatively smooth surfaces and suppression of formation of oxides.

continued on page 94

TECHNOLOGY LEADERS

Profiles Of Pathsetting Companies Serving The Engineering Field

ADAPTIVE RESEARCH

Adaptive Research of Huntsville, Alabama, is a leading developer of Computational Fluid Dynamics (CFD) software for simulation of physical processes involving fluid flow and heat transfer. Adaptive was acquired last year by Pacific-Sierra Research Corp. of Santa Monica, enhancing the financial and technical resources of the experienced CFD research and development operation. Following 23 consecutive years of growth and nearly \$30 million in revenues in 1993, the new acquisition reaffirms Pacific-Sierra's commitment to expand investment in advanced scientific

software products. Pacific-Sierra is healthy, debt-free, and 100% employee owned.

Adaptive's CFD2000® software offers a fully integrated solution for modeling fluid flow, heat transfer, and other physical phenomena. From the intelligent window environment, the analyst can address all aspects of the simulation—including geometry and computational grid, fluid and material properties, initial and boundary conditions, solution monitoring and control, and even 3D field visualization and animation.

Adaptive Research is positioned on the leading edge of CFD tech-

nology with new methods utilizing unstructured grid generation and adaptive mesh refinement techniques. Linear tetrahedral elements and automatic remeshing allow for flow calculations over very complex surface shapes and can even compute the associated rigid-body motion dynamics.

In Santa Monica, Pacific-Sierra's Computer Products group is a leading authority on Fortran 90 compiler products, automatic parallelization software for high-speed systems, and superscalar Fortran and C optimization technology. The VAST® System is a suite of software tools that opti-

mize and translate Fortran and C programs on today's superscalar workstations, parallel processors, and mainframe supercomputers.

For more information, contact Pacific: Computer Products Group, Pacific-Sierra Research Corp., 2901 28th St., Santa Monica, CA 90405; Tel: 310-314-2300; Fax: 310-314-2323; E-mail: info@psrv.com.

Adaptive Research Division, 4960 Corporation Drive, Suite 100A, Huntsville, AL 35805; Tel: 205-830-2620; Fax: 205-830-2628; E-mail: info@arc-cfd.com.

For More Information Write In No. 760

ALGOR, INC.

Algor Houdini: the Only Automatic CAD Solid Model to 8-Node "Brick" Finite Element Mesh Converter

Algor, Inc. is a leading maker of mechanical engineering analysis and design optimization software for UNIX, Windows NT, and Pentium processor-based workstations. More than 11,000 engineers in more than 60 countries use Algor software.

Algor's Houdini is the first software which takes CAD solid models from Pro/ENGINEER, EDS/Unigraphics, CATIA, AutoCAD, Cadkey, Intergraph, SDRC, and others and automatically creates 8-node "brick" finite element meshes for use in popular FEA programs, including Algor, Abaqus, Ansys, Cosmos, Nastran, NISA, Patran, Procast, and SDRC.

Houdini's Menupak user interface streamlines the mesh generation process and presents input and output file format choices on

a single screen. Houdini's many advanced global mesh control options are specified from a point-and-click menu.

Houdini is featured in *The World of Houdini*, a new video training kit that demonstrates how to use Houdini in a variety of modeling scenarios. These include automatic 8-node "brick" finite element mesh generation, global mesh optimization controls, and advanced mesh manipulation capabilities which help engineers deal with complex finite element modeling and analysis challenges.

The video training kit includes a high-quality video, the complete training notes from Algor's two-day Houdini Education Seminar, a CD-ROM with the models used in the video, and Viewpak software for viewing the



models on your computer.

Houdini enables engineers to have the level of control over the generated mesh desired for their analysis needs. *The World of*

Houdini video training kit helps engineers develop the skills needed to use Houdini more effectively.

For More Information Write In No. 761

ANSYS, INC.

ANSYS, Inc., located in Houston, PA, has been a leader in design and analysis software for 25 years. John Swanson, the com-

pany founder and chief technologist, is internationally recognized as an innovator in computer software technology. TA Associates, a


large investor in growth companies, recently acquired majority ownership in ANSYS. Peter Smith, a former top executive with Digital Equipment Corporation, has been named chief executive officer and will lead ANSYS into its next growth phase.

ANSYS is one of the most widely recognized large-scale programs for finite element analysis (FEA), allowing engineers to construct computer models, apply design criteria, and analyze responses. It is used in a variety of industry applications, including aerospace, government, defense, power machinery, biomechanics, and electronics.

ANSYS solves complex design problems because of its powerful capabilities, including preprocessing, postprocessing, and design optimization, along

with structural, thermal, magnetic, fluid flow, coupled field, and nonlinear analyses. ANSYS Revision 5.1 features a completely redesigned graphical user interface (GUI) focusing on ease of use.

The illustration shows a 3D model of the HPOTP (High Pressure Oxidizer TurboPump), used on the space shuttle. Engineers at Sverdrup Technology, Marshall Space Flight Center, worked in conjunction with Pratt and Whitney to design an improved turbopump to replace one built in the 1970s. The different colors represent components or the element type numbering for the different regions of the housing.



Contact: ANSYS, Inc., 201 Johnson Road, Houston, PA 15342-1300; Tel: 412-746-3304; Fax: 412-746-9494.


For More Information Write In No. 762

ASTRO-MED, INC.

Astro-Med challenged the established beliefs of the recorder industry eight years ago when it introduced the first all-recorder chart recorders with "no moving parts," thus casting aside galvanometric technology that depends on a moving stylus to record data.

Since that time, Astro-Med has introduced four generations of its "New Technology" recording systems, each more powerful than its predecessor, and today Astro-Med believes that it is the industry leader. R&D is the key to Astro-Med's success. The company spends 7% of its revenue annually on new product development.

The MT95K2 is a typical example of Astro-Med's wave of revolutionary product development. Not only does it operate with "no moving parts" and record with laser printer resolu-



tion, but the recorder permits the user to see the data on a monitor as it is being recorded on chart paper. In addition, the user can program the recorder through a floppy disk as well as store the data internally for subsequent

review. These are but a few of the advanced features that have put the K2 in a class by itself.

Recently the Dash IV and Dash 10 portable recorders joined the New Technology recorder family. Each offers unsurpassed capabilities

combined with true portability provided by its internal battery, and both have big, bright, high-response monitors for viewing data and for easy chart setups.

Astro-Med has also extended its technology to other specialty printers. One specialty printer, the Tough Printer, is a ruggedized high-speed printer that supports multiple printer languages such as Postscript and PCL5. The Tough Writer is ideal for use on aircraft test flights, on ships, or in heavy industry.

With its R&D efforts continuing in high gear, Astro-Med has several exciting new graphic recorder products in various stages of development.

Contact: Astro-Med, Inc., Astro-Med Industrial Park, West Warwick, RI 02893; Tel: 800-394-3633; Fax: 401-822-2430.

For More Information Write In No. 763

DATA TRANSLATION

Data Translation's DT-Open Layers Software for Windows Makes Your Job Easier

Data Translation's® two premier applications under the DT-Open Layers® standard for Windows™ development offer you unparalleled ease-of-use and productivity gains without compromising power and functionality.

DT VEE™ for Windows is a comprehensive visual programming language that uses icons or objects, instead of text, to develop your data acquisition applications—fast.

Begin with DT VEE's high-level objects that acquire, process, display, and share data. Program intuitively by connecting these objects in a logical sequence. Then run. It's that easy.

DT VEE's graphical user interface creates the man-machine interaction you need, whether it is for detailed laboratory applications, production line controls or manufacturing test.

Programs can be changed dynamically—add, replace, or delete objects on-the-fly—for fast debug. Automatic wiring makes connections between



objects foolproof—DT VEE won't let you create "bad" wires.

You can expand capabilities by creating user objects that combine DLLs, other DT VEE objects, or your own tried-and-true algorithms. You can create your own objects, too, and reuse your code from application to application.

DT VEE is fully compliant

with the DT-Open Layers standard. Plus, DT VEE is based on HP VEE for Windows™, and is backed by the Hewlett-Packard and Data Translation commitment to quality.

GLOBAL LAB Image® marks a revolutionary advancement in PC-based scientific image analysis. An innovative architecture

accommodates Add-In Modules that allow you to easily incorporate a variety of specialized functions into the already feature-rich GLOBAL LAB Image.

GLOBAL LAB Image puts an end to compromise. Modularity gives you the ability to add powerful, new capabilities to the easiest-to-use imaging package, while retaining its affordability. New modules are written as Windows DLLs, and their icons appear as tools in the GLOBAL LAB Image toolbox. In these ways, GLOBAL LAB Image continues to grow with your changing application needs.

Both DT VEE and GLOBAL LAB Image run on Data Translation's new data acquisition boards and frame grabbers for the PCI bus.

To test-drive DT VEE or GLOBAL LAB Image, call for a free evaluation at 800-525-8528.

For More Information Write In No. 764

DAVID SARNOFF RESEARCH CENTER

The David Sarnoff Research Center, a subsidiary of SRI International, conducts research in consumer electronics, solid-state physics, materials science, and communications.

Sarnoff is a client-supported facility with expertise in software and digital IC design, process and materials research, digital signal processing hardware and software, electro-mechanical devices, and displays. This expertise is applied to projects for both commercial and government customers.

Many of the major advances in electronics during the past 50 years have been pioneered at Sarnoff in West Windsor, NJ. Originally it was established as RCA Laboratories, but after RCA was sold to General Electric in 1986, the Sarnoff Center became part of SRI International, in Menlo Park, CA. Developments made at Sarnoff include color television, high-speed computer

memories, injection lasers, liquid crystal technology, solid-state amplifiers for satellite communications, MOS transistors and logic arrays, and optical and capacitive video disc systems.

To be competitive in the



The David Sarnoff Research Center offers a full line of visible and infrared detectors and cameras, as well as III-V semiconductor components.

Information Age, Sarnoff is finding new and different ways to "partner" with clients to leverage resources and maximize benefits.

Rather than adhere to one narrowly defined business model, Sarnoff's approach is to be flexible and to add value to product development.

Examples of partnering efforts include continuing participation in the Grand Alliance, which is developing a system for HDTV; membership in the Phosphor Technology Center of Excellence, bringing together academia, government, and industry to develop advanced phosphor technology; and being a founding member of the Consortium for Educational

Process and Technology to develop collaborative and long-distance learning techniques.

Sarnoff is also commercializing

some of its own technologies through new spin-out companies. SENSAR, the first spin-out, was introduced in 1992 to commercialize computer vision hardware and software, and now has three products on the market. A second company will target the video server and video production markets.

Whether it be helping a client bring a product to market, forming alliances to advance R&D, or spinning out new companies that will attack electronic imaging problems, Sarnoff expects to play a significant role in the evaluation of digital imaging technologies.


For more information, please contact Manager, Media Relations, David Sarnoff Research Center, CN 5300, Princeton, NJ 08543-5300; Tel: 609-734-3038; Fax: 609-734-2870.

For More Information Write In No. 765

DIGITAL EQUIPMENT CORPORATION

More than two years ago, Digital Equipment Corporation began charting a new course to reflect the rapidly changing dynamics of the marketplace and of customer needs and expectations. In many ways, Digital returned to its roots as an industry leader in networking and enterprise-wide computing. But to adapt to a new competitive environment, the company had to make some fundamental changes in the way it does business—from organization structure to its approach to the market.

Although the process continues—in fact, it has accelerated in the last year—Digital already is a much different company. It is more focused on competitive products and services, and on delivering significant value to its customers and business partners. By building on a history of tech-



Digital's Alpha chip—a performance leader in the microprocessor industry.

nological innovation, Digital is delivering superior new products that will help make its customers more efficient and productive.

The proof, of course, is in Digital's performance and ability to deliver value to its customers. The company is determined to be a profitable, growing company and the computing technology partner of choice for customers and business partners, as displayed by Chairman Robert B. Palmer

in the core value statement:

"We have the ability—directly and through our partners—to implement and support networked platforms and applications in multivendor environments more quickly and cost effectively than anyone else.


"This capability is making Digital the leader in open client/server computing—the combination of technologies that enables PCs, laptops, workstations and other devices to tap into computers so that these systems and the people who use them can share data and work together."

For more information about Digital, visit the World Wide Web at <http://www.digital.com>, or send E-mail to: moreinfo@digital.com.

For More Information Write In No. 766

DSP DEVELOPMENT CORPORATION

Data Acquisition, Analysis, and Visualization Software



If your working life is consumed by collecting, analyzing, visualizing, crunching, and reporting on your data, you should be interested in DADiSP. DADiSP is a visually-oriented

software package for the display, management, analysis, and presentation of scientific and technical data. If you collect, manipulate, edit, reduce, transform, display, or analyze your data, and you

don't want to have to program, DADiSP can handle and simplify your data needs. In short, DADiSP improves your day-to-day productivity. Point-and-click operations, icons, buttons, and pop-up menus let you choose from hundreds of functions. We could continue describing the product, but read what customers say, and then call for a FREE product trial:

- "...able to complete at least 50% more work in the same amount of time..."
- "The ability of DADiSP to provide custom time series data analysis without modifying or writing software makes the program a very powerful tool."
- "Simplicity itself to use. The graphical waveform processor equivalent of a powerful word processor. The use of DADiSP has dramatically decreased the time spent extracting and analyzing data."

• "There is a wealth of built-in functions available...the worksheets and types of analysis possible are virtually unlimited..."

Users in industry, government, and education have successfully applied DADiSP in the following areas: • data analysis • data acquisition and input • scientific visualization • data management • graphics • signal processing • statistical analysis • test and measurement • laboratory automation • experimental hypothesis testing • communications • medical research • image processing • quality management • process monitoring • physiology experiments • noise and vibration analysis • radar and sonar analysis.

Contact: DSP Development Corp., One Kendall Square, Cambridge, MA 02139; Tel: 617-577-1133; Fax: 617-577-8211; E-mail: info@dadisp.com; Internet: <http://www.dadisp.com>.

For More Information Write In No. 767

EPIX, INC.

Tomorrow's Imaging Today

EPIX provides state-of-the-art hardware and software to OEMs, system integrators, VARs, and end users in the image processing industry through its flexible image acquisition, processing, and display hardware and supporting software for PC/AT-compatible computers.

EPIX imaging boards and software interface to almost any video source, including video cameras, recorders, high-resolution and/or high-frame-rate cameras, line-scan cameras, and medical and graphical displays. User-customizable, menu-driven image analysis software for DOS and Windows provides morphology, blob analysis, motion analysis, densitometry, measurement, filtering, transforms, archiving, and annotation. C libraries are also available, providing comprehensive support for programmers.

The 4MEG VIDEO Model 12, available with 4, 16, or 64 Mbytes of on-board memory, features programmable memory configurations—high resolutions up to

31,000 pixels per line, or up to 16,000 lines; or lower resolutions for image sequences with over 65,000 frames—and 50-MHz capture and display rates using an internal or external pixel clock. Also featured is a 12-MIPS on-board digital signal processor which performs 12 million instructions per second.

The **IMAGE MEMORY EXPANSION** allows up to 256 Mbytes of image memory to be added to the Model 12 for real-time capture of 872 images, 640 pixels by 480 lines, storing 29 seconds of video at 30 fps! Image memory is upgradable to adapt to expanding applications. All features of the Model 12 are available with the addition of the **IMAGE MEMORY EXPANSION**, including sequential capture, configurable




image buffers, programmable video formats, image display, and on-board processing. The **IMAGE MEMORY EXPANSION** supports all Model 12 camera interfaces operating at data rates between 2 MHz and 30 MHz.

The **COC402** (pictured) is designed to enhance the 4MEG VIDEO Model 12 board with additional processing power. The **COC402**, for the ISA (PC) bus, features two Texas Instruments

50-MHz, 32-bit, TMS320C40 digital signal processors. The **TMS320C40s** can perform parallel processing at up to 550 million operations per second. The **COC402** allows video-rate processing of basic operations and highly accelerated execution of complex operations. The **COC402** was

designed to allow user-developed programs to be executed as quickly as possible. A combination of zero-wait-state static RAM (SRAM) for program storage and communication provides program execution at maximum speed.

Specialized area and line-scan camera interface cards and video multiplexers are also available.

For More Information Write In No. 768

GAGE APPLIED SCIENCES, INC.

Manufacturer of the World's Fastest PC-Based Data Acquisition Products

Gage Applied Sciences, Inc. was founded in 1987 by a group of Canadian engineers and entrepreneurs with a mandate of designing, manufacturing and marketing high-quality, high-speed data acquisition and instrumentation products based on the IBM PC platform.

Today, Gage is the recognized leader in the ultra-fast data acquisition market with its family of multi-MegaHertz A/D and D/A cards for the ISA bus.

World's Fastest 12 bit A/D Board

Gage manufactures the world's fastest 12 bit A/D system, the 60 MSPS **CompuScope 6012**, available on any platform.

Other products include the 250 MSPS **CompuScope 2125** and many other models which provide excellent performance at a reasonable price.

One of the most unique features of the CompuScope product line is the very deep data buffers it

offers: up to 16 million samples. This allows the user to digitize an analog signal at very high speeds for a very long period of time.

Software Support

In addition, Gage supplies its powerful **GageScope** scope-emulation software which can be used to evaluate the usefulness of a particular CompuScope card in an application without writing a single line of programming code! Drivers are also available for custom programming.

Applications

CompuScope cards have been used in many applications such as Non-Destructive Testing, Medical Ultrasound, LIDAR, Radar, Laser Doppler Anemometry, Telephony, Communications, etc.

The list keeps on expanding every day as scientists around the world figure out more ways of



using computers to solve problems by analyzing digitized data.

Due to rapid expansion, Gage has relocated to a bigger factory space. The new address is:

Gage Applied Sciences, Inc.,

5610 Bois Franc, Montreal, Quebec, Canada H4S 1A9; Tel: 1-800-567-GAGE or 514-337-6893; Fax: 514-337-8411; BBS: 514-337-4317; E-mail: prodinfo@gage-applied.com.

For More Information Write In No. 769

GENERAL DEVICES

Enclosures and Slides Meet critical Technical Requirements For Design Engineers

The technology required to develop and manufacture enclosure systems for electronic applications has progressed nearly as fast as the equipment the systems contain.

Forty-year-old General Devices first recognized the necessity for keeping up with components when company founder Herbert Fall, while serving as a World War II Naval officer, pioneered the telescoping slide, making "hard" rack-mounted equipment easier to access.

It was too obvious—slide the equipment to you for maintenance instead of completely disconnecting and removing from the rack.

General Devices uses flexible manufacturing methods to produce the basic components of Vent Rak® cabinets and racks. Standard components can be modified for unique applications:

- custom vertical panel openings, panel widths or cabinet depths
- specified access and control cutouts
- structural reinforcements
- special airflow provisions
- low or very high level EMI/RFI shielding.

RFI/EMI CABINETS

Solving RFI/EMI problems is most effective at the point of origin, but in many cases, the solution must be found downstream from the source. General Devices' Vent Rak cabinets provide the required shielding attenuation to meet military or commercial testing applications. Vent Rak cabinets of steel or aluminum act as a barrier between emitter and susceptor of EMF. These enclosures provide shielding by reflecting and absorbing the electromagnetic radiation.

Normally, the shielding effectiveness of a solid conductor barrier (steel or aluminum enclosure welded along all seams) can be sig-

nificant. However, it is not the limiting factor in achieving high shielding effectiveness. The amount of shielding achievable is controlled by barrier discontinuities such as apertures, seams, cable penetrations and air vents.

Shielding and cooling requirements demand air filters or vent panels that are opaque to EMI but still offer minimum resistance to air flow. Barrier discontinuities and seams are a necessary part of the enclosure design, which is also limited by production limitations, accessibility, and maintenance of the equipment to be mounted in the enclosure.



General Devices' enclosures and cabinets meet all military, commercial and consumer specifications governing EMI and RFI.

For More Information Write In No. 770

HUMMINGBIRD COMMUNICATIONS

Specializing in PC-to-main-frame communications services since 1984, Hummingbird began pioneering world-class PC X server software products in 1989. Its PC X products provide easy PC-to-UNIX and X Window System integration, making it possible for PC users to access the world of UNIX system functionality and features through a graphical user interface.

With the introduction of eXceed for Microsoft Windows PCs in 1991, Hummingbird became the first company to offer PC X servers for both the DOS and Microsoft Windows environments. In 1993, Hummingbird advanced its product line further with eXceed/NT, a Windows NT PC X server, and with eXceed/OS2, the first independent

PC X server for OS/2. Hummingbird is the only company to offer PC X integration products for all four (DOS, Windows, Windows NT - Intel, MIPS, and Alpha, and OS/2) PC platforms.

Today, Hummingbird, headquartered in North York, Ontario, Canada, is a publicly traded company (on both TSE and NASDAQ) with over 175 employees and with offices in Mountain View, CA; Washington, DC; Geneva,

Switzerland; Munich, Germany; Paris, France; and Leeds in the United Kingdom. Since its entrance into the PC X server market in 1989, Hummingbird has become a worldwide technology and market share leader, claiming the largest share of the PC X server market since 1991. The company has recently acquired Beame & Whiteside Software, recognized for its technology innovation and superior NFS solutions.

Hummingbird products are sold and supported in over 40 countries around the world—directly to major accounts and indirectly through major distributors and resellers. Supporting these efforts is a network of VARs, dealers and systems integrators.


Hummingbird offers the most comprehensive PC-to-UNIX integration product line available today. In addition

to X servers for all major PC operating systems and user environments, its software family includes X Development Toolkits for Microsoft Windows, Windows NT, and IBM OS/2, and serial connectivity PC X server software for high-speed access to X hosts over telephone lines, an important capability in today's mobile and fast-paced business world. All products adhere tightly to industry standards.

Hummingbird maintains a Home Page on the World Wide Web. You may reach it at: <http://www.hummingbird.com>.

For more information, such as product reviews, corporate details, independent market analyses, or to obtain evaluation software, contact Hummingbird sales at: 1 Sparks Avenue, North York, Ontario, Canada M2H 2W1; Tel: 416-496-2200; Fax: 416-496-2207.

For More Information Write In No. 771



INTEGRATED ENGINEERING SOFTWARE

Integrated Engineering Software (Integrated), a Canadian research and development organization, provides the international engineering community and scientific firms with 2D/3D electromagnetic Computer-Aided Engineering (CAE) software tools. All programs are based on our unique Boundary Element Method (BEM) solution, one of the most powerful and advanced field solution algorithms available.

Programs enable research engineers in both large and small organizations to test various physical and material configurations, examine new design concepts, and optimize designs for a wide variety of electromagnetic applications prior to actually building a costly prototype.

CAE Program Packages

Integrated program packages include MAGNETO (2D/RS) and AMPERES (3D), magneto-static field solvers; OERSTED (2D/RS) and FARADAY (3D), time-harmonic field solvers; ELECTRO (2D/RS) and COULOMB (3D), electrostatic

field solvers; and KELVIN (2D/RS), a heat transfer analysis solver. Currently under development is LATTICE (2D), a spice model generator mainly used in the design and analysis of printed circuit boards.

Analysis and Design Applications

MAGNETO, AMPERES, OERSTED, and FARADAY are used for designing and analyzing electrical/electronic equipment such as solenoids, transformers, magnets, AC/DC motors, recording heads, and charging fixtures. These four programs also cater to

linear, nonlinear, and permanent magnetic materials.

Use ELECTRO and COULOMB for the design and analysis of electrical/electronic equipment such as insulators, grounding electrodes, telecommunication cables, microstrip and integrated circuits, bushings, and transmission lines.

In addition to Integrated's electromagnetic analysis options, thermal analysis solver KELVIN is used for the design and analysis of heat transfer problems.

30-Day FREE Evaluation

Integrated offers a 30-day free evaluation of all full version software

to allow potential customers to test program capability with no obligation to purchase.

Fields which may have applications for Integrated products include the following: advanced mate-


rials, automation, computer hardware, defense industries, energy, manufacturing equipment and design, medical research, photonics and optics, scientific/laboratory equipment, subassemblies and components, telecommunications, transportation industries, etc.

Future Directions

The evolution of Integrated software depends, as Company President Dr. Y. Bulent Yildir states, on the needs of Integrated's diverse customer base. "For 10 years, Integrated has been a customer-driven company. To predict future enhancements to our current lineup of software, all one has to do is look at the future requirements of Integrated's customers."

Contact: Integrated Engineering Software, 46-1313 Border Place, Winnipeg, Manitoba, Canada R3H 0X4; Tel: 204-632-5636; Fax: 204-633-7780; E-mail: info@integrated.mb.ca.

For More Information Write In No. 772



IOTECH, INC.

Notebook & Desktop PC-Based Data Acquisition

IOtech, Inc. manufactures notebook and desktop PC-based data acquisition systems and IEEE 488 hardware and software for use in a wide variety of portable and stationary PC- and workstation-based applications. IOtech's parallel port-based portable data acquisition systems include PCMCIA and parallel port-based products that provide resolution from 100 kHz to 1 MHz and boast expansion channel capacities ranging from 72 to 256 channels. They are supported by an array of signal conditioning and expansion add-ons, including temperature, strain-gage, accelerometer, pressure, LVDT, high-voltage, current loop, isolation, filtering, simultaneous sample and hold, frequency, and digital I/O options.

IOtech recently introduced the WaveBook/512—the only 12-bit, 1-MHz notebook PC-based portable data acquisition product

available. A DSP-based multi-channel digitizer, the unit can acquire data at 1M sample/s over as many as 72 differential input

channels. Its functionality and expandability, combined with its lightweight and compact 8.5" x 11" x 1.375" form factor, make it the ideal solution for cramped on-board test applications. A typical WaveBook/512 system for vibra-



tion-analysis test, replete with power and signal conditioning options, weighs less than 10 pounds and fits neatly into a brief-

case for easy portability.

The WaveBook/512 is supported by an 8-channel simultaneous sample and hold card, an 8-channel programmable low-pass filter card, and an 8-channel dynamic signal input module. The

WaveBook/512 and all associated expansion and signal conditioning hardware can be powered from an included AC adapter, or from any 10 to 30V source, such as a 12V car battery. IOtech offers an optional rechargeable battery/excitation module, the DBK30A, that provides up to 3.5 hours of portable operation.

IOtech's PC-based data acquisition products include graphical Windows setup and acquisition applications; DOS and Windows drivers for most popular programming languages; VBX custom controls; and support for third-party software packages such as Snap-Master, LAB-TECH NOTEBOOK, DASY-Lab, and LabVIEW.

For further information, contact: IOtech, 25971 Cannon Road, Cleveland, OH 44146; Tel: 216-439-4091; Fax: 216-439-4093.

For More Information Write In No. 773

THE MACNEAL-SCHWENDLER CORPORATION

The world standard in finite element analysis software

The MacNeal-Schwendler Corporation (MSC) is the leading developer of finite element analysis (FEA) software used in the field of computer-aided engineering. The Predictive Engineering approach—simulating the performance characteristics of a design before it is built or before a physical prototype is developed—has saved companies hundreds of millions of dollars in research, design, engineering, and manufacturing.

FEA is an analytical method used by engineers to help determine how well structural designs survive in real-world conditions such as stress, vibration, heat and electromagnetic fields and forces. FEA operates on the premise that a complex structure can be divided into smaller elements to form a finite element model simulating the structure's physical properties. The model is subjected to rigorous mathematical analysis. The

results of the analysis can then be reviewed by the user in a variety of formats. From car horns to spark plugs to the Space Shuttle, FEA has significantly reduced the time and costs associated with proto-

mechanical components. Other products include MSC/ARIES for full-function solid modeling and FEM and FEA pre- and post-processing; MSC/EMAS, an electromagnetic analysis system for elec-

and results visualization capabilities to provide an open system environment to integrate computer-aided design, test, and analysis software; MSC/MVISION—the Materials Software System for Visualization, Selection, Data Integration—enables engineers to work in a concurrent manner to choose and exploit materials as a design variable. MSC's newest products include MSC/NAS-TRAN for Windows, bringing the user the power of MSC/NASTRAN into a PC environment, and MSC/NASTRAN for Pro/-ENGINEER.

All of MSC's software runs on a variety of platforms from PCs to supercomputers.

For More Information Write In No. 774



typing and physical testing. It also helps ensure product performance, safety and reliability.

The MSC product line includes our core product, MSC/NAS-TRAN, a powerful, highly flexible analysis program on an open architecture for analyzing the stress, vibration, and heat transfer characteristics of structures and

trical apparatus, EMC, RF & microwave, and antenna; MSC/DYTRAN, for solving highly nonlinear, transient dynamic problems; MSC/ABAQUS, for advance material models, special purpose finite elements, user specific routines, and coupled analysis procedures; and MSC/PATRAN with geometry access

THE MATHWORKS, INC.

MATLAB® Technical Computing Environment

Now employing over 250 people, The MathWorks Inc. was founded in 1984 and is located in Natick, MA. The founders of The MathWorks recognized the need among engineers and scientists for more powerful computation environments beyond that represented by procedural languages such as Fortran.

In response to that need, they

combined their expertise in mathematics, engineering, and computer science to develop MATLAB®, a high-performance technical computing environment that combines comprehensive math and graphics functionality with a powerful high-level language.

The MathWorks has also developed SIMULINK® for simulating nonlinear dynamic systems, Real-Time Workshop™ for real-time C code generation, and an extensive family of add-on products called toolboxes to meet the more specific needs of vertical-market scientific and engineering applications. Over 150,000 technical professionals today use MATLAB to explore, analyze, simulate, design, and solve their most complex and challenging problems.

MATLAB, the underlying numeric computation

foundation for all of The MathWorks products, combines hundreds of built-in mathematical functions with powerful 2D and 3D graphing capabilities. In addition, MATLAB offers an underlying programming environment that enables users to create their own functions in a fraction of the time required to write a program in Fortran, Basic, or C. MATLAB offers the convenience of an application package and the flexibility of a language to customize and add new functions as needed. These unique features have made MATLAB the industry standard for technical computing.

MATLAB has found widespread acceptance in diverse application areas where matrix theory plays an important role, such as signal processing, control system design, process identification, image processing, neural network design, and numerical analysis. The MATLAB application toolboxes have been created by


renowned experts in their respective fields and represent theory and algorithms at the cutting edge of scientific and engineering research. This solid algorithmic foundation assures maximum efficiency and reliable results.

NASA engineers and scientists nationwide have adopted the MATLAB Technical Computing Environment for several mission-critical research and design projects, including the next-generation High Speed Civil Transport. For researchers who require performance and cannot afford to be limited to "black box" functionality, The MathWorks continues to design and develop products based on an "open architecture." This approach enables users to extend MATLAB for custom applications and to meet their specific requirements.

For More Information Write In No. 775



NATIONAL INSTRUMENTS



National Instruments is leading a revolution in instrumentation-the Virtual Instrumentation Revolution. With virtual

instrumentation, personal computers and workstations are combined with software and hardware to build a powerful, but low-cost,

Instruments is dedicated to providing the highest quality products for data acquisition, data analysis, and instrument control. As part of our


instrumentation system. This complete system can consist of all the popular instrumentation alternatives, including plug-in data acquisition (DAQ) boards and GPIB, VXI, and RS-232 instruments.

dedication to quality, in 1993 we announced a new organizational structure that is compatible with the guidelines from the ISO 9000 standards, ensuring that we deliver products and service of unequalled quality to our customers. All of our products reflect the National Instruments commitment to high quality and innovation at a competitive price. We pledge to continue this commitment to you with investments in research and development that are well beyond industry norms. Likewise, our continued commitment to service will be demonstrated with a growing list of options for customer education and support.

For More Information Write In No. 776

NUMERA SOFTWARE CORPORATION

Numera Software Defines Ultra-Value Market



Numera is defining a new segment in the computer-aided design (CAD) industry-the "ULTRA-

VALUE" market. The ultra-value CAD market lies between the retail market and the value market with

typical prices under \$1,000. The following key components define the ultra-value market: high-end features typically found only in very expensive CAD packages; open architecture that allows a broad variety of third-party developers to create custom solutions using industry-standard programming tools such as Visual Basic® and Visual C++™; file compatibility with currently used CAD applications; and superior customer service and technical support.

Numera Visual CADD 1.2 is designed to attract a wide variety of CAD users. It is the first Windows CAD package compatible with the Microsoft Office suite of business applications, making it the logical

choice for the millions of Microsoft Office customers who need the precision and control that a CAD package offers. In addition, Visual CADD acts as an OLE 2.0 client, allowing linkage to a Word document or an Excel spreadsheet.

Visual CADD 1.2 offers several unique drawing features including: *Direct Distance*, which assigns an entity's length or size with a single key stroke; *tracking*, a navigational tool, referencing entities and locating points for edits, moves, and copying; and *matching*, which instantly extracts characteristics from any entity and applies them to the next command.

For more information, or to order Numera Visual CADD 1.2 directly, call: 800-956-CADD.

For More Information Write In No. 777

NYE LUBRICANTS INC.

Specialty Lubricants for Mechanical and Electromechanical Devices

Nye Lubricants designs and manufactures synthetic oils and greases that improve the efficiency and extend the operating life of highly engineered mechanical and electromechanical devices.

Founded as a whale oil enterprise in 1844, Nye began designing synthetic lubricants for OEM applications in the 1960s. The company maintains an extensive lubricant "drug store"—synthetic hydrocarbons, esters, polyglycols, silicones, polyphenyl and fluorinated ethers—and its engineers tap the different technical qualities of these functional fluids to deliver the best solutions to customers' design problems.

This approach to problem-solving has made Nye the vendor of choice for many of the world's most innovative component manufacturers. More than 50 Nye oils and greases are written into the

specifications of US automobile manufacturers and their component suppliers; two specify only Nye synthetic greases in antilock braking systems and air bag connectors. In other industries, Nye lubricants are specified in many dif-

ferent products including aerospace bearings, optical instruments, medical instrumentation, telecommunication connectors, electrical con-

trols, appliances and exercise equipment. In addition, leading computer and electronics manufacturers, NASA and the US military regularly turn to Nye for proprietary lubrication research projects.

Beyond their more than 400



ferent products including aerospace bearings, optical instruments, medical instrumentation, telecommunication connectors, electrical con-

synthetic oils and greases, Nye offers a unique array of specialty products, including fluorinated barrier films to control fluid and

oil migration, ultraclean lubricants for precision ball bearings, and proprietary index-matching gels that are used as connecting media for fiber optic splices. Nye also maintains the most extensive line of motion control "damping greases," a cost-efficient way to build smooth, controlled, quiet motion into mechanical and electromechanical devices. Electrically conductive greases, sonic coupling fluids, heat sink compounds, vacuum greases and vacuum pump fluids round out their specialty products.

To learn more about Nye products and services, contact: Don Fairbanks, Nye Lubricants, PO Box 8927, New Bedford, MA 02742-8927; Tel: 508-996-6721; Fax: 508-997-5285.

For More Information Write In No. 778

RAG ELECTRONICS, INC.

Over 20 years ago, Richard A. Gertzman founded RAG Electronics. RAG was one of the first companies to **provide high-quality, cost-effective, used test equipment backed by a warranty.**

To ensure long-lasting, trouble-free used test equipment, RAG has developed a **rigorous reconditioning process.** In RAG's state-of-the-art lab, all units are **fully calibrated and certified traceable** to the NIST in accordance with MIL-STD-45662A. RAG provides all manuals, standard accessories, and a six-month parts and labor **warranty.**

Used equipment is now more popular than ever before. RAG

sells to the U.S. Government, major universities, and primary and sub-contractors. Companies in all industries and sizes, from manufacturers to R&D firms and more.

RAG also **buys recent-model, pre-owned test equipment** such as RF and microwave equipment, spectrum analyzers, synthesizers, oscilloscopes, environmental chambers, power supplies and more. If you have equipment you're **no longer using**, you may find it advantageous to contact RAG and speak with someone in purchasing.

RAG is an authorized distributor of **new test equipment** from world-class manufacturers, in-

cluding **Tektronix** and **Fluke.** New test equipment is in stock, **ready to ship today.**

Providing **personalized service**, RAG assigns an expert RAG representative to meet your needs. RAG delivers the **fastest response** on quotes in the industry. If your requirement isn't in stock, RAG will **search nationwide** and quickly let you know what they find. With dozens of similar instruments on the market, a knowledgeable RAG sales engineer will help you select the right equipment for your application.

RAG's **free** catalog includes a wide range of instruments. The catalog subscription is free if you

call at 1-800-455-3457 or fax them at **1-800-272-4329.** Call if you have an upcoming requirement or you're looking for a specific item; RAG will gladly recommend the most **cost-effective solution**, fax the **data sheet** to you, and advise you of **price and availability.**


For More Information Write In No. 779

RESEARCH SYSTEMS, INC.

IDL 4.0 Offers Significant Enhancements in Math and Statistics, Scientific Functions, Programmability, and Documentation

IDL is an integrated computing environment for data analysis, visualization, and application development. IDL includes powerful image and signal processing routines, comprehensive 2D and 3D plotting, enhanced 3D visualization tools, hypertext on-line help, and extensive mathematics and statistics routines in the following areas: Curve and surface fitting, differential equations, eigensystems, FFTs and Wavelet transforms, multi-dimensional gridding, integration, linear systems, non-linear systems, optimization, special and transcendental functions, probability functions, correlation analysis, statistical fitting of data, hypothesis testing, multivariate analysis, frequency domain analysis, time series analysis and forecasting.

IDL's built-in interface controls allow engineers to build complete point-and-click applica-



tions that enable technicians and non-programmers to perform complex tasks. Also included are program debugging capabilities and tools for building IDL applications that maintain native hard-

ware "look and feel." Organizations can continue to take advantage of their software investments by using IDL's links that allow users to call their external programs or call IDL as a graph-

ics/plotting "engine" from their C or Fortran programs.

IDL is completely portable, giving users in heterogeneous labs confidence that their IDL applications will run the same no matter what their computer hardware. Personal computer versions include Windows, Windows NT, Macintosh, and native Power Macintosh. Workstation versions are available for DEC, HP, IBM, SGI, and Sun.

IDL prices range from \$1500 to \$3000.

For more information, contact: Research Systems, Inc., 2995 Wilderness Place, Boulder, CO 80301; Tel: 303-786-9900; Fax: 303-786-9909; E-mail: info@rsinc.com.


For More Information Write In No. 780

SOUTHCO, INC.

Southco, Inc. designs and manufactures industry's broadest line of latches and access hardware, offering value-added support such as:

- CAD drawing files of our products to facilitate your design efforts;
- Factory-trained field sales and engineering service-at your service;
- Total Quality Management for consistently high-quality products;
- Fast samples to help in your testing efforts;
- Southco engineering recommendations to assist you;
- Product modifications and custom design expertise to provide precisely the solutions you want.

Southco has received some of industry's most prestigious awards for quality, which helps recognize our company-wide efforts to meet today's demands for excellence, as well as our commitment to TQM.



Southco's systematic, prevention-oriented quality management efforts include:

Corporate Quality Council. Top management fosters the

importance of quality throughout the entire corporation through this council: giving direction, setting policies, and supporting the overall quality program.

Southco Quality Policy Manual. The comprehensive policy manual provides clear direction for the quality system and is supported by procedures and work instructions, giving every Southco employee the tools needed to take responsibility for quality.

ISO 9001. Southco is an ISO 9001 registered supplier.

Statistical Process Control. Southco manufacturing processes


employ stringent SPC methods to control quality from part-to-part and batch-to-batch. Each Southco operator, through in-house SPC training, becomes an authority on the process he or she controls.

Failure Mode Effects Analysis (FMEA). These preventive measures are conducted at the design and process stages to determine possible failures and their effects, before any customer buys the product.

For more information, contact: Southco, Inc., Brinton Lake Road, Concordville, PA 19331; Tel: 610-459-4000; Fax: 610-358-6314.

For More Information Write In No. 781

SYNRAD, INC.



Synrad, Inc., the world leader in sealed CO and CO₂ lasers, is proud of its technological achievements in its first 11 years. Synrad has grown from being a manufacturer of 10 and 25 watt CO₂ lasers to become the largest manufacturer of sealed CO and CO₂ lasers between 10 and

240W, as well as offering a full line of electro-optical components and subsystems for lasers with wavelengths ranging from excimer to CO₂. Synrad's latest innovation is the 60 Series laser, with output power up to 240W (pictured).

Synrad, Inc. was founded in

1984 by Peter Laakmann to do advanced research in electro-optics, including gas lasers. Synrad research and development resulted in a new implementation of radio frequency (RF) excited plasma section that paved the way for higher quality CO₂ and CO sealed-off lasers at much lower cost.

Synrad's CO and CO₂ lasers are built using a basic family of modules that are incorporated into all of the power levels, from 10 to 300W. The plasma discharge section and housing are aluminum extrusion. This patented "all-metal" technology allows for mass production and low

costs, and translates into superior quality lasers at a fraction of the price of competing lasers.

The competitive advantage enjoyed by Synrad has resulted in a sustained growth rate of over 50% in sales over the last few years. This impressive growth continues in 1995, in part due to the increasing number of new users of laser technology. Synrad CO and CO₂ lasers are an inexpensive and reliable alternative to existing mechanical tools such as hot knives, dies, routers, blades, milling machines, saws, etc. CO and CO₂ laser applications include cutting, marking, drilling, and heat treating of most non-metals, as well as engraving of anodized aluminum.

For More Information Write In No. 782

GOVERNMENT TECHNOLOGY SERVICES, INC. (GTSI®)

Uniting Government With Technology

GTSI is the leading reseller to the Federal Government of micro-computer and UNIX workstation hardware, software and networking products from the largest selection of brand-name manufacturers. GTSI specializes in offering a variety of mobile, desktop and engineering workstation computing solutions and cross-platform integration services for DOS/Windows, UNIX-RISC and Macintosh-based networking solutions. GTSI sells directly and indirectly to all departments and agencies of the Federal Government, many state and local governments, and hundreds of system integrators and prime contractors that sell to the government market.

In 1994, GTSI acquired Falcon Microsystems, which for ten years had been the leading reseller of Apple and other products to the government. This merger allows GTSI to offer its customers more

products, services and expertise than ever before.

GTSI provides about 40,000 products from over 400 manufacturers and is recognized as a true one-stop shop for technology-based solutions. GTSI makes these products available through a variety of important procurement vehicles such as GSA Schedules A and B/C, the Air Force Desktop IV contract, Navy Companion contract, Army Portables-1 contract, and the NASA SEWP contract.

GTSI has continued to expand its NASA SEWP contract and has added a variety of major product lines to provide NASA with a robust product offering of software, peripherals, x-terminals and multi-function products. New products include Apple Power Mac systems configured to provide full x-terminal functionality, Netscape, Oracle, ESRI and a variety of software product lines; a full spectrum of printer and

storage solutions, as well as a variety of telemetry products. In addition to all NASA centers, the contract is available to NASA contractors under cost-reimbursement contracts.

In 1995, GTSI unveiled GTSI Online—the first on-line service to provide electronic selection, ordering and payment of personal computer and workstation products for the government marketplace.

GTSI Online puts over 15,000 products—GTSI's entire contract offering—on your desktop.

With a constant focus on customer service and satisfaction,

GTSI sets the standard for, and is the undisputed leader in, providing technology solutions to the government market.


Contact: GTSI, 4100 Lafayette Center Drive, Chantilly, VA 22021; Tel: 800-999-4874; Fax: 703-222-5214.

For More Information Write In No. 783



AUTOFACT® '95 is the industry's premier conference and exposition for computer-based design and manufacturing technology. See computers involved in all aspects of the manufacturing process – including product design, integration and manufacturing.

New this year! Explore pavilions dedicated to PDM/EDM, Rapid Prototyping and Simulation. Plus, get the latest information on products in over 150 technology categories.



AUTOFACT®

November 14-16, 1995 • McCormick Place East • Chicago, Illinois
The Computer Technology Conference and Exposition for Manufacturing

RETURN COUPON

☐ **Yes, I'm interested in attending AUTOFACT '95.** Please send a brochure when available. (Approximately August 1, 1995).

Print or attach business card.

Name/Title _____
 Company/Division _____
 Address _____
 Mail Stop _____
 City/State/Zip _____
 Phone () _____
 Fax () _____

Mail or FAX to:
 Society of Manufacturing Engineers,
 Attn: Irene Tsatsanis,
 One SME Drive
 Dearborn, MI 48121-0930

Phone: 800/733-4763
 FAX: 313/271-2861

Call 800/733-3976 for information on exhibiting in AUTOFACT '95.



Society of Manufacturing Engineers

AF95/NASA

Call 800/733-4763 for a free brochure. Or, mail this coupon.

For More Information Write In No. 521

continued from page 80

Chilling the inert gas produces two additional benefits: one is the creation of an ultradense inert atmosphere around the welds; the other is that the chilled gas cools the metal more quickly down to a temperature at which the metals are not reactive. The report describes experimental welds made on aluminum in ambient air, under helium purge, and under chilled-helium purge. While a vast improvement was obtained by use of the helium purge, a further improvement was obtained by use of the chilled-helium purge.

This work was done by William F. McGee and Daniel J. Rybicki of Martin Marietta for **Marshall Space Flight Center**. To obtain a copy of the report, "Super Chilled Root Side Purging," **write in 60** on the TSP Request Card.

Inquiries concerning rights for the commercial use of this invention should be addressed to the Patent Counsel, Marshall Space Flight Center; (205) 544-0021. Refer to MFS-31010.



Mathematics and Information Sciences

Numerical Stability in Hyperbolic Boundary-Value Problems

A technical memorandum discusses the stability of numerical solutions involving semidiscrete approximations to hyperbolic partial differential equations in initial-and-boundary-value problems. This is a topic of practical significance because hyperbolic partial differential equations arise in the mathematical modeling of waves and blasts. Solutions are often needed over restricted regions of what would otherwise be unbounded spaces. The outer boundaries are then artificial, introduced only to limit the domains of the numerical solutions. The conditions at such artificial boundaries can cause numerical instabilities that degrade the computed solutions.

The solution of the semidiscrete approximation requires an extrapolation of the difference equation at the boundary where the boundary condition is not specified for the partial differential equation. This requires a numerical-boundary-condition scheme. The improper treatment of the numerical boundary conditions can cause numerical instability even though the semidiscrete approximation is stable for the pure initial-value or Cauchy problem.

This work was done by Robert F.

Warming and Richard M. Beam of **Ames Research Center**. To obtain a copy of the report, "Stability of Semidiscrete Approximations for Hyperbolic Initial-Boundary-Value Problems: Stationary Modes," **write in 21** on the TSP Request Card. ARC-12265

Finite-Element Modeling for Structural Analysis

A report presents a study of finite-element mathematical modeling as used in analyzing stresses and strains at joints between thin, shell-like components (e.g., ducts) and thicker components (e.g., flanges or engine blocks). As a result of the study, two basic approaches were suggested for determining correct values of stresses and strains. The first approach is to use a global/local model to evaluate the system. This provides the correct total response and a correct representation of stresses away from any discontinuities. The global model involves a coarse computational mesh; to minimize the cost of computation, finer meshes are used only to compute responses in local regions of interest. The second approach involves the development of special transition finite elements to model the transitions between shells and thicker structural components.

This work was done by J. B. Min and S. G. Androlake for **Marshall Space Flight Center**. To obtain a copy of the report, "An Assessment of Finite-Element Modeling Techniques for Thick-Solid/Thin-Shell Joints Analysis," **write in 82** on the TSP Request Card. MFS-28971

Constraint-Based Scheduling System

A report describes the continuing development of software for a constraint-based scheduling system that is to be implemented eventually on a massively parallel computer. The system is based on machine learning as a means of improving scheduling. The system is designed to learn when to change its search strategy by analyzing its search progress and learning the general conditions under which a resource bottleneck is likely to occur.

This work was done by Monte Zweben and Megan Eskey of **Ames Research Center**; Todd Stock, Will Taylor, Bob Kanefsky, and Ellen Drascher of Sterling Software; Michael Deale of Lockheed Engineering and Sciences

Co.; and Brian Daun and Gene Davis of RECOM Technologies. To obtain a copy of the report, "Constraint Based Scheduling," **write in 25** on the TSP Request Card. ARC-13215



Physical Sciences

Calibration of Partial-Pressure-of-Oxygen Sensors

A report and analysis of, and discussion of improvements in, a procedure for calibrating partial-pressure-of-oxygen sensors to satisfy Spacelab calibration requirements has been released. The sensors exhibit fast drift, which results in a short calibration period that is not suitable for Spacelab. By assessing the complete process of determining the total drift range available, the calibration procedure was modified to eliminate errors and still satisfy requirements without compromising the integrity of the system. The calibration period was extended from 32 days to over 90 days. The modified procedure involves bench calibration rather than expensive late mission-flow processing.

This work was done by David W. Yount and Kevin Heronimus of McDonnell Douglas Aerospace for **Marshall Space Flight Center**. To obtain a copy of the report, "Calibration Period Process for Spacelab PPO2 Sensors," **write in 20** on the TSP Request Card. MFS-31039

More About Measuring Interfacial Tension Between Liquids

A report presents additional discussion of a technique for measuring the interfacial tension between two immiscible liquids. The technique was described in "Measuring Interfacial Tension Between Immiscible Liquids" (LEW-15855), *NASA Tech Briefs*, Vol. 19, No. 1 (January, 1995), page 60.

This work was done by Nasser Rashidnia of NYMA, Inc.; R. Balasubramaniam of Case Western Reserve University; and David M. Del Signore of the University of Toledo for **Lewis Research Center**. To obtain a copy of the report, "Liquid-Liquid Interfacial Tension Measurement Using a Capillary Tube," **write in 3** on the TSP Request Card. LEW-15811

the solutions supersource

SEPTEMBER 12-14, 1995
DALLAS CONVENTION CENTER



Mobile/Wireless Computing

Infrastructure

Network Management

Windows

Media & Protocols

Interoperability

LAN/WAN

Windows NT

Network Computing

Groupware

Telecommunications

Internet

Client/Server

Multimedia

Network Security

NetWare®

Enterprise Networking

ATM

networks expo® Dallas '95 10th Annual

Networks Expo Dallas will feature every networking solution you need to know about — and provide the insight you need to make great buying decisions.

Start with our extensive exhibit hall, packed wall-to-wall with industry leaders: Novell, Microsoft, IBM, Hewlett-Packard, Banyan, AT&T, MCI and hundreds more. With thousands of solutions for gaining competitive advantage from your network.

You'll always see the cutting-edge network solutions and new products first at Networks Expo. And you'll learn about them at the most comprehensive Corporate Education and Training Program in the business: 60+ sessions covering today's best solutions for...

- LAN/WAN management and planning
- Groupware, wireless, client/server, mobile, telecommuting
- Optimizing NetWare 4.1, Windows 95 and NT
- High-speed networking, including ATM and Fast Ethernet

Network with the right people at Networks Expo Dallas. Get your hands on enterprise solutions from top companies at 16 interactive Network Professional Association (NPA) Hands-On Labs. Plan Internet strategy with the experts at our new Internet Pavilion featuring the interactive Internet Theater™. It's all here. All your solutions, all in one place. Networks Expo Dallas. Your solutions supersource.

CALL 801-655-8024 TODAY FOR ATTENDEE INFORMATION.
CALL 800-829-3976, EXT. 318 FOR EXHIBITOR INFORMATION.
OR MAIL/FAX THE COUPON BELOW FOR MORE INFORMATION.



Networks Expo is produced and managed by Blenheim Group USA, Inc.
Fort Lee Executive Park • One Executive Drive • Fort Lee, NJ 07024
800-829-3976 • 201-346-1400 • Fax 201-346-1602

Networks Expo® is a registered service mark of Blenheim Group USA, Inc. WINDOWS WORLD/Dallas Conference and Exposition is the property of INTERFACE GROUP - NEVADA, Inc. WINDOWS WORLD is produced in cooperation with Microsoft Corporation. WINDOWS WORLD, Windows, and the Windows logo are trademarks of Microsoft Corporation. NetWare® is a registered trademark of Novell, Inc. Novell, Inc. is not associated with the NetWare® Solutions Products Pavilion. Networks Expo is a trade event only. Minors under the age of 18 are not permitted on site. Your badge is nontransferable and will be confiscated and terminated upon any attempt to transfer or sell it. Networks Expo reserves the right to use photographs taken of you at the Show for promotional purposes. The Internet Theater™ is a trademark of Pencom Systems, Inc.

WINDOWS WORLD®
for desktop solutions:
One trip, two great events
Get your networking
solutions at
**NETWORKS EXPO
DALLAS**

Please complete and return this coupon by mail, or FAX to 201-346-1602, Attn: Jay Gorga.

Name _____ Title _____
(PLEASE PRINT)

Company _____

Address _____ City _____ State _____ Zip _____

Telephone (_____) _____ Fax (_____) _____

Please send me information about:

☐ Attending ☐ Exhibiting ☐ Corporate Education & Training Program

For the following Networks Expo event(s):

☐ Dallas (September 12-14, 1995) ☐ Boston (February 13-15, 1996)

LITERATURE SPOTLIGHT

Free catalogs and literature for NASA Tech Briefs' readers.
To order, write in the corresponding number
on the Readers Information Request Form (page 65).




COMPUTER CONTROLLED VALVES

Brochure describes company's line of remote and computer controlled on-off, metering and servo valves, pressure generators, automated pressure and flow control systems, pressure gauge calibration systems and capability for custom configurations. Pressure range from high vacuum to 60,000 psi. Tel: 607-257-5544. Toll Free in USA and Canada 1-800-825-5764. Fax: 607-257-5639. Address: 83 Brown Road, Bldg. 4, Ithaca, NY 14850.

Advanced Pressure Products

For More Information Write In No. 300




CYCLIC PRESSURE CONTROL SYSTEM

C.P.C.S. is a Windows-based automatic cyclic pressure control system. It supplies pneumatic or liquid cyclic pressure between the maximum and minimum values at a given fixed rate, allowing fatigue tests of a variety of samples such as artificial arteries. Advanced Pressure Products; Tel: 607-257-5544; from USA and Canada: 800-APP-VALVE; Fax: 607-257-5639.

Advanced Pressure Products

For More Information Write In No. 301




AUTOMATED PRESSURE GAUGE CALIBRATION SYSTEM

Fully Programmable Automated Pressure Gauge Calibration System, available in pressure ranges from vacuum up to 60,000 psi, Windows Control software provided. Both electronic and mechanical overpressure fail-safe systems with automatic pressurizing fluid refill system. Advanced Pressure Products; Tel: 607-257-5544; from USA and Canada: 800-APP-VALVE; Fax: 607-257-5639.

Advanced Pressure Products

For More Information Write In No. 302



PMI ANALYTICAL SERVICES

Porous Materials Inc. offers sample testing services including:

- * Gas and liquid permeability
- * Bubble point - largest pore size
- * Bulk and absolute density
- * BET single and multi-point surface area
- * Filter integrity
- * Pore analysis using mercury/non-mercury intrusion

* Adsorption/desorption isotherms, physisorption or chemisorption (H_2 , CO , H_2O , NH_3 , CO_2 and other gases), liquid sorption

* Particle size analysis
 Porous Materials Inc.; Tel: 607-257-5544; from USA and Canada: 800-TALK-PMI; Fax: 607-257-5639.

Porous Materials Inc.

For More Information Write In No. 303



APP ANALYTICAL SERVICES

Advanced Pressure Products offers a complete line of pressure and flow related services including the following:

- * Isostatic pressure testing
- * Burst testing
- * Compression testing
- * Pressure gauge calibration
- * Flow meter calibration
- * Fatigue testing
- * Leak testing

Advanced Pressure Products; Tel: 607-257-5544; from USA and Canada: 800-APP-VALVE; Fax: 607-257-5639.

Advanced Pressure Products

For More Information Write In No. 304




APP CUSTOM CONTROL SYSTEMS

APP can design custom control systems to meet your pressure and flow control needs. A full line of pressure and flow gauges, generators, regulators and valves can all be computer-controlled to solve virtually any problem you may have. Advanced Pressure Products; Tel: 607-257-5544; from USA and Canada: 800-APP-VALVE; Fax: 607-257-5639.

Advanced Pressure Products

For More Information Write In No. 305



GAS ASSIST INJECTION MOLDING UNIT

APP, the World leader in pressure and flow control systems, announces the first PC-Controlled (MS Windows Control Software) Gas Assist Injection Molding Equipment. This Flow Control System Allows for Varied Wall Thicknesses & Provides Unsurpassed Control Over Velocity of Advancing Plastic Melt Front. If you are in the injection molding business, you must contact us to hear about this revolutionary new control technique and 21st Century control software!! Advanced Pressure Products; Tel: 607-257-5544; from USA and Canada: 800-APP-VALVE; Fax: 607-257-5639.

Advanced Pressure Products

For More Information Write In No. 306



APP POSITION CONTROLLED VALVE

The Advanced Pressure Products Remote Position Controlled Valve provides a very cost-effective remote controller for metering valves. The valve is controlled by a single analog voltage which determines the desired position of the valve. The controller moves the valve to match this target position. Automatic limit protection is provided. Control can be provided from a simple remote potentiometer or an analog voltage or milliamp output. Advanced Pressure Products, Cornell U. Research Park, Bldg. 4, 83 Brown Rd., Ithaca, NY 14850-1298. Tel: 1-800-APP-VALVE (1-800-227-8258).

Advanced Pressure Products

For More Information Write In No. 307



PMI COMPLETE FILTER ANALYZER

The PMI Complete Filter Analyzer can solve all of your filter testing needs. It combines tests for bubble point, gas permeability (liquid permeability optional), pore distribution, and filter integrity. Raw filter material can be tested as well as complete filter cartridges. Porous Materials Inc.; Tel: 607-257-5544; from USA and Canada: 800-TALK-PMI; Fax: 607-257-5639.

Porous Materials Inc.

For More Information Write In No. 308

Parts Libraries - Computervision

Libraries of compiled macros for CADD5 5 & CADD5 4X create a wide variety of standard hardware items.

SOLIDS & WIREFRAME, INCH & METRIC

Programs will create all fastener holes • hex nuts • bolts all screws (soc. hd., slotted, phillips) • washers (flat, lock, spring) • pins (dowel, split, cotter, spiral) • retaining rings & grooves • structural beams (all) • pipe fittings • springs (compression, extension, torsion) • thread inserts & holes. 1000's of parts. Bill of Materials programs automate the process of tracking and creating BOMs, including creation of graphic BOM table and part labels, works without CADD5 Data Extract. Full 30 day DEMO available.

Also available: Layer Management System - automates layer lists, layer changes to models, much, much more.

Design Solutions Software Co.
Glen Mills, PA 19342 (610) 358-4054

For More Information Write In No. 309



INTRUPEDIA™ FROM NATIONAL INSTRUMENTS

National Instruments offers a free new CD-ROM of instrumentation information for building test and measurement, and process monitoring and control applications. The Windows-compatible Instrupedia features more

than 60 tutorial application notes to help users combine hardware and software to build computer-based systems for instrument control and data acquisition, analysis, and presentation. National Instruments; Tel: 512-794-0100; 800-433-3488 (US and Canada); Fax: 512-794-8411; E-Mail: info@natinst.com; WWW: http://www.natinst.com.

National Instrument

For More Information Write In No. 310




TIME AND FREQUENCY PRODUCTS

TrueTime's Precision Timing Products catalog features GPS-Synchronized Clocks in rackmount, portable, and board-level configurations. Includes illustrations and product specifications for our complete line of Synchronized

Clocks, Time Code Products, and Remote Displays to fit a variety of time and frequency applications.

TrueTime, Inc.

For More Information Write In No. 311



NONOXIDE CERAMIC POWDERS

The properties of boron nitride, titanium diboride and other nonoxide ceramic powders are described in a full-color brochure. Also included is information on various electronic and metallurgical applications, and the company's manufacturing,

quality analysis and customer service capabilities. Tel: 800-822-4322; Fax: 216-529-3975.

Advanced Ceramics Corp.

For More Information Write In No. 312




AIR FILTERS

Universal Air Filter Company manufactures custom-designed filter products for original equipment manufacturers. Universal filters are used extensively in the electronics, HVAC, digital switch, medical, defense, and data processing industries. The brochure describes applications and engineering and production capabilities. Universal Air Filter Company, 3400 Missouri Avenue, East St. Louis, Illinois 62203. Tel: 800-541-3478; Fax: 618-271-8808.

Universal Air Filter Company

For More Information Write In No. 313



REMOTE VIEWING INSTRUMENTS (RVI)

If you have requirements to observe or visually inspect items located in inaccessible areas or hostile environments, select from over 1500 RVI's outlined in this new product catalog from ITI. Borescopes, Fiberscopes and Videoscopes to provide sharp, clear images never before available. INSIGHT from the "Leader in Remote Viewing." Instrument Technology, Inc. Tel: 413-562-3606; Fax: 413-568-9809.

Instrument Technology, Inc.

For More Information Write In No. 314



RUGGED MINIATURE SWITCH

The new Series 70 is an environmentally rugged line of lighted and unlighted switches. Ready for wet, dusty or oily duty, the Series 70 is ideal for a variety of control and instrumentation requirements. Available with DPDT Momentary or Alternate switch actions. Mounts on 0.700" centers with 0.880" behind the panel space. Lighted pushbuttons use T-1 LED or Incandescent MFB lamps for a wide variety of display types, colors, and lighting styles. StacoSwitch, Inc., Costa Mesa, CA 92626. Tel: 714-549-3041; Fax: 714-549-0930.

StacoSwitch, Inc.

For More Information Write In No. 315



PRECISION MOTION CONTROL

API's 1995/96 172 page step motor systems catalog, featuring the new Intelligent Drive series, contains motion control technical, application and product data. Definitions, market applications, comparison charts, specifications

and diagrams simplify the selection process. API products range from full/half-step driver modules to high performance microstep systems. American Precision Industries, Motion Technologies Group, Controls Div., 45 Hazelwood Drive, Amherst, NY 14228; Tel: 716-691-9100; Fax: 716-691-9181.

American Precision Industries

For More Information Write In No. 316




NEW SEAL SELECTION GUIDE

American Variseal announces their new Seal Selection Guide for high performance spring-energized seals. This unique eight-page color manual describes Variseal's wide range of products for static, reciprocating and rotary service. Engineering charts include seal performance ratings at various pressures, temperatures and speeds. Also included are data on seal materials, gland design, surface finish, standard sizes, custom designs, and technical support. Call 1-800-466-1727.

American Variseal

For More Information Write In No. 317




High Speed DATA ACQUISITION SYSTEMS are designed to meet exacting measurement requirements. Components feature fast throughput and highly accurate digitizers (overall 0.1% accuracy with 100 kps to 200 Msps, and 32 Megapoints/channel). Automatic setups, analysis and touch screen controls in PC-based software add

excellent user interfaces for high speed dynamic measurements in the physical and material sciences. Hi-Techniques, Inc., 152 Owen Road, Madison, WI 53716; Tel: 608-221-7500; 800-248-1633.

Hi-Techniques, Inc.

For More Information Write In No. 318



PC-BASED TEST SOLUTIONS

FREE 40 page, 1995 PC-Based Test Solutions Source Book featuring PC based hardware, software and system products for ATE and Test & Measurement applications. Includes complete information on GTXI® instrumentation

chassis and systems, plus ATEasy®-ATE software development environment and instruments-on-a-card. Request your free copy today! 800-886-1201 or 714-263-2222; Fax: 714-263-1203.

Geotest, Inc.

For More Information Write In No. 319



FERROFLUIDS FOR STEPPER MOTORS

FerroMotion brochure explains the unique advantages of adding ferrofluids in motion control applications. Exclusive technology increases positional accuracy, improves settling time, damps out vibration and midrange resonance, extends motor life in damp or

corrosive environments. Small lots can be retrofitted or use viscous inertial dampers. 40 Simon Street, Nashua, NH 03061. Tel: 603-883-9800; Fax: 603-883-2308.

Ferrofluidics Corp.

For More Information Write In No. 320



Find out how Datum Inc. Network Time Servers and Board Level Timing Modules can be used to synchronize your network and workstations to Global Positioning System, GPS, satellites and IRIG Time Code. TCP/IP and Novell Netware™ networks can be synchronized to within 1-10 milliseconds. VME, VXI, PC, SUN SBus™, QBus™ workstations can be synchronized to within 1 microsecond. Tel: 800-348-0648 or 408-578-4161; Fax: 408-578-4165.

Datum Inc. — Bancomm Division

For More Information Write In No. 321



SURFACE MEASUREMENT SYSTEM

The WYKO RST Plus surface measurement system rapidly measures the three-dimensional surface texture of a wide variety of materials such as plastics, film, glass, ceramics, paper, machined parts, metal, etched silicon, and much more. The system

provides quantitative surface height measurements up to 500 µm with subnanometer resolution. Results are displayed as three-dimensional color images with industry-standard surface statistics. For more information, contact WYKO Corporation at 1-800-FON-WYKO.

For More Information Write In No. 324



CUSTOM ELECTROFORMS

Rugged, light weight electroforms can be used down to -423 °F or up to 1000 °F. Diameters from 0.030" - 8" with wall thicknesses from 0.0003" to 0.025" can be supplied. Can be made

an integral unit with a bellows, eliminating welding or soldering. Servometer Corporation, 501 Little Falls Rd., Cedar Grove, NJ 07009-1291; Tel: 201-785-4630; Fax: 800-785-0756; Fax (outside USA): 201-785-0756.

Servometer Corporation

For More Information Write In No. 327



PORTAGE ELECTRIC PRODUCTS INTRODUCES CONDENSED PRODUCT GUIDE

This new mini-guide to the wide-ranging line of PEPI thermal controls contains a

fast-reading overview of twenty-four different creep-action and snap-action devices. All PEPI thermostats and thermal protectors can be customized to fit particular applications. For further information, contact Portage Electric Products, Inc.; Tel: 216-499-2727; 770 Freedom Ave. NW, PO Box 2170, North Canton, OH 44720; Fax: 216-499-1853.

Portage Electric Products, Inc.


For More Information Write In No. 330



Constant Temperature Superconductivity Intermediate Controls Refrigerating Circuits 1995

NESLAB Instruments, Inc.

For More Information Write In No. 322



and miniature illumination systems. Also described are centering microscopes, optical cutting tool geometry analyzers, X-Y tables, and micro-finishing equipment. Tel: 716-873-9907; Fax: 716-873-9998.

Titan Tool Supply Co., Inc.

For More Information Write In No. 325




OPTO-MECHANICAL PRODUCT GUIDE

Daedal's Opto-Mechanical catalog contains hundreds of laboratory bench optical mounts, positioning devices, and optical hardware. Complete specifications, dimensions, and pricing are included. All products can be ordered by phone or FAX, charged to Visa or MasterCard, and are shipped free anywhere in the continental US. Daedal Division, Parker Hannifin Corp., PO Box 500, Harrison City, PA 15636; Tel: 800-822-7001; Fax: 412-744-7626.

Daedal Division, Parker Hannifin Corp.

For More Information Write In No. 328



HIGH RESOLUTION DATA ACQUISITION

FREE booklet shows many ways to automate data collection using your personal computer. It comes with a FREE Instatrend Real-Time Graphics Demo Disk. Dianachart, Inc., 101 Round Hill Drive, Rockaway, NJ 07866. Tel: 201-625-2299.

Dianachart, Inc.

For More Information Write In No. 331




CALIBRATION STANDARDS CATALOG

Free 1995 catalog of metrology calibration standards for surface contamination, critical dimensions, film thickness, surface profiling, characterization and more. Important for ISO 9000 certification. From VLSI Standards, 3087

North First St., San Jose, CA 95134; Tel: 408-428-1800; Fax: 408-428-9555.

VLSI Standards

For More Information Write In No. 323



POLYURETHANE AND EPOXY TOOLING RESIN SYSTEMS

New Selector Chart ES-160 describes the CONATHANE® TU-401 and UC-Series of non-MBOCA, non-TDI, non-MDA liquid castable tooling resin systems.

TU-401 Series flexible elastomers provide high elongation, high tensile and tear strength, and excellent abrasion resistance. CONAP® and CONATHANE® UC-Series provide tough, high hardness, high impact resistant, dimensionally stable castings. CONAP, INC., Tel: 716-372-9650; Fax: 716-372-1594.

For More Information Write In No. 326



Hardigg Cases offers over 225 standard rotationally molded transit cases, including a full line of 19" EIA rack mount cases, deck cases, and flangemount cases. Hardigg's expert engineering, manufacturing, and test facilities provide start to finish custom design capability. A complete list of standard cases allows for rapid delivery...as few as

three working days! Take advantage of over forty years of experience...design a Hardigg case into your next project!

HARDIGG CASES

Tel: 1-800-JHARDIGG; Fax: 413-665-8061

For More Information Write In No. 329



"SMART" HIGH-POWERED ACTUATORS

Get fast-acting, high-force actuators driven by ETREMA TERFENOL-D®, the magnetic shape change

metal with the highest strain of any commercial transducer material. ETREMA offers standard and custom actuators, TERFENOL-D materials, and complete custom design and manufacture. Call 800-327-7291 for applications assistance.

ETREMA Products Inc.

For More Information Write In No. 332



1995 PCMCIA PRODUCTS CATALOG

The new PCMCIA-PC CARD standard has brought many new devices such as Video Capture, 16-bit Stereo, CD-ROM, Pager, and mini PC Card Camera Cards. ENVOY DATA has released its new catalog with these products plus many others like: Memory, I/O (serial, parallel, SCSI, A/D, etc.) with Industrial Card and Drives, Multimedia, Industrial, and Engineering tools for PCMCIA applications. Tel: 602-892-0954; Fax: 602-892-0029. 953 E. Juanita Ave., #A, Mesa, AZ 85204.

Envoy Data Corporation

For More Information Write In No. 333



OVENS & FURNACES UP TO 2700 °F

Capabilities, specifications and prices for over 250 standard ovens and furnaces to 2700 °F as well as custom-designed heat processing systems. Includes: laboratory, bench, cabinet, truck, walk-in and conveyor ovens; clean room and pharmaceutical ovens; laboratory and industrial furnaces and environmental test chambers. For baking, drying, pre-heating, annealing, stress relieving, curing, sterilizing, depyrogenation and heat treating. Tel: 708-546-8225.

The Grieve Corporation

For More Information Write In No. 336



1995 ROGAN KNOB CATALOG

The complete lineup of Rogan knobs and dials--including a range of new offerings--is featured in their new fully illustrated catalog. New products included in this edition are several new Pure Touch Knobs™ such as clamping knobs in an expanded range

of sizes, the all new five-lobe clamping knob and raised bar pointer knob. ROGAN CORPORATION, 3455 Woodhead Drive, Northbrook, IL 60062; Tel: 800-423-1543; Fax: 708-498-2334.

Rogan Corporation

For More Information Write In No. 339



B92 CATALOG RELEASE

The latest catalog from W.M. Berg, Inc., coincides with Berg's silver anniversary. Founded in 1967, Berg has grown to become a recognized industrial leader of miniature precision mechanical components. A significant number of new items are added

as well as expanding previous product lines. Featuring 50,000 standard components, 80% of which we are able to ship from stock within 24 hours. Available in metric version too: M92. Tel: 516-596-1700; Fax: 516-599-3274.

W.M. Berg

For More Information Write In No. 342



MECHANICAL COMPONENTS

PIC Design's new Catalog 43 is bigger than ever--288 pages including new Modular Framing Elements, Linear Motion Systems & Positioning Tables and expanded lines of Lead Screws & Nuts, Belts & Pulleys, Ball Slides, Shoulder Screws, Bearings,

Shafting, Couplings and much more. PO Box 1004, Middlebury, CT 06762. Tel: 800-243-6125; Fax: 203-758-8271.

PIC Design

For More Information Write In No. 334

ENGINEERING INNOVATIONS ON CD-ROM



Published monthly, this new CD-ROM contains key engineering patents from all disciplines. Designed to help innovative organizations track competitive developments, identify new applications and save on design and production time.

Derwent North America

For More Information Write In No. 337



POSITIONING/ MOTION CONTROL CATALOG

NEW, detailed 160 page catalog covers NEAT's expanding line of precision positioning and motion control components and systems. Featured are single axis, X-Y, multi-axis, rotary, high vacuum, air bearing, and microscope stages. NEAT also provides a complementary line of stepping and servomotor drives and controls. NEAT specializes in providing modified, custom, and turnkey SOLUTIONS to a wide range of positioning and motion control applications. Please contact our Sales Engineers at 800-227-1066, or send E-mail to neat@tiac.net for more information.

NEAT also provides a complementary line of stepping and servomotor drives and controls. NEAT specializes in providing modified, custom, and turnkey SOLUTIONS to a wide range of positioning and motion control applications. Please contact our Sales Engineers at 800-227-1066, or send E-mail to neat@tiac.net for more information.

New England Affiliated Technologies

For More Information Write In No. 340



INSTRUMENTS FOR DATA ACQUISITION AND CONTROL

New Daytronic catalog describes "intelligent" data acquisition instruments that perform all required signal conditioning tasks, and can evaluate acquired data and initiate necessary actions for

real-time process control. Higher-level instruments can also serve as high-speed computer front ends in a network environment. Daytronic Corporation; Tel: 513-866-3300; Fax: 513-866-3327.

Daytronic Corporation

For More Information Write In No. 343



PARTS EXPRESS

Our FREE catalog features 212 pages packed with electronic parts for the do-it-yourselfer. Over 12,000 items including speakers, semiconductors, tools, wire, capacitors, hardware, test equipment, kits, connectors, adhesives, educational books and videos, TV parts, and much more. Call toll free 800-338-0531. Parts Express, 340 E. First St., Dayton, OH 45402.



For More Information Write In No. 335

"HANDS-ON" ADVANCED COMPOSITE WORKSHOPS— SINCE 1983



The brochure describes 13 different "hands-on" workshops in advanced composite materials technology. These workshops cover fabrication, repair, manufacturing, tooling, blueprint reading, adhesive bonding, ultrasonic inspection of composites, and 4 engineering workshops. Emphasis is placed on prepreg carbon and aramid fiber materials and processes, utilizing vacuum bagging and high-temperature curing methods in the oven and autoclave. Three workshops are Canadian DOT approved. REFRESHER WORKSHOPS OFFERED. For a free brochure, call 1-800-638-8441; Fax: 702-827-6599.

Abaris Training Resources

For More Information Write In No. 338



GENESYS BOROSCOPES & ENDOSCOPES

Genesys Instruments, Inc. designs and manufactures boroscopes and endoscopes for the health care and industrial markets at highly competitive prices. This NEW brochure features standard scopes for immediate shipment, as well as custom

design and prototyping services for any precision optical product specifications. Genesys Instruments is ready with quick service, support and delivery. Call 800-839-9038 for your FREE BROCHURE! Genesys Instruments, Inc., 120 Carando Drive, Springfield, MA 01104; Fax: 413-788-7784.

Genesys Instruments

For More Information Write In No. 341



ELECTRO-MAGNETIC DESIGN SOFTWARE

The legendary Vector Fields suite of software, including the TOSCA, ELEKTRA and OPERA packages, combines classical finite element techniques with user friendly interactive

graphics for high accuracy 2D and 3D simulation and design of all types of electromagnetic equipment.

Vector Fields Inc.

1700 North Farnsworth Avenue

Aurora, IL 60505

Tel: 708-851-1734 Fax: 708-851-2106

For More Information Write In No. 344



AFFORDABLE VACUUM ACCESSORIES

New vacuum accessories catalog features over 800 affordable products including flanges, fittings, construction components, valves, vacuum gauges and residual gas analyzers. These high

quality products are backed by Balzers technical service and support. In-stock items are shipped within 48 hours. Visa and MasterCard are accepted. Balzers, 8 Sagamore Park Road, Hudson, NH 03051; Tel: 603-889-6888; Fax: 800-555-3173; for orders toll-free: 800-555-3172.

Balzers

For More Information Write In No. 345



REFRACTORY METALS DELIVER PERFORMANCE BY DESIGN

The world's largest totally integrated source for molybdenum, from the mine to fabricated products. We make molybdenum billets, forging bar, rod, plate, sheet, foil, and extrusions, plus molybdenum powder for powder metallurgy spray applications. Also available are tungsten products, clad metal systems, and machined and stamped components. Tel: 216-692-3007; Fax: 216-692-0029.

Climax Specialty Metals

For More Information Write In No. 346



MOTORS THAT SURVIVE

Empire Magnetics' catalog "Motors That Survive," features specialized motors for hostile application environments. The 42-page catalog highlights the company's 1.8" stepper motors, brushless motors, gearboxes, brakes and resolvers for use in harsh environments that are destructive to ordinary motors. Motor versions are rated for vacuum, radiation, high temperature, cryogenic, wet, abrasive, dusty, oily, and corrosive conditions. Tel: 707-584-2801; Fax: 707-584-3418.

Empire Magnetics Inc.

For More Information Write In No. 347



STATICIDE SOLVES STATIC CONTROL PROBLEMS

STATICIDE, a highly effective topical method for controlling static electricity, is designed for commercial and industrial uses. Available in concentrate, general purpose and heavy duty formulas for long-term static control applications, STATICIDE is non-toxic, non-flammable, non-staining, completely biodegradable and safe for all surfaces. Tel: 800-782-8420.

ACL Incorporated

For More Information Write In No. 348



COATINGS RESIST ABRASION AND CORROSION

Magnaplate-applied abrasion and corrosion-resistant coatings for metal parts are detailed in 8-page Engineering Data Guide. Hardness, friction, wear, temperature, thickness and corrosion and abrasion resistance properties of 13 super-hard, non-stick, permanent, surface-enhancing coatings are described. Also includes applications and FDA/USDA approvals. General Magnaplate Corp., 1331 Route 1, Linden, NJ 07036; Tel: 800-852-3301 or 908-862-6200; Fax: 908-862-6110.

General Magnaplate Corp.

For More Information Write In No. 349



BROCHURE FEATURES FLEXIBLE BORESCOPES

Visual inspections are easy with a flexible borescope. Machida, Inc. offers a line of flexible borescopes for various industrial inspections. With insertion tube lengths from 1 to 20 feet and diameters from .5mm to 12.5mm, Machida borescopes can accommodate most inspections. Flexible borescopes include an angulating tip for accessibility to different views. Machida also carries engine inspection kits, blending borescopes, video systems, light sources and borescope accessories. Machida, Inc.; Tel: 800-431-5420.

Machida, Inc.

For More Information Write In No. 350



FREE DESIGN AID

Save layout time and eliminate detailing with this 16 page Template catalog. This catalog shows FULL SIZE drawings of many tooling components used in designing jigs and fixtures. It includes Spring & Ball Plungers, Nuts, Bolts, Washers, Knobs and many other items, all with sizes and part numbers. Also included will be a copy of the current catalog listing these and additional items, along with prices. Northwestern Tools, Inc., 3130 Valleywood Drive, Dayton, OH 45429; Tel: 513-298-9994; Fax: 513-298-3715.

Northwestern Tools, Inc.

For More Information Write In No. 351



A new PRODUCT SELECTION GUIDE to advanced composite pre-pregs from ICI Fiberite, Tempe, AZ, presents an overview of the resins, fibers and fabrics used to manufacture the company's preimpregnated unidirectional tape, fabrics, and tow. The 20-page guide also lists average mechanical properties for 350° F epoxy pre-pregs, 350° F toughened epoxy pre-pregs, 350° F cyanate ester materials, and thermoplastic pre-pregs as well as 250° F epoxy and phenolic pre-pregs. ICI Fiberite, 2055 E. Technology Cir., Tempe, AZ 85284; Tel: 602-730-2234.

ICI Fiberite

For More Information Write In No. 352



FIRESTONE CONTEST ENTRY KIT

Win \$2,000 in Firestone Industrial Product Company's 1995 Innovators Design Contest. The free Entry Kit contains information on Firestone's Airstroke® actuators and Airmount® isolators, design problem-solver sheets, entry sheets, contest rules and a Firestone Engineering Manual & Design Guide. One grand-prize winner receives \$2,000, two first-place winners receive \$1,000 each and two second-place winners receive \$500 each. Deadline: December 31, 1995. Fax name and address to: Firestone Innovators Design Contest, c/o CRE, Inc., 317-631-0272, or call 800-888-0650. E-mail: Firestone@industry.net.

Firestone

For More Information Write In No. 353




KEITHLEY CONTAMINANT MONITOR

Keithley's new Quantox™ oxide charge monitoring system, based on Corona-Oxide-Semiconductor (COS) technology, measures oxide parameters cost-effectively, including mobile

oxide charge, thickness, effective charge, flatband voltage, interface state density, and type tests. It monitors parameters immediately after the monitored process step. Keithley Instruments, Inc., 28775 Aurora Rd., Cleveland, OH 44139; Tel: 800-552-1115; Fax: 216-498-2911.

Keithley Instruments, Inc.

For More Information Write In No. 354



QUIT GUESSING SIMULATE IT WITH VISSIM™

VisSim is an innovative block diagram language for nonlinear dynamic simulation. VisSim's uniquely integrated approach to model construction and execution leads to rapid prototyping, faster execution, and greater productivity. NEW! Version 2.0 has MMI. Call: 508-392-0100 or Fax: 508-692-3102. Visual Solutions, Inc., 487 Groton Rd., Westford, MA 01886. FREE WORKING DEMO.

Visual Solutions, Inc.

For More Information Write In No. 355



VIRTUAL REALITY COMPUTER NETWORK APPROACH

The SCRAMNet® Network, a real-time communications system based on a replicated shared-memory concept, is optimized for the high-speed transfer of data among computers. Applications include simulation, telemetry and virtual reality. Call for this FREE application summary. SYSTRAN Corp. Tel: 800-252-5601; Fax: 513-258-2729; E-mail: info@systran.com.

SYSTRAN Corp.

For More Information Write In No. 356




PEAKFIT™ NONLINEAR PEAK ANALYSIS SOFTWARE

PeakFit separates and characterizes unresolved peaks in data using sophisticated nonlinear curve-fitting techniques. PeakFit offers 30 functions for peak analysis of spectroscopy, chromatography, pharmacology, engineering, statistics, and other data. Graphical control of parameter values enables you to manipulate individual peaks. PeakFit generates numeric and statistical summaries and curve-fit graphs, which can be printed or exported.

Jandel Scientific Software

For More Information Write In No. 357




PLANT AUTO- MATION SOLU- TIONS FROM ROCKWELL SOFTWARE

Learn The New Way to Succeed In Plant Automation from Rockwell Software Inc. Rockwell Software is the one source for a complete suite of DOST™ and Windows™ industrial software. Programming packages are available for the Allen-Bradley™ family of processors, and MMI/operator interface and communications software supports Allen-Bradley, Modicon®, GE Fanuc™, Reliance®, and Square D™ processors. Rockwell Software Inc.; Tel: 414-321-8000; Fax: 414-321-9647.

Rockwell Software Inc.

For More Information Write In No. 360



PRECISION STRIP/WIRE

Elgiloy® is a combination strip and wire mill. We process a variety of alloys including Inconel®, Hastelloy®, Monel®, MP35N®, Titanium and Stainless. Our sales and engineering staff are qualified to handle your custom material requirements, and our on site testing lab assures you of prompt deliveries. Tel: 708-695-1900; Fax: 708-695-0169.

Elgiloy® Limited Partnership

For More Information Write In No. 363



MAKE YOUR OWN THERMO- COUPLES, MAKE YOUR OWN

The HOTSPOT allows thermocouple wire to be formed into freestanding junctions, or welded to metal surfaces. It provides a simple means of fabricating thermocouples "when needed and where needed." Brochure and specification sheet available. Address: 7300 North Crescent Blvd., Pennsauken, NJ 08110. Tel: 609-662-7272; Fax: 609-662-7862.

DCC Corp.

For More Information Write In No. 366



MCM ELECTRONICS OFFERS NEW 332 PAGE CAT- ALOG, FREE!

MCM is the industry leader in the distribution of consumer electronic repair parts and accessories. Catalog #35 contains more than 21,000 items including TV/VCR and appliance repair parts, semiconductors, speakers, test equipment, computer products and more. All items are in stock and ready to ship from distribution centers near Reno, NV and Dayton, OH, allowing two-day shipping to most of the continental U.S., at ground rates. Call toll free: 800-543-4330. TB01.

MCM Electronics

For More Information Write In No. 358



NEW 1995-96 COLE- PARMER® INSTRUMENTS CATALOG

The new, free 1995-96 Cole-Parmer instruments catalog contains over 1700 full-color pages and features more than 40,000 products covering scientific instruments, equipment, and supplies. The catalog includes a detailed 40-page product index and table of contents, informative introductory pages for many of the catalog sections, "Hot Tips," and an 8-page section of late-breaking products. Contact Cole-Parmer Instrument Company—in the USA or Canada, call toll-free 1-800-323-4340.

For More Information Write In No. 361



ENGINEERING SOLUTIONS FOR MAGNETIC SHIELDING

Ad-Vance Magnetics has released their newest engineering catalog featuring 25 solutions to magnetic shielding problems, basic relationship between E and H vectors, calculation support in shield design, enhanced skin effect and technical article reprints. Ad-Vance Magnetics, 625 Monroe St., Rochester, IN 46975; Tel: 219-223-3158; Fax: 219-223-2524.

Ad-Vance Magnetics

For More Information Write In No. 364



PRESSURE VESSEL MECHANICAL INTEGRITY

New PC software analyzes mechanical integrity of installed pressure vessels to insure compliance with OSHA's 29 CFR 1910.119-Process Safety Management of Highly Hazardous Chemicals. Created by engineers familiar with older vessels, program uses ASME B&PV Code, NBIC, and API 510 guidelines. Free demo disk.

Computer Engineering, Inc.

For More Information Write In No. 359



INTRODUCING TYGON 2000 TUBING

Tygon 2000 is unequalled in its chemical resistance by that of any other clear, flexible plastic tubing. The tubing has virtually no extractables and is completely free of plasticizers and phthalate, reducing the risk of contamination sensitive fluids. The tubing is also environmentally safer to dispose of than most tubing. Carbon dioxide and carbon monoxide are the only bi-products released upon incineration. For literature, write to Norton Performance Plastics Corporation, PO Box 3660, Akron, OH 44309-3660, or call 216-798-9240.

Norton Performance Plastics Corp.

For More Information Write In No. 362



CD-ROM CAT- ALOG—WORK- BENCHES AND SYSTEMS

This interactive multi-media presentation covers Teclab's workbenches and laboratory systems furniture. Designed for Windows™, the CD-ROM presentation features hundreds of benches. Meeting the Challenge, Teclab's introductory video, highlights unique features and benefits of a Teclab bench. Select what you want by clicking on the icons that interest you. Teclab, Kalamazoo Technical Furniture, 6450 Valley Industrial Drive, Kalamazoo, MI 49009; Tel: 800-832-5227; Fax: 616-372-6116.

Teclab

For More Information Write In No. 365

NEW VIDEO SHOWS HOW TO PREDICT LAB RESULTS WITH FEA



Finite Element Analysis In Action! is a new kind of instructional video for engineers. Live lab and computer demonstrations show how to better use any FEA software. A case study of brittle fracture—which can happen to almost any material, even steel—provides real-world examples. Two lab experiments and two FEA analyses are conducted and the results compared. Demonstrates specific modeling and analysis techniques for predicting lab results with FEA.

APD

For More Information Write In No. 367



FREE ACCESS TO FEDERALLY FUNDED TECHNOLOGY

National Technology Transfer Center offers free access to federally funded technology, an electronic bulletin board announcing technology transfer opportunities, training on technology transfer issues, and strategic partnering conferences. Why not call (800) 678-6882 today and discover the research opportunities right at your fingertips.

National Technology Transfer Center

For More Information Write In No. 368

NASTRAN[®] and FEMAP[®]

Unlimited Problem Size
Windows Interface
Pre/Post Processing
DMP
DXF and IGES Import
Linear Statics
Normal Nodes
Buckling
Heat transfer Analysis
Nonlinear Analysis
Aeroelasticity
Dynamic Response
Cyclic Symmetry
And Much More For Only
\$3,995

MACRO Engineering

100 McAdoo Dr., Madison, AL 35758
(205) 461-7090 fax 772-9847

For More Information Write In No. 423

Rotating Electrical Connectors



- Superior to conventional slip rings, Mercotac's liquid metal-wetted contacts provide increased reliability. Extremely low electrical noise, less than 1 milliohm resistance.
- Durable, compact, low cost, no maintenance. Ideal for computers, instrumentation, thermocouples, strain gauges, packaging, heating and control equipment.



Mercotac Inc.

6195 Corte del Cedro
Carlsbad, California 92009
619 431 7723 • Fax 619 431 0905

For More Information Write In No. 424

New on the Market

Product of the Month



The SmartMotor[™] line of drives from Baldor Electric Co., Fort Smith, AR, combines adjustable speed control electronics with an industrial motor in one package. Advantages include guaranteed motor-control compatibility, easy installation, and elimination of the panel space previously needed for a stand-alone inverter. The drive design reduces line voltage reflections that contribute to premature motor failure in adjustable speed drive applications. Ranging from 1 to 10 horsepower in NEMA standard frame sizes, the initial units meet FCC standards for radio frequency interference (RFI).

For More Information Write In No. 700

NuVision Technologies Inc., Beaverton, OR, has released the SGS 19S stereoscopic 3D display kit for use with a monochrome or full-color monitor. Comprised of a liquid crystal modulator, viewing glasses, and driver box, the kit produces stereoscopic 3D images by alternately displaying left and right eye images. The modulator mounted on the monitor encodes the images with circular polarization. The glasses decode the images, providing the 3D display. Applications include 3D computer graphics, inspection systems, molecular and solids modeling, and scientific visualization.

For More Information Write In No. 701




The SuperView 100 video windows model from RGB Spectrum, Alameda, CA, combines a high-resolution workstation screen with four simultaneous, live video windows on a single monitor or projector. Designed for applications requiring simultaneous display of video and graphics, the system is compatible with any workstation to 1280x1024 pixels. Users can insert up to four live video images in real time. Inputs from cameras, recorders, and teleconferencing systems are accepted.

For More Information Write In No. 702

Mectrol Corp., Salem, NH, has introduced the RS Series rotary actuators. A urethane timing belt forms two air-sealed loops between the two parallel end-plates of the actuator case. Directed air pressure expands either loop, pulling the belt from the other loop past a seal, rotating an output shaft. Features include shock-free starts and stops; no backlash or bounce-back; adjustable travel stops; and no leakage.

For More Information Write In No. 703



SICK Optic-Electronic Inc., Eden Prairie, MN, has introduced the FGS Flexible Guarding System, a self-contained, noncontacting light curtain that features a 2" x 2" cross-section and nominal protective heights from 12" to 72" in 6" increments. Designed for use on hazardous machines for point-of-operation, area, perimeter, or entry/exit guarding, the curtain allows unrestricted access while providing control-reliable safeguarding. Resolutions of 14 or 30 mm and scanning ranges to 60' are provided.

For More Information Write In No. 704

The Model TJE pressure transducer from Sensotec Inc., Columbus, OH, provides 0.1% FS accuracy over a pressure range from 1 to 60,000 psi. Featuring all-welded stainless steel construction, the transducer has an operating temperature range from -73.3° C to 163° C. Options include compensated temperature ranges, pressure ports, electrical terminations, and an intrinsically safe internal amplifier.

For More Information Write In No. 705

Lighthouse Digital Inc., Grass Valley, CA, has introduced generic, solid-state data communications matrix switchers that provide switching of any input to any or all outputs. Switching is non-protocol-dependent and I/O connectors can be copper or fiber optic. Signal data rates in 50 Mbs maximum, 500 Mbs maximum, and 1.5 Gbs maximum bandwidths are available. Applications include data acquisition networks and digital video and audio.

For More Information Write In No. 706

New on the Market

Metrum, Littleton, CO, has introduced a variable data rate/high-capacity **digital data acquisition recorder** with sustained transfer rates from 0 to 64 Mb/sec., and the ability to store a 27.4 or 20.8 Gb single tape cassette. Record times range from 57 minutes and 44 minutes at 64 Mb/sec. to 76 hours at 800 Kb/sec., depending on the data rate and type of tape cassette. The recorder is available in a standard 19" rack-mount configuration and can be used for ASW, telecommunications, telemetry, flight test, and digital video/imaging applications.

For More Information Write In No. 707



The Model 250 23-bit **data acquisition system** from Lawson Labs Inc., Kallispell, MT, features 22-bit monotonicity, linearity at 0.001% of full scale, and sampling rates over 5 kHz. The system combines a RISC microcontroller with a multi-pass, A/D conversion architecture to achieve DC accuracy at high sample rates. At maximum speed, effective resolution is 19.5 bits. The system can operate as a polled or scanning A/D and interfaces to a host computer via a standard parallel port. Using external multiplexers, up to 96 channels can be sequentially scanned.

For More Information Write In No. 708



Cyberware, Monterey, CA, has introduced the WB2 and WB4 3D **whole-body scanners** for product designers, CAD/CAM, research, medical appliance design, anthropometry, and ergonomics applications. In as little as 12 seconds, the units scan the entire human body in color and 3D. The scanners use two or four scanning instruments mounted on vertical towers; with a person standing on either scanner's platform, the instruments move down from the head to scan the body. Workstation software controls the scanning and motion operations, with scans from each system combined into a complete 3D model.

For More Information Write In No. 709

A line of temperature-responsive **bellows assemblies** from Servometer Corp., Cedar Grove, NJ, are custom designed, manufactured and assembled to measure response over a temperature range of 66° C to -45.6° C. The lightweight assemblies are thin-walled, electrodeposited nickel bellows that are soldered to custom end pieces. The bellows is filled and sealed with a working fluid having a known coefficient of thermal expansion. When the temperature of the filled bellows changes, the volumetric expansion of the fluid is translated into linear motion, per degree change in temperature.

For More Information Write In No. 710

The CX100 precision **frame grabber** for OEM, industrial, and scientific applications from ImageNation Corp., Beaverton, OR, has a sampling jitter of $\pm 3\text{ns}$ and video noise less than one LSB. It features crystal-controlled timing for image accuracy and repeatability, and digital synchronization for compatibility with standard resettable cameras and VCRs. Image transfer rate is 1 Mb per second. A software interface, C library with source code, and Windows DLLs for C developers and Visual Basic developers are provided.

For More Information Write In No. 711



Super Emotia™ and Super Emotia GX high-resolution **PC-to-video scan converters** are available from Extron Electronics, Anaheim, CA. Users can record computer-generated video to videotape, and can produce display of VGA, Super VGA, XGA PC and Mac video on video-only LCD projectors and monitors. The systems feature horizontal and vertical shift, freeze frame, and overscan/underscan switch. They require no special software or hardware for installation. The Super Emotia GX adds a genlock sync input and component video output.

For More Information Write In No. 712

nuLogic Inc., Needham, MA, has introduced the FlexMotion **servo and stepper motor control board** with up to ten complete motion axes in a single PC ISA slot. The FIFO bus interface and command set provide high-speed communications, while off-loading complex motion functions from the host PC. The board provides two, four, or six axes of servo control, with two axes of stepper control. An optional two- or four-axis daughter card is available in servo or stepper configurations.

For More Information Write In No. 713

Thermofoil™ Heaters put the heat where you need it



Flexible etched-foil heaters • Odd shapes, profiled or multiple elements • Efficient heat transfer: Up to 110 W/in²
• 200°C polyimide, 235°C rubber, 600°C mica, 120°C transparent insulations • Optional sensors & controllers

Precise, reliable heating • Minimal space, mass, & design overhead • Medical diagnostic instruments • Aerospace devices • Commercial appliances • Packaging machinery • Scientific instruments • Electronics


MINCO PRODUCTS, INC.
7300 Commerce Lane • Minneapolis, MN 55432-3177 U.S.A.
Telephone: (612) 571-3121 • FAX: (612) 571-0927

For More Information Write In No. 425

FIBER REINFORCED LOW SHRINKAGE ADHESIVE

MASTER BOND SYSTEM EP30R

- Outstanding dimensional stability
- Superior impact resistant, high modulus bonds
- Fast room temperature or elevated temperature cures
- Excellent chemical resistance
- Remarkable long term durability
- Easy application
- Convenient packaging



For information, call or write:
Master Bond Inc.
154 Hobart Street
Hackensack, NJ 07601
201-343-8983

Master Bond Inc.
Adhesives, Sealants & Coatings

For More Information Write In No. 431

New on Disk




Pointwise Inc., Fort Worth, TX, has announced Gridgen Version 10 **structured grid generator software** combining a user interface with grid generation techniques for numerical simulations such as computational fluid dynamics (CFD). Gridgen offers a suite of tools with which the space on and around a CAD-designed product can be discretized. The cost is \$5000 for a perpetual right-to-use license.

For More Information Write In No. 730

Production ResponseAgent™ Release 1.0 intelligent **manufacturing planning and scheduling software** has been introduced by Red Pepper Software Co., San Mateo, CA, to generate optimized plans, monitor critical manufacturing variables, alert users to problems as they arise, and recommend optimized solutions in real time. The ResponseAgents continuously monitor and alert users to changes in conditions. System prices begin at \$150,000.

For More Information Write In No. 731




Spiral Software, Brookline, MA, has introduced EasyPlot Version 3 **data visualization and analysis software**, featuring 3D graphing, image plots, 3D curve fitting, a programming interface, on-line help, and a Preferences dialogue that provides access to power-user features. The Windows version costs \$399; DOS, \$349; and a DOS/Windows bundle, \$449.

For More Information Write In No. 732


Matra Datavision, Andover, MA, has announced STRIM Professional Solutions Version 6 **styling, prototyping, tooling, and plastic analysis software** featuring a new user interface based on the OSF/MOTIF standard. The styling application combines a free-form surface modeler and photorealistic imagery to produce complex shapes. Prices begin at \$11,500.

For More Information Write In No. 733




VisSim Version 2.0 from Visual Solutions, Westford, MA, is an upgrade to its **modeling and nonlinear simulation software**. New features include a Man Machine Interface display mode for operator training, an Animate block for drawing, design tools, and printing enhancements. The program runs in Windows, Windows NT, and UNIX operating systems. Prices range from \$495 to \$4195.

For More Information Write In No. 734



Mitutoyo/MTI Corp., Aurora, IL, has introduced MeasurLink™ real-time **data acquisition software** that allows immediate measuring data analysis and feedback. The Windows-based program establishes a database of part feature characteristics that can include notes and pictures.

For More Information Write In No. 735



Gsharp™ **graphing software** from Advanced Visual Systems, Waltham, MA, automatically creates 2D and 3D graphs from complex, recurring visual data. Designed for applications requiring precise graph layout, Gsharp creates graphs interactively and turns them into reusable macros. Prices begin at \$4,800.

For More Information Write In No. 736

MINITAB for Windows Release 10 Xtra **statistical software** has been introduced by Minitab Inc., State College, PA. The program includes Microsoft's Win32s system, providing faster processing speed without upgrades. Features are zone control charts, short run, and run charts. Prices are \$495 for academic customers; \$895 for commercial customers.


For More Information Write In No. 737

IGES Data Analysis, Melrose Park, IL, has announced version 1.5 of CALSVIEW **graphics viewing and markup software** for 2D and 3D CAD, legacy raster data, technical illustrations, plot files, and scanned images. Data files can be accessed from any system, and users can view data graphically from any angle, check distances, create comments on files, interrogate drawing entities, and convert to various output formats. A programming interface allows integration with product data management systems. Prices start at \$595.

For More Information Write In No. 738

Robochart Versions 2.0 and 8.0 **flow diagram editing software** from Digital Insight, Simi Valley, CA, are designed for creation and modification of all types of flow diagrams. They feature an expanded library of more than 250 object shapes and 30 arrow types, unlimited label size and diagram complexity, a command-line printing facility, and a hypertext linking feature. User-defined objects can be outline or image formats. The first floating license is \$850; additional licenses are \$395 each.

For More Information Write In No. 739




Jandel Scientific, San Rafael, CA, has released SigmaGel for Windows **electrophoretic gel analysis software** that analyzes electrophoretic gels on a PC. Spatial, intensity, and/or molecular weight calibrations can be set or loaded for each image. Features include lane, spot, and molecular weight measurement modes; a built-in spreadsheet and graph window; and DNA sequence graphs with text files of the results. The program costs \$495.

For More Information Write In No. 750


Version 2.2 of HiQ **numerical analysis and data visualization application software** from National Instruments, Austin, TX, includes an improved user interface, controls, and indicators such as switches and buttons, data communication capabilities, high-resolution printing, and automation features. Users can build interactive analysis, simulation, and modeling applications using data fitting, linear algebra, signal processing, statistics, and differential equations. The cost is \$695.

For More Information Write In No. 751




International TechneGroup Inc., Milford, OH, has introduced IGES/Works® Version 3.0 **data exchange software** that reads IGES files from any source, allowing users to view, analyze, edit, and transfer the data to any other CAD/CAM/CAE system. Enhancements include solids display, data reduction, GUI recorder, geometry analysis, and surface reversal.

For More Information Write In No. 752



LapFEA 3D **stress and vibration analysis software** for Power Macintosh from LAPCAD Engineering, San Diego, CA, performs 3D stress and vibration analysis of structures, components, and mechanical systems. Included are solid and transparent layering, manual and automatic meshing, animation, contour mapping, and cross-sectional analysis. Applications include product design/analysis, manufacturing methods, process design, packaging, instrumentation, and thermal systems/devices. Prices range from \$295 to \$795.


For More Information Write In No. 753



Pattern Recognition Workbench **neural network modeling and pattern recognition software** from Unica Technologies Inc., Brighton, MA, integrates a proprietary spreadsheet for interactive data processing, and an experiment manager to manage neural network modeling and pattern classification experiments. Manufacturing engineers and researchers can use the program to analyze and improve manufacturing aspects on PCs, and DEC and Sun workstations. Prices start at \$3,495.

For More Information Write In No. 754

New Literature



Combat® Boron Nitride, a **synthetic ceramic material**, is described in a 12-page brochure from The Carborundum Co., Amherst, NY. The material is available in solid, powder, liquid, and aerosol spray forms for products in thermal, mechanical, chemical, and electrical applications. Resisting temperatures to 3000° C, it has a dielectric strength of nearly 2300 volts per mil, and can be machined to close tolerances without firing.

For More Information Write In No. 720

Hottinger Baldwin Measurements, Marlboro, MA, offers an eight-page brochure describing its **inductive displacement transducers**. The devices are used for research and development, production engineering, safety, and quality assurance applications, where safety, compact size, high resolution, and accuracy are required.

For More Information Write In No. 721



Humphrey Inc., San Diego, CA, has released a 24-page catalog of **guidance and control system instruments** such as gyroscopes, vertical indicators, rate sensors, position transducers, accelerometers, power supplies, and magnetometers. Applications include aerospace, oceanography, the military, and general industry.

For More Information Write In No. 722



A brochure from Bodine Electric Co., Chicago, IL, includes flow charts and conversion tables for selecting **motors and gearmotors**. Methods for calculating speed and torque for various applications are included.

For More Information Write In No. 723

Penn Engineering & Manufacturing Corp., Danboro, PA, has released a 20-page catalog of Standard Insert® **threaded inserts for plastics**, including ultrasonic, molded, and post-molded threaded inserts in brass, stainless steel, and aluminum. The inserts offer an alternative to typical joining methods such as adhesives or traditional hardware.

For More Information Write In No. 724




The Micro Slides Division of Anorad Corp., Hauppauge, NY, has released a 20-page catalog of **positioning systems and components**. It describes crossed roller bearings, ways, slide assemblies, linear position stages, positioning controllers, and rotary positioning stages.

For More Information Write In No. 725

Detroit Tool Industries, Madison Heights, MI, has released a brochure on **Spiralock® locking threaded fasteners and thread forms**. Tapped holes or fasteners using the thread forms can accept any standard male bolt and are reusable.

For More Information Write In No. 726



Precision Flying Requires Precision Materials. Elgiloy®

- Resists Stress & Cracking
- Corrosion Resistant
- Non-Magnetic • Long Fatigue Life
- Performs Consistently in Temperatures Ranging From -300° to 850° F

Over 40
Alloys in
Strip
AND
Wire

Elgiloy® Limited Partnership

1565 Fleetwood Drive

Elgin, IL 60123

Tel: (708) 695-1900


Fax: (708) 695-0169

Pratt & Whitney and GE Approved

For More Information Write In No. 416

FEMAP

Finite Element
Modeling and
Post-Processing



New 3-D Automatic Mesher

Direct Interfaces with:

- AutoCAD R13
- AutoCAD Designer
- MicroStation Modeler
- Stereo-Lithography
- IGES, DXF

Available for:
Windows
Windows 95
Windows NT
and UNIX

Supports Twenty Finite Element Analysis Programs

ENTERPRISE SOFTWARE PRODUCTS, INC.

610-594-2454 • 610-594-7579 FAX • femap@pond.com E-Mail


FEMAP ADVANCED MESHING MODULE utilizes ACIS software by SPATIAL TECHNOLOGY INC. All Product Names are Trademarks or Registered Trademarks of their respective owners.

SL-GMS

...for unprecedented performance

Build high-precision, animated screens for visual display. Build interactive screens to control real-time applications.


Since 1984 SL-GMS (SL-Graphical Modeling System) a fully object oriented graphics tool—the most advanced available—dramatically simplifies your work in creating interface screens of any complexity and animating them with your application data. With SL-GMS the screen you build is automatically the high-performance optimized production version—not a prototype.



■ Remote sensor and device control



■ Network monitoring and control displays



■ Dual reservoir monitoring system

SL supports most flavors of UNIX (X Window) on SUN, HP, IBM, MIPS, DEC (VAX/Alpha, OpenVMS/OSF-1). Intel: Windows NT, OS/2, Windows[®] 95, SCO, QNX[®]. For SGI, SL-GMS generates pipe-line display-code to reach real-time, native speeds.

For more details call: 1-415-927-1724

SL
Sherrill-Lubinski

SL Corporation
Suite 110 Hunt Plaza
240 Tamal Vista Boulevard
Corte Madera, CA 94925
© 1995 Sherrill-Lubinski Corporation
All trademarks and registered trademarks mentioned are property of their respective companies.

For More Information Write In No. 414



Free DSP Catalog

Discover the latest revolution in Digital Signal Processors, the ADSP-2106x Super Harvard Architecture Computer from Analog Devices, Inc. We are ready to deliver SHARC boards and modules for your PC-based DSP applications today. We've been the foremost supplier of PC solutions for ADI DSPs for years and our new SHARC products maintain and advance our leadership role. Call BitWare today, because you've got a lot on your plate, and so do we.

BITWARE RESEARCH SYSTEMS

800-848-0436

33 North Main Street • Concord, NH 03301
FAX: 603-226-6667 • E-Mail: bitware@bitware.com

For More Information Write In No. 580

SmartCore™ the New Approach



\$59 qty 1

Call our AutoFAX
916-753-0618
from your FAX.
Ask for data sheet
#34. Also ask
about our \$99
evaluation kit.

The SmartCore™ is a shortcut to a custom-designed controller. It is a C-programmable microprocessor core with memory, supervisor, DMA, and clock already built in. All you need to do is add interface and control logic.



1724 Picasso Ave.
Davis, CA 95616
916.757.3737
916.753.5141 FAX

For More Information Write In No. 582




FREE!
130
Page
Catalog

"Optics
for
Industry"

Free 130 page product catalog from Rolyn, world's largest supplier of "Off-the-Shelf" optics. 24-hour delivery of simple or compound lenses, filters, prisms, mirrors, beamsplitters, reticles, objectives, eyepieces plus thousands of other stock items. Rolyn also supplies custom products and coatings in prototype or production quantities. **ROLYN OPTICS Co.**, 706 Arrowgrand Circle, Covina, CA 91722-2199, (818)915- 5707, FAX (818)915-1379

For More Information Write In No. 581



**Fasteners
For Use
In Or With
PC Boards
(Bulletin K)**

Penn Engineering offers a wide variety of PEM[®] brand broaching fasteners to satisfy component-to-board, board-to-board, and board-to-chassis production-fastening needs. These fasteners are designed for use with all types of printed circuit boards, as well as acrylic, polycarbonate and aluminum panels. Contact Penn Engineering & Manufacturing Corp., P.O. Box 1000, Danboro, PA 18916. Fax: 215-766-0143 or call: **1-800-237-4736**.

Clinch it with PEM[®]
FASTENERS & PRESSES

For More Information Write In No. 583

You Can Turn Your PC Into A Waveform Recorder!



Today's most advanced data recording systems are not paper chart recorders. They're paperless, PC-based data acquisition systems from Dataq Instruments. We've replaced traditional instruments in a variety of applications with low-cost and flexible alternatives that save our customers thousands in paper costs alone. Factor in the productivity gains of computer-based analysis, and you have a solution you can't afford to ignore.

- ◆ Battery-powered and desktop solutions
- ◆ Hard copy to any graphics printer
- ◆ Sample rates of 1 to 500,000 Hz
- ◆ Connects from 1 to 240 channels to any PC

DATAQ INSTRUMENTS, INC.
800-553-9006

For More Information Write In No. 584

CALL FOR
FREE
INFORMATION



Advertisers Index

Abaris Training Resources	(RAC 338)	99
ACL Incorporated	(RAC 348)	100
Ad-Vance Magnetics	(RAC 364)	101
Adaptive Research	(RAC 523,760)	57,81
Advanced Ceramics Corp.	(RAC 312)	97
Advanced Pressure Products	(RAC 300,301,302,304,305,306,307)	96
Aerospace Optics Inc.	(RAC 539)	35
Algor, Inc.	(RAC 571,761)	11,81
Amco	(RAC 409)	45
American Precision Industries		
Controls Division	(RAC 316)	97
American Variseal	(RAC 317)	97
Ansys, Inc.	(RAC 522,762)	55,82
APD	(RAC 367)	101
Apple Computer Inc.		8-9
Ashlar Incorporated	(RAC 501)	19
Assembly Technology		
Expo '95	Insert	
Astro-Med, Inc.	(RAC 531,763)	COV III,82
Bal Seal Engineering		
Company, Inc.	(RAC 419)	60
Balzars	(RAC 345)	100
W.M. Berg	(RAC 342)	99
Big Sky Laser		
Technologies, Inc.	(RAC 461)	2a
Bitware Research Systems	(RAC 580)	106
Climax Specialty Metals	(RAC 346)	100
Cole-Parmer Instrument		
Company	(RAC 361)	101
Computer Engineering, Inc.	(RAC 359)	101
Conap, Inc.	(RAC 326)	98
Cybernetics	(RAC 504,596)	7,47
Daedel Div.		
Parker Hannifin Corp.	(RAC 328)	98
Data Translation	(RAC 530,764)	15,83
DATAQ Instruments, Inc.	(RAC 584)	106
Datum Inc.		
Bancoinn Division	(RAC 321)	98
Daytronic Corporation	(RAC 343)	99
DCC Corporation	(RAC 366)	101
Derwent North America	(RAC 337)	99
Design Solutions Software Co	(RAC 309)	97
Dianachart, Inc.	(RAC 331)	98
Digi-Key Corporation	(RAC 588)	5
Digital Equipment		
Corporation	(RAC 520,766)	36-37,84
Directed Energy, Inc.	(RAC 469)	16a
DSP Development Corp	(RAC 541,767)	2,84
Eastman Kodak Company	(RAC 420)	68
Edmund Scientific Co.	(RAC 464)	12a
EG & G Electro-Optics	(RAC 462,372)	9a,21a
Electronic Conventions		
Management	(RAC 666)	73
Elgilloy Limited Partnership	(RAC 363,416)	101,105
Empire Magnetics, Inc.	(RAC 347)	100
Enterprise Software		
Products, Inc.	(RAC 440)	105
Envoy Data Corporation	(RAC 333)	99
EPIX, Incorporated	(RAC 517,768)	49,85
Etrema Products Inc.	(RAC 332)	98
Evans	(RAC 407)	42
Exciton Inc.	(RAC 376)	21a
Ferro Corporation	(RAC 422)	72
Ferrofluidics Corp.	(RAC 320)	97
Firestone Industrial		
Products Company	(RAC 353)	100
Gage Applied Sciences Inc.	(RAC 570,769)	13,85
GE Plastics	(RAC 602)	51
General Devices		
Company, Inc.	(RAC 537,770)	71,86
General Magnaplate Corp.	(RAC 349)	100
Genesys Instruments	(RAC 341)	99
Geotest, Inc.	(RAC 319)	97
The Grieve Corporation	(RAC 336)	99
GTSI	(RAC 505,783)	25,92
Hardigg Cases	(RAC 329)	98
Hewlett-Packard		
Company	(RAC 502,438)	31,74-77
Hi-Techniques, Inc.	(RAC 318)	97
Hitachi Denshi America, Ltd.	(RAC 411)	61
Hummingbird Communications		
Ltd.	(RAC 507,771)	4,86
ICI Fiberite	(RAC 352)	100
Instrument Technology, Inc.	(RAC 314)	97
Integrated Engineering		
Software	(RAC 511,772)	29,87
IOtech, Inc.	(RAC 662-665,773)	41,87
Iscan	(RAC 429)	108
Janco	(RAC 406)	39
Jandel Scientific Software	(RAC 357)	101
Keithley Instruments, Inc.	(RAC 354)	100
Kevev X-Ray, Inc.	(RAC 405)	32
Lasiris, Inc.	(RAC 370)	21a
Lee Laser	(RAC 471)	17a
Libbey Owens Ford	(RAC 460,374)	1a,21a
Machida, Inc.	(RAC 350)	100
MacNeal-Schwendler		
Corporation	(RAC 408,561,774)	44,COV IV,88
Macro Engineering	(RAC 423)	102
Macsyma Inc.	(RAC 427)	107
Master Bond Inc.	(RAC 431)	103
The MathWorks, Inc.	(RAC 519,775)	17,88
MCM	(RAC 358)	101
Melles Griot	(RAC 415)	64
Mercotec Inc.	(RAC 424)	102
Merlin Engineering Works	(RAC 428)	107
Mikron Instrument		
Company, Inc.	(RAC 417)	60
Minco Products, Inc.	(RAC 425)	103
National Instruments		
Corp.	(RAC 503,310,776)	COV II,97,89
National Photocolor		
Corporation	(RAC 470)	16a
National Technology		
Transfer Center	(RAC 401,368)	16,101
Neslab Instruments,		
Inc.	(RAC 322,451,473,371)	98,5a,18a,21a
Networks Dallas	(RAC 587)	95
New England Affiliated		
Technologies	(RAC 340,378)	99,21a
Northwestern Tools, Inc.	(RAC 351)	100
Norton Performance Plastics		
Corporation	(RAC 362)	101
Numerica Software Corp.	(RAC 660,777)	1,89
Numerical Algorithms		
Group Inc.	(RAC 402)	18
Nye Lubricants, Inc.	(RAC 510,778)	53,90
Optima Precision Inc.	(RAC 463)	10a
Parts Express	(RAC 335)	99
PC Video Conversion	(RAC 410)	61
Penn Engineering		
& Manufacturing Corp.	(RAC 583)	106
PIC Design	(RAC 334)	99
Pittman	(RAC 403)	23
Porous Materials, Inc.	(RAC 303,308)	96
Portage Electric		
Products, Inc.	(RAC 330)	98
RAG Electronics	(RAC 508,779)	3,90
Remcor Products Company	(RAC 467)	14a
Research Systems, Inc.	(RAC 555,780)	27,91
RGB Spectrum	(RAC 400,421)	12,72
Rockwell Software Inc.	(RAC 360)	101
Rocky Mountain Instrument	(RAC 452)	COV IVa
Rofin-Sinar, Inc.	(RAC 455,380)	7a,21a
Rogan Corporation	(RAC 339)	99
Rolyn Optics Company	(RAC 581)	106
David Sarnoff		
Research Center	(RAC 512,785)	43,83
Schneider Corporation		
of America	(RAC 466,377)	13a,21a
Science Accessories		
Corporation	(RAC 412)	63
Scientific Imaging		
Technologies, Inc.	(RAC 450)	COV IIa
Servometer Corporation	(RAC 327)	98
SL Corporation	(RAC 414)	106
Society of Manufacturing		
Engineers	(RAC 521)	93
Southco, Inc.	(RAC 532,533,781)	59,91
Space Optics Research Labs	(RAC 468)	15a
StacoSwitch, Inc.	(RAC 315)	97
Stanford Research Systems	(RAC 373)	21a
StereoGraphics Corporation	(RAC 404)	28
Synrad	(RAC 538,782)	69,92
Sysran Corp.	(RAC 356)	100
Technology 2005	Insert	
Teclab, Kalamazoo		
Technical Furniture	(RAC 365)	101
Titan Tool Supply Co., Inc.	(RAC 325)	98
TrueTime, Inc.	(RAC 311)	97
II-VI Incorporated		
(RAC 490-492,472,375)		11a,18a,21a
Universal Air Filter Company	(RAC 313)	97
Vetor Fields Inc.	(RAC 344)	99
Velmex, Inc.	(RAC 465)	12a
Visual Solutions, Inc.	(RAC 355)	100
VLSI Standards	(RAC 323)	98
Wyko Corporation	(RAC 324)	98
Z World Engineering	(RAC 582)	106

*RAC stands for Reader Action Card. For further information on these advertisers, please write in the RAC number on the Reader Action Card in this issue. This index is compiled as a service to our readers and advertisers. Every precaution is taken to insure its accuracy, but the publisher assumes no liability for errors or omissions.

New Macsyma® 2.0

Symbolic-numerical-graphical math software

"Macsyma is now the leader in the mathematical program marketplace."


- PC Magazine

"Macsyma is the heavy artillery . . . remarkably easy to use . . . Users with heavy math needs should insist on Macsyma."

- IEEE Spectrum

"No comparable math software has such satisfying on-line help and such an abundance of tutorial demonstrations."

- MC Extra (Germany)



Best Notebook Interface†

Only Macsyma combines formatted text, textbook display of math, in-place editable graphics and hypertext links in re-executable notebooks.

† On PCs. Older interface on workstations.

Call for a free demo disk today.




Macsyma Inc.
20 Academy Street
Arlington, MA 02174

800-macsyma tel: 617-646-4550
(800-622-7962) fax: 617-646-3161
email: info@macsyma.com

For More Information Write In No. 427

High Resolution 875-line Recording of FLIR & Video



Improved Horizontal Resolution

Merlin Scan Converter Systems translate 875-line video to 525-line format for standard, low-cost video equipment. The difference between 875-line and 525-line rate recording provides a better image by improving horizontal resolution. Available in 120VAC and in 120VAC and 28VDC configurations.




Merlin
MERLIN ENGINEERING WORKS

1888 Embarcadero Rd, Palo Alto, CA 94303 Phone(415) 856-0900

HEADHUNTER™

HEAD & EYE SLAVED POINTING SYSTEM

Real-time head & eye movement monitoring systems for advanced man/machine interface. Applications include workstation control, simulation/training, human factors & target designation.



ISCAN

P.O. Box 382076
Cambridge, MA 02238-2076 USA
Tel: 617-273-4455
Fax: 617-273-0076

For More Information Write In No. 429

**Make
U.S. Savings Bonds
part of your
retirement savings
program.**



They're the safe, easy and affordable way to save for retirement. Buy U.S. Savings Bonds for as little as \$25. Ask your banker or your employer about including U.S. Savings Bonds in your retirement savings program.

For more information, write
U.S. Savings Bonds, Washington,
DC 20226. For a recorded message
of current rate information, call
1-800-4US BOND • 1-800-487-2663



A public service of this magazine

THE TECHNOLOGY CONNECTION

To Advertise Call (800) 944-NASA

Connecting With Consultants

East

Robert P. Bell
Robert Platt Bell, P.C.
P.O. Box 19668
Alexandria, VA 22320
(703) 683-8822

Former patent examiner specializing
in patent application preparation and
prosecution.

C. Bruce Hamburg, Esq.
Jordan And Hamburg
122 East 42nd St.
New York, NY 10168
(212) 986-2340

Patents, trademarks, copyrights,
chip protection, searches, licensing,
litigation.

West

John R. Flanagan
Registered Patent Attorney
1900 13 St., Suite 205
Boulder, CO 80302
(303) 449-0884

Patent services nationwide,
low fixed fees.

Technology Transfer Events

Announcing The Second Annual SBIR TECHNOLOGY OF THE YEAR AWARDS

Has your company developed a novel, commercially promising technology/product through the government's Small Business Innovation Research (SBIR) Program? You may be eligible for a 1995 SBIR Technology of the Year Award, presented by the Technology Utilization Foundation in cooperation with SBIR-sponsoring agencies of the federal government.

Nominees will have the opportunity to showcase their technology/product at Technology 2005, the world's largest tech transfer conference and exhibition (Oct. 24-26, Chicago), and will be featured in the pages of *NASA Tech Briefs*.

To learn more about this prestigious national award and obtain a nomination packet, call Wayne Pierce at (212) 490-3999.

Industrial Products

MIL-3

- Precision Machined Parts for Science & Industry
- Prototype to Production
- Certified Supplier
- EDI & Barcoding
- Rush Orders OK

MILLENNIUM THREE CORP.

11 Insight Dr. Platteville, WI 53818
PHONE: 800-336-7502
FAX: 608-348-5048

Engineering Catalog

80/20 Inc. FAST
Manufacturers of The Industrial Erector Set®
T-SLOT ALUM. EXTRUSIONS
for Machine Frames, Work
Stations, Shop Projects,
Guarding, Enclosures, Etc.
FREE "Book of Solutions" catalog with
over 1400 stock components
(219) 478-8020 • FAX 478-8121
2570 Commercial Road • Fort Wayne, IN 46809

Apollo 11 Commemorative T-Shirt

Striking full-color illustration on quality white

T-shirt recaptures the spirit and excitement of the Apollo moon landing. Available in children's and adult sizes - S, M, L, XL. \$12.95 each plus \$5.00 shipping/handling. (NY residents add sales tax.)




Mail order with check to:
Associated Business
Publications, Dept.
F, 317 Madison
Avenue, Suite
921, New York,
NY 10017. Be
sure to indicate
size(s). Credit
card orders call
(212) 490-3999.

NASA Tech Briefs, ISSN 0145-319X, USPS 750-070, copyright© 1995 in U.S., is published monthly by Associated Business Publications Co., Ltd., 41 E. 42nd St., New York, NY 10017-5391. The copyrighted information does not include the (U.S. rights to) individual tech briefs which are supplied by NASA. Editorial, sales, production and circulation offices at 41 East 42nd Street, New York, NY 10017-5391. Subscription for non-qualified subscribers in the U.S., Panama Canal Zone, and Puerto Rico, \$75.00 for 1 year \$125.00 for 2 years; \$200.00 for 3 years. Single copies \$10.00. Foreign subscriptions one-year U.S. Funds \$195.00. Remit by check, draft, postal, express orders or VISA, MasterCard, or American Express. Other remittances at sender's risk. Address all communications for subscriptions or circulation to NASA Tech Briefs, 317 Madison Ave., New York, NY 10017-5391. Second Class postage paid at New York, NY and additional mailing offices.

POSTMASTER: please send changes to NASA Tech Briefs, P. O. Box 10523, Riverton, NJ 08070-0523.

NASA Tech Briefs, August 1995

MONITOR, RECORD & ANALYZE



- No Delay . . . see full traces on monitor while recording
- On-Board Data Analysis as well as by host program
- Patented Twin Printhead Design . . . 300 dpi laser printer resolution for clear, crisp traces
- On-Board Signal Conditioning for voltage, temperature, pressure and strain recording
- Front Panel Floppy Drive for personal chart and system setups
- Data Capture . . . store up to 32 megabytes in RAM; 170 megabytes to internal hard drive; stream to external 2 gigabyte drive via SCSI; archive to DAT or floppy drive
- 8 to 32 Waveform Channels . . . plus 32 events; DC to 20 kHz; chart speeds to 500 mm/sec
- Record analog, digital, or both

The MT95K2 lets you preview your data, record it, store it, play it back, analyze it, record it again, and more! For a basic 8 channel recorder or a sophisticated 32 channel recording system, the MT95K2 is the perfect platform for you today and tomorrow!

Phone, fax, or write for details.


 **Astro-Med, Inc.**

Astro-Med Industrial Park, West Warwick, Rhode Island 02893
Phone: (401) 828-4000, Toll Free: (800) 343-4039, Fax: (401) 822-2430
In Canada Call: 1-800-565-2216

Sales and Service Centers throughout the U.S., Canada and Europe • Dealers located throughout the world.

Astro-Med is System Certified to ISO 9001

MSC/PATRAN is the OPEN CAE environment.



W I D E O P E N



MSC/PATRAN defines the concept of the open CAE environment. It's boundless. Broad. Deep. Full-featured. Fast. Extensively integrated. Fully programmable. And ready to use. MSC/PATRAN is tightly integrated with MSC/NASTRAN and provides direct CAD geometry access that is second to none in the industry. Unique preference tools give analysts the flexibility to access the solver of their choice, using the syntax specific to that code. From small companies to large corporations, MSC/PATRAN users create customized applications to suit their particular needs. Enhancing MSC/PATRAN's advanced functionality is an easy-to-learn, easy-to-use, Motif-compliant user interface. Experience the wide-open performance that MSC/PATRAN can deliver to your organization. Call 800-642-7437, ext. 500 today for our informative brochure. Don't get left behind.

Simply **P**owerful.™



**The
MacNeal-Schwendler
Corporation**

For More Information Write In No.