

May 1999

Vol. 23 No. 5




TECH BRIEFS

ENGINEERING SOLUTIONS FOR DESIGN & MANUFACTURING

NASA's Invention of the Year

Product of the Year Winners

Design Show Highlights



*Rapid
Product
Development*

Photonics Tech Briefs

JOHN F. KENNEDY
SPACE CENTER LIBRARY
DOCUMENTS DEPARTMENT
CIRCULATION COPY

SPC
RM. 3870, K69X
0788

www.nasatech.com

New High-Performance PCI Data Acquisition

Get the reliability, accuracy, performance, and ease of use your measurement applications require – **at a new low price.** Choose PCI E Series data acquisition (DAQ) boards from National Instruments and get the best for less.

✓ Reliability

High-grade components and exhaustive product testing combine to provide increased reliability.

✓ Accuracy

Our DAQ products feature precision onboard voltage references for accurate measurements. And, we back them up with calibration certificates for NIST traceability.

✓ Performance

Our bus master DAQ products make high performance measurements, maintaining measurement accuracy at high gains and fast acquisition rates.

✓ Ease of Use

If a DAQ board isn't easy to use, it's not low cost. Our products give you Plug and Play compatibility (no jumper posts, switches, or pots); autocalibration; and intuitive software configuration.



Get E Series Performance and Accuracy so you can
Take Measurements, Not Estimates




www.natinst.com/info/pcidaq (800) 327-9894

Tel: (512) 794-0100 • Fax: (512) 683-9300 • info@natinst.com

For More Information Circle No. 501

BUY ONLINE!



Choose Your PCI DAQ Board

	16 channels in, 12 bits, 200 kS/s, 8 digital I/O lines, 2 counter/timers	\$395
PCI-6023E		
	16 channels in, 12 bits, 200 kS/s, 2 channels out, 8 digital I/O lines, 2 counter/timers	\$595
PCI-6024E		
	16 channels in, 12 bits, 200 kS/s, 2 channels out, 32 digital I/O lines, 2 counter/timers	\$695
PCI-6025E		
	24 static digital I/O lines with handshaking and a user-defined start-up state	\$95*
PCI-6503		

Call for quantity pricing!


U.S. pricing; includes NI-DAQ driver software unless otherwise noted.
*Hardware only pricing



Call today for
datasheets or
download from
our Website



© Copyright 1998 National Instruments Corporation. All rights reserved. Product and company names listed are trademarks or trade names of their respective companies.



Really fast printing. (As in six times faster.)

Introducing the HP DesignJet 1000 Series printers. Six times faster than our 700 Series.

Pure Speed: HP's new DesignJet 1050C and 1055CM large-format printers. With JetExpress technology, 300-ft. paper rolls, a bigger printhead and stringent HP quality standards, you'll be able to crank out print after print at speeds up to six times faster than our 700 Series printers. And remember, HP inks and printing materials provide the highest quality results. To contact one of our expert VIP resellers, call 800-851-1170 ext. 4098. Or visit us at www.hp.com/info/4098.

hp HEWLETT
PACKARD
Expanding Possibilities

To find out how to trade in your old large-format printers, call 800-851-1170.

© 1999 Hewlett-Packard Company. Prints D-size color line drawing in 45 seconds in Draft mode, on bond media. Actual print times vary with files. In Canada, call 1-800-387-3867, Dept. 316.

Sealing and Bearing Solutions

Add performance, not cost

Luytex® Slydring® is recommended for high performance applications because of its high load bearing capability. By replacing conventional metal wear rings with efficient, lightweight, maintenance-free, self-lubricating Luytex® Slydring®, engineers can reduce costs while improving overall product performance. Superior wear resistance, exceptional anti-friction properties, and the ability to cope with most environmental and temperature extremes make Luytex® Slydring® the best choice for long service life and dependable operation.

Luytex® is a composite material of special thermoset resins impregnated with a fine-weave mesh fabric. Environmentally friendly Luytex® materials contain no hazardous or toxic substances and are precision machined to meet diverse and demanding requirements for industries such as aerospace, food processing, mobile, injection molding, oil & gas, and general hydraulics, to name a few.

Busak+Shamban, 800-767-3257.

For More Information Circle No. 586



BEARINGS TO KEEP YOU ROLLING



Durobal® are the ultimate roller element bearings composed of custom engineered polymers. Offering design solutions to problems associated with metal bearing applications, Durobal® bearings provide value added design freedom. Applications include medical and photo processing equipment, business machines, and other industrial and consumer products.

DUROBAL®

For sales and technical assistance please call:

800-767-3257

www.busakshamban.com

- Zero maintenance
- Self-lubricating
- Wear and corrosion resistant
- Environmentally friendly
- Low friction
- Lightweight
- Low noise
- Non-magnetic, non-metallic
- Wide temperature range (cryogenic to 550°F)


Busak+Shamban



For More Information Circle No. 588

Add value, not cost

Available in stock for immediate delivery, the Turcon® Glyd Ring® T is a patented, compact, bi-directional piston seal that outperforms most conventional seal designs. It has a unique seal profile that offers substantial improvement in leakage control and low friction operation at a competitive price.



The Turcon® Glyd Ring® T is designed to accommodate larger than normal extrusion gaps, which can reduce hardware costs while still providing excellent extrusion resistance. The side edge profile eliminates blow-by effects, and the wiping ability of the sealing edges protects against contamination.

Turcon® seals are well known for superior performance. Temperature ranges from -65° to +400°F (-54° to +205°C) and operating pressures to 5000 psi (53 MPa) are standard. Sizes to 100 inches (2500 mm) are available.

Busak+Shamban, 800-767-3257.

For More Information Circle No. 587

Your Ultimate Destination!

↑ #1 Availability of Product
↑ #1 On-Time Delivery
↑ #1 Over-All Performance

Superior^{ave}

Servicerd

www.digikey.com

SAME-DAY SHIPMENT!

on orders entered by:

- 5:00 PM CT -All delivery options
- 7:00 PM CT -UPS Next-Day
- 8:00 PM CT -UPS 2nd/3rd Day

Call, write, fax or visit us on the Internet for your FREE CATALOG today!

Digi-Key[®]

Digi-Key Corporation


701 Brooks Ave. South • Thief River Falls, MN 56701

Toll-Free: 1-800-344-4539 • Fax: 218-681-3380


Order Online www.digikey.com

For More Information Circle No. 550

Is personal **productivity**
a thing of the past?



Traditionally, the value of your CAD/CAM system was based on how productive it made you. Today the value of your mechanical design automation system is not based on how productive it can make the individual, but rather how well it integrates, communicates and collaborates enterprise wide. RAND Worldwide™ is a company which offers more than just hardware and software. A company with highly skilled professionals spanning the globe. A company whose combined knowledge, wisdom and skill are accessible by all of its people worldwide to solve your most demanding enterprise solutions, quickly. A company that is **smarter, faster and friendlier.**



© 1998 RAND WORLDWIDE. ALL RIGHTS RESERVED.

1.877.RAND-AID

| www.rand.com

For More Information Circle No. 577



FEATURES

- 20 InReview
- 22 National Design Engineering Show: Leading Design to the 21st Century
- 28 Product of the Year Award Winners
- 30 NASA's Invention of the Year
- 34 Application Briefs



BRIEFS



36 Special Coverage: Sensors

- 36 GPS "Compound Eye" Attitude Sensor
- 38 Compact Magnetic-Sensor Units for Detecting Mines
- 42 Resonant Microstrip Patch Antenna as Ice-Thickness Gauge
- 44 Acoustical-Sensor Assemblies for Use in Flows
- 45 Biotelemetry Using Implanted Unit to Monitor Preterm Labor



48 Electronic Components and Systems

- 48 $\text{LaNi}_{5-x}\text{M}_x$ Alloys for Ni/Metal Hydride Electrochemical Cells
- 50 Finite-Width Coplanar-Waveguide Patch Antenna



52 Software

- 52 Updated Software for Predicting Noise From Aircraft



54 Materials

- 54 Durable Advanced Flexible Reusable Surface Insulation



56 Mechanics

- 56 Eclipse Aerotow Dynamics Experiment
- 58 Direct Thrust-Measurement Technique Applied to an F-15 Airplane



59 Machinery/Automation

- 59 Experiment on Quasi-Tailless Flight of an X-31A Airplane



62 Bio-Medical

- 62 Improved Suit for Protection During Abrasive Blasting
- 62 Exoskeletal System for Neuromuscular Rehabilitation



65 Physical Sciences


- 65 Single-Crystal YAG Reinforcement Preforms for Refractory Composites



DEPARTMENTS

- 14 Commercial Technology Team
- 16 UpFront
- 18 Reader Forum
- 32 Commercialization Opportunities
- 47 Special Coverage Products: Sensors
- 76 Special Coverage Products: Composites & Plastics
- 77 New on the Market
- 78 New on Disk
- 79 New Literature
- 80 Advertisers Index

SPECIAL SUPPLEMENTS



1a - 24a Photonics Tech Briefs

Follows page 32 in selected editions only.



1b - 10b Rapid Product Development

Follows page 64 in selected editions only.


(Also available online at www.nasatech.com)

NEW Mechanical Event Simulation with Kinematic Elements


Dynamic stresses are shown on the spring. Other suspension components are modeled with a damper element and kinematic elements for faster processing.



Original CAD Solid Model from SolidWorks.



See Dynamic Stresses During the Event at
www.algor.com



CAD Solid Model Assemblies to Mechanical Event Simulations and Faster Stress Analyses with Algor's New Kinematic Elements

Algor's Release 12 introduces 2- and 3-D kinematic elements, which produce massive speed gains in processing for a Mechanical Event Simulation or static stress analysis. Kinematic elements can be used in place of regular (flexible) elements when an area of the model is relatively rigid when compared with regions of stress interest. Kinematic elements can be constrained or loaded with force, traction, pressure or gravity. Because these elements have mass and can transmit forces, they can produce motion and stress in flexible elements. Engineers, therefore, can import CAD solid models or assemblies and specify which parts are to be modeled as kinematic or flexible elements, as appropriate. This means that for the first time engineers can run a virtual experiment on complete CAD solid models or assemblies using Mechanical Event Simulation on desktop computers.

Kinematic elements can interact with impact walls and other parts of an assembly made of kinematic or other element types. Engineers can set up test runs of Mechanical Event Simulations by modeling the entire assembly with kinematic elements and processing for motion only. This means the engineer can study the motion of the event to see if it works prior to adding regular (flexible) elements for the detailed stress analysis.

Kinematic elements can dramatically speed up processing runs for regular linear static stress analysis when significant parts of the model are relatively rigid.

Download and try a **FREE** Limited-time Trial Version of Algor's Release 12 Software Featuring Mechanical Event Simulation at:
www.algor.com

Get a **FREE** demo video and CD-ROM from Algor.
Complete this form and fax it to: +1 (412) 967-2781.

Or contact: www.algor.com
info@algor.com
+1 (412) 967-2700

Name _____ Company _____
Address _____
City _____ State/Prov _____ Country _____ Zip/Postal Code _____
Phone _____ Fax _____ E-mail _____ (kine-us)

ALGOR
When the Engineering Has to be Right
Algor, Inc.
150 Beta Drive, Pittsburgh, PA 15238-2932 USA
Phone: +1 (412) 967-2700
Fax: +1 (412) 967-2781
California: +1 (714) 564-0844
Europe (UK): +44 (1784) 442 246
E-mail: info@algor.com
Web: www.algor.com

- 66 Computing Chemical Kinetics With Low-Dimensional Manifolds
- 68 Quadrupole Mass Analyzer Based on Linear Ion Trap
- 69 Inflatable Membrane Reflectors for Multiple-Purpose Applications



70 Books and Reports

- 70 Active Homopolar Magnetic Bearing
- 70 Properties of Cubic Boron Nitride Films



71 Special Coverage: Composites & Plastics

- 71 Crimping Thin PTFE Tubes Onto Thin Stainless-Steel Tubes
- 72 Polymeric Composite Damage Protective Overwraps for Composite Pressure Vessels
- 72 Hybrid Composite Overwraps for Low-Pressure Tanks
- 73 Integrally Wound Skirt for Composite-Overwrapped Tank
- 73 Repair of Composite-Overwrapped Pressure Vessels
- 74 Ceramic Composites of ZrB_2 , HfB_2 , ZrC , HfC , and SiC

This document was prepared under the sponsorship of the National Aeronautics and Space Administration. Neither Associated Business Publications Co., Ltd. nor the United States Government nor any person acting on behalf of the United States Government assumes any liability resulting from the use of the information contained in this document, or warrants that such use will be free from privately owned rights. The U.S. Government does not endorse any commercial product, process, or activity identified in this publication.

PRODUCT OF THE MONTH

ESDU engineering design database now available in electronic format from Information Handling Services.

16



ON THE COVER



Dozens of new products were introduced recently at the National Design Engineering Show (NDES) in Chicago, including Mechanical Desktop® 4 mechanical CAD software from Autodesk, San Rafael, CA. The new release contains updated assembly-centric design features and commands. For instance, in this design automation example, the shaft generator, standard content, and screw connection commands help to streamline the process of creating 3D content, so designers do not have to draw each piece independently. For more information on this and other new products unveiled at NDES, see the feature beginning on page 22.

(Image courtesy of Autodesk)

Permissions: Authorization to photocopy items for internal or personal use, or the internal or personal use of specific clients, is granted by Associated Business Publications, provided that the flat fee of \$3.00 per copy be paid directly to the Copyright Clearance Center (222 Rose Wood Dr., Danvers, MA 01923). For those organizations that have been granted a photocopy license by CCC, a separate system of payment has been arranged. The fee code for users of the Transactional Reporting Service is: ISSN 0145-319X/94 \$3.00+.00


Is your GPS product ready to roll over?

At midnight on August 21, 1999 the GPS satellite clocks will roll to January 6, 1980. Datum has developed upgrades to all of its GPS timing receivers that allow them to properly roll over to August 22, 1999.

To see if your Datum receiver needs this upgrade, and to get full details, see our web page, www.datum.com/crollover.htm, or call 800/348-0648 for full details.



Bancomm-Timing Division
6781 Via del Oro
San Jose CA 95119-1360
Tel: 408/678-4161 Fax: 408/574-4950
e-mail: bt_sales@datum.com
www.datum.com



Deep Memory Oscilloscopes

1 Gigabyte Memory!

- ➡ 100 MS/s
- ➡ Up to 4 Channels
- ➡ 8 and 12 Bit Models
- ➡ Built-in Jaz Drive
- ➡ Export Data Effortlessly



**Every Modern
Lab Should
Have a
Gage DMO**

For Free Application Engineering

Call: 1-800-567-GAGE

Ask for Extension: 3406

www.gage-applied.com/ad/nasa599.htm

GaGe

GAGE APPLIED SCIENCES INC.

1233 Shelburne Road, Suite 400
South Burlington, VT 05403

Tel: 800-567-GAGE

Fax: 800-780-8411

e-mail: prodinfo@gage-applied.com


There are a ton of reasons to use Vespel[®] just about anywhere.



The reasons to use Vespel[®] polyimide parts and shapes keep piling up. And not just because they stand up to heat, friction, pressure and aggressive environments – with minimal or no lubrication. Manufacturers are finding that Vespel[®] parts in a wide range of applications can really trim the bottom line. That's because the reliability and long life of Vespel[®] parts can make them the most cost-effective choice for general applications in the long term.


If your applications require parts that can withstand extreme temperatures (cryogenic to 550 F), Vespel[®] should be your first choice. Vespel[®] should also be considered for parts that rub together, if metal parts are too noisy, or if fluid flow needs to be controlled.

Superior performance and reliability aren't the only ways Vespel[®] can save you money. Often, you can consolidate two or more existing parts in one Vespel[®] piece.



Seal Rings.

In the assembly of automobile transmissions, and farm and construction equipment, Vespel® seal rings reduce costs by replacing expensive metal rings, which can fracture or deform during assembly. They also reduce warranty costs by producing a better seal.



Bushings.

In aircraft engine vanes, Vespel® bushings withstand high-frequency vibration dithering and offer excellent stability and lubricity at extreme temperatures. They also reduce assembly time.



Thrust Devices.

The automotive industry counts on Vespel® thrust devices because they reduce friction, extend component life and can be easily molded. What's more, the variety of Vespel® grades allows manufacturers to specify the properties they need most.



Thrust Washers.

In construction equipment transmissions, Vespel® thrust washers reduce costs and manufacturing time by eliminating the need for secondary machining. Vespel® washers also withstand high pressure and exhibit minimal wear with limited or no lubrication.



Compressor Disc Valves.

Supermarkets are cooling foods more efficiently with disc compressors, featuring components made of Vespel®. Vespel® not only reduces energy and noise levels, but it also offers excellent wear resistance. The Vespel® part is expected to operate for 15 years without failure.



Insulators.

In plasma-arc cutting torches, Vespel® insulators provide superior strength and durability at high temperatures up to 550 F, lasting up to six times longer than fragile ceramic insulators.



Stripper Fingers.

Thanks to its high temperature resistance, Vespel® parts are ideal for copier stripper fingers. The Vespel® fingers resist heat as well as toner buildup, allowing a greater number of copies without part changes.



And Vespel® parts can be direct-formed, which eliminates machining costs.

When you consider how cost-effective Vespel® parts can be in the long term, it's clear that we don't just make better bushings, bearings, washers and seals. We make better sense.

www.dupont.com/enggpolymer

IF YOU WANT TO GET TECHNICAL

For information,
call 1-800-972-7252.
Or write: DuPont Vespel®,
G-52491, P.O. Box 80010,
Wilmington, DE
19885-1010.



Vespel®
Polyimide Parts and Shapes

For More Information Circle No. 513

COMBINE MULTIPLE COMPUTER & VIDEO SOURCES ON A SINGLE SCREEN



SUPERVIEW™ DISPLAY PROCESSOR LETS YOU COUNT UP TO 10 IN REAL-TIME AND FULL COLOR

Display up to **10**
simultaneous video inputs
including NTSC/PAL or S-Video

Display up to **10**
simultaneous computer inputs
up to 1280 x 1024 pixels

Display a combination of **10**
simultaneous video and
computer inputs

Position and scale each
window independently

Zoom within each window

Overlay computer graphics
on video

RS-232 or front panel control

Visit our web site
<http://www.rgb.com>

RGB SPECTRUM®
a visual communications company™
950 Marina Village Parkway
Alameda, California 94501
Tel: (510) 814-7000
Fax: (510) 814-7026
E-mail: sales@rgb.com



Published by Associated Business Publications
Publisher Joseph T. Pramberger
Chief Editor Linda L. Bell
Associate Publisher, *Photonics Tech Briefs* Linda Silver
Editor, Market Focus Editions Robert Clark
Internet Editor Suzanne Bilyeu
Production Manager Margery Koen
Assistant Production Manager John Iwanciw
Art Director Lois Erlacher
Production Artist Christopher Coleman
Circulation Manager Hugh J. Dowling

BRIEFS & SUPPORTING LITERATURE: Written and produced for NASA by
Advanced Testing Technologies, Inc., Hauppauge, NY 11788

Technical/Managing Editor Ted Selinsky
Sr. Technical Analyst Dr. Larry Grunberger
Art Manager Eric Starstrom
Staff Writers/Editors Dr. Theron Cole, George Watson
Graphics Robert Simons
Editorial & Production Joan Schmiemann, Becky D. Bentley

NASA:

NASA Tech Briefs are provided by the National Aeronautics and Space
Administration, Technology Transfer Division, Washington, DC:

Administrator Daniel S. Goldin
Director, Commercial Technology Dr. Robert Norwood
Publications Director Carl Ray

ASSOCIATED BUSINESS PUBLICATIONS

317 Madison Avenue, New York, NY 10017-5391
(212) 490-3999 FAX (212) 986-7864

Chairman/Chief Executive Officer Bill Schnirring (bill@abpi.net)
President/Chief Operating Officer Domenic A. Mucchetti
MIS Manager Ted Morawski
Webmaster Albert Sunseri
Credit/Collection Felecia Lahey
Accounting Manager Larry Duze
Trade Show Manager Melissa Hinnen
Human Resources Manager Lourdes Del Valle
Office Services Manager Sylvia Ruiz

NASA TECH BRIEFS ADVERTISING ACCOUNT EXECUTIVES


Headquarters (212) 490-3999
CT, MA, NH, ME, VT, RI, Eastern Canada Dick Groth
at (508) 553-0967
NY Mike Venezia
at (860) 871-7491
NJ, PA, DE, VA, DC, MD Ryan Kraven
at (212) 490-3999
NC, SC, GA, FL, AL, TN, MS, LA, AR, OK Christa Collins
at (954) 966-3939
OH, Western PA, WV Louise Clemens
at (216) 397-7477
MN, ND, SD, WI Bob Casey
at (847) 223-5225
IL, MO, IA, KS, NE Jeff Casey
at (847) 223-5225
IL, MI Colleen Bresnahan
at (847) 223-5225
IN, KY, Southwest OH, Western NY, Central Canada Chris Casey
at (847) 223-5225
N. Calif., CO Bill Hague
at (408) 492-9292
WA, OR, ID, MT, WY, UT, Western Canada Bill Madden
at (253) 858-1192
S. Calif., NV, TX Blake Dahlgren
at (310) 860-0172
AZ, NM Linda Silver
at (310) 247-0317
International Sales Rachel Di Santo
at (0144) 01932-564999
Internet Advertising Luke Schnirring
at (212) 490-3999
TechDeck Postcard Advertising Erving Dockery
at (212) 490-3999

For a complete list of staff e-mail addresses, visit www.nasatech.com

1 Engineer. 1 Idea.

1,165 Parts.

20 Days.



Revolutionary.

For a long time industrial designer Simon Floyd had an idea for a new type of engine. He also had at his fingertips one of the leading "high end" CAD systems, but the one thing he didn't have was spare time. "This is a complex assembly and the task of designing it in any conventional CAD system was just too daunting. However, once I got my hands on IronCAD, I finally had the power to realize my vision," says Mr. Floyd. IronCAD's unique Drag & Drop Solid Modeling and Design Flow™ Architecture gave him the power to not only work fast, but to innovate while he designed. He's become so enthusiastic about IronCAD, he now offers it to his clients. To see a case study of Simon Floyd's awesome engine design and to learn more about how IronCAD is powering the next industrial revolution, log on.

www.ironcad.com

800.339.7304



Join the revolution or be left behind.

NASA's R&D efforts produce a robust supply of promising technologies with applications in many industries. A key mechanism in identifying commercial applications for this technology is NASA's national network of commercial technology organizations. The network includes ten NASA field centers, six Regional Technology Transfer Centers (RTTCs), the National Technology Transfer Center (NTTC), business support organizations, and a full tie-in with the Federal Laboratory Consortium (FLC) for Technology Transfer. Call (609) 667-7737 for the FLC coordinator in your area.

NASA's Technology Sources

If you need further information about new technologies presented in *NASA Tech Briefs*, request the Technical Support Package (TSP) indicated at the end of the brief. If a TSP is not available, the Commercial Technology Office at the NASA field center that sponsored the research can provide you with additional information and, if applicable, refer you to the innovator(s). These centers are the source of all NASA-developed technology.

Ames Research Center

Selected technological strengths: Fluid Dynamics; Life Sciences; Earth and Atmospheric Sciences; Information, Communications, and Intelligent Systems; Human Factors.
Carolina Blake
(650) 604-0893
cblake@mail.arc.nasa.gov

Dryden Flight Research Center

Selected technological strengths: Aerodynamics; Aeronautics; Flight Testing; Aeropropulsion; Flight Systems; Thermal Testing; Integrated Systems Test and Validation.
Lee Duke
(805) 258-3802
lee.duke@dfrc.nasa.gov

Goddard Space Flight Center

Selected technological strengths: Earth and Planetary Science Missions; LIDAR; Cryogenic Systems; Tracking; Telemetry; Command.
George Alcorn
(301) 286-5810
galcorn@gsfc.nasa.gov

Jet Propulsion Laboratory

Selected technological strengths: Near/Deep-Space Mission Engineering; Microspacecraft; Space Communications; Information Systems; Remote Sensing; Robotics.
Merle McKenzie
(818) 354-2577
merle.mckenzie@ccmail.jpl.nasa.gov

Johnson Space Center

Selected technological strengths: Artificial Intelligence and Human Computer Interface; Life Sciences; Human Space Flight Operations; Avionics; Sensors; Communications.
Hank Davis
(281) 483-0474
hdavis@gp101.jsc.nasa.gov

Kennedy Space Center

Selected technological strengths: Environmental Monitoring; Sensors; Corrosion Protection; Bio-Sciences; Process Modeling; Work Planning/Control; Meteorology.
Gale Allen
(407) 867-6626
galeallen-1@ksc.nasa.gov

Langley Research Center

Selected technological strengths: Aerodynamics; Flight Systems; Materials; Structures; Sensors; Measurements; Information Sciences.
Dr. Joseph S. Heyman
(804) 864-6006
j.s.heyman@larc.nasa.gov

John H. Glenn Research Center at Lewis Field

Selected technological strengths: Aeropropulsion; Communications; Energy Technology; High Temperature Materials Research.
Larry Viterna
(216) 433-3484
cto@grc.nasa.gov

Marshall Space Flight Center

Selected technological strengths: Materials; Manufacturing; Nondestructive Evaluation; Biotechnology; Space Propulsion; Controls and Dynamics; Structures; Microgravity Processing.
Sally Little
(256) 544-4266
sally.little@msfc.nasa.gov

Stennis Space Center

Selected technological strengths: Propulsion Systems; Test/Monitoring; Remote Sensing; Nonintrusive Instrumentation.
Kirk Sharp
(228) 688-1929
ksharp@ssc.nasa.gov

NASA Program Offices

At NASA Headquarters there are seven major program offices that develop and oversee technology projects of potential interest to industry. The street address for these strategic business units is: NASA Headquarters, 300 E St. SW, Washington, DC 20546.

Carl Ray
Small Business Innovation Research Program (SBIR) & Small Business Technology Transfer Program (STTR)
(202) 358-4652
cray@mail.hq.nasa.gov

Gerald Johnson
Office of Aeronautics (Code R)
(202) 358-4711
g_johnson@aeromail.hq.nasa.gov

Bill Smith
Office of Space Sciences (Code S)
(202) 358-2473
wsmith@sm.ms.oss.hq.nasa.gov

Dr. Robert Norwood
Office of Aeronautics and Space Transportation Technology (Code R)
(202) 358-2320
rnorwood@mail.hq.nasa.gov

Roger Crouch
Office of Microgravity Science Applications (Code U)
(202) 358-0689
rcrouch@hq.nasa.gov

John Mulcahy
Office of Space Flight (Code MP)
(202) 358-1401
jmulcahy@mail.hq.nasa.gov

Granville Paules
Office of Mission to Planet Earth (Code Y)
(202) 358-0706
gpaules@mtpe.hq.nasa.gov

NASA's Business Facilitators

NASA has established several organizations whose objectives are to establish joint sponsored research agreements and incubate small start-up companies with significant business promise.

Wayne P. Zeman
Lewis Incubator for Technology
Cleveland, OH
(216) 586-3888

Joe Boeddeker
Ames Technology Commercialization Center
San Jose, CA
(408) 557-6700

Dan Morrison
Mississippi Enterprise for Technology
Stennis Space Center, MS
(800) 746-4699

Marty Kaszubowski
Hampton Roads Technology Incubator (Langley Research Center)
Hampton, VA
(757) 865-2140

NASA-Sponsored Commercial Technology Organizations

These organizations were established to provide rapid access to NASA and other federal R&D and foster collaboration between public and private sector organizations. They also can direct you to the appropriate point of contact within the Federal Laboratory Consortium. To reach the Regional Technology Transfer Center nearest you, call (800) 472-6785.

Joseph Allen
National Technology Transfer Center
(800) 678-6882

Dr. William Gasko
Center for Technology Commercialization
Massachusetts
Technology Park
(508) 870-0042

Gary Sera
Mid-Continent Technology Transfer Center
Texas A&M University
(409) 845-8762

Chris Coburn
Great Lakes Industrial Technology Transfer Center
Battelle Memorial Institute
(440) 734-0094

Ken Dozier
Far-West Technology Transfer Center
University of Southern California
(213) 743-2353

J. Ronald Thornton
Southern Technology Applications Center
University of Florida
(352) 294-7822

Lani S. Hummel
Mid-Atlantic Technology Applications Center
University of Pittsburgh
(412) 383-2500

NASA ON-LINE: Go to NASA's Commercial Technology Network (CTN) on the World Wide Web at <http://nctn.hq.nasa.gov> to search NASA technology resources, find commercialization opportunities, and learn about NASA's national network of programs, organizations, and services dedicated to technology transfer and commercialization.

If you are interested in information, applications, and services relating to satellite and aerial data for Earth resources, contact: Dr. Stan Morain, **Earth Analysis Center**, (505) 277-3622.

GREETINGS EARTHLINGS. WE BRING YOU GIFTS.




ACTIVE PIXEL SENSOR

will help develop low cost, high resolution digital cameras and camcorders.




THIN FILM
STRAIN GAUGE

can be used in the design and testing of advanced engines in environments up to at least 1100 degrees Celsius.



HIGH PERFORMANCE
POLYMERS

can be used to make ultra-light, thin, flexible circuits for computers and other electronic devices.



MICROMECHANICS
ANALYSIS CODE

models tire constituents under mechanical loads to accurately predict tire handling and increase tire performance.

YOUR PRODUCT HERE.

Call us for a free search of NASA technology that may help your company's bottom line.

NASA has partnered with thousands of companies to help them develop all sorts of new products. You too can tap into the most cutting-edge technology ever developed. Visit our Web site or call the National Technology Transfer Center.



1-800/678-6882

A few other products that have benefited from NASA technology.



WWW.NASATECHNOLOGY.COM/TB 1-800-678-6882

PRODUCT OF THE MONTH

Engineering Sciences Data Unit (ESDU) International, a division of Information Handling Services, Englewood, CO, has released the ESDU database of mechanical, process, and structural engineering data items in electronic format, on the Internet and CD-ROM. The database contains more than 1,250 data items in 230 volumes. Each volume contains data items covering a specific engineering problem or component; data items may be methods, data examples, programs, or equations that are written to a common standard and are validated by committees of international engineering experts. The database is organized into subject areas such as aerospace, mechanical engineering, process engineering, and structural engineering. Topics covered include fluid mechanics, fatigue testing, noise and vibration, heat transfer, stress and strength, chemical engineering, and wind engineering. The data service is available on a subscription basis.

For More Information Circle No. 750



NASA Center Renamed for Glenn

NASA's Lewis Research Center in Cleveland, OH, has been officially renamed the John H. Glenn Research Center at Lewis Field. Ohio Senator Mike DeWine proposed the name change in recognition of Glenn's contributions to science and space, and to the state of Ohio. "I cannot think of a better way to pay tribute to two of Ohio's famous names, one an aeronautic researcher and the other an astronaut legend and law-maker, than by naming a NASA research center after them," said NASA Administrator Daniel S. Goldin.

The center was built in 1941 and was re-named in 1958 for George William Lewis, research director for the National Advisory Committee for Aeronautics. "The blending of names reflects the pioneering research in aerospace technology that employees have performed throughout the center's history," said Center Director Donald J. Campbell.

For more information on the center, visit the web site at: <http://www.grc.nasa.gov>

NASA's Highway in the Sky

NASA's Advanced General Aviation Transport Experiments (AGATE) Alliance has awarded its Highway in the Sky (HITS) contract to a team led by Avidyne Corp. (Lexington, MA) and AvroTec (Portland, OR). The two companies and their partners will design the general aviation aircraft cockpit of the future, which is expected to be completed in 2001. The goal of HITS technology is to increase utility, safety, and ease of flying. Affordable glass cockpit technology will provide pilots with direct access to the information needed to safely determine routes, speeds, and proximity to adverse weather conditions and other aircraft.

Avidyne will design the HITS software using technology that will replace today's dials and gauges with large digital displays. AvroTec will develop computing and display hardware, building from their FlightMonitor line of multi-function displays. Partner companies include Raytheon Aircraft, Rockwell Collins, and AlliedSignal.


The AGATE Alliance aims to make single-engine/single-pilot planes as safe and economical as automobiles for trips ranging from 200 to 1,000 miles. Under the leadership and sponsorship of NASA and the Federal Aviation Administration (FAA), more than 70 companies have joined forces to establish new standards



This image depicts the single-engine aircraft instrument panel showing computer-generated displays.

and validate emerging technologies in the U.S. small aircraft industry.

For more information, visit the AGATE Alliance web site at www.agate.larc.nasa.gov; Avidyne at www.avidyne.com; and AvroTec at www.avrotec.com




YOU
CAN DO
THREE THINGS
at **ONCE.**
SHOULDN'T YOUR
DOCUMENT
SYSTEM?


***Xerox 8830DDS. The first system to scan, print, or copy
wide-format documents simultaneously.***

The Xerox 8830 Digital Document System makes juggling several jobs at once a lot easier. And now, it's faster than ever at seven D-size documents per minute. Scan one drawing while printing another. Or temporarily interrupt printing to make copies. Plus, our unique AccXES™ Controller gives you direct scan-to-network capability. The result—your work process can be up to 300% faster than with other copiers or printers in its class.

Discover 25 ways to simplify the way you work.
Call 1-877-XES-8212, ext. 119 today.
Or log on to www.engineeringsystems.com



YOU CAN JUDGE YOUR RESEARCH BY ITS COVER



**DISPLAY
THE DYNAMICS
OF YOUR
COMPUTATIONS
WITH:**

Tecplot[®] **Version 7.5**

PRODUCTIVE POWER FOR DATA VISUALIZATION

When you need a plotting program that renders CFD data and calculations into vivid, colorful 2D and 3D images, turn to Tecplot. With Tecplot, you will:

- ☐ Achieve superior visuals, with ease
- ☐ Create presentation-quality plots and grids
- ☐ Interface with industry standard data formats
- ☐ Modify Tecplot to address specific needs
- ☐ Use Tecplot's engine to visualize data for turnkey solutions
- ☐ Leverage solutions from C or FORTRAN code base
- ☐ Link Tecplot with third-party libraries for specialized analysis
- ☐ Add I/O capabilities for unique data formats

www.amtec.com

e-mail: tecplot@amtec.com or Call Toll Free: 800.676.7568

AMTEC[®]

AMTEC ENGINEERING, INC.
P.O. Box 3633, Bellevue, WA 98009-3633
TELEPHONE: 425.827.3304

©1998 Amtec Engineering, Inc. All rights reserved worldwide.
Amtec and Tecplot are registered trademarks of Amtec Engineering, Inc., Bellevue, WA.
All other trademarks are the property of their respective owners.

Reader Forum

Reader Forum is devoted to the thoughts, concerns, questions, and comments of our readers. If you have a comment, a question regarding a specific technical problem, or an answer to a question that appeared in a recent issue, send your letter to the address below.

Your April Reader Forum included a letter from Joel Solomon requesting information on packaging that can be hermetically sealed and contain a nitrogen environment. I may know of a product that would meet Joel's requirements. The product is designed to contain viral and biochemical contaminants. Joel can contact me via e-mail for more information, and to let me know what size packages he is looking for.

Jan Nanning
nanning@bigfoot.com

I recently saw a science show on cable TV in which they showed a NASA scientist demonstrating the benefits of a silicon-based (99% air-1% silicon) material — a "solid smoke" that had excellent thermal benefits. I'm looking for more information on this material.

Bill Severa

(Editor's Note: Bill, the "solid smoke" material, developed by NASA, is called Aerogel. It is made of silica, alumina, carbon, and other materials, and weighs less than the same volume of air. Aerogel is the lightest known solid and can protect virtually anything from heat or cold. A block the size of a human weighs less than a pound, but can support the weight of a compact car! For detailed information on aerogel, see NASA's Marshall Space Flight Center's Aerogel Web Page at: <http://www.aerogels.com>.)

I am doing finite element analysis (FEA) models of thermocouple probes using mineral-insulated (MI) cable. I have a problem approximating the magnesium oxide insulation. I know the density, but I don't know the elastic modulus. Someone I spoke to gave me a value of 30 million psi for MgO insulation. This number seems high, and I am concerned that using this value adds too much stiffness to my model. Does anyone with experience modeling MI cable have any suggestions on how I might model this? Thank you.

Bob Griswold
griswoldb@harcollabs.com


Post your letters to **Reader Forum** on-line at: **www.nasatech.com** or send to: Editor, *NASA Tech Briefs*, 317 Madison Ave., New York, NY 10017; Fax: 212-986-7864. Please include your name, company (if applicable), address, and phone number or e-mail address.

Meet the world's smartest numeric software...

Visit us at booth #1039 at CLEF, May 25-27 in Baltimore to see the newest version of Mathematica!


...fully integrated into the world's most complete technical computing system.

PRECISE



Do you trust every digit of every number your computer gives you? With *Mathematica* you can. Only *Mathematica* can keep track of the precision of its numerical results automatically throughout each calculation, and report only the digits it can justify. Throw in its complete suite of matrix manipulation and statistical analysis tools, and the world's most complete collection of special mathematical functions, and you'll see why *Mathematica* gives you the most precise numerical results you'll find anywhere.

PRACTICAL



How much time do you spend exporting information from one program just so you can read it into another? We've spent a decade making sure that *Mathematica*'s capabilities all fit seamlessly together. Numeric tools work in concert with symbolic algebra capabilities, visualization tools, and a state-of-the-art programming language. All your work is stored in an automatically formatted "notebook" file that you can send to your colleagues, print, or put on the web.

PROGRESSIVE



Because *Mathematica* is smarter, it lets you use your computer in smarter ways. *Mathematica* is a powerful modeling and simulation environment, and its programming language makes simple scripting shells look like Stone Age tools. The *Mathematica* language lets you use your existing programming knowledge, and define problems easily and incrementally, and even connect C, C++, and Fortran code. Do calculations you'd never try before, getting your results quickly and easily.

Engineering with

MATHEMATICA®
PRECISE. PRACTICAL. PROGRESSIVE.



Information and purchases: www.wolfram.com/eng/ntb
or call toll free 1-877-815-5802

Sales inquiries outside the U.S. and Canada: www.wolfram.com/intdealers

All *Mathematica* products are available for Microsoft Windows, Macintosh, and most Unix platforms.

Wolfram Research, Inc.: www.wolfram.com; info@wolfram.com; +1-217-398-0700
Wolfram Research Europe Ltd.: www.wolfram.co.uk; info@wolfram.co.uk; +44-(0)1993-883400
Wolfram Research Asia Ltd.: www.wolfram.co.jp; info@wolfram.co.jp; +81-(0)3-5276-0506

© 1999 Wolfram Research, Inc. *Mathematica* and *MathLink* are registered trademarks of Wolfram Research, Inc. and are not associated with Mathematica Policy Research, Inc. or MathTech, Inc.

WOLFRAM
RESEARCH

www.wolfram.com

For More Information Circle No. 510


Drafting for the Non-Drafter

Visio Technical 5.0 Plus

Steven S. Ross

Visio has long been used by engineers and others who occasionally must draw, but who are not really drafters. It works by allowing users to drag pre-drawn "SmartShapes" into their drawings. There's an added bonus for those who worry about company-wide quality control: The shapes can be standardized so that a specific valve or circuit or chair always looks the same, and always carries the same data with it. This approach works best, of course, for drawing tasks that have lots of repetitive symbols involved — piping, circuits, layout of manufacturing processes, and so forth.

Visio has always come in two flavors. There's a simple version for typical management tasks such as drawing organizational charts or office layouts. And there's the more robust technical version for in-



Even site plans can be cobbled together in Visio. Here is a loading area with crane. The symbols (shapes) in the upper right corner represent containers. They don't scale automatically to the rescaled crane unless everything is connected. The best thing to do is to insert all the shapes and then rescale as necessary.

dustrial design tasks. Both are essentially 2D drafting engines, but the technical version includes 4,000 SmartShapes for such tasks as HVAC control, electrical and electronic schematics, manufacturing and assembly drawings, site and landscape planning, and more.

Technical 5.0 Plus, the latest version, includes support for AutoCAD Release 14 (and earlier) DWG and DXF files and for Bentley MicroStation DGN files. DXF is a reasonably standard ASCII-text file format that allows most CAD packages to exchange drawing files. The exchange is often far from perfect, but tends to work fairly well for basic mechanical design tasks.

Visio's support is not seamless; 5.0 Plus can read DGN, and read or write DXF and DWG. The DGN files are imported only as displayable backgrounds, onto which layers with Visio shapes and connectors can be added. MicroStation users can save files in DXF, which makes the resulting drawings completely editable in Visio.

You can import DWG files the same way (as displayable backgrounds), or you can allow Visio to convert one or more layers of the DWG file into Visio format for editing. If you choose the second option, entities in the DWG file are converted into Visio shapes, with preservation of any symbol attributes that may have been noted in the entities.

Visio promotional literature doesn't really talk about whether the full intelligence of a Visio SmartShape will survive a round trip to and from AutoCAD or MicroStation, or to Visio's own AutoCAD near-clone, IntelliCAD, which uses the DWG format. The answer is "no." To be fair, the problem is not an easy one to solve, and Autodesk has not solved it either for its shape-drag program, Actrix.

In cases where you convert, for example, a DWG file to Actrix or Visio, dimensions and 3D solids tend to disappear or to convert with minor, nagging problems.


We found Visio to translate DWG geometry a bit more cleanly than Actrix. Actrix seems to have a slight edge on translating entities (blocks) into intelligent shapes, however. Neither program displays referenced ("xref") drawings along with the DWG base drawing you translate.

Visio Technical 5.0 Plus also has new facilities management and process engineering tools. The neatest thing about the facilities management tools is a link to standard database software such as Paradox, Oracle, and Microsoft Access. The link makes it easier to handle space plans, and to track equipment company-wide.

The process engineering tools include piping and instrumentation diagrams (P&IDs) and process flow diagrams (PFDs). In a Visio drawing that uses these tools, even components that are connected to piping diagrams and schematics stay connected and auto-

matically route themselves as you add new components.

Of course, not everything you draw can be handled with pre-drawn shapes and connectors. Visio Technical in-



In this circuit diagram, clicking on the component shows its direct connection; the diagonal line extending to the lower left from the clicked object is "logical" only — Visio drew the line itself, based on the circuit logic.

cludes a basic set of drafting tools, and such niceties as a "valve builder" tool to make drawing of hydraulic or pneumatic valves rather simple.

On the electrical side, Visio automatically generates a SPICE (Simulation Program for Integrated Circuits Emphasis) input file or "netlist" of circuit designs you draw. These lists of components and their interconnections can be used by other design tools to validate or fine-tune your circuit.

This version carries an estimated street price of \$349. It will run on a slow Pentium or even a 486 machine with 16 MB of RAM in Windows 95 (NT requires at least 24). For all but the simplest drawings, plan on using a Pentium 166 or faster and at least 32 MB of RAM. We found a Pentium 200 with 64 MB in Windows NT to be quite comfortable.

You can reach Visio at 520 Pike St., Ste. 1800, Seattle, WA 98101; 800-24-VISIO; www.visio.com/technical

Steven S. Ross is associate professor of journalism at Columbia University, New York, NY. He has authored three commercial software packages, including a units conversion program and an engineering calculations program.

There are lots of ways to do control design, but only one way to accelerate it.

Speed control design projects to completion with our fully integrated software solution

Move rapidly from initial design concepts to prototype embedded code

With the new control design solution from The MathWorks, you'll spend less time coding and debugging, and more time exploring ideas and getting results. That's because our solution supports the entire control design process with a complete, integrated set of powerful design, simulation, and code generation tools.

It's based on MATLAB® and Simulink®, the world's leading technical computing software

Now you can explore real-world system behavior while you're still

in the development stage, then quickly fine-tune your design. Use MATLAB for data analysis and algorithm development, Simulink and Stateflow™ for intuitive and realistic control system simulation, and Real-Time Workshop® for generating C code that runs on a variety of hardware target platforms.

See how our control design solution works for others

See how leading automotive and aerospace companies are accelerating development with our control design solution. Their stories are included in our free technical kit. Get yours today.

Visit our Web site to see demos and examples and to order a free control design technical kit.



SIMULINK®

www.mathworks.com/demo4

Call 508-647-7000 • Fax 508 647-7001 • E-mail info@mathworks.com


The MathWorks, Inc. 24 Prime Park Way, Natick, MA 01760 • Employment opportunities: www.mathworks.com/newjobs.html
Europe: www.mathworks.com/eur • Australia: +2-9922-6311 • Brazil: +11-816-3144 • India: +805-549-338 • Israel: +3-561-5151 • Japan: +3-5978-5410
Korea: +2-556-1257 • New Zealand: +7-839-9107 • Singapore: +842-4222 • S. Africa: +11-325-6238 • Taiwan: +2-505-0525

© 1999 by The MathWorks, Inc. MATLAB, Simulink, Stateflow, Handle Graphics, and Real-Time Workshop are registered trademarks, and Target Language Compiler is a trademark of The MathWorks, Inc. Other product or brand names are trademarks or registered trademarks of their respective holders.

For More Information Circle No. 529



Flight control system example

Our integrated control design solution allows you to move smoothly through the stages of your design process. Use MATLAB for data analysis and algorithm development (top), Simulink and Stateflow for both dynamic and event-driven simulation (middle), and Real-Time Workshop for generating prototype code (bottom).



National Design Engineering Show: Leading Design to the 21st Century

National Manufacturing Week® Home of Industry's Best



TO MANUFACTURING EXCELLENCE


IBM



Design engineers from 21 different industries attended the National Design Engineering Show (NDES), one of four shows comprising National Manufacturing Week in Chicago from March 15-18. More than 1,100 exhibitors displayed products in CAD/CAM/CAE, materials, fluid power, motion control, electronics, rapid prototyping, and other areas. A number of exhibitors introduced new products at the show, including those on the following pages.

continued on page 24


Ignore All Speed Limits



Powerful, responsive, incredibly fast. Clearly, the full family of Kodak Motion Analyzers leaves everything else far behind.

So whatever your application — solving a high speed production line glitch, testing airbags, product R&D, you name it — the possibilities are unlimited.

Kodak Motion Analyzers come souped-up with your favorite features. Or ruggedized for tough,



hard-driving environments. Even compact to get you in and out of tight spaces. You can

capture a single frame or reach speeds of over 40,000 frames per second. Plus you get stop-on-a-dime instant replay and ample memory for long record times.


Call 619-535-2908 or e-mail us today for more information. Then go as fast as you like. Wherever the road leads you.

1-800-462-4307, ext. 1008 • www.masdkodak.com/ntb • e-mail: masdkodak@aol.com

KODAK



EASTMAN KODAK COMPANY, MOTION ANALYSIS SYSTEMS DIVISION
For More Information Circle No. 511




• SolidWorks Corp. (Concord, MA) announced XchangeWorks, a new data exchange plug-in that enables engineers to import solid modeling CAD data directly into AutoCAD and Mechanical Desktop®. It integrates seamlessly with existing AutoCAD and Mechanical Desktop

mechanical design environments, allowing for direct translation of part files created with many CAD products such as SolidWorks®, Pro/ENGINEER®, and Unigraphics™. XchangeWorks is available on CD at no charge from the SolidWorks web site at: www.solidworks.com, or www.xchangeworks.com, or by calling 1-800-393-4118.

Products


• Hewlett Packard invited NDES attendees to visit the new Design Chain Engineering web site, where users will find solutions, case studies, events, and other information necessary to connect a firm's product development team for collaborative engineering with remote sites and suppliers. The site is designed to help companies gain time, money, and competitive advantages as they trim delays, diminish errors, reduce development costs, and speed total supply chain time to market. For more information, visit the HP Design Chain Engineering Website at www.hp.com/go/design_chain. (Look for a report on HP's interactive audioconference on collaborative engineering in the June issue of NASA Tech Briefs.)

• Visionary Design Systems (Santa Clara, CA) announced that future versions of its IronCAD design software will incorporate the solid modeling technologies from both Spatial Technology (ACIS®) and Unigraphics Solutions (Parasolid™) simultaneously. Until now, CAD systems could only operate on one underlying modeling kernel at a time. IronCAD will offer the addition of Parasolid to ACIS to enhance operability. Users will be able to intermingle parts based on the two different kernels, and will enable creation of parts based on either kernel. For more information, contact Visionary Design Systems at 408-969-8000; www.vds.com or www.ironcad.com




• Anacon Systems (Springfield, MO) introduced the Digi-Drive SO160090-100A and the SO170090-050A, two new motor controllers for half-horsepower single-phase induction motors. Using

RISC-based proprietary control technology and software algorithms optimized for motor control functions, the series provides a wide range of speed adjustment. The customizable electronics easily integrate into existing or new single-phase motor applications such as fan, appliance, pump, and compressor control, and permit either analog or digital speed control through their A-to-D converter or serial interface input. Previously, multiple discrete speeds in single-phase motors were only available by using complex and expensive motor design or external relays and electronics to reach the two- or three-speed capability. The Anacon drives enable an electronic control system to allow motor speed to be set by the designer. For more information, contact Anacon at 512-762-4445; www.anaconsystems.com



• Knowledge and Innovation Server™ from Invention Machine Corp. (Boston, MA) is an intranet-based software tool that enables users to access, capture, and manage technical knowledge. Organizations can access a large knowledge base of 3D animated scientific effects and technical examples, add and share in-house technical

knowledge, perform competitive patent analyses, and chart technical trends. Available via a corporate intranet, it is operated through a standard web browser. For more information, contact Invention Machine at 617-305-9250; www.invention-machine.com



• Mechanical Desktop® 4 was previewed by Autodesk (San Rafael, CA). The latest version of the mechanical CAD software, and its add-on Mechanical Desktop 4 Power Pack, is built on top of AutoCAD® 2000, the newest version of the PC design software. Mechanical Desktop 4 will offer new assembly-centric design features,

and design and drawing automation capabilities from Genius™ Desktop 3 software. The new version will be released this summer for Windows 95/98/NT platforms. For more information, contact Autodesk at 415-507-5000; www.autodesk.com



KINGSTON STORAGE.

PROVEN IN NASA'S
TOUGHEST TESTS.



THE NASA SPACE SHUTTLE USES KINGSTON'S

Data Express® removable drive enclosures in space for the same reasons you can rely on them for your mission-critical applications here on earth. Kingston's Data Express delivers ultimate reliability and flexibility. Try our rugged DE200 for virtually every removable application, including RAID.

www.kingston.com/storage

- Supports high capacity 3.5" standard and LP half-height drives
- Supports AT/IDE and SCSI including SCA and ULTRA
- Lock-down, all-steel carrier for shock and vibration applications
- Key lock for enhanced security
- Platform independent; bootable from any computer system
- Highly-rated mating connectors, up to 25K cycles
- Optional hot swap, solenoid lock features available
- Comprehensive 7-year warranty

Call a Kingston® consultant today at (800) 259-9370 to find out more about Data Express DE200. It's one of the most versatile removables in the solar system.



Kingston Technology Company, 17600 Newhope Street, Fountain Valley, CA 92708, USA (714) 438-1850, Fax (714) 438-1847. © 1999 Kingston Technology Company. All rights reserved. All trademarks and registered trademarks are the property of their respective owners.

• Designing the wiring and cable harnesses for electrical and electronic systems is an old story. Most engineers are forced to wait for a physical prototype, which they then use to reverse-engineer the design of the system wiring. Then they sketch it out for manufacturing. Linius Technologies (Westborough, MA) offers Embassy 2.0, a MicroSoft Windows-based suite of 3D wire harness design tools that automates the complete design process, including design handoff to manufacturing. It accepts connectivity data from schematic capture packages and combines that with a 3D solid model of the assembly, enabling engineers to design wire harnesses and cables within the context of the 3D model. The new release includes more than 30 design enhancements. For more information, contact Linius at 508-616-9300; www.linius.com

• IBM and Dassault Systemes exhibited two recently introduced products: Version 5 Release 1 of CATIA, their CAD/CAM/CAE software, and Version 2 Release 2 of CATweb™, which offers high-speed web-based e-business navigation tools to explore native engineering data over the web. The new version of CATIA for Windows NT and UNIX is built using STEP, Java, CORBA, and OLE standards. A built-in knowledge engine guides users through a task by combining explicit rules of product behavior with interactive capture of design intent. CATweb allows downloading of multiple 3D models and 2D drawings on the client's machine. It also provides capabilities for design review with new annotation and mark-up features. For more information on CATIA, visit Dassault at www.dsweb.com; for information on CATweb, visit IBM at www.ibm.com



zero backlash for its lifetime at half the cost of a ball screw. It also incorporates BSA's patented ActiveCAM technology, which uses a stainless steel cam that automatically rotates and produces high axial rigidity without sacrificing life, torque, or positional accuracy, according to BSA. For more information, contact BSA at 408-629-1132; www.ball screws.com

• Ball Screws and Actuators (San Jose, CA) announced the rollout of its 1" XC Series plastic antibacklash nut assembly. The one-inch size barrier has been out of reach for antibacklash plastic nuts because load requirements in much light and medium manufacturing can be as much as 500 pounds. BSA says its new nut assembly uses an advanced plastic compound that offers

Space for Business


In the NDES Motion Hall, NASA showcased its newest technologies and presented attendees with the opportunity to view first-hand the future of space exploration and its applicability to industry. Exhibits in the NASA pavilion illustrated how NASA works with businesses to develop the products and technologies of tomorrow, and how to turn those technologies into products that benefit Americans. "Many new technologies coming out of these programs will find their way into industrial and consumer products," said Vernotto McMillan, deputy director of NASA's Marshall Space Flight Center's Technology Transfer Office.

Representatives from the NASA Space Product Development Program were on hand to talk with companies interested in learning more about the benefits of doing commercial work through the program. Other sections of the NASA exhibit included microgravity

product demonstrations, industrial solutions processes, technology transfer collaborations, and a mock-up of a portion of the International Space Station.

One technology on display was special lighting that had been developed for NASA's commercial plant growth experiments in space, but is now being used to treat cancer. The Light Emitting Diodes surgical probe consists of 144 pinhead-sized diodes, is 9" long, and is about 1/2" in diameter. NASA's industry partner, Quantum Devices of Barneveld, WI, improved the LEDs and is working on new applications for them. The probe was developed for photodynamic cancer therapy under a NASA Small Business Innovation Research (SBIR) program grant managed by NASA's Marshall Space Flight Center, Huntsville, AL.

A keynote presentation was given by a panel of NASA engineers and commercial outreach officials. "NASA: Provid-



Ronald Ignatius, president of Quantum Devices, demonstrates the Light Emitting Diodes surgical probe, developed with NASA.

ing Solutions for the Manufacturing Industry" highlighted some of the hottest new technologies coming out of the space program that are available to U.S. companies, and described how to access them. These included embedded web technology and a segmented cold cathode display panel for flat-panel theater-vision TV.

For more information, visit NASA Marshall's Technology Transfer Center web site at: www.nasasolutions.com; for information on the Space Product Development program, visit <http://microgravity.nasa.gov>

who has the budget for **HP** performance? **You** do.



HP 34401A DMM. 6½ digits of resolution for only \$995.*

HP LogicDart. Performs basic logic monitoring, tests dc voltage, frequency, and timing analysis for \$795.*



HP 54600 Series. The feel of analog and the power of digital. 60- to 500-MHz bandwidth. Starting at \$1,995.*



HP E3631A triple output & E3632A bench power supplies. Clean power and programmable (HP-IB or RS-232). \$995.*



HP 53100 Series 225-MHz counters. 10 and 12 digits/resolution, optional 3- & 5-GHz input. Starting at \$1,575.*



HP 34970A data acquisition/switch unit. Modular system offers 20 channels of 6½-digit measurements for only \$1,685.*



HP 54645D MSO. The industry's first mixed signal scope—two scope and 16 logic channels synchronized. \$4,995.*



HP 33120A 15-MHz function/arb generator. Custom waveforms for only \$1,795.*

Call HP DIRECT today at 1-800-452-4844, Ext. 5920, for your FREE HP Basic Instruments Catalog.



Or check out our online HP Basic Instruments (BI) Catalog at

<http://www.hp.com/info/bi45>

Skeptical that a company such as HP can meet your need for low-cost, high-performance instruments? We understand. Ironically, it's *because* of our high-end technology that we're able to deliver a lineup of affordable test instruments.

Who needs products within budget, without compromise?

You do. And so do thousands of other engineers and technicians who ask for instruments without all the costly frills. So each of our basic tools offers just what you need to get the job done right.

That doesn't mean we cut corners. We use our traditional engineering and manufacturing strengths to offer a multitude of high-end technologies in our no-compromise basic instruments.

And we make them incredibly easy to buy through HP DIRECT, where one call can put you in touch with engineers who know how to make the measurements you need to make. You can call with a measurement question, for information on specs, or to discuss which product best suits your needs.

**hp HEWLETT®
PACKARD**
Expanding Possibilities



The *NASA Tech Briefs* Readers' Choice Product of the Year Award winners (left to right): Peter McHugh accepts for Omron Electronics, the Bronze winner; Ryan McDonald for National Instruments, the Gold winner; and Bob Kadarau for InPart, the Silver winner. (Photo by Michael Kardas)

The Product of the Year Finalist awards are displayed by representatives from (left to right) Waterloo Maple, Hyde Park Electronics, IOtech, Raytek, DuPont Performance Lubricants, Algor, and Haptic Technologies. (Photo by Michael Kardas)



NASA Tech Briefs Product of the Year Awards

For the second consecutive year, *NASA Tech Briefs* hosted a gala reception at the top of the John Hancock Center during NDES to present its 1998 Readers' Choice Product of the Year Awards. The fourth annual awards were voted on by the readers of *NASA Tech Briefs*, who turned out in record numbers to vote for the Gold, Silver, and Bronze award winners. Nine other Product of the Year Finalists were presented with awards; all had received Product of the Month honors during 1998.

Each month, *NASA Tech Briefs* editors choose a Product of the Month, which is the one product they feel exhibits exceptional technical merit and practical value. In the December issue, readers are invited to vote for the one product of those 12 highlighted during the year that represents the most innovative product introduced to the engineering community. The product receiving the most votes is the Gold Award winner, and Product of the Year.

This year's Readers' Choice Product of the Year Gold Winner was LabVIEW 5.0 graphical instrumentation software from National Instruments, Austin, TX. The award was presented to Ryan McDonald of National Instruments by *NASA Tech Briefs*' Chief Editor Linda Bell; Senior Editor Bob Clark; and Associate Editor Suzanne Bilyeu. Lab-

VIEW 5.0 provides tools for system developers to create distributed applications, whereby various sections of code can execute on different machines across a network.

The Silver Product of the Year Award was presented to InPart of Saratoga, CA, for the DesignSuite® Internet-based library of 3D CAD models and detailed specs for mechanical components from leading U.S. suppliers. The models can be viewed and downloaded directly to the user's 3D CAD system.

Omron Electronics of Schaumburg, IL, took home the Bronze Award for its F30 machine vision system. The miniature system incorporates all of the elements of a machine vision system — the camera lens, lighting, and processor — into a 3 × 3 × 6" assembly that sets up in minutes.

The following companies were honored as Product of the Year Finalists:

- Algor, Inc. (Pittsburgh, PA) for Release 12 of its finite element analysis based mechanical engineering software;
- IOtech (Cleveland, OH) for the Personal Daq™ full-featured PC-based data acquisition systems utilizing the Universal Serial Bus (USB);
- Waterloo Maple (Waterloo, ON, Canada) for Release 5 of Maple V technical computing software;
- DuPont Krytox Performance Lubricants (Wilmington, DE) for Krytox®

XP lubricants that include a soluble additive to enhance performance of PTFE greases and oils;

- Raytek (Santa Cruz, CA) for the Thermalert® GP two-piece infrared temperature monitoring system;
- Hyde Park Electronics (Dayton, OH) for the Superprox® Model SM607 small-target, ultrasonic proximity sensors;
- SPSS (Chicago, IL) for SigmaPlot 5.0 scientific graphing software for automated graphing and data analysis;
- Haptic Technologies (Montreal, Canada) for the PenCAT/Pro® 3D pen with force-feedback that allows CAD designers to feel objects on the computer screen; and
- Inova Computers (Osterville, MA) for the ICP-K233 family of 3U Compact-PCI single-board computers.

All readers who submitted ballots in the Product of the Year contest were placed in a random drawing to win valuable software donated by winners of last year's Product of the Year awards. Congratulations to these *NASA Tech Briefs* readers:

- Paul M. Reilly of Fujitsu C.P.T., San Jose, CA: Winner of CADKEY 98 mechanical design software from Baystate Technologies, Marlborough, MA; and
- Martin Holland-Bak of Willamette Valley Co., Eugene, OR: Winner of MATLAB technical computing software from The MathWorks, Natick, MA.

THE REASONS TO GET NEW MATHCAD 8 ARE GOING TO JUMP RIGHT OUT AT YOU.

Award-winning
2D CAD package
Imagination Engineer™ LE For Mathcad
FREE WITH MATHCAD® 8!

INTRODUCING MATHCAD 8. IT'S THE MAJOR BREAKTHROUGH YOU'VE BEEN WAITING FOR. AND ITS NEW 3D VISUALIZATION FEATURES ARE JUST PART OF THE STORY.


The biggest math release in years, Mathcad 8 is the most flexible tool available for technical calculations and presentations. It delivers expanded math functionality and more problem-solving power. Plus new IntelliMath™ technology that streamlines calculations by completing tasks for you automatically. You also get advanced formatting options for the best-looking documents and specifications. Full compliance with Windows NT/95/98. And more.

Put it all together with our interactive worksheet interface – which lets you work with equations, text, and graphs visually, just as you do with pencil and paper – and you'll see why Mathcad, the world's #1 choice in technical calculation software, is now even better.


Choose either Mathcad 8 Professional, the worldwide standard for technical professionals. Or Mathcad 8 Standard, for anyone who's ready to go beyond spreadsheets and calculators. Both offer capabilities that make your current calculation methods look – well, a little flat.




For more information, visit
www.mathsoft.com
or call 1-800-MATHCAD today.



New Open GL® graphics deliver rich 3D visualization of systems, solutions and data. Rotate, spin, and zoom in on your graphs for the first time ever by using your mouse. Adjust lighting, color, and surface properties — and add annotations quickly.



Let Mathcad's IntelliMath™ technology analyze your problem and select the best solution algorithm.



The Professional Edition's powerful new solving technology beats the competition, supporting linear programming, optimization routines and problems with hundreds of variables and constraints.

GET MATHCAD 8 AT ONE OF THESE RETAILERS





NASA Selects Top Inventions of the Year

From an unusually strong field of candidates, NASA has selected a spacecraft stabilization device and a high-temperature resin material as the agency's top inventions for 1998. NASA's Commercial Invention of the Year award went to PETI-5, a material developed by three scientists at Langley Research Center. Charles E. Clagett of Goddard Space Flight Center was unanimously chosen as NASA's Government Inventor of the Year for designing the Apparatus for Providing Torque and for Storing Momentum Energy.

A Versatile Substance

PETI-5 — short for "Phenylethynyl Terminated Imide Oligomers," fifth composition — was NASA's unanimous choice for Commercial Invention of the Year. The substance can be used both as a glue that holds fibers together and as an adhesive with a variety of aerospace and commercial applications. It was developed at Langley Research Center, Hampton, VA, by Paul Hergenrother, Joseph Smith, and Brian Jensen.

PETI-5 originally was conceived for the High-Speed Research (HSR) Program, a joint effort between NASA and private industry. HSR required a composite matrix and adhesives that would be strong, lightweight, easy to process, resistant to aircraft fluids, and able to withstand temperatures of 350° F for up to 60,000 hours. No materials were available that met all of these requirements.

PETI-5, a single material, was developed in both composite and adhesive forms to satisfy the HRS specifications. Its chemical composition allows it to cure into a tough, heat-resistant plastic, which is easily formed into complex parts with application of heat and mild pressure. PETI-5 can be processed from readily available chemicals, is non-toxic, and adjusts to environmental changes.

According to NASA, private industry already has shown considerable interest in PETI-5. The material has been licensed to Culver City Composites, a composite prepreg supplier; Imitec, Inc., a resin supplier; Fiberite, Inc., a prepreg supplier; and Cytec Engineered Products, Inc., an adhesive supplier.

Several PETI-5 products are now available commercially, including composite matrix prepreps, supported film adhesives, paste adhesives, core splice materials, and

self-filleting film. These products have resulted in approximately \$10 million in sales, with NASA receiving about \$475,000 in royalties.

PETI-5 is also NASA's nominee for the National Inventor of the Year award, sponsored by the Intellectual Property Owners, Inc. (IPO), in cooperation with the U.S. Patent Office.



PETI-5, a versatile, high-temperature resin and adhesive, was used in the fabrication of this fuselage subcomponent. The material also cures into a tough, heat-resistant plastic that is easily formed into complex parts.

Re-Inventing the Reaction Wheel


The Apparatus for Providing Torque and for Storing Momentum Energy was developed for NASA's Small Explorer (SMEX) program. For the latest SMEX spacecraft, NASA required a compact reaction/momentum wheel that could accelerate at a high rate with little noise and vibration. No commercially available reaction wheel had met the requirements.

Charles Clagett, who heads the Component and Hardware Systems Branch at Goddard Space Flight Center in Greenbelt, MD, delivered a durable, compact design that has at least a four-year life expectancy. The device, also known as the SMEX Reaction/Momentum Wheel, provides approximately twice the torque and 40 times better dynamic balance of comparably sized commercial reaction wheels at less than half the cost. This low-noise device also allows detection of signals that would have been obscured by previous reaction wheels. According to NASA, Clagett's invention has enabled Goddard Space Flight Center to carry out missions that could not be supported by previous technology. The SMEX Reaction/Momentum Wheel has been used successfully in the last two SMEX projects: the Transition Region and Coronal Explorer (TRACE) mission and the Submillimeter Wave Astronomy Satellite (SWAS).

Goddard has licensed the SMEX Reaction/Momentum wheel to CTA Space Systems and to Ithaco Inc., a manufacturer of flywheel-type reaction/momentum wheels. CTA Space Systems, a satellite manufacturer, has used the NASA invention on its GEM Star I and Early Bird 3 satellites. Orbital Sciences Corporation, which recently purchased CTA Space Systems, is using the SMEX wheel on its OrbView 3 satellite.

NASA's top inventors were honored during a ceremony at NASA Headquarters, where they received award checks and certificates. Here are the remaining 1998 Invention of the Year nominees:

- **Ames Research Center:** Low-Density Resin Impregnated Ceramic Article Having an Average Density of 0.15 to 0.40 G/CC; and Low-Density Resin Impregnated Ceramic Article and Method for Making the Same. Inventors: Huy K. Tran, William D. Henline, Ming-ta S. Hsu, Daniel J. Rasky, and Salvatore R. Riccitello. NASA Case # ARC-12011-1.
- **Goddard Space Flight Center:** Micro Pulse Laser. Inventor: James D. Spinhirne. NASA Case # GSC-13493-1.
- **Johnson Space Center:** Rotary Blood Pump and Method for Reducing Pumping Damage to Blood. Inventors: Richard J. Bozeman, James W. Akkerman, Gregory S. Aber, George A. Van Damm, James W. Bacak, Paul A. Svejkovsky, and Robert J. Benkowski. Contributors: Michael E. DeBakey, Cetin Kiris, Dochan Kwak, and Bernard J. Rosenbaum. NASA Case # MSC-22424-1 and MSC-22822-1 (ARC-14087).
- **Kennedy Space Center:** Particle Fallout/Activity Sensor. Inventors: Curtis M. Ihleford, Robert C. Youngquist, John S. Moerk, and Kenneth A. Rose, III. Contributors: William Haskell, Robert Cox, Paul Morgan, Timothy Hodge, Christian Schwindt, and Steven Klinko. NASA Case # KSC-11687-1.
- **Langley Research Center:** Apparatus and Method for Measuring Strain in Bragg Gratings. Inventor: Mark E. Froggatt. NASA Case #LAR-15318-1.
- **John H. Glenn Research Center:** Process for Non-Contact Removal of Organic Coatings from the Surface of Paint-



The Apparatus for Providing Torque and for Storing Momentum Energy provides approximately twice the torque and 40 times better dynamic balance of comparable commercial wheels, at less than half the cost.

ings; Atmospheric Pressure Method and Apparatus for Removal of Organic Matter with Atomic and Ionic Oxygen. Inventors: Bruce A. Banks and Sharon K. Rutledge. NASA Case # LEW-1603-1 and LEW-20002-1.

- **Marshall Space Flight Center:** Selectively Lockable Knee Brace. Inventors: W. Neill Myers, Michael D. Shadoan, John C. Forbes, Kevin J. Baker, and Darron C. Rice. NASA Case # MFS-28991-1. Parachute Having Improved Vent Line Stacking. Inventor: John E. Hengel. NASA Case # MFS-28508-1.

ELECTROMAGNETIC DESIGN SOFTWARE

At the Forefront of Technology

The **OPERA** suite of software is in daily use in design offices and research laboratories around the world.

OPERA offers specialized modules for the design of products as diverse as:

• Proximity Sensors	• M.R.I Body Scanners
• Solenoids	• X-Ray Tubes
• Magnetic Recording Heads	• C.R.T.'s
• Electrical Machines	• Thin-Screen Displays
• N.D.T. Equipment	• Klystrons
• Loudspeakers	• Eddy Current Brakes

VF VECTOR FIELDS

1700 N. Farnsworth Ave., Aurora, IL 60505
 Tel: (630) 851-1734 Fax: (630) 851-2106
 E-Mail: info@vectorfields.com
 Web Site: www.vectorfields.com



Commercialization Opportunities

GPS "Compound Eye" Attitude Sensor

A proposed GPS sensor would give information on approximate attitude as well as on position. This sensor would be based on a concept that is related to that of an insect's compound eye. (See page 36.)

Acoustical-Sensor Assemblies for Use in Flows

Improved sensor assemblies measure acoustic signals in gases or liquids flowing in or around any of a variety of moving or stationary objects. These objects can be land vehicles, aircraft, submarines, and other structures exposed to winds or water streams. (See page 44.)

Biotelemetry Using Implanted Unit To Monitor Preterm Labor

This system monitors key physiological parameters of a fetus and its uterine environment. The main purpose is to detect preterm labor to enable timely treatment. (See page 45.)

Improved Suit for Protection During Abrasive Blasting

In contrast to earlier suits, this suit can be donned faster, requires no special undergarments, needs no respirator, eliminates the need for showering after abrasive blasting, and needs no laundering prior to reuse. (See page 62.)

Exoskeletal System for Neuromuscular Rehabilitation

A system of sensors and actuators for the lower extremities of human patients and astronauts is under development to serve diverse purposes in neuromuscular research and rehabilitation. The design is guided by the findings that show that patients with injured spinal cords can relearn how to walk. (See page 62.)

single-crystal yag reinforcement preforms for refractory composites


Preforms of YAG fibers can now be readily fabricated in net size and shape, with tailored orientation of the fibers. These preforms can serve as fiber reinforcements in certain composite materials that withstand temperatures as high as 1,700 °C. (See page 65.)

Inflatable Membrane Reflectors for Multiple-Purpose Applications

Experiments demonstrate the feasibility of inflatable reflectors with very low system aerial densities. Diverse applications include radio and optical communications, telescopes, and the concentration of sunlight for power generation. (See page 69.)

Ceramic Composites of ZrB_2 , HfB_2 , ZrC , HfC , and SiC

Improved ceramic composites have been invented in an effort to obtain better resistance to ablation at high temperature. Potential applications, other than thermal protection of spacecraft during the reentry into the Earth's atmosphere, include laboratory and industrial processes involving hot oxidizing gases. (See page 74.)



With our full spectrum of **Space-Grade Adhesives**, NuSil Technology can help launch your next aerospace project successfully. In fact, NuSil Technology offers nearly 50 standard products to help solve even your most challenging design issues. (That's 10 times more than anyone else.)

NuSil Technology represents the industry benchmark. Our controlled volatility silicone elastomers are available as electrically conductive, thermally conductive, optically clear, and fast curing just to name a few. Make sure your next project gets off the ground better, faster and more cost-effectively — contact NuSil Technology today.

NuSil Technology
1050 Cindy Lane
Carpinteria, CA 93013, U.S.A.
(805) 684-8780
Fax (805) 566-9905
www.nusil.com

NuSil Technology — Europe
Atlantic Parc - Les Pyramides No.5
P.A. de Malignon 64600 Anglet
FRANCE
+33 (0)5 59 31 41 04
Fax +33 (0)5 59 31 41 05

NuSil SILICONE
TECHNOLOGY
ISO 9001 Certified

PHOTONICS

Tech Briefs

Applications Challenge UV Fabrication

Test System for IR Imagers

New! SPIE Kicks Off a Column

**New Products—
see page 24a**

www.ptbmagazine.com



The Source for Next Generation Precision Technology



Modular Photonics Test Systems

Model 8800 and 8200 mainframe controllers house a variety of plug-and-play instrumentation modules which enable users to test and characterize components and systems used in DWDM, datacom, sensor and other applications.

High-Density LD Control

Control up to 16 laser diodes with our Model 8016 High-Density LD Controller. When used with the Model 708 eight-channel butterfly telecom LD Mount, pump lasers or DFB lasers can be controlled in a convenient, rack-mountable configuration.



DWDM Reference Standard

The Model 2010WR Wavelength Reference Standard provides a rock-solid set of densely spaced vapor cell absorption lines in the 1512 to 1563nm range, accessible via a single-mode output port. Applications include OSA calibration or locking of WDM sources.



The new kids on the bench.


Newport is now into fiber optic test and measurement instrumentation in a big way. Our presence in the fiber optic market is greater than ever. And with the introduction of this new line, so is your choice of test equipment.

Our instruments offer all the features and functions you need to perform DWDM-related tests with speed, precision and accuracy. So now you can concentrate on the quality of your testing without wondering about the quality of your equipment.

Newport. Your new, one-stop shop for fiber optic testing. For your free 1999/2000 catalog that features our entire product line, visit www.newport.com/wdm or call us today at 800-222-6440.

Tunable and Locked LD Sources


Our Model 2010 Tunable Laser Diode systems feature 20 laser modules which cover the 630 to 1780nm range. Model 2010S Stabilized Light Sources incorporate a vapor cell-based locking mechanism, creating a reliable light source with an extremely narrow linewidth of <100 kHz at a variety of preselected wavelengths.



USA: 800-222-6440, 949-863-3144 • Belgium: 016-402927 • Canada: 905-567-0390 • France: 01-60916868 • Germany: 06151-3621-0
Italy: 02-924-5518 • Netherlands: 030-6592111 • Switzerland: 01-744-5070 • Taiwan R.O.C.: 886-2-2769-9796 • UK: 01635-521757

Come Visit Us at CLEO, Booth 614
For More Information Circle No. 471

Introducing the *biggest*, yet *smallest* breakthrough in Galvanometers





Actual size

Our new Model 6200 closed-loop galvanometer provides the high level of performance you expect from Cambridge Technology—with one noticeable difference, the size.

Contact us today to discuss your scanning applications.



REFLECT INTO THE FUTURE



EG&G ORC
Electroformed Products
manufactures the
world's smallest,
largest and most
economical **METAL**
OPTICS including
parabolas, ellipses,
spherics, aspherics
and more.

Nickel, copper or alloys
combined with an
extensive variety of
spectral coatings are
produced in complex
shapes with close
tolerances and low-
cost tooling.

Ask about all new
EnviroCoat™, rapidly
becoming the most
sought after
replacement to rhodium,
with reflectivity greater
than 92%. Exceptional
for outdoor lighting
applications in harsh
humidity and coastal
environments.

EG&G's metal cold
mirror coatings perform
at temperatures up
to 400°C setting
industry's highest
standards for product
excellence.

EG&G ORC
Electroformed Products
also specializes in optics
technology for indus-
trial, military and

scientific applications. Advanced systems, including custom
optical components, subassemblies and precision lenses are
engineered to perform more accurately and efficiently.
Yes, precious metal plating is available in gold and rhodium.

 **EG&G® ORC ELECTROFORMED PRODUCTS**

1300 Optical Drive, Azusa, CA 91702

Phone: 626/815-3050 • Fax: 626/815-3051

Now Online: <http://www.orc-ef.com/n/>
Email: nasa@orc-ef.com

PHOTONICS Tech Briefs

Supplement to *NASA Tech Briefs*' May 1999 Issue
Published by Associated Business Publications

Features


- 4a 1998 Readers' Choice Products of the Year
- 8a Applications Challenge Optical Fabrication
- 14a A Turnkey Test System for IR Imagers

Photonics Tech Briefs

- 18a Novel Coating Technology Improves Ball Lenses
for Fiber Coupling
- 20a Two-Axis Reflective Device for Image Stabilization
and Beamsteering
- 22a Making Curved Diffractive Optics by
E-beam Lithography

Departments

- 6a The Power of Light—a New Column from SPIE,
the International Society of Optical Engineering
- 24a New Products



On the Cover: Meeting both
shape and surface-quality
specifications in polishing
of deep-UV optics requires a
delicate balancing act between
the various process parameters.
Cover image courtesy of Alpine
Research Optics.

Einstein
Fresnel
Galileo
Newton
Kobayashi
Maxwell
Snell
Michelson
Morley
Fraunhofer
Planck
Edison
Wollaston
Maiman


See Us at CLEO, Booths 110-112

Wait a Minute... Who's Kobayashi?


OptoSigma's Mitsuo Kobayashi is a dreamer. He didn't discover gravity or a new moon, but awoke early one morning with a revolutionary new concept in opto-mechanical positioning. After a few quick sketches, he rushed to work. It didn't take long for us to realize that his extended contact bearing stage was an astronomical leap forward. The rest is history.

Now available from OptoSigma in a wide range of models, Kobayashi's "Dream Stage" combines crossed-roller and ball-bearing concepts for eye-opening load capacities and laser-straight travel accuracies.

And because it uses only two-pieces with an integrated bearing design, conventional bearing ways are eliminated. So there are no preload screws to adjust, nothing to loosen up.



The great minds at OptoSigma are always searching for better ways to make your job easier. It often begins with a dream. And continues with the best selection, prices and service in the industry.




Call (949) 851-5881 today for your **Free** copy of the OptoSigma Catalog and a complete listing of our Stages, Optics & Mounts.

OptoSigma.
A Stage Ahead in Positioning.




2001 DEERE AVENUE • SANTA ANA • CALIFORNIA • 92705
TEL: (949) 851-5881 • FAX: (949) 851-5058
E-MAIL: optosigm@ix.netcom.com • WEB SITE: www.optosigma.com

Advanced PC Laser Beam Analyzers



- 8 Bit/10 Bit/ 12 Bit Digitizers
- 1024 X 1024 Pixel Resolution
- UV to Far IR Cameras
- Digital Camera 10 Bit and 12 Bit Input
- Ultracal™ Precise Camera Calibration
- LabView™ Virtual Instrument
- Versatile M² Accessory
- Legendary Customer Service and Product Reliability

Advanced Laser Beam Diagnostics can make the difference between borderline and peak laser performance; between good and excellent laser science; between marginal and reliable laser based products; between cumbersome and quick laser alignment. Whatever you do with lasers, you can do it better with Spiricon Advanced Beam Diagnostics.



**See the
Difference !
Measure
the Accuracy !**



**Contact
Us Now !**

SPIRICON[®]
Inc.
Laser Beam Diagnostics

Phone: (435) 753-3729

E-mail: sales@spiricon.com

Visit www.spiricon.com

for **FREE Software**


For More Information Circle No. 460

Photonics Tech Briefs

1998

Readers' Choice Product of the Year

Readers' votes for *Photonics Tech Briefs*' 1998 Product of the Year have been tallied, and the winners are:



Gold Winner

and

Product of the Year:

PixelVision (Beaverton, OR) **AdaptIII™** CCD Camera, designed for high-performance imaging at rates of up to 10,000 frames per second

Silver Winner

BEI Sensors & Systems Co. (Sylmar, CA) **LIE5** Optical Linear Encoder, with flip-chip-on-glass optics and built-in interpolation circuitry yielding resolutions as fine as 0.1 micrometer

Bronze Winner

Synrad (Mukilteo, WA) **Digital Laser Marking Kit**, based on the Synrad DH Series 125-W sealed RF-excited CO₂ laser marking head

Other finalists include Photon Inc. (Santa Clara, CA) Goniometric Radiometer for laser diode measurement; Berkeley Nucleonics Corp. (San Rafael, CA) Model 625A SmartARB Signal Generator; and Lasiris Inc. (St-Laurent, Quebec, Canada) LPM Series Long Phase Mask

Winners were chosen by reader vote on *Photonics Tech Briefs*' web site from among the six Products of the Month nominated by the editors during 1998. The awards will be presented at a ceremony at CLEO '99 in Baltimore late this month.

THE PHOTONIC HAMMER... 157 nm LASER




Break into the Real Deep UV with
the New LPF™ (F₂) Series

The "Photonic Hammer's" high quantum energy of nearly 8 eV carried by 157-nm photons packs quite a blow when interacting with atoms or molecules. The LPF at 157 nm offers maximum performance, reliability and efficiency.


- Shortest commercially available laser wavelength
- 5 W average output power
- Outstanding gas and tube lifetimes with NovaTube® technology
- Multiple models available up to 300 Hz

The LPF series is smashing existing performance barriers and proving to be an effective tool for R&D for 157 nm exposure experiments; micromachining of very tough materials such as fused silica/quartz, sapphire, PTFE (Teflon); surface analysis and photodissociation.

Call Lambda Physik's application lab at 1-800-EXCIMER to have your samples tested.



*Holes drilled in PTFE (Teflon)
using a contact mask*



*Fresnel lens in fused silica
produced by focal
point scribing*



LAMBDA PHYSIK

LASERTECHNIK

Driving the Pulse of UV Technology

U.S.A: 1-800-Excimer • (954) 486-1500

FAX: (954) 486-1501

e-mail: marketingusa@lambdaphysik.com • www.lambdaphysik.com

Germany: 49 (0) 551 69380


FAX: 49 (0) 551 68691

Japan: 81 (0) 45 9397848


FAX: 81 (0) 45 9397849

Choose from the industry's widest selection of Blackbody Temperature References...

...for "NIST traceable" calibration



- Choose from a broad line of stationary and portable units to meet your needs
- Designed for highest possible emissivity – up to 0.999
- Temperature range: -20° to 3000°C, NIST traceable
- Units available with large aperture and 0.01°C stability
- Also available: precision, fixed temperature freezing point of metal sources – and hand-held M190 calibration transfer standards



**CALL OR
E-MAIL TODAY!**



MIKRON®

16 Thornton Rd., Oakland, NJ 07436 U.S.A.
Tel. 800-631-0176 or +1-201-405-0900
Fax: +1-201-405-0090
E-mail: sales@mikroninst.com • www.mikroninst.com

For More Information Circle No. 461

SPIE

The Power of Light

With this issue Photonics Tech Briefs inaugurates a regular column to be contributed by SPIE — the International Society for Optical Engineering — that will enable the reader to better understand the mission and purpose of the association and the scope of its activities.

What is SPIE?

From its origins in 1955 as the Society of Photo-Optical Instrumentation Engineers, SPIE—the International Society for Optical Engineering—is the largest international professional society serving the practicing engineer and scientist in the fields of optics and photonics. The Society serves the global technical and business communities with more than 13,000 individual, 310 corporate, and 3,000 technical group members in more than 74 countries worldwide.

SPIE exists to serve its members and the worldwide technical and economic communities with which its members interact. The Society accomplishes this mission primarily by bringing information on the latest technological breakthroughs and their application to thousands of individuals and organizations.

Among the many services the Society offers are the sponsorship, planning, and execution of technical conferences, product exhibitions, and symposia; the publication and distribution of archival professional journals, conference proceedings, newsletters, and optics-related texts and monographs; and the development and delivery of professional continuing education programs, some live via satellite or other electronic means.

In addition, SPIE provides numerous services to its members, including on-line electronic databases, electronic bulletin-board and networking services, and employment assistance. To further serve the public good, the Society sponsors a number of awards, scholarships, and educational grants every year.

But most importantly, SPIE is its members—their voices, their ideas, their energy, and their professional endeavors. SPIE's membership comprises the global community of the most exciting technological frontier in the world today—applied optics and photonics.

For more information, contact SPIE: <http://www.spie.org>; E-mail: spie@spie.org; phone: (360) 676-3290; fax: (360) 647-1445.

FOR THE LATEST PHOTONICS TECHNOLOGIES

Visit www.ptbmagazine.com





The official web site for Photonics Tech Briefs magazine, from the publishers of NASA Tech Briefs

- Industry News
- NASA Technology Reports
- Reader Forum
- Hot Products
- Article Archive
- Resources

...and much more, free of charge and updated daily.


Interested in online marketing opportunities?
Contact Luke Schnirring, (212) 490-3999; luke@abptuf.org

Optical Modeling Software for Serious Engineering.



Output irradiance. 4 million rays,
120 minutes to trace.

*Arc source with an elliptical reflector
and an integrating light pipe.*



The industry standard for quantitative
analysis of optical systems.

S e r **3** i e s :

ASAP Gives You The Competitive Edge:

- Advanced non-sequential ray tracing for fast and accurate analysis of 3-D optical and mechanical systems
- 2-D radiant intensity, radiance and irradiance analysis anywhere in your system
- Source modeling from simple fans and point sources to complex emitting objects
- Optimized CAD translation for precise ray tracing and analysis
- Model laser and laser diode propagation through your system
- OPD, phase, amplitude, and polarization analysis anywhere in your system

For More Information Circle No. 477



**Breault Research
Organization**

Applications CHALLENGE

Optical Fabrication

Understanding failure mechanisms enables production of laser optics with higher damage resistance and longer operating lifetime.


Optics for the deep ultraviolet (below 250 nm) is a rapidly growing field. To date, this growth has been primarily driven by excimer-based applications such as microlithography, photorefractive keratectomy (PRK), laser-assisted *in-situ* keratomileusis (LASIK), laser marking, and various micromachining tasks. Recently, however, solid-state UV lasers have also become available; these promise to generate further market expansion by enabling a new range of applications.

Producing optics that can withstand prolonged exposure to intense UV radiation has presented a number of challenges to manufacturers. Over the past few years, intensive research and testing have yielded fabrication methods enabling a significant increase in the lifetime of excimer laser components. However, the different output characteristics of excimer and solid-state lasers result in somewhat different damage mechanisms. It is not yet clear if the techniques developed for excimer laser optics will be applicable in the solid-state regime, because of their different damage mechanisms. This article will review what has been learned about long-life excimer laser components and discuss the probable direction of future work on solid-state UV laser optics.

UV Damage

Excimer lasers are pulsed sources that produce light at the UV wavelengths of 351, 308, 248, 193 and 157 nm. The most powerful excimer lasers produce up to about 200 W of total power, with repetition rates in the 100-Hz to 1-kHz range, and pulse lengths of tens of nanoseconds. The output beam from an excimer laser is rectangular, with a smallest dimension of at least 10 mm. The intensity profile is fairly homogeneous, and free of hot spots (localized areas of high intensity). Because its wavefront quality is far from diffraction-limited, an entire excimer laser beam cannot be easily concentrated into a small spot. This fact keeps the peak fluences normally encountered in a subsequent optical train fairly low, generally in the 0.1- to 5-J/cm² range.

Because of these moderate fluences, the failure mechanism in optical components used with excimer lasers is not usually catastrophic surface damage. In fact, the actual mechanism of damage is often impossible to clearly identify. A gradual decline in performance (*e.g.*, reflectivity for a mirror) is observed as the total accumulated pulse count increases. The component typically ceases to perform adequately before catastrophic failure occurs. With no single damage event, it has become stan-



Meeting both shape and surface-quality specifications in polishing of deep-UV optics requires a delicate balancing act between the various process parameters.

dard in both the microlithography and PRK industries to define a 5% decrease in reflectivity as failure for an excimer laser mirror. At the present time, it is possible to produce excimer optics that can withstand well over one billion pulses before failing. *Continued*





Figure 1. Schematic of subsurface damage.




THE WORLD LEADER IN DIGITAL CAMERAS


INSPECTION



MEDICAL



ULTRA HIGH SPEED



SCIENTIFIC



FILM SCANNING



CUSTOM APPLICATIONS



SMD - THE DEFINING STANDARD IN PERFORMANCE, FLEXIBILITY AND VALUE:

- High Frame Rates
- High Resolution
- High Sensitivity
- Flexible Operating Modes
- New Pricing/Best Value
- Responsive Customer Support

SMD, THE ONLY DIGITAL CAMERA YOU SHOULD BUY.



- True 12 Bit Dynamic Range
- 15FPS to 1MFPS
- Up to 2K x 3K
- Monochrome/Color
- User Programmable
 - Binning
 - Gain
 - ROI
 - Shutter
 - Antiblooming

719 599-7700

5055 Corporate Plaza Dr. • Colorado Springs, CO 80919
www.smd.com • Info@smd.com

One distinct mechanism limiting laser damage resistance that has been identified is subsurface damage (SSD). Work performed at Lawrence Livermore National Laboratory has shown SSD to consist of fractures and scratches (see Figure 1) caused by the various grinding and polishing processes, which become partially or totally hidden during subsequent fabrication steps. It is theorized that a so-called polishing redeposition layer, which is a thin layer of the substrate material that actually flows while the piece is being worked, covers these defects and seals them below the final polished surface. SSD has the potential to reduce damage threshold by providing a place for light-absorbing contaminants to reside, by allowing atoms at or near the fractures to be more easily ionized, and by causing local intense modulations in the electromagnetic field.

Damage can also occur when residual polishing compound left on the part from fabrication absorbs UV laser light and heats up. But, it is very difficult to entirely remove all traces of polishing compound from a surface. This material adheres to the part's surface and can also work its way into microfractures and surface defects. In these latter




Figure 2. Nomarski DIC micrograph of damage induced by ArF_2 at 193 nm. Photo courtesy of Spica Technologies Inc.

instances, it becomes virtually impossible to remove through cleaning.

Optical Fabrication

Alpine Research Optics (ARO) has been producing high-damage-threshold UV laser optics for eight years. In that

time, we have found no single magic bullet that eliminates laser damage. Rather, incremental lifetime improvements have come by combining a number of individual techniques. For example, our approach to minimizing SSD is to use a sequence of successively finer grinding

**See us at
CLEO:
Booth 1119**

Introducing Our New Spring Line

Stiletto ✱

Diode-Pumped Laser Systems

- ✱ Power Levels to 35W
- ✱ Factory Sealed, Rugged & Compact
- ✱ Affordable OEM & Turnkey Systems
- ✱ 1-50kHz Q-Switched Operation
- ✱ Ideal for Marking, Drilling & Micromachining

High Performance Diode-Pumped Lasers
Cutting Edge Optonics, Inc.

20 Point West Blvd. • St. Charles, MO 63301
 314.916.4900 • 314.916.4994 fax
www.ceolaser.com • rods@ceolaser.com

LightTools.

Refine your prototype
in software, not hardware.

With *LightTools*, you can easily simulate and optimize your designs without leaving your desk. The accuracy of the *LightTools* model will save you many time consuming hardware iterations. The cost of a single failed hardware iteration in time, profits, and market share can be astronomical.

LightTools is easy to use,
intuitive and powerful. With
LightTools, you can easily

create detailed system models or import them from CAD programs. An interactive ray trace gives you immediate feedback. Define a light source, import measured lamp data, model real-world surfaces, or create lens arrays and quickly get quantitative output.

Still doesn't meet your specifications? Use *LightTools* surface receivers, and up to ten different irradiance and intensity output formats to determine where your system could be improved. These easy-to-use tools allow you to quickly refine your designs for optimum performance.

LightTools now has many new features including a macro language, polarization ray trace, multi-layer coatings simulation, faster ray tracing of imported objects and other refinements.

So, start building and refining your prototypes in software, not
 hardware. Call us now to see how easy it is to try *LightTools* and start saving time and money.



OPTICAL RESEARCH ASSOCIATES

Corporate Headquarters: 3280 East Foothill Boulevard, Pasadena, CA 91107 (626) 795-9101 FAX (626) 795-0184

East Coast Office: Westborough, MA Midwest Office: Beachwood, OH E-mail: service@opticalres.com WWW: <http://www.opticalres.com>

LightTools is a registered trademark of Optical Research Associates.

For More Information Circle No. 480

and polishing steps. Each step removes sufficient material to eliminate any damage caused by the previous step. Another important change has been to utilize polishing compounds other than the commonly used ceria (CeO_2). Ceria absorbs strongly at short wavelengths, and any residual ceria on a part can quickly lead to damage.

The only two materials that make suitable substrates for the fabrication of transmissive optical elements in the deep UV are fused silica, which transmits down to about 190 nm, and calcium fluoride (CaF_2), which extends down to around 130 nm. One of the most basic

lifetime-limiting factors with both of these substances is bulk material absorption. Absorption leads to heating, which can directly damage a component. Absorption is a much more significant problem for fused silica than CaF_2 , because the latter has both a significantly higher coefficient of thermal conductivity as well as a lower thermal coefficient of refractive index. The result is that CaF_2 heats up more slowly than fused silica, and experiences a smaller optical change when it does heat up.

Another bulk material problem that occurs with extended exposure to deep UV light, especially at wavelengths of 193

nm and below, is color-center formation. Color centers are lattice defects that exhibit increased absorption. For fused silica, prolonged exposure to intense deep-UV light can also produce a phenomenon known as densification. This is an actual physical shrinkage, accompanied by an increase in the index of refraction, in the region of exposure. While densification does not necessarily damage a component, it can significantly change its optical properties, thus rendering it useless in a system.

Unfortunately, the processing of calcium fluoride presents several unique challenges. CaF_2 is anisotropic, hygroscopic, and very prone to chipping and fracturing. During polishing, small particles can break loose from the substrate edge and be dragged over the surface, producing scratches. Eliminating these scratches requires lengthening the polishing time. Unfortunately, the longer the polishing time, the more difficult it is to hold a given flatness or surface figure.

Thus, fabricating CaF_2 components requires a very delicate balancing act between the various process parameters (polishing time, spindle speed, spindle pressure, etc.) in order to simultaneously meet both shape and surface quality specifications. In this connection, we have found that the use of pad polishing, as opposed to conventional pitch laps, can speed up the process, making it easier to achieve tight surface quality specifications. Probably the most important step we have taken, however, is simply to environmentally isolate the polishing area for CaF_2 , completely preventing any cross-contamination from our fused silica polishing procedures.

Considerable development has also been achieved on the optical coatings, especially for use at 193 nm. The main problem at this wavelength is the limited number of adequately transmissive materials. We have found that various fluoride materials produce thin films with the best combination of optical and mechanical characteristics. We have also determined that conventional E-beam evaporation is the most effective deposition method for these materials. Ion-assisted deposition, which can create high-density, high-damage-threshold coatings at visible and IR wavelengths, sometimes produces oxides that are absorptive in the UV.

UV Solid-State Lasers

Solid-state UV lasers typically function by frequency-multiplying the fundamental wavelength of a laser crystal, usually Nd:YAG or Nd:YVO₄, which both have a fundamental of 1.064 μm . This leads to multiplied output at the third (355 nm),

Spectral Ingenuity



See us at CLEO
Booths 235 & 728

Every wavelength measurement task has unique requirements. That's why CVI offers thousands of options for customizing our spectral products. From advanced CCD spectrometers to reliable computer-controlled monochromators and optical filters, CVI offers the industry's widest selection of spectral products. Whatever your application, we'll deliver the spectral products you need at a price that fits your budget. For more information, call today at (860) 928-5834.

SM240

Hand-held CCD Spectrometer

Spectral Range:	210 - 1700nm
Spectral Resolution:	2.5nm
Stray Light Rejection:	$< 10^{-3}$
CCD Sensitivity:	30 V/ $\mu\text{J}/\text{cm}^2$
Price:	\$2,049

CVI Spectral Products
www.cvilaser.com




Figure 3. Nomarski DIC micrograph of typical damage induced by a Q-switched infrared laser. Photo courtesy of Spica Technologies Inc.

fourth (266 nm), and fifth (213 nm) harmonics. Both CW and pulsed operation are possible, with pulse repetition rates usually in the 1-kHz to 10-kHz range. The total UV pulsed power available from solid-state lasers is much smaller than from excimer lasers, with a typical maximum of about 5 W. However, they can have pulse lengths of just a few nanoseconds, so that the peak power can be quite high. Furthermore, solid-state lasers tend to have inhomogeneous beams, exhibiting hot spots of very high fluence. Finally, solid-state lasers can produce excellent mode quality (TEM_{00}), meaning that the beams can be easily concentrated into small focused spots. As a result, solid-state laser optics can routinely expect to experience peak fluences in the 10 to 50 mJ/cm² range, a value much higher than for excimer laser optics. Also, the higher repetition rates of solid-state lasers mean that their optics can quickly accumulate a very large total pulse count. Figures 2 and 3 show differences in damage mechanisms.

These unique characteristics lead to different damage mechanisms from those experienced with excimer lasers. The high peak fluences can literally blast a small hole in an optical coating or surface. For a typical beam diameter of about 1 mm, damage sites of 100 to 200 μ m in size generally occur. Several of these may accumulate before the optic becomes unusable. Under certain circumstances, optics for solid-state lasers may also exhibit a gradual performance deterioration. This happens when dust or another contaminant settles on the optics surface. A high-fluence pulse may ablate this contaminant, leaving a very

small damaged area in its wake. This damaged area, which is usually in the 10- μ m size range, then scatters incident light, thus reducing the efficiency of the optic. A buildup of such damage sites over time will cause an appreciable reduction in component performance.

Extensive testing is now being performed by organizations such as Lawrence Livermore National Lab (as part of the National Ignition Facility program) to determine the effect of various process techniques on UV solid-state laser damage resistance. One promising approach appears to be the use of superpolishing methods, where the optic is typically fully immersed in the polishing slurry (a mixture of water and abrasives). As the polishing progresses, the slurry is gradually thinned until it becomes essentially just water. Superpolishing results in optics with very low surface roughness, which may raise the peak fluence levels that the part can withstand.

In recent years, tremendous progress has been made in extending the lifetime for excimer laser optical components. Now, the emergence of solid-state UV lasers, with much higher peak powers and repetition rates, has raised the performance bar once again. Through cooperation among sophisticated testing facilities, laser and component manufacturers, and systems integrators, ARO confidently expects to meet the need for long-lifetime optical components for these lasers.

For more information, please contact David Collier or Wayne Pantley at Alpine Research Optics, 3180 Sterling Circle, Boulder, CO 80301; (303) 444-3420, Fax (303) 444-1686, E-mail: AROcorp@AROcorp.com, www.optics.org/aroCorp/.

High power laser line generator



LASIRIS introduces the **Magnum series** high-power laser diode line generators. With up to 4 W of optical power, built-in thermoelectric cooling and patented uniform line-generating optics, the **Magnum series** is the ideal structured light source for high background-noise or power-hungry applications — capable of withstanding temperatures of -45°C to +55°C — clearly visible, *even in full sunlight*.

MADE TO OUTPERFORM.

- uniform intensity distribution
- visible red up to 750 mW @ 670 nm
- infrared up to 4 W
- full CDRH safety compliance
- ultra-thin line (user adjustable)
- modulation option

MADE TO OUTLAST.

- rugged industrial design
- vibration tested up to 10g
- ESD-protected to more than 8,000 V
- over-temperature protected

Call **1-800-814-9552**
— and get the power you need.

LASIRIS

For U.S. customers, FOB NY State

3549 Ashby St., St-Laurent, Quebec, Canada H4R 2K3

Tel: (514) 335-1005 Fax: (514) 335-4576

Internet: <http://www.lasiris.com>

E-mail: sales@lasiris.com

For More Information Circle No. 464

a Turnkey Test System for IR Imagers

With IRWindows™, the months-long task of creating an automated test is reduced to literally minutes.

Infrared imaging systems, the see-in-the-dark marvels that performed so well in Desert Storm, have historically been produced in small quantities, primarily for military customers. But new low-cost technologies and the economics of large-scale production have made these devices available to commercial customers, for tasks ranging from the mundane, such as troubleshooting steam pipes, to the exotic, such as night vision for cars. Along with these changes, a new challenge has emerged: the need for quick, repeatable, accurate, low-cost testing of the IR imager.

In the low-volume high-dollar military market, it was practical to have experienced and knowledgeable personnel, typically part of the engineering team, involved in the testing of the production systems. For small quantities, testing could be done manually: the operator would position the correct target in front of the blackbody, set the blackbody temperature, wait for the system to settle, take a data point by observation of unit under test (UUT) output,

and repeat the process for the next data point. This is a slow, tedious, error-prone process that relies on trained and experienced observers to accurately

interpret the imager output. For larger production quantities, automated testing needed to be developed. In addition to faster testing, an automated test system could help eliminate operator error both in the operation of the equipment and in the recording and reduction of test data.

Bob Nicklin, senior systems engineer for industrial automotive IR products at Raytheon TI Systems, in Dallas, TX, has implemented automated test systems for several IR imaging programs at Raytheon. "Repeatability, accuracy, quality, and operator independence are all as much a concern for us as speed," Nicklin said. "Manual testing imposes a boring, repetitive task on an operator, and we can't get the consistent overall product quality that we're committed to delivering. The time saved is an obvious tangible benefit, but these less tangible effects are important."

The obstacle to automated testing, however, was the time and expense of




Figure 1. Typical MTF curve produced by IRWindows™.




Figure 2. Turnkey IR target projector.

developing the test system. The process looked something like this:

- Specify and purchase a properly sized blackbody, target wheel, and collimator. Determine an appropriate set of target styles and sizes.
- Buy a computer, an IEEE-488 interface card to communicate with the test equipment, and suitable hardware interfaces to read the data output from the UUT.
- Get everything to work together: Install the IEEE-488 and data capture cards, along with their associated drivers, in the computer. Learn the interface message set for the blackbody and target wheel, and then write and debug the code to adapt the driver software to these instruments.
- Research the principles behind each functional test to be implemented (modulation transfer function, minimum resolvable temperature difference, etc.) and then create the algorithms for each test, using an appropriate programming language. Debug the algorithms. Exhaustively verify the test results from these algorithms against manual test data from many different UUTs.
- Create a user interface so that the program can be used by someone other than the programmer.
- Compose and format reports to present test results in a clear and understandable fashion.

Several man-years could be expended on the development of such test equipment. The result, too, would be a specialized test system, suitable only for one type of imaging system. Since development time was limited and the target audience small, the user interface was typically rudimentary—difficult to learn and use. To add a new test or modify an existing one, the software engineer would have to be tracked down and scheduled to rewrite some of his code. When a new imaging system needed testing, the process would start all over again.

Santa Barbara Infrared (SBIR) Inc., of Santa Barbara, CA, a leading manufacturer of infrared test equipment, saw this process repeated time and time again by its customers. One thing that stood out was that the bulk of this process was not UUT-specific: with sufficient planning, the framework for an automatic test system could be designed to be universal, with a relatively small fill-in-the-blanks menu set

to allow the test engineer to define the specifics for his particular UUT. This is the basis for their IRWindows™ test software (see Figure 1). Designed to work with SBIR's off-the-shelf target projectors (Figure 2), it provides a turnkey solution for IR imaging testing. With this product, the systems design and integration are already done: the hardware works together, the test algorithms are designed and debugged, and


standard reports are already formatted. The designers had the luxury of enough time to develop a really good user interface: for the engineer a versatile and easily configured test set, and for the production line an easy-to-understand and "idiot-proof" execution menu.

An engineer familiar with using other Windows applications can learn how to use IRWindows™ in a few hours.

Continued

HITACHI

An Infrared Eye For Detail



KP-F2 KP-M2R

Near-Infrared, 1/3"
& 1/2" CCD Cameras

For all your high-resolution image processing requirements, look to Hitachi's two new, near-infrared-sensitive video cameras. Both provide external triggering, field-on-demand and up to 1/10,000 second shuttering speed. The KP-F2 features a 1/3", progressive scan, 658 x 496 pixel CCD, with peak sensitivity of approximately 760 nanometers, and useful sensitivity extending beyond 1000 nanometers. The camera has a full pixel output of 30 frames per second, or an optional dual output of 60 frames per second. The KP-M2R offers a 1/2", 768 x 494 pixel CCD, operating at EIA standards, with a peak sensitivity of 640 nanometers, and useful sensitivity extending beyond 900 nanometers.

Request Your Free Demonstration

HITACHI

Hitachi Denshi America, Ltd.

www.hdal.com

• Atlanta 770-242-3636	• Dallas 817-488-4528	• New York 516-921-7200
• Chicago 630-250-8050	• Los Angeles 310-328-6116	• Canada 416-299-5900

A knowledge of programming is not needed. After learning IRWindows™, the months-long task of creating an automated test is reduced to literally minutes. It is actually easier to specify a test in IRWindows™ than to perform the test manually. Additionally, uncertainty about the validity of the test results is no longer an issue.

Nicklin chose to buy IRWindows™ to test Raytheon's new uncooled PalmIR

camera. "A capital equipment purchase is so much easier than putting together a test equipment development program," said Nicklin. "Sure, we understand the principles and could create our own test system, but we had more important problems to worry about. Our own hardware is where we need to spend our time." Success with the



Figure 3.
Driver's Vision
Enhancement
IR test system.

PalmIR program led Nicklin to implement the same IRWindows™ test system on several other Raytheon camera programs, most recently the Driver's Vision Enhancement (DVE) system (see Figure 3), a night vision camera to be offered as an option in next year's Cadillac DeVille. "We really need automation on DVE," says Nicklin. "We're committed to deliveries of as many as 60 units per day to Cadillac. But it makes sense even for a small program. With the time savings and the improved overall product quality, the software is essentially free."

Automated testing is the better way to test infrared imaging systems. It eliminates operator error, removes reliance on human perception, and generates repeatable and accurate test results. Automated testing is now practical even for the development lab, or the end user, or other applications that do not have the high volume of testing traditionally associated with automatic test systems.

For more information, contact Greg Smoyer at Santa Barbara Infrared Inc., 312 A N. Nopal St., Santa Barbara, CA 93103; (805) 965-3669; fax: (805) 963-3858; E-mail: gsmoyer@sbir.com.

Spectral Luminator®



Take a look at these advantages:

- Tunable sources from UV to 1 μ m
- Milliwatts of single wavelength power delivered out of optical fibers
- Milliwatts per cm^2 with uniform illuminator accessory
- Totally prealigned - nothing to adjust
- Integrated systems - all in one box
- Resolution down to 5 nm

Oriel's new Spectral Luminator® is an arc lamp source and grating monochromator in a single box! Its simple design (patent pending) allows us to provide you with a low cost tunable source for applications where 5 nm or wider bandwidth is sufficient and where a 10^{-3} , typical, stray light level will suit your illuminator or excitation needs. Build your own Spectral Luminator®, from the various options, or order a complete system.



For Your FREE
catalog go to
www.oriel.com
203 • 377 • 8282

Oriel
INSTRUMENTS

Making Light ■ Moving Light ■ Measuring Light

150 Long Beach Boulevard, P.O. Box 872, Stratford, CT 06615-0872 USA

TEL: 203•377•8282 FAX: 203•375•0851 E-MAIL: res_sales@oriel.com

www.oriel.com

BENELUX FRANCE GERMANY ITALY SWITZERLAND UNITED KINGDOM



NASA Spinoff, an annual publication, features stories on the successful transfer and application of NASA-generated technology to industry—assisting them in the development of new commercially available products and services.


If your organization has used NASA technology in the development of a commercial product and you wish your success story to be included in a future issue of NASA Spinoff, please contact us at:

disrael@sti.nasa.gov
or call Danielle Israel at:
(301) 621-0242

For a free copy of the latest Spinoff, visit www.nasatech.com



A World of Solutions.



Circle 472



Circle 473



Circle 474

It's the little things we do that bring the world closer to you. With innovative designs and the highest manufacturing standards backed by extensive engineering support, UDT Sensors offers:

Standard and Custom Photodetectors

X-Ray and UV Detectors

Fiber Optic Emitters and Detectors

LED's and Optical Switches


Opto-Assembly / Medical Products

Ceramic Substrates / Hybrids


SMT / Through-Hole PCB Assembly

Tool & Die / Injection Molding and Cable Over-Molding

Like what companies around the world do, call us at (310) 978-0516.



Circle 475



Circle 476

Commercial • Medical • Analytical/Diagnostic • Military/Aerospace



UDT SENSORS, INC.

An **OSI** Systems, Inc. Company

12525 Chadron Ave., Hawthorne, CA 90250
(310) 978-0516 • FAX (310) 644-1727

UDT Sensors &
OSI Electronics

**ISO-9002
Certified**

Novel Coating Technology Improves Ball Lenses for Fiber Coupling

Applying LPCVD technology to optical thin films has enabled production of coatings with superior optical and mechanical characteristics.

Deposition Sciences Incorporated, Santa Rosa, California

Small ball (full sphere) lenses in the 0.5-mm to 3.0-mm diameter range offer a number of practical advantages for fiber-to-fiber coupling and fiber collimation. Ball lenses are more physically compact and less expensive than commonly used gradient index (GRIN) lenses. Furthermore, the complete rotational symmetry of ball lenses makes them easier to mount, position, and align to a fiber than the cylindrically shaped GRIN lenses. Despite these advantages, the wide-scale use of ball lenses in the fiber telecommunications business has been limited, because of difficulties in depositing high-performance antireflection (AR) coatings on these lenses. Specifically, coatings produced using traditional evaporative technology are highly nonuniform; also, the tooling used leaves an uncoated stripe on the part. Together, these factors then require that the micro-ball lenses be precisely oriented during coupler or collimator assembly. In work performed at Deposition Sciences Incorporated (DSI), low-pressure chemical vapor deposition (LPCVD) technology has been adapted to uniformly coat the entire surface of ball lenses. The economics of this process make it viable for the volume production of components for the telecommunications market.

In a traditional evaporative coating chamber, one or more racks hold the substrates to be coated. The first step in the process is to pump all air out of the chamber to achieve a very high vacuum (10^{-6} Torr or better). A succession of coating materials is then evaporated, typically using either resistive heating or electron-beam bombardment. Because the chamber is in near vacuum, the mean free path of evaporated atoms or molecules is several meters. They stream out and recondense onto any surface in the chamber that has a direct line of sight to the source. This process makes the deposition rate highly dependent upon the distance from the source to the substrate surfaces, as well as their relative angular orientation. In order to maximize layer uniformity, the racks are rotated during coating, so that every part experiences the same "average" distance from the source. Complex internal masking is also often used to enhance deposition uniformity throughout the chamber.

There are two significant drawbacks to applying this evaporative technique to coat small ball lenses. First, highly curved ball lenses cannot be coated uniformly because of the significantly different orientation that the center and edge of each lens has with respect to the

coating source. Second, processing an entire ball requires coating one side first, and then turning the balls 180° and repeating the procedure to coat the second side. Furthermore, in order for the chamber tooling to securely hold a ball lens, it must cover slightly more than half the sphere, so the end result is an uncoated stripe that runs around the entire circumference of the finished part. Together, these factors require that the tiny ball lenses be precisely oriented during the assembly process to ensure that the right part of the coated surface is facing correctly.


To successfully address this coating problem, DSI has developed a form of LPCVD, called IsoDyn™, that avoids the limitations of evaporative technology. LPCVD is widely used in the semiconductor industry to produce thin films during integrated circuit production, but had not been widely used for optical thin films.

In the IsoDyn process, parts are placed in an evacuated chamber and heated to about 500°C . The chamber is then filled with a chemical vapor at relatively high (usually 0.1 to 5.0 Torr) pressure. The heat causes a chemical reaction in the precursor gas, resulting in deposition of the desired substance on all exposed surfaces of the substrate. This procedure can be repeated using various precursor gases to build up a multilayer coating.

The high gas pressure results in a short mean free path for the gas molecules, causing deposition to occur at the same rate on every surface within the chamber, regardless of its position or orientation. Consequently, this technique can produce extremely uniform coatings on highly curved or unusually shaped parts. Furthermore, there is no need to hold parts in traditional tooling and move them during the coating process. The lack of tooling that masks off some of the part during coating enables the production of uniform thin films covering virtually the entire surface of ball lenses.

Another benefit of the IsoDyn process is that the entire volume of the reactor can be filled with parts, and all surfaces of a part can be coated in a single run. This translates directly into higher throughput, and hence lower production cost.

Continued



Transmission of a dual-wavelength (1310 nm and 1550 nm) IsoDyn coating showing less than 0.01 dB loss per surface for a total loss of 0.02 dB.

The Source for
Next Generation
Precision Technology
www.newport.com/oam6



We've been creating great stuff in our own backyard for quite some time.


Newport is more than just a catalog supplier of optics and mechanics.

specifications with prototype-to-production capabilities.


We manufacture them.

And while that may seem like a new concept, the truth is we've been manufacturing precision optics and mechanics right in our own facility for thirty years.

For your next generation precision optics and mechanics visit Newport at:
www.newport.com/oam6



Efficient optical fabrication lets us be very cost competitive.




Newport's world class manufacturing facilities are equipped to process custom and high volume products.

In fact, Newport manufactures optics and mechanics in high volume, and custom builds to your

1969
1999
30th
Anniversary

OEM
spoken here



For details on our extensive range of optics and mechanics, request our new catalog today.

USA: 800-222-6440, 949-863-3144 • Belgium: 016-402927 • Canada: 905-567-0390 • France: 01-60916868 • Germany: 06151-3621-0
Italy: 02-924-5518 Netherlands: 030-6592111 • Switzerland: 01-744-5070 • Taiwan R.O.C.: 886-2-2769-9796 • UK: 01635-521757

Come Visit Us at CLEO, Booth 614

For More Information Circle No. 482

We don't consider it a polarization solution until we've nailed it.

Using man-made birefringent polymers and liquid crystals, Meadowlark Optics has become

a leader in precision optics by consistently providing innovative solutions that outperform their conventional counterparts.


Which is one reason why we've won eight major technology awards in the last seven years and earned a reputation with applications engineers for being "right on specs".

We've also earned quite a reputation among OEMs, because we have a world-class R&D department, meticulous quality control, and a willingness to "custom manufacture" for your applications.

If you need the perfect polarization solution, call Meadowlark Optics.

We'll nail one for you.

meadowlark optics
polarization solutions



Ask for
your free
catalog.

Call 303.833.4333 or visit us
online at www.meadowlark.com

DSI is now utilizing IsoDyn coating technology to produce a range of ball lenses for telecommunications, called IsoSpheres™, including BK 7, spinel, sapphire, LaSF N9, LaSF N18, LaSF N35, and stabilized cubic zirconia. The standard multilayer coating for these products has a specified insertion loss of less than 0.01 dB per surface at either 1310 nm or 1550 nm. A dual-wavelength antireflection coating for both these wavelengths (see graph), as well as other

single-wavelength and dual-wavelength combinations, is also available.

This work was performed by Dr. Donald Z. Rogers, Manager, Telecommunications Business Unit, **Deposition Sciences Incorporated**, Santa Rosa, CA. IsoSphere and IsoDyn are trademarks of the Deposition Sciences Corporation, an Advanced Lighting Technologies Company. For more information call (707) 573-6742, fax (707) 579-0731 or E-mail don.rogers@deposci.com.

Two-Axis Reflective Device for Image Stabilization and Beamsteering

A fast steering mirror is low in cost and has many applications.

Ball Aerospace and Technologies, Boulder, Colorado


Scientists, astronomers, optical researchers, and manufacturers frequently require two-axis reflective optical mechanisms to meet the requirements of robust beamsteering systems. Image tracking, scene scanning, line-of-sight pointing and/or beam stabilization designs often incorporate reduced-performance devices in complex arrangements to constrain costs.

Galvoscaners and piezo motor mechanisms have been employed in the past to accomplish two-axis beamsteering. These devices usually incorporate mirrors attached to separately located and controlled tip-and-tilt structures, which introduce several disadvantages in the realms of beam orthogonality, align-

ment stability, and heat dissipation, as well as problems with the generally limited area available in optics layouts. Combined tip-and-tilt mechanisms are generally available but tend to be very expensive. Custom systems complete with electronic stabilization filters and reaction masses may increase the price to several hundred thousand dollars.

Ball Aerospace and Technologies Corp. recently introduced a low-cost two-axis fast steering mirror (FSM). The operation of this design, based on technology developed over a 15-year period, depends on a synergistic combination of five components: mirror, suspension, actuators, sensors, and control electronics.

Continued



Ball Aerospace engineers use two Fast Steering Mirrors to validate a laser pointing and tracking device in the laboratory.

The mirror is available as an aluminum, beryllium, or glass substrate. Metal mirrors are light in weight to reduce inertia and to provide optimal dynamic performance via high-efficiency actuators and high-bandwidth position sensors. The reflective surface of an aluminum mirror is produced by diamond turning; an optical coating is applied to allow for cleaning and to provide selective spectral performance. Beryllium mirrors are nickel-plated and polished. Glass mirrors are user-replaceable, with a variety of flatness and coating options; they provide the least expensive option and greatest flexibility, but with some reduction in performance.

The mechanism's design differs from other technologies in that its unique suspension provides two-axis rotation about the center front surface of the mirror. The FSM can be substituted for a folding mirror to yield dynamic steering and/or angular adjustment in the optical train.

Lorentz-force (voice-coil) actuators are used in pairs to produce diametrically balanced "push-pull" forces on the mirrors' opposite edges.

Passive permanent-magnet armature sections are placed on the mirror; no heat is produced by the motor coils directly on the substrate, and no wiring is required on the moving mechanism. The minimal heat from the highly efficient actuator motor coils is dissipated into the FSM assembly's base.

Mirror position is derived from custom differential eddy-current sensors that achieve exceptional resolution and repeatability. Measurement signals are generated and demodulated in electronics housed in the assembly base. The position sensor output is returned to the control electronics to achieve local high-bandwidth servo control.

Modular electronics provide for two-axis commands from the user. The response to user commands emanates from closed-loop servo control, consisting of the mirror's angular position and feedback into an internal loop with compensation.

In the laboratory test setup shown in the photograph, Ball engineers use two FSMs to validate a laser pointing and tracking hardware design and control algorithm developed to detect and compensate for small deviations in a received optical signal. FSM commands are generated, which null the effects of mechanical jitter or vibration on the optical signal introduced by satellite platform disturbances. Bandwidths above 500 Hz with submicroradian accuracies have been achieved.

The fast steering mirrors are also in use in a Daylight Tracking System located at the Starfire Optical Range in


Albuquerque, NM. The mirrors are controlled by a digital system that receives error signals from a high-speed CCD camera. The track bandwidth is variable from 20 to 100 Hz, depending on the camera's coadd factor. The FSM is used to remove line-of-sight angular deviations caused by atmospheric gimbal-mount and seismic disturbances. Closed-loop RMS track errors of less than 1 microradian have been demonstrated.

A typical closed-loop bandwidth and disturbance rejection plot for Ball's Model 3B is shown in the figure. In addition to the Model 3B, three other models are available with varying perfor-

mance specifications. The most recently added, the Model 3G, features a user-removable and replaceable glass substrate, allowing for easy cleaning or replacement. The notion of disposable optics can easily be entertained with this configuration. Glass substrate mirrors also offer the flexibility of interchangeable elements and reduced cost.

Recent applications for FSMs have been found at the Naval Research Laboratory at Flagstaff, AZ; Boeing North American, Autonetics Electronic Systems Division, Anaheim, CA; Goddard Space Flight Center, Greenbelt, MD; Boeing Company Defense and Space Group,

Are Things Moving too Fast for You?



See Your World In Slow Motion.

Redlake Imaging offers the **NEW** MotionScope® e/Cam series of Ethernet based high-speed digital imaging systems for motion analysis.

- Up to 255 e/Cam systems per network.
- Capture controlled or intermittent events.
- 8,000 digital frames per second.
- Easy-to-use "Point & click" application software.

1-800-453-1223

Phone: 1-408-779-6464 FAX: 1-408-778-6256

E-Mail: sales@redlake.com

REDLAKE IMAGING

Call **1-800-453-1223**
or visit our **WEB** site



**Straightforward
answers for
your most
challenging
applications...**

Period


- Flexible Fused Silica Capillary
- Multimode Step Index Optical Fiber
- Rigid Fused Silica Rod and Capillary
- Specialty Assemblies

**Call Polymicro
Technologies
Specialists in
Fused Silica**



**Polymicro
Technologies, Inc.**

18019 North 25th Avenue
Phoenix, Arizona 85023-1200
Phone: 602-375-4100
Fax: 602-375-4110
URL: <http://www.polymicro.com>
E-Mail: sales@polymicro.com



A typical Closed-Loop Bandwidth and Disturbance Rejection Curve for the Ball Aerospace Model 3B fast steering mirror.

Redstone Arsenal, AL; SVS R&D Systems Inc., Albuquerque, NM; and Boeing North American, Rocketdyne Technical Services Division, Kihei Maui, HI.

This work was done by Albert Berta, product manager for commercial fast steering mir-

rors, and associates for Ball Aerospace and Technologies Corp. in Boulder, CO. For more information Berta may be reached at (303) 939-5566; fax: (303) 939-6862; E-mail: aberta@ball.com; www.ball.com/aerospace/fastmir.html.

Making Curved Diffractive Optics by E-Beam Lithography

Substrates need not be flat, and grating lines need not be straight.

NASA's Jet Propulsion Laboratory, Pasadena, California

Electron-beam (e-beam) lithography has shown promise as a technique for fabricating diffractive optical elements on nonflat substrates. Such optical elements could include convex or concave diffraction gratings with curved grating lines, for use in imaging spectrometers or other scientific instruments operating at wavelengths from ultraviolet through midinfrared.

Heretofore, diffractive optical elements made, variously, by diamond ruling and optical holography have been available commercially on flat substrates only. The lines in these gratings have been straight or else have had modest, regular curvatures at most. In contrast, diffractive optical elements made by electron-beam lithography can have arbitrary line shapes and/or arbitrary phase functions.


The present electron-beam-lithographic technique is an extension of another, recently developed electron-beam-lithographic technique for writing phase holograms into thin films of poly(methylmethacrylate) on flat substrates. By patterning and otherwise controlling the electron-beam exposure and monitoring the development/etching process until precise depths are achieved, one can adjust optical phase delays to a precision

of less than 1/50th of a wavelength, within 0.5- μ m-square regions. Devices produced by use of this technique on flat substrates include Fresnel lenses, arrays of Fresnel lenslets, gratings with both straight and curved grooves, holograms that yield gray-scale images, and patterns for free-space optical interconnections.

Application of the technique to a concave or convex substrate (see figure) involves the following sequence of steps:

1. Establish a grid of points on the substrate.
2. For each grid point, determine the electron-beam-apparatus focus, rotation, and deflection calibration values.
3. From the values obtained in step 2, determine the depth of focus over which patterning errors can be considered negligible, and use the depth-of-focus information to define depth zones.
4. Partition the exposure pattern into subpatterns — one subpattern for each depth zone.
5. Using the electron-beam apparatus, expose each depth zone according to its subpattern. Readjust the apparatus, as needed, when proceeding to the next subpattern.

The technique has been demonstrated by using it to form a small prototype



A Substrate To Be Patterned by electron-beam lithography is partitioned into zones of different focal depth, in essentially the same manner in which elevation contours are formed on a topographical map. An electron-beam subpattern exposure is then performed in each zone.


diffraction grating on a convex spherical substrate. In a test, the grating exhibited a first-order-diffraction efficiency of 88 percent. There was no evidence of degradation of the grating by curvature of the substrate. The prototype grating was small. Continuing development efforts are directed toward increasing the patterned area and decreasing the amount of light scattered (as distinguished from diffracted) by gratings of this type.

This work was done by Paul Maker, Richard Muller, and Daniel Wilson of Caltech for NASA's Jet Propulsion Laboratory. For

further information, access the Technical Support Package (TSP) **free on-line** at www.nasatech.com under the Manufacturing/Fabrication category.

In accordance with Public Law 96-517, the contractor has elected to retain title to this invention. Inquiries concerning rights for its commercial use should be addressed to: Technology Reporting Office, JPL, Mail Stop 122-116, 4800 Oak Grove Drive, Pasadena, CA 91109; (818) 354-2240.

Refer to NPO-20296, volume and number of this NASA Tech Briefs issue, and the page number.



CHILLERS/COOLERS CATALOG

NESLAB's newest product catalog features industrial chillers and liquid coolers. It includes features, specifications, and customizing options available, including refrigeration, controller, pump, fluid, heater, and electrical specs. NESLAB offers a range of cooling solutions for applications such as industrial lasers, EDM, plastics, plating, packaging, chilled rolls, and welding. There is a NESLAB solution to fit each constant-temperature application. NESLAB Instruments, PO Box 1178, Portsmouth, NH 03802-1178; (603) 430-2271; fax (603) 430-8411; E-mail: neslab@neslabinstruments.com; <http://neslabinc.com>.

NESLAB Instruments

For More Information Circle No. 490




1999 PRECISION OPTICS CATALOG

Edmund Scientific's new 1999 Catalog features hundreds of technical solutions from our extensive inventory of precision optics, machine vision products, and optical components. All off-the-shelf precision optics and optical instruments are available in prototype and OEM manufacturing production quantities. Edmund Scientific Co., Industrial Optics Division, 101 East Gloucester Pike, Dept. B991N954, Barrington, NJ 08007; (609) 573-6250; fax: (609) 573-6295; web site: www.edsci.com.

Edmund Scientific

For More Information Circle No. 491

Reliable Infrared Test Instrumentation For More Than Thirty Years . . .



EOI **Electro Optical Industries, Inc.**

859 Ward Drive

Santa Barbara, CA 93111-2960

805-964-6701 x280 Fax 805-967-8590

E-Mail EOI@sonatech.com

- Blackbodies
- Computerized Test Sets
- Differential Sources
- Optical Systems
- Extended Area Sources
- Digital Thermometers
- Freezing Point Standards
- Custom Solutions to Your Problems

Defining Infrared Standards

NEW PRODUCTS

PRODUCT OF THE MONTH




Blue External Cavity Diode Laser

TuiOptics GmbH, Munich, Germany, introduces what it calls the first direct blue external cavity diode laser (ECDL). TuiOptics, which is represented in the U.S. and Canada by Polytec PI, Auburn, MA, offers an ECDL with single-mode transverse and longitudinal output in the 400-nm region. Center wavelength can be chosen in the range between 395 and 405 nm, and the laser is coarsely tunable over more than 2 nm.

TuiOptics says that the mode-hopping-free tuning of a few GHz makes the laser usable in high-resolution spectroscopy and the research community.

For More Information Circle No. 760



Thirteen-Element IR LED Array

Optek Technology, Carrolton, TX, adds the OPR5013L thirteen-element infrared LED

array to its family of hybrid surface-mount components. The company says this component is mechanically and spectrally matched to its OPR5013 phototransistor array, making the pair an ideal choice for 13-bit absolute encoder applications. The polyimide package features an operating temperature range from -55 to +125 °C and wrap-around gold-plated mounting pads compatible with most reflow soldering processes. Optek says the array may be used in any design requiring an IR light source with a wide emission pattern.


For More Information Circle No. 761



5-W Bars & 4-W Fiber-Array Packages at 670 & 690 nm

Coherent Inc. Semiconductor Group (CSG), Santa Clara, CA, now offers high-power visible diode laser bars and fiber-coupled products based on a 1-cm-long 5-W diode laser bar mounted on its industry-standard conduction-cooled package at wavelengths of 670, 680, and 690 nm. CSG also offers a 4-W fiber-array package (FAP), the engine to its microprocessor-based system, the FAP-S. Output of the FAP is an 800- μ m-diameter fiber bundle with an NA of <0.16 FWHM. According to Coherent, these products are ideal for medical therapeutics, illumination applications, and pumping of solid-state media.

For More Information Circle No. 762



Measuring and Analysis Package

Capture, a measuring, recording, and analysis package from Pinpoint Laser Systems, Newburyport, MA, is

designed for use with precision measuring systems like Pinpoint's own Microgage. The company says the program loads quickly in Windows and is easy to use on the production floor, in the machine shop, the quality control lab, and the field. Measuring units can be scaled in inches, 1/1000 inch, meter, millimeter, micron, and custom units. An auto-zeroing function is available. A signal strength indicator provides a numeric and a graphical display of the signal strength.

For More Information Circle No. 763




Linear Variable Attenuator

Amphenol Fiber Optic Products, Lisle, IL, makes available a linear variable attenuator, a passive in-line

component that precisely reduces the intensity of optical signals with minimum back-reflection. The company says that, unlike competitive products, adjustments beyond upper and lower limits automatically reset without damage. The response function—attenuation dB versus adjustment turns—is linear over its range and operates within many environmental, vibration, and shock conditions. Wavelength ranges include 1285-1330 nm and 1525-1620 nm.

For More Information Circle No. 765



Laser Diodes for DWDM Applications

Mitsubishi Electronics America, Inc., Sunnyvale, CA, announces

electroabsorption modulator (EAM) distributed feedback (DFB) laser diodes for dense wavelength-division multiplexing (DWDM) applications. The FU-641SEA Series of integrated EAM DFB diodes meets the 10-Gb/sec transmission speed standard for metropolitan-area Internet and cable broadband signal distribution applications. The FU-632SEA Series devices meet the 2.5-Gb/sec speed requirement for DWDM, and can cover up to 700-km and 360-km distances for the FU-632SEA-3M and FU-632SEA-6M devices respectively.

For More Information Circle No. 766



Small-Diameter CO₂ Optics

Laser Research Optics, Providence, RI, offers a broad line of small-diameter carbon dioxide laser optics for low-power industrial and medical laser systems. The line includes lenses, turning mirrors, and

beam combiners with coatings available for specific phase and polarization requirements. Power-handling capacity is 25-200 W, and the optics are optimized for 10.6- μ m radiation where depth of field is important. Sizes range from 0.5 to 1.1 in., and include 15 and 25 mm; focal lengths range from 1-25 in. in half-inch increments. Total absorption value is <0.2 percent.

For More Information Circle No. 768



Portable Laser Marking System

Laser Marking Technologies, Lafayette, CO, introduces the revised LE-100D Series portable

laser marking system. This device, based on a diode-pumped solid-state laser, is an enclosed Class 1 Nd:Y₀₄ unit. According to the company, the system offers high beam quality, elimination of an external cooling system, high peak power, and plug-and-play operation. Laser Marking says the device can provide more than 10,000 hours of continuous operation.

For More Information Circle No. 769




DWDM System Analyzer

The new OSA-155 optical system analyzer from Wavetek Wandel & Goltermann, Research Triangle Park, NC, is a dense wavelength-division multiplexer (DWDM) testing

device offering measurements of wavelength, power, and optical signal-to-noise ratio for various carriers of multiwavelength signals in the range of 1450 to 1650 nm with 50-GHz/0.8-nm spacing. The company says that conventional spectrum analyzers can determine optical parameters, but do not provide external filter functions for further bit-error analysis. The OSA-155 is fitted with an external monitor output for this application.

For More Information Circle No. 767



Dense Wavelength-Division Multiplexers

AMP Inc., Harrisburg, PA, says its new line of dense wavelength-division multi-

plexers (DWDM), add/drop multiplexers, and band-pass WDMs provides a family of devices that allow individual wavelengths to be combined into or separated from a single optical fiber. The line is available in industry-standard 100- and 200-GHz channel spacings for all standard wavelengths within the ITU grid. Four-channel DWDMs are available now, and 8-channel devices will be available in this quarter; 16- and 32-channel DWDMs will follow. The products will come in either a low-profile cassette or a module compatible with AMP ATDU or Lucent LGX distribution hardware.

For More Information Circle No. 770

Melles Griot makes Optical Components & Coatings

Melles Griot optical components and coatings cover the entire spectrum from UV to IR whether for research, development, or production. We will exceed your expectations with consistent, reliable products, and delivery to your schedule.

Lenses

- Singlet, doublet & triplet
- Cylindrical
- Beam expanding & collimating

Mirrors






- Aluminum, silver & gold
- Broadband & laser line
- High energy & ultrafast
- Spherical, ellipsoidal & parabolic

Filters

- Colored glass
- Short / long pass
- Neutral density
- Interference

Optical Coatings

- Reflective & antireflective
- Metallic & dielectric
- Polarizing
- Single- & multilayer
- Narrow & broadband



Find out more:

Call 1-800-835-2626

or FAX or E-mail

Visit our
overstock sale
online!

PHOTONICS COMPONENTS

16542 Millikan Avenue • Irvine, California 92606

1-800-835-2626 • (949) 261-5600 • FAX (949) 261-7790

E-mail: mgsales@irvine.mellesgriot.com

Canada (613) 226-5880 Denmark 5761 5049 France (01) 3012-0680 Germany (06251) 84060 Japan (03) 3407-3614



Netherlands (0316) 333041 Singapore 392-5368 Sweden (08) 630-8950 United Kingdom (01223) 203300

MELLES GRIOT

www.mellesgriot.com


For More Information Circle No. 478

Coating Technology Innovation.



We built our reputation by building coatings and filters that surpass the highest performance standards. For example, our patented BlackEye™ Surveillance Filter is guaranteed to keep undercover teams under cover. Our exclusive Hot Mirrors can take the heat without ever changing color. And our BlackLite™ Fluorescence Filters, BARC-11 Broadband AR Coatings and Double-Sided UV/Heat Coatings impress even the toughest critic.

For more information or a quote, call (310) 381-3060 today. ZC&R. Our coatings are built on technology innovation.



- AR Coatings
- Band Pass Color Filters
- Beamsplitters
- Fluorescence Filters
- Heat & Color Coatings
- High Power Laser
- Laser Protection Filters
- Metal & Mirror Coatings
- Surveillance Filters
- Thin Film Polarizers

- Up to 24" Diameter
- Automated Coating
- Automated Cleaning
- High or Low Volume
- MIL-C-675, MIL-M-13508 & MIL-C-48497 Qualified
- Fast delivery



ZC&R

1401 Abalone Ave. / Torrance, CA 90501
310-381-3060 / 800-426-2864 / FAX: 310-782-9951
e-mail: info@zcrcoatings.com / www.zcrcoatings.com

Fast Fax Information Form

Fax: (413) 637-4343

Fax this form for quickest processing of your inquiry, or use the on-line LeadNet Service at www.nasatech.com.

Name: _____

Company: _____

Address: _____

City/St/Zip: _____

Phone: _____ Fax: _____

e-mail: _____

Circle the numbers below to receive more information about products and services featured in this issue.

401	402	403	404	405	406	407	408	409	410	411	412	413	414	415	416	417	418	419	420
421	422	423	424	425	426	427	428	429	430	431	432	433	434	435	436	437	438	439	440
441	442	443	444	445	446	447	448	449	450	451	452	453	454	455	456	457	458	459	460
461	462	463	464	465	466	467	468	469	470	471	472	473	474	475	476	477	478	479	480
481	482	483	484	485	486	487	488	489	490	491	492	493	494	495	496	497	498	499	500
501	502	503	504	505	506	507	508	509	510	511	512	513	514	515	516	517	518	519	520
521	522	523	524	525	526	527	528	529	530	531	532	533	534	535	536	537	538	539	540
541	542	543	544	545	546	547	548	549	550	551	552	553	554	555	556	557	558	559	560
561	562	563	564	565	566	567	568	569	570	571	572	573	574	575	576	577	578	579	580
581	582	583	584	585	586	587	588	589	590	591	592	593	594	595	596	597	598	599	600
601	602	603	604	605	606	607	608	609	610	611	612	613	614	615	616	617	618	619	620
621	622	623	624	625	626	627	628	629	630	631	632	633	634	635	636	637	638	639	640
641	642	643	644	645	646	647	648	649	650	651	652	653	654	655	656	657	658	659	660
661	662	663	664	665	666	667	668	669	670	671	672	673	674	675	676	677	678	679	680
681	682	683	684	685	686	687	688	689	690	691	692	693	694	695	696	697	698	699	700
701	702	703	704	705	706	707	708	709	710	711	712	713	714	715	716	717	718	719	720
721	722	723	724	725	726	727	728	729	730	731	732	733	734	735	736	737	738	739	740
741	742	743	744	745	746	747	748	749	750	751	752	753	754	755	756	757	758	759	760
761	762	763	764	765	766	767	768	769	770	771	772	773	774	775	776	777	778	779	780
781	782	783	784	785	786	787	788	789	790	791	792	793	794	795	796	797	798	799	800
801	802	803	804	805	806	807	808	809	810	811	812	813	814	815	816	817	818	819	820
821	822	823	824	825	826	827	828	829	830	831	832	833	834	835	836	837	838	839	840

WIN A FREE SUBSCRIPTION...

to a new e-mail newsletter from *NASA Tech Briefs*, featuring exclusive technology and business news as well as previews of upcoming issues. To qualify, simply complete the survey below and fax this page to (413) 637-4343. Your response will be kept completely confidential and will be used for statistical purposes only. This survey is optional and not required to order product information above.

1a. Are you involved in advising, recommending, specifying, or approving the purchase of computer-aided design (CAD) software for your company? ☐ Yes ☐ No

1b. If yes, do you plan to increase your purchase of CAD software in the next 12 months? ☐ Yes ☐ No

2. Which of the following types of CAD software do you now use? (check one) ☐ 2D ☐ 3D ☐ Both

3. Please list the names of CAD packages you (or your department) currently use.

4. Please list any additional CAD packages you are considering purchasing in the next 12 months.

☐ Check here to receive your free subscription to the new *NASA Tech Briefs* e-mail newsletter. (Please be sure to fill in your e-mail address at the top of this page.)



Application Briefs


Rugged Monitors Display Crystal-Growing Data

PanelMount™ flat panel monitors
Dolch Computer Systems
Fremont, CA
510-661-2220
www.dolch.com

Rugged active-matrix color flat-panel monitors from Dolch have passed a challenging test. A pair of PanelMount monitors displayed vital information to crew members in a landmark crystal-growing experiment on the Russian space station Mir, despite rough conditions and erratic power problems. The monitors are now qualified to continue the experiments on future International Space Station missions.

The monitors were used to help unlock the mysteries of proteins, providing clues to the characteristics of these fundamental building blocks of life. Medical researchers used their knowledge of the three-dimensional structure of proteins to design drugs aimed at combating diseases such as cancer, diabetes, and AIDS.

The Interferometer Protein Crystal Growth (IPCG) team selected standard commercial PanelMount monitors for their inherent ruggedness, compact size, and flexible mounting options. The monitors displayed bright, high-resolution graphics from the on-board phase-shift interferometer, according to NASA scientist Bill Witherow. "Our astronaut/scientists were able to track the growth process over a long period, and report



Marc Murbach, Principal Investigator; Garret Nakashiki; and Mike Jones (left to right) of NASA Ames Research Center assemble the crystal-growing experiment ejector systems.

their observations of important characteristics as they occurred. We could not have been more pleased with the performance of the monitors," said Witherow.

The Dolch technical support team worked with the IPCG designers on mounting and interfacing issues, and provided special display-screen impact protection against the escape of glass fragments in the event of accidental breakage. Dolch monitors are now certified by NASA as Commercial Off-the-Shelf (COTS) equipment for use in space programs.

For More Information Circle No. 756

Commercial Field Computer Forms Basis of NASA Data Acquisition System

Model 2100 Field Computer System
SoMat Corp.
Champaign, IL
217-328-5359
www.somat.com

NASA's Marshall Space Flight Center (MSFC), Huntsville, AL, chose a \$12,000 commercial field computer from SoMat Corp. as the basis for the Space Shuttle's Solid Rocket Booster (SRB) data acquisition system. The Enhanced Data Acquisition System (EDAS) flies on the SRBs to collect data during booster ascent, descent, and water splashdown. EDAS is used to characterize flight environments in support of planned upgrades to the SRB, and to determine if a redesign of the SRB is necessary to prevent future water-impact damage. The use of the commercial computer system enabled NASA and Boeing North American (NASA's contractor for the shuttle) to design the EDAS in one year, versus the three years required to develop the system from scratch.



Four EDAS units were installed in the forward skirt on the right-hand booster for shuttle mission STS-91 in June 1998.

The SRB is made up of four solid rocket segments plus forward and aft assemblies. During the first two minutes of shuttle ascent, the SRBs provide 80 percent of the shuttle's total thrust. They separate from the vehicle at an altitude of about 28 miles, and parachute into the ocean, aft-first, at 60 miles per hour. The SoMat computer, installed in an enclosure designed and built at MSFC, underwent rigorous tests to ensure its safe operation and durability.

The computer previously had flown on shuttle flights, controlling a camera in the SRB nose cone. The system is powered by three 9-volt batteries, enough power to sample and record data for three hours. The system also is a series of stackable modules, with one module per data channel. The configuration chosen by NASA consists of six modules that monitor strain gauges, accelerometers, and calorimeters.


Four EDAS units were installed in the forward skirt on the right-hand booster for Shuttle Mission STS-91 in June 1998. In its first flight, EDAS started recording six seconds after liftoff. The system record-

ed data for 10 minutes and then shut down. After the computer was recovered, the data was evaluated by a SoMat program called EASE. NASA plans to fly the EDAS for several flights to achieve a better understanding of the effect of rougher water on the splashdown of the SRBs.

For More Information Circle No. 757

Can you find the highly weatherable parts made of Luran® S?

BASF Plastics



(hint: they take to color beautifully)

Luran® S ASA resists fading and discoloring even in severe, outdoor use. It also resists heat, salts, fuels and detergents. Beyond that, it's tough, lightweight and provides enhanced color stability, maintaining its gloss and color throughout years of exposure.

Luran® S is made by BASF, the worldwide plastics supplier renowned for exceptional product quality and responsive service. That includes accelerated color matching time and prompt delivery.

If your application demands a performance plastic that stands up to the rigors of the environment and looks great doing it, look to Luran® S ASA.

For more information, samples or to have a sales representative call, please contact us at **1-800-BC-RESIN**. We also invite you to visit our website at www.basf.com/plastics. Smart Fax/Automated Data System 1-800-TOPFAX-1 (734-283-8373 outside the US.)

We don't make your products.

We help make them better.

BASF Plastics Technology

BASF Corporation
Plastic Materials



Special Coverage: Sensors

GPS “Compound Eye” Attitude Sensor


Attitude within several degrees would be determined relatively easily.

Goddard Space Flight Center, Greenbelt, Maryland

A proposed Global Positioning System (GPS) sensor would give information on approximate attitude as well as on position. Unlike other GPS-based attitude sensors, this attitude sensor would not depend on carrier-phase measurements and thus would not be subject to the difficulties and limitations involved in determining attitude from such measurements. Instead, this attitude sensor would be based on a concept that is related to that of an insect's compound eye and that has been implemented in optical attitude sensors of the star-tracker type.

The sensor would be equipped with multiple directional antennas mounted on a convex hemispherical surface. The number of antennas and their locations on the surface would be chosen to obtain a regular or slightly irregular polyhedral (e.g., half-dodecahedral or half-icosahedral) arrangement. Each antenna would thus be aimed to receive GPS signals from a field of view, called a “visualization cone,” approximately coincident with the solid angle intercepted by the corresponding face of the polyhedron from the center of the hemisphere (see figure).

By virtue of the conventional GPS function, the positions of the GPS satellites and of the sensor would be known accurately and thus the direction from the sensor to each GPS satellite would be known accurately. Therefore, the reception of a signal from a given GPS satellite or satellites through a given antenna would provide partial attitude information: It would signify that the sensor is oriented so that the visualization cone of the given antenna contains the known direction(s) to the satellite(s). In a similar manner, the simultaneous reception of GPS signals



This GPS Sensor Would Include Six Antennas aimed outward from faces of a half regular dodecahedron. Their fields of view would be partially overlapping “visualization cones.” The purpose of this arrangement is to deduce the orientation of the sensor from the known location of each GPS satellite “visible” to each antenna.

ADVERTISEMENT



MODEL 750 ISOTRON® Accelerometer

This general purpose accelerometer has integral electronics and operates over a wide dynamic range from 0.5 mg to 50 g.

It provides broadband frequency response from 1 Hz to 6 kHz and has a sensitivity of 100 mV/g. It includes a built-in low-pass filter and signal ground isolation. The unit features a top connector and is hermetically sealed.

For More Information Circle No. 543



MODEL 50/50M1 ISOTRON®

Accelerometers

Developed to fit the widest range of applications, these lightweight, low-cost accelerometers are hermetically sealed

and weigh only 3.8 grams. They provide milli-g resolution (0.001 g's) and can be powered by a +12 Vdc constant current supply. Sensitivity is 50 mV/g over a full-scale range of ± 40 g's. Frequency response is 1 Hz to 5 kHz. Model 50M1 has an integral magnet for mounting convenience.

For More Information Circle No. 544




MODEL 256/256HX ISOTRON®

Accelerometers

Designed for modal and other vibration measurements on small structures, these lightweight accelerometers are

hermetically sealed and weigh as little as 3.2 grams. They provide milli-g resolution (0.004 or 0.001 g's), wide dynamic range (± 500 or ± 50 g's), broadband response (1 Hz to 10 kHz) and signal ground isolation. Sensitivity is 10 or 100 mV/g. Both adhesive and stud mounting are available.

For More Information Circle No. 545



Endevco's Quality Measurement Products: Same Rock-Solid Performance and Dependability at New Rock-Bottom Prices.

For over 50 years you've come to know and depend on Endevco quality for precision shock and vibration measurement. Now, thanks to recent major process improvements, our newly introduced product lines provide the same high performance at significantly lower prices.

Whatever your application, you can select accelerometers, signal conditioners, and accessories from our very broad

product line. With Endevco, you can now engineer a total measurement solution at optimum price/performance. And in addition to dependable, rugged Endevco products, you get our strong application support team to help you with technical issues.

With time-proven rock-solid quality, Endevco now brings you rock-bottom prices. Contact us by fax, phone, email, or visit our website today.

The Measurement Solutions Company.



30700 Rancho Viejo Road, San Juan Capistrano, CA 92675-1748

Tel: (877)-ENDEVCO (Toll Free) Fax: (949) 661-7231

Web Site: <http://www.endevco.com/rock-solid.html> Email: applications@endevco.com

For More Information Circle No. 548



MODEL 4475 ISOTRON®

Power Supply

This portable 10-channel power supply, designed to work with ISOTRON transducers, features spring terminals for

quick and reliable input connections, and uses an external DC power source. The unit supplies 4.7 mA to the ISOTRON and has a bandwidth of 0.2 Hz to 50 kHz. Outputs are provided through both BNC and DB-15 connectors. LED indicators display operating status. The unit weighs 2.5 lbs and is ideal for on-vehicle testing.

For More Information Circle No. 546



MODEL 133 PE/ISOTRON® Signal Conditioner

This three-channel signal conditioner can be operated manually or by computer, using the standard RS-232

port and optional application software. It has a built-in 4-pole Butterworth high-pass filter with optional corner frequencies. Bandwidth is 100 kHz with gain range programmable from 0 to 1000. Meets filter requirements of J211 and ISO 6487. The 5.57" x 2.52" x 2" unit weighs 4 lbs.

For More Information Circle No. 547

Please visit us at Sensors Expo Baltimore
Booth 1034


through the other antennas would make it possible to draw additional conclusions as to how the sensor must be oriented in order to make possible the observed combination of antennas and signals.

The precision of the attitude estimate obtained in this way depends on a number of factors, including notably the number of antennas and the way in which the signal-reception data are processed. Simplistic processing of raw data yields attitude estimates with errors of the order of visualization-cone angles (tens of degrees in the case of a half-do-

decahedron). Errors can be reduced by use of optimization techniques in which, for example, greater weights are assigned to signals from directions that lie in overlaps between cones. Errors could be reduced further by increasing the number of antennas to obtain smaller cone angles and overlaps; for example, a first-order calculation has shown that with 16 antennas distributed over the hemispherical surface (on a "buckey-ball"), errors would be reduced to $<3^\circ$. Refinements in processing should make it possible to reduce the errors to the subdegree range.

This work was done by David A. Quinn of Goddard Space Flight Center and John C. Crassidis of Texas A & M University. For further information, access the Technical Support Package (TSP) free online at www.nasatech.com under the Electronic Components and Systems category.

This invention is owned by NASA, and a patent application has been filed. Inquiries concerning nonexclusive or exclusive license for its commercial development should be addressed to the Patent Counsel, Goddard Space Flight Center; (301) 286-7351. Refer to GSC-13966.



Pressure controls made **your way!**

For over 35 years, Tescom has provided a diverse range of quality pressure control solutions that meet or exceed customer expectations. Whether it's one of our 60+ standard models, a simple modification or a one-of-a-kind custom control, we'll build a regulator, valve or system that meets your unique requirements.

Control styles: pressure reducing and back pressure, hydraulic or pneumatic, electronic, miniature, cartridge, tracking, vaporizing, vacuum or changeover.

Choices: loading and sensing styles, venting options, materials of construction, seals, porting configurations and more. Pressure ranges: vacuum to 20,000 PSIG. Flow: $C_v = 0.00005$ to 8.0.

Our application specialists will find or create a control solution for you. Give them a call.

ISO 9001 Quality System Certified

MITI/KHK Product Certification

12616 Industrial Blvd., Elk River, MN 55330 800 447-9643 www.tescom.com

TESCOM
CORPORATION
INDUSTRIAL CONTROLS DIVISION

Compact Magnetic-Sensor Units for Detecting Mines

Inexpensive, mass-produced units would be deployed in large numbers.

NASA's Jet Propulsion Laboratory, Pasadena, California

Compact, low-power-consumption magnetic-sensor units called "integrated sensor system" (ISS) units are being developed for detecting buried mines and arsenals without exposing human searchers to unnecessary danger. The fully developed ISS units would be mass produced at relatively low cost, so that they could be deployed in large numbers and regarded as disposable. Many ISS units would be dispersed onto a mine field from a low-flying aircraft. After a specified time, the ISS units would transmit magnetic-field- and attitude-measurement data to the same or different aircraft for processing. Analysis of the data would reveal local deformations of the Earth's magnetic field, indicative of the magnetic dipole moments of mines and other objects.

Each ISS unit (see figure) would contain a miniature three-axis flux-gate magnetometer, a Sun-angle sensor, a data subsystem, a battery power subsystem, a transmitter, and a patch antenna. The ISS unit would be packaged with nonmagnetic components. The entire unit would be designed with great care to ensure that the magnetometer readings would not be corrupted despite the proximity of the magnetometer to the electronic circuitry and packaging.

The three-axis magnetometer chosen for the ISS is one that was recently developed for use in an airborne unit. It includes low-noise ferromagnetic cores with windings for the three axes, plus

The World Standard in Real-Time Data Recorders.

In the world of *real time data recording*, there is no room for compromise because the incoming data is priceless. Decisions need to be made *instantaneously* as the recording takes place – in real time. Engineers doing aerospace telemetry, automotive testing, electrical power transmission or telecommunications analysis, have made the Astro-Med MT95K2 the world standard because of its recording power and reliability. For detailed information and engineering specifications call, fax, or E-mail Astro-Med today.

- No Delay... see full traces on monitor while recording
- On-Board Data Analysis as well as by host program
- Patented Twin Printhead Design... 300 dpi laser printer resolution for clear, crisp traces
- On-Board Signal Conditioning for voltage, temperature, pressure and strain recording
- Front Panel Floppy Drive for personal chart and system setups
- Data Capture...store up to 32 megabytes in RAM; 1 gigabyte to internal hard drive; stream to external 2 gigabyte drive via SCSI; archive to DAT or floppy drive
- 8 to 32 Waveform Channels... plus 32 events; DC to 20 kHz; chart speeds to 500 mm/sec
- Record digital data via ethernet, SCSI, GPIB, or parallel interfaces




Astro-Med, Inc.

Astro-Med Industrial Park, West Warwick, Rhode Island 02893 • Telephone: (401) 828-4000
Toll Free: 800-343-4039 • Fax: (401) 822-2430
E-mail: astro-med@astro-med.com
Web Site: <http://www.astro-med.com>


Astro-Med is System Certified to ISO 9001

Sales and Service Centers throughout the U.S., Canada and Europe. Dealers located throughout the world.





BLOCK DIAGRAM



DRAWING BASED ON PROPOSED DESIGN

This ISS Unit is one of many that would be dispersed over the ground to detect magnetic-field anomalies caused by mines.

drive and readout circuits made of commercially available components.

The Sun-angle sensor, designed previously for use on small satellites, is a wide-angle optoelectronic sensor module in a pyramidal housing. The angle of the Sun, relative to the unit, is deduced from differences among the currents generated by four solar photovoltaic cells.

The data subsystem would include a 22-bit analog-to-digital (A/D) converter. The flow of data and the general operation of the rest of the ISS unit would be controlled by a field-programmable gate array (FPGA). A 4-Mb static random-access memory (SRAM) would store data (typically about 7 minutes' worth) until transmission. Data would not be acquired during transmission because op-

eration of the transmitter could corrupt the magnetometer readings.

The battery power subsystem would include six high-capacity Li/SOCl₂ cells, plus power-regulation circuitry that is part of the data subsystem. Once activated, the ISS unit would continue to operate until the battery runs down (nearly two hours).

The transmitter would operate at a center frequency of 2,250 MHz. It would contain a frequency synthesizer in the form of a voltage-controlled oscillator locked in phase with a temperature-controlled crystal oscillator (TCXO). The output of the frequency synthesizer would be phase-modulated with the data signal, then amplified, then fed to the patch antenna.


Future refinements of the ISS design would effect increases in magnetic sensitivity, making it possible to detect mines

with smaller magnetic moments. Of course, the magnetic-field-based ISS units would not be capable of detecting mines constructed entirely of nonferrous materials. On the other hand, they can be expected to detect a variety of mines of a low-technology type that are built at clandestine factories and have large magnetic moments. As newer mines are made with ever weaker magnetic moments, the basic ISS design could be modified to incorporate electronic chemical sensors to detect explosive vapors.

This work was done by Hamid Javadi of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Electronic Components and Systems category. NPO-20471



a. Fruitcake



b. Root canal



c. Opera



d. Parts lubricated with Krytox®

Why do components with DuPont Krytox® last practically forever?

For starters, Krytox® lubricants are based on exclusive space-age fluoropolymer technology. Available in oil, grease and dry film, Krytox® provides long-lasting lubrication over the broadest range of temperatures (-70°F to 650°F) in even the most extreme conditions. Krytox® is also compatible with metals, elastomers, engineering plastics — and all chemicals including oxygen — which means it's nonflammable, chemically inert, and insoluble in solvents and water. It's clean, white, and it stays

put, with virtually no change in physical properties over time.

And if you're looking for a clean solution to the assembly and operation of moving parts, try easy-to-apply Krytox® dry film.

Whether your application is automotive, aerospace, small motors, paper making or chemical processing, you just can't get a longer-lasting lubricant than Krytox®. For more information, call 1-800-424-7502. Krytox®. Lubrication beyond your highest expectations.



Krytox®
performance lubricants

<http://www.lubricants.dupont.com>



Resonant Microstrip Patch Antenna as Ice-Thickness Gauge

Conformally mounted sensors would measure prelaunch ice buildup on space-shuttle external tanks.

Lyndon B. Johnson Space Center, Houston, Texas

Researchers at Johnson Space Center (JSC) recently demonstrated that the resonant microstrip patch antenna (RMPA), which has been proven in commercial applications, can be applied with equal success to measuring prelaunch ice buildup on the insulated low-temperature external tanks of the space shuttle orbiter. To do this, they explored the following questions: Why is prelaunch ice buildup on the shuttle external tanks measured, how is the ice measured now, how does the RMPA sensor work, and will the performance of this sensor satisfy the Space Shuttle Program launch-commit criteria.

Accurately measuring prelaunch ice buildup on the orbiter external tanks is a programmatic concern. After the tanks are filled, launch countdown continues unless the "accreage ice" builds to more than 1/16 in. (1.6 mm), at which point the applicable launch-commit criterion requires that the launch be delayed. The delay is necessary because, during initial ascent through the atmosphere, an ice layer thicker than 1/16 in. (1.6 mm) could

become fragmented, causing damage to orbiter heat-shield tiles and windows. Therefore, the ability to measure the thickness of ice is vital to vehicle performance and safety. At present, ice measurements are performed on the launch pad, by teams of technicians who manually scratch away the ice layer to determine its thickness. However, the large size of external tanks limits accessibility and the number of measurements that can be taken in this way. A sensor that could automatically perform these measurements would increase accessibility and reduce risk.

JSC researchers needed a sensor that could be applied to the Shuttle's external tanks; the RMPA sensor and associated microprocessor-controlled electronic circuitry satisfied their need. But there was a drawback: Inasmuch as active circuits are essential parts of an RMPA sensor, operation of the circuits could, potentially, cause localized heating that could cause inaccurate measurements. Therefore, a multiple-element RMPA that could be integrated into the tank insulation was designed.

An RMPA sensor is driven by a microprocessor-controlled microwave signal generator. It is characterized by, among other things, an electric field (E field) distributed throughout a dielectric material between a circular copper patch and an underlying copper back plane (ground plane) through the dielectric material. The RMPA sensor can be modeled as a high-Q cavity (where "Q" denotes the resonance quality factor) that capitalizes on its resonant sensitivity; this means that it offers a distinct advantage over a nonresonant electromagnetic (EM)-wave sensor.

The high-Q cavity is bounded by the circular copper patch and the ground plane. The E field within the cavity is both excited and sensed by use of a probe perpendicular to the ground plane at the feed point. An example of the E field within the cavity and the associated fringing E fields is illustrated in the figure. The magnetic (H) field, which is not shown in the figure, is orthogonal to the E field. The magnetic field in the vicinity of the edge of the cir-

Watt's The Big Deal?

Introducing the World's First Miniature NIST-traceable Lamp for Optical Fibers



The **LS-I-CAL** NIST-traceable Fiber Optic Light Source is your (calibrated!) light at the end of the tunnel -- or fiber, to be correct. This low-cost, calibrated VIS-Shortwave NIR light source provides the user with absolute spectral intensity values vs. wavelengths -- at the fiber entrance port. Imagine ... a calibrated source for *fibers*!

That's just one of the benefits the **LS-I-CAL** offers. Consider:


- **Low cost.** At \$549, the **LS-I-CAL** is thousands of dollars less than conventional radiometric standards.
- **Small size.** "Portable" best describes the **LS-I-CAL**. It will operate from any well-regulated 12VDC power source, and it's small enough to fit into a shirt pocket.
- **NIST-traceable calibration.** Included is calibration data for the lamp's spectral output from 300-1050 nm.
- **SMA 905 connector.** The lamp couples to optical fibers, accessories and our low-cost IRRAD2000 Spectroradiometers.

See the Light ... the **LS-I-CAL** Fiber Optic Light Source

Call Now (727) 733-2447



Fax: (727) 733-3962
E-mail: Info@OceanOptics.com
Web: www.OceanOptics.com



A Resonant Microstrip Patch Antenna is configured for use in sensing nearby material layers. The electric-field lines depicted here approximate those of the transverse magnetic 1,1 (TM₁₁) mode.

cular patch is associated with currents that flow along the patch and ground-plane surfaces, and can be regarded as a diffuse magnetic boundary of the resonant cavity. The fringing E and H fields play an important role in the operation of the RMPA because they constitute the means for coupling between the internal cavity fields and the external fields.

The high-Q RMPA transmits primary electromagnetic fields and senses reflected and scattered electromagnetic fields through alteration of its resonant condition. The RMPA emits a continuous-wave signal that is partly reflected and partly transmitted at interfaces between layers of materials in and near the antenna, including layers of nearby materials (e.g., coal, rock, and/or ice) that one seeks to characterize.

The return signal, which is coupled through the fringing fields, alters the E field at the feed point. The microprocessor-controlled electronic circuitry of the RMPA changes the signal frequency until the measured impedance or admittance is real. The resonant resistance or conductance measured at the feed point can change by a significant amount when the layers of materials change.

The RMPA sensor has been proven useful in several commercial applications; for example, to measure the thickness of ice on a roadway, to measure the thickness of uncut coal in a mine, and as an ore-pass monitor. It should be possible to put the RMPA to good use in measuring ice buildup on the orbiter low-temperature external tanks. The replacement of measurements by technicians with measurements by RMPA sensors would make it possible to measure ice buildup on a greater portion of the tank surface in a timely manner; this would enable launch personnel to satisfy the applicable launch-commit criterion and to reduce the potential danger to the shuttle and its crew.

This work was done by Larry G. Stolarczyk of Raton Technology Research, Inc., for Johnson Space Center. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Electronic Components and Systems category.

In accordance with Public Law 96-517, the contractor has elected to retain title to this invention. Inquiries concerning rights for its commercial use should be addressed to

Larry Stolarczyk
Raton Technology Research
848 Clayton Highway
Raton, NM 87740

Refer to MSC-22766, volume and number of this NASA Tech Briefs issue, and the page number.

SL-GMS

The Most Complete Dynamic Graphics for Process Control Applications

**NEW
Version
6.0**

- Easy Drawing Tool Customization
- High Performance Map Navigation
- Java Code Generation for Dynamic Graphics
- ActiveX, Java Bean Components

When building a complex, mission-critical application, you wouldn't think of building your own database for handling data.

With SL-GMS, there is no need to develop your own solution to graphical display and interaction problems. Let SL-GMS manage all the graphics for you. You concentrate on the application.



SL-GMS is seen embedded in a high-performance operator station displaying complex graphical screens.

Configurable Drawing Tool

Design complex, reusable, hierarchical symbols defining both graphics and dynamic behavior, using a powerful, state-of-the-art drawing tool, SL-GMSDraw.

For OEM or System Integrator use, the drawing tool is provided in library or DLL form and can be modified, enhanced, and embedded in a proprietary system to provide your own look-and-feel and datasource linkage.

High-Performance Run-Time Engine

The Run-Time Engine, provided as a library or DLL, contains all the logic necessary to display complex dynamic graphics and to define user interaction. The graphics can be constructed using the drawing tools or created on the fly from an application database. MFC-compatible C++ Classes supplied for easy integration into Windows applications. Graphics displayed using Win32. On UNIX, VMS, and QNX® it is based on X Window/Motif.

High-Performance Mapping Libraries and Tools

Fast display and navigation of multi-layered maps obtained from a variety of standard map formats or DXF files. Generate dynamic graphics symbols from information in your data-base and overlay them on detailed map backgrounds.

A Unified Solution for Component or Network Applications

SL-GMS ActiveX and Java Bean components are provided. These can be used as is or customized for specific behavior or datasources. They are easily incorporated into common frameworks, such as Visual Basic, Visual Cafe, and HTML pages.

Pure Java Code Generation

An SL-GMS dynamic graphics display can be converted to source code for a Pure Java applet, and run in a browser, such as Netscape 3.0 / 4.0 or Internet Explorer 3.0 / 4.0. The datasource for the applet can be customized for your application.

Performance and Portability

SL-GMS is highly compact and portable. It runs on Windows NT and Windows 95, along with most varieties of UNIX, including SUN, HP, IBM, and others. The run-time engine is available on VMS and QNX®.

Call: 415/927-1724
<http://www.sl.com>

SL

Sherrill-Lubinski
SL Corporation
Suite 110 Hunt Plaza
240 Tamal Vista Boulevard
Corte Madera, California 94925

©1999 Sherrill-Lubinski Corporation.
All trademarks mentioned are property of their respective companies.

**WITH THOUSANDS
OF COST EFFECTIVE
EMI SHIELDING
SOLUTIONS IN OUR
CATALOG...**



**TECKNIT
NOW INTRODUCES
THE BEST PRICE
PERFORMANCE
SOLUTION
OF THEM ALL...**

**NEW
NC-CONSIL**



NC-Consil is an advanced elastomer gasket filled with nickel coated graphite particles. It provides high electrical conductivity, broad band shielding and environmental sealing for a wide range of commercial applications. Available in extruded profiles, sheets plus molded and die-cut shapes, NC-Consil can be easily fabricated to meet custom requirements. A compatible adhesive is available.

NC-Consil, it's the new nickel-graphite gasket that delivers broad band shielding performance at an incredible price. Call (908) 272-5500 for more detailed specifications.



TECKNIT®
EMI SHIELDING PRODUCTS

129 Dermody St., Cranford, NJ 07016
(908) 272-5500 / fax (908) 272-2741
Tecknit home page: <http://tecknit.com>

Acoustical-Sensor Assemblies for Use in Flows

Screens and absorbers reduce spurious signals.

Ames Research Center, Moffett Field, California


Improved sensor assemblies have been invented for measuring acoustic signals in gases or liquids flowing in or around any of a variety of moving or stationary objects. Examples of such objects include land vehicles, aircraft, submarines, structures exposed to winds or natural water streams, and industrial equipment containing or surrounded by process streams. In comparison with older acoustical-sensor assemblies designed for use in flows, these assemblies offer reduced response to noise generated by flows at and near sensor-assembly surfaces and increased protection for fragile acoustical transducers. These assemblies can be made to discriminate against sounds coming from outside preferred ranges of directions. They can also be mounted flush with surfaces of objects to minimize flow-induced noise and drag.

The figure illustrates two assemblies within the scope of the invention. In each case, the sensor is a microphone or other dynamic-pressure transducer. Each sensor is mounted in a cavity, wherein it is recessed from a streamlined surface. The cavity is lined with a sound-absorbing foam filler. A hole in the filler tapers conically from the sensor at its narrow end to an opening on the streamlined surface at its wide end. The cone angle is chosen,


along with other design parameters, to obtain the desired directional response.

The opening on the streamlined surface is covered with a screen or porous sheet, which prevents or reduces the propagation of surface-flow disturbances (turbulence) into the cavity while allowing the acoustic waves of interest to propagate to the sensor. The placement of the sensor in the recess behind the screen thus reduces the intensity of flow-induced noise arriving at the sensor. Moreover, spurious acoustic disturbances arriving from immediately upstream or downstream of the opening can be rejected by reflection from the shear layer in the flow adjacent to the screen. Because the fluid in the cavity is still or nearly still, relative to the fluid outside the cavity, the sensor is protected against damage by the flow. The screen also protects the sensor against impacts of particles entrained in the flow.

The sensor assembly shown in the upper part of the figure is mounted inside a streamlined body with a rounded fairing on its upstream end, for measuring sounds arriving at the surface of the body. The sensor assembly shown in the lower part of the figure is mounted on the wall of an object; this sensor assembly includes its own fairing, which protrudes into the



SENSOR ASSEMBLY MOUNTED IN STREAMLINED OBJECT WITH FLUSH OPENING



SENSOR ASSEMBLY MOUNTED IN FAIRING THAT PROTRUDES BEYOND BOUNDARY LAYER

Sensors Are Mounted Behind Screens at the apices of conical holes in sound-absorbing foam fillers.

flow beyond the wall boundary layer or free shear layer, for measuring sounds free of interference from turbulence in this layer.

This work was done by Fredric Schmitz, Sandy Liu, Stephen Jaeger, and W. Clifton Horne of **Ames Research Center**. For further information, access the Technical Support

Package (TSP) **free on-line at www.nasatech.com** under the Physical Sciences category.

This invention has been patented by NASA (U.S. Patent No. 5,684,756). Inquiries concerning nonexclusive or exclusive license for its commercial development should be addressed to the Patent Counsel, Ames Research Center; (650) 604-5104. Refer to ARC-12099.

Biotelemetry Using Implanted Unit To Monitor Preterm Labor

Pressure changes are telemetered to the outside and analyzed to detect intrauterine contractions.

Ames Research Center, Moffett Field, California

A biotelemetric system for monitoring key physiological parameters of a fetus and its uterine environment is undergoing development. The main purpose of the monitoring is to detect preterm labor in order to enable timely treatment. At the present stage of development, the system monitors pressure changes and temperature. The pressure changes serve as direct indications of intrauterine contractions that could be associated with the onset of preterm labor. Future versions of the system are expected to monitor additional parameters, including pH and the heart rate of the fetus.

The system (see Figure 1) includes a transmitting unit that contains a thermistor (the temperature sensor) and a piezoresistive transducer (the pressure sensor), a receiver, data-acquisition subsystem, and a digital signal-processing subsystem. The fully developed transmitting unit is projected to be small enough that it could be introduced into the uterine cavity through a 10-mm trocar during endoscopic fetal surgery; the surgical procedure for implanting this transmitter would be less invasive than

are the hysterotomies performed to implant the transmitting units of telemetric systems developed previously for the same purpose.

The transmitter generates a pulsed signal at a carrier frequency between 174 and 214 MHz. The temperature and pressure information are conveyed by pulse-interval modulation (PIM): Pulses are transmitted in pairs at a pulse-pair-repetition frequency of about 1 to 2 Hz. The interval between the two pulses in each pair is proportional to the sensed pressure, while the interval between pairs is proportional to the departure of the sensed temperature from a predetermined nominal value. The low data rate is sufficient for monitoring intrauterine contractions, which typically occur over several minutes. The transmission range is 3 to 10 ft (1 to 3 m), depending on the position of the transmitter in the body.

Transmitter power is supplied by two silver oxide batteries; at an average power consumption <40 μ W, the operational lifetime ranges from 4 to 6 months. The fully developed transmitting unit would be electronically identi-





Figure 1. A **Transmitting Unit in a Uterus** monitors physiological parameters and transmits its reading to external equipment. The fully developed transmitting unit, resembling a large pill, would be small enough to be implantable by minimally invasive surgery.

Design Your Own Data Acquisition System



Let **DAQ Designer™ 99** help you interactively configure your custom measurement solution.

Connect any signal to your PC

- Thermocouples
- Pressure sensors
- Millivolt signals
- Frequency inputs
- 0-20 mA current
- Voltages up to 250 V
- Thermistors
- Strain gauges
- RTDs
- Load cells

Get advice on products for:

- Analog, digital, and timing I/O
- Signal conditioning
- Remote and distributed I/O
- Image acquisition
- PC-based DMMs, scopes, arbs, and switches
- Software, including LabVIEW™
- PCI, CompactPCI, PXI™, ISA, PCMCIA, parallel port, serial, USB, Ethernet, and VXI



- More video product descriptions
- System configuration diagram provided
- More than 50 new products

Call today for your **FREE** **DAQ Designer 99** **CD-ROM**



NATIONAL INSTRUMENTS™

www.natinst.com/daq

(800) 327-9894

Tel: (512) 794-0100 • info@natinst.com

© Copyright 1998 National Instruments Corporation. All rights reserved. Product and company names listed are trademarks or trade names of their respective companies.



cal to a larger prototype that has already been constructed (see Figure 2), but would be miniaturized by following the chip-on-board approach, in which unpackaged integrated-circuit chips are flip-chip bonded directly onto a printed-circuit board along with other components. The transmitter is encapsulated in biocompatible silicone rubber.

The receiver converts the PIM radio-frequency signal into a digital pulse stream, which is then decoded to obtain voltages proportional to the temperature and pressure readings. These voltages are digitized in the data-acquisition subsystem, which is a Personal Computer Memory Card Association (PCMCIA) circuit card in a laptop computer. The digital data are then processed in the digital signal-processing system, which is the remainder of the laptop computer.

The processing is done by a LabVIEW® program that displays and stores the pressure and temperature data as functions of time, performs peak detection, and determines the frequency of contractions. The program integrates the pressure over time to obtain an index of the amount of preterm labor. A unique feature of the program is the application of statistical and frequency-analysis functions to the



Figure 2. A **Prototype Transmitting Unit** would be miniaturized and encapsulated in biocompatible silicone rubber.

pressure data to help a pediatric surgeon detect preterm labor. Among other things, the program displays the frequency spectrum of intrauterine contractions. Another unique feature is a contraction-detecting algorithm.

This work was done by John W. Hines of Ames Research Center and Christopher J. Soms, Robert D. Ricks, and Carsten W.

Mundt of Sverdrup Technology, Inc. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Electronic Components and Systems category.

Inquiries concerning rights for the commercial use of this invention should be addressed to the Patent Counsel, Ames Research Center; (650) 604-5104. Refer to ARC-14280.

Laser Solutions for Industry


www.synrad.com

SYNRAD
An Excel Technology Company

6500 Harbour Heights Parkway Mukilteo, WA 98275 1.800.SYNRAD1 toll free 1.425.349.3500 tel 1.425.485.4882 fax synrad@synrad.com e-mail



Special Coverage: Sensors




The VS1 Series self-contained **photoelectric sensor** from Banner Engineering Corp., Minneapolis, MN, is a convergent mode sensor with built-in amplifier that can switch loads up to 50 milliamps. The tiny sensing system is designed for space-restricted areas, such as inside machinery. It

operates on 12 to 24V dc and uses a visible red sensing beam in the convergent sensing mode to form a visible spot at either a 10-mm or 20-mm focus.

The sensor provides repeatability of 250 microseconds, with output response time of 1 millisecond. Green and yellow LED indicators provide operating status information. Users have a choice of light operate (N.O.) or dark operate (N.C.) models. The sensor operates in temperatures of -20°C to +55°C, and has a black ABS/polycarbonate housing with an acrylic lens.

For More Information Circle No. 711




The Model 740B02 **dynamic strain sensor** from PCB Piezotronics, Depew, NY, features ICP® sensor microelectronic circuitry and a quartz sensing element for measuring small dynamic strain on top of large static loads.

The high-resolution sensor also can be used to detect wave propagation for material velocity characterization.

The sensor is designed for use in active vibration control, noise-path analysis, modal testing, and for use on aircraft, composite materials, smart structures, and vibrating machinery. It has sensitivity of 50 mV/ $\mu\epsilon$ and an amplitude range of $\pm 100 \mu\epsilon$ peak. Housed in titanium, the sensor has a low profile and possesses a 10-foot integral cable, terminating in a 10-32 connector.

For More Information Circle No. 709



MTS Corp., Sensors Div., Cary, NC, offers Tempsonics® Auto-SE **position sensors** for product designers in the medical, automotive, aeronautic, and consumer products fields. The sensors eliminate degradation under regular shock, vibration, and high-cycle wear. They are non-contact and based on the company's magnetostrictive technology.

The magnetostrictive linear position sensors are protected from the elements and have a long life expectancy with virtually no maintenance requirements. The sensors'

design flexibility allows them to be used in a variety of applications by product designers, engineers, and R&D professionals.

For More Information Circle No. 708



Baumer Electric, Southington, CT, has introduced a family of **ultrasonic position sensors** with analog output and tech mode. The sensors offer single, one-button programming and require no special tools for set-up. The teach function allows the user to

select both limits of the sensing range and the steepness of the analog output. The output function is invertible, which allows the user to select a rising or falling output slope for each application.

All adjustments are made using the teach-in button, and settings can be monitored using the multi-colored LED indicator. Operating range is 100 to 700 mm, and the analog output supplies 0 to 10 volts. Set-up configuration is saved on an internal EEPROM. Applications include breakage control, monitoring roll diameters, and measuring applications.

For More Information Circle No. 707



Patriot Sensors & Controls Corp., Simi Valley, CA, offers the SP101 **pressure transducer**, which features a flush-mount design and high frequency response with pressure ranges from 15 to 5,000 psi. Units are interchangeable without system calibration, making them suitable for applica-

tions with small envelope restrictions or where non-clogging installation is required. Capabilities include a 200% overpressure and up to a 1000% burst pressure.

The transducer can be mounted onto walls of machined or plastic housings, in a reservoir, or against flexible tubing. The design flexibility allows pressure output readings for monitoring pressure in small vessels, medical equipment, automated manufacturing equipment, pipes, or pumps. The unit has a corrosion-resistant stainless steel diaphragm.

For More Information Circle No. 710



SIE Sensors, Toledo, OH, has introduced a series of self-contained, compact, capacitive **proximity sensors** available in 6.5-mm, M8, 10-mm, M12 housings. The VDC sensors feature outputs in PNP or NPN, normally open or normally closed. Sensing distances range from 1.5 to 8 mm, and are adjustable with the potentiometer and complimented with an LED status indicator.

Each unit is available with 2M cable or quick-disconnect. The sensors are IP67 rated, CE approved, protected from short-circuiting and overloads, and have a temperature range from -30°C to +70°C. They are available with a choice of metal, stainless steel, PVC, or PTFE housings. They can detect materials such as plastic, glass, ceramics, metal, liquids, and wood in true flush mountings.

For More Information Circle No. 706



LaNi_{5-x}M_x Alloys for Ni/Metal Hydride Electrochemical Cells


A systematic approach to extension of cycle lives has emerged from recent studies.

NASA's Jet Propulsion Laboratory, Pasadena, California

Studies of physical and chemical effects in the hydride-forming electrodes of rechargeable nickel/metal hydride electrochemical cells have yielded results that now guide efforts to formulate improved electrode alloys to extend the cycle lives of the cells. These efforts involve finding appropriate ternary solutes and amounts of those solutes to alloy with the original hydride-forming binary alloy LaNi₅ to form alloys of general composition LaNi_{5-x}M_x. Here, M denotes any suitable element or alloy that forms a strong bond with lanthanum, as explained below.

Findings consistent with this approach were reported in two previous articles in *NASA Tech Briefs*: "LaNi_{5-x}Sn_x Electrodes for Ni/MH Electrochemical Cells" (NPO-19805), Vol. 22, No. 8 (August 1998), page 60 and "LaNi_{5-x}Ge_x Electrodes for Ni/MH Electrochemical Cells" (NPO-19962), Vol. 22, No. 8 (August 1990), page 61. At the time of reporting the information for those articles, there was no explanation of the basic physical and chemical mechanisms for the degradation of cycle lives of LaNi₅ electrodes and for the improvements afforded by partial substitution of Sn or Ge for Ni. The basic mechanisms are still not well understood, but the following understanding has emerged from the research performed thus far:

Hydrides of LaNi₅ are thermodynamically unstable against disproportionation reactions in which they decompose into Ni plus LaH₂ or La(OH)₃. In addition, upon absorption of hydrogen, LaNi₅ can expand by as much as 24 volume percent; the combination of large expansion during absorption and the corresponding large contraction during subsequent desorption of hydrogen induces structural defects and reductions in particle sizes, with a consequent increase in the diffusion of metal atoms in the LaNi₅ crystalline lattice. This increase in diffusion increases the La content at the surface, where the La is readily oxidized to form a thick hydroxide layer in one of the disproportionation reactions. The present approach involving formulation of LaNi_{5-x}M_x is based on suppressing diffusion of La and thereby preventing disproportionation of LaNi₅.



Cyclic Lifetimes of electrodes made of LaNi_{5-x}M_x are related to heats of formation of M with La. The lifetime ratio for a given M is defined as (the number of charge-discharge cycles to half of initial charge capacity for an electrode made of LaNi_{5-x}M_x) ÷ (the corresponding number of cycles an electrode made of LaNi₅).

More specifically, the approach is to seek compositions and crystalline structures to immobilize lanthanum atoms in the Haucke-phase metal hydrides. The most promising ternary solutes for this purpose should be elements that form the strongest chemical bonds with lanthanum—stronger than the bonds between nickel and lanthanum. The solute atoms would be positioned on the nickel planes of the Haucke phase, so that they would be close to lanthanum neighbors. Strong bonds to neighboring atoms would suppress the formation of crystalline-lattice defects as well as movements of lanthanum atoms.

Preliminary support for this approach has been found through an analysis of cyclic lifetimes for various solutes as reported in the literature; the analysis reveals a close relationship between cyclic lifetime and the heat of formation of the solute with lanthanum (see figure). The finding of this relationship motivated the hypothesis that the rates of disproportionation and/or degradation could be re-

duced by adding solutes that bond strongly with lanthanum. Among the solutes that exhibit high heats of formation with lanthanum are germanium and tin (mentioned in the cited prior articles), plus indium.

This work was done by Ratnakumar Bugga, Robert Bowman, Adrian Hightower, Charles Witham, and Brent Fultz of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Electronic Components and Systems category.

In accordance with Public Law 96-517, the contractor has elected to retain title to this invention. Inquiries concerning rights for its commercial use should be addressed to


Technology Reporting Office

JPL

Mail Stop 122-116
4800 Oak Grove Drive
Pasadena, CA 91109
(818) 354-2240

Refer to NPO-20107, volume and number of this NASA Tech Briefs issue, and the page number.

NEW
plug-and-play
PCI
data acquisition
boards from
KEITHLEY



CLEANLY ENGINEERED FOR CLEANER OUTPUT

Our new 32 bit PCI boards give you higher-performance data acquisition and digital I/O because we pay closer attention to the important details. Like design integrity, component quality and advanced manufacturing, assembly and testing. Everything it takes for the true plug-and-play functionality you need – without background noise skewing your results. Just compare our specs, and you'll see what a difference our dedication makes.

Easy to set up and easy to use, these PCI boards produce consistent data you can trust. And you can trust Keithley for application support, to help you meet all your data acquisition demands.

For complete specifications or to talk with an Application Engineer, contact Keithley today at 1-888-KEITHLEY (1-888-534-8453).

KEITHLEY

A WORLD OF MEASUREMENT SOLUTIONS

MODEL	KPCI-PIO24	KPCI-PIO96	MODEL	KPCI-1801HC	KPCI-1802HC
• PCI Bus Architecture	32 Bit PCI	32 Bit PCI	• PCI Bus Architecture	32 Bit PCI	32 Bit PCI
• Number of I/O Lines	24 Bi-directional	96 Bi-directional	• Number of Channels	64 Singled-ended/ 32 Differential	64 Singled-ended/ 32 Differential
• Sink Current	64mA	64mA	• Resolution	12 Bit	12 Bit
• Source Current	15mA	15mA	• Sampling Rate	333kS/sec (Max)	333kS/sec (Max)
• Software Platforms	Windows® 95/98/NT	Windows® 95/98/NT	• Analog Outputs	2 (12 Bit)	2 (12 Bit)
• Bundled Software	DriverLINX®, TestPoint™, LabVIEW® Drivers	DriverLINX®, TestPoint™, LabVIEW® Drivers	• Software Platforms	Windows® 95/98/NT	Windows® 95/98/NT
			• Bundled Software	DriverLINX® and TestPoint™ Drivers	DriverLINX® and TestPoint™ Drivers

Enhance Microwave Performance



Registered
ISO 9001

ECCOSORB®, Emerson & Cuming Microwave Product's complete range of microwave absorbing materials, effective in controlling electromagnetic interferences from 0.8 through 40 GHz. Products Include:

- Cavity damping-surface current absorbing elastomers & foams
- Broadband & tuned specular absorbing elastomers & foams
- Lossy magnetic machinable rod & sheet series for terminations & loads

We specialize in providing custom shaped ECCOSORB® absorbing materials, ECCOSTOCK®, dielectrics and ECCOSHIELD® shielding products.

**EMERSON
& CUMING**
MICROWAVE PRODUCTS

*the recognized global leader in
microwave absorbing materials.*

800-650-5740

28 York Avenue, Randolph, MA 02368
781/961-9600 • fax 781/961-2845
email: sales@emersoncumingmp.com

www.emersoncumingmp.com

Finite-Width Coplanar-Waveguide Patch Antenna

Developmental phased-array antennas would incorporate antenna elements like this one.

John H. Glenn Research Center, Cleveland, Ohio

The upper part of Figure 1 illustrates an antenna derived by widening the middle strip conductor of a finite-width coplanar waveguide (FCPW) to form a rectangular patch. An FCPW offers all the advantages of a conventional coplanar waveguide, along with the additional advantage that its finite-width ground planes suppress the propagation of spurious substrate electromagnetic modes that would otherwise degrade the electrical performance of an array of patch antenna elements.

The lowest order of resonance of an FCPW patch antenna occurs at a frequency for which the guide wavelength, $\lambda_{g(\text{slot})}$, equals the sum of mean lengths of slots from point a to point i. At resonance, the electric-field lines are oriented as shown by the curved arrows, and the antenna radiates with a polarization parallel to sides c-d and f-g.

An experimental FCPW antenna element like that of Figure 1 was fabricated by use of gold paste and screen printing on ceramic substrates. The substrate material had a relative permittivity of 5.9, making it possible to reduce patch dimensions significantly to make an array of such elements more compact. Dimensions included $D = 0.01125$ in. (0.286 mm), $S = 0.012$ in. (0.305 mm), $W = 0.004$ in. (0.102 mm), and $G = 0.024$ in. (0.700 mm). The input impedance of the antenna was measured by use of through-reflect-line on-wafer calibration standards, a pair of microwave probes, an automatic network analyzer, and de-embedding software from the National Institute of Standards and Technology; these measurements revealed that the antenna resonated at frequency of 19.95 GHz with a de-embedded input impedance of 534Ω at plane P-Q.




Figure 1. An FCPW Patch Antenna is derived by widening the middle strip conductor of a finite-width coplanar waveguide to form a rectangular patch.




Figure 2. FCPWs and FCPW Patch Antennas are elements of developmental modules that will eventually be used to make compact phased-array antennas.

The upper part of Figure 2 illustrates two back-to-back FCPWs on the top side of a dielectric substrate, a connecting FCPW on the bottom side of the substrate, and FCPW-to-FCPW vertical interconnections (vias). An experimental unit having this configuration was made of substrate material and conductor strips with dimensions D , S , W , and G as described above, and with vias of ≈ 0.01 in. (≈ 0.25 mm) diameter.


The lower part of Figure 2 shows a system-level integrated circuit (SLIC) module that was undergoing development at the time of reporting the information for this article. The completed module would contain all the circuitry of an eight-element phased-array antenna. The module would contain four dual-channel monolithic microwave integrated circuits (MMICs) and supporting circuitry. Each of the dual channels would contain a three-bit phase shifter, an analog attenuator,

and amplitude-calibration and -control elements. A photonic link would bring the radio-frequency signals and digital control signals into the module. Another photonic link would return information on the status of the module to an external controller.

This work was done by Richard Q. Lee and Kurt A. Shalkauser of Glenn Research Center; Jonathan Owens, James Demarco, Joan Leen, and Dana Sturzebecher of PSD, Army Research Laboratory, AMSRL-PSE; and Rainee N. Simons of NYMA, Inc. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Electronic Components and Systems category.

Inquiries concerning rights for the commercial use of this invention should be addressed to NASA Glenn Research Center, Commercial Technology Office, Attn: Tech Brief Patent Status, Mail Stop 7-3, 21000 Brookpark Road, Cleveland, Ohio 44135. Refer to LEW-16666.

Simply Powerful



Powerfully Simple

With LabVIEW™, there are no compromises – LabVIEW has the simplicity AND the power.

Featuring:

- New instrument and data acquisition Wizards
- Powerful 32-bit multithreading technology
- Compatibility with ActiveX controls and automation

Discover the power to make it simple with LabVIEW!

Call today for your **FREE LabVIEW Evaluation Package**



NATIONAL INSTRUMENTS™

www.natinst.com/info/lv

(800)-452-6914

Tel: (512) 794-0100 • info@natinst.com

© Copyright 1998 National Instruments Corporation. All rights reserved. Product and company names listed are trademarks or trade names of their respective companies.





Software

Updated Software for Predicting Noise From Aircraft

The FOOTPR and RADIUS computer programs implement state-of-the-art mathematical models for predicting levels of noise generated by existing or proposed aircraft. These programs can be used to calculate Federal Aviation Administration (FAA) noise-certification levels, airport-vicinity noise footprints, and levels of noise generated during climb and en route. FOOTPR and RADIUS originated in research at Lewis (now John H. Glenn) Research Center in the year 1981. Since that time, seven jet-noise models, four fan-noise models, a fan-noise-suppression model, and second core and turbine-noise models have been added to these codes, and a ground-reflection model already in the codes has been enhanced.

FOOTPR computes histories of noise at various observer stations (usu-

ally on the ground) for an aircraft flying at a specified set of speeds, orientations, and coordinates. These time histories are in the forms of spectra, overall sound-pressure level (OASPL), perceived noise level (PNL), and tone-weighted perceived noise level (PNLT). For each source of noise, free-field noise levels are initially computed with no correction for propagation losses other than those associated with spherical divergence. The total spectra can be corrected for the effects of atmospheric attenuation, extra ground attenuation, reflection from the ground, and shielding by the aircraft. The corresponding values of the OASPL, PNL, and PNLT are then calculated.

From the history at each point, true effective perceived noise levels (EPNLs) are calculated. Values of EPNL, maximum PNL, or maximum PNLT are thus found, as desired, for a grid of specified points on the ground.

RADIUS computes customary one-third-octave sound-pressure levels at a fixed radius at angles specified by the user. The noise-source subroutines used in RADIUS are the same as those in FOOTPR.

FOOTPR and RADIUS are batch-executed programs written in Fortran 77. No system software libraries (other than those for basic mathematical functions) are needed for execution. The current versions of these programs are executed on Unix-based computers, but they can be run on almost any computer/operating system combination that supports Fortran.

This program was written by Jeffrey Berton of John H. Glenn Research Center and Karen Kontos, Robert E. Kraft, Bangalore Janardan, and Philip Gliebe of General Electric Aircraft Engines. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Mechanics category.
LEW-16576

Non-Contact Infrared Thermometer With Laser Sighting

Palm Size



- Simple temperature measurement from -20 °C to 300 °C
- Laser sight pinpoints measured spots.
- Automatic-backlit LCD display at dark places by a brightness sensor
- Automatic power off for saving battery life
- Audible buzzer high alarm standard
- Emissivity adjustable from 0.30 to 1.90 in 0.01 steps

Handheld Infrared Thermometer

Model **IR-TA**

Measurement and Control System

CHINO

CHINO Works America Inc.

VICTORIA BUSINESS PARK 18005 SO. SAVARONA WAY, CARSON, CALIFORNIA 90746
TEL:213-321-3943/45 FAX:310-532-7195

CHINO CORPORATION

32-8, KUMANO-CHO, ITABASHI-KU, TOKYO 173, Japan
TEL:03-3956-2171 FAX:03-3956-0915

FREE Limited-Time Trial Version of Algor's NEW RELEASE 12

Download and See for Yourself how Easy it is to Use

www.algor.com

Release 12 software is Algor's most comprehensive release since 1990. Release 12 features seamless integration with CAD and an all-new single user interface for Finite Element Analysis (FEA) so you can control all of Algor's modeling and analysis software from within Superdraw III. Each data input screen has real-time data checking to prevent input errors during an FEA. The Release 12 interface also features unit definition and context-sensitive help. An all-new material library system and improved engineering capabilities support the new user interface. Release 12 includes hundreds of improvements to make your engineering accurate and easy.

Now you can download a free limited-time trial version of Algor's Release 12 software. The download includes a complete version of Release 12 so you can try out Algor's wide range of engineering and simulation software from a simple Linear Static Stress Analysis to a Nonlinear Material Analysis, Physics-based Mechanical Event Simulation or Multiphysics Analysis. You can also try out Algor's new seamless integration with CAD using Houdini. Then select from Algor's three types of automatic FEA solid meshes: tetrahedral; all-brick or hybrid, with bricks on the surface and tetrahedra inside. Algor's automatic meshers work from the surface inward, creating a higher-quality FEA solid mesh with the best-shaped elements on the model's surface where stresses tend to be the greatest.

The download also comes with tutorials that give you a guided tour of this new software. These tutorials are available for a variety of analysis types and take you through an analysis from beginning to end, demonstrating the features and capabilities of Release 12 as you go.

See for yourself how easy and accurate our Release 12 software is by downloading it from www.algor.com and trying it for a limited time for free. Or call us at +1 (412) 967-2700 or complete the form below to request a demo CD-ROM.


Algor's Houdini
Solid Model
Interface

CAD Solid Modeler

Superdraw III
Single User
Interface

Finite Element
Analysis and
Mechanical Event
Simulation


Seamless CAD-interfacing makes using your CAD solid models for FEA, Multiphysics and Mechanical Event Simulation easy by running Algor from within the CAD solid modeler.



Superdraw III, Algor's single user interface for FEA, controls all functions for modeling and Finite Element Analysis or Mechanical Event Simulation.



Algor's downloadable keystroke-specific tutorials give you a walk-through demo of Release 12. Tutorials can be printed out or viewed on the screen as you work.



Unlike other engineering software trial versions that are limited, the trial version of Algor's Release 12 software contains complete Linear and Nonlinear FEA Stress Analysis and multiple Physics-based Mechanical Event Simulation software packages including stress and motion, heat transfer, fluid flow and electrostatic capabilities.

Get a **FREE** demo video and CD-ROM from Algor.

Complete this form and fax it to: +1 (412) 967-2781.

or contact:

www.algor.com
info@algor.com
+1 (412) 967-2700

Name _____ Company _____

Address _____

City _____ State/Prov _____ Country _____ Zip/Postal Code _____

Phone _____ Fax _____ E-mail _____ (rel12-us)

ALGOR
When the Engineering
Has to Be Right

Algor, Inc.
150 Beta Drive, Pittsburgh, PA 15238-2932 USA
Phone: +1 (412) 967-2700
Fax: +1 (412) 967-2781
California: +1 (714) 564-0844
Europe (UK): +44 (1784) 442 246
E-mail: info@algor.com
Web: www.algor.com



Durable Advanced Flexible Reusable Surface Insulation

Blankets covered with impermeable foils are sealed loosely at their edges.

Ames Research Center, Moffett Field, California

Continuing efforts to develop lightweight, flexible thermal-insulation blankets that withstand high temperatures have led to design and fabrication concepts that effect the following improvements:

- Increase durability while providing adequate thermal protection to structures that would otherwise be subjected to multiple cycles of aeroconvective heating; and
- Provide for closing out the edges of insulating blankets in such a way as to minimize intrusion of water, minimize leakage of heat, provide smooth aerodynamic surfaces at joints between adjacent blankets, and accommodate thermal expansion without buckling of outer blanket surfaces.

Blankets that incorporate these improvements are denoted collectively as "durable advanced flexible reusable surface insulation," and are the latest in a series of similarly named blankets made largely of ceramic fibers.

As shown in Figure 1, a blanket of the present type includes (1) a bulk insulating layer of fibrous ceramic batting sandwiched between inner and outer ceramic fabric layers, (2) a screenlike metal fabric woven from wire, (3) an outer layer of metal foil, and (4) ceramic thread stitching. The metal fabric and foil layers are made of one or two refractory metal(s) — typically, nickel alloy(s).

In fabrication, the metal fabric, ceramic fabric, and batting layers are first stitched together as a first subassembly, using ceramic threads in a lock-stitch pattern. After stitching, the outer ceramic fabric layer is heat-cleaned. A second subassembly is then formed by attaching the




Figure 2. Foil Extensions at the Edges of Two Adjacent Blankets are held on the frame and sealed by the snap-fitting cap.

metallic fabric layer to the first subassembly, and, in particular, to the ceramic fabric layer by stitching along lines that lie between the first-subassembly stitch lines. Portions of the outer ceramic and metal fabric layers protrude beyond the edges of the stitched area; these portions are stitched together with ceramic thread to form closeout extensions.

The metal-foil layer is then brazed to the metal fabric, thereby providing a relatively impermeable outer layer that helps to protect the ceramic layers against intrusion by water. Unlike in another design, there is no need to braze the metal foil to the ceramic fabric; therefore, a conventional brazing alloy can be used. (Conventional brazing alloys tend not to wet ceramic surfaces.)

After brazing, the blanket is closed out by any of three different methods, only one of which can be described in the space available for this article: A frame of fibrous refractory insulating material is

placed around the periphery of the blanket. The frame can be made in sections [typically about 6 in. (≈ 15 cm) long] and is designed to permit flexing of the blanket on the perimeter without creating any gaps. The frame sections are attached mechanically to the surface of the structure to be protected.

Figure 2 depicts part of a frame that abuts two adjacent blanket sections. The metal-foil layer of each blanket extends onto the outer (top in the figure) surface of the frame. Pairs of rectangular opposed recesses are machined into each frame section, and rectangular openings are made in the metal-foil extensions at the locations of the recesses in the frame. A snap-fitting cover includes pairs of legs that extend through the openings into the recesses. The legs engage the recessed surfaces so as to secure the cover over the edge portions of the foil layers. The blankets are thus sealed on the surface by snapping in the cover.

This work was done by Daniel Rasky, Demetrius A. Kourtides, Daniel L. Dittman, Marc D. Rezin, Clement Hiel, and Wilbur C. Vallotton of Ames Research Center. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Materials category.

This invention has been patented by NASA (U.S. Patent No. 5,811,168). Inquiries concerning nonexclusive or exclusive license for its commercial development should be addressed to the Patent Counsel, Ames Research Center; (415) 604-5104. Refer to ARC-12081.




Figure 1. This Blanket Differs From Other Insulating Blankets in several respects, including notably the method of attachment of the outer metal foil.

WE HELPED KEEP INVENTOR GRADY DUGAS FROM SPINNING HIS WHEELS.



*Ingenious new
lock system of
Dupont Zytel® nylon
sets the brakes when
weight is removed
from seat.*

With the technical support we at DuPont had to offer, the development process rolled along smoothly. Our material expertise made it possible for Dr. Dugas to engineer a lock providing outstanding durability, good looks and low maintenance while adding very little weight. Let DuPont help keep you moving forward. For more information, call 1-800-533-1313.



DuPont Engineering
Polymers

www.dupont.com/enggpolymer



Eclipse Aerotow Dynamics Experiment

Flight tests have been successful.

Dryden Flight Research Center, Edwards, California

NASA Dryden Flight Research Center is supporting a Phase II Small Business Innovation Research (SBIR) contract between the U.S. Air Force Research Labs and Kelly Space & Technology (KST). KST's innovation is to use an aerotowed reusable launch vehicle to put small satellites into low orbits around the Earth. In support of this idea, the SBIR is to demonstrate aerotow with representative aircraft; namely, a C-141A as the towing airplane and a QF-106A (a modified F-106) as the towed airplane. NASA Dryden has developed a computational simulation of the dynamics of the tow rope and towed airplane, conducted dynamic-stability studies, developed test plans, and completed successful ground, taxi, and flight tests.

Towing a launch vehicle to altitude should make it possible increase the payload and decrease the cost of the launch. No previous aerotow experiments produced tow-dynamics data of any consequence. Dryden's expertise in conducting unusual flight tests was needed to perform simulations of the dynamics (see Figure 1), determine a safe flight-test approach, and conduct the aerotow flight tests.

Dryden provided support for the modifications that were made in converting the F-106 into the towed experimental airplane, and for its operation and maintenance. Dryden also provided research instrumentation, the test range, flight-safety, operations, research pilots, and research engineering analysis of the aerotow system. The Air Force Flight Test Center also supported this project by providing the C-141A airplane and flight crew.

Tests of the entire tow system (see Figure 2) have been completed. These included high-speed taxi (through rotation of the QF-106A airplane) and successful flight tests.

The results of the tests showed that, among other things, the tow rope is not a straight line as previously assumed. The rope exhibits considerable sail from the airflow. Observed stability boundaries do not match those predicted from the simulations; with a differential altitude of approximately 200 ft (60 m) between the aircraft, the tow-rope tensions were sta-




Figure 1. Eigenvalues of Oscillations of the Tow System in short-period, phugoid, and "bungee" (simple longitudinal) modes were identified, and a flight envelope for stable towing of the QF-106A behind the C-141A was predicted on the basis of computational simulations of the dynamics.



Figure 2. The C-141A Airplane Towed the QF-106A Airplane in flight tests. The airplanes were connected by a tow rope 1,000 ft (305 m) long.

Since posting our new Web site, over 9,000 people have had a chance to win a Trek® Bike* valued at \$1,800.

Why not go online now to see if you are one of six instant winners!

Begin by visiting www.spirallock.com. Then, click on the **WIN A TREK® BIKE** button and fill out the registration form that appears on-screen. The name of the winner will be posted immediately!

While at our Web site, be sure to learn more about Spirallock. Thanks to its unique, 30° wedge ramp (vs. 60° for standard thread forms), it offers important advantages to engineers worldwide.

"A thread form that locks without washers, inserts or adhesives. I didn't know there was one until I visited the Spirallock Web site."

Jim D., Design Engineer, Los Angeles, CA

"Thread loosening due to vibration is a problem we encounter. And the Spirallock thread form appears to be an excellent solution."

Derek S., Design Engineer, Coventry, UK



248.543.7800

*One Trek Bike given away every 30 days. Complete rules for this promotion can be found on our Web site.

For More Information Circle No. 560

ble. The rope sail also alters the trim of the aircraft relative to the predictions from the simulations; the angle at the point where the rope meets the QF-106A was found to be more acute than it was

predicted to be, making it necessary to use more elevon deflection. Analysis was continuing at the time of reporting the information for this article.

This work was done by Al Bowers and Jim

Murray of Dryden Flight Research Center. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Mechanics category. DRC-98-79

✚ Direct Thrust-Measurement Technique Applied to an F-15 Airplane

Preliminary results show that thrust can be measured accurately by use of strain gauges.

Dryden Flight Research Center, Edwards, California

Direct measurement of aircraft-engine thrust by use of strain gauges offers several advantages over traditional model-based methods of calculating thrust, provided that care is taken during the installation and calibration of strain gauges, and provided further that secondary load paths are understood. Advantages of the strain-gauge-based thrust-measurement method depend upon the specific engine/airframe interface, but can include the following:

- Simplification of the sensor installation, relative to the sensor suite that would be needed to support model-based calculations;
- Immunity (unlike in model-based methods) to drift and to the associated loss of accuracy as the engine deteriorates over time; and
- Excellent dynamic response.

Flight tests were performed to assess the suitability of the strain-gauge-based thrust-measurement method for application to the full flight envelope and power range of the F-15 airplane powered by F100-PW-229 engines. Other objectives of the flight tests were to determine whether unmeasurable secondary load paths affect the accuracy of this method significantly and to compare direct measurements against proven model-based thrust calculations.


Preliminary results from the flight tests showed that by properly accounting for secondary forces, and through the use of output data from a digital electronic engine-control system, excellent gross thrust-data accuracy was obtained during a subsonic-to-supersonic acceleration maneuver (see figure). Preliminary assessment of measurements throughout the remainder of the flight envelope show similar encouraging results.

At the time of reporting the information for this article, an in-depth analysis of the results from full-flight-envelope tests was planned for the near future, and the results were presented at the 1998 Joint Propulsion Conference. A description of the direct thrust sensor sys-

tem, along with installation and calibration issues, were to be included in the presentation.

This work was done by Tim Connors and Robert Sims of Dryden Flight Research

Center. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Mechanics category. DRC-98-81



An F-15 Airplane at an altitude of 30,000 ft (9.1 km) was made to accelerate from mach 0.9 to mach 2.0, then to decelerate from mach 2.0 to mach 0.9 in a flight test of the strain-gauge-based thrust-measurement method.



Machinery/Automation

Experiment on Quasi-Tailless Flight of an X-31A Airplane

Lessons learned will be applied in future development of thrust vectoring.

Dryden Flight Research Center, Edwards, California

An experiment consisting of flight tests on the X-31A airplane (see figure) has demonstrated the ability to use thrust vectoring to replace the functions of stabilization and turn coordination usually required of a rudder and vertical tail. Comments by the pilot indicated no difference in handling qualities for the majority of the tests flown. The experiment showed that the greatest demand was placed on the thrust-vectoring system at low thrust settings and high roll accelerations. It was demonstrated that a higher level of interaction between the engine and flight-control system will be needed for future reduced-tail or tailless aircraft with thrust-vector control. This experiment helped to introduce thrust vectoring as a new design dimension for future aircraft.

The quasi-tailless concept involves the use of in-flight simulation to assess the effect of partial to total removal of the vertical tail; in implementing this concept in the experiment, the rudder control surface was used to cancel the stabilizing effects of the vertical tail. Yaw-thrust-vector deflections were used to restabilize and control the aircraft. The quasi-tailless mode was flown supersonically with gentle maneuvering. Precise approaches and ground attack profiles were flown subsonically with more aggressive maneuvering.

The supersonic quasi-tailless test showed that maneuvers typically required of transport aircraft could be controlled by thrust vectoring for fairly high levels of instability. A tail-reduction setting of 70 percent was used during part of the experiment and was found to be equivalent to an instability-amplitude-doubling time of approximately 170 ms. The fidelity of the sideslip feedback measurement was found to be a critical factor in determining the amount of destabilization achieved by the quasi-tailless system. The sideslip feedback path included an equivalent delay of approximately 67 ms from complementary filtering of flight-test-boom and inertial parameters, and a deadband caused by mis-

aligned dual redundant sideslip vanes. These factors both influenced the level of destabilization achieved in flight.

To accomplish the objectives of the subsonic tests, it was necessary to maneuver the airplane more aggressively. The precise-approach tests provided a first look at the use of thrust vectoring as a primary means of control at low power settings. The flying qualities were found to be independent of tail-reduction setting up to a setting of 50 percent (an instability-amplitude-doubling time of about 0.92 s). High throttle activity coupled with a lag on the thrust-estimation algorithm resulted in errors in the thrust-control loop gain as high as 4 dB. Because of the high loop-gain margin of the X-31A, these errors did not produce any noticeable

stability problems. The tests showed that an accurate and redundant on-board thrust-estimation algorithm is necessary in an integrated propulsion/flight-control system. Either the design of such a system should provide for better estimation of thrust changes resulting from rapid throttle movements, or else a high stability margin for the thrust-vector control loop should be required.

All precise approaches were flown in clear air. A limited nonlinear simulation study showed that even with the deadband and lag in the sideslip feedback path, no significant handling-qualities problems were introduced with simulated turbulence. The issues of ride qualities and rejection of disturbances in the presence of atmospheric

Sensitive Equipment Protection

Systems Design Expertise

- Market Leader: Hardigg manufactures more than one half of all rotationally molded shipping cases sold in the US
- Over 295 commercial off the shelf standard sizes
- Quick as a Jack Rabbit delivery capability
- Custom design service
- Full cushioning design and manufacturing service

EGSA
Federal Supply Schedule
Contract No.
GS-14F-6140A



Hardigg Cases

147 North Main Street • South Deerfield, MA 01373 USA
Tel: 1-800-542-7344 or 413-665-2163 • Fax: 413-665-8061
www.hardigg.com • www.militarycases.com • Email: cases@hardigg.com



The X-31A Airplane was operated with thrust vectoring in a quasi-tailless mode to test and demonstrate advanced control concepts.

turbulence would be better addressed with a real tailless or reduced-tail vehicle. Because of limitations on frequency response and fidelity, the in-flight quasi-tailless system is not accurate enough to reproduce the true directionally unstable behavior characteristic of the response of an aircraft to turbulence.

A reasonable approach to the engine-out failure condition must be developed. If this approach is to include emergency devices that would be de-

ployed to regain directional stability, then the cost, weight, and complexity of such devices must be considered. The cost and weight of adding a thrust-vector system are being reduced by production of axisymmetric thrust-vectoring engines. The X-31A quasi-tailless flight test experiment showed that tailless and reduced-tail fighter-type airplanes are feasible. When the thrust-vectoring capability and reduced-tail configuration are incorporated into the design from the begin-

ning, the benefits of lower drag, reduced structural complexity, and reduced radar cross section could, potentially, outweigh the concomitant added complexity.

This work was done by John Bosworth and Patrick Stoliker of Dryden Flight Research Center. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Machinery/Automation category. DRC-96-12

New Standard

The Best Just Got Better.™



For nearly 40 years, MKS Baratron® capacitance manometers have been the standard in measuring process pressure accurately and repeatably. And they keep getting better. The particle resistant 627B has the fastest warm-up, the most stable output, the best on-board diagnostics, and, at 20 mTorr, the lowest full scale range available. The 627B sets the new standard by which process manometers are measured. Don't take a risk with an unproven manometer. Trust MKS to keep your process up and running.

ORION®

MASS-FLO®




BARATRON®

HPS™

Around The Process, Around the World.
(978) 975-2350

Check out our Baratron Capacitance Manometer Upgrade Program on our web site at www.mksinst.com.



Within you is a world
of ideas that can be
realized with the

power
to **VISUALIZE**



Starting at \$3,225

Within you is the power to visualize - empower yourself with HP VISUALIZE Personal Workstations' leading edge technology, performance and value.

HP's breakthrough *fx+* graphics deliver the world's fastest application performance with Intel processors on Windows NT. The VISUALIZE Personal Workstation features single or dual Intel® Pentium® III or Pentium® III Xeon™ processors up to 550MHz, and ECC SDRAM scalable to 2GB.

Beyond leadership graphics performance, HP bundles innovations for easy, single-point system administration and system diagnostics to maintain and protect your investment.

With HP's leadership in technology, performance and value, the answer is clear. HP's VISUALIZE Personal Workstations are the Ultimate Design Machines - engineered to solve your toughest mechanical design problems.

For more information visit: www.hp.com/info/vis1



**HP
VISUALIZE**
PERSONAL
WORKSTATIONS

THE **ULTIMATE** DESIGN MACHINE

Intel, the Intel Inside logo, and Pentium are registered trademarks, and Pentium III Xeon is a trademark of the Intel Corporation.

Information Circle No. 590



Improved Suit for Protection During Abrasive Blasting

Less time is spent in preparation and cleanup.

John F. Kennedy Space Center, Florida

An improved suit to be worn by a worker during abrasive blasting has been developed. Denoted an environmentally controlled abrasive-blasting suit (ECAB), it provides comprehensive protection that, heretofore, has been afforded by a set of special under- and over-garments (including a helmet) and a respirator. These garments and the respirator must be donned in a time-consuming "suit-up" procedure before abrasive blasting. After blasting, the worker must not only doff the garments and respirator but must also shower and the garments must be laundered before they are used again. In contrast, donning the ECAB takes less "suit-up" time, there is no need to wear special undergarments inside the ECAB, there is no need for a respirator, it is not necessary to shower after doffing the ECAB, and the suit does not require laundering prior to reuse.

The ECAB (see figure) is an ensemble that forms a closed envelope to isolate the worker from the hazards of the abrasive-blasting environment. The design of the ECAB also reflects a concern for mobility and comfort to increase the worker's endurance. The ensemble includes a helmet, a coverall, detachable gloves, detachable boots, plus detachable hoses and a manifold for supplying and distributing air for both breathing

and cooling. The helmet features a transparent visor and disposable blast shields.

The arms and legs of the coverall terminate in special cuffs designed for



The ECAB Protects the Worker from the hazards of abrasive blasting, and offers advantages over older, multiple-garment protective ensembles.

attachment and detachment of the gloves and boots. A similar provision is made for attachment and detachment of the helmet. The coverall materials are capable of withstanding impacts by abrasive particles that bounce back from the workpiece. The gloves are flexible enough to enable the worker to operate the abrasive-blasting equipment with ease. The boots are soled and sized to accept safety shoes or boots.

All attachment/detachment cuffs include seals to prevent the entry of abrasive particles into the suit. Relief valves allow air to flow out of the suit but resist the inflow of atmospheric air, thereby helping to maintain a slight positive pressure of supplied air within the suit.

The ECAB is designed and built to provide long-term multiple use.

This work was done by Raymond A. Anderson and Robert E. Persson formerly of EG&G Florida, Inc., for Kennedy Space Center. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Bio-Medical category.

Inquiries concerning rights for the commercial use of this invention should be addressed to the Technology Programs and Commercialization Office, Kennedy Space Center, (407) 867-6373. Refer to KSC-11868.

Exoskeletal System for Neuromuscular Rehabilitation

This system could help a neurally impaired patient regain the ability to walk.

NASA's Jet Propulsion Laboratory, Pasadena, California

A system of sensors and actuators designed to fit on the lower extremities of human patients and astronauts like an exoskeleton is under development to serve diverse purposes in neuromuscular research and rehabilitation. This system will be operated under both Earth and microgravity conditions. A product of integrated research efforts in several fields of science and engineering, the

design of the system incorporates advances in microsensors, robotics, and mathematical modeling of the dynamics of walking. The design of the system has been guided by research findings that show that the spinal cord (even when cut off from the brain by injury) is capable of relearning the ability to walk.

The system could be used by an astronaut exercising in space under the con-

ditions of microgravity to help maintain normal locomotion skills, muscle mass, and bone calcium levels. On Earth, the same system could be used for the rehabilitation of stroke or spinal-cord-injured patients in an effort to restore part or all of their ability to walk.

At present, one way to perform such rehabilitation is to suspend the patient in a harness over a treadmill so that their



Plan Now To Attend!

TECH

EAST '99

Your source for engineering solutions, product & business ideas,
and profitable partnerships

Sponsored by



Two venues, twice the opportunity to explore the cutting edge!

**September 20-22, 1999
Boston, MA
Hynes Convention Center**

New England Design & Manufacturing Expo

The latest products and services to help engineers meet their
design, prototyping, testing, and production challenges.
Featuring the CAD & Rapid Prototyping Pavilion.

Colocated with:



Photonics East

The Northeast's only optics and
photonics exhibition



Electronic Imaging Intl.

The East Coast's #1 annual
imaging expo

**November 1-3, 1999
Miami Beach, Florida
Fontainebleau Hilton**



Technology 2009

The tenth annual "Engineering Innovation Show" —
America's premier showcase of new and next-generation
technologies available for license and commercial
development. Colocated with:

Southeast Design & Manufacturing Expo
The only major design show targeting the Southeast
high-tech corridor

Small Business Tech Expo

2nd annual expo of resources and technologies to launch new products
and partnerships



Visit hundreds of exhibits free of charge!

Circle no. 570 for information on Boston.
Circle no. 571 for information on Miami.

Or visit www.techeast.net

To exhibit at Tech East, call Stephanie Torchinsky, (212) 490-3999; stephanie@abptuf.org.

SALES ENGINEERS
NATIONWIDE

extruded & molded
elastomers

Seals & Gaskets
Turnkey Assemblies

ESD
EMI RFI
shielding

precision engineered solutions

RUBBERCRAFT

A SANDERS INDUSTRIES COMPANY

Tel: 1.800.RUBBER.9 • Fax: 310.618.1832

www.rubbercraft.com

For More Information Circle No. 419

Are You an INSIDER?

Subscribe today to NTB INSIDER, the FREE e-mail newsletter for NASA Tech Briefs readers.

Twice each month, the INSIDER will bring you exclusive previews of upcoming briefs and articles in *NASA Tech Briefs*, advance notice of online and trade show opportunities, and NASA/industry news you won't find elsewhere. In a recent edition, for example, the INSIDER had the scoop on NASA's Inventions of the Year...weeks ahead of any other source.

Subscribe online at www.nasatech.com


legs bear only part of their entire weight while therapists manipulate the patient's legs to assist in stepping on the running treadmill. As the patient gains more ability to step, the amount of assistance needed is decreased. The disadvantages of this approach are several: a limited number of therapists can assist only a small number of patients, the assisted movements are only approximations of normal stepping motions, and there is no way to quantify changes in the amount of assistance needed. Thus, there is a need for something that can accurately measure limb motions, apply and measure controlled forces and torques, and be used to manipulate an entire leg in normal kinematic patterns and speeds. Such a device could be used to study more subjects with greater thoroughness and precision, and could make it possible to rehabilitate more patients with higher levels of success than can now be attained with human assistance alone. Such a robotic device could also be used to preserve normal locomotion skills for astronauts during long-term microgravity conditions.

The present exoskeletal system is a prototype of such a robotic device. Encouraging results have been obtained in preliminary tests performed on humans in the Neurological Rehabilitation and Research Unit of the University of California at Los Angeles. When the system is fully developed, continuous analysis and control of the force and torque actuators needed for normal walking motions will be generated from a combination of dynamical motion modeling and sensory feedback from the exoskeleton.

Thus, the development of the exoskeletal system involves the parallel development of sensors capable of measuring six degrees of freedom and computational resources capable of instantaneous analysis and control. This approach uses the exoskeleton to control and monitor the movements of each segment of the lower limb during locomotion and a mathematical model that accounts for such details as the masses and kinetics of limbs and the moment arms of individual muscles of the knee, hip, and ankle. Variables that can be investigated by use of the model include the percent of body weight loading, the frequency of stepping, the speed of walking, and changes in muscle output that would occur in hypertrophy or atrophy.

This work was done by James Weiss, Antal Bejczy, Bruno Jau, and Gerald Lilienthal of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Bio-Medical category.
NPO-20370

Rapid Product Development



Designing a Hybrid Electric Vehicle: The Tools it Takes.....	11b
Turning Information into Knowledge.....	5b
3D Tool for Modeling Early-Stage Designs.....	8b
New Products	10b

Mastercam Solids solid modeling software from CNC Software, Tolland, CT, can be combined with Mastercam Mill to create and machine solids in a single integrated interface. In this example, the flashlight was removed from a mold block to create a cavity, and a toolpath was applied. See New Products (page 10b) for more information. (Image courtesy of CNC Software)

Designing a Hybrid Electric Vehicle: The Tools it Takes


The quest to produce a hybrid electric vehicle (HEV) challenges the imaginations of automotive engineers around the world. Numerous configurations must be weeded out and prototypes are prohibitively expensive. These design problems seem tailor-made for tools such as MATLAB, Simulink, Stateflow, and Real-Time Workshop, a suite of design tools from The MathWorks, Natick, MA. Using these tools, auto engineers can swap engines and battery banks, try different chassis combinations, and make decisions that will guide future design efforts for cars that don't yet exist.

Already, two major players in the national effort to build an HEV have created simulators based on The MathWorks products that have become mainstays in HEV design. The Advanced Vehicle Simulator (ADVISOR), developed at The National Renewable Energy Laboratory (NREL) in Golden, CO, and the PNGV Analysis Toolkit from Southwest Research Institute (SwRI) in San Antonio, TX, both take advantage of Simulink's user-friendly, object-oriented environment for developing models, performing dynamic system simulations, and designing and testing new ideas. The tools have set the course for HEV development at national labs, universities, and among the Big Three auto makers.

"This is the next step toward realizing the development of these vehicles," said Scott McBroom, Senior Research Engineer at SwRI. "We're convinced this is the way to go."

In Pursuit of a Cleaner Car

The nation's effort to build practical and efficient hybrid electric cars by 2004 began in earnest with software developers involved in the Partnership



The ADVANCED Vehicle Simulator (ADVISOR) takes advantage of Simulink's user-friendly, object-oriented environment. (Courtesy of Keith Wipke, NREL)

for a New Generation of Vehicles (PNGV), a government initiative announced by President Clinton in 1993. With increasing U.S. dependence on foreign oil — most of which is used to fuel America's cars — and increased awareness of the perils of air pollution, alternate transportation had risen to national attention. Hybrid vehicles seem to offer the best hope of a near-term solution. Computer models and early prototypes indicate that HEVs will boost fuel economy and cut emissions, while still providing the safety, performance, and range that American drivers demand.

Under the PNGV program, NREL entered into contracts with Ford, General Motors, and Chrysler to produce hybrid propulsion systems by 1998, first-generation prototypes by 2000, and market-ready HEVs by 2003. In addition to the industrial partnerships, NREL has sponsored HEV research at the nation's leading engineering schools.

Engineers at the Big Three auto makers are pushing to meet PNGVs lofty goal of tripling conventional gas mileage to around 80 miles per gallon. Chrysler, which joined the initiative in 1996, is still in the modeling phase, while GM and Ford, which have been in the program since 1993, are testing their concepts on mule vehicles. More than 20 organizations currently use ADVISOR, and the tool is continuously fed up-to-date component test data through user and university validation efforts.

What's Under the Hood?

Hybrid vehicles use an electric motor and a bank of high-voltage batteries in conjunction with a "heat" engine, usually a conventional internal combustion engine (ICE). The components are arranged either in parallel or series configurations. Computer modeling with ADVISOR has already shown some basic characteristics for each.

In a parallel hybrid vehicle, both the electric motor and the ICE are con-




JUST HOW OLD IS THE PLATFORM BEHIND MECHANICAL DESKTOP?

PERHAPS A LITTLE MUSIC TO SET THE MOOD.

Fifteen years ago, Reagan was in the White House, vinyl ruled the music industry, and Autodesk developed the 2D platform Mechanical Desktop® still rests on today. SolidWorks® solid modeling software, on the other hand, was built from the ground up as a 3D tool. And since it was first introduced in 1995, it has become the fastest growing




program in CAD history. Instead of making you go around in circles, SolidWorks makes designing in 3D a simple, straightforward process. In fact, in a recent study, a user experienced with both programs was able to create a 3D model, complete with detailed drawings, more than twice as fast with SolidWorks 98Plus. Apparently, she had more than twice as much fun, too. If that sounds like music to your ears, call us today.



SOLIDWORKS 98 PLUS

TO LEARN MORE, AND TO FIND
OUT HOW TO RECEIVE OUR FREE
MIGRATION KIT FOR AUTOCAD
AND OTHER 2D USERS, CALL US
AT 1-800-693-9000 OR VISIT
WWW.SOLIDWORKS.COM/3208

MORE POWER. LESS SWEAT. SolidWorks



Simulink control block diagram for ADVISOR vehicle simulator. (Courtesy of Keith Wipke, NREL)

nected mechanically to the drive wheels. The ICE provides supplementary power when the vehicle is accelerating or climbing steep grades. Parallel HEVs don't need generators and have lower mass and better highway efficiency. They have the added benefit of redundant drive power, meaning the car can still be driven if one of the power systems fails. Parallel vehicles require a complicated mechanical coupling and a multi-speed transmission. Because the ICE must perform over a range of speeds, tuning can be difficult and efficiency is diminished.

In a series HEV, only the electric motor drives the wheels. The ICE runs an alternator, providing power to the electric motor and the battery bank. Series HEVs have simpler mechanics, allowing more freedom for component placement. Because the electric motor provides enough torque throughout the range of required speeds, a single-speed gearbox can take the place of the transmission. Full power is available at all times in a series HEV, and because the ICE runs only when the batteries need charging, it can be tuned to run efficiently at a single RPM. Because series HEVs lack the redundant drive systems of their parallel counterparts, they are extremely sensitive to battery and electric motor efficiency. Some vehicles may have trouble negotiating long, uphill grades.

For the two basic HEV configurations, there are a number of control strategies not found in conventional vehicles. While the efficiencies of each component are important, it is the way they are interconnected that really determines the value of an HEV design. Enter ADVISOR, with its ability to model all of the HEV components, monitor their interaction and response, and output the performance data.

"There are many ways to design these systems, and if you were to design and build each one individually and test it, it would require an enormous amount of time and money," said Dr. Larry

Michaels, Application Engineering Manager at The MathWorks. "By modeling on computer, you can evaluate all of these configurations very quickly and very cost effectively."

Virtual Trial and Error

ADVISOR is termed "steady-state" and "backward-looking" because its simulations begin with desired outputs and work back toward component choices and configurations. "You're trying to get into the ballpark with ADVISOR," added Dr. Michaels. "Trying to find a configuration that looks promising and that will meet performance and fuel economy goals. The idea is to see if this configuration should be pursued further and then to build prototypes based on that idea. Many times the negative answers are more important than the positive answers. The computer model is a way to quickly and easily see if you are ever going to get what you want out of it. Sometimes, even under ideal conditions, it won't meet goals. That idea can then be discarded."


According to NREL's Tony Markel, ADVISOR, with all of the components modeled, allows HEV designers to use a variety of standard and custom driving cycles like the Federal Urban Driving Schedule (FUDS) and the Federal Highway Driving Schedule (FHDS). With the power of Simulink, ADVISOR easily can handle battery state-of-charge corrections and vehicle soak periods. The simulator gives designers quick and accurate assessments of important vehicle performances such as fuel economy, emissions, acceleration, and grade sustainability. ADVISOR

results can then be run through MATLAB to find equilibrium points or ideal operating conditions.

ADVISOR's Graphical User Interface (GUI) is designed to facilitate entry and modification of elements such as drivetrain configuration, transmission, vehicle type, energy storage system, generator, driving cycle, control strategy, and scaling. The GUI corresponds to a top-level Simulink block diagram, which shows the model's data flow from trip, through road load, driveline, motor and energy storage, and on to numeric outputs for fuels used and tailpipe emissions. Looking down two layers into the "road load" subsystem shows the interaction of next required speed and previous speed through other subsystems representing roll, climb, aerodynamics, and acceleration to arrive at figures for torque and speed required at the virtual vehicle's "wheels."

On the Virtual Road


In 1996, NREL tested five vehicle configurations with ADVISOR in pursuit of PNGV's goal of 80 mpg. These included three lightweight (series, parallel, and ICE) and two conventional-weight (parallel and ICE) configurations. Simulink's block group modeling platform allowed designers to easily manipulate each component and find the strengths and weaknesses of each design. Using ADVISOR, NREL engineers found that parallel and series



Vehicle parameter input screen for ADVISOR vehicle simulator, developed in MATLAB/Simulink Environment. (Courtesy of Keith Wipke, NREL)

vehicles showed the same fuel economy sensitivity to most parameters, but series vehicles were three times more sensitive to battery and electric motor efficiency.

Results also showed that to reach the 80 mpg goal, ICE efficiency would have



SOLID OPPOSITION.



SOLID EDGE.

45% FEWER MOUSE CLICKS.

57% FEWER KEYSTROKES.

36% MORE PRODUCTIVE.

click.

CAD THE WAY YOU THINK.

Are you a designer or just another "mouse clicker?" Imagine serious, affordable mechanical CAD software that aids design using STREAM technology. Think SOLID EDGE. Software proven to use 45 percent fewer mouse clicks, 57 percent less keystrokes, and to increase productivity by more than 36 percent. CAD the way you think! For more productivity information, contact: www.solid-edge.com, call toll free 800-807-2200, or e-mail solidedge@ugsolutions.com.



SOLID EDGE

**Unigraphics
Solutions**

Unigraphics Solutions, Parasolid, Solid Edge, Unigraphics, ProductVision, IMAN, GRIP, managedServices and LightningStart are trademarks, registered trademarks or service marks of Unigraphics Solutions Inc. All other trademarks, registered trademarks or service marks belong to their respective holders. Copyright©1999 Unigraphics Solutions. All rights reserved. The information within is subject to change without notice and does not represent a commitment on the part of Unigraphics Solutions.

to be raised to nearly 35 percent and vehicle weight would have to drop to 1000 kg, about half the weight of today's conventional vehicles. While the conventional-weight vehicles modeled did not make the 80 mpg goal, they did manage a 20-percent improvement in fuel economy over today's cars.

According to Markel, ADVISOR has enabled NREL to specify 176 distinct vehicles for evaluation, verification, and data storage. The findings may drive research into battery and electric motor technology, and accelerate NREL's goal of having most metal auto components made of aluminum by 2015.

Last year, NREL used ADVISOR in a new test that allowed for different control strategies in the series and parallel HEVs, an analysis made feasible only with computer simulation. These tests showed that the best-designed parallel vehicles got 24 percent better gas mileage than conventional cars, surpassing its series counterpart by 4 percent.

ADVISOR has been well-validated at NREL and at a number of universities that use the simulator in their HEV design programs. ADVISOR's findings generally have fallen within 2 to 4 percent of actual measurements on HEV prototypes. A validation study at

Virginia Tech in 1997 found that "the validation process shows that ADVISOR has extensive values as a simulation tool for HEVs."

Forward-Looking Design


Software engineers at SwRI began looking for a way to take HEV development beyond steady-state, backward-looking models like ADVISOR, and offer a dynamic environment for designing, testing, and proving their ideas without hardware prototypes. SwRI used Simulink to put together modular component libraries of engines, vehicles, mechanical couplings, driveline components, energy storage devices, and a number of other HEV essentials.

At the direction of The United States Council for Automotive Research (USCAR) — a legalized consortium of Ford, General Motors, and Chrysler — SwRI used those libraries as the foundation for their PNGV Analysis Toolkit. Participants in the PNGV since its inception, engineers in SwRI's Engine and Vehicle Research Division, were familiar with most of the widely used HEV simulators, including Simple-V and ADVISOR. SwRI chose MATLAB and Simulink for their PNGV Analysis Toolkit because of programming efficiency, Simulink's self-documenting feature, and customer familiarity with the software.

Both the PNGV Toolkit's GUIs and the block diagrams go beyond simple choices of components, and require detailed descriptions of the components' performance values, allowing the HEV's subsystems to be tested. According to Ashok Nedungadi of SwRI, despite the dense models, the use of MATLAB GUIs "allows a novice to use the tool."

The PNGV Analysis Toolkit is being used to evaluate new drivetrain options, test and debug control strategies, size and specify sub-components, and evaluate software and hardware modifications. USCAR now owns the software. Its members, who are engineers at the Big Three auto makers, will now be using the PNGV Toolkit to develop HEVs that meet PNGV's goals. Michaels agreed that new, dynamic, forward-looking simulators offer the best chance for both fine-tuning HEV components and designing and testing control strategies between them.

For more information, contact The MathWorks at 24 Prime Park Way, Natick, MA 01760; Tel: 508-647-7000; Fax: 508-647-7101; e-mail: info@mathworks.com; www.mathworks.com.



For prototypes and short runs, take the express!

Introducing Ren Shape-Express™ Moldmaking System

A revolutionary new composite board for short run and prototype injection molds.

Ciba Specialty Chemicals has developed Ren Shape-Express™ Moldmaking System (patent pending) — a composite tooling board that combines high-speed machinability with excellent pressure and temperature resistance. The board is suitable for short-run and prototype injection molding applications. Beta test sites are proving that lot sizes of hundreds (and more) of parts can be shot from a single mold.

It can be machined with conventional CNC equipment at high feed rates and fast spindle speeds. It also helps eliminate cutter marks and reduce benchworking. Produce core and cavity injection mold inserts in a fraction of the time of machining metals.



Ren Shape-Express™ Moldmaking System can accommodate the processing of a wide range of plastics — from polyolefins and engineering thermoplastics to glass and mineral-filled resins.

Start saving time and money with Ren Shape-Express™ Moldmaking System. Call today for more information.

50 Years
of Ren® Tooling

For more information contact:



Ciba Specialty Chemicals
Adhesives & Tooling

4917 Dawn Avenue
East Lansing, MI 48823
Tel: 800-955-5509
Fax: 517-324-1475

Turning Information into Knowledge

IBM and Enovia Build a Corporate Knowledge Base

The need for today's corporations to innovate is becoming increasingly critical to their survival as competition increases globally. Delivering products with a consistent level of quality and in an efficient manner might ensure positive revenue, but it does not ensure the maintenance or growth of market share. With an increasing number of competitors — which employ the latest technologies to ensure manufacturing efficiency — revenue growth can occur most rapidly by increasing the size of existing markets. Increasing market size and market share can be ensured by consistently launching products that are dynamic, fresh, and desirable.

Core objectives for a corporation include not only reducing the cost of developing new products, but also increasing the speed with which new products can be brought into existing markets. Launching new products quickly requires an environment that facilitates cost reduction, and encourages and supports innovation.

Significant progress has been made in reducing product development costs. Use of modern computer-aided design (CAD) tools has allowed design engineers to more efficiently create a detailed product definition. With digital mock-up technologies, product designs can be validated before cutting any metal. Similarly, implementation of




Figure 1. Traditional product development lifecycles require substantial data conversion and interpretation.

product data management technology has enabled increased access to product information.

This progress, however, has focused on the production engine within a business rather than on the innovation engine. Even though CAD systems enable designers to create information faster, the number of new products a company can create is constrained by business processes and other systems.

For example, designers often are not able to view manufacturing constraints and the impact of these constraints on their design efforts. Thus, though parts of the process may be automated and supported by digital data, the overall process, which involves other departments within the organization, does not function smoothly or efficiently. As a result, the time required for analysis and justification of new products constrains

the number of new products that can be introduced in a given period of time.

Innovation Requires Change

Today's serial development processes generate and utilize large amounts of product information, but prevent corporations from developing product knowledge. Serial development processes consist of several sequential stages, each of which uses information from the previous stage, and generates information to be used in subsequent stages. Between each stage, information must be transferred to other people and departments, re-interpreted, and converted into a format expected by that department. The data conversion and interpretation comprise a significant portion of the time consumed by the product development process.




Figure 2. CAD, PDM, and ERP all contribute during different phases of product development.

Does Your RP Service Bureau Measure Up?

The measure of an exceptional rapid prototyping service bureau encompasses more than consistent dimensional accuracy. At Solid Concepts, you can also count on fast turnaround and competitive pricing.

- Rapid Prototypes
- Urethane Castings
- Casting Patterns
- CNC Machined Prototypes
- CNC Tooling
- Injection Molding

Behind Solid Concepts' value added is our unparalleled depth of expertise, which helps to ensure precision, accuracy and uncompromising quality—all at very competitive prices.

To see for yourself how we measure up, why not let us quote on your next project? It's easy — just e-mail your data to quotes@solidconcepts.com, call us toll-free at 1-888-765-4388, or visit us at <http://www.solidconcepts.com>.

SOLID CONCEPTS

Solid Concepts • 28231 Avenue Crocker • Unit #10 • Valencia • CA • 91355 • 805 • 257 • 9300 • Fax • 805 • 257 • 9311

CAD and other tools support product definition and enable more rapid transformation from one format to another. Product data management (PDM) provides a single location from which to access information, thus minimizing time consumed by data transfer. Enterprise resource planning (ERP) systems integrate data and processes associated with manufacturing planning and assembly of the product. These technologies contribute more strongly during different portions of the product development process towards compressing the product lifecycle. Despite their benefits, they do not eliminate the re-interpretation required by various departments involved in a serial development process, and do not encourage parallel development activities.

To maximize compression of the product development lifecycle, companies must not only represent product data in digital format, but they must also ensure that multiple departments can interpret the information easily and unambiguously. Secondly, they must re-architect their product development process to allow multiple disciplines to not only access product knowledge at any point in the process, but to productively utilize that knowledge to progress their portion of the overall product development lifecycle. This activity can be undertaken with a consolidated focus on the drivers that have the greatest bearing on reducing cycle time and cost of creating new products, while more efficiently employing available resources. For example, allowing the design, analysis, manufacturing, and maintenance disciplines to define their respective deliverables in concert would have an enormous bearing on the overall cycle time by consolidating the influence each of these disciplines has on the product itself.

A New Era

Today, the tools exist to define product information so that it can be utilized by all disciplines involved in the product development process at any time during that process. Successful utilization of these tools requires working in a new way. First, companies must define product information in a context within which multiple disciplines can access it and utilize it productively. In this form, it becomes corporate knowledge. Secondly, companies must design processes so that participants can perform their roles in the product development process without the need for completely mature information. This allows departments to work in parallel. As

information matures, each department revises its work, if necessary, based upon any new information.

The tools for collecting, storing, organizing, managing, and giving access to product and process knowledge make up a new environment referred to as Virtual Product Development Management (VPDM).

This type of corporate transformation represents a significant paradigm shift. Product development processes have evolved over decades; changing them, even slowly, is difficult. By automating tasks and allowing enterprise information sharing, CAD and PDM systems deliver significant reductions in cycle time. But to move to the next level of competitiveness through product innovation, companies must think about product development in a new way.

The Corporate Knowledge Base

The core concept lies in focusing the product, resource, and process modeling environments to foster communication. Multiple disciplines must be able to work in parallel, accessing and utilizing information from a corporate knowledge base. This knowledge base will contain an entire product definition, includ-

design that occur early in the design cycle are orders of magnitude less expensive than those made after the product is released. Moreover, the design is able to mature more quickly, compressing traditional product development processes.

Providing the Answer

To create collaborative, innovative design environments, companies must think about product development in a new way. They also require specific tools that enable creation and accumulation of product knowledge.

ENOVIAVPM is a software solution that addresses the needs of companies wanting to increase the size of their markets by developing innovative products faster. The primary objective of ENOVIAVPM is to optimize end-to-end development of competitive and innovative products — in effect, to create better products.

To optimize products and processes, ENOVIAVPM provides a high degree of collaboration. This includes simultaneously defining, configuring, and optimizing product definition, manufacturing process, and product operations, and propagating changes consistently through the entire product and process

and maintenance instructions;

- Action flow mechanism tailored to facilitate communication and control, especially during phases of the product development cycle where a large quantity of change occurs;
- Maturity management capability, better suited to promote controlled data sharing in a concurrent design and product development environment;
- Publish and subscribe capability, which enables individuals to pull information passively, and subsequently automate responses accordingly;
- Technical publication applications, which allow maturity, versioning, configuration management, and generation capabilities to documents at the paragraph level. This capability is particularly useful for specifications, assembly instructions, published bills of material, and maintenance operations.

Bringing It All Together

Software alone is rarely sufficient to deliver substantial corporate-wide benefits, especially given the paradigm shift required to fully leverage the power of ENOVIAVPM. To prepare the organization for effective utilization of a tool such as ENOVIAVPM, a company must first examine business objectives to ensure that increasing market size is the proper goal. Secondly, a company must analyze existing processes to determine where process linkages between departments are weak. Next, these processes must be re-engineered to ensure that multiple disciplines can interact to simultaneously define and simulate a product. Finally, the proper tools must be implemented, along with other required complementary products, such as network management, load balancing, and backup and archive. All of these tools must be integrated carefully with legacy applications in a manner that does not disrupt normal day-to-day operations.

These steps will enable a company to realize the tremendous benefits that can be derived from improving its ability to innovate. IBM and ENOVIA can help a company not only start its innovation engine, but bridge the gap between its innovation and production capabilities. The resulting environment encourages involvement from all disciplines in the entire product development process.

This article was written by Steve Shoaf, IBM PDM II Solutions Manager, North America. For more information, contact ENOVIA Corporation, Charlotte, NC, at 877-ENOVIA2 or 704-944-8888; www.enovia.com.




Figure 3. A knowledge-based environment in which multiple disciplines interact to define a product and how it will be manufactured facilitates innovation and compresses the product development lifecycle.

ing processes required to build the product, as well as plant designs for the factories in which manufacturing will take place. The traditional handoff of data no longer will be necessary, nor will the data conversion and re-interpretation that typically accompany them.

Because downstream disciplines can define information before designs are complete, design engineers can utilize this information to perform intelligent product simulations. They can understand performance, manufacturing processes, and maintainability constraints, all of which are relevant to the initial product design. Changes to the

definition. To capture and access knowledge during the product development process, ENOVIAVPM manages product information such as features and relationships generated by tools such as assembly and configuration modelers.

ENOVIAVPM achieves these objectives by delivering the following capabilities:

- A data model uniquely tailored to properly model and represent a virtual product definition;
- Generic configuration management capability, which can co-configure a large cross-section of data, from specifications to technological links, dependencies, and manufacturing

3D Tool for Modeling Early-Stage Designs

An innovative method makes possible low-cost "rough-draft" models at early stages of the design process.

Z Corporation, Somerville, Massachusetts

The allure of a convenient method to quickly produce low-cost concept models is powerful. Such a method could not only replace existing modeling techniques but would offer a means to make many more models than ever before and thus would foster creativity and innovation. The problem is that most of the conventional methods as well as the so-called "rapid prototyping" tools do not address the needs of the early stages of the product development process.

A 3D modeling tool should be useful at the earliest stages of design and allow for many "rough draft" designs. Many iterations of any proposed design will ideally be seen only by the designer, before he or she is ready to have the design critiqued by others. In order for this tool to be practical, it must be easy enough to use that the designer has the luxury of making a model just for a quick look.

It must be fast enough to fit within the existing design process—for example, a designer must be able to print a model during a one-hour lunch. To deliver on speed, the system must also be easily accessible to the designer. If the part can be produced in one hour, but must be made at a remote location and delivered, the first advantage does little good.

The models must be cheap: the majority may have extremely short lives before ending up in the trash. This means that the total cost per model, including capital cost, materials, and maintenance, must be low enough that the designer is not inhibited from making twenty or so iterative design models on a given project.

Finally, if this model is to serve as the basis for a decision, it must also accurately represent the design. The importance of the ability to build complex geometries, such as undercuts, over-

hangs, cores, and inner passages, is obvious. The designer needs to evaluate the actual design, not a simplification resulting from the limitations of the fabrication method.

Based on these criteria—speed, cost, ease of use, and the ability to fabricate complex geometries—nearly every modeling technique fails the test. Conventional model-making methods such as cutting of foam core, molding of clay, or handwork of wood are very time-consuming, especially when the communication with their remote location is taken into account. They are labor-intensive and hence inherently expensive.

Finally, all these methods are limited in the types of geometries that can be made. CNC machining is neither simple to use nor fast enough to be practical for early-stage concept models; it also requires the designer to interface with a shop group in a distant location with its own backlog of work. In addition, the types of geometries that can be made via CNC are extremely limited.

Most rapid prototyping systems are not rapid at all. Furthermore, the equipment and materials are generally exceedingly expensive, while the systems are difficult to use and most are not office-compatible. While rapid prototyping provides true CAD design verification, since the digital data is used directly to fabricate the model, many techniques use support structures which render true model representation impossible.


While the gap between the potential of iterative modeling and the reality of the tools available seems daunting, there is a new technology that is able to cross this chasm. It is a very fast, inexpensive, and surprisingly simple tool which can build complex three-dimensional objects directly from a CAD file.

Z Corporation has commercialized a technology that radically streamlines the process of building three-dimensional models automatically from CAD files. The Z402™ system, based on the Massachusetts Institute of Technology's patented 3DP™ technology, is an affordable 3D printer. The system builds parts out of a starch-based powder and aqueous binder in an office environment, thereby providing engineers, marketers, and manufacturers a means to communicate and improve designs in three dimensions instead of on a flat screen or paper. The Z402 system is about 10-20 times faster than any competing rapid prototyping technology, making it a powerful tool for reducing the time required to bring a new product from conceptualization to market. For example, the build time for a part with dimensions of 8" × 4" × 1.5" is about 45 minutes.


In addition to its speed, which has set a new standard in the rapid prototyping industry, the Z402 system is surprisingly inexpensive to operate: the equipment (with software) sells for \$59,000, and the materials generally total less than a dollar per cubic inch of part, and often as little as 50 cents.

Finally, the Z402 system has the ability to produce complex geometries with no supports, since all stressed elements have support from unbound powder until fully cured. This allows for the building of parts that would be impossible on other systems. The maximum part size is 8" × 10" × 8". The machine size is 29" × 36" × 42" high, and it weighs 300 pounds.


The designer must first export the design from the 3D CAD system into the STL file format. STL is the *de facto* standard file format for all rapid prototyping equipment and approximates the surface of the solid model by covering it with a multitude of small trian-




Step 1: As it traverses left to right, the roller collects powder.



Step 2: The roller spreads a thin layer of powder over the build piston.



Step 3: The roller discharges excess powder down the powder overflow chute.



Step 4: As it traverses right to left, the print assembly prints the part cross-section.

gles. Ideally, to make a good rapid prototyping model, the STL file must be made from a watertight solid model. The biggest drawback of the STL format is the magnitude of the file sizes generated, which slows down computer time and uses a lot of memory and disk space. This can be minimized by reducing the number of triangles generated, *i.e.*, increasing their size and therefore reducing the accuracy of the STL file. File-size reduction can be achieved by saving the file as Binary STL instead of ASCII STL. Binary STL is the recommended file format, although either type file can be read by the Z402 system software.

Ready to Print

The user is now ready to 3D-print the part on the Z402 system, which produces the part layer by layer from powder that is bound by a proprietary liquid binder. Minimal training on hardware and software is needed to operate the system. The user first fills the machine with powder, and then imports the STL file into the Z402 system software, a Windows™-based application that can run on a standard (\$1500) Pentium PC. The Z402 system software slices the STL file into cross-sections that can be anywhere between 0.005" and 0.010" thick. The user, in selecting the layer thickness, makes a tradeoff between resolution (stair-stepping) and print speed.

The Z402 system then prints these cross-sections one after another from the bottom of the design to the top. Inside the Z402 machine there are two pistons, as shown in the diagram. The feed piston is on the left and is shown in the 'down' position filled with powder. The build piston is the piston on the right, shown in the 'up' position. Also represented in the diagram is the roller (drawn as a circle) and the print assembly (drawn as a square.)

To begin the 3D printing process, the print assembly moves to the right and spreads a layer of powder in the same thickness as the cross section to be printed. Then, as the print assembly returns to the left, the 128 jets in the Z402 binder cartridge apply a binder solution to the powder, causing the powder particles to bind to one another in the shape of the cross-section of the layer. The feed piston comes up one layer of thickness and the build piston drops one more layer of the thickness. The Z402 system then spreads a new layer of powder and repeats the process until the part is completely printed.

At this point the build box is filled with powder, some of which is loose

and some of which is bonded to form the part. The excess powder is removed with a vacuum hose and then the part is picked out from the loose powder and depowdered in a post-processing unit. The part can be infiltrated with various materials to improve its strength and surface finish. The standard method of infiltration is a quick dip in wax; however, Z Corporation recently released a new materials system that makes concept models so strong that they can support the weight of a person. Parts made with the new materials can be sanded, painted, drilled, tapped, and finished in a number of ways for even higher-quality models. The key to the new materials system is the use of ZR10 resin for infiltrating the part. The resin, which is applied by using a simple hand-held applicator, cures in 20-40 minutes, depending on the size of the part.

Very fast 3D printing allows for design verification by the designer. It also provides a means for communication between the designer and the design supervisor, or other designers working on products which will interface with each other. By providing almost instantaneous feedback on each proposed design change, the Z402 system allows the designer to make more

iterations of a design at a faster rate.

Carefree 3D printing improves communication with the marketing department and can provide feedback from potential customers at a stage in the design cycle when changes are inexpensive and easy to implement.

Finally, 3D printing early in the design cycle also provides improved communication with the manufacturing group, which results in early detection of flaws and improved design for manufacturing.

The Z402 system can transform 3D modeling into an indispensable, everyday adjunct to the inherently limited 2D visualization provided by computer screens and printouts. The Z402 system will improve part visualization and communications while enhancing creativity and reducing the number of design flaws. Z Corp. can be found on the Internet at www.zcorp.com.

For more information, please contact the author of this brief, Marina Hatsopoulos, at Z Corp., 35 Medford St., Suite 213, Somerville, MA 02143; (617) 628-2781; fax: (617) 628-2879; E-mail: marina@zcorp.com; www.zcorp.com. Z402 is a trademark of Z Corporation. 3DP is a trademark of the Massachusetts Institute of Technology. Windows is a trademark of the Microsoft Corporation.

Now You Can Access Past Issues of...

Rapid Product Development

Online at www.nasatech.com

NASA Tech Briefs' official web site also features exclusive NASA Technical Support Packages, searchable tech brief articles, NASA and industry news, a supplier directory, online reader service, and much more...updated daily and free of charge.




www.nasatech.com



NEW PRODUCTS

Software Estimates Part Cost

Boothroyd Dewhurst, Wakefield, RI, has released DFM Concurrent Costing software, which analyzes a range of manufacturing processes, including hot forging, cold or hot die casting, powder metal processing, sand casting, and investment casting, allowing engineers to estimate the cost of producing a part. It provides information on manufacturing and material selection, and can be used at both the concept stage and during design decisions, providing a means for exploring alternative design strategies before 3D modeling, prototyping, and other cost-intensive stages of development are reached. A library of secondary operations includes information on finish machining, deburring, surface treatment, and packaging. **Circle No. 740**



Spray Coatings for Tooling

General Magnaplate Corp., Linden, NJ, offers Plasmatize® 2139, a series of thermal spray release coatings for metallic and non-metallic tooling. The coatings are designed to replace toxic silicone and other sprayed, painted, or dipped one-time release agents. The coatings eliminate the need for cleaning demolded parts. Users can select smooth or matte surfaces, and products can undergo final finishing immediately after demolding. Specific coatings are available for use on Invar and ferrous tooling, aluminum and non-ferrous tooling, fiber reinforced plastic, plaster and plastic tooling, and General Magnaplate's proprietary CMPT™ toolface. **Circle No. 742**



Part-to-CAD Inspection

The ShapeGrabber™ computer-aided inspection system for part-to-CAD verification and inspection from Vitana Corp., Gloucester, Ontario, Canada, includes a scanning head, translation stage, acquisition and inspection software, training, and a PC. The system introduces new technologies to simplify fixturing, streamline scan alignment, and reduce noise. It can scan half a million data points and produce a detailed 3D inspection report in one or two hours for a typical part. Other features include 15,360 points per second digitizing with patented laser scanning technology, 0.001" measurement accuracy, and a choice of motion platforms for parts of virtually any size. The system compares parts and tooling directly to 3D CAD files without requiring dimensional drawings. **Circle No. 746**

ware, training, and a PC. The system introduces new technologies to simplify fixturing, streamline scan alignment, and reduce noise. It can scan half a million data points and produce a detailed 3D inspection report in one or two hours for a typical part. Other features include 15,360 points per second digitizing with patented laser scanning technology, 0.001" measurement accuracy, and a choice of motion platforms for parts of virtually any size. The system compares parts and tooling directly to 3D CAD files without requiring dimensional drawings. **Circle No. 746**

Vision Gauge System

The Vision Gauge System from Diversified Engineering & Manufacturing, Orange, CT, is a non-contact optical measuring sensor and controller used to measure or guide product that is produced in a continuous process flow, up to a thickness (diameter) of one inch. The integrated, standalone, measurement/observation/monitoring (MOM) device allows the measurement of width, thickness, diameter, edge, or gap gauge of either opaque or transparent materials. Position or thickness can be monitored down to 0.0002" as the material flows through the system. It features a 5000-pixel CCD linear image sensor with optics and light source in one package. The processed material is passed through the optical window area of the U-shaped frame, where the measurement occurs. A controller provides numeric and bar graph LED monitoring. **Circle No. 744**



Solid Modeling and Machining

CNC Software, Tolland, CT, has released a new version of Mastercam® Solids hybrid solid modeling software that can be used with Mastercam Mill to provide integrated solid modeling and machining. Based on the Parasolid kernel, the software includes functions such as solid body construction, automated filleting and chamfering, thin-wall creation and shelling, and volumetric data. When added to Mastercam Mill, the software allows users to create and machine solids, surfaces, and wireframes, and program multiple types of data as a single model. Users can import Parasolid files as true solids; built-in translators for IGES, VDA, DXF, CADL, STL, and ASCII are included. **Circle No. 733**



Design Automation Software

POINTER design automation software from Synaps, Atlanta, GA, is a multi-platform design and analysis program that performs nonlinear, multidimensional constrained optimization, and automates the selection process or path to find the best solution for cost-effective product design. Features include three search algorithms: genetic algorithm, downhill simplex, and gradient; an automated training feature; and the ability to link the program to existing executables. The software is designed to exploit flaws in the user's analysis, allowing logical errors to be found and eliminated. **Circle No. 741**

PCB Design Software

PADS Software, Marlborough, MA, offers PADS-PowerPCB 3.0 interconnect software, which enables users to complete complex PCB designs. The software allows electronics manufacturers to speed time-to-volume production. Enhancements include Intelligent Attribute Definition and Control, which provides the ability to intelligently integrate with enterprise resource planning (ERP), manufacturing resource planning (MRP), and product data management (PDM) systems. OLE Automation allows users direct database access with no translation required. Other features include automatic assignment of alphanumeric pins, lock-protect nets, and enhancements to copper pour and test point rules flexibility. **Circle No. 747**

Mold Base Creator

Toolbox/MB for SolidWorks 98Plus from Cimlogic, Nashua, NH, allows SolidWorks users to create mold bases as constrained assemblies. The add-on is fully integrated with SolidWorks 98Plus, and supports the DME A and B series. The software creates complete assemblies in four picks, and includes components such as core pins, ejector pins, A and B plates, dowel pins, locating rings, and bushings. Built-in design tools help users add ejector pins and support pillars. **Circle No. 748**



CAD Software

DATACAD LLC, Avon, CT, has released DataCAD 8.05.01 for Windows 95/98/NT, an updated version of its 32-bit CAD software for 2D/3D applications. The enhanced version provides improved visualization capabilities and new options for customizing the user interface and hardcopy output. Users can map drawing line color to printed line width, density, and color directly from DataCAD using the new Pen Table dialog. An enhanced QuickShader feature provides lighting intensity controls and background color settings. The Drawing Window can be saved as a bitmap image for use in technical presentations. **Circle No. 743**



Single-Crystal YAG Reinforcement Preforms for Refractory Composites

Preforms can be made in net size and shape, with tailored orientation of fibers.

John H. Glenn Research Center, Cleveland, Ohio

Preforms (essentially, shaped mats) of single-crystal yttrium aluminum garnet (YAG) fibers can now be readily fabricated in net size and shape, with tailored orientation of the fibers. These preforms can be used as fiber reinforcements in ceramic- and metal-matrix composite materials that withstand temperatures as high as 1,700 °C. The development of these preforms and composites is a continuing effort in conjunction with other efforts to develop lightweight components for aircraft turbine engines.

The single-crystal form of YAG is needed for creep resistance; the polycrystalline forms of YAG and other oxide fiber materials do not resist creep adequately at the contemplated high operating temperatures. It would be expensive and impractical to construct preforms by weaving, braiding, or laminating premanufactured single-crystal fibers, and handling of the fibers during such construction would weaken them.

A proprietary process is being developed to overcome the above-mentioned limitations. In this process, reinforcement preforms are formed to net-shape, eliminating the need for operations such as weaving and braiding of single filaments. The net-shape preforms can have random, oriented, or mixed reinforcement in selective areas. Reinforcement volume-fraction shape and orientation can be controlled. Thin complex parts such as airfoils can be fabricated. Single-crystal porous preforms with vol-

ume percent in the range of 30 to 54 percent and strut dimensions in the range of 10 to 125 micrometers have been produced.

Figure 1 shows a scanning electron micrograph of porous single-crystal YAG reinforcement. Figure 2 shows a Laue x-ray diffraction pattern from this porous YAG preform. The Laue x-ray pattern is characteristic of single-crystal YAG, thus proving its single-crystal nature. High

magnification microscopy indicated the absence of grain boundaries and confirmed the single-crystal nature. Reinforcement preforms with random, unidirectional and [0/90] reinforcement have been fabricated so far. Sufficient permeability of the preforms was demonstrated by conducting infiltration of the preform by polymer and metal matrices by pressure infiltration. Work is underway to optimize the preform rein-




Figure 1. A Scanning Electron Micrograph shows a random porous single-crystal YAG.

An \$1,800



Value!

Visit www.spiralock.com

**You Could Be An Instant Winner
Of A Trek® Bike!**

RUGGED PORTABLE COMPUTER

Power to go!




Using cutting edge technology, ITTools offers powerful, rugged portable systems at a surprisingly reasonable price. Whether for industrial PLC programming, data acquisition, or for power hungry engineering applications such as 3D modeling, ITTools has the right system for the job. With up to 450MHz Pentium II processors, 15.1" (actual viewing area) TFT displays and AGP graphics, it's a workstation with "power to go".

ITTools Surging into the future.

1800 Bloomsbury Ave Ocean NJ 07712 ph: 732-922-1154 fax: 732-922-3166
www.ittools.com

For More Information Circle No. 421

SHOCK & VIBRATION RECORDERS



**IST Recorders ...
Defining the
State-of-the-Art**

*Self-contained,
battery powered
field data recorders
for mechanical
measurements*

- Shock, vibration, strain, pressure, temperature, humidity
- Transportation, flight test, packaging, crash test, accident reconstruction
- 10 & 12-bit, 15 kHz digitization
- Onboard memory to 108 MB+
- Operates 30-60 days
- Windows 95 PC Setup/Analysis
- Easily interface field data to lab vibration systems for transport simulation

Measures & Records 3D Acceleration

IST

Instrumented
Sensor Technology

4704 Moore Street
Okemos, MI 48864-1722
517/349-8487 Fax: 517/349-8469
E-Mail Address: info@isthq.com
Web Site: http://www.isthq.com



For purchase or rental



Figure 2. A Back-Reflection Laue X-Ray Diffraction Pattern from the pre-form in Figure 1 confirms its single-crystal nature.

forcing efficiency and infiltration with ceramic and inter-metallic matrices.

Porous single crystals made by this proprietary approach also have applications such as selective emitters, filters, and photonic band-gap materials due to their unique physical properties. Porous single crystals of sapphire, YAG, eutectic YAG, doped sapphire, and ytterbia have been fabricated by this process and potential exists for fabricating porous single crystals of many other materials.

This work was done by Prashant G. Karandikar, Ronald Roy, and Uday Kashalikar of Foster-Miller, Inc., for John H. Glenn Research Center.

Inquiries concerning rights for the commercial use of this invention should be addressed to John H. Glenn Research Center, Commercial Technology Office, Attn: Steve Fedor, Mail Stop 4-8, 21000 Brookpark Road, Cleveland, Ohio 44135. Refer to LEW-16665.

Computing Chemical Kinetics With Low-Dimensional Manifolds

This method can be used to predict the concentration of NO_x in combustion exhaust.

John H. Glenn Research Center, Cleveland, Ohio

A method of computing the concentrations of chemical species in chemically reacting flows includes, among other things, utilization of a prior chemical-kinetic method based on a concept of intrinsic low-dimensional manifolds (ILDM) in composition space. The present method is particularly suitable for predicting concentrations of nitrogen oxides (NO_x)

Case Number	Predicted Concentration, Parts Per Million	Measured Concentration, Parts Per Million
1	20.5	21.6 to 26.5
2	6.9	10.6
3	4.9	12.0
4	13.9	3.1
5	28.5	35.1

Concentrations of NO_x as predicted by the present method approximated those measured in experiments in five test cases of combustion of hydrogen jets injected radially into a can downstream of an air inlet. The differences between predicted and experimental values for cases 2 through 5 should be analyzed with caution because the CFD computations for those cases were not carried out to full convergence.

generated in the combustion of hydrocarbon fuels in flows simulated by techniques of computational fluid dynamics (CFD).

The composition of a chemical system can be regarded as a point in composition space, which is a multidimensional space in which each dimension represents the concentration of one of the chemical species present. The chemical-kinetic rate equations of the system can be regarded as representing how the composition point moves in the space. In a typical case, the composition changes much more rapidly in some dimensions than in others, so that the composition point can be regarded as (1) first moving rapidly toward an attracting manifold of reduced dimensionality (for example, a surface in space of three or more dimensions), then (2) moving along the manifold toward an equilibrium point.

In the ILDM method, one identifies such a manifold, assumes that the composition always lies on the manifold, and uses the reduced dimensionality of the manifold to reduce the amount of computation needed to solve the corresponding equations of chemical kinetics. One still accounts for all of the chemical species of a complex system, but takes advantage of the simplification to parameterize the system by use of relatively few variables. In principle, the manifold can be identified once the number of its dimensions is known or assumed.

In the present method, the ILDM method is implemented by a computer code that automatically identifies a manifold on which a simplified mathematical model of a chemical system is parameterized by two variables: (1) a mixture fraction that is a function of mass fractions of species present in the system and (2) a progress variable, which can be either another function of species mass fractions, a temperature, or a Gibbs function. The only restriction on the choice of the progress variable is that this variable must be a single-valued function in the given system. The resulting species concentrations, rates, and properties are stored in look-up tables. These tables can then be used as the chemistry model in CFD calculations. By using look-up tables, the calculation of properties and reaction rates is replaced by interpolation, resulting in significant savings in central processing unit (CPU) time.

The method can also be used to post-process results of CFD simulations of reacting flows and, in particular, of flows in combustors burning hydrocarbon fuels in air. Typically, a CFD code yields


the flow velocities, temperatures, and concentrations of the major chemical species (fuel, O_2 , N_2 , H_2O , CO , and CO_2). For each node on a computational grid, the mixture fraction and progress variable can be calculated from the CFD output data. Then with the help of interpolation routines that can be called from the CFD code, the mixture fraction and progress variable can be used to obtain concentrations of such minor species as NO_x (see table). This computation amounts to a mapping procedure that can be accomplished rapidly; computations for a million nodes take only a few minutes.

This work was done by A. T. Norris of the Institute for Computational Mechanics in Propulsion for John H. Glenn Research Center. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Physical Sciences category.

Inquiries concerning rights for the commercial use of this invention should be addressed to John H. Glenn Research Center, Commercial Technology Office, Attn: Steve Fedor, Mail Stop 4-8, 21000 Brookpark Road, Cleveland, Ohio 44135. Refer to LEW-16659.

NOW YOU CAN DRIVE YOUR CAR LONGER & FARTHER THAN YOU EVER THOUGHT POSSIBLE.

HERE'S THE REASON...



- ➔ U.S. Government (National Bureau of Standards) found Tufoil for Engines has a surface friction of .029, making it the most slippery substance known to man
- ➔ Canadian Government (Kapuskasing) found that Tufoil for Engines increased cranking speed in extreme weather by nearly 10% (great news for your battery during those cold-weather starts)
- ➔ "Guinness Book of World Records" chose Tufoil as "The World's Most Efficient Lubricant." That makes Tufoil the **ONLY** engine treatment ever listed by the Guinness Book

NOTE: Tufoil does NOT rely on famous spokespersons or fancy infomercials. Our recognition comes from sources that need no introduction or compensation.

FACT: Efficient running engines use less gas, need less repair, run smoother and last longer.

FACT: Tufoil is economical to use. Just 4-ounces into the crankcase at each oil change can actually "double the life of your engine." (Ask about our "Quarter-Million Mile Club")

FACT: Tufoil has been tested against most of the major engine treatments on the market (Call for the FREE report)

Call 1-800-922-0075 to ORDER

Data Acquisition & Control Made Easy

3-Step System

Step #1

Select Boards To Perform Your Application:

A/D D/A Converters

Digital I/O Board

Counter/Timer Board

Optical Isolator Bd.

Prototype Boards

\$35 - \$125 / Board

Step #2

Select Application Style:

Style #A

TMCPort

(Up To 7 Bds.)



Style #B


Mezzanine

(Up To 16 Bds.)



Step #3

Connect PC's Parallel Port Cable To LPTek's Interface Bd.



LPTek Corp.

Computer I/O instrumentation.

1100 Shames Drive
Westbury, NY 11590-1746 USA
Tel #: 516-333-8820
Fax #: 516-333-8814
E-mail: sales@lptek.com

www.lptek.com

Quadrupole Mass Analyzer Based on Linear Ion Trap

Size, mass, and power consumption would be reduced, relative to traditional QMAs.

NASA's Jet Propulsion Laboratory, Pasadena, California

An improved quadrupole mass analyzer (QMA) has been proposed for use in determining the compositions of gas mixtures. The proposed QMA would incorporate two major innovations over traditional QMAs: (1) It would feature a simplified radio-frequency-excited quadrupole electrode structure that would be smaller, weigh less, and consume less power, relative to the quadrupole electrode structure of the corresponding traditional QMA; and (2) It would include dc end electrodes that would enable it to function as either a traditional transmission-mode mass spectrometer or an ion-trap mass spectrometer (ITMS).


The figure illustrates the proposed quadrupole electrode configuration and the corresponding traditional configuration, both designed for an inner radius r_0 . In the traditional configuration, the outer cylindrical electrode is grounded, while a radio-frequency signal of amplitude V_0 is applied in opposite polarities to successive rod electrodes at 90° angular intervals. The radius of the quadrupole electrodes ($1.1468r_0$) and the radius of the outer shielding electrode ($3.54r_0$) are chosen to eliminate a sixth-order departure from the ideal quadrupolar electric potential and thereby obtain a close approximation to the ideal quadrupolar electric field.

The proposed quadrupole electrodes would be made from a single, precisely machined hollow cylinder cut lengthwise into eight sectors with alternating angular widths of 30° and 60° . The 30° sectors

would be electrically grounded, while the radio-frequency signal of amplitude V_0 would be applied in opposite polarities to successive 60° sectors. This configuration would also eliminate the sixth-order departure from the ideal quadrupolar potential, yielding a similar close approximation to the ideal quadrupolar electric field. A simple comparison of overall radii shows that the cross-sectional area of the proposed QMA would be less than $1/10$ that of the traditional QMA. If the proposed and traditional QMAs were of the same length, then the proposed QMA could be made to weigh about $1/10$ as much.

Further analysis of the electric fields reveals that the proposed QMA could achieve the same stability parameters as does the traditional QMA at an excitation voltage about 10 percent smaller, and that the capacitance of the proposed QMA would be about $1/4$ that of the traditional QMA. As a result, the energy stored in the electric field of the proposed QMA would be only about $1/5$ that of the traditional QMA. As a further result, if the resonance quality factors of the excitation circuits were the same in both cases, the proposed QMA would consume only about $1/5$ the power of the traditional QMA.

The ITMS version of the proposed QMA would be based on a linear ion trap, in which the trapping volume would be roughly a cylinder of length L and small characteristic radius R about the axis of symmetry. In contrast, a traditional ITMS is based on a point-node ion trap, in



The Proposed QMA Electrodes would feature reduced cross section and power consumption, relative to the corresponding traditional QMA electrodes.

which the trapping volume is roughly a sphere of radius R . Thus, the trapping volume of the proposed ITMS version would be about $3L/4R$ times that of a traditional ITMS. One could choose the dimensions of the electrodes to obtain $L \gg R$, such that the trapping volume of the proposed ITMS version would be 100 to 1,000 times the volume of the corresponding traditional ITMS; the number of ions generated and trapped would be increased accordingly.

This work was done by John D. Prestage of Caltech for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Physical Sciences category.

In accordance with Public Law 96-517, the contractor has elected to retain title to this invention. Inquiries concerning rights for its commercial use should be addressed to

*Technology Reporting Office
JPL
Mail Stop 122-116
4800 Oak Grove Drive
Pasadena, CA 91109
(818) 354-2240*

Refer to NPO-20011, volume and number of this NASA Tech Briefs issue, and the page number.

Inflatable Membrane Reflectors for Multiple-Purpose Applications


Attention to details of design and modeling could result in fairly precise surfaces.

NASA's Jet Propulsion Laboratory, Pasadena, California

Experiments have demonstrated the feasibility of inflatable reflectors with very low system aerial densities of the order of 1 kg/m². Diverse applications include radio and optical communications, telescopes, and the concentration of sunlight for power generation. The same technology can be used for structural beams in single or multiple layers with excellent rigidity. Development work thus far has focused on potential uses in outer space, but inflatable rigidized structural elements are suitable for terrestrial applications where large lightweight surfaces and structures are needed.

The basic concept of an inflatable reflector is simple: stretch a membrane beyond its elastic limit by using a combined mechanical tensioning and pressure. The shape the resulting surface takes is a good approximation to an ellipse with higher order correction terms. The shape can be modified by changing the boundary, the pressure, or the membrane material. A change in area of approximately 1 percent is required to plastically deform the membrane into the desired shape. After forming, the pressure is released with the resulting surface being a self-supporting membrane reflector. For imaging applications, the aberrations induced by the membrane reflector could be compensated for by secondary and tertiary optics. The design problem is to choose the membrane material and boundary conditions to obtain the desired reflector shape.

The figure shows an experimental apparatus on which a stainless steel membrane is stretched across a circular boundary and pressurized to deform it into a curved mirror.



A Stainless Steel Membrane is stretched across a circular boundary and pressurized to deform it into a curved mirror.

mirror in the far-infrared or submillimeter wavelengths (measured surface 8 micrometers root-mean square [RMS] over the central 40 cm of the membrane). The global surface figure can be adjusted by changing the pressure, the stretching forces, or the boundary over which the membrane is stretched.

This work was done by Neville Marzwell of Caltech and Mark Dragovan of the Fermi Institute, University of Chicago, for NASA's Jet Propulsion Laboratory. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Physical Sciences category.
NPO-20359

Paroscientific, Inc. DigiQuartz® Pressure Instrumentation

Features:

- **0.01% Accuracy**
- 1×10^{-8} Resolution
- Digital Output Signal
- Environmentally Rugged
- High Reliability & Stability
- ISO 9001 Quality System
- 5 Year Extended Warranty

Products:

- Barometers
- Transducers
- Transmitters
- Depth Sensors
- Portable Standards
- Fiber-Optic Systems
- Water Stage Sensors
- Meteorological Systems

4500 148th N.E., Redmond, WA 98052

Tel: (425) 883-8700 Fax: (425) 867-5407

Internet: <http://www.paroscientific.com>



Books & Reports

Active Homopolar Magnetic Bearing

A report presents information on an earlier work on active magnetic bearings with high-critical-temperature superconducting coils. To recapitulate, the device is a homopolar radial-type active magnetic bearing with a bias coil and control coils made of a high-critical-temperature superconductor. The report discusses

major features of the design and operation of the bias and control coils, measurements of ac power losses in the control coils, and results of experiments in which the device was operated at the temperature of liquid nitrogen. The experimental findings and conclusions stated in the report are nearly identical to those noted earlier. One particularly notable conclusion is that ac losses appeared to be related to coil inductances


and that it may therefore be possible to reduce these losses by winding the control coils from twisted, multifilamentary forms of the superconductor.

This work was done by G. V. Brown, E. DiRusso, and A. J. Provenza of John H. Glenn Research Center. To obtain a copy of the report, "An Active Homopolar Magnetic Bearing With High Temperature Superconductor Coils and Ferromagnetic Cores," access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Machinery/Automation category.

Inquiries concerning rights for the commercial use of this invention should be addressed to John H. Glenn Research Center, Commercial Technology Office, Attn: Steve Fedor, Mail Stop 4-8, 21000 Brookpark Road, Cleveland, Ohio 44135. Refer to LEW-16419.

Marketplace To Advertise — Call (212) 490-3999

DATA ACQUISITION WITH ANTI-ALIASING



Create brick-wall filters with the iDSC board.

- 16-Bit Data Acquisition
- 8 Simultaneous Inputs
- Multiple Sampling Rates
- DASYLab, LabVIEW, HP VEE
- Guaranteed Anti-Aliasing
- User-Specified Filters
- Channel-by-Channel Cutoffs
- Linear Phase Response

MICROSTAR

LABORATORIES™

888 MSTARLABS (888 678-2752)


www.mstarlabs.com ♦ info@mstarlabs.com

For More Information Circle No. 580

POSITION ACCURACY to ±0.5 arc second!

Inductosyn® transducers provide absolute or incremental position data to ±0.5 arc second (Rotary) or ±40 microinches (Linear). Resolution to 26 bits.


For brochure, call 914/761-2600 or fax 914/761-0405.



FARRAND CONTROLS
DIVISION OF RUHLE COMPANIES, INC.
99 Wall Street, Valhalla, NY 10595
www.ruhle.com

For More Information Circle No. 581

Flexible Bladders



- BLADDER TANKS & AIR CELLS
- DIAPHRAGMS & ACTUATORS
- BELLOWES & FUEL CELLS
- STRESS TEST BLADDERS
- CUSTOM INFLATABLES
- PNEUMATIC / HYDRAULIC PRESSES

AERO TEC 800-526-5330

AERO TEC LABORATORIES INC.

RAMSEY, NJ 07446-1251 USA
TEL: 201-825-1400 • FAX: 201-825-1962
e-Mail aerotec@cybernex.net
<http://www.atlinc.com>

For More Information Circle No. 582

MICRONIC DIAMETER METAL FIBERS



Bekaert metal fibers are available in a variety of alloys, diameters, fiber forms and fabrics. They are proven performers in a number of advanced technology applications. These applications include, but are not limited to, the following: polymer and hot gas filtration, EMI/RFI shielding, conductive textiles and plastics, air bag systems, magnetic separation, gas burners, glass forming, nickel electrode substrates, wound cartridge filters as well as conductive coatings and adhesives.

Bekaert Fibre Technologies.
1-800-241-4126

For More Information Circle No. 583

Properties of Cubic Boron Nitride Films

A report describes an experimental study of the surface-chemical, microstructural, and tribological properties of cubic boron nitride (c-BN) films, which are potentially useful as hard, wear-resistant coatings on bearings and on steel-cutting tools. For the experiments, BN films about 500 nm thick were synthesized by magnetically enhanced plasma ion plating onto titanium interlayers on mirror-finish silicon substrates. The films were characterized by x-ray photoelectron spectroscopy, transmission electron microscopy, electron diffraction, Fourier-transform infrared spectroscopy, atomic-force microscopy, and surface profilometry.

This work was done by Donald R. Wheeler, Phillip B. Abel, Kenneth W. Street, and Kazuhisa Miyoshi of John H. Glenn Research Center and Shuichi Watanabe, Masao Murakawa, and Shojiro Miyake of the Nippon Institute of Technology. To obtain a copy of the report, "Surface Chemistry, Microstructure, and Tribological Properties of Cubic Boron Nitride Films," access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Materials category.

Inquiries concerning rights for the commercial use of this invention should be addressed to John H. Glenn Research Center, Commercial Technology Office, Attn: Steve Fedor, Mail Stop 4-8, 21000 Brookpark Road, Cleveland, Ohio 44135. Refer to LEW-16695.



Special Coverage: Composites & Plastics

Crimping Thin PTFE Tubes Onto Thin Stainless-Steel Tubes

Crimps prove superior to wrapped wires, flared tubes, ringed hose barbs, and the like.

John H. Glenn Research Center, Cleveland, Ohio

A crimping technique has been developed for fastening polytetrafluoroethylene (PTFE) tubes of 0.032-in. (0.81-mm) outside diameter and 0.0105-in. (0.267-mm) inside diameter onto stainless-steel hypodermic tubes of 0.0105-in. (0.267-mm) outside diameter. The technique was developed to provide lightweight connections that would not slip or leak when subjected to rapid, repeated movements.




Figure 1. The Crimping Tool is a modified pair of crimping pliers containing a hexagonal crimping die. The hexagon was chosen over other shapes because it minimizes the amount of copper extruded from the sleeve during the crimping process.

The technique is needed because connections made with such conventional means as wrapped and/or twisted wires, flared tubes, ringed hose barbs, and combinations of these eventually slip and/or leak when handled or moved repeatedly.

The development of the technique included tests that revealed that the best crimp reduction for PTFE is about 18 percent. The dimensions of the crimping sleeves and the crimping tool were chosen accordingly. The crimping sleeves were made from copper rods of 0.047-in. (1.2-mm) diameter, cut to 1/8-in. (3-mm) length, and drilled to an inside diameter of 0.033 in. (0.84 mm). The crimping tool was made by machining a pair of crimping pliers down to a thickness of about 0.100 in. (2.54 mm) and cutting a 0.038-mm (0.97-mm) hexagonal crimping die into its tip (see Figure 1).

Optionally, one can prepare the crimp area on the stainless-steel tube with a light grit blast prior to joining to improve the subsequent grip on the tube. To make a connection, one first slips the copper crimping sleeve over the PTFE tube, then inserts the stainless-steel tube

into the PTFE tube a sufficient distance to enable proper positioning of the crimping sleeve as described next. The crimping sleeve is positioned so that PTFE and stainless-steel tube segments 0.05 to 0.06 in. (1.3 to 1.5 mm) long protrude from opposite ends of the crimping sleeve. The tool is then applied to effect the crimp. Figure 2 shows a completed connection.

Limited experience thus far seems to indicate that a connection made by this technique does not leak measurably when exposed to vacuum or to pressure up to 115 psi (0.79 MPa). The technique can readily be modified, by appropriate changes in dimensions of the sleeves and tool, for PTFE and stainless-steel tubes of different diameters. Potential uses for this technique could include




Figure 2. A Crimped Connection made by the present technique grips more strongly than does a connection made by the traditional twisted-wire technique. One reason for the superiority of the present technique is that the grip is spread over a larger area.

The Leader in Advanced Composite Training

- Composite Laminate Design
- Design and Analysis of Composite Structural Joints
- Structural Analysis and Repair Design
- Advanced Composite Drawing Interpretation
- Ultrasonic Inspection of Advanced Composites

Training at our facility or yours.
Call for our complete 13-course catalog.

Abaris Training Resources, Inc.
5401 Longley Lane, Suite 49
Reno, NV 89511 USA
(775) 827-6568 • Fax: (775) 827-6599
www.abaris.com • e-mail: sc@abaris.com

(800) 638-8441

ABARIS
TRAINING

Is Jitter Hurting Your Image?



Fred Molinari,
President

Stabilize your image with our PCI frame grabbers.

Image jitter is caused by an inferior frame grabber front-end design. Our MACH Series™ of PCI frame grabbers were designed with the most accurate front end in the industry and optimized for minimal jitter.

For more information, visit our web site or call today!

www.datatranslation.com/jitter

PCI FRAME GRABBER BOARDS AND SOFTWARE

MACH Series Board	Input	Camera Interface	Jitter (Typical)	Price (US)
DT3155	Monochrome	RS-170/CCIR	±3.5 ns	\$ 695
DT3152	Monochrome	Variable scan 0-20 MHz	±2.5 ns	\$ 995
DT3152-LS	Monochrome	Line scan	±2.5 ns	\$1,295
DT3154	RGB	RGB	±2.5 ns	\$ 795
DT3153	Composite color	NTSC, CCIR, PAL	±5.5 ns	\$ 695
DT3157	Monochrome	RS-422 digital 8- to 16-bit	N/A	\$1,195
Software				Price
DT-Active Open Layers™				\$ 250
Frame Grabber SDK™				\$ 50 / \$150
HLImage++®				\$1,995

DATA TRANSLATION

BUY ONLINE! www.datatranslation.com
(800) 525-8528

joining fuel lines for gas-powered models, joining pneumatic and gas lines in general, and perhaps joining tubes in medical equipment.

This work was done by Myron M. Joseph (retired) and George J. Saad of **John H. Glenn Research Center**. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the

Manufacturing/Fabrication category.

Inquiries concerning rights for the commercial use of this invention should be addressed to John H. Glenn Research Center, Commercial Technology Office, Attn: Tech Brief Patent Status, Mail Stop 7-3, 21000 Brookpark Road, Cleveland, Ohio 44135. Refer to LEW-16689.

Polymeric Composite Damage Protective Overwraps for Composite Pressure Vessels

These overwraps would weigh less than conventional glass-fiber-based damage protective overwraps do.

NASA's Jet Propulsion Laboratory, Pasadena, California

Damage-tolerant polymeric composite overwraps have been proposed for light-weight pressure vessels that are made of composites of graphite fibers in polymeric matrices. Graphite-fiber/polymer composites are vulnerable to impact damage; overwraps on the pressure vessels help to protect against such damage.

In current practice, an overwrap is made of a composite of glass fibers in a polymeric matrix. The glass fibers are too weak to contribute significantly to the structural strength of the underlying pressure vessel, and the glass-fiber-based overwrap adds significantly to the weight of the vessel.

According to the proposal, the outer layers of a graphite-fiber/polymer pres-

sure vessel would be made of polybenzoxazole (PBO) fibers in a polymeric matrix. The PBO fibers would protect the underlying graphite/polymer composite layers against impact damage, but unlike glass fibers, the PBO fibers would be almost as structurally efficient as the graphite fibers. Layers of PBO fibers could even be used as substitutes for some of the layers of graphite fibers, in which case the overwrap would contribute very little additional weight to the vessel.

This work was done by Joseph Lewis of Caltech for NASA's Jet Propulsion Laboratory. No further documentation is available. NPO-20442

Hybrid Composite Overwraps for Low-Pressure Tanks

The weight contributed by the overwraps on the end surfaces would be reduced.

NASA's Jet Propulsion Laboratory, Pasadena, California

Hybrid versions of the high-performance overwraps used on some low-pressure tanks have been proposed. The hybrid overwraps would weigh less than do the corresponding nonhybrid overwraps, as explained below.

In current practice, the overwrap material used on all areas of a tank is a composite that contains graphite fibers. The minimum tape thickness of this overwrap material is about 0.005 to 0.007 in. (≈0.13 to 0.18 mm); consequently, the thickness of the low-angle-helical (L.A.H.) wrap on each end surface of

the tank cannot be made less than about 0.010 to 0.014 in. (≈0.25 to 0.36 mm). However, thinner L.A.H.-wrap thicknesses are needed on the ends of most tanks of this type; in such cases, the excess thicknesses of carbon-fiber-based overwraps give rise to unnecessary weight penalties.

According to the proposal, the material for the L.A.H. end wraps would be a composite based on polybenzoxazole (PBO) fibers. The minimum tape thickness of the PBO-fiber-based overwrap material would be about 0.001

in. (≈ 0.025 mm), and the strength and elastic modulus of PBO fibers is almost equal to that of graphite fibers; as a result, no weight penalty would exist for an end wrap based on PBO fibers.

Also according to the proposal, the hoop wrap on the cylindrical portion of a tank would still be made of the conventional graphite-fiber-based composite material. This would not entail an unnecessary weight penalty because the needed hoop-wrap thickness is greater than the minimum graphite-fiber tape thickness.

This work was done by Joseph C. Lewis of Caltech for NASA's Jet Propulsion Laboratory. No further documentation is available. NPO-20443

Integrally Wound Skirt for Composite-Overwrapped Tank

Strength would be increased and weight reduced.

NASA's Jet Propulsion Laboratory, Pasadena, California

The skirt that supports a composite-overwrapped tank would be made an integral part of the composite overwrap, according to a proposal. In current practice, the structure that supports a composite-overwrap tank usually includes a layer of rubber between the tank and its skirt. The rubber layer is heavy and constitutes a relatively weak link in the tank-supporting structure.

The proposal arose from an investigation of how to reduce the weight of the tank and its supporting structure, considering the tank as part of an overall tank/structure system. The investigation revealed that elimination of the rubber layer could reduce the weight of the system considerably.

The fiber reinforcement in the skirt would be filament wound directly onto the tank, without an intervening layer of rubber. The weight of the tank/structure system would be reduced and the strength of the skirt/tank bond increased accordingly, and the skirt would bear part of the hoop stress of the tank.

This work was done by Joseph C. Lewis of Caltech for NASA's Jet Propulsion Laboratory. No further documentation is available. NPO-20455

Repair of Composite-Overwrapped Pressure Vessels

It would no longer be necessary to replace entire expensive vessels in cases of localized damage.

NASA's Jet Propulsion Laboratory, Pasadena, California

Pressure vessels overwrapped with graphite-fiber-based composite materials that become damaged would be salvaged by a proposed repair technique. The need for the technique arises as follows: High-performance graphite-fiber-based composites are very susceptible to damage from impact or cutting. Heretofore, when a composite-overwrapped vessel has been damaged, it has been necessary to replace the vessel in its entirety. However, some vessels of this type are so large and expensive that it is uneconomical to discard them in the event of damage.

Before you launch a composite design, make sure it's going to fly.

FiberSIM

Production-proven composite design software.

Design your next composite part with complete confidence that it will fly in production. FiberSIM can help you do this. FiberSIM is a suite of CAD integrated software tools that fits easily into your existing design and manufacturing processes to deliver unprecedented improvements in performance, quality, productivity and cost. Call, or visit our web site now. We'll make sure your designs will fly.

781.290.0506 x300


COMPOSITE DESIGN
TECHNOLOGIES, INC.

www.cdt.com

For More Information Circle No. 429

Thermofoil™ Heaters

put the heat where you need it



Flexible etched-foil heaters • Odd shapes, profiled or multiple elements • Efficient heat transfer: Up to 110 W/in²
• 200°C polyimide, 235°C rubber, 600°C mica, 120°C transparent insulations • Optional sensors & controllers

Precise, reliable heating • Minimal space, mass, & design overhead • Medical diagnostic instruments • Aerospace devices • Commercial appliances • Packaging machinery • Scientific instruments • Electronics

MINCO


PRODUCTS, INC.

7300 Commerce Lane • Minneapolis, MN 55432-3177 U.S.A.
Telephone: (612) 571-3121 • FAX: (612) 571-0927

Six-Axis

NEW
High-Resolution
ISA Bus Interface

Force/Torque Sensors



Features Include:

- Easy Integration into Robot Controllers
- Six Axes of Force/Torque Sensing ($F_x, F_y, F_z, T_x, T_y, T_z$)
- High Overload Protection
- Intelligent Interfaces
- Sizes from 17mm dia. to 250mm dia.

Applications Include:

- Product Testing
- Biomedical Research
- Wind Tunnel Testing
- Fluid Flow Analysis
- Robotics



Developing Products for Manufacturing Productivity

Tel: +1.919.772.0115 • Fax: +1.919.772.8259

Email: info@ati-ia.com • http://www.ati-ia.com

Peachtree Center, 503-D Highway 70 East, Garner, North Carolina 27529 USA

For More Information Circle No. 431

Shock & Vibration Damping. Up To 94%

Sorbothane® viscoelastic material absorbs and dissipates unwanted energy and outperforms rubber and other materials by providing:

- Shock Absorption
- Vibration Isolation
- Sound Damping


Sorbothane is the ultimate damping and isolation material

Standard products and cost-effective custom molding available

Free brochure and prototype sample.
800.838.3906

Sorbothane Inc.

2144 State Route 59, Kent, Ohio 44240 • tel 330.678.9444 fax 330.678.1303
www.sorbothane.com



The proposed repair technique would involve adhesive bonding of a composite doubler over each damaged area. The doubler would transfer structural loads around the damaged area.

The fiber reinforcement in a doubler could be made of graphite, polybenzoxazole, or aromatic polyamid, for example. The fiber and matrix materials and the dimensions of the doubler would be chosen by design to suit the specific damaged area. The doubler would be bonded in place by use of a room-temperature-curing adhesive. Use of additional fiber overwrapping of the doubler would be determined on a case-by-case basis.

This work was done by Joseph C. Lewis of Caltech for NASA's Jet Propulsion Laboratory. No further documentation is available.
NPO-20456

Ceramic Composites of ZrB_2 , HfB_2 , ZrC , HfC , and SiC

These ceramics offer superior resistance to ablation at high temperature.

Ames Research Center, Moffett Field, California

Improved zirconium- and hafnium-based ceramic composites have been invented in an effort to obtain better resistance to ablation at high temperature. These ceramics are suitable for use as thermal-protection materials on the exterior surfaces of spacecraft reentering the terrestrial atmosphere, and in laboratory and industrial environments that include flows of hot oxidizing gases.

The predecessors of these ceramic composites are ZrB_2/SiC and HfB_2/SiC composites, which exhibit high resistance to oxidation and thermal shock, high configurational stability, and high resistance to ablation. The ablation resistance of ZrB_2/SiC and HfB_2/SiC composites is believed to arise from the formation of coherent passivating oxide scales on their surfaces. However, each such composite exhibits a transition point




Figure 1. This Pseudo-Ternary Phase Diagram is for a ceramic composite of either (1) ZrB_2 , ZrC , and SiC or (2) HfB_2 , HfC , and SiC . The preferred composition ranges mentioned in the text are represented by the shaded trapezoidal area.

Composition in Volume Percentages		Effective Conversion Rate, $\mu\text{m}/\text{min}$.	Peak Surface Temperature, $^{\circ}\text{C}$
64 ZrB_2 + 20 ZrC + 16 SiC	Newer Compositions	-0.98	2,020
64 ZrC + 20 ZrB_2 + 16 SiC		-6.83	2,100
80 ZrB_2 + 20 SiC	Older Compositions	-17.78	2,200
80 HfB_2 + 20 SiC		3.47	1,810

Figure 2. **Effective Conversion Rates** and peak surface temperatures are indicators of resistance to ablation. A negative effective conversion rate represents growth or effusion of oxide scale on the surface of the ceramic, while a positive effective conversion rate signifies removal and conversion of surface material.

within its operational envelope of mach number vs. stagnation heat flux; beyond this point, the cohesiveness of the oxide scale decreases in such a way that microspallation of the oxide scale and concomitant accelerated conversion occur. Thus, resistance to ablation decreases beyond the transition point. The present innovative ceramic composites offer superior resistance to ablation.

A ceramic of the present type is a multiphase composite of (1) zirconium diboride and zirconium carbide with silicon carbide, (2) hafnium diboride and hafnium carbide with silicon carbide, or (3) mixed diborides and/or carbides of zirconium and hafnium with silicon carbide. The composite material is made by sintering a mixture of the metal diboride, metal carbide, and silicon carbide powders at a temperature of about $1,900^{\circ}\text{C}$ or greater. Typical composition ranges in volume percentages of the starting ceramic powders are the following:

Constituent.....Proportion, Volume Percent
 ZrB_2 and/or HfB_2 20 to 64
 ZrC and/or HfC 20 to 64
 SiC ≤ 20 (Preferably 10 to 16)

A given composition is said to be diboride- or carbide-rich, depending on the ratio between the metal diboride and metal carbide contents.

Figure 1 is a pseudo-ternary phase diagram for the special case of composites made from either (1) ZrB_2 , ZrC , and SiC or (2) HfB_2 , HfC , and SiC but not (3) mixtures of the diborides and/or carbides of both Zr and Hf . "Pseudo-ternary phase diagram" as used here signifies that the three points of the triangle represent the starting ZrB_2 or HfB_2 , ZrC or HfC , and SiC components, as distinguished from a true ternary diagram in which the individual elements Zr or Hf , Si , and C are represented. The composition ranges stated above are represented by the shaded trapezoidal area.

The table in Figure 2 presents some results of a test in which two composites of the present type and two of the previous type were exposed to an arc jet at a heat flux of $400 \text{ W}/\text{cm}^2$. The results show that with respect to conversion rates, the present ceramic composites resist ablation or conversion better than do the corresponding predecessor ZrB_2/SiC and HfB_2/SiC composites. The results are even more impressive when densities and surface temperatures are taken into account: About 50 seconds into the test, the ZrB_2/SiC ceramic underwent a transition in which the surface temperature rapidly climbed to a maximum of $2,200^{\circ}\text{C}$, with resul-

tant micro and macro spallation, and stability was not reestablished.

This work was done by Jeffrey Bull of Ames Research Center, Michael White of White Materials Engineering, and Larry Kaufman of Cambridge Technology Center. For further information, access the Technical Support Package (TSP) free on-line at www.nasatech.com under the Materials category.

This invention has been patented by NASA (U.S. Patent No. 5,750,450). Inquiries concerning nonexclusive or exclusive license for its commercial development should be addressed to the Patent Counsel, Ames Research Center; (650) 604-5104. Refer to ARC-12087.



FIND NOVEL TECHNICAL CONCEPTS WITH Knowledge and Innovation Server™


Easy to use, easy to deploy, easy to maintain

- Provides access to 6,000 animated scientific effects/examples
- Organizes in-house technical know-how and expertise
- Deploys on local Intranets with standard Web browsers
- Users include R&D engineers, technologists, and engineering managers
- Application to any technical discipline

Click on the technical function and get novel concepts in a second.

"By using the Knowledge and Innovation Server, engineers can easily access a large knowledge-base of technical effects via an Intranet to aid in the development of new products."

— Julian Blossius,
Jet Propulsion Laboratory



Requirements:
Windows 95/98/NT



Software That Invents®

Call 1-800-595-5500, Fax 617-305-9255,
E-mail: info@invention-machine.com
or visit us at www.invention-machine.com

Knowledge and Innovation Server is a trademark of Invention Machine® Corporation.



Special Coverage: Composites & Plastics




DuPont, Wilmington, DE, offers Krytox[®] dry film that can reduce the coefficient of friction in a range of applications, including mold release, allowing rubber and plastic parts to eject faster and cleaner. It also creates non-stick surfaces and facilitates parts movement. For the

internals of switches, a coating of the film permits movement without attracting dirt.

The Krytox dry film also can be used in wire drawing applications, in which it coats wire as it is pulled through a die, reducing heat generation and increasing the speed of the pull. The film joins the Krytox family of products, which includes oils and greases, and high-performance lubricants such as XP PFPE lubricants.

For More Information Circle No. 759



Loctite[®] Encap[®] two-part epoxy and polyurethane potting and encapsulating compounds from Loctite Corp., Rocky Hill, CT, protect critical components from the effects of exposure to chemicals, moisture, thermal and mechanical shock, and vibration.

They also prevent corrosion

and ensure integrity of electrical and electronic devices. The line features five two-part epoxy systems for temperatures in excess of 125 °C. The two-part systems involve an epoxy or polyurethane resin and an associated hardener, which initiates cure.

Also available are three two-part polyurethane resins, which operate most effectively in temperatures below 250 °F. When combined with the appropriate polyurethane hardener, the resins offer adhesion and abrasion resistance, high impact strength, and flexibility at low temperatures. These systems are suited for applications involving delicate components that will be exposed to sub-zero temperatures.

For More Information Circle No. 704




Polydamp[®] Low Emissivity Foam (PLE) from Polymer Technologies, Newark, DE, is a thermal foam material for insulating equipment where operators or components need to be kept at very stable temperatures. It is designed for trucks, medical diagnostic equipment, refrigeration applications, and buildings.

The construction of the material addresses three thermal problems: conduction, convection, and radiation. It is available in sheets, rolls, or fabricated

shapes, and is available with an optional PSA backing. The foam is part of the company's line of acoustical composites and engineered foam products for acoustical, gasketing, shielding, and structural applications.

For More Information Circle No. 700



EP21AR polymer adhesive from Master Bond, Hackensack, NJ, is a two-component epoxy adhesive for high-performance bonding in applications where high chemical resistance is a requirement. The adhesive cures at room temperature, or more rapidly at

elevated temperatures. It has a two-to-one mix ratio by weight, and develops a bonding strength of more than 2000 psi at room temperature.

The adhesive produces bonds that are resistant to thermal cycling and chemicals, including strong acids, alkalis, water, salts, and many organic solvents, over a temperature range of -60 °F to more than +250 °F. It withstands prolonged immersion in concentrated sulfuric acid, as well as high concentrations of nitric and hydrochloric acid. The adhesive adheres to metal, glass, ceramic, wood, vulcanized rubber, and plastic; the hardened adhesive is an electrical insulator.

For More Information Circle No. 705



Bixby International, Newburyport, MA, has introduced multi-layer composites that are extruded and laminated in one step. The process produces rigid or flexible plastic sheet and film, coated fabric, and plastic, foam, and fabric composites for uniformity and durability. The process combines up to five layers (two fabrics and three plastics) in one pass.

Custom composites are available in a variety of polymers, foams, papers, and fabrics. Various adhesive and plastisol coatings, custom color matching, and full-color sublimation printing also are available. Extruded

and laminated products can be produced in thicknesses ranging from 6 to 250 mils (1/4").

For More Information Circle No. 703



Emerson & Cuming Specialty Polymers, Billerica, MA, offers ECCOBOND[®] CS 6000 electrically conductive adhesive, which reduces stress in the bonding of electrical or electronic components. The silver-filled silicone material has favorable electrical and thermal conductivity properties

and a low ionic impurity, making it suitable for die and component attachment.


The adhesive features flexibility and has tough adhesion over wide temperature cycles. The single-component, silver-colored paste cures in one hour at 150 °C, and has a work life of eight hours.

For More Information Circle No. 701

New on the MARKET

Portable Data Acquisition

IOtech, Cleveland, OH, has introduced the Daqbook/260™ portable data acquisition system for notebook and desktop PCs. The system combines measurement and control I/O with user-configurable signal conditioning and signal connection. Three internal expansion slots accommodate any combination of signal conditioning and expansion options, including thermocouple, RTD, strain, high-voltage, current, frequency, acceleration, and pressure. The system features 16-bit resolution, 100-kHz sampling, and up to 64 channels of analog input using optional expansion cards. The unit is attached to the parallel port or PCMCIA slot on a PC. It comes with IOtech's DaqView™ Out-of-the-Box™ data acquisition and display software. **Circle No. 720**




Linear Positioner

Baldor Electric, Northern Magnetics Div., Fort Smith, AR, has released a Compact Positioning Stage, which features a zero-backlash, non-wearing linear motor that eliminates mechanical-drive linkages to provide smooth, quiet operation. The stage has a maximum stroke of 2" (0.5 Min) and an approximate total weight of 1.5 pounds. It offers continuous forces to 1 pound, and peak forces to 3 pounds. Designed originally for laser eye-surgery applications, the positioner is suitable for semiconductor manufacturing, medical equipment, precision machining, and inspection and measurement equipment. **Circle No. 719**



Video Inspection Tool

AQUA Communications, Cambridge, MA, has introduced SnakeEye™, a lightweight, modular, portable video diagnostic tool that combines a miniature CCD camera with TFT-LCD display technology. The unit delivers full-color video and features a video in/out port, which allows connection to a standard VCR or to a PC video capture card. SnakeEye is designed for qualitative inspections in hard-to-reach places such as engines and fuel tanks. The device comes with a rechargeable battery pack, AC adapter, and an auto adapter. Options include a 3-foot gooseneck adapter and C-mount camera. **Circle No. 731**




Data Acquisition

OMEGA Engineering, Stamford, CT, offers the Datasuttle Express (DS-EXP), a high-speed portable data acquisition system. Features include high-speed sampling rates of up to 100 kHz and 0.012% A/D resolution. The system accepts several input types, including thermocouple, accelerometer, RTD, and strain gauge, along with digital I/O, analog output, and counter/timer. Multiple units can be interfaced to a single PC for 240 analog inputs, 30 analog outputs, 30 counter/timers, and 180 digital I/Os. It comes with Quicklog software, which enables low-speed data acquisition, datalogging, charting, and DDE capability. **Circle No. 713**



AMONG PRECISION METAL FORMING COMPANIES YOU EXPECT AMAZING SPEED FROM THE **STANDOUT**



To become a partner with you we must exceed your expectations. It's part of being a STANDOUT.

To discuss your needs, or to receive your copy of our booklet "How To Design Metal Stampings" call TOLL FREE **1-800-677-8881**.



Dayton Rogers
MANUFACTURING CO.

www.daytonrogers.com

Plant Locations:
St. Petersburg, FL
Columbus, OH
Arlington, TX
Van Nuys, CA
Minneapolis, MN
Rochester, NY

For More Information Circle No. 434

EMI/RFI SHIELDING

Superior performance shielding gaskets
Electronic grade plating finishes
Many base metal variations
Hundreds of shapes & sizes
Custom modifications

MEDICAL DIAGNOSTICS

TELECOMMUNICATIONS

COMPUTERS

AEROSPACE, MILITARY

INSTRUMENTATION

ELECTRONIC ENCLOSURES



OMEGA SHIELDING
PRODUCTS

1384 Pompton Ave., Cedar Grove, NJ 07009
tel: 973-890-7455 fax: 973-890-9714
E-mail: sales@omegashielding.com
web site: <http://www.omegashielding.com>
ISO 9002 Quality System Certified




TRIM-LOK[®] INC.

If you have an edge...We have a trim!

Call for
FREE
Samples

Trim-Lok's Regular Trim



Regular Trim is a flexible PVC trim with a metal clip inside, designed to provide a permanent grip on your application. Available in several sizes, colors and finishes.

For over 25 years, the **leader** in flexible plastic and rubber extrusions!

Come see us on-line at <http://www.trimlok.com>

NOW
ACCEPTING:



call toll free: e-mail: trimlok@aol.com

1-888-TRIMLOK

714-562-0600 fax

6855 Hermosa Circle • Buena Park, CA 90622-6180

For More Information Circle No. 436

CRYOGENIC ADHESIVES

Designed To Your Specifications

MASTER BOND EP29LPSP EPOXY

- Two-part system ■ Convenient mix ratio
- Flexible cure schedules
- Service down to liquid helium temperatures
- Outstanding thermal shock resistance
- Superior dimensional stability
- Convenient packaging



Master Bond Inc.
Adhesives, Sealants & Coatings

For information,
call or write:
Master Bond Inc.
154 Hobart Street
Hackensack, NJ 07601
201-343-8983

For More Information Circle No. 437

New on DISK

Link for Excel

Wolfram Research, Champaign, IL, offers Mathematica Link for Excel, which provides an interface between Microsoft Excel and the Mathematica technical-computing system. The software allows Excel spreadsheets to perform integration and differentiation, and solve differential equations. It enables users to perform data analysis using Mathematica's statistics capabilities, including data smoothing and manipulation, linear and nonlinear regression with diagnostics, and hypothesis testing. With the linking software, Mathematica Applications Library add-ons such as Finance Essentials also can be brought into Excel. **Circle No. 732**

Vision Application Builder

IMAQ Vision Builder from National Instruments, Austin, TX, is an interactive software environment for the development of computer-based vision systems. Its set of machine-vision and image-processing tools includes functions for quantitative analysis, image enhancement, grayscale, color, morphology, blob analysis, and pattern matching. The software also returns critical tolerance measurements such as distances, areas, and locations, and enables developers to load images from files or capture images from analog or digital cameras. The software is optimized for speed with Intel's MMX processors and includes an image browser. **Circle No. 734**




Numerical Library

Visual Numerics, Boulder, CO, has introduced Version 3.0 of IMSL C Numerical Library (CNL), which consists of more than 250 pre-built mathematical and statistical analysis functions written in C. Programmers of C or C++ can embed the functions directly into numerical analysis applications. Version 3.0 offers 22 new statistical functions focused in two primary areas: time series analysis and forecasting, and non-parametric statistics. The software also supports symmetric multi-processing (SMP) technology, a processing capability built into many leading PCs and workstations. **Circle No. 739**

CAD Model Repair

CADfix[™] from International TechneGroup, Milford, OH, is designed to facilitate product data interoperability. It assesses geometric and topological imperfections in CAD models (IGES, STL, Parasolid, ACIS) and makes the corrections automatically or interactively. CADfix features "smart healing" technology, intuitive model partitioning tools for CAE applications, and comprehensive NURBS surface-repair functions. The software allows a repaired model to be transformed so that data is suitable for the end-user application. **Circle No. 737**



Data Acquisition Tool

The MathWorks, Natick, MA, has released the Data Acquisition Toolbox, designed to provide direct access to live, measured data from MATLAB computation and visualization software. Users can acquire, analyze, visualize, model, and report data results in one environment. Features include analog input/output and digital I/O; integration with MATLAB and MATLAB toolboxes; multi-channel support; and high-speed, event-based acquisition. The Toolbox supports National Instruments' E-Series boards, HP's VXI E1432-Series hardware, Microsoft Windows' multimedia sound card, and third-party extensions by vendors such as DSP Technologies. The toolbox is Windows 95/98/NT compatible and requires MATLAB 5.3. **Circle No. 735**

New LITERATURE




Fasteners and Inserts

Penn Engineering & Manufacturing Corp., Danboro, PA, offers a Product Guide and Index to Bulletins detailing fasteners, inserts, and fastener-installation press systems. This 12-page guide also provides an index to product literature and contact information for authorized distributors and engineering representatives worldwide. **Circle No. 722**

Optoelectronics CD-ROM

Sharp Microelectronics of the Americas, Camas, WA, has released a CD-ROM describing optoelectronic devices, applications, power devices, GaAs Hall devices, and Hall ICs. The CD contains more than 1,500 pages of data on products including photocouplers, photointerrupters, visible LEDs, laser diodes, and solid state relays. **Circle No. 724**



Pressure Switches

Pressure switches catalog #N-404 from Norgren-Herion USA, Warrendale, PA, offers a range of switches for pneumatic, hydraulic, and process-control applications. The 32-page catalog includes both electromechanical and digital solid-state models, for pressures from vacuum to 10,000 psi. **Circle No. 725**

Field Calibrators

A 12-page catalog from Fluke Corp., Everett, WA, describes the Fluke 740 line of documenting process calibrators. Products include the Fluke 744, which is designed for calibrating, maintaining, and trouble-shooting HART instrumentation. Other new products include the Fluke 718 Pressure Calibrator and the Fluke 705 Loop Calibrator. **Circle No. 727**




Linear Guides

Thomson Industries, Port Washington, NY, offers a 186-page catalog featuring 17 types of RoundRail™ and ProfileRail™ linear guides. Included are linear guides with different contact technologies (ball, roller, sliding bearings); mounting types (fully supported, unsupported, end supported); and mounting styles (above, below, side). **Circle No. 728**



Bolting Solutions

A revised catalog from SUPERBOLT, Carnegie, PA, contains technical information on mechanical and stud/bolt tensioners, and an updated installation/removal procedure. Products include reusable Multi-Jackbolt tensioners, which are designed so that bolts can be tensioned using only a hand torque wrench. **Circle No. 723**



When this ray of light hits this aluminum beam, our inductive sensor resolves the thermal deflection of the beam to **0.000000001 m**


Semiconductor, disk drive, metals, automotive, biomedical, plastics...no matter what your industry, you may need our resolution. Call or log on for a report on this demonstration, and find out how our noncontact measuring systems can work for you.

www.kamaninstrumentation.com
800-552-6267

KAMAN
see what's happening

For More Information Circle No. 438

GPS ON VIDEO



Encode Mode

- Annotates Video with GPS data (SN, Lat, Long, Speed, Course, Date, Time, Hour Offset, Status, Alt.)
- Encodes Video with GPS data (Edge-coding is off screen in normal scan)
- Provides live GPS data to moving map program (using optional computer interface adapter cable)
- Precision millisecond time can be offset to local time worldwide
- Switch Select for Top/Bottom Display, Add/Sub Offset Hours, Kts/MPH/KmPH, Feet/Meters

Decode Mode


- Reads edge-coded GPS data from recorded Video in VCR play or pause, and outputs SGRPMC message to moving map program (using optional computer interface adapter cable)

Prices (includes shipping)

Video Encoder/Decoder, Model VED-M with DC cable	\$1250
Compatible 12 Channel GPS receiver, Model GPS-35V	\$350
Computer Interface Adapter Cable	\$25
S-Video (YC) Adapter	\$50
AC Adapter (9 VDC Wall Transformer)	\$15

Terms

US: MasterCard/Visa or Net 30
Export: To be managed through
Export Trading Company



693 Melrose Road
Lottsburg, VA 22511
(804) 529-5950
vdata@crosslink.net

Other Products

GPS Receiver/IRIG-B Timecode Generator, Model GTP
GPS or IRIG-B synchronized video sync generator, Model VSG
Video Encoder/Decoder with IRIG-B input, Model VED-A

Advertisers Index

Company	Web Site	Circle Number	Page	Company	Web Site	Circle Number	Page
Abaris Training Resources, Inc.	www.abaris.com	427	71	Lasiris	www.lasiris.com	464	13a
Aero Tec Laboratories Inc.	www.atlinc.com	582	70	LPtek Corp.	www.lptek.com	424	68
Algor, Inc.	www.algor.com	514, 519	7, 53	Master Bond Inc.		437	78
Amtec Engineering, Inc.	www.amtec.com/tecplot	407	18	MathSoft, Inc.	www.mathsoft.com	505	29
Astro-Med, Inc.	www.astro-med.com	521	39	The MathWorks, Inc.	www.mathworks.com/demo4	529	21
ATI Industrial Automation	www.ati-ia.com	431	74	Meadowlark Optics		466	20a
BASF Corporation	www.basf.com/plastics	537	35	Melles Griot	www.mellesgriot.com	478	COV IIIa
Bekaert Fibre Technologies	www.bekaert.com/bft	583	70	Microstar Laboratories, Inc.	www.mstarlabs.com	580	70
Breault Research Organization	www.breault.com	477	7a	Mikron Instrument Company Inc.	www.mikroninst.com	461	6a
Busak + Shamban	www.busakshamban.com	586-588	2	Minco Products, Inc.		430	73
Cambridge Technology	www.camtech.com	488	1a	MKS Instruments	www.mksinst.com	417	60
Chino Works America, Inc.		404	52	National Instruments Corporation	www.natinst.com/info/pcidaq www.natinst.com/daq, www.natinst.com/info/lv	501, 413, 416	COV II, 45, 51
Ciba Specialty Chemicals		602	4b	The National Technology Transfer Center	www.NASATECHNOLOGY.COM/TB	526	15
Composite Design Technologies, Inc.	www.cdt.com	429	73	Neslab Instruments	www.neslabinc.com	490	23a
Continuum	www.continuumlasers.com	527	COV III	Newport	www.newport.com/wdm, www.newport.com/oam6	471, 482	COV IIa, 19a
Cutting Edge Optronics, Inc.	www.ceolaser.com	462	10a	NuSil Silicone Technology	www.nusil.com	408	32
CVI Laser	www.cvilaser.com	463	12a	Ocean Optics, Inc.	www.OceanOptics.com	410	42
Data Translation	www.datatranslation.com	428	72	Omega Shielding Products Inc.	www.omegashielding.com	435	77
Datum, Bancomm-Timing Div.	www.datum.com	405	8	Optical Research Associates	www.opticalres.com	480	11a
Dayton Rogers Manufacturing Co.	www.daytonrogers.com	434	77	OptoSigma	www.optosigma.com	485	3a
Digi-Key Corporation	www.digikey.com	550	3	Oriel Instruments	www.oriel.com		16a
DuPont Engineering Polymers	www.dupont.com/enggpolymer			Paroscientific, Inc.	www.paroscientific.com	425	69
DuPont Krytox	www.lubricants.dupont.com	535	41	Polymicro Technologies	www.polymicro.com	468	22a
DuPont Vespel	www.dupont.com/enggpolymer	513	10-11	Rand Worldwide	www.rand.com	577	4-5
Eastman Kodak Company, Motion Analysis Systems Div.	www.masdkodak.com/ntb	511	23	Redlake Imaging Corporation	www.redlake.com	467	21a
Edmund Scientific	www.edsci.com	491	23a	Research Systems, Inc.	www.rsinc.com	575	COV IV
EG & G Orc				RGB Spectrum	www.rgb.com	406	12
Electroformed Products	www.orc-ef.com/n/	470	2a	Rubbercraft Corporation of California	www.rubbercraft.com	419	64
Electro Optical Industries, Inc.		469	23a	SL Corporation	www.sl.com	411	43
Emerson & Cuming	www.emersoncumingmp.com			SMD, Silicon Mountain Design, Inc.	www.smd.com	486	9a
Microwave Products		415	50	Solid Concepts	www.solidconcepts.com	603	6b
Endevco	www.endevco.com/rock-solid.html	543-548	37	SolidWorks Corporation	www.solidworks.com/3208	600	1b
Farrand Controls	www.ruhle.com	581	70	Sorbothane, Inc.	www.sorbothane.com	432	74
Federal Laboratory Consortium	www.federalabs.org		64A-D	Spiralock	www.spiralock.com	560, 420	57, 65
Fluoramics, Inc., TuFoil	www.tufoil.com	423	67	Spiricon Inc.	www.spiricon.com	460	4a
Gage Applied Sciences Inc.	www.gage-applied.com	564	9	Synrad, Inc.	www.synrad.com	414	46
Hardigg Cases	www.hardigg.com	418	59	Tech East '99	www.techeast.net	570, 571	63
Hewlett-Packard Company, Basic Instruments	www.hp.com/info/bi45	503	27	Tecknit	www.tecknit.com	412	44
Hewlett-Packard Company, Design Jet	www.hp.com/info/4098	533	1	Tescom Corporation	www.tescom.com	409	38
Hewlett-Packard Company, Visualize Personal Workstations	www.hp.com/info/vis1	590	61	Trim-Lok	www.trimlok.com	436	78
Hitachi Denshi America, Ltd.	www.hda.com	465	15a	UDT Sensors, Inc.		472-476	17a
Instrumented Sensor Technology	www.isthq.com	422	66	Unigraphics Solutions Inc.	www.solid-edge.com	601	3b
Invention Machine Corp.	www.invention-machine.com	433	75	V-data		439	79
ITTools	www.ittools.com	421	66	Vector Fields	www.vectorfields.com	440	31
Kaman Instrumentation	www.kamaninstrumentation.com	438	79	Visionary Design Systems, Inc.	www.ironcad.com	558	13
Keithley Instruments, Inc.	www.keithley.com	523	49	Wolfram Research, Inc.	www.wolfram.com	510	19
Kingston Technology Company	www.kingston.com/storage	507	25	Xerox Engineering Systems	www.engineeringsystems.com	531	16A-B, 17
Lambda Physik, Inc.	www.lambdaphysik.com	481	5a	Z C & R Coatings	www.zcrcoatings.com	479	COV IVa

NASA Tech Briefs, ISSN 0145-319X, USPS 750-070, copyright © 1999 in U.S. is published monthly by Associated Business Publications Co., Ltd., 317 Madison Ave., New York, NY 10017-5391. The copyright information does not include the (U.S. rights to) individual tech briefs that are supplied by NASA. Editorial, sales, production, and circulation offices at 317 Madison Ave., New York, NY 10017-5391. Subscription for non-qualified subscribers in the U.S., Panama Canal Zone, and Puerto Rico, \$75.00 for 1 year; \$125 for 2 years; \$200.00 for 3 years. Single copies \$10.00. Foreign subscriptions one-year

U.S. Funds \$195.00. Remit by check, draft, postal, express orders or VISA, MasterCard, and American Express. Other remittances at sender's risk. Address all communications for subscriptions or circulation to NASA Tech Briefs, 317 Madison Ave., New York, NY 10017-5391. Periodicals postage paid at New York, NY and additional mailing offices.

POSTMASTER: Send address changes to NASA Tech Briefs, PO Box 10523, Riverton, NJ 08076-9023.

Are you seeking beam quality or power?
YOU JUST FOUND BOTH!



Powerlite ***Precision Series***

Whether you're looking for a scientific, industrial or OEM solutions, **Continuum's** award winning Powerlite Series of Pulsed Nd:YAG Lasers offer advanced features and the reliability necessary to meet your needs. The ultimate OPO pump source has unsurpassed passive beam pointing stability and beam quality. Powerlite Precision Series lasers deliver 550mJ to over 3J per pulse at 10Hz to 50Hz. **Continuum** combines 25 years of laser expertise and engineering to give you powerful, rock-solid lasers.

Call **Continuum** for help with your application.

Continuum™

Corporate Headquarters: 3150 Central Expressway, Santa Clara, CA 95051
Phone: (800) 956-7757 Fax: (408) 727-3550 Email: continuum@ceoi.com
Japan: scisales@hoyacont.co.jp Germany: info@ceoi.de
France: serge.diane@wanadoo.fr









<http://www.continuumlasers.com>



Knowledge is Power

*...power to interpret,
understand and discover.*




IDL 5.2 is available for most popular operating systems: Windows 95, Windows 98, Windows NT, Mac OS, UNIX (Solaris, HP-UX, IRIX, Digital UNIX & AIX), Linux, Solaris for Intel, and OpenVMS.

Discovery is about visualizing your data in a whole new way. For over 20 years, technical test engineers, researchers and application developers have relied on Research Systems' visualization and data analysis software to provide the building blocks essential to analysis and new insights.

With IDL®, the *Interactive Data Language*, you can manipulate complex or extremely large datasets — even those 2 Gigabytes or larger — from various sources to detect and display patterns, trends and anomalies. IDL 5.2 has added handling of unique data files such as DICOM, DXF and HDF-EOS.

IDL's high-level language allows breakthrough application development in less time. Simplified programming and rapid prototyping features eliminate the tedious edit-compile-link-debug cycle required by traditional languages. Object Graphics and cross-platform portability enable you to develop in one environment, reuse code and easily move to new platforms now or in the future.

Discover Answers. Discover IDL.



IDL GUIBuilder™

Visually build your graphical user interfaces (GUIs) in a fraction of the time with drag and drop ease.

The IDL GUIBuilder, a new, powerful development tool within IDL, facilitates the rapid generation of high-quality, platform-independent GUI design.

VISIT OUR WEB SITE TODAY TO DOWNLOAD IDL 5.2



**RESEARCH
SYSTEMS**
Software = Vision.

www.rsinc.com

tel: 303.786.9900 email: info@rsinc.com

International Offices

Austria • Germany • Liechtenstein • Luxembourg • Switzerland • The Netherlands • Brazil • China • France • Belgium • India • Italy • Japan • Korea • Spain • Portugal • Taiwan • United Kingdom

IDL is a registered trademark of Research Systems, Inc. All other marks are the property of their respective owners. All rights reserved.

For More Information Circle No. 575

IDL
the Interactive Data Language