



## Introduction

- Many future launch vehicles are planning to use liquefied natural gas (LNG) in combination with liquid oxygen (LOX)
- LNG as a rocket fuel

  - Highly efficient, widely available, and low cost Clean combustion characteristics, improving refurbishment and reusability
  - Can self-pressurize ullage of tanks (reduces helium usage)
- Compositional changes due to preferential boiloff (or weathering) occur
- Integrated refrigeration and storage (IRaS) can provide active heat extraction (i.e. refrigeration) to eliminate weathering)

# Experimental

## Cryostat Apparatus

- 400-liter vertical vacuumjacketed cylindrical vessel (cryostat) with an integrated pulse tube cryocooler (approximately 50 W at 100 K)
- RTDs and 1.6-mm diameter liquid sample tubes on vertical rake for 5 liquid levels



# Integrated Refrigeration and Storage of LNG for Compositional Stability

### L Rose<sup>1</sup>, A M Swanger<sup>1</sup>, W U Notardonato<sup>1</sup>, J E Fesmire<sup>1</sup>, J Gleeson<sup>2</sup>, and R Carro<sup>2</sup>

<sup>1</sup>Cryogenics Test Laboratory, NASA Kennedy Space Center, FL 32899, USA <sup>2</sup>Bionetics Corp. at NASA Kennedy Space Center, KSC, FL 32899 USA

## **Objectives**

- 1. Compare composition changes of LNG using traditional boiloff/venting to using IRaS
- 2. Study feasibility and cost-effectiveness of long-term storage
- using active refrigeration
- 3. Investigate feasibility and benefit of densified LNG

# **Experimental Approach**

#### Test steps

- 1. Fill with LNG and leave vent open 2. Sample LNG while LNG evaporates, until tank is empty
- 3. Fill cryostat with LNG again

- 4. Close vent and turn on cryocooler 5. Adjust heater controls for zero boiloff (ZBO) 6. Allow zero boil-off for 2 weeks

#### Sampling procedure

- spectrometer (only during boiloff test)
- 1. Continuously analyze vent output with mass 2. Three times a week, sample each of the five liquid levels 3. Once a week, sample each of the five liquid levels using a
- gas analyzer

## **Modes of Operation**

- Boiloff: Without refrigeration, in order to determine a baseline in the change in composition, and to study stratification of the LNG (boiloff test)
- Zero boiloff: Cryocooler active to determine the operational parameters of the IRaS system for eliminating the weathering as well as stratification effects in the bulk liquid



- Mass spectrometer
- Cryostat with integrated cryocooler and heat exchanger built and in place
- Connecting hardware, instrumentation, and data-recording setup in-work
- Sourcing LNG



## Sampling Methods

Sampling two different ways Precisive 5-283 Gas Analyzer from MKS (Infrared */optical analyzer)* 

Gases measured Methane Ethane Propane Iso-Butane n-Butane Pentanes CO2

### Status

• LN<sub>2</sub> boiloff test performed for heat leak approximation. The heat leak during this test was < 22 W.