



### Properties of Phenylethynyl Imide Composites Fabricated Via VARTM

Roberto J. Cano<sup>†</sup>, <u>Sayata Ghose<sup>§, ø,</sup> Kent A. Watson<sup>§</sup></u>, Prasad B. Chunchu<sup>+</sup>, Brian J. Jensen<sup>†</sup> and John W. Connell<sup>†</sup>

<sup>†</sup>NASA Langley Research Center, Hampton, VA 23681-2199
 <sup>§</sup> National Institute of Aerospace, Hampton, VA 23666-6147
 <sup>+</sup>ATK Space Systems, Inc., Hampton, VA 23681-2199
 <sup>ø</sup>Currently at The Boeing Company, Seattle, WA 98124-2207

19<sup>th</sup> International Conference on Composite Materials July 28-August 2, 2013 Montréal, Canada








- Introduction to VARTM Processing
- Phenylethynyl Terminated Imide (PETI) Resins
- Past Research and Issues
- Current HT-VARTM Process
- Experimental
- Laminate Fabrication Results
- Mechanical Properties
- Structural Sub-Component Demonstration Article
- Summary







- Upper half of metal mold replaced by vacuum bag
- Atmospheric pressure provides both the resin driving force and the preform compaction force
- Distribution medium is used to facilitate resin flow
- Room temperature process

*Ref: Seeman Composites Resin Infusion Molding Process (SCRIMP), TPI Composites, U.S. Patent 4,902,215 (1990)* 



# **VARTM Characteristics**



#### Strengths

- Reduced cost
- Complex shapes
- Essentially no size limitation

Weaknesses/Possible Issues

- High fiber volume more difficult to obtain than in autoclave
- Void content < 2% for aerospace applications (like epoxies)?
- Most applications tolerate higher void content than aerospace
- Applicable to high temperature resins?
- Controlled Atmospheric Pressure Resin Infusion (CAPRI)
  - Patented by The Boeing Company
  - SCRIMP variation
  - vacuum debulking and reduced pressure difference
  - minimizes thickness gradients and resin bleeding

Ref: J.A. Woods et al., U.S. Patent 7,334,782 (2008)



# Selection of PETI Resins for HT-VARTM



- Precursor form offers
  - Low melt viscosity, large processing window
  - Long shelf-life
  - No solvent, no unreacted toxic monomers
  - Commercial availability in prepreg solutions and neat resin form (for RTM and RI)
- Cured resin offers
  - High temperature performance (>1000 h at 300 ° C in air)
  - Composite mechanical properties including damage tolerance meet aerospace criteria
- Disadvantages
  - High temperature cure (typically 1-3 h at 371 °C)
  - High cost (relative to epoxies)
  - Niche market (jet engine applications, recent interest in airframe structure)



# State of the Art




- PETI laminates from same resins (different mol wt) by autoclave (prepreg), RI and RTM, porosity levels of < 2% routinely achieved</p>
- Difference between RTM and VARTM = pressure (1.4 vs. 0.1 Mpa)
- HT-VARTM laminate porosity by volume reduced from ~10% to as low as 1% by identification of porosity sources and processing modifications.

Ref: S. Ghose, et al.; "High Temperature VARTM of Phenylethynyl Terminated Imides," High Performance Polymers, 21 (5), 653 (2009)

### Experimental





> Steel plate with 3 holes to provide one resin inlet and two vacuum outlets

- ➢ Polyimide bagging material (Thermalimide™)
- Inner bag with several layers of carbon fiber preform, 5 layers of Aluminum (Al) screen distribution media (DM), Release Ease<sup>™</sup> fabric a breather material

High temperature sealant to seal both an inner bag and an outer bag (for redundancy should a leak occur in the inner bag after infiltration)



# Experimental



> Resins:PETI-9:cured  $T_g \sim 265$  ° C (Imitec, Inc.),PETI-330:cured  $T_g \sim 330$  ° C (Ube America, Inc.)

Fabrics: T650-35-3K-8HS IM7-6K-5HS IM7-6K uniweave (unidirectional weave)

Rheology

▶C-scan


Acid digestion


Mechanical properties (unaged and aged, room temperature and elevated temperature)

- Short Block Compression (SBC)
- Open Hole Compression (OHC)
- Compression After Impact (CAI)




### LaRC<sup>™</sup> PETI-330









(m-PD)





asymmetric biphenyl dianhydride (a-BPDA)




phenylethynyl phthalic anhydride (PEPA)

nitrogen NMP








Where Ar = 1,3,4-APB and m-PD; 50:50 ratio,  $M_n \sim 1290$  g/mol





# **Rheology Profile of PETI-330**



2 h hold at 280 °C

2 h hold at 260 °C


Larger processing window at 260 °C for PETI-330

Rheology conditions: 100 – 371 °C at 4 °C/min; 2 h hold at infusion temperature, frequency of 10 rad/sec, autostrain




### LaRC<sup>™</sup> PETI-9





# **Rheology Profile of PETI-9 / PETI-300**





4 h hold at 260 °C

2 h hold at 260 °C

Rheology conditions: 100 – 371 °C at 4 °C/min; 4 h hold at infusion temperature, frequency of 10 rad/sec, autostrain




# **Typical PETI Panels Quality**



#### **PETI-9/T650**



#### **PETI-330/IM7**



Void – 3.6 %, Fiber volume – 63 % Void – 2.9 %, Fiber volume – 57 %

Quasi lay-up:

OHC  $[\pm 45/(0/90)/\pm 45/(0/90)]_{s}$  (Biaxial Fabric) OHC  $[-45/0/+45/90]_{2s}$  (Uniweave Fabric) SBC, CAI  $[\pm 45/(0/90)/\pm 45/(0/90)]_{2s}$  (Biaxial Fabric)

Heat treatment of C-fibers at 400 ° C
Infusion at 260 ° C
Staged cure cycle



# Fiber and Void Volume Contents of PETI Laminates



		Material:	Fabric /	Resin				
Test	IM7-5HS/ PETI-9	T650-8HS/ PETI-9	IM7-Uni/ PETI-9	IM7-5HS/ PETI-330	T650-8HS/ PETI-330	IM7-Uni/ PETI-330		
SBC RT	57.2/3.9	59.6/4.4		53.4 / 3.9	58.3 / 4.5	-		
SBC ET	57.2/3.9	59.6/4.4		53.4/3.9	58.3/4.5	-		
SBC Aged	57.2 / 3.9	59.6 / 4.4	-	53.4 / 3.9	58.3 / 4.5	-		
OHC RT	58.7 / 2.7	63.7 / 3.6	57.4 / 2.7	57.5 / 2.9	62.4 / 3.2	56.5 / 1.7		
OHC ET	57.6 / 2.4	60.0 / 3.7	57.5 / 3.1	53.5 / 4.2	63.1 / 3.4	53.5 / 3.8		
OHC Aged	58.2 / 2.6	57.5 / 2.9	61.9/3.7	55.7 / 3.6	62.4 / 3.2	55.7 / 1.7		
CAI RT	56.8 / 2.9	61.7 / 4.2		55.9 / 2.9	60.1 /3.8			
CAI ET	56.8 / 2.9	60.8 / 4.2		55.9 / 2.9	60.1 /3.8	-		
	Fiber Volume % / Void Volume %							

PETI-9 Aged for 1000 hr at 177° C PETI-330 Aged for 1000 hr at 288° C




### **TGA/MS: Source of Volatiles**



Heating Ramp Heat to 280 °C Hold 1 h Heat to 371 °C Rate 10 °C /min

Atmosphere N<sub>2</sub>




- Heating ramp designed to simulate laminate fabrication cycle (N<sub>2</sub> versus vacuum)
- Benzene, toluene and benzaldehyde detected during both heating ramps
- Other species listed evolved only during second heating ramp
- Total weight loss was 0.5-1.0 %


Ref.: Sayata Ghose, Kent A. Watson, Roberto J. Cano, Sean M. Britton, Brian J. Jensen, John W. Connell, Helen M. Herring, and Quentin J. Lineberry, High Performance Polymers, October 2009; vol. 21, 5: pp. 653-672

### Short Block Compression Properties of PETI-330






### Short Block Compression Properties of PETI-9



## **Open Hole Compression Properties**


NASA





PETI-8 data from Ghose et al., SAMPE Proceedings, Long Beach, CA, May 2011.


# OHC Properties of PETI-9 Aging Effects



# **Compression After Impact Properties**

NA SA







# **Compression After Impact**




Test condition: dropped weight of 5.3691 kg and an indenter with a 1.59 cm diameter hemi-spherical tip

Material	CAI Test Temp., °C	Impact Energy, J	Drop Height, cm	Max. Force, N	Dent Depth, mm	Damage Area*, cm <sup>2</sup>
PETI-330 / IM7 5HS	RT	399.54	63.24	25.41	0.62	3.16
PETI-330 / IM7 5HS	288	385.97	61.09	25.20	0.51	4.23
PETI-330 / T650 8HS	RT	448.04	70.91	28.26	0.96	8.70
PETI-330 / T650 8HS	288	460.61	72.90	27.51	0.45	8.56
PETI-9 / IM7 5HS	RT	375.98	59.51	25.38	0.45	1.92
PETI-9 / IM7 5HS	177	384.04	60.78	25.20	0.58	2.38
PETI-9 / T650 8HS	RT	447.82	70.88	27.63	1.05	3.90
PETI-9 / T650 8HS	177	451.00	71.38	25.94	1.06	3.14

\*approximated from C-scan images post impact

# Structural Sub-Component: IM7/PETI-9 HT-VARTM Hat Stiffened Panel



3.6% Void Volume Fraction/ 54% Fiber Volume Fraction



### Conclusions



- LaRC developed polyimide resins with appropriate viscosity/ processing windows have been developed for HT-VARTM and HT-RTM
- With suitable hardware, infusion temperature, and cure cycle adjustments, LaRC<sup>™</sup> PETI-330 and PETI-9 can be successfully processed by HT-VARTM
- > HT-VARTM void contents of 1.3 to 4% are the lowest reported
- A database of compressive, OHC and CAI properties was developed on two resins and three types of carbon fabrics
- HT-VARTM composites demonstrated 67-100% retention of properties at elevated temperature (177 ° C for PETI-9 and 288 ° C for PETI-330) as well as after aging for 1000 h at those same temperatures
- Fabrication of a prototype part demonstrated that HT-VARTM has the potential to be a viable out-of-autoclave process for these polyimide systems



### Acknowledgments



James M. Baughman of Lockheed Martin for the photomicrographs

Louis E. Simmons and Fred M. Whitehead of NASA LaRC for cutting the panels

Janice Y. Smith, Kathleen Devol, Christopher W. Wright, and Gregory T. Shanks of NASA LaRC for mechanical properties





