Vibration Mitigation Using An Inerter-based Isolation System

Sima Abolghasemi

Research assistant at The University of Tennessee

Spring 2022



Nicholas E. Wierschem

J. Brent Knight

Assistant Professor at The University of Tennessee


Structural Dynamics Analysis at NASA Marshall Space Flight Center

INTRODUCTION

- ➤ There are many methods to mitigate vibrations in structures to prevent or reduce probable damages.
- Recently, the inerter has gain attention from engineers and researchers as it is attractive for many structural control methods.
- Many investigations have been done regarding the effectiveness of the inerter in reducing the vibration, but most are theoretical.
- Experimental studies featuring inerters, particularly regarding of isolation systems, have been limited.

INERTER

- An inerter can produce large mass effects despite having a small physical mass through the transformation of translational motion to the rotational motion.
- Can be made with ball-screw or lead-screw to provide the linear motion and a flywheel for rotational motion.
- In this study, the flywheel can be modified to provide two inertance values.
- Self-aligning ball bearing is used to reduce alignment issues with the inerter in the isolation layer during the test.



ANALYTICAL MODEL & PROPERTIES

✤ Inertance

$$\omega = \alpha(\dot{u}_b)$$

$$\alpha = 2 \pi/\rho$$

$$T = \frac{1}{2}J\omega^2$$

$$J = (J_1 + J_2 + J_3)$$

$$T = \frac{1}{2}J\alpha^2(\dot{u}_b)^2$$

$$\frac{d}{dt}\left(\frac{\partial T}{\partial \dot{u}_i}\right) = J\alpha^2(\ddot{u}_b)$$

✤ EOM

System Parameters unit Value 3.13 ms kg 2.13 mb kg ks 870890 N/m kb 114210 N/m **b** (bigger flywheel) 28.41 kg **b** (smaller flywheel) 2.32 kg





Diagram of the system with isolation featuring a rotational inertial damper

$$m_s \ddot{u}_s + c_s (\dot{u}_s - \dot{u}_b) + k_s (u_s - u_b) = -m_s \ddot{u}_g(t)$$

 $(m_b + b)\ddot{u}_b + c_s(\dot{u}_b - \dot{u}_s) + c_b\dot{u}_b + k_s(u_b - u_s) + k_bu_b = -m_b\ddot{u}_g(t)$

EXPERIMENTAL MODEL



 System configuration including isolator configuration with concentrated rotational mechanism paired with beam spring isolators

Video of the experimental test of the box with the inerter and the flywheel






Photo of the model on shake table at The University of Tennessee






EXPERIMENTAL RESULTS




TENNESSEE KNOXVILLE


RMS and maximum absolute acceleration considering various filter passband



Results after making the base isolation stiffer



RMS and maximum absolute acceleration considering various filter passband



Т

CONCLUSION

- Inerter creates large mass effects with only a small amount of physical mass.
- ➢ As expected from analytical models, the effect of the inerter is to reduce the isolation mode frequency.
- > The amplitude of the isolation mode was shown to be significantly reduced.
- It is ideal for scenarios where a lower isolation frequency is required, but the static deflection or dynamic response of the isolation mode should not be increased.
- A drawback of using an inerter in the isolation layer was observed when considering the RMS and peak value of the acceleration response due to increased high frequency response.
- ➤ The results of this work experimentally demonstrate the potential of isolation systems with inerters and encourage their further study.

This material is based upon work supported by NASA under corporative agreement No. 80NSSC20M0185. Any opinions, findings, and conclusions or recommendations expressed in this material are those of the authors and do not necessarily reflect the views of NASA.

A special thanks to The University of Tennessee for its effort to provide facilities and an environment for students and researchers to pace their achievements.

