

Advances in PSP Testing in LaRC High Reynolds Number Facilities

Daniel T. Reese and A. Neal Watkins
NASA Langley Research Center



AIAA SciTech Forum and Exposition

National Harbor, MD

January 25, 2023





- **PSP Background**
- **High Reynolds Number Facilities at LaRC**
 - **National Transonic Facility (NTF)**
 - **Transonic Dynamics Tunnel (TDT)**
- **Wind tunnel facility**
- **Recent upgrades**
- **Preliminary results**
- **Additional Advancements**
- **Summary & Conclusions**

PSP Background: Technique



Pressure sensitive paint (PSP)

- Powerful optical method providing global measurements of surface pressure.
- Well suited for application in a variety of NASA Langley wind tunnels.
- Can provide time-resolved measurements using a variant of the process known as unsteady PSP (uPSP).





Photophysical Process

1. UV light **excites** luminescent probe molecules suspended in a permeable polymer binder.
2. Excited molecules return to ground state, releasing photons in the process. (i.e. paint **fluoresces**)
3. Emission is **quenched** by oxygen molecules. Higher pressure equates to more O₂, resulting in more quenching.
4. Emission is **captured** by a camera such that darker regions = higher pressure.

NTF: Wind tunnel facility



- National Transonic Facility (NTF)
 - Highest Re_C in the world
 - $146 \times 10^6/\text{ft}$ at Mach 1
 - Isolate Re_C , M , and q effects
 - Mach 0.2 – 1.2
 - Air or nitrogen operation
 - T_t : 116K to 322K (-250 °F to 120 °F)
 - P_t : 100 to 830 kPa (15 to 120 psia)
 - Fan driven/closed circuit
 - 2.5 m x 2.5 m (8.2 ft x 8.2 ft) test section
 - Slotted floor/ceiling
- PSP/TSP testing conducted at NTF since late 1990s



NTF is a high pressure, low temperature environment


All equipment hardened for operation in the plenum (environmental enclosures not practical)

NTF: Recent upgrades — lighting





Lighting Improvements

- Over time, existing heating system for LEDs has progressively gotten worse
- Last PSP test showed significant degradation
 - Exposure times increasingly long as tunnel temperature lowered
 - Need for wind-off images showed lighting was extremely unstable
- New heating system devised and implemented for lights
 - Full cryogenic test in 01/2023
 - First used for PSP in 04/2023




Lighting provided by LED illuminators

- Custom built for NTF optical access
- 400 nm nominal wavelength (~20 nm FWHM)
- Radiant Flux: ~27W (each die)



Preliminary results show new heating method ~5x brighter.

NTF: Recent upgrades — paint application



Paint application improvements

- Traditionally, PSP applied on basecoat
 - Adds significant time, especially when tunnel is at cryogenic conditions
- Now apply cryogenic PSP directly to model surface [Christian Klein, *et al.*, AIAA 2020-0122]
 - Saves significant application time
 - Shows little degradation during tunnel operation (impacts, dust, oil, etc.)
 - Allows for reapplication
 - Wipe off PSP layer and reapply


TDT: Wind tunnel facility



Transonic Dynamics Tunnel (TDT)

- Continuous-flow, closed-circuit
- 16'×16' slotted test section
- $0.01 \text{ atm} < P < 1 \text{ atm}$
- $0 < \text{Mach} < 1.2$
- Max Reynolds number of:
 - $9.6 \times 10^6 / \text{ft}$ (in R-143a)
 - $3 \times 10^6 / \text{ft}$ (in air)
- Max Q: 26 kPa (550 psf) in R-134a
- Optimized for aeroelastic and dynamic testing

TDT is a low pressure, high temperature environment



Only facility in the world capable of testing dynamic aeroelastically-scaled models at matched Mach number.



uPSP slated for initial demonstration January 2023

TDT: Recent upgrades — paint formulation



uPSP for rarefied atmospheres:

- uPSP measurements in the TDT need to be able to work in the heavy gas environment (R-134a)
 - Still need oxygen to function
 - Keep “impurity” (air or oxygen) levels as low as possible
 - Need to be able to function in low tunnel pressure environment
- Calibration chamber set up to provide very low concentrations of air
 - Down to ~50 Pa (~ 1 psf)
 - Balance is nitrogen
- Very little sensitivity with standard uPSP
- Designed a newer uPSP formulation for very low oxygen concentrations
- However, this formulation cannot be used in air mode
 - New uPSP formulation rapidly quenches with increasing oxygen concentration
 - Will need the “standard” uPSP formulation for air mode testing
- Will be used in the upcoming test entry






TDT: Recent upgrades — enclosures



“The Enclosures” allow for uPSP in TDT


- Modular design to house high-speed camera & high-power UV LED lights.
- Constant supply & venting of cooling air maintains internal room P/T as tunnel P reduced & T increased.
- Remotely monitor interior environment and control all equipment contained within from control room.



High-Powered UV Lights



High-Speed Camera




TDT: Recent upgrades — high speed datalink



Capturing TB of data per camera each day needing processing and storage



- High speed datalink between wind tunnel and LaRC's high performance compute resource
 - Need way to process/store large datasets quickly → "10 Gbps" line between TDT and K-Cluster
 - Quick turnaround opens the door for "near real time" uPSP results during testing




TDT: Preliminary results




Comparison with Kulite sensors



P_{RMS}





Spectral Comparison



Pressure time history

Dynamic Mode Decomposition (DMD)



Additional Advancements: Skin friction from PSP




- Qualitative skin friction lines can be calculated from pressure and temperature gradients
- Work currently being done under an SBIR Phase II contract with Innovative Scientific Solutions, Inc. & Western Michigan University
- Requires no additional experimentation
 - If quantified skin friction is required, may need to instrument with a few skin friction sensors
 - Can be used on new or legacy data (in which PSP y/c or TSP information has been acquired)

Skin friction topology extracted from surface pressure data of a supercritical airfoil

Will be implemented in upcoming testing campaigns

[T. Liu, *et al.*, MST 2016]



Extracted Skin Friction Field

Summary & Conclusions



- PSP is a powerful measurement technique well suited for application in a variety of NASA Langley wind tunnels
 - uPSP provides time-resolved global surface pressure measurements, a vast improvement over the point measurements returned using traditional dynamic pressure sensors
 - Refined UV light heating design shows initial 5x improvement over existing standard
 - Improved paint application technique in NTF will yield superior cryogenic PSP measurements
 - Enclosures will allow for the first uPSP measurements in the TDT facility, even in heavy gas and reduced pressure
 - New paint formulation enables sufficient sensitivity for PSP measurements under rarefied/low O₂ conditions
 - Established a high-speed datalink between wind tunnel and center HPC, promoting rapid processing and enabling “near-real-time” pressure measurements
 - “Bonus” skin friction measurements can be extracted from PSP and/or TSP data as additional capability to any PSP/TSP data collection
- Funding for this work provided by the following programs in NASA:
 - Transformational Tools and Technologies (TTT) Innovative Measurements (IM) subtask
 - TTT Revolutionary Computational Aerosciences (RCA) subtask
 - Aerosciences Evaluation and Test Capabilities (AETC)