

Characterization of Additively Manufactured GRCop-42 And GRCop-84

Wayne D. Jennings¹ and David L. Ellis²

¹ HX5, LLC at NASA Glenn Research Center, 21000 Brookpark Rd., Cleveland, OH 44135

²NASA Glenn Research Center, 21000 Brookpark Rd., Cleveland, OH 44135

Society of Applied Spectroscopy
the 65 th Annual MAY meeting conference
May 24th, 2023
John Carroll University, Dolan Science Center
University Heights, OH

The Application - Regeneratively Cooled Rocket Engine Main Combustion Chamber Liners



- **Rocket engine liners have complex internal cooling channels (flowing propellants) required to keep the liners from melting**
- **A major shift has occurred in their manufacturing**
 - The traditional subtractive and joining methods were costly and required months or even years to make a chamber assembly
 - Additive manufacturing decreases cost and time significantly while enabling new designs
- **Changing to Laser Powder Bed Fusion (L-PBF) additive manufacturing requires detailed characterization to confirm that the new method will produce similar thermophysical and mechanical properties compared to traditional manufacturing methods**



30,000 lb_f class GRCop-84
combustion chamber liner
made from L-PBF

Hot Fire Test Of 30k lbf AM LPBF GRCop-84 Engine Liner (Low Cost Upper Stage Program)



Full video at:

https://www.youtube.com/watch?v=FfeP4BVTsps&ab_channel=NASA%27sMarshallSpaceFlightCenter

Material Requirements for GRCop Alloys

- **Liner material must have**
 - High thermal conductivity
 - Higher elevated temperature strength up to 700-800 °C
 - Longer low cycle fatigue (LCF) life
 - Longer creep life / slow creep rate
- **In addition, low thermal expansion is desired to help minimize thermally induced stresses**
- **GRCop Alloys**
 - **A family of Cu-Cr-Nb alloys with a nearly pure Cu matrix strengthened by Cr₂Nb particles**
 - **GRCop-42 and GRCop-84 have been successfully tested and flown**
 - GRCop-42 (Cu-4 at.% Cr-2 at.% Nb) has higher thermal conductivity but slightly lower strength and life in reusable launch vehicles
 - GRCop-84 (Cu-8 at.% Cr-4 at.% Nb) trades thermal conductivity for longer life in reusable engines

Samples Examined and Build Parameters

- **NASA is examining ten samples made by multiple processing routes**
 - Eight GRCop-42 and two GRCop-84 builds were examined
- **Program is measuring geometric capabilities, thermophysical properties, mechanical properties, microstructure, surface texture, and chemistries to determine effect of powder lot, machine, and build parameters**


Identifier	Alloy	Company	Machine	Layer Height (um)	Recoater	Energy Density (J/mm ³)	Scan Strategy
GRCop-42-1	GRCop-42	A	EOS M280	40	Rubber	75	Continuous
GRCop-42-2	GRCop-42	B	EOS M290	45	Steel	90.3	Stripes
GRCop-42-3	GRCop-42	B	EOS M400-1	60	Steel	83.3	Stripes
GRCop-42-4	GRCop-42	C	EOS M400-1	40	Rubber	75	Continuous
GRCop-42-5	GRCop-42	A	EOS M280	40	Steel	75	Continuous
GRCop-42-6	GRCop-42	D	EOS M290	40	Carbon Fiber Brush	N/A	N/A
GRCop-42-7	GRCop-42	E	EOS M400-4	60	Steel	83.3	Stripes
GRCop-42-8	GRCop-42	F	EOS M290	45	Carbide	90.3	N/A
GRCop-84-1	GRCop-84	G	Concept M2	30	Rubber	100	Checkerboard
GRCop-84-2	GRCop-84	H	EOS M290	40	Steel	107.1	Stripes

Bulk Chemical Analyses - Ametek Arcos Inductively Coupled Plasma – Optical Emission Spectroscopy (ICP-OES)



- **Ametek Arcos Inductively Coupled Plasma – Optical Emission Spectroscopy (ICP-OES) unit used to determine metals between H and U**
 - Necessary for discovery of unknown trace elements
 - Analyzes spectra between 130 nm and 770 nm wavelengths
- **LECO 844 Series Combustion Analyzer was used for C and S**
- **LECO 736 Series Inert Gas Fusion unit was used for N and O**
 - C, S, and O are detected with non-dispersive infrared (NDIR) cells tuned to the element being measured
 - N is detected by the change in thermal conductivity of the gas relative to the carrier gas

Typical ICP-OES Cr Spectrum And Analysis



- Sample spectra are compared to reference spectra
- Combination of wavelength, intensity, and reference spectra used to identify the elements present and quantify the amounts
- ICP-OES is capable of ppm level detection of metals

Bulk Chemistries



Alloy	Sample	Controlled Elements							Cr:Nb Ratio	
		Cu	Cr (wt.%)	Nb (wt.%)	Fe (ppm)	O (ppm)	Al (ppm)	Si (ppm)	Weight Basis	Atomic Basis
Nominal	Aim	Bal.	3.32	2.95	<20	<400	-	-	1.14	2.03
GRCop-42	GRCop-42-1	Bal.	3.22	2.82	90	795	16	390	1.14	2.03
GRCop-42	GRCop-42-2	Bal.	3.29	2.95	70	530	10	220	1.11	1.99
GRCop-42	GRCop-42-3	Bal.	3.25	2.89	70	435	9	210	1.13	2.01
GRCop-42	GRCop-42-4	Bal.	TBD							
GRCop-42	GRCop-42-5	Bal.	3.20	2.77	90	885	21	340	1.15	2.06
GRCop-42	GRCop-42-6	Bal.	3.31	3.08	40	510	9	200	1.08	1.92
GRCop-42	GRCop-42-7	Bal.	3.16	2.75	30	710	7	110	1.15	2.05
GRCop-42	GRCop-42-8	Bal.	TBD							
GRCop-84	Aim	Bal.	6.65	5.85	<20	<400	-	-	1.14	2.05
GRCop-84	GRCop-84-1	Bal.	6.48	5.77	20	1210	9	60	1.12	2.00
GRCop-84	GRCop-84-2	Bal.	6.52	5.61	40	1175	9	310	1.16	2.08


N.D. - No detectable peak in spectrum

<X - Peak detected but concentration below lower limit of detection


Alloy	Sample	Trace Elements								Other Interstitial Elements		
		Ag (ppm)	Co (ppm)	Mo (ppm)	Ni (ppm)	P (ppm)	Ti (ppm)	Y (ppm)	Zr (ppm)	C (ppm)	S (ppm)	N (ppm)
GRCop-42	GRCop-42-1	16	22	<50	160	50	< 10	< 1	N. D.	19	7	22
GRCop-42	GRCop-42-2	10	N. D.	N. D.	20	30	< 10	N. D.	N. D.	13	7	21
GRCop-42	GRCop-42-3	9	N. D.	N. D.	20	30	< 10	N. D.	N. D.	8	8	22
GRCop-42	GRCop-42-4	TBD										
GRCop-42	GRCop-42-5	21	21.3333	<50	150	50	< 10	113	N. D.	32	12	38
GRCop-42	GRCop-42-6	9	N. D.	N. D.	10	30	N. D.	N. D.	N. D.	13	8	23
GRCop-42	GRCop-42-7	7	14	100	50	40	40	3	7	7	8	4
GRCop-42	GRCop-42-8	TBD										
GRCop-84	GRCop-84-1	9	N. D.	N.D.	10	20	< 10	N. D.	N. D.	22	11	7
GRCop-84	GRCop-84-2	9	20	<50	10	130	< 10	N. D.	N. D.	33	13	29

GRCop-42 Cr, Nb, and Cr:Nb Ratios Compared to Specification


Cr



Nb




Cr:Nb Ratio



- Cr is below the aim but falls within the specification limits
- Nb is below lower specification limit
 - Problems encountered dissolving Nb into melt
 - Corrected in more recent powder atomization runs
- Cr:Nb is within specification because both Cr and Nb were low
 - Probably have 6-6.5 vol.% Cr₂Nb instead of target 7 vol.%

Phase Identification: X-ray Diffraction (XRD) Of Extracted Particles


- **Particles first extracted to concentrate them and make detection of minor phases easier**
 - Cu dissolved with concentrated nitric acid
 - Remaining particles filtered through 0.45 μm filter paper
- **Bruker D8 Advance diffractometer used for XRD**
 - Cu K_{α} radiation
 - Small step size and long dwell time for maximum S/N
- **JADE software used to implement whole pattern fitting (WPF, aka, Rietveld refinement)**
 - Allows quantitative measurement of phases present




D8 goniometer (above) and unit (below)



XRD Phase Analyses



Example of particles



XRF Spectra

Sample	Alloy	Total (wt.%)	Cr ₂ Nb	Cr	NbO [†]	Cu ₂ O
GRCop-42-1	GRCop-42	6.83	83.9	7.3	-	5.5
GRCop-42-2	GRCop-42	7.12	90.7	8.7	0.6	
GRCop-42-3	GRCop-42	7.26	94.4	5.6		
GRCop-42-4	GRCop-42	6.05	93.5	5.6	-	1.9
GRCop-42-5	GRCop-42	6.27	74.7	23.6		1.7
GRCop-42-6	GRCop-42	4.92	74.7	23.6		1.7
GRCop-42-7	GRCop-42	7.55	86.2	7.8	6.0	
GRCop-42-8	GRCop-42	7.17	94.0	6.0		
Average		6.64	86.5	11.0		
Nominal Cr ₂ Nb		6.1				
GRCop-84-1	GRCop-84	12.69	82.7	10.0	7.3	
GRCop-84-2	GRCop-84	12.70	81.4	11.2	7.5	
Average		12.70	82.1	10.6		
Nominal Cr ₂ Nb		12.3				

[†]NbO in Samples GRCop-42-1 and GRCop-42-4 not reported due to poor peak fit

TESCAN MAIA-3 Field Emission Scanning Electron Microscope (FESEM) With EDS and EBSD Capabilities




- FESEM operated at 20 kV to provide EDS data for Nb ($K\alpha=16.581$ keV) and strong EBSD patterns
- Energy Dispersive Spectroscopy (EDS)
 - Oxford X-MAX 50 EDS mapped macroscopic chemical compositions
- Electron Backscattered Diffraction (EBSD)
 - Oxford Nordlys Nano unit mapped phases and crystallographic data
- Data analysis was conducted using Oxford Instruments AZtec software




TESCAN MAIA-3 SEM at NASA GRC


Typical EDS Spectrum For Mounted GRCop-42 Sample




Typical Mounted Sample EDS TruMap X-ray Maps




Secondary Electron (SE) Image




Cu, K Series




Cr, K Series



Nb, L Series




Al, K Series




O, K Series


Typical EDS Spectrum For Extracted Particles




Typical Particle EDS TruMap X-ray Maps




Secondary Electron (SE) Image




Cu, K Series




Cr, K Series



Nb, L Series




Al, K Series




O, K Series

EDS X-ray and EBSD Phase Maps

EDS X-ray Maps




EBSD Phase Map




Phase Name	Phase Fraction (%)
Cu	97.87
Cr	0.22
Cr₂Nb FCC C15	0.64
Cr₂Nb Hex. C14	1.26
Zero Solutions	0.01

EBSD Inverse Pole Maps And Pole Figures For Typical HIPed GRCop-42 Sample


IPF Orientation Maps




IPF-X



IPF-Y (Build Dir.)





IPF-Z



The IPF-Y map indicated a strong crystallographic orientation in the Y direction, the build axis


Pole Figure




Typical Cu Residual Strains In HIPed GRCop-42



Grain Orientation Spread
(GOS) Map





Maximum Orientation Spread
(MOS) Map



- Heat color maps indicate the degree of residual strain and by inference residual stresses
- Two measures of strain were calculated
 - GOS calculates the average orientation of the grain, compares every pixel's orientation to the average, and determines the mean difference giving the average deformation in a grain
 - MOS is similar to GOS but uses the maximum difference within a grain rather than the average
- Higher values (yellows and reds) indicate more strain and hence higher residual stresses
- Results indicate HIPing successfully recrystallized the Cu grains but new grains retained strong texture

Cu Grain Size And Morphology In HIPed GRCop-42 Sample




Minimum grain – 10 pixels
Minimum grain boundary
angle - 3°

Measurement	Minimum	Maximum	Mean	Standard Deviation
Area (μm^2)	6.4	1,329.28	15.93	27.47
Aspect Ratio	1.04	11.32	2.2	0.88
Breadth (μm)	0.8	44.96	3.65	1.76
ECD (μm)	2.85	41.14	4.15	1.76
GOS (°)	0.52	4.13	1.71	0.42
Length (μm)	3.58	76.56	7.7	4.18
MOS (°)	0.91	11.51	3.36	1.08
Perimeter (μm)	8.84	650.07	20.68	17.89
Slope (°)	2.81	175.78	85.48	37.92

- Many pixels were not successfully indexed
- Potential causes:
 - Secondary phases
 - Very fine grains
 - Grain boundaries
- The results are still likely representative of most Cu grains


Selected Histograms Of Cu Grain Measurements

Equivalent Circular Diameter (ECD)



- There may be smaller grains than detected using 10 pixels
- Would need smaller step size in EBSD to resolve them


Aspect Ratio




- Grains are elongated based upon the aspect ratio

Selected Histograms Of Cu Grain Measurements (Cont.)

Slope



Maximum Orientation Spread (MOS)



- Unusual notches in slope histogram noted
- More work is needed to understand this phenomenon

- Small MOS angles indicate low strains and low residual stresses
- Highest MOS grains retain some residual stresses but are minimal in number

Summary


- A combination of spectroscopic and other techniques was used to characterize AM L-PBF GRCop alloys produced on multiple build platforms using different powder lots, machine setups, and processing parameters
- The results showed the bulk chemistries were similar but did have varying Cr:Nb ratios and other minor differences
- Phase extraction and XRD gave quantitative values of the phases present and revealed NbO as a ceramic inclusion
- EDS revealed that there was a nearly pure Cu matrix with Cr_2Nb , Cr, NbO, and Al_2O_3 particles. Al_2O_3 was not observed in XRD because it was encapsulated in the NbO.
- EBSD revealed a crystallographically textured, fine grained, columnar Cu grain structure even after a HIP cycle that recrystallized the Cu grains

Conclusions


- **Spectroscopic techniques such as ICP-OES, XRD and EDS can make significant contributions to characterizing and understanding AM materials**
- **Adding other techniques in parallel such as EBSD can add additional information that can lead to a detailed understanding of results such as mechanical property anisotropy**

Backup Slides


EDS X-Ray Maps For Ceramic Inclusions




Secondary Electron (SE) Image




Cu, K Series




Cr, K Series



Nb, L Series




Al, K Series




O, K Series

Representative EBSD Kikuchi Patterns

Cu




Cr₂Nb, C15 FCC




Cu Grain Size Distributions

Length (Major Axis)




Breadth (Minor Axis)




Neighbors and Grain Orientation Spread (GOS)



Number of Neighboring Grains



Grain Orientation Spread (GOS)



Grain Slope - 1° Bins

Slope

