




NASA's BioSentinel mission: lessons learned & what's next


Sergio R. Santa Maria ARC Space Biosciences

sergio.santamaria@nasa.gov

What are we going to encounter beyond LEO?



What are we going to encounter beyond LEO?




- Both interplanetary & modulated by the solar cycle
- GCRs: high-energy protons and highly charged, energetic heavy particles
- GCRs not effectively shielded & can fragment

<u>Challenges</u>: SPEs – unpredictable; large doses in short time


GCRs – biology effects poorly understood (but most hazardous)

Cell nuclei showing DNA damage






The limits of life in space - as we know it - is 12.5 days on a lunar round trip or 1.2 years in LEO. As we send people further into space, we need to understand the biological risks and how they can be addressed





NASA Ames biological CubeSat missions







NASA Artemis I mission












Artemis 1: secondary payloads (6U CubeSats)













BioSentinel mission

Objectives:

- o Develop a deep space tool with autonomous life support technologies
- o Study the space radiation environment beyond LEO and its effect on biology

What is it & what's inside?

Key Parameters					
Form Factor	# Spacecrafts	Orbit	Launch Date		
6U CubeSat	1	Heliocentric	Nov 16, 2022 (SLS Artemis I)		
Mass	Dispenser or Interface	Mission Duration	Current Phase/Activity		
~ 14 kg	OSA 6U dispenser	6 months	Science Phase		





BioSentinel mission

Objectives:

- o Develop a deep space tool with autonomous life support technologies
- o Study the space radiation environment beyond LEO and its effect on biology

What is it & what's inside?

Key Parameters					
Form Factor	# Spacecrafts	Orbit	Launch Date		
6U CubeSat	1	Heliocentric	Nov 16, 2022 (SLS Artemis I)		
Mass	Dispenser or Interface	Mission Duration	Current Phase/Activity		
~ 14 kg	OSA 6U dispenser	6 months	Science Phase		

Payload & Bus	Instrument #1	Instrument #2	Spacecraft Bus	Spacecraft Bus
Title/Acronym	4U BioSensor payload	LET spectrometer	Iris v2 radio	Propulsion system
Organization	NASA ARC	NASA JSC	JPL	Georgia Tech

Data Systems	Mission Operations Center	Science Operations Center	Ground Station/Network	Data Repository
Title/Acronym	MMOC	BioSentinel SOC	Deep Space Network	ТВС
Organization	NASA ARC	NASA ARC	NASA	NASA






BioSentinel mission

Objectives:

- Develop a deep space tool with autonomous life support technologies
- o Study the space radiation environment beyond LEO and its effect on biology









BioSentinel: key components

Subsystem	Description	Vendor	Subsystem	Description	Vendor
4U BioSensor			LET spectrometer		
Fluidics	18 PC cards & manifolds with integrated valves, pumps, bubble traps & desiccant chambers	NASA ARC	Radiation sensor	Timepix-based sensor (TID and LET particle characterization)	NASA JSC
Optics	3 LED lights & TAOS sensor per fluidic well (16 wells per card)		Bus ADCS		
Thermal	Dedicated thermal control per fluidic card		Reaction Wheels / Star Tracker / IMU	XACT 3-axis Attitude-Control System & Star Tracker	Blue Canyon Technologies
Sensors	Temperature, RH, pressure		Sun Sensors	5 sun sensors	SolarMEMS
Bus C&DH			Bus Power		
Processor	UT700 LEON 3	Space Dynamics	EPS	TI-MSP430 FRAM	NASA ARC
Data Storage	MRAM & Flash		Batteries	18650B Li-ion	Panasonic
Bus Comm			Solar Array	4 HaWK solar arrays	MMA Design
Radio	Iris v2 transponder	JPL	Propulsion		
Antenna	Medium & low gain		Thruster	7-nozzle 3D printed system	Lightsey Space Research




BioSentinel: science payloads























BioSentinel: microfluidic system
























BioSentinel: microfluidic card


















BioSentinel: optical detection system

Dedicated 3-color optical system at each well to track growth *via* optical density and cell metabolic activity *via* dye color changes


LEDs:


570 nm (green, measures pink)


630 nm (red, measures blue)

850 nm (infrared, measures growth)










alamarBlue turns pink when cells are metabolically active



HR repair defective cells show sensitivity to ionizing radiation



BioSentinel: optical detection system

Dedicated 3-color optical system at each well to track growth *via* optical density and cell metabolic activity *via* dye color changes


LEDs:


570 nm (green, measures pink)


630 nm (red, measures blue)

850 nm (infrared, measures growth)










alamarBlue turns pink when cells are metabolically active




HR repair defective cells show sensitivity to GCRsim ionizing radiation



BioSentinel: ISS experiment

- ISS instrument launched on SpaceX CRS-24 on Dec 21, 2021, and installed into SABL incubator
- First set of fluidic cards (1 out of 9) activated on Jan 31; last one completed in mid-June
- ISS payload returned on SpX-25 in late-August
- Data will be used as LEO microgravity control and compared to deep space mission data

Card 8 optical readings after ~72 hours







Bio activity ~48 hours after activation (and continued for ~7 days)

Reagents (growth medium and alamarBlue dye) working properly

ISS LET spectrometer data from April 14






Ground control unit at NASA ARC




BioSentinel: ISS experiment (card 8 example)





BioSentinel: how did we get here?





- Model organism & strain selection
- How to fly the biology? Dry/wet?
- Long-term viability & biocompatibility
- Materials, sterilization method, reagents, fluidic components...
- Multiple fluidic cards; 288 wells
- LEO control (and ground)
- Data telemetry & processing





BioSentinel: radiation environment characterization

- LET spectrometer instrument mounted outside the BioSensor enclosure (free-flyer, ISS, ground)
- Reports cumulative ionizing radiation dose & particle distribution based on linear energy transfer (LET)

Performing nominally; unaffected by BioSensor issues


Science objectives:

- Characterize radiation environment
- Compare ISS, deep space, and ground data
- Characterize contribution from solar and GCR particles
- Characterize solar particle event (SPE)




	Absorbed dose rate (mGy/day)	Total absorbed dose since Artemis I launch (Nov 16)
Ground	~ 0.002 - 0.003	< 0.5 mGy
ISS (120-day average)	0.218	-
Free-flyer (248-day average)	0.298	73.7 mGy (as of July 21, 2023)
Free-flyer (projected by modeling)	0.25 ± 0.04	-


Ground LET spectrometer - Dec 16



ISS LET spectrometer - April 14



Free-flyer LET spectrometer – Dec 16





BioSentinel: radiation environment characterization


- LET spectrometer instrument mounted outside the BioSensor enclosure (free-flyer, ISS, ground)
- Reports cumulative ionizing radiation dose & particle distribution based on linear energy transfer (LET)

Performing nominally; unaffected by BioSensor issues

Science objectives:

- Characterize radiation environment
- Compare ISS, deep space, and ground data
- Characterize contribution from solar and GCR particles
- Characterize solar particle event (SPE)

LET spectrum (in Si; 20M events); first 49 days





	Absorbed dose rate (mGy/day)	Total absorbed dose since Artemis I launch (Nov 16)
Ground	~ 0.002 – 0.003	< 0.5 mGy
ISS (120-day average)	0.218	-
Free-flyer (248-day average)	0.298	73.7 mGy (as of July 21, 2023)
Free-flyer (projected by modeling)	0.25 ± 0.04	-




BioSentinel: radiation environment characterization

- CME event on March 13
- >100 MeV proton intensity enhancement
- Steady return to background levels
- BioS LET spectrometer detected event









BioSentinel: top risks & lessons learned

	Risk Description	Mitigation Approach
1	Long-term pre-launch integration time for biology	Turn spacecraft over as late as possible
2	DSN antenna oversubscription	Use non-DSN antennas (e.g., ESA)
3	Flight software update after deployment	SIM tests; revert to previous version if issues arise



BioSentinel: top risks & lessons learned

	Risk Description	Mitigation Approach
1	Long-term pre-launch integration time for biology	Turn spacecraft over as late as possible
2	DSN antenna oversubscription	Use non-DSN antennas (e.g., ESA)
3	Flight software update after deployment	SIM tests; revert to previous version if issues arise

	What Happened?	What did we learn from it?	Proposed Mitigation Strategies	Recommended Actions
1	Lower (than expected) yeast viability on ISS unit	Long duration effects inside sealed enclosure decreases viability of biology	Late integration	Modify design for future missions to include late load and integration options; add more desiccant inside payload enclosure
2	Unknown launch date	Loss of personnel & constant changes in trajectory	Analyze risks associated with unique mission conditions	Document for later project personnel on why specific decisions were made
3	Late payload EVT not ideal	EVT provided many lessons learned that could not be implemented for this mission	Work around issues without design changes	Conduct early EVT (scaled down EVT) to feed potential design changes



BioSentinel: top issue

Top Issue: launch delays

Issue: Artemis I launch had multiple launch delays independent of secondary payloads

How the project managed the issue?
Long-term testing (reagents, biology, etc.)

Environmental monitoring requests once at KSC

Constant communication with NASA HQ

Results: Loss of personnel

Constant replanning (e.g., moving trajectories)

Additional battery recharging

Effects of long-term storage inside BioSensor enclosure


Recommendations: Constant communication between project, NASA, and SLS

Plan for such complex mission (e.g., personnel, battery charging)


Improve environmental monitoring if biology involved




BioSentinel: lessons learned & LEIA




<u>LEIA</u>: Lunar Explorer Instrument for space biology Applications







- Three awarded Space Biology ground investigations (two ARC Pls)
- Significant instrument heritage from BioSentinel
- ARC team selected for a PRISM2 award to perform science experiments on the lunar surface (synthetic biology & stress/damage response)
- LEIA will have additional countermeasures to improve long-term viability (e.g., late load of biology and improved desiccant storage)
- LEIA suite also include a LET spectrometer and a fast neutron detector
- Power & data from CLPS lander







LEIA lunar surface mission

Science Aims:

- 1. Determine cellular sensitivity to the lunar environment
- Test production of antioxidant carotenoids for use in crew dietary supplementation.
- Engineer genes from tardigrades and yeast to test for enhanced tolerance to the lunar surface
- Measure biologically relevant radiation at the south pole landing site










ARES LET Spectrometer



Mini-FND





How are we improving LEIA based on lessons learned from BioSentinel?



LEIA improvements

LEIA prototype (open configuration)








LEIA improvements

How are we preventing high humidity inside the BioSensor enclosure?




Increased desiccant

Improved seals & protected connectors



LEIA improvements



Redesigned bag tray & re-routed plumbing

Late load installation



BLEO instrumentation: future & ongoing

A flexible design that will be used in different space environments

