


Engineered Hexagonal Boron Nitride: Titanium Dioxide Composites for High Voltage Insulation

Dr. Sean P. McDarby (USRA),
Alanys V. Luna (University of Puerto Rico),
Dr. Diana Santiago (GRC),
and Dr. Maricela Lizcano (GRC)
NASA Glenn Research Center (GRC)
Universities Space Research Agency (USRA)
Cleveland, Ohio, USA
ICACC – February 1, 2024

www.nasa.gov





High Power Transformation of Aerospace





Limits of Power Transmission in Aerospace






A. Amasour, D. Sacksteder, A. Goretski, M. Lizcano, NASA/TM-20205008006

- Credit: Woodworth, A.
- High current requires thick and heavy copper cables, which have high resistance
- High voltage requires thick commercial insulation
- Temperature tolerance is and issue in the state-of-the-art insulation



Insulation Material Targets

- Enhanced Thermal Conductivity
- Resistance to partial discharge
- Functional Operation Temperature
 > 200 °C
- Temperature Tolerant > 260 °C
- Retains Dielectric strength of SoA materials
- Decrease diameter and weight of insulation
- Retain high strength of cable system






Hexagonal Boron Nitride as an Insulation Material


- NASA Glenn Research
 Center (GRC) has spent 20
 years specializing in boron
 nitride-based research.
- Applied widely in many applications commercial and industrial.
 - Aerospace and space components
 - Radiation Shielding
 - Energy Storage
 - Lubricants
 - Thermoelectrics
 - Cosmetics
 - Paints
 - Insulation materials
 - Microelectronics

Properties

- Insulation
 - Wide bandgap above 6 eV
- Mechanical Strength
 - Similar to graphite, hard and shearing.
- Thermal Conductivity
 - hBN ~ 100 W/m·K in plane, ~ 10-30 W/m·K through plane
 - Strong thermal shock characteristics
- Stability
 - Hydrophobic
 - Chemically stable
 - Stable above 1000 °C in air
- Lightweight
 - 2.1 g/cm³



ACS.org



O. Shinpei, S. Fukushima, M. Shimatani, *Materials* **2023**, *16*(5), 2005

Engineered Hexagonal Boron Nitride




Material Control

- Shape Control
 - Platelet structure, some rods and amorphous spheres
 - Control of aspect ratio/number of layers is key
 - Can be sintered and made into larger structures. (pyrolytic)
- Size Control
 - 100s nm to 100 μm wide as platelets
 - 1 atom thick to 10s of µm thick


Multifunctionality


- Edge and surface functionalization
 - Oxidation, Silanation, Hydrogenation
- Intercalation
 - Metal Halides, Salts,
 Solvents/polymers
- Exfoliation
 - Thinner layers
 - Expanded layers

Momentive PT 110 hBN



PT 110 hBN Exfoliated with TiO₂





Three Types of Intercalation



4

Iron Oxide

- Separating Layers
- Fully removeable

B


Alumina

- Ceramic Compatibility
- Improved Thermal Shock





Custom Kettle Furnace for Intercalation




Single FeCl₃ Exfoliation hBN Credit: Nguyen, B.

C

Titania

- Crystal Tunability
- Dielectric Strength
- Composite Matrix





Titania Properties

Titanium Dioxide

- Sintering temperature ~1500 C
- Hot pressable and formable
- Lower Thermal Conductivity, but close (~7-10 W/m·K)
- Capacitive

Two major crystal forms, anatase and rutile

Anatase

- Lower density (3.78)
- Lower dielectric constant ~14/110¹
- Interesting semiconduction/ion conductivity properties, bandgap of 3.4 eV²
- Longer e-hole pair lifetime can promote chemistry (better photocatalyst)

Rutile


- Denser form (4.23) higher than alumina
- More stable form
- Higher dielectric constant ~89/170¹, bandgap of 3.0 eV²
- Bright white, used in paints


Preferentially makes small nanoparticles upon oxidation

Allows for targeted final product control




Titania Coating Method







Sample Coated by oxidation/metal addition




Sample Coated by diluted TTIP/Water injection method









The Crystal Structure is Easily Tunable





hBN Coated with Anatase TiO₂





hBN Coated with Rutile TiO₂

Titania Intercalation and Exfoliation


Method optimization

- TiCl₃ is hard to work with
 - Rapidly reacts with wet air
 - Low boiling point/sublimation
 - Liquid at room temperature
 - Likely to form oxide before removal or hydration
- Titanium tetraisopropoxide (TTIP)
 - Reacts slower with air
 - High boiling point (close to AlCl₃ and FeCl₃)
 - Can be diluted with isopropanol for optimal coating
 - Larger molecule
 - Liquid at room temperature





Momentive PT110 hBN (40-100 µm platelets) Intercalated and Exfoliated with TiO₂



Insulation Composite Testing



Methods of Insulation Composite Testing

- Twin screw extrusion of target high temp polymer
 - Requires large amounts of powder composite >10 grams per run depending on loading
 - Trial an error required to achieve goal loadings
 - The best method of mixing, can make tapes and wires but hard to start with
- Small scale compounding and injection molding
 - Limited to thermoplastic polymers
 - Requires expensive equipment to use high temperature polymers
 - High throughput

Tape Casting

- Works at very small sample sizes
- Can use high temp stable thermosets without expensive equipment
- Settling of composite material may be an issue
- High throughput

High Temp Tape Extrusion



PDMS Tape Cast with hBN








Polydimethylsiloxane (PDMS) chosen as tape cast polymer matrix

- Silgard 184 Elastomer (PDMS type)
 - Good Dielectric properties
 - Can withstand temps up to 200 C
 - Room temperature cure
 - Accelerated cure at higher temperatures
 - Low enough viscosity to mix well with composites
- Processing conditions,
 - Mix elastomer and hBN powders by shear mixing (Thinky mixer)
 - Degas
 - Pour and cast into a tape
 - Allow to cure at elevated temp over night

PDMS Tape Cast with hBN




Samples Cut and Stacked for Thermal Conductivity/Breakdown







PDMS Tape Cast Composite Testing



30% AC6097 (500 nm platelets) Small



30% PTC120 (5-10 µm platelets) Medium




30% PT110 (40-100 µm platelets) Large


- Cross Section Images show particle sizes inside tape
- Larger particles less well mixed and likely include air voids
- Not many particles on the surface



PDMS Tape Casting Optimization



- Thermal conductivity measured by a modified transient plane source (C-Therm, surface dissipation method)
- Breakdown done in DC 2 kV/s ramp
- Small (500 nm), Medium (5-10 μm), Large (40-100 μm)






Summary of Achievements and Future Work

Accomplishments


- hBN platelets coated with titania, and both crystal patterns formed by heat treatment
- hBN exfoliated with titanium isopropoxide and separated particles formed with titanium nanoparticles interspersed
- Test platform composite properties chosen as a PDMS matrix and tested across multiple hBN types

Future Work


- Process improvement for large particle mixing
- Confirmation of internal structure of exfoliated hBN
- Dielectric properties testing of composites
- Multilayer stacking
- Large scale tape extrusion
- High yield exfoliation process optimization



Exfoliated PT110 with Titania



Tape extrusion from twin screw extruder



hBN/PDMS cross section

Thank You!



- **Transformational Tools and** Technologies (TTT) Project
- **GRC Boron Nitride Team**
 - Dr. Sean Patrick McDarby
 - Dr. Diana Santiago
 - Dr. Maricela Lizcano
 - Dr. Kristina Vailonis
 - Dr. Tiffany Williams
 - Dr. Baochau Nguyen
 - Dr. Witold Fuchs
 - Dr. Ching-cheh Hung (retired)
 - Ms. Alanys V, Luna
 - Ms. Janet Hurst (retired)
- Materials Chemistry and **Physics Branch**
- Materials and Structures Division





