

Nondestructive Evaluation Sciences Branch


Thermal Inspection of Low Emissivity Surfaces Using a Pulsed Light Emitting Diodes (PLED) Heat Source

Joseph N. Zalameda,

Peter W. Spaeth, and Samuel J. A. Hocker


NASA Langley Research Center

SPIE Thermosense Conference April 21 – 25, 2024



Outline

- Introduction/Motivation
- Pulsed Light Emitting Diodes (PLED) Heat Source Description and Setup
- PLED Thermography Inspection Results
 - Unpainted Aluminum Sample with Material Loss
 - Unpainted Aluminum Sample with Circular Material Loss
 - Polished Ti-6Al-4V Disk Inspection
- Quantitative Single Side Model Fit
- Conclusions



Introduction


Nondestructive Evaluation Sciences Branch

Objectives

- Develop heat source for reflective (low emissivity) surfaces and therefore remove requirement to paint or apply a stick-on emissivity enhancement layer
- Investigate the use of high-powered LED chips for thermal nondestructive evaluation
- Measure sample with known defects and compare to conventional flash thermography
- Investigate quantitative thermal NDE with PLED heat source

Payoffs

- Inspection of area “as is” saves inspection complexity, time and cost especially for large area inspections
- Improve model based quantitative single side thermal inspections



PLED Light Configuration and Spectral Output


Nondestructive Evaluation Sciences Branch


PLED Light Configuration



17 cm

PLED Light Spectral Output







Direct View Observation of Heat Source


Nondestructive Evaluation Sciences Branch

Direct View of Heat Source



Single Pixel Plot







PLED Thermal Inspection Setup

Nondestructive Evaluation Sciences Branch

PLED Thermal Inspection System



Drawing of PLED Thermal Inspection System





Emissivity Measurement of Inspected Samples

Nondestructive Evaluation Sciences Branch

Sample	Average Surface Temperature (Celsius)	Measured Emissivity
Unpainted Aluminum Sample with Material Loss	39.3	0.35 +/- 0.020
Unpainted Aluminum Sample with Circular Material Loss	44.3	0.21 +/- 0.012
Polished Additive Manufactured Ti-6Al-4V Disk	65.8	0.39 +/- 0.017
Painted Aluminum Sample	34.3	0.90 +/- 0.008



Inspection of Aluminum Sample with Material Loss

Nondestructive Evaluation Sciences Branch

Picture Front




Picture Back



Material Removed

7.6 cm


Flash Thermal Inspection




7.6 cm

Flash Lamp Reflections

PLED Thermal Inspection






Inspection of Aluminum Sample with Circular Material Loss

Nondestructive Evaluation Sciences Branch


Picture Front



Picture Back



Flash Thermography Inspection



PLED Thermography Inspection





Inspection of Unpainted Polished Ti-6Al-4V Additively Manufactured Disk


Nondestructive Evaluation Sciences Branch

Polished Disk



21.0 mm


Flash Inspection




Porosity Indications

Flash Inspection Reflections

PLED Inspection





21.0 mm



PLED Thermography Comparison to X-ray CT of Ti-6Al-4V Disk

Nondestructive Evaluation Sciences Branch






PLED Single Side Inspection of Ti-6Al-4V Disk with Model Fit


Nondestructive Evaluation Sciences Branch

$$T(t, l) = \frac{(F_0 t \alpha)}{K l} + \frac{F_0 l}{K} \left(\frac{1}{3} - \frac{2}{\pi^2} \left(\sum_{n=1}^{nmax} \frac{-1^{2n}}{n^2} e^{\frac{-\alpha n^2 \pi^2 t}{l^2}} \right) \right) - \frac{(F_0 (t-t_0) \alpha)}{K l} - \frac{F_0 l}{K} \left(\frac{1}{3} - \frac{2}{\pi^2} \left(\sum_{n=1}^{nmax} \frac{-1^{2n}}{n^2} e^{\frac{-\alpha n^2 \pi^2 (t-t_0)}{l^2}} \right) \right) U(t - t_0)$$

Example Curve Fit to Model




- Quantitative Single Side Model-Based Thermal NDE is Possible with the PLED Heat Source, $\alpha = 0.022 \text{ cm}^2/\text{sec}$, literature thermal diffusivity value for solid Ti-6AL-4V is $0.029 \text{ cm}^2/\text{sec}$



Conclusions

- The PLED heat source has been demonstrated as a viable heat source for thermal inspection of low emissivity surfaces
- The PLED heat source advantage is the light is not observable with the mid-wave infrared camera
- Single sided model fit revealed good agreement to the data and therefore quantitative single side model-based thermal NDE is possible with the PLED heat source



Acknowledgements

Nondestructive Evaluation Sciences Branch

- William P. Sommers of the Nondestructive Evaluation Sciences Branch for the X-ray CT measurements
- James B. Bly for the heat source fabrication
- William B. Bretton for sample fabrication
- NASA Transformational Tools and Technologies Project and the Transformative Aeronautics Concepts Program for support of this work