

Biosynthesized Thermoplastic/Regolith Composites for Closed-Loop In-Space Manufacturing

Allison Christy, Ph.D.

ACS Fall 2026 Meeting

Advanced Polymeric Materials Branch

NASA Glenn Research Center, Cleveland, OH

Notice for Copyrighted Information

This manuscript is a work of the United States Government authored as part of the official duties of employee(s) of the National Aeronautics and Space Administration. No copyright is claimed in the United States under Title 17, U.S. Code. All other rights are reserved by the United States Government. Any publisher accepting this manuscript for publication acknowledges that the United States Government retains a non-exclusive, irrevocable, worldwide license to prepare derivative works, publish, or reproduce the published form of this manuscript, or allow others to do so, for United States government purposes.



Presentation overview

Overview of ISM system


PHB Crystallinity & Regolith as an In-situ nucleating source

Regolith/PHB Composite Development


LESTR Exposure

Next Steps

Overview of Closed-Loop ISM System




Manufacturing & Closing the Loop




- Manufacturing targets include consumables and outfitting supplies
- Fundamental materials data will guide additional applications
- Multiple routes of manufacturing expand versatility of system
- End-of-life recycling methods include bacterial fermentation and repolymerization, chemical, and mechanical recycling routes
- Closed-loop is key for sustained long-duration missions and reduction of waste



Regolith/Resin Composites




- Poly(hydroxyalkanoate)s (PHAs) are bacterially synthesized resins which offers route to in-situ manufacturing & reduced initial payload requirements for long-duration missions
- PHAs can use various sources of carbon (including waste products, CO_2 , polymers etc.) to create more material
- Poly(3-hydroxybutyrate) (PHB) is the most common PHA, but generally requires additives to improve performance & manufacturability due to high crystallinity
- PHB will be used as proof of concept for initial study, although other biosynthesized resins are also viable candidates
- Plant based, additive free PHB used for all samples





Regolith Simulant Candidates

- 5 candidate regolith simulants studied for materials screening from Space Resource Technologies
 - Mars Jezero Delta (JEZ-1)
 - Lunar Highlands (LHS-1)
 - Lunar Mare (LMS-1)
 - Lunar South Pole (LSP-2)
 - Mars Global (MGS-1)
- Design system for as many regions and potential applications as possible





Regolith as In-Situ Nucleating Agent




- PHB is highly crystalline with slow crystallization kinetics, narrow processing temperature
 - This makes material very brittle and processing challenging
 - Mineral additives have been used terrestrial to improve properties
- Could regolith particles be used as in-situ nucleating agents to reduce or control crystallinity?
 - Used compression molding to achieve up to 80 w/w% loading with sufficiently thin films for study




Regolith/PHB Composite Crystallinity – *Differential Scanning Calorimetry*





Regolith/PHB Composite Crystallinity – *Differential Scanning Calorimetry*




Regolith/PHB Composite Crystallinity – *Cross Polarized Optical Microscopy*




- Captures variations in crystal structure
- Hot stage attachment allows for real-time monitoring of crystallization
 - 20% regolith samples chosen for study




Regolith/PHB Composite Crystallinity – *Effect of Regolith Loading*



JEZ-1



LSP-2





20%


40%

80%

Regolith/PHB Composite Crystallinity – *Hot Stage Microscopy*




Neat PHB




20 % MGS-1


Regolith/PHB Composite Crystallinity – *Hot Stage Microscopy*




(a) Neat PHB




(b) 20% LMS-1




Regolith/PHB Composite Crystallinity – *Hot Stage Microscopy*



Crystallization Progress as a Function of Time





Crystallization Progress as a Function of Temperature



Regolith/PHB Composite Development


- Compression molding
 - High loading, high pressures
 - Inconsistent particle distribution
- Injection molding
 - High particle loading, consistent particle distribution
 - More complex shapes
- Extruding
 - Most consistent particle distribution
 - Lower particle loading
- Additive manufacturing
 - More complex shapes
 - Lower particle loading, thermal exposure




Injection Molded Composites

- Optimized processing profile for each material
- Increased viscosity at higher loadings






Injection Molded Composites – *Tensile Strength*



Injection Molded Composites – *Fracture Surface*



60% LHS-1


60% MGS-1




60% LMS-1

Extruding Composites




- Cooling sensitivity, particle size distribution, and narrow melt window presented challenges to manufacturing
- Successfully extruded filament using neat PHB, 10% and 20% LMS-1D, and began 40% MGS-1







Printing Filament

- Raise 3D Pro, direct drive extruder
- Custom print profile for neat PHB and composite filament
 - Best results with unheated print bed




Printing Filament – *Key Takeaways*

- Successfully printed neat PHB and composite filament
- Consistent filament diameter crucial
- Composite filaments prone to clogging or under extrusion
 - Nozzle size is limitation for larger particles



Lunar Environment Structural Test Rig (LESTR) Exposure


- LESTR capable of testing under simulated Lunar conditions, can cycle $\sim 40\text{K}$ to 125K
- Composite samples included as ride-alongs to assess effects of vacuum and cold temperatures on material
- Looking for signs of thermal stress:
 - Cracking
 - Embrittlement
 - Surface changes



Lunar Environment Structural Test Rig (LESTR) Exposure

- Injection molded and 3D printed samples tested
- Samples held at 12.0945 K and 7.37E-6 Torr for 24 h
- No signs of catastrophic failure or significant thermal stress

Before LESTR




Neat PHB

LSP-2 40%

After LESTR



Before LESTR



After LESTR




Sample #




Sample #5

Key Takeaways & Ongoing Work


- **Successful proof of concept!**
 - **Regolith as in-situ additive to improve PHB crystallinity**
 - **Multiple routes of manufacturing**
- **Type and amount of regolith affects the mechanical and thermal properties of composite**






Key Takeaways & Ongoing Work

- Successful proof of concept!
 - Regolith as in-situ additive to improve PHB crystallinity
 - Multiple routes of manufacturing
- Type and amount of regolith affects the mechanical and thermal properties of composite
- **Further process optimization, additive manufacturing improvement**
- **Compression, flexural, impact injection molding samples and testing**
- **Additional LESTR testing, environmental exposure evaluation**
- **Samples on MISSE-23 and MISSE-24 experiments for space exposure evaluation**




Next Steps


- Manufacturing complex parts and larger structures
- Development of bio-recycling and biosynthesis of resin from waste products
- Explore mechanical recycling methods
- Computational modeling to predict materials performance
- Create materials with bio-engineered PHAs
- Systems analysis



Acknowledgements


- Dan Scheiman, GRC, Thermal Data
- Laura Wilson & Rich Martin, GRC, Microscopy
- NASA STMD CIF program
- Mango Materials
- Frances Donovan & the NASA CUBES Team








Questions?





Backup Slides




Ultrasonic Welding for In-Situ Assembly and Repair







Future Work

Future Work:






- Optimize composite parameters for improved extrusion stability
- Explore lower regolith loadings & alternative simulants
- Investigate additives to tune PHB melt behavior
- Expand PHB printing trials into more complex geometries
- Continue environmental testing on printed parts













Conclusion



Conclusion




Neat PHB**20% MGS-1****20% LMS-1****20% LHS-1****20% JEZ-1****20% LSP-2**



JEZ-1



- Smallest average particle size
- Highest Mg, smallest Si content



LHS-1




30x



100x



150x




LMS-1





MGS-1



30x



100x



150x






Particle Size Distribution

Using a combination of laser and sieve analysis


JEZ-1 Particle Size Distribution



Particle Size Distribution

Using a combination of laser and sieve analysis


LHS-1 Particle Size Distribution



Particle Size Distribution


Using a combination of laser and sieve analysis

LMS-1 Particle Size Distribution



Particle Size Distribution


Using a combination of laser and sieve analysis



Particle Size Distribution

Using a combination of laser and sieve analysis


MGS-1 Particle Size Distribution





Particle Size Distribution

Using a combination of laser and sieve analysis






Particle Size Distribution

Using a combination of laser and sieve analysis

LHS-1 Particle Size Distribution






Particle Size Distribution

Using a combination of laser and sieve analysis


LMS-1 Particle Size Distribution





Particle Size Distribution

Using a combination of laser and sieve analysis





Particle Size Distribution

Using a combination of laser and sieve analysis

MGS-1 Particle Size Distribution

