

Evaluating Crystallinity in Thermoplastic Composites for Aerospace Applications

Allison Christy

ACS Fall 2026 Meeting

Advanced Polymeric Materials Branch

NASA Glenn Research Center, Cleveland, OH

Notice for Copyrighted Information

This manuscript is a work of the United States Government authored as part of the official duties of employee(s) of the National Aeronautics and Space Administration. No copyright is claimed in the United States under Title 17, U.S. Code. All other rights are reserved by the United States Government. Any publisher accepting this manuscript for publication acknowledges that the United States Government retains a non-exclusive, irrevocable, worldwide license to prepare derivative works, publish, or reproduce the published form of this manuscript, or allow others to do so, for United States government purposes.

1000µm



Presentation overview

Overview of Crystallinity in Thermoplastics


Carbon fiber/PEKK Composites

Regolith/PHB Composites for In-Space Manufacturing

Key Takeaways

Next Steps

Role of Crystallinity in Thermoplastics



Highly crystalline regions have...

- Increased storage modulus
- Increased chemical resistance
- Increased stiffness and strength
- Increased heat deflection temperature

Amorphous regions have...

- Increased flexibility
- Optical transparency
- Decreased shrinkage
- Increased gas permeability


Factors Affecting Crystallinity

1. Chemistry and tacticity
2. Polymer structure
3. Mechanical stress and force
4. Thermal processing


● = monomer unit




linear polymer chain




branched polymer chain




isotactic




syndiotactic



atactic



**Poly(etherketoneketone)
(PEKK)**



**Poly(3-hydroxybutyrate)
(PHB)**

Factors Affecting Crystallinity

1. Chemistry and tacticity
2. Polymer structure
3. **Mechanical stress and force**
4. **Thermal processing**





Figure 3.4 Cooling behaviour of materials



Crystallinity is Complex & Composites are Difficult to Evaluate

Varied
cooling
rates and
stress
exposure




Varied
crystallinity
profile, varied
composite
properties

Conventional Methods to Evaluate Polymer Crystallinity







***X-Ray Diffraction
(XRD)***




***Differential Scanning
Calorimetry (DSC)***

Polarized Light Optical Microscopy and Fourier Transform Infrared (FTIR) Spectroscopy






Differential Scanning Calorimetry of PEKK Resin




$$X_c = \frac{\Delta H_m}{\Delta H_{100\%}} \times 100$$



Sample	X_c (%)
Quenched	11.75
2.5 deg/min	22.28
5 deg/min	27.35
10 deg/min	28.32
20 deg/min	27.14

Fourier Transform Infrared (FTIR) Spectroscopy








Fourier Transform Infrared (FTIR) Spectroscopy – Crystallinity Index




- 962 consistent with aromatic bending, susceptible to crystallinity changes
- 957 corresponds to C-O-C backbone



Fourier Transform Infrared (FTIR) Spectroscopy – Crystallinity Index




- 1305 corresponds to carbonyl, should increase with higher crystallinity
- 1280 is diphenyl ether groups in backbone and shouldn't change with crystallinity




- Generally, saw good agreement with DSC and FTIR data, except for the SC sample
- SC has the largest crystallites, should be the most crystalline – FTIR captured this more effectively than DSC
- Additional experimental validation in progress

Differentiating Crystallites





Quenched
 X_c : 11.75%




Slow Cooled
 X_c : 21.32%

Differentiating Crystallites




Slow Cooled PEKK

Self nucleated, spherulite dominated




Quenched PEKK



**Quenched PEKK
+ Annealed 1h 225°C**


*CF nucleated, transcrystalline
dominated*

Crystallinity in Ultrasonically Welded Films




- Overall trend captured in SC and Q samples
- Data between DSC and FTIR for annealed samples differed – compared to optical microscopy


Before
welding



Slow Cooled PEKK: no loss of crystallinity, consistent with both FTIR and DSC data





Quenched PEKK: no change in crystallinity, consistent with FTIR and DSC data




Annealed PEKK: loss of crystallinity in weld area, trend captured by FTIR, not DSC – more sensitive to regional variations


After
welding




Crystallinity in Ultrasonically Welded Films



- Key takeaways from initial study: amorphous material much better for ultrasonic welding
- Variations in crystallinity are not always captured by DSC – this is important because crystallinity directly impacts weld strength




Ultrasonically Welded Prepreg w/ Energy Directors




- Lap shear strength stronger when amorphous material is used as an energy director
- Welding crystalline material proved to be challenging, required higher pressures/longer duration – in many cases welding was not possible
- Welding parameters could be further optimized

Hot Stage Microscopy – PEKK


Starting crystallinity




T = 0 min, 390°C




Nucleation
T = 6 min, 270°C




T = 8 min, 230°C



T = 11 min, 170°C



T = 15 min, 90°C




Hot Stage Microscopy Key Takeaways & Ongoing Work


- *Key takeaways:* Self nucleated crystallinity can be efficiently tracked with hot stage microscopy; thick films made it challenging to resolve single layers; PEKK much easier to visualize than LM-PAEK
- *Ongoing work:* Repeating experiment with thinner films, higher resolution, and various cooling rates; experiments with CF embedded films to evaluate fiber nucleation/transcrystallinity; use kinetics/modeling to guide processing




Regolith/PHB Composites




- Poly(3-hydroxybutyrate) (PHB) is a bacterially synthesized resins that use various sources of carbon (including waste products, CO₂, polymers etc.) to create more material
- PHB is highly crystalline but crystallizes very slowly
 - Poor mechanical performance
 - Poor processability





Regolith/PHB Composites






- Poly(3-hydroxybutyrate) (PHB) is a bacterially synthesized resins that use various sources of carbon (including waste products, CO₂, polymers etc.) to create more material
- PHB is highly crystalline but crystallizes very slowly
 - Poor mechanical performance
 - Poor processability
- **Can we use regolith to alter PHB crystallinity?**
- **Does this play a role on material performance?**




Composites with 20 wt% Regolith





Regolith/PHB Composite Crystallinity – Bulk Behavior




Regolith/PHB Composite Crystallinity – *Cross Polarized Optical Microscopy*




- Captures variations in crystal structure
- Hot stage attachment allows for real-time monitoring of crystallization
 - 20% regolith samples chosen for study




Regolith/PHB Composite Crystallinity – *Effect of Regolith Loading*



JEZ-1



LSP-2





20%


40%

80%

Regolith/PHB Composite Crystallinity – *Hot Stage Microscopy*




Neat PHB




20 % MGS-1


Regolith/PHB Composite Crystallinity – *Hot Stage Microscopy*






(a) Neat PHB




(b) 20% LMS-1



Regolith/PHB Composite Crystallinity – *Hot Stage Microscopy*




Regolith successfully increased rate of PHB crystallization and decreased overall crystallinity – could be used as in-situ additive!




Key Takeaways

- Assessing the crystallinity of thermoplastic composites is important to produce materials with optimal performance
- DSC is an effective tool for gathering bulk crystallinity profiles; FTIR and POM are effective for analyzing regional variations
- Regolith simulants can be used as an in-situ additive used to vary crystallinity




Key Takeaways & Next Steps

- Assessing the crystallinity of thermoplastic composites is important to produce materials with optimal performance
- DSC is an effective tool for gathering bulk crystallinity profiles; FTIR and POM are effective for analyzing regional variations
- Regolith simulants can be used as an in-situ additive used to vary crystallinity
- **Obtain WAXS and SAXS and compare to other methods**
- **Conduct broader study on the effects of crystallinity on weld strength and performance for in-situ repair**
- **Use fundamental data to guide modeling efforts for predicting material performance**




Questions?





Backup Slides

Polymer Composite Use in Aircraft

Materials used in Boeing planes





Boeing 787 Dreamliner skin structure




- Thermoset composites are cured in an irreversible reaction using autoclave process
 - *Slow and energy intensive manufacturing and complex repair*
- Thermoplastic composites are consolidated at higher temperatures using compression molding in reversible transition
 - *Potential for efficient repair and increased manufacturing speeds*



Crystallinity on Ultrasonically Welded Samples



US Annealed









US Slow Cooled




US Quenched


Cross Polarized Light Optical Microscopy




Hot Stage Microscopy – LM-PAEK




T = 0 min, 310°C



T = 5.5 min, 200°C



T = 9 min, 130°C



- Much smaller crystallites, thicker sample
- Will explore using slower cooling speeds and thinner samples to improve resolution

Regolith/PHB Composite Development

- 5 candidate regolith simulants studied for materials screening from Space Resource Technologies
 - Mars Jezero Delta (JEZ-1)
 - Lunar Highlands (LHS-1)
 - Lunar Mare (LMS-1)
 - Lunar South Pole (LSP-2)
 - Mars Global (MGS-1)
- Design system for as many regions and potential applications as possible

