

General Disclaimer

One or more of the Following Statements may affect this Document

- This document has been reproduced from the best copy furnished by the organizational source. It is being released in the interest of making available as much information as possible.
- This document may contain data, which exceeds the sheet parameters. It was furnished in this condition by the organizational source and is the best copy available.
- This document may contain tone-on-tone or color graphs, charts and/or pictures, which have been reproduced in black and white.
- This document is paginated as submitted by the original source.
- Portions of this document are not fully legible due to the historical nature of some of the material. However, it is the best reproduction available from the original submission.

Future Development-The PHE Improvement Study

Space Gateway Support
Propellants Engineer
Kenneth Ahmie

Introduction

- SGS recently completed a study for the KSC Propellants and Life Support Office.
- The study covered the technical relevance and feasibility of user recommended upgrades to improve user operability and safety of the Propellant Handlers Ensemble.
- This presentation will review the results of the study.

Background

- KSC established priority study topics
 - Tackiness
 - Dexterity / Agility
 - Suit Relief Valve
 - Visibility
 - Sizing
 - Electrostatic Discharge (ESD)



Tackiness

- Anti-static spray is used to control electrostatic discharge.
- Anti-static spray leaves tacky residue on fabric, gloves, and communication cable.
- Anti-static spray changed to a water based spray to eliminate tacky condition.

Tackiness

- Liquid hydrazine leaves a viscous residue on butyl rubber gloves.
- Condition is eliminated by a water wash.
- Atmospheric carbon dioxide reaction with hydrazine producing carbazic acid


Dexterity / Agility

- Unable to relocate Disconnect
- Disconnect is rigid
- Gloves are cumbersome
- Suit is heavy, fabric gathers at the legs
- Suit is too large / too small
- Sleeves and legs are too long / too short




Dexterity / Agility

- Gloves are not tactile
- PHE is cumbersome
- Thick gloves are required.
- Training improves performance




Dexterity / Agility

- A Flexible Cuff with a larger inside diameter is being considered.
- Adding another suit size improves fitting.



Relief/Exhaust Valves

- Maintains positive pressure in suit
- Deep squatting can lead to Negative pressure
- Require Faster closing response
- Test Bed
 - Model actual conditions
 - Exhaust mode
 - Reverse flow
 - Static



Results

	Exhaust PPM/MIN	Reverse Flow PPM	Static PPM/SEC
Relief Valve A	5	2	1
Exhaust Valve B	1	1	5
Exhaust Valve C	2	5	3
Exhaust Valve D	3	3	2
Exhaust Valve E	4	4	4

Visibility

- Visor Materials
 - Polyvinyl Chloride, Bubble contour
 - Polycarbonate with hardcoat, single plane curvature
- Hood
 - Stove Pipe Configuration
 - Fabric Construction
 - Communication system with microphone




Visibility

- Surface scratches produced glaring
 - Soft covers reduced scratches and glare
- Reduced visibility; horizontal / vertical
 - Correct suit size reduces visibility issue
- ESD- visor materials are insulative
 - Anti-static spray non-compatible
- ESD is still a concern.




Sizing

- PHE is designed to 1970 Military data
- KSC conducted anthropometric survey plus opinion survey
- User physical attributes changed
- Identified PHE misfit characteristics
- Identified most used sizes



Sizing

- Patterns photographed, scanned, validated
- Pattern Modification
 - Back Pack & Hood
- Fit Testing
- Corrected 75% of issues..



ESD

- Antistatic Spray in use presently
- ESD Coating using Nanotechnology
- ESD event during biomedical test
- Understand ESD (ESPL)
- Test select fabrics
 - Resistance Test
 - Charge Decay
 - Surface Potential

ESD

- ESD Events
- Spark Incendivity

Summary

- The results of this study will be used by KSC to provide a basis for upgrades that will enhance user operability and safety in future versions of the Propellant Handlers Ensemble or implemented as “drop-in” improvements to the existing Propellant Handlers Ensemble inventory.