

TEM Analysis of Interfaces in Diffusion-Bonded Silicon Carbide Ceramics Joined Using Metallic Interlayers

¹ T. Ozaki

² H. Tsuda

³ M. C. Halbig

⁵ M. Singh

¹ Y. Hasegawa

² S. Mori

⁴ R. Asthana

¹Technology Research Institute of Osaka Prefecture, Osaka, Japan

²Osaka Prefecture University, Osaka, Japan

³NASA Glenn Research Center, Cleveland, Ohio, USA

⁴University of Wisconsin-Stout, Menomonie, WI, USA

⁵Ohio Aerospace Institute, Cleveland, Ohio, USA











outline

1. Introduction

properties and applications of SiC

2. Sample preparations used for diffusion bonding

Substrates : SA-Tyrannohex ™ (SA-THX)

Interlayers: Ti-Mo foil

3. Experimental results

TEM and STEM images of substrates (SA-THX)

TEM and STEM images of diffusion bonded samples

4. Discussion about the microstructure of the formed phases by diffusion bonding

the orientation relation between the precipitated TiC and Mo-Ti (SS)

5. Summary





SiC is an attractive material

(high-temperature, extreme environment applications)

- 1. Excellent mechanical properties
- 2. Good oxidation resistance
- 3. High thermal stability

Developed for wide range uses

(not only as a monolithic material, but also in composites)

- 1. monolithic materials injector applications
- composites materials combustion liner, nuclear and fusion reactor, turbine engine applications





However, geometrical limitations hinder the wide use of SiC. It is difficult to fabricate large, or complex shaped components by Hot Pressing or CVD.


Therefore, new advanced methods are needed.


Under those circumstances, one cost-effective solution for fabricating large, complex-shaped components is the joining of simple shaped ceramics.


In this study, we are going to focus on diffusion bonding.

Mismatch of elastic modulus (E) and coefficient of thermal expansion (CTE; α) between substrate and interlayer

We have to pay attention to mismatch of elastic modulus and CTE when we select interlayer material to join SiC.








Both E and CTE of Mo is closer to SiC than that of Ti.

- Ti and Mo have been used to join α SiC.
- Better quality bonds formed with Mo than with Ti. But,
- Ti can lower the diffusion bonding temperature.

Therefore, **Ti-Mo** bilayer that possesses both advances of Ti and Mo is also very attractive.

Therefore in this work, we utilize Ti-Mo as interlayers.

Diffusion Bonding of a SA-THX using Ti/Mo metallic Interlayers



Used sample

@NASA


<u>SA-THX</u> ...SiC fiber-bonded ceramics, UBE Industries Ti-foil Mo-foil

Bonding structure

SA-THX // 10µmTi-12.5µmMo-10µmTi // SA-THX


Bonding process

Hot-press in 1200°C, 4hour, vacuum 30MPa




M.C. Halbig, et. al., Ceramics International41(2015)2140–2149


Until now, the phases formed during diffusion bonding have been studied (to join SiC-SiC using Ti interlayer)



Unfortunately, there has been little literature on TEM observation of the phases formed during diffusion bonding.

Because, it seems very hard to prepare TEM sample from the bonded area. However, recently we successfully obtained a clean, less-damaged, and precisely selected thin specimen from diffusion bonds by using an FIB.









Objectives

We diffusion bonded SiC and SiC (<u>SA-THX</u> and <u>SA-THX</u>)
using <u>Ti-Mo foil metallic</u> interlayer.
We carried out <u>TEM and STEM observations</u> with the diffusion bonded sample <u>prepared by FIB technique</u>.

- 1. Evaluate microstructures of the diffusion bonded SA-THX by TEM and STEM.
- 2. Characterize the complex microstructure in the diffusion bonded area by TEM observation and SAED analysis.

FIB and Cs-corrected STEM

Focused Ion Beam, FIB

(Hitachi FB-2200)

Cs-corrected STEM (Hitachi HD-2700)





Prepared thin samples for TEM and STEM.

Checked the thin samples prepared by FIB.

Three-Observation mode:


SEM, **BF-STEM** and **HAADF**








Fabricating procedure of the thin sample (SIM image obtained by FIE





SEM

image


HAADF

image

BF-STEM

image


STEM observation of the FIB sample (HD-2700)






STEM observation of the FIB sample (HD-2700)

Position 1 (SiC-reaction layer)






Ti3SiC2 phase ----- Some voids exist.


SA-THX phase ----- Some precipitations (secondary phase) exist.






STEM images (obtained from SA-THX area.)








Only in <u>HAADF</u>-image, the contrast is observed clearly.


⇒The precipitations is light element.
(probably carbon)




STEM images (obtained from SA-THX area.)

near the boundary of the SA-THX fiber









away from the boundary of the SA-THX fiber







SA-THX forming process


SA-THX forming process




Under high pressure & high temp. In hot press



Deforming fibers & Evaporating SiO and CO gas




Closed-pack hexagonal columnar structure



Diffusion transports carbon from the center of fibers to its surface



Unique SA-Tyrannohex structure




SEM microstructure of SA-TX surface

SA-THX has been developed by Dr. T. Ishikawa et al. T. Ishikawa et al, *Science*, 282, 1295-1297 (1998). T. Ishikawa et al, *Nature*, 391, 773-775 (1998).

Also, SA-THX is consisting of a highly ordered, closed-packed structure of very fine hexagonal columnar fibers, with a thin interfacial carbon layer between the fibers. The interior of the fiber element was composed of sintered crystalline β-SiC.

These precipitations stem from residual carbon in SA-THX forming.

Position 1 (SiC-reaction layer)



The precipitations are not observed in the reaction layer.

The precipitations don't affect diffusion bonding quality a lot?




Let's Try with TRI!


Objectives


We diffusion bonded SiC and SiC (<u>SA-THX</u> and <u>SA-THX</u>)
using <u>Ti-Mo foil metallic</u> interlayer.
We carried out <u>TEM and STEM observations</u> with the diffusion bonded sample <u>prepared by FIB technique</u>.


- 1. Evaluate microstructures of the diffusion bonded SA-THX by TEM and STEM.
- 2. Characterize the complex microstructure in the diffusion bonded area by TEM observation and SAED analysis.

TEM image and SAD patterns of diffusion bond (Ti-Mo foil) @CMCEE11












STEM image of diffusion bond









coarse and fine TiC pillars




TEM image and SAED patterns of TiC pillar






Schematic image of the location of TiC in [Mo-Ti]ss matrix.





The TiC pillars point to almost <100> direction.




the relation of the crystallographic orientation between Mo-Ti and TiC









R.G. Baker and J. Nutting, Precipitation Process in Steels, I.S.I. Special report, No. 64 (1959).



Let's Try with TRI!

Summary

- ➤ 1. We picked up thin samples from the bonded area of diffusion bonded SA-THX by a FIB micro-sampling technique. The prepared thin samples were sufficiently thin and less-damaged, and allowed the detailed evaluation by TEM and STEM.
- ➤ 2. Submicron-sized carbon precipitations were observed in the SA-THX phase away from the boundary of SA-THX fiber. These precipitations did not exist in the reaction phase. It indicates that these precipitations will not affect the diffusion bonding quality a lot.
- ➤ 3. TiC pillars were observed around the reaction layer which has a complicated microstructure. The TiC had an orientation relation with the matrix Mo-Ti(SS). In observing from [100]_{Mo-Ti}//[011]_{TiC} incidence, TiC and Mo-Ti were located in almost (002)_{Mo-Ti}//(002)_{TiC} relation. It should be considered that precipitated TiC and matrix Mo-Ti has Baker-Nutting's relation that is often seen when NaCl-type material precipitates in a matrix of bcc-type materials.