
Electric Motor Noise from Small Quadcopters Part I – Acoustic Measurements



Motivation



- Electric motors driving small Unmanned Aircraft Systems (sUAS) propulsors.
- Noise expected to be problem, especially for Urban Air Mobility (UAM) missions.
- Noise sources need to be understood (propeller, motor, etc.).
- Need noise prediction methods for electric motors.





Companion paper in this session will present source characteristics.


Future work will focus on larger motors.



Experimental Setup









NASA

Motor & Propeller With Tether



NASA

Motor Only With Tether






Test Matrix

	3DR "Blue"	2212	2312
Speed Variation (RPM)	4380, 5370, 6260	4380, 5370, 6260, 4773	4380, 5370, 6260, 4773
Acoustics (Small, Medium, Large Arrays)	X	X	X
Speed Controllers E300 3DR 420S	X X -	X X X	X - X
Load Motor Only 2-Bladed 3-Bladed	X X -	X X -	X X X
Phased Array	X (location study)	X	X
Current Probe	2 loops	1 loop	1 loop
Ping Test	X	X	X
Motor kV Constant (RPM/Volt)	850	920	960
		M 2312/9	60KY




Background Noise



- Motor-only SPL comparisons for three motors, microphone 9 on medium array, 4380 RPM.
- Noise floor from 1/4-inch microphones, not chamber


3DR Motor Spectra, 5370 RPM






2212 Motor Spectra, 5370 RPM






2312 Motor Spectra, 5370 RPM








3DR Motor Only vs With Propeller, 5370 RPM





SPL Directivity, 5370 RPM




NASA


Phased Microphone Array

Normal to Motor










Microphone 2 used for phased array acoustic spectra is located toward the center





3DR Motor Only vs With Propeller, 5370 RPM







3DR Motor Only vs With Propeller, 5370 RPM Phased Array, 2050 Hz












Motor Only




3DR Motor Only vs With Propeller, 5370 RPM Phased Array, 4638 Hz












Motor Only




3DR Motor Only vs With Propeller, 5370 RPM Phased Array, 5029 Hz












Motor Only




3DR Motor Only vs With Propeller, 5370 RPM Phased Array, 5469 Hz












Motor Only




3DR Motor Only vs With Propeller, 5370 RPM Phased Array, 6250 Hz












Motor Only




3DR Motor Only vs With Propeller, 5370 RPM Phased Array, 7520 Hz












Motor Only




3DR Motor Only vs With Propeller, 5370 RPM Phased Array, 7617 Hz










Motor Only




2312 Motor Only vs With Propellers, 5370 RPM Phased Array, 5029 Hz






Motor Only




-Mic 7 -Phased Array

Two-Bladed Propeller




Three-Bladed **Propeller**







2312 Motor Only vs With Propellers, 5370 RPM Phased Array, 6250 Hz




Motor Only



Two-Bladed Propeller



Three-Bladed **Propeller**



Conclusions



- Tones are most important noise source.
- Motor noise peaks in a direction normal to the motor rotor axis.
- Adding a propeller introduces shaft order/blade passing frequency tones, and higher harmonics that are evident up to about 4000 Hz.
- Propeller increases the broadband noise across the entire spectra.
- Strong motor tones can be amplified by the propeller loading by 5 to 15 dB and can exceed the propeller noise levels.
- A phased microphone array provides acoustic spectra that are in good agreement with far field microphone data.
- Beamform images successfully distinguish motor and propeller noise contributions.



This work was supported by NASA's Revolutionary Vertical Lift Technology (RVLT) project in the Advanced Air Vehicles Program.